

# **T700 PROGRAMMING SOFTWARE**

PGM700 Version 3.05

USER'S GUIDE

Copyright 1996  
All rights reserved

TAIT ELECTRONICS LTD.  
CHRISTCHURCH,  
NEW ZEALAND.

IPN 438-70010-04



## TABLE OF CONTENTS

1. Introduction	Page
1.1 PGM700 package	4
1.2 Features of PGM700 Version 3.05	4
1.3 Requirements	5
1.4 Typographic Conventions	5
2. Before you start	
2.1 Making a back-up	6
2.2 Installing PGM700	6
2.2.1. Installing PGM700 on a hard disk	6
2.3 Setting up PGM700	6
3. Getting started	
3.1 A short example	8
3.1.1 To start PGM700	8
3.1.2 Information required	10
3.1.3 To enter data	11
3.1.4 To save data	13
3.1.5 To load data	14
3.1.6 To program radio	14
3.1.7 To print data	15
3.2 What you have achieved	16

	Page
4. Menu Commands	17
4.1 Disk menu	19
4.1.1 Load a file	19
4.1.2 Save a file	19
4.2 Radio menu	20
4.2.1 Read radio data	20
4.2.2 Program radio data	20
4.3 Edit menu	21
4.3.1 Radio specification	21
4.3.2 Radio Options	23
4.3.3 Channel Data	25
4.3.4 Memory key storage	26
4.3.5 Group Options	27
4.3.6 Group Membership	27
4.3.7 Group Parameters	27
4.3.8 Selcall Setup	29
4.3.9 Selcall Identity	30
4.3.10 Selcall Options	31
4.3.11 Low Current Repeater options	35
4.4 Utility menu	35
4.4.1 Clear/new	35
4.4.2 Print	35
4.5 Quit menu	35
5. Error and Warning messages	36
Appendix A Screen Colour Configuration	41
Appendix B Using PGM700 with older radios	43

## Chapter 1

### 1 **Introduction**

#### 1.1 **PGM700 Package**

PGM700 is a comprehensive software package designed to allow easy programming of TAIT T700 series mobile radios.

The radio models supported by PGM700 are:

Type	Frequency Band
T720	66-88 MHz
T730	136-174 MHz
T750	400-520 MHz

The menu driven environment is easy to use and offers great flexibility to the user. Moving between menus and within menus using the cursor keys is simple. Help information is available at every step if required.

#### 1.2 **Features of PGM700 Version 3.05**

PGM700 version 3.05 includes all the features that were introduced in version 3.02, along with a new screen for the Low Current Repeater option.

The key PGM700 features are outlined below:-

- \* Full support for different display adaptors. Automatic detection of colour or monochrome adaptors and user configurable colours.
- \* Faster data entry with full cursor control when editing and automatic simplex entries for new channels.
- \* Programming of voting and scan groups. Up to 16 scan or voting groups can be defined.
- \* Programming of radio options. Options such as hookswitch monitoring, BCD channel selection and status functions are easily programmed.
- \* Memory key storage. Memory keys can be programmed to channels, groups or selective calling identity numbers. The keys can also be write protected so they cannot be erased by the user.

- \* Channel Access. Permitting the user to access channels and define their own scan groups can easily be programmed.
- \* Selective calling programming. All parameters and options for the Tait T700-30 signalling package can be programmed.
- \* Low current repeater programming. Enables you to set how the radio operates in low current repeater mode.

NOTE: The data files produced by earlier versions are still compatible with PGM700 Version 3.05.

To be able to utilize all the new features that PGM700 offers, you will need a radio that carries Version 3 software or later.

### 1.3 Requirements

The basic requirements to use PGM700 are:

- \* IBM PC, XT, AT or true IBM compatible computer.
- \* 256 Kbytes of RAM.
- \* DOS version 3.0 or higher.
- \* Any 80-column monitor (monochrome, colour, LCD or Plasma).
- \* One floppy disk drive, although a hard disk with a floppy drive is recommended.
- \* A radio programming lead.

To take full advantage of PGM700's features, a printer is also recommended.

### 1.4 Typographic conventions

All typefaces used in this manual have the following uses:

- < >      Angle brackets in text or on DOS command lines show the KEY to push. TEXT of this sort should not be typed verbatim.
- Underline represents text you must type (such as command-line).
- " "      Double quotes represent text as it appears on screen.

## Chapter 2

### 2 **Before you Start**

#### 2.1 **Making a Backup**

The original PGM700 program disk is formatted for double-sided, double-density disk drive and can be read by IBM PCs and close compatibles.

You should make a complete working copy of the original PGM700 program disk, then store the original disk in a safe place. Your computer's DOS manual will explain how to use the disk copy command supplied with your computer.

#### 2.2 **Installing PGM700**

Your PGM700 disk contains all the programs necessary to program your T700 radios.

##### 2.2.1 **Installing PGM700 on a hard disk**

If you wish to install PGM700 and its support programs onto your hard disk (e.g. drive C), the following steps can be used, otherwise go straight to section 2.3:

- Step 1: Have the DOS prompt for your hard disk on the screen e.g. "C:>" or type `c:` <ENTER>
- Step 2: Change into the root directory by typing `cd \` <ENTER> at the DOS prompt. Create a new subdirectory by typing `md T700` <ENTER> and go into the subdirectory by typing `cd T700` <ENTER>
- Step 3: Put your floppy disk carrying the programming software in floppy drive A and type: `copy a:PGM700*.*` <ENTER> and you should have at least two files copied across namely "PGM700.EXE" and "PGM700CF.EXE".
- Step 4: Remove the floppy disk and store it in a safe place.

#### 2.3 **Setting up PGM700**

The colours used by PGM700 are user configurable. The default colours are set to black and white, so that PGM700 can be used on monochrome, colour, LCD or plasma screen of your computer.

If you have difficulty reading text or dislike the colours used by PGM700, you can use the configuration program (PGM700CF) to change the colours. (See Appendix A for instructions).

## Chapter 3

### 3 Getting Started

#### 3.1 **A short example**

Now you have installed PGM700 on your system, you are ready to start programming. At this point, it is appropriate to find out a few basics, for instance: how to start PGM700, how to enter data, how to save the data and how to use PGM700 to program a radio with the entered data.

Brief explanations on how to use PGM700 to perform a simple example will be given. For a comprehensive explanation of the whole PGM700 menu system, please refer to chapter 4 of this guide.

##### 3.1.1 **To start PGM700**

To start the PGM700 program, follow the directions below:

To start PGM700 from a floppy diskette:

Step 1: Have the DOS prompt for drive A on the screen and put the PGM700 program disk (working copy) in drive A.

Step 2: Type the following commands

A: PGM700 <ENTER>


To start PGM700 from a hard disk:

Step 1: After the DOS prompt type cd T700 <ENTER> to change to the correct sub-directory, then type PGM700 <ENTER> to start the program.

When it starts up, PGM700 looks for a file called PGM700.CNF in the current directory. This file contains the screen display colours which PGM700 will use. If the file is not found, PGM700 will use its default colours. When you are working on a particular monitor, it is useful to have a copy of PGM700.CNF which contains the colours that suit your personal preference.

Note: PGM700 will use the colours defined in the PGM700.CNF regardless of the colour adapter used in your computer. In other words, if you have difficulty reading the text on the screen, it is likely that the PGM700.CNF in your current directory was configured for a different display adapter. In this case, you could just exit from PGM700, delete PGM700.CNF and restart PGM700. It should now default to black and white only.

After starting the program, the title screen will be displayed. It shows the version number, date and copyright information for the software. Pressing any key will cause the main menu bar of PGM700 to appear as shown in Figure 1.0. You are now set to go.



.. press any key ..

**Figure 1.0 Title page of PGM700**

Disk Radio Edit Utility Quit

load a file save a file
----------------------------

**Figure 2.0 Main menu of PGM700**

### 3.1.2 Information required

The remaining sections of this chapter will provide a step by step demonstration of how to use PGM700. This encompasses:

- how to enter data
- how to save data in a file
- how to load an existing data file
- how to program a radio

The following information is supplied to program a T750 radio:

Radio model	T750
Synthesiser reference frequency	10 kHz
Control head	Standard
Transmit timer	50 sec.
No. of channels	3

The Selcall, Scan, Low Current Repeater and Voting features will not be used in this demonstration.

The following data is to be programmed into the corresponding channels:

#### Channel 1:

Receive frequency	400.05 MHz
Transmit frequency	400.05 MHz
Transmit power	High
Front panel display	01

#### Channel 2:

Receive frequency	400.10 MHz
Transmit frequency	406.10 MHz
Receive CTCSS frequency	114.8 Hz
Transmit CTCSS frequency	114.8 Hz
Transmit power	High
Front panel display	02

Channel 3:

Receive frequency	404.0 MHz
Transmit frequency	404.0 MHz
Transmit power	Medium
Front panel display	03

A hard copy of the channel information is required and the data is to be stored on disk under the name "T700DEMO.DAT".

3.1.3 **To Enter Data**

To enter radio specifications.

- \* Use the →← cursor keys to invoke the 'Edit' menu from the menu bar, select "radio specification" and press <ENTER> to bring up a form titled "radio specification". A list of radio models the PGM700 supports will also be presented to you to choose from as shown in Figure 3.0.

< RADIO SPECIFICATIONS >	
Radio model	
Synth. freq	0.00 kHz
Control head	STANDARD
Tx timer	60 sec
Channels	1
Scan/Voting	0 groups
Selcall active	N
Low current repeater <Y/N>?	N

<RADIO SELECTION
T720
T730
T750
T758

Select the radio type with ↑↓ cursor, then [ENTER]

**Figure 3.0 Radio Specification data entry form**

- \* Use the ↑↓ cursor keys to select "T750" and press <ENTER>. PGM700 will automatically type in "T750" in the radio model field as well as the default synthesiser frequency which is 12.5 kHz for T750.

- \* With the cursor in the "Synth. freq" field, type 10 <ENTER>. The cursor will move to the next field.
- \* Leave the control head as standard by pressing <ENTER>.
- \* Type 50 <ENTER> for maximum Tx timer of 50 seconds.
- \* Type 3 <ENTER> to indicate 3 channels to be programmed.
- \* Press <F10> to go back to the main menu as Selcall, scan and voting features are not used in this demonstration.

For data entry, <DEL> deletes a character in the current field and <F3> erases the entire contents of the current field.

NOTE: PGM700 Version 3.05 only gives menus that are relevant to the current setting. Specifying a control head other than standard, having any scan or voting groups or activating the selcall option will invoke the appropriate sub menus in the edit menu. These are not required for this example and are covered in detail in Chapter 4.

#### To Enter Channel Data

- \* choose the "channels" command from the EDIT menu. A form filled with zeros and default data where appropriate will be displayed.
- \* It is not necessary to type in trailing zeros.
- \* Type 400.05 and press <ENTER> for Rx frequency of Channel 1, the cursor will move to the Tx field and fill in 400.05 automatically. This feature speeds up the data entry for simplex channel operation.
- \* Press <ENTER> to accept 400.05 MHz for Tx frequency.
- \* Press <ENTER> to ignore CTCSS Rx frequency.
- \* Press <ENTER> to ignore CTCSS Tx frequency.
- \* Press <ENTER> to accept the transmit power as high
- \* Press <ENTER> to accept the default display code.

- \* Type 400.I and press <ENTER> for Rx frequency channel 2. Again the cursor will move to the Tx field and fill 400.I0 automatically.
- \* Type 406.I and press <ENTER> for Tx frequency
- \* Press <F1> for help, this will cause a list of valid CTCSS frequency to be displayed. Use the  $\uparrow\downarrow$  keys to choose "14.8" from the list and press <ENTER>. PGM700 will automatically type 14.8 into both the CTCSS Rx and Tx field.
- \* Press <ENTER> to accept 14.8 for CTCSS Tx frequency or repeat the step above to get a different tone for CTCSS Tx.
- \* Press <ENTER> to accept the transmit power as high.
- \* Press <ENTER> to accept the display code
- \* Type 404.0 and press <ENTER> for Rx frequency of channel 3.
- \* Press <ENTER> to accept the Tx frequency.
- \* Press <ENTER> to ignore CTCSS Rx frequency.
- \* Press <ENTER> to ignore CTCSS Tx frequency.
- \* Type M and Press <ENTER> to set transmit power to medium.

Press <F10> to accept all the data entered and to return to the main menu.

NOTE: Also in the edit menu there is a radio options sub menu which deals mainly with the radio's monitoring conditions. The default settings are sufficient for this example. These options are covered in detail in Chapter 4.

### 3.1.4 **To save data**

To save data on disk.

- \* Use the  $\rightarrow\leftarrow$  cursor keys to invoke the disk menu from the main menu bar, select "save a file" and press <ENTER>. PGM700 will then prompt you for the name of the file to which you want to save the entered data.
- \* Type T700DEMO.DAT and press <ENTER>
- \* A message "writing data to disk, please wait" will be displayed while the data is being written to T700DEMO.DAT and then it returns to the main menu.

In order to demonstrate how to load a file from disk into PGM700 the entered data is to be cleared.

To clear data in PGM700

- \* Use the →← cursor keys to invoke the utility menu from the main menu bar then select "clear/new" and press <ENTER>, PGM700 will then clear all the entered data. At this point, it is as if PGM700 has just been started.

### 3.1.5 To load data from disk

- \* Using the →← cursor keys to invoke the disk menu from the main menu bar, select "load a file" and press <ENTER>. PGM700 will then prompt you for the name of the file which you would like to load.

NOTE: If you have earlier specified a file, PGM700 will automatically type the name. This name can be accepted by pressing enter or a new file may be specified.

- \* Type T700DEMO.DAT and press <ENTER>
- \* A message "reading file from disk" will be displayed briefly while the data is being read from T700DEMO.DAT followed by "file has been successfully read" if the reading is successful. Pressing any key will take you back to the main menu.

To check that the data loaded is correct.

- \* Use the →← cursor keys to invoke the edit menu from the main menu bar, select the "Radio Specifications" option and press <ENTER>. The radio specification form will be displayed. The data should be correct.
- \* Press <F10> to go back to the main menu.

### 3.1.6 To program radio

- \* Use the →← cursor keys to invoke the radio menu from the main menu bar, select the "Program Radio" option and press <ENTER>. A message "Validating all data" will briefly be displayed while PGM700 checks that all the data is valid. PGM700 will then prompt you for the communication port number to which the radio will be connected. Select "Com Port # 1" and press <ENTER>.

- \* Connect a T750 radio to communication port # 1 of your computer with the lead provided, power up the radio and press any key to continue.
- \* Data is then written to the radio during which time the message "writing data to radio, please wait" is displayed.
- \* A series of '\*' will appear below the message to indicate that the programming is in progress.
- \* A message, "Data has been successfully written into the radio" is displayed if the process is successful.
- \* Press any key will return you to the main menu.

### 3.1.7 **To print data**

To produce a printed copy of the data.

- \* Power up your printer making sure that it is on-line.
- \* Select "print" from the Utility Menu and press <ENTER>.
- \* The printer will then print a hard copy of the data entered.
- \* A message "printing in progress..." is displayed during printing and then it will return you to the main menu.

Figure 4.0 shows the printed copy of the data.

PGM700 - T700 RADIO PROGRAMMING SOFTWARE

06/12/1990

```
< RADIO SPECIFICATIONS >-----
Radio model           : T750
Synthesiser frequency : 12.5 KHz
Control head         : STANDARD
Transmit timer value  : 60 sec
Channels             : 1
Scan/Voting          : 0 groups
Seccall active       : N

< RADIO OPTIONS >-----
Hookswitch CTCSS monitor : N
[MON] key enabled       : Y
Tx inhibit on invalid CTCSS : Y
BCD channel selection   : N
Control head fitted    : Y
[STAT] function enabled : N
Status polarity, (Y) for +ve: Y
[MEM] key enabled      : Y
Auto quiet             : Y
Quiet delay            : 20 sec

< CHANNEL DATA >-----

```

Channel	Rx freq [MHz]	Tx freq [MHz]	CTCSS Rx [Hz]	CTCSS Tx [Hz]	Tx Power	Disp code
1	400.05000	400.05000	0.00	0.00	H	01

Figure 4.0 Printed copy of data

3.2

### What you have achieved

Now exit PGM700 (choose the exit command from the quit menu) and look at what you have created.

At the DOS prompt, type `dir *.DAT` and press <ENTER>. You will see a file called "T700DEMO.DAT" this file contains the data you have entered.



## Chapter 4

### 4 Menu Commands

Before we describe the various menu options available to you, we suggest that you take a few minutes to go through the commonly used keys in PGM700. These keys together with their functions are listed in table 4.1.

While you are in data entry session, the status/information window provides an at-a-glance function key reference for your current position.

When you are in channel data entry, the default quick reference line looks like this:

F1 Help, F3 clear field, F5 print data, F7 save data, F10 entry complete  
ENTER data ↑↓ →← cursor, ↑↓ page, ESC to abort.

At the top of the main PGM700 screen is the main menu bar (as shown in Figure 2.0) which offers five choices, each invoking a pull down menu with many options.

Key            Function

F1      Brings up help with information about the current field.

F3      Erases the content of the current field.

F5      Outputs all the data to a printer

F7      Saves all the data in a file specified by you.

F10     Accepts all data and return to main menu

→      In main menu: Advances the cursor to the next command of the menu bar.

In data entry: Accepts the current entered valid data and advances the cursor to the next sequential field.

Both wrap around at the last and first fields.

←      In main menu: moves the cursor to the previous command of the menu bar.

In data entry: Accepts the current entered valid data and moves the cursor to the previous field.

Both wrap around at the last and first fields.

↓      In a menu: moves the selecting bar up in the command menu.

In data entry mode: moves the cursor into the field directly above the current field while accepting the validated data of the current field.

↑      In a menu: moves the selecting bar down in the command menu.

In data entry mode: moves the cursor into the field directly below the current field while accepting the validated data of the current field.

<ENTER>    In a menu: selects a menu item.

In data entry mode: confirms data entry in the current field and advances the cursor to the next field.

<ESC>      In a menu: Leave menu without making a selection.

In data entry mode Press <ESC> twice will abort the data entry and return to the main menu without saving any changes.

<Page Up>    Moves the cursor to the previous page of data or information if any.

<Page Dn>    Moves the cursor to the next page of data or information if any.

<DEL>        Deletes one character in the current field.

<INS>        Toggles insert editing mode in the current field.

## 4.1 Disk

### 4.1.1 Load a file

This option allows you to load any file that was produced by PGM700.

Enter the complete file name (include directory path if appropriate) of the file you want to load. If it cannot be found or is of an incorrect format, an error message will be displayed in the status window. If PGM700 already holds working data it will be overwritten.

For a directory listing, the '\*' wildcard character may be used (e.g. B:\*.DAT will display all the filenames on drive B that match this criteria).

"File has been successfully read" will be displayed in the status/information window if the file has been read successfully.

Pressing <ENTER> when no filename has been specified or <ESC> will take you to the main menu without loading the data.

### 4.1.2 Save a file

This option allows you to save all the entered data in a file on to disk.

Enter the complete filename (include directory path if appropriate) of the file you want to save the data to (e.g. B:DEMO.DAT will save all the data to a file called DEMO.DAT on drive B). If the named file already existed, you will be asked if it should be overwritten. 'N' will prohibit save and will prompt you for another filename.

For a directory listing, the '\*' wildcard character may be used (e.g. B:\*.DAT will display all the filenames on drive B that match this criteria).

If an error is encountered while saving data to file, an error message will be displayed. It will return you to the main menu if the data has been successfully saved to the specified file.

Pressing <ENTER> when no filename has been specified or <ESC> will take you to the main menu without saving the data.

## 4.2 Radio

### 4.2.1 Read Radio

This option allows you to read any radio supported by PGM700 (see chapter I for a list of radio models supported).

#### Setting up

When this option is first selected in a new session, it will prompt you for the communication port that your radio is connected to. Use the up or down arrow keys to select the desired port and press <ENTER>. The selected port will be used for the rest of the session; that is, it remains valid until you exit to DOS. Should you wish to change the communication port number, you will have to exit to DOS and restart PGM700.

If the radio is not connected to the computer at this point, you will now have to connect the radio to the selected communication port of the computer with the lead provided. Power up the radio and then press any key to continue.

An unsuccessful logon will cause an error message to be displayed in the status/information window: check that power is applied to the radio, the cable is connected to the radio and to the correct communication port, then try again. If the logon process is successful, the radio data will be read by PGM700. The data is then available for changing if desired.

A series of "\*" will appear at the bottom of the screen as the reading is in progress.

A message saying, "successfully read radio data" will be displayed if no error is detected during the read process. Pressing any key will return you to the main menu.

### 4.2.2 Program radio

This option allows you to program the radio with entered data, data read from a previously created data file, or data read from another radio.

### Setting up

If neither "read radio" nor "program radio" has been used before, PGM700 will prompt you for the communication port number which the radio is connected to. Use the up or down arrow key to select the desired port and press <ENTER>. The selected port will be used for the rest of the session, that is it remains valid until you exit to DOS

Should you select a wrong port or wish to change to a different port, you will have to exit to DOS and restart PGM700.

If the radio has not been connected and powered up at this point, you will have to connect the radio to be programmed to the selected port with the lead provided. Power up the radio and then press any key to continue.

PGM700 will first check that the correct radio model is connected to the selected port. It will then program the radio with the radio specification data, channel data and the voting data if applicable.

A series of "\*" will appear at the bottom of the screen as the programming is in progress.

The data is then automatically read back from the radio for verification. If no discrepancy is found, a message saying "Data has been successfully written into the radio" will be displayed.

4 . 3

### **Edit**

The Edit menu is for changing existing radio data or for creating new radio data. The menu is kept as simple as possible by only showing the choices relevant to the settings in the Radio specifications option. All data is entered by typing in the appropriate field. Alternatively the help key, <F1> can often be used to list the choices available. The choice is selected by pressing <ENTER>. Any invalid data entered will cause the computer to emit a beep, and either clear the invalid data or warn the user of the consequences.

4 . 3 . 1

### **Radio Specifications**

This option is for entering data that is related to the overall operation of the radio. It has eight settings all of which are important as to how the radio functions.

### Radio model

When "radio specification" is invoked, if no radio model has been selected, a list of the radio models supported by PGM700 will be presented to the user from which a radio model can be selected.

If a radio model has previously been chosen, the list can still be obtained by pressing <F1> when the cursor is in the radio model field.

The <ESC> key can be pressed to leave the model list without selection.

PGM700 will automatically type in the default synthesiser frequency on the selection of a new radio model.

### Synthesiser frequency

There are two valid synthesiser frequencies for each radio model. Pressing <F1> will give the two valid synthesiser frequencies for the chosen radio model.

### Control head

There are currently three control heads available for the T700. Pressing <F1> will give a selection from which the appropriate control head can be chosen.

Choosing any control head other than standard will create a memory option in the Edit menu which is for defining the memory keys which the other heads have.

### Transmit timer value

This specifies the length of time for which the radio can transmit continuously. It can be set between 10 and 990 seconds in steps of 10 seconds. The default is 60 seconds.

This timer can be disabled by setting it to zero(0) seconds.

### Channels

This specifies the number of channels to be programmed into the radio. Up to 100 channels may be programmed for Version 3 radios. See appendix B if your radio is an earlier version.

### Scan/Voting

This specifies the number of scan and voting groups you have. You may have up to 16 groups for Version 3 radios. See appendix B if your radio is an earlier version.

It is not permitted to specify any active group unless the number of channels is 2 or greater. This is because a group must contain at least 2 channels.

Specifying the number of groups creates a set of group options in the edit menu for defining these groups.

### Selcall active

This enables all the selective calling options for Version 3 radios fitted with a Tait T700-30 signalling unit. The Selcall options will appear in the edit menu if this is active (activate by typing Y).

Selective calling can be disabled by typing N.

### Low Current Repeater (y/n)

This enables the Duplex low current repeater option for version 3 radios fitted with the appropriate hardware.

Activate low current repeater by typing Y, deactivate by typing N.

The Duplex low current repeater option will appear in the edit menu if this is active.

## 4.3.2 **Radio Option**

This section is for setting up the options that affect the way the radio operates. These options are programmable for Version 3 radios.

### Hookswitch CTCSS monitor

When Y is specified for this option, monitor RF activity on a channel by taking the mic. off-hook.

Monitored conversation is usually activity on your channel with a different CTCSS frequency than your own. If Selcall is used then it depends on how your Selcall system is set up (see section 4.3.8.).

### <MON> key enabled

This setting is the same as hookswitch monitoring, except monitoring is achieved by pressing the <MON> key when this option is set to Y.

#### Tx inhibit on invalid CTCSS

If a channel is busy with an invalid CTCSS signal and the channel is not being monitored, the radio is prevented from transmitting if this feature is enabled (Type <Y>). A beep will sound from the radio when the user tries to transmit, and a double beep will sound when the channel becomes free.

#### Transmit inhibit on Busy

If Y is selected, the radio will be transmit inhibited if an RF carrier is detected. Note this applies only to V3.07 and later radio software.

#### BCD channel selection

This is for applications where the channels need to be addressed independently of the control head by BCD address. For normal operation this option should be set to N.

#### Control head fitted

This is for BCD addressing in applications where a Tait control head is not used. For normal operation this should be set to Y.

NOTE: When the display is disabled the version of the radio will still be displayed.

#### <STAT> function enabled

This when enabled (Y) provides a status indication in front of the LCD channel which can be toggled by the user pressing the <STAT> button. This is normally used in conjunction with selective calling where the status digit is transmitted. The radio on power up will keep the same status it had before the power was turned off.

#### Status polarity. (Y) for +ve

The status code also appears as a single BCD digit on the options connector on the control PCB. This setting presents the digit as either positive or negative logic. Y sets positive logic, N sets negative logic.

#### <MEM> key enabled

When set to Y enables the <MEM> button for programming memory keys, scan and priority channels.

### Auto quiet

When a channel has been monitored by pressing the <MON> key, it can be set so that it automatically quiets itself after a specified duration of no RF activity by setting this option to Y.

### Quiet delay

This sets the duration before a radio will automatically quiet itself. This period can be between 0 and 650 seconds with the duration starting as soon as there is no RF activity on the channel.

## 4.3.3 **Channel Data**

This option allows the entry of individual channel data. Seven parameters are required for each channel. They are:

- \* Receive frequency (MHz)
- \* Transmit frequency (MHz)
- \* CTCSS receive frequency (Hz)
- \* CTCSS transmit freq. (Hz)
- \* Transmit power
- \* LCD display

### Receive frequency and transmit frequency

These fields specify the frequencies which the radio will receive or transmit, with a single line corresponding to one channel. The entered data should be in the normal frequency band for the radio model specified in the radio specifications section. These frequency bands are given in chapter I or can be displayed when in a frequency field by pressing <F1>. Frequencies outside these bands will be accepted but a warning message will be issued.

The transmit or receive frequency also has to be divisible by one of the two reference frequencies valid for the radio model. The radio will automatically select the appropriate reference frequency using the frequency in the specifications section as the default.

The transmit frequency is entered with the receive frequency only if the transmit frequency is zero (0). This helps to speed up simplex channel data entry. Do not adjust the receive frequency. The software does this automatically.

Any frequency entered which is divisible by a synthesiser frequency but is outside the normal band will be accepted with a warning message.

### CTCSS receive and CTCSS transmit frequencies

These fields specify the CTCSS receive and transmit frequencies if they are used.

The entered CTCSS frequency is checked against a look-up table. An error message is generated if an invalid CTCSS frequency is entered.

A list of valid CTCSS frequency is displayed by pressing <F1> while in one of these fields.

The CTCSS transmit frequency is entered with the CTCSS receive frequency only if the CTCSS transmit frequency is zero (0).

### Transmit power

This field specifies the transmit power for the corresponding channel. The valid options are:

H - High

M - Medium

L - Low

X - Transmit inhibit

Any other character entered will generate an error.

### LCD Display Code

This field specifies the 2 character display on the front panel LCD display of the radios for the corresponding channel.

The valid characters are 0..9, A, b, c, h, E and '\_' for space, otherwise an error is generated.

## 4.3.4 **Memory key storage**

This option allows programming of memory keys to either channels, groups or selcall numbers. This option is for version 3.05 radios only. (see appendix B). There are 3 settings for each Memory key as outlined below.

### Type

This sets what type of function you want assigned to the memory key. C sets the memory key to a channel. G sets the key to a group. S sets the key to a selcall Txcall identity number.

### No./Txcall

This is the channel, the group or the txcall selcall identity number you want assigned to that memory key.

### Write protected

Specifying Y to this option will stop the user being able to overwrite from the radio what is programmed to that memory key.

#### 4.3.5 **Group Options**

There are two options for group functions.

##### Channel access permitted

This option when set to N will stop the user accessing individual channels. Access to a single channel may be implemented if a channel is programmed to a memory key (see memory key storage).

Channel access should be permitted if channels are to be programmed that are not included in groups.

##### User programmable scan group I

This option for Version 3 radios only, decides whether the user can define what channels they have in scan group I. Y will let the user program their own scan channels.

#### 4.3.6 **Group Membership**

This allows the channel make-up of the groups to be specified. Enter the channel numbers which are to belong to the indicated group. You cannot enter a channel twice in the same group, but a channel may be reused in different groups.

Each group must have at least two members up to a maximum of 16 members.

#### 4.3.7 **Group parameters**

This section allows the various parameters of the voting, scan and priority groups to be defined. The fields or parameters are outlined below. Earlier radios than Version 3.05 can only use voting groups (see appendix B).

##### Type

This sets the type of group to be used. Groups are expressed as their abbreviations A, B, S and P. These groups are:

- \* Voting group type A (A)
- \* Voting group type B (B)
- \* Scan group (S)
- \* Scan group with priority channel (P)

The voting groups select the channel in its group with the strongest RF signal. The type of voting system is defined by the characteristics of the base signal. A normal community linked repeater system would be classified as type A (intermittent base operation).

Some bases operate in a continuous transmit mode. The radio votes on a polling basis. This type of operation is classified as B.

Note: Voting features may not be appropriate for all systems.

Scan groups scan sequentially through the channel list and lock onto a channel when a signal is present, while a priority group is the same as a scan group except it samples its priority channel every two and a half seconds. If the priority channel is active, the radio will capture the priority channel even if the radio is locked on a scan channel.

Note: For a user programmable scan group the type for group I must be either "P" or "S"

#### Vote

This only applies to voting groups and decides how often a channel is sampled during a voting sequence. This can be set to either 1 or 2 samples a voting sequence. 2 samples are normally used if greater immunity to fast fading effects, etc. is required. The trade-off is against the speed of the vote. Scan and priority groups ignore this setting.

#### Priority Channel

This is only applicable to priority groups and is the channel deemed to be the priority channel. Scan and voting groups ignore this setting.

The priority channel does not have to be a member of the scan group.

#### Display

This is the LCD display that is displayed on the control head for the group. The valid characters are 0...9 , A , b , c , h , E and \_ for space.

#### Default Tx channel

This is the channel the radio will transmit on when in a group and not locked into a channel. For scan and priority groups this default Tx channel will change with activity to the last captured channel. Voting groups will also change to the last channel voted, but will return to the default Tx channel after leaving a group.

### Lead in delay (LID)

This is a delay that is sometimes required to allow for differences in key time of repeaters. This delay occurs from the time the radio first detects a busy signal, to the start of the voting sequence. It is only applicable to type A voting. Other group types ignore this parameter.

### Hold Time (HLD)

A hold time may be specified. This is a delay from the time the radio loses the signal to when it resumes scanning. No scan occurs if the signal is detected again during the hold time. The hold time should be an appropriate length to stop loss of syllables in a conversation. The default is 5s.

### Polling Interval (POL)

The polling interval is only applicable on type B voting systems. This specifies the time between automatic "refresher" votes on a continuous base signal system. Type A voting, scanning and priority groups ignore this parameter.

## 4.3.8 **Selcall setup**

This section describes how the radio is set up for use with the Tait T700-30 signalling module. This section and the rest of the edit section is devoted to Selcall and is only applicable if you have a Version 3.05 or later radio fitted with a T700-30 board. If this is not the case the selcall active option in the Radio Specifications section should be set to N which will set the edit menu so it does not have the selcall sections.

### <Send> key enabled

Some selcall systems may not want the <Send> key to perform any function. Specifying N to this option will disable the <Send> key.

### ANI enabled

An automatic number identification sequence can be transmitted with conversation to enable the base to identify the user. This feature is enabled by typing Y.

Note: The ANI position must also be specified (see section 4.3.10).

### Emergency (Y)/Priority (N)

The remote emergency switch (or optionally the <Aux> key) may either activate a Priority Call function or an Emergency status function depending on how this option is set. Y sets the emergency function and N the priority function.

### <AUX> key initiates emergency/priority function

If Y is answered for this option the <Aux> key will activate the function that is set in the previous setting. If N, the <AUX> key will behave normally. This setting is relevant only if you have an Enhanced or a Keypad control head.

### Last number redial

Applicable only to keypad control heads, this setting if enabled by typing Y will allow the user to redial the last number dialled.

### Monitor CTCSS and SELCALL

This sets the monitoring conditions of the radio. Setting this option to Y enables all RF activity on your channel to be monitored. Setting this option to N limits monitored conversation to your CTCSS frequency. If on a channel with no CTCSS frequency, this option will have no effect (i.e. all RF activity on your channel will be monitored).

### Selcall mute enabled

If Y is answered for this option, then the radio will only unmute on reception of a valid Selcall sequence. If N is answered then Selcall sequences will have no effect on the mute.

## 4.3.9 **Selcall Identity**

This section is for setting the individual selcall identification numbers. Numbers are 5 digits long with transmission sequences having the option of including a status digit. The status digit is entered after the 5 digit code and can be either a fixed digit or can be the status of the radio by typing S. A fixed status digit may be specified as '0-9', 'E' (emergency) or 'P' (priority). A wildcard digit G is used to specify group calls. All codes must have at least one starting digit and once a G is used the subsequent digits also have to be G.

e.g. A valid group code would be 87GGG and would call all users whose identity code start with 87.

### Fleet prefix

A prefix for codes may be specified which will limit the user to only dialling codes in their fleet. For convenience this prefix is automatically entered when programming the identity codes, but can be overwritten if codes outside the fleet are required.

### Rx decode

This is the code which when received will initiate the radio to respond.

### ANI code

The ANI (Automatic Number Identification) code is one which is sent during transmission so the base can identify the user. It is often the same as Rx decode, but this need not be the case. It may include a status digit.

### Tx call code

This is the number which the radio will call when the <SEND> key is pressed. It may include a status digit.

### Emergency/Priority code

This code is sent when the remote emergency switch is activated (or optionally the <AUX> key is pressed). It is either the priority code or the emergency code depending on how this feature is programmed (see section 4.3.8). It is often the same as the Tx call code but this need not be the case. It may include a status digit, which is often fixed as "E" or "P".

### Aux call code

This is the number which the radio will call when the <SEND> key is held for approximately two seconds. It can be disabled by leaving the field blank. It may include a status digit.

### Auto ack. code

This is a code the radio sends back to the caller to acknowledge the radio received the call. It can be either a selcall number or a beep by typing "BEEP". It can be disabled by leaving the field blank. The selcall number may include a status digit.

#### 4.3.10 **Selcall Parameters**

These parameters control the details of how the Selcall system behaves. It is normally only set once for a given fleet.

##### Tone set

This is set to any of the standard tone sets; EEA, ZVEI-I, ZVEI-II, PVZEI, CCIR, NATEL, EIA or DZVEI. The tone set can be chosen by pressing <F> and selecting the tone set that is applicable to your system.

##### Tone period

This is the duration of each tone and may either be 20, 33, 40, 50, 60, 70 or 100 ms. This can also be selected by pressing <F>.

##### Lead in tone

A lead in tone may be specified for applications such as accessing repeaters. This can be programmed to be any digit 0-F that is valid for the tone set selected. The lead in tone can be switched off by typing X. The duration of the lead in tone is defined by the lead in delay.

##### Lead in delay

This delay which is for lead in tones as well as giving the transmitter time to stabilise can be set anywhere from 0 ms through to 5.1 s in steps of 20 ms.

##### Group format

The group format can be set to either International or Sigtec. Press <F> and select the appropriate format.

Note: The International format may not be valid for your system.

##### Max status digit

If the status function is enabled (section 4.3.2.) the maximum status digit can be defined. Valid digits are 0 to 9. E and P may not be selected.

##### Tone blanking

Operator fatigue can be prevented by specifying Y to this option which will program the radio to automatically mute the mobile when it is decoding a valid selcall sequence.

### Remote Reset

This option is reserved for future use and should be left at its default value. Future uses for this option include remote control applications and permission to speak systems.

### Alert duration

This sets how long a user will hear the alert tone when their mobile has been called. This can range from 2.5 seconds to 10 minutes in steps of 2.5 seconds or alternatively it can be set to infinity by making this parameter 0. The alert is cancelled by pressing any button on the radio.

### Ext alert enabled

An external device such as a car horn, etc. may be connected to the radio via the radio's power socket. This feature, when enabled by typing <Y> will activate the device when the radio receives a call, after a suitable delay (see below)

### Ext alert delay

This is the delay before the external device will be activated after receiving a call. It can be set from 2.5 s to ten minutes.

### Ext alert duration

This parameter defines how long the external device will sound once it is activated. It can be set from 2.5 s to ten minutes and is cancelled in the same manner as the normal alert tone.

### ANI position

This controls whereabouts during transmission the ANI (Automatic Number Identification) sequence is sent. It can be set to L where the sequence is transmitted on the leading edge of the press to talk, T where it is set on the trailing edge, or R where it is sent randomly during the transmission. A combination of these can also be set. e.g. L+R+T or L+R.

### ANI suppression

A suppression time where no ANI transmission occurs can also be specified. This time starts after the first ANI sequence and can range from zero (no suppression) through to ten minutes.

### Defer call

If this is enabled by typing Y, any call that is to be attempted when the channel is busy will be deferred. The deferred call will be sent when the channel is free, unless the operator has cancelled the call by pressing a key. Deferred calling is useful in that before sending a call a channel does not have to be monitored to see if it is free.

### Defer hold time

This parameter defines how long the radio will wait for the channel to be clear when deferring a call. Once this time has elapsed the call will be cancelled. The time can be set from zero seconds to ten minutes, or it may be set to infinity by specifying a value of zero.

### Group call

Users who have the keypad control head have the ability to make unrestricted group calls. This option when set to N will inhibit this facility.

### Group display hold time

This parameter sets how long the "GrP" indication remains flashing on the control head after a group call. This can range from 2.5 s to ten minutes or can be set to infinity by typing 0.

Figure 5.0 shows a printed copy of the selcall default setting

```
< SELCALL SETUP >-----
[SEND] key enabled           : Y
ANI enabled                  : N
Emergency (Y)/Priority (N)   : N
[AUX] key initiates emergency function : N
Last number redial          : Y
Monitor CTCSS and Selcall   : Y

< SELCALL IDENTITY >-----
Fleet prefix                 :
RXDECODE code                :
TXCALL code                  :
Priority code                 :
AUXCALL code                 :
Auto ack code                : BEEP

< SELCALL PARAMETERS >-----
Tone set                     : CCIR
Tone period                   : 20 ms
Lead in tone                  : X
Lead in delay                 : 500 ms
Group format                  : SIGTEC
Max status digit             : 9
Tone blanking                 : Y
Remote reset                  : IGNORE
Alert duration                : 5 sec
Defer call                    : N
Group calls                   : Y
Group display hold time      : 30 sec
```

Figure 5.0 Selcall default settings

#### 4.3.11 Duplex Low Current Repeater

The T700 low current repeater option reduces the current drawn by a duplexed T700 in idle mode by switching the radio on and off according to the settings defined on this screen.

This screen is available from the Edit menu, once you have set the Low Current Repeater field to 'Y' on the Specification screen.

The example screen shown in figure 6.0 is set to an on/off duty cycle that would reduce the average current drawn to about 100mA.

< DUPLEX SPECIFICATION >	
Low current repeater on time in mSec	100
Low current repeater off time in mSec	300
Low current repeater hold time in 10mSec	3
Is radio talk through <Y/N>	Y

**Figure 6.0 Low Current Repeater Specification**

#### 4.4 Utility

##### 4.4.1 Clear/new

This option clears all entered information and PGM700 will be as if you have just started.

##### 4.4.2 Print

This option prints all entered data if any, on a printer. If a printer error is detected, a message "printer not ready" will be displayed in the status window.

#### 4.5 Quit

##### 4.5.1 Exit

This option is used at the end of the session to return to DOS. Note that all data must be saved to prevent loss.



## Chapter 5

### Error and warning messages

PGM700 diagnostic messages fall into two classes; errors and warnings. These messages are displayed in the status/information window as they occur. A tone is also generated for each error or warning message. Errors indicate invalid data entered, illegal conditions, communication errors or an incorrect order of data entry attempted. All error messages are preceded by "Error".

Warnings do not prevent you from proceeding. They indicate that the data entered is outside the normal limits of PGM700 and thus requires your attention. Any data entered that causes a warning message will be accepted and processed accordingly. All warning messages are preceded by "Warning".

In the following lists, messages are presented alphabetically within message class. A probable cause and remedy are provided for each message.

### **Error Message**

### **Possible remedies**

- |   |   |
|---|---|
| 1. Cannot open (filename)   | Use a different filename  |
| 2. Cannot read (filename)   | Check filename - you may have attempted to read a file which was not produced by PGM700                             |
| 3. Can't check radio status, restart PGM700.                        | Check connection, power the radio down and up again.  |
| 4. Duplicated channel number.                                       | Use another channel.  |
| 5. Each group must have at least 2 members.                         | Enter at least 2 channels for each group.   |
| 6. End of message from radio not found. Try again                   | Check PC-radio link.  |
| 7. Exceed maximum number of active group.                           | Change number of active group to any number less than or equal to I6.   |
| 8. Fail to close (filename)   | Save the data under a different filename.   |
| 9. Fail to logon to radio, check PC radio connection and try again. | Check that the PC-radio link is securely connected.   |
| 10. Fail to read file.  | File is not in the right format. It may not have been created by PGM700.  |
| 11. Fail to read radio data.  | Check radio - PC connection.  |
| 12. Fail to save data to file.                                      | Disk could be full. Try to save the data again on a separate floppy disk. For instance, by typing <u>A:T750.DAT</u> |
| 13. Fail to send command to radio, try again.                       | Check radio - PC connection   |
| 14. Fail to send data to radio, try again.                          | Check radio - PC connection   |
| 15. Fail to write to (filename)                                     | Use a different filename.   |
| 16. (Filename) does not exist in current directory.                 | Type <u>*.*</u> <ENTER> to see the file directory.  |
| 17. First digit must be in range of 0...9.                          | Enter first digit from 0...9  |

**Error Message****Possible remedy**

- |   |  |
|---|--|
| 18. First N digits must agree with fleet prefix code (where N is the number of digits in the Fleet prefix). | An identity code that starts with the fleet prefix should be entered.                            |
| 19. For voting, radio must have at least 2 channels.  | Either set active group to zero or make number of channels greater than one (1).                 |
| 20. Frequency not divisible by X kHz (X is the specified synthesiser frequency).                            | Either enter a frequency that is divisible by the synth frequency or change the synth frequency. |
| 21. 'G' must be used after the first 'G' code.  | Enter a code whose remaining digits after a 'G' are 'G's.  |
| 22. Group member not specified.   | Either set active group in radio specifications to zero or edit group membership.                |

Use the following Function Keys to change colours/attributes that PGM700 uses.

F1	Main screen	
F2	Border	
F3	Title	
F4	Text	
F5	Selected prompt	(Prompt 1)
F6	Unselected prompt	(Prompt 2)
F7	Selected data field	
F8	Unselected data field	
F10	Exit and save changes	
ESC	Exit and throw away changes	

- |  |   |
|--|---|
| 23. Group N has an invalid member (where N is the group number).                         | Edit the group membership so it has valid members.  |
| 24. Illegal character used in filename.  | Use a different filename. Make sure that all characters used are legal filename characters for DOS. |
| 25. Illegal selcall code used.   | Enter a code that is five digits long.  |
| 26. Illegal status code entered.   | Enter either a digit or a S, E or P as the status indicator.  |
| 27. Invalid channel number specified in memory key N (where N is the memory key number). | Edit memory key storage so that a correct channel number is entered.                                |

<b><u>Error Message</u></b>	<b><u>Possible remedy</u></b>
28. Invalid default Tx channel in group N (where N is the group number).	Set the default Tx channel in the group parameters so it is a member of the group.
29. Invalid group number specified in memory key N (where N is the memory key number).	Edit memory key storage so that a correct group number is entered.
30. Memory N stores selcall code with invalid prefix code (where N is the memory key number).	Edit memory key storage so that a legal selcall code is entered.
31. No files match this criteria.	Type *.*<ENTER> to see the file directory.
32. PC COM port initialisation error, try again.	Check radio - PC link.
33. PC radio communication error detected, try again.	Check radio - PC link.
34. Radio data not identical to programmed data, try again.	Radio could be faulty.
35. Radio model has not been selected.	Select a radio model in the radio specifications.
36. Received error message from radio.	Recheck all the entered data.
37. Rx frequency of channel N not divisible by X kHz (X is the specified synthesiser frequency and N is the channel number).	Either enter a frequency that is divisible by the synth frequency or change the synth frequency.
38. Selcall not active but memory N stores selcall code (where N is the memory key number).	Either enable selcall or edit memory key storage so that the memory key does not store a selcall code.
39. This is not a member of the group.	Enter a channel which is a member of the group.
40. This radio can only be programmed with N channels (where N is the number of channels).	Reduce the number of channels specified in the radio specifications.
41. This radio does not have group scan capability.	
42. Voting group has no channel member.	Edit group membership so that the group has members.

**Error Message**

**Possible remedy**

43. Wrong radio model connected.

Make sure that the radio model specified is the same as the one connected.

### **Warning Messages**

1. Frequency above normal band.
2. Frequency below normal band.
3. Group I has been specified as an user programmable scan group.
4. Polling interval of group N will be default to 60 s. (where N is the group number).
5. Priority channel of group N will be default to I. (where N is the group number)
6. This display code already exists.
7. Selcall features not incorporated in this radio.  
radio.
8. Voting features not incorporated in this radio.
9. Vote of group N will be default to I. (where N is the group number).

### **Things to check**

- Is this correct?
- Is this correct?
- Is the type in the group parameters set to S or P?
- Have you set the correct group type?
- Have you set the correct group type?
- Is this O.K.?
- Selcall data will not be programmed onto the
- Voting data will not be programmed onto the radio.
- Have you set the correct group type?

## APPENDIX A

### Screen Colour Configuration

On the original program disk is a file called PGM700CF.EXE. This is a file which, when run, allows the user to configure the screen colours and attributes to suit a desired preference. If it is not used then a default set of attributes is selected.

#### How to use PGM700CF

To run the screen configuration program type PGM700CF <ENTER>. A screen as shown below is displayed:

PGM700 Configuration - Display Colour Selection

Version 1.01

Title
Text
Prompt 1 : Selected data field
Prompt 2 : Unselected data field

For a colour monitor additional features are offered and the screen appears thus:

<u>Foreground</u>	<u>Background/attribute</u>
	Shift F1 Main screen
F2	Shift F2 Border
F3	Shift F3 Title
F4	Shift F4 Text
F5	Shift F5 Selected prompt (Prompt 1)
F6	Shift F6 Unselected prompt (Prompt 2)
F7	Shift F7 Selected data field
F8	Shift F8 Unselected data field
F10	Exit and save changes
ESC	Exit and throw away changes.

The top half of the screen displays an example of the different types of text used in PGM700. To change any of these colours or attributes, press the corresponding function key <F1> - <F8> as shown in the menu for monochrome systems or <F1> - <F8> and <SHIFT> <F1> - <SHIFT> <F8> for colour systems.

For example, if you wish to change the title colour, press <F3>. The effect of this will be shown. Further pressing of <F3> will scroll through the colours available.

To save the changes and exit from the program, press <F10>; or press <ESC> to exit from the program without saving any changes. If <F10> is used, a new file called "PGM700.CNF" is created or the old "PGM700.CNF" is overwritten if it already exists.

## **APPENDIX B**

### **Using PGM700 Version 3.05 with older radios.**

PGM700 Version 3.05 will program older versions of T700 radios, however, new programming features in PGM700 version 3.05 will not work on the older radios. The version number of the radio is displayed for a few seconds when the radio is turned on. Version 3 radios or later are ideally suited for Version 3.05 programming software.

