

KENWOOD

SERVICE MANUAL

VHF DIGITAL TRANSCEIVER, UHF DIGITAL TRANSCEIVER

**NX-3720H(G), NX-3720H, NX-3720(G), NX-3720,
NX-3820H(G), NX-3820H, NX-3820(G), NX-3820**




TABLE OF CONTENTS

1	PRECAUTION.....	1-7
2	SPECIFIC SERVICE INSTRUCTIONS.....	1-7
3	DISASSEMBLY.....	1-30
4	ADJUSTMENT.....	1-33
5	TROUBLESHOOTING.....	1-152

This product complies with the **RoHS** directive for the European market.



This product uses Lead Free solder.

Document Copyrights

Copyright 2017 by JVC KENWOOD Corporation. All rights reserved.

No part of this manual may be reproduced, translated, distributed, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, for any purpose without the prior written permission of JVC KENWOOD Corporation.

Disclaimer

While every precaution has been taken in the preparation of this manual, JVC KENWOOD Corporation assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

JVC KENWOOD Corporation reserves the right to make changes to any products herein at any time for improvement purposes.

Firmware Copyrights

The title to and ownership of copyrights for firmware embedded in KENWOOD product memories are reserved for JVC KENWOOD Corporation. Any modifying, reverse engineering, copy, reproducing or disclosing on an Internet website of the firmware is strictly prohibited without prior written consent of JVC KENWOOD Corporation. Furthermore, any reselling, assigning or transferring of the firmware is also strictly prohibited without embedding the firmware in KENWOOD product memories.

Transceivers containing AMBE+2™ Vocoder:

The AMBE+2™ voice coding technology is embedded in the firmware under the license of Digital Voice Systems, Inc.

Copyrights

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by JVC KENWOOD Corporation is under license. Other trademarks and trade names are those of their respective owners.

NOTE

- This equipment should be serviced by only qualified technicians.
- Danger of explosion if the battery is incorrectly replaced; replace only with the same type.
- To dispose of batteries, be sure to comply with the laws and regulations in your country or region.

SPECIFICATION

NX-3720H(G)/3720H (K TYPE)

GENERAL		
Frequency Range		136~174 MHz
Max. Channels per Radio		Up to 1000 channels with option
Number of Channels		512
Number of Zones		128
Channel Spacing	Analog	12.5/15/25*1/30*1 kHz
	Digital	6.25 /12.5 kHz
Operating Voltage		13.6V DC \pm 15%
Operating Temperature Range		-22°F to +140°F (-30°C to +60°C)
Frequency Stability		\pm 1.0 ppm
Dimensions (W x H x D) (Projections not included)	Radio with Control Head	6.30 x 1.69 x 6.30 in. (160 x 43 x 160 mm)
Weight (net)	Radio with Control Head	2.65 lbs (1.2 kg)
RECEIVER		
Sensitivity	NXDN 6.25kHz Digital (3%BER)	0.20 μ V
	NXDN 12.5kHz Digital (3%BER)	0.25 μ V
	DMR 12.5 kHz Digital (5% BER)	0.30 μ V
	DMR 12.5 kHz Digital (1% BER)	0.45 μ V
	Analog (12dB SINAD)	0.25 μ V
Selectivity	Analog @ 12.5kHz	70dB
	Analog @ 25kHz	80dB
Intermodulation	Analog	70dB
Spurious Rejection	Analog	80dB
Audio Distortion		2%
Audio Output		4W / 4ohm
TRANSMITTER		
RF Power Output (H / M / L)		50W/30W/5W
Spurious Emission		-73dB
FM Hum & Noise	Analog @ 25 kHz	45dB
	Analog @ 12.5kHz	40dB
Modulation Distortion		2%
Emission Designator		16K0F3E*1, 11K0F3E, 8K30F1E, 8K30F1D, 8K30F7W, 4K00F1E, 4K00F1D, 4K00F7W, 7K60FXE, 7K60FXD, 4K00F2D

*1 25 and 30 kHz are not included in the models sold in the USA or US territories.

Analog measurements made per TIA603. Specifications are measured according to applicable standards.

JVC KENWOOD Corporation reserves the right to change specifications without prior notice or obligation.

SPECIFICATION

NX-3720(G)/3720 (E TYPE)

GENERAL		
Frequency Range	136~174 MHz	
Max. Channels per Radio	Up to 1000 channels with option	
Number of Channels	512	
Number of Zones	128	
Channel Spacing	Analog	12.5 / 20 / 25 kHz
	Digital	6.25 /12.5 kHz
Operating Voltage	13.2V DC (10.8~15.6 V DC)	
Operating Temperature Range	-30°C to +60°C	
Frequency Stability	±1.0 ppm	
Dimensions (W x H x D) (Projections not included)	Radio with Control Head	160 x 43 x 160 mm
Weight (net)	Radio with Control Head	1.2 kg
RECEIVER		
Sensitivity	NXDN 3 % BER (6.25 kHz/12.5 kHz)	0.20 μV / 0.28 μV
	NXDN 1 % BER (6.25 kHz/12.5 kHz)	-5.0 dBμV (0.28μV) / -2 dBμV (0.40μV)
	DMR 12.5 kHz Digital (5 % BER)	-4.5 dBμV (0.30μV)
	DMR 12.5 kHz Digital (1 % BER)	-2 dBμV (0.40μV)
	Analog, EIA 12 dB SINAD (12.5/20&25 kHz)	0.25 μV
	Analog, EN 20 dB SINAD (12.5/20&25 kHz)	-1 dBμV (0.45 μV) / -3 dBμV (0.35 μV)
Selectivity	Analog @ 12.5kHz	70dB
	Analog @ 20kHz	78dB
	Analog @ 25kHz	80dB
Intermodulation	Analog	70dB
Spurious Rejection	Analog	80dB
Audio Distortion	2%	
Audio Output	4W / 4ohm	
TRANSMITTER		
RF Power Output (H / L)	25W/5W	
Spurious Emission	-36dBm ≤ 1GHz, -30dBm >1GHz	
FM Hum & Noise	Analog @ 25 kHz	50dB
	Analog @ 20kHz	50dB
	Analog @ 12.5kHz	45dB
Modulation Distortion	2%	
Emission Designator	16K0F3E, 14K0F2D, 14K0F3E, 12K0F2D, 8K50F3E, 7K50F2D, 8K30F1E, 8K30F1D, 8K30F7W, 4K00F1E, 4K00F1D, 4K00F7W, 7K60FXE, 7K60FXD, 4K00F2D	

Analog measurements made per TIA603. Specifications are measured according to applicable standards.
JVC KENWOOD Corporation reserves the right to change specifications without prior notice or obligation.

SPECIFICATION

NX-3820H(G)/3820H (K,K2 TYPE)

GENERAL		
Frequency Range	K	450~520MHz
	K2	400~470MHz
Max. Channels per Radio	Up to 1000 channels with option	
Number of Channels	512	
Number of Zones	128	
Channel Spacing	Analog	12.5/ 25*1 kHz
	Digital	6.25 /12.5 kHz
Operating Voltage	13.6V DC \pm 15%	
Operating Temperature Range	-22°F to +140°F (-30°C to +60°C)	
Frequency Stability	\pm 1.0 ppm	
Dimensions (W x H x D) (Projections not included)	Radio with Control Head	6.30 x 1.69 x 6.30 in. (160 x 43 x 160 mm)
Weight (net)	Radio with Control Head	2.65 lbs (1.2 kg)
RECEIVER		
Sensitivity	NXDN 6.25kHz Digital (3%BER)	0.20 μ V
	NXDN 12.5kHz Digital (3%BER)	0.25 μ V
	DMR 12.5 kHz Digital (5% BER)	0.30 μ V
	DMR 12.5 kHz Digital (1% BER)	0.45 μ V
	Analog (12dB SINAD)	0.25 μ V
Selectivity	Analog @ 12.5kHz	70dB
	Analog @ 25kHz	80dB
Intermodulation	Analog	70dB
Spurious Rejection	Analog	80dB
Audio Distortion	2%	
Audio Output	4W / 4ohm	
TRANSMITTER		
RF Power Output (H / M / L)	45W/30W/5W	
Spurious Emission	-75dB	
FM Hum & Noise	Analog @ 25 kHz	45dB
	Analog @ 12.5kHz	40dB
Modulation Distortion	2%	
Emission Designator	16K0F3E*1, 11K0F3E, 8K30F1E, 8K30F1D, 8K30F7W, 4K00F1E, 4K00F1D, 4K00F7W, 7K60FXE, 7K60FXD, 4K00F2D	

*1 25 kHz are not included in the models sold in the USA or US territories.

Analog measurements made per TIA603. Specifications are measured according to applicable standards.

JVC KENWOOD Corporation reserves the right to change specifications without prior notice or obligation.

SPECIFICATION

NX-3820(G)/3820 (E TYPE)

GENERAL		
Frequency Range	400~470MHz	
Max. Channels per Radio	Up to 1000 channels with option	
Number of Channels	512	
Number of Zones	128	
Channel Spacing	Analog	12.5 / 20 / 25 kHz
	Digital	6.25 /12.5 kHz
Operating Voltage	13.2V DC (10.8~15.6 V DC)	
Operating Temperature Range	-30°C to +60°C	
Frequency Stability	±1.0 ppm	
Dimensions (W x H x D) (Projections not included)	Radio with Control Head	160 x 43 x 160 mm
Weight (net)	Radio with Control Head	1.2 kg
RECEIVER		
Sensitivity	NXDN 3 % BER (6.25 kHz/12.5 kHz)	0.20 μV / 0.28 μV
	NXDN 1 % BER (6.25 kHz/12.5 kHz)	-5.0 dBμV (0.28μV) / -2 dBμV (0.40μV)
	DMR 12.5 kHz Digital (5 % BER)	-4.5 dBμV (0.30μV)
	DMR 12.5 kHz Digital (1 % BER)	-2 dBμV (0.40μV)
	Analog, EIA 12 dB SINAD (12.5/20&25 kHz)	0.25 μV
	Analog, EN 20 dB SINAD (12.5/20&25 kHz)	-1 dBμV (0.45 μV) / -3 dBμV (0.35 μV)
Selectivity	Analog @ 12.5kHz	68dB
	Analog @ 20kHz	76dB
	Analog @ 25kHz	78dB
Intermodulation	Analog	70dB
Spurious Rejection	Analog	80dB
Audio Distortion	2%	
Audio Output	4W / 4ohm	
TRANSMITTER		
RF Power Output (H / L)	25W/5W	
Spurious Emission	-36dBm ≤ 1GHz, -30dBm>1GHz	
FM Hum & Noise	Analog @ 25 kHz	50dB
	Analog @ 20kHz	50dB
	Analog @ 12.5kHz	45dB
Modulation Distortion	2%	
Emission Designator	16K0F3E, 14K0F2D, 14K0F3E, 12K0F2D, 8K50F3E, 7K50F2D, 8K30F1E, 8K30F1D, 8K30F7W, 4K00F1E, 4K00F1D, 4K00F7W, 7K60FXE, 7K60FXD, 4K00F2D	


Analog measurements made per TIA603. Specifications are measured according to applicable standards.
JVC KENWOOD Corporation reserves the right to change specifications without prior notice or obligation.

SECTION 1 PRECAUTION

This service manual does not describe PRECAUTION.


SECTION 2 SPECIFIC SERVICE INSTRUCTIONS

2.1 SYSTEM SET-UP



2.2 REALIGNMENT

2.2.1 Modes



*1:In order to use the Front panel programming mode, it is necessary to purchase the "Front panel program" feature option.

Mode	Function
User mode	For normal use.
Panel test mode	Used by the dealer to check the fundamental characteristics.
Panel tuning mode	Used by the dealer to tune the transceiver.
PC mode	Used for communication between the transceiver and PC.
Data programming mode	Used to read and write frequency data and other features to and from the transceiver.
PC test mode	Used to check the transceiver using the PC. This feature is included in the FPU.
Firmware programming mode	Used when changing the main program of the flash memory.
Clone mode	Used to transfer programming data from one transceiver to another.
Front panel programming mode	Frequency, signaling and features write to the transceiver.
Transceiver information mode	Used to confirm the transceiver firmware version, Encryption Library version.

2.2.2 How to Enter Each Mode

Mode	Operation
User mode	Power ON
Panel test mode*2	<ul style="list-style-type: none"> • [↩] + Power ON • [⏏] + Power ON Select the "Panel Test" using the [▲] / [▼] button. Press the [⏏] button.
PC mode	Received commands from PC
Panel tuning mode	[Panel test mode] + [⏏]
Firmware programming mode*2	<ul style="list-style-type: none"> • [△(AUX)] + Power ON • [⏏] + Power ON Select the "Firmware Prog" using the [▲] / [▼] button. Press the [⏏] button.
Clone mode*2	<ul style="list-style-type: none"> • [🏠] + Power ON • [⏏] + Power ON Select the "Clone" using the [▲] / [▼] button. Press the [⏏] button.
Front panel programming mode*2	<ul style="list-style-type: none"> • Press the PF button to which Front panel programming mode is set during the user mode. • Press the [⏏] button and enter the Menu mode. Select the any icon assigned the Front panel programming mode using the [▲] / [▼] button. Press [⏏] button. Select the "Panel Program" using the [▲] / [▼] button. Press the [⏏] button.
Transceiver information mode*2	<ul style="list-style-type: none"> • [+] + Power ON • [⏏] + Power ON Select the "Transceiver Info" using the [▲] / [▼] button. Press the [⏏] button.

*2 There is the two or three as how to enter.

2.2.3 Panel Test Mode

Setting method refer to ADJUSTMENT.

2.2.4 Panel Tuning Mode

Setting method refer to ADJUSTMENT.

2.2.5 PC Mode

2.2.5.1 Preface

The transceiver is programmed by using a personal computer, programming interface (KPG-46U/46X) and FPU (programming software).

The programming software can be used with a PC. Figure 1 shows the setup of a PC for programming.




Fig.1

2.2.5.2 Connection procedure

- (1) Connects the transceiver to the computer using the interface cable (KPG-46U/46X).

Note:

You must install the KPG-46U/46X driver in the computer to use the USB programming interface cable (KPG-46U/46X).

- (2) When the POWER switch on, user mode can be entered immediately. When PC sends command the transceiver enter PC mode, and "PROGRAM" is displayed on the LCD. When data transmitting from the transceiver, the red LED lights. When data receiving to the transceiver, the green LED lights.

Note:

The data stored in the computer must match the "Model Name" when it is written into the flash memory.

2.2.5.3 KPG-46U/46X description (USB programming interface cable: Option)

The KPG-46U/46X is a cable which connects to a USB port on a computer.

When using the KPG-46U/46X, install the supplied CD (with driver software) in the computer. The KPG-46U driver runs under Windows 7, 8.1, 10.

The KPG-46X driver runs under Windows 7, 8.1, 10.

The latest version of the USB driver is available for download from the following URL:

<http://www.kenwood.com/usb-com/>

(This URL may change without notice.)

2.2.5.4 Programming software KPG-D3/D3N description

The FPU is the programming software for the transceiver supplied on a CD. This software runs under Windows 7, 8.1, 10. The data can be input to or read from the transceiver and edited on the screen.

Note:

KPG-D3N can't be used for E type.

2.2.6 Firmware Programming Mode

2.2.6.1 Preface

Flash memory is mounted on the transceiver. This allows the transceiver to be upgrade when new features are released in the future. (For details on how to obtain the firmware, contact Customer Service.)

2.2.6.2 Connection procedure

Connect the transceiver to the personal computer using the programming interface (KPG-46U/46X). (Connection is same as in the PC mode.)

2.2.6.3 Programming

- (1) Start up the firmware programming software (KENWOOD Firmware Loader). The KFL.exe exists in the KPG-D3/D3N installed folder.
- (2) Set the baud rate to "auto" or 1152000, 576000, 115200, and 57600.
- (3) Set the firmware to be upgrade by file name item.
- (4) Enter the Firmware programming mode by using section "2.2.2 How to Enter Each Mode". Then, the yellow LED on the transceiver light and "FIRMWARE PROG" is displayed.
- (5) Check the connection between the transceiver and the personal computer, and make sure that the transceiver is in the Program mode.
- (6) Press "Write" button in the window. When the transceiver starts to receive data, the "LOADING" display lights.
- (7) If writing ends successfully, the checksum is calculated and a result is displayed.
- (8) If you want to continue programming other transceivers, repeat step (4) to (7).

Note:

If write is performed by KFL, Firmware programming mode will start automatically even if Firmware programming is set to disable in the programming software.

2.2.6.4 Function

If you press the [Δ (AUX)] button while "FIRMWARE PROG" is displayed, the checksum is calculated, and a result is displayed. If you press the [Δ (AUX)] button again while checksum is displayed, "FIRMWARE PROG" is redisplayed.




2.2.7 Clone Mode

Programming data can be transferred from one transceiver to another by connecting them via their modular microphone jacks. The operation is as follows.

■The following data cannot be cloned.


- Tuning data
- Transceiver Embedded Message
- ESN (Electronic Serial Number) data

■Button guide on the Clone/ Front Panel Programming Password input screen.

- Confirm ([] button): The password confirmation
- Delete ([] button): Delete the latest digit from the current password number (Press and hold to delete all password numbers)
- Select([] button): Determine the latest digit of the password number.



(1) In the source transceiver, enter the clone mode by using section "2.2.2 How to Enter Each Mode". When the Clone/ Front Panel Programming Password is set to the transceiver, "Input Password" is displayed on the LCD. If the password is not set, the transceiver displays "CLONE MODE".


(2) When you enter the correct password, "CLONE MODE" is displayed, the transceiver can be used as the cloning source. The following describes how to enter the password.


- (3)
- **How to enter the password using the MIC keypad;**
If one of the buttons 0 to 9 is pressed while the "Input Password" is displayed, the password number is displayed on the LCD. Each press of the button shifts the display in order to the left.
When you enter the password and press [] or [*] button, "CLONE MODE" displayed if the entered password is correct. If password is incorrect, "Input Password" is redisplayed.

- **How to enter password using the [▲] and [▼] buttons;**

If the [▲] / [▼] button is pressed while "Input Password" is displayed, the Clone/ Front Panel Programming Password input screen is displayed.

If the [▲] or [▼] button is pressed while the clone/ Front Panel Programming Password input screen is displayed, the number (0 to 9) blinks on the LCD. When you press the [] button, currently selected number is determined. If you press the [] button after entering password in this procedure, "CLONE MODE" is displayed if entered password is correct. If the password is incorrect, "Input Password" is redisplayed.

- (4) Power ON the target transceiver.
(5) Connecting the cloning cable (part No.E30-3382-05) to the modular microphone jacks on the source and target.
(6) Press [] button on the source while the source displays "CLONE MODE". The data of the source is sent to the target. While the target is receiving the data, "PROGRAM" is displayed. When cloning of the data is completed, the source displays "END", and the target automatically operates in the User mode. The target can then be operated by the same program as the source.

- (7) The other target can be continuously cloned. When the [] button on the source is pressed while the source displays "END", the source displays "CLONE MODE". Carry out the operation in step (4) to (6).

Note:

- Cannot be cloned if the Password (Write) is programmed to the target.
- "Model name" must be same to clone the transceiver.




Fig.2

2.2.8 Front Panel Programming Mode




If the Front Panel Programming Mode is used, the frequency or other data of the conventional channel is rewritable only by the transceiver.

Moreover, the conventional channel can be added.

■The following setup items can be changed or added by using the Front panel programming mode.

- RX/TX Frequency
- Channel Type
- Transmit Mode (Mixed mode only)
- Channel Spacing
- Decode QT/DQT/RAN, Encode QT/DQT/RAN
- Color Code
- Slot Selection
- Transmit Power
- Channel Name

■Button guide on the Clone/ Front Panel Programming Password input screen.

- Confirm ([] button): The password confirmation
- Delete ([] button): Delete the latest digit from the current password number (Press and hold to delete all password numbers)
- Select ([] button): Determine the latest digit of the password number.

2.2.8.1 Enter to the Front panel programming mode.

Enter to the Menu Mode by pressing [Front Panel Mode] PF button or [Menu] button. When the Front Panel Mode is selected, it can enter to the Front panel programming mode.

If the Clone/Front panel programming Password is not set to the transceiver, "Panel Program" is displayed on the LCD.

If the Clone/Front panel programming Password is set to the transceiver, "Panel Program" is displayed on the LCD when you enter the correct password while "Input Password" is displayed.

2.2.8.2 Data Writing

Before moving to next Zone/Channel, "Keep This Change?" appears on the LCD, if you select "OK", the new data is written to memory. If you select "Cancel", the new data not be written; the new data will be erased.

- The setup items for Front panel programming mode are as follows.

No.	Setup item	Display	Remarks
1	RX Frequency	RX Frequency	Receive Frequency
2	TX Frequency	TX Frequency	Transmit Frequency
3	Channel Type	Channel Type	Analog/NXDN/DMR
4	Transmit Mode *3	Transmit Mode	Analog/NXDN/DMR
5	Channel Spacing	Channel Space	Analog: 12.5kHz/20kHz/25kHz Note: 20kHz is applied for E type only.
			NXDN: 6.25kHz/12.5kHz
			DMR: 12.5kHz

No.	Setup item	Display	Remarks
6	RX Signaling	RX QT/DQT	Receive QT/DQT
7	TX Signaling	TX QT/DQT	Transmit QT/DQT
8	RX RAN	RX RAN	None, 1~63
9	TX RAN	TX RAN	None, 1~63
10	Color Code	Color Code	0~15
11	Slot Selection	Slot Selection	Slot 1, Slot 2
12	Transmit Power	Transmit Power	Low/Medium/High
13	Channel Name	Channel Name	

*3: In "Channel Type" display, "Transmit Mode" can be entered only when Mixed mode is selected.

- Button operation

Button \ Item	Zone Select	Channel Select	RX Frequency	TX Frequency	Channel Type	Transmit Mode *5	Channel Spacing
[]	Decision	Decision	Decision	Decision	Decision	Decision	Decision
[←]	Unused	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item
[△]	Unused	Unused	Go to the TX Frequency	Go to the RX Frequency	Unused	Unused	Unused
[⏏]	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode
[▲]	Zone change	Channel change	Frequency up	Frequency up	Channel type change	Transmit Mode Change	Channel Spacing Change
[▼]	Zone change	Channel change	Frequency down	Frequency down	Channel type change	Transmit Mode Change	Channel Spacing Change
[▶]	Unused	Unused	Frequency step change	Frequency step change	Unused	Unused	Unused
[◀]	Unused	Unused	Frequency step change	Frequency step change	Unused	Unused	Unused
MIC Keypad [0] ~ [9]	Zone number select	Channel number select	Go to the direct enter mode		Channel number select (1,2 or 3)	Transmit Mode number select (1 or 2)	Channel spacing select *4
MIC Keypad [*]	Decision	Decision	Decision	Decision	Decision	Decision	Decision
MIC Keypad [#]	Unused	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item

Button Item	RX Signaling	TX Signaling	RX RAN	TX RAN	Color Code	Slot Selection	Transmit Power	Channel Name
[]	Decision	Decision	Decision	Decision	Decision	Decision	Decision	Decision
[↶]	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item/ Delete
[△]	Unused	Unused	Unused	Unused	Unused	Unused	Unused	Character/Digit switching
[🏠]	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode	Exit panel program mode
[▲]	Signaling number change	Signaling number change	RX RAN up	TX RAN up	Color Code up	Slot up	Transmit power change	Go to the direct enter mode
[▼]	Signaling number change	Signaling number change	RX RAN down	TX RAN down	Color Code down	Slot down	Transmit power change	
[▶]	Signaling type change	Signaling type change	RX RAN ON/OFF	RX RAN ON/OFF	Unused	Unused	Unused	
[◀]	Signaling type change	Signaling type change	RX RAN ON/OFF	RX RAN ON/OFF	Unused	Unused	Unused	
MIC Keypad [0] ~ [9]	Go to the direct enter mode					Slot number select (1 or 2)	Transmit power select (1, 2 or 3)	
MIC Keypad [*]	Decision	Decision	Decision	Decision	Decision	Decision	Decision	Decision/ Character/ Digit switching
MIC Keypad [#]	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item	Back to the previous item

*4: K type

*5: Mixed Mode only

Channel spacing select (1 or 2)

E type


Channel spacing select (1, 2 or 3)

• Direct enter mode

Button Item	RX Frequency	TX Frequency	RX Signaling	TX Signaling	RX RAN	TX RAN	Color Code	Channel Name
[]	Decision							Character/Channel name decision
[↶]	Delete							
[△]	Unused							Input character switching
[🏠]	Exit panel program mode							
[▲]	Unused							Character selection (upper case character → lower-case character → digit → upper case character...)
[▼]								Character selection (upper case character → lower-case character → digit → upper case character...)
[▶]								Move a cursor to the right
[◀]								Move a cursor to the left
MIC Keypad [0] ~ [9]	Add a digit to the current number							
MIC Keypad [*]	Decision							Input character switching
MIC Keypad [#]	Delete/Back to the previous item							Delete

• Front panel programming mode flow chart


Enter the Front panel programming mode by using section "2.2.2 How to Enter Each Mode".



2.2.9 Transceiver Information Mode

Use this function to confirm the transceiver firmware version, Encryption Library Version.

- (1) Enter the Transceiver Information mode by using section "2.2.2 How to Enter Each Mode".
- (2) The transceiver firmware version appears on the LCD.
- (3) Use the [▲] and [▼] buttons to select the confirmation items.



- (4) To exit the transceiver information mode, turn the transceiver power OFF.

Note:

The Encryption Library Version will also display Radio Feature License (KWD-3004AE) as Inactive.

2.3 INSTALLATION

2.3.1 Connection Cable (KCT-60: Option)


The KCT-60 connection cable kit is used to connect the transceiver to a Horn alert cable, KCT-18 (Ignition sense cable), KES-5 (External speaker), or through the KCT-36 extension cable.

2.3.1.1 Installing the KCT-60 (Connection cable) in the transceiver

- (1) Remove the ACC. cap on the rear of the transceiver.
- (2) Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
- (3) Connect the 15-pin connector of the KCT-60 to a Horn alert cable, KCT-18, KES-5, or through a KCT-36 extension cable.

Note:

You must setup using the KPG-D3/D3N.



D-sub 15-pin Pin No.	Name	Molex 15-pin Pin No.
11	FNC6	10
12	5C	-
13	HR1	13
14	HR2	14
15	GND	3


2.3.2 Horn Alert Function

The Horn alert function (max. 2A drive) is enabled by installing the KCT-60 in the transceiver.

2.3.2.1 Installation Procedure

- (1) Remove the ACC. cap on the rear of the transceiver.
- (2) Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
- (3) Insert the two crimp terminals of the Horn alert cable to pins 13 and 14 of the square plug.
- (4) Connect the square plug to the 15-pin connector of the KCT-60.
- (5) Connect the remaining two Horn alert cables to your car Horn alert signal control.

The internal FET switch can be controlled by turning the HA function on/off and by using a signaling decode output. The maximum current of HA is 2A. This switch is the FET switch of P-channel type. Therefore, a DC power supply is necessary to use the HR1. The voltage range is from 5V to 16V.




2.3.1.2 Terminal function

D-sub 15-pin Pin No.	Name	Molex 15-pin Pin No.
1	SB	1
2	IGN	2
3	PA or EXT-SP	12
4	DO	4
5	DI	5
6	FNC1	9
7	FNC2	11
8	FNC3	7
9	FNC4	6
10	FNC5	8

Note:


You must set up using the KPG-D3/D3N.



2.3.3 Ignition Sense Cable (KCT-18: Option)

The KCT-18 is an optional cable for enabling the ignition function. The ignition function lets you turn the transceiver power on and off with the car ignition button.

2.3.3.1 Installing the KCT-18 (Ignition sense cable) in the transceiver



2.3.4 External Speaker (Option)

2.3.4.1 KES-5


External speaker KES-5 can be installed for KCT-60.

■Connection procedure

- (1) Remove the ACC. cap on the rear of the transceiver.
- (2) Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
- (3) Insert the two crimp terminals of the KES-5 to pins 3 and 12 of the square plug.
- (4) Connect the square plug to the 15-pin connector of the KCT-60.

Note:

You must set up using the KPG-D3/D3N.
Before the external speaker can be used, you must assign one of the buttons as "External Speaker", using the KPG-D3/D3N.



2.3.5 Changing Serial Port Level

2.3.5.1 Change FNC1 (TXD) and FNC2 (RXD) of D-SUB 15-pin connector from TTL level to RS-232C level


FNC1 (TXD /6pin) and FNC2 (RXD /7pin) of D-SUB 15-pin connector are configured at the TTL level as the default value. But you can change these serial port level to RS-232C level through the RS-232C level converter IC (IC605) by configuring the port.

Remove the R625, R633 and R634 chip jumpers and solder the chip jumpers to R605, R610 and R611.

2.3.5.2 Change FNC1 (TXD), FNC2 (RXD), FNC3 (RTS) and FNC4 (CTS) of D-SUB 15-pin connector from TTL level to RS-232C level

FNC1 (TXD /6pin), FNC2 (RXD /7pin), FNC3 (RTS /8pin) and FNC4 (CTS /9pin) of D-SUB 15-pin connector are configured at the TTL level as the default value. But you can change these serial port level to RS-232C level through the RS-232C level converter IC (IC605) by configuring the port.

Remove the R623, R625, R630, R631, R633 and R634 chip jumpers and solder the chip jumpers to R604, R605, R608, R609, R610 and R611.



■In the case of 5-1.

[TTL level]

R625, R633 and R634: 0ohm chip jumper.
R605, R610 and R611: open.

[RS-232C level]

R605, R610 and R611: 0ohm chip jumper.
R625, R633 and R634: open.

■In the case of 5-2.

[TTL level]

R623, R625, R630, R631, R633 and R634: 0ohm chip jumper.
R604, R605, R608, R609, R610 and R611: open.

[RS-232C level]

R604, R605, R608, R609, R610 and R611: 0ohm chip jumper.
R623, R625, R630, R631, R633 and R634: open.

2.3.6 Changing of Signal Type

2.3.6.1 Change signal output of D-SUB connector from DEO to AFO

The output (4pin) of D-SUB 15-pin connector is configured at the DEO as the default value.

Remove the R613 chip jumper and solder the clip jumper to R612.

2.3.6.2 Change signal input of D-SUB connector from DI to MI2

The input (5pin) of D-SUB 15-pin connector is configured at the DI as the default value.

Remove the R659 chip jumper and solder the chip jumper to R601.

2.4 CIRCUIT DESCRIPTION

2.4.1 Overview

The NX-3720H/3720 is a VHF Analog FM & Digital Mobile transceiver designed to operate in the frequency range of 136 to 174MHz. The NX-3820H/3820 is a UHF Analog FM & Digital Mobile transceiver designed to operate in the frequency range of 450 to 520MHz (K) or 400 to 470MHz (K2, E).

The unit consists of a transceiver IC, a transmitter, a digital control unit, and a power supply circuit.

2.4.2 Frequency Configuration

The receiver uses the direct conversion system. Incoming signals from the antenna are mixed with the local signal from the PLL circuit and converted to the baseband signal. The transmit signal frequency is generated by the VCO/PLL, and modulated by the signal from the DSP. It is then amplified and fed to the antenna.




Fig.1 Frequency Configuration

2.4.3 Receiver System

2.4.3.1 RF circuit

The receive signal from ANT SW (D205, D206, D207, D208 and D209) passes through the high-pass filter (L303, L304, L313, L315 and L317 (L315 and L317 are the NX-3720H/3720 only.)) to remove unwanted signals and amplified by a RF amplifier (incorporated in IC302). The signal is then fed to the mixer (incorporated in IC302) and converted to the baseband signal.

2.4.3.2 Baseband circuit

The baseband signal is then fed into an ADC (incorporated in IC302), generates the I and Q data. This data is in the form of Serial Interface, and sent to the MPU/DSP (IC404).




Fig.2 RF and Baseband circuit

2.4.3.3 Audio amplifier circuit

Audio processing (high-pass filter, low-pass filter, de-emphasized and so on) at Analog FM mode and decoding at Digital mode are processed by MPU/DSP. I2S signal from DSP is converted to audio signal at IC607. The signal goes to internal speaker and connector for external speaker (J2) through the electronic volume control (IC412), pre amplifier (IC608) and audio power amplifier (IC601).

2.4.4 Transmitter System

2.4.4.1 Audio Band Circuit

The signal from microphone is amplified and converted to digital signal by IC607. IC607 includes AGC function. Digital signal is transferred to IC404.

2.4.4.2 Baseband Circuit

The audio signal transferred from IC607 is processed at IC404. Voice signals of 300Hz or lower and frequencies of 3 kHz or higher are cut off and an audio range 300Hz to 3 kHz is extracted. The audio signal is then pre-emphasized in FM mode and synthesized with the signals, such as QT and DQT, as required, and is transferred to PLL Frequency Synthesizer block in IC302. The DTMF and MSK baseband signals are also generated by IC404.

In Digital mode, the audio signal is converted to the 4-Level FSK baseband signal and is transferred to PLL Frequency Synthesizer block in IC302.

2.4.4.3 Drive and Final amplifier

The RF signal from IC302 is amplified by pre-drive amplifier (IC202). The output of the pre-drive amplifier is amplified by the drive amplifier (Q201) and RF Power module (IC201) to 50W [NX-3720H], 45W [NX-3820H], 25W [NX-3720, NX-3820] (5W when the power is low). IC202 is MMIC. Q201 is MOS FET. The output of the final amplifier is then passed through the coupler, antenna switch (D205, D206 and D207), harmonic filter (LPF) and applied to the antenna terminal.

2.4.4.4 APC circuit

The Automatic transmission power control (APC) circuit controls the transmitter output in adjusted value by monitoring it with a coupler. RF detection and comparison functions are included in the power-control IC (IC205).

The power control IC output is given as a drive source of the RF power module's gate (IC201), and completes APC feedback loop. When a normal antenna load is connected, forward RF Power is detected by the coupler and direct in power-control IC (IC205). Forward RF Power is converted into DC voltage in IC205 and compared with the SPC.

The output voltage goes through DC amp (IC203 2/2) to Drive amp (Q201) and RF Power module (IC201).

The voltage controls the gate bias voltage of Q201 and IC201, and keeps transmission output stable.




Fig.3 Drive and Final amplifier and APC circuit

2.4.5 PLL Frequency Synthesizer

2.4.5.1 TCXO (X401)

TCXO (X401) generates a reference frequency of 19.2MHz for the PLL frequency synthesizer. This reference signal is buffered by Q401. And it is distributed to PLL (IC302).

The oscillation frequency is adjusted TCXO directly by controlled the D/A converter of FCNT.

2.4.5.2 VCO

• **NX-3720H (K), NX-3720 (E)**

There is one VCO contain TX VCO and RX VCO.

The VCO (Q105) generates the carrier for the transmitter and the receiver. VCO oscillation frequency range is 272 to 348MHz. The transmit frequency range is same as receiver frequency range.

The local signal frequency range is also 272 to 348MHz.

The oscillation frequency is divided into two by IC 302 and it becomes the use frequency.

The VCO oscillation frequency is determined by voltage control terminals "CP" and "ASSIST".

The voltage control terminal "CP" is controlled by PLL (IC302). The voltage control terminal "ASSIST" is controlled by the control voltage from D/A converter (IC411).

For the modulation input terminal, "VCO_MOD" of PLL (IC302), the output frequency changes according to the applied voltage. This is used to modulate the VCO output.

• **NX-3820H (K)**

There is one VCO contain TX VCO and RX VCO.

The VCO (Q105) generates the carrier for the transmitter and the receiver. VCO oscillation frequency range is 300 to 346.7MHz. The transmit frequency range is same as receiver frequency range.

The local signal frequency range is 900 to 1040MHz. The local signal is three times the number of VCO oscillation frequency range.

The output frequency is divided into two by IC 302 and it becomes the use frequency.

The VCO oscillation frequency is determined by voltage control terminals "CP" and "ASSIST".

The voltage control terminal "CP" is controlled by PLL (IC302). The voltage control terminal "ASSIST" is controlled by the control voltage from D/A converter (IC411).

For the modulation input terminal, "VCO_MOD" of PLL (IC302), the output frequency changes according to the applied voltage. This is used to modulate the VCO output.

• **NX-3820H (K2), NX-3820 (E)**

There is one VCO contain TX VCO and RX VCO.

The VCO (Q105) generates the carrier for the transmitter and the receiver. VCO oscillation frequency range is 266.7 to 313.3MHz. The transmit frequency range is same as receiver frequency range.

The local signal frequency range is 800 to 940MHz. The local signal is three times the number of VCO oscillation frequency range.

The output frequency is divided into two by IC 302 and it becomes the use frequency.

The VCO oscillation frequency is determined by voltage control terminals "CP" and "ASSIST".

The voltage control terminal "CP" is controlled by PLL (IC302). The voltage control terminal "ASSIST" is controlled by the control voltage from D/A converter (IC411).

For the modulation input terminal, "VCO_MOD" of PLL (IC302), the output frequency changes according to the applied voltage. This is used to modulate the VCO output.

2.4.5.3 PLL IC

PLL (IC302) compares the difference in phases of the VCO oscillation signal and the TCXO(X401) reference frequency. And it returns the difference voltage to the VCO CP terminal and realizes the "Phase Locked Loop".

This allows the VCO oscillation frequency to accurately match (lock) the desired frequency.

When the frequency is controlled by the PLL, the frequency convergence time increases as the frequency difference increases when the set frequency is changed. To supplement this, The ASSIST Voltage from D/A converter (IC411) is used before control by the PLL (IC302) to bring the VCO oscillation frequency close to the desired frequency. As a result, the VCO CP voltage does not change and is always stable at approx. 2.5V.

The desired frequency is set for the PLL (IC302) by the MPU/DSP (IC404) through the 3-line "/DCR_CS", "DCR_DO", "BCLK" serial bus for PLL. IC404 monitors through the "PLD", whether the PLL (IC302) is locked or not. If the VCO does not lock to desired frequency (unlock), the "PLD" logic is low.

2.4.6 Control Circuit

The control circuit consists of MPU/DSP (IC404) and its peripheral circuits. IC404 mainly performs the following;

- (1) Switching between transmission and reception by PTT signal input.
- (2) Reading system, zone, frequency, and program data from the memory circuit.
- (3) Sending frequency program data to the PLL.
- (4) Controlling the audio mute circuit by decode data input.

2.4.6.1 MPU

The MPU/DSP (IC404) is 32bit RISC processor and Fixed/Floating-Point VLIW DSP, equipped with peripheral function.

This MPU operates at 288MHz (MAX) clock and 3.2V /1.8V/1.2V DC. Controls the flash memory, Mobile DDR, the receive circuit, the transmitter circuit, the control circuit, and the display circuit and transfers data to or from an external device.

2.4.6.2 Memory Circuit

Memory circuit consists of the MPU/DSP (IC404) and the Mobile DDR (IC402), the flash memory (IC401). The flash memory has capacity of 512Mbit that contains the transceiver control program for the MPU and stores the data. It also stores the data for transceiver channels and operating parameter that are written by the FPU. This program can be easily written from external devices. The Mobile DDR has capacity of 512Mbit. The MPU copies the program to the Mobile DDR from Flash memory. And MPU is used as a work area Mobile DDR.

■Flash memory

Note:

The flash memory stores the data that is written by the FPU (KPG-D3/D3N), tuning data (Deviation, Squelch, etc.), and firmware program (User mode, Test mode, Tuning mode, etc.). This data must be rewritten when replacing the flash memory.

■Mobile DDR (static memory)

Note:

Mobile DDR is used as a work area of the MPU.

2.4.6.3 LCD

LCD interface connector (CN6) of the SUB unit.

The LCD is controlled using parallel interface from MPU/DSP (IC404) through the interface connectors (CN1 of the TX-RX unit and CN7 of SUB unit) and flexible cable.

2.4.6.4 Button Detection Circuit

Buttons are detected using I/O Expander IC (IC6) of the SUB unit. If pressed button is detected by IC6, it is informed to MPU/DSP (IC404) of the TX-RX unit through serial line.

2.4.6.5 DSP

The DSP circuit consists of a MPU/DSP (IC404) and processes the baseband signal. The DSP operates at 288MHz (MAX) clock, the I/O section operates at 3.2V/1.8V and the core section operates at 1.2V.

The DSP carries out the following processes:

- 4Level FSK processing
- Analog FM pre-emphasis/de-emphasis
- Vocoder processing between audio codec and modulation/demodulation
- CAI processing, such as error correction encoding
- QT/DQT encoding/decoding
- DTMF encoding/decoding
- MSK encoding/decoding
- 2-tone /5-tone encoding/decoding
- Compressor/expander processing
- Voice scrambler processing
- Transmit/receive audio filtering processing
- Microphone amplifier AGC processing
- Audio mute processing
- Modulation level processing
- Active Noise Reduction
- Voice recording/playback processing
- Voice announce processing

2.4.7 Power Supply Circuit

+B is connected to RF Power Module, 50BU regulator (Q15, Q16 and D13) through the fuse (F1), DC/DC converter IC (IC25) via fuse (F1), SB1 switch (Q12 and Q13) through the fuse (F4) and SB2 switch (Q17 and Q18) through the fuse (F5).

Q15, Q16 and D13 regulates +B voltage to 5V (50BU). Then IC13 regulates 50BU to 3.1V (31BU). Then IC15 regulates 31BU to 1.2V (12BU). 50BU, 31BU and 12BU operate whenever +B is supplied.

IC25 regulates +B voltage to 5.4V (54M). 54M is controlled by BAT_CNT signal from Power management IC (IC22). When Power switch is turned on, BAT_CNT signal is controlled by /PSW signal. 54M goes to DC/DC converter ICs (IC24, IC12) and AVR ICs (IC20, IC17, IC26, IC609, IC23).

IC24 (12M) is enabled while the 54M is operating. 12M provides the power to the MPU/DSP (IC404) and turns on IC12 (18M). 18M provides the power to the MPU/DSP and DDR (IC402) and turns on IC20 (32M). 32M provides the power to the MPU/DSP, Flash memory (IC401) and many control circuits and turns on IC17 (32A), IC26 (50A). Then 32A turns on IC21 (18M_3).

The Power management IC (IC22) watches +B voltage. If +B voltage is higher than 8.5V, IC22 outputs high voltage to the /BINT terminal. If the /BINT is high, SB1 (Q12 and Q13) and SB2 (Q17 and Q18) are turned on by SBC signal from MPU/DSP (IC404). In the same way, IC609 (50AC) and IC23 (50C) and IC19 (32C) are turned on by SBC. 50C is fed to IC14 (200C). IC14 (200C) is the DC/DC boost converter. The 200C circuit then outputs approximately +20VDC.

SB1 supplies SUB unit and Audio power amplifier (IC601) with +B voltage. SB2 supplies D-sub unit and 9VAVR (IC1) with +B voltage. Then IC1 regulates +B to 9V (90C). Then IC16 regulates 90C to 5V (50CT). If the MPU/DSP (IC404) controls TXC, ANT SW and ASSW signals to High, Q20, Q23 (90T), Q21, Q22 (90ANT) and Q206 are turned on and transmission circuits are enabled to transmit. When the Power management IC (IC22) and MPU/DSP (IC404) detect /PSW signal (Power switch), /IGN signal (Ignition sense) and /BINT signal, they set the SBC signal to Low, and turn the transceiver power off.

When D20, Q11 detect over-voltage condition, they turn SB1 and SB2 off, and transfer that the MPU/DSP (IC404) through IC22.




Fig.4 Power Supply Circuit

2.4.8 Signaling Circuit

2.4.8.1 Encode (QT/DQT/DTMF/2-tone /MSK)

Each signaling data signal of QT, DQT, DTMF, 2-tone and MSK is generated by IC404, superposed on a modulation signal and output to VCO and PLL.

2.4.8.2 Decode (QT/DQT/DTMF/2-tone/MSK)

The audio signal and signaling data (QT, DQT, DTMF, 2-tone and MSK) are separated by IC404. Next IC404 decode the signaling data.

2.4.9 Bluetooth/GPS Circuit (GPS model only)

The main component of the Bluetooth/GPS circuit is Bluetooth/GPS IC (IC5) on Module unit.

The clocks of Bluetooth/GPS IC require 19.2MHz for core and 32.768 kHz slow clock (X1 and X2) for UART.

Bluetooth/GPS IC communicates to the MPU/DSP (IC404) on the HCI UART. Interface of UART & Digital audio (PCM) between the MPU/DSP (IC404) and the Bluetooth/GPS IC (IC5), have level conversion at the level conversion IC (IC6 and IC7) on Module unit.

The Bluetooth/GPS IC is powered by 1.8V and 3.3V which are supplied from 2 discrete external regulators (IC2 and IC3) on Module unit.




Fig.5 Bluetooth/GPS Circuit

2.4.9.1 Bluetooth Circuit

TX/RX frequency is 2400-2483.5MHz (79ch Hopping, 2402-2480MHz, 1MHz step). Transmitting power is +2dBm at Bluetooth antenna input.

Using the printed antenna with Bluetooth, and connected to the Bluetooth/GPS IC (IC5) through the saw filter (L11).

Frequency configuration for Bluetooth is following:

There are two LO modes: 2X and Offset LO (OSLO). 2X where LO is $2 * RF_FREQ$ (e.g. when transmitting at 2441MHz it is at 4882MHz). OSLO where LO is at $(2/3) * RF_FREQ$ (e.g. when transmitting at 2441MHz it is at 1627.333MHz).

In RX the 2X is always used.

In GFSK TX if power is >10dBm then OSLO is used

In EDR2 TX if power is >-12dBm then OSLO is used

In EDR3 TX if power is >-12dBm then OSLO is used

Otherwise 2X is used for TX as well.

2.4.9.2 GPS Circuit

The GPS RF signal is received with the active antenna, and connected to the Bluetooth/GPS IC (IC5) through the terminal (CN5) and saw filter (L9).

The output is passed to pin L2 of the GPS IC. The input match for pin L2 comprises of C38, C36 and L7. The control and data lines for the GPS IC are GPS_PA_EN, BTFM_nSHUTDOWN, GPS_TX and GPS_RX. GPS_TX and GPS_RX are shared with Bluetooth data line.

Frequency configuration for GPS is following:

Lo is GPS: 1571.324MHz




Fig.6 GPS Circuit

2.5 COMPONENTS DESCRIPTION

2.5.1 TX-RX unit (XC1-182K-00,XC1-183K-XX)

Ref. No.	Part Name	Use / Function
IC1	IC	Voltage regulator (90C)
IC12	IC	DC/DC converter (18M)
IC13	IC	Voltage regulator (31BU)
IC14	IC	DC/DC converter (200C)
IC15	IC	Voltage regulator (12BU)
IC16	IC	Voltage regulator (50CT)
IC17	IC	Voltage regulator (32A)
IC18	IC	Ignition
IC19	IC	Voltage regulator (32C)
IC20	IC	Voltage regulator (32M)
IC21	IC	Load Switch (18M_3)
IC22	IC	Power management
IC23	IC	Voltage regulator (50C)
IC24	IC	DC/DC converter (12M)
IC25	IC	DC/DC converter (54M)
IC26	IC	Voltage regulator (50A)
IC101	IC	DC amplifier (CV/Assist)
IC202	IC	MMIC (Pre-drive)
IC203	IC	DC amplifier (APC)
IC205	IC	RF power control
IC301	IC	Attenuation
IC302	IC	Transceiver IC
IC401	IC	Flash memory
IC402	IC	SDRAM
IC403	IC	Logic control
IC404	IC	MPU/DSP
IC405,406	IC	Analog switch
IC407,408	IC	Logic control
IC409	IC	I/O expander
IC410	IC	A/D converter
IC411,412	IC	D/A converter
IC413	IC	Ignition
IC414	IC	DC amplifier (VREF/25VREF)
IC602,603	IC	Logic control
IC604	IC	I/O expander
IC605	IC	RS232C Driver
IC606	IC	Logic control
IC607	IC	Codec
IC608	IC	Audio amplifier
IC609	IC	Voltage regulator (50AC)
Q11	Transistor	DC switch (OVRB)
Q12	FET	DC switch (SB1)
Q13,14	Transistor	DC switch
Q15,16	Transistor	Voltage regulator (50BU)

Ref. No.	Part Name	Use / Function
Q17	FET	DC switch (SB2)
Q18	Transistor	DC switch
Q19	FET	DC switch
Q20	FET	DC switch (90T)
Q21	Transistor	DC switch
Q22	FET	DC switch (90ANT)
Q23	Transistor	DC switch
Q25	Transistor	DC switch (SBC)
Q101	Transistor	Tripler
Q102	Transistor	Tripler
Q103	FET	DC switch
Q104	Transistor	Ripple filter
Q105	FET	VCO oscillation
Q106,107	Transistor	VCO Buffer amplifier
Q201	FET	TX Drive amplifier
Q202	Transistor	DC switch
Q204-206	Transistor	DC switch
Q301	FET	DC switch
Q401	Transistor	TCXO Buffer amplifier
Q402-404	FET	DC switch
Q601	FET	Level conversion
Q602	Transistor	DC switch
Q603	FET	Horn alert switch
Q604	Transistor	Audio mute
Q605	FET	Audio mute
Q606	FET	DC switch
D1	Zener diode	Reverse protection
D13	Zener diode	Voltage regulator (50BU)
D14,15	Diode	Reverse current prevention
D16,17	Diode	DC/DC converter
D18,19	Diode	Reverse current prevention
D20	Zener diode	Over voltage protection
D21	Diode	Reverse current prevention
D22	Zener diode	Over voltage protection
D24	Diode	Backup battery charge
D26,27	Diode	Reverse current prevention
D101	Zener diode	Over voltage protection
D102	Variable capacitance diode	VCO frequency control
D103-106	Variable capacitance diode	VCO assist tune
D107	Zener diode	Speed up
D108	Variable capacitance diode	TX modulation
D201	Zener diode	Over voltage protection
D202	Diode	RF switch
D204	Diode	TX Reverse power detection

Ref. No.	Part Name	Use / Function
D205-209	Diode	Antenna switch
D301-304	Diode	Excessive input protection
D401	Diode	Reverse current prevention
D402-406	Diode	Line protection
D407	Zener diode	Over voltage protection
D408-410	Diode	Reverse current prevention
D601	Zener diode	Over voltage protection
D602	Diode	Reverse current prevention
D603-608	Zener diode	Line protection
D609,610	Diode	Line protection
D611	Zener diode	Over voltage protection
D612,613	Diode	Line protection
D614,615	Diode	Reverse current prevention
D616,617	Diode	Surge protection
D618	Diode	Over voltage protection
D619	Diode	Reverse current prevention

2.5.2 SUB unit (XC3-050M-00)

Ref. No.	Part Name	Use / Function
IC1	IC	Voltage regulator (50M)
IC3,4	IC	Level conversion
IC5	IC	Bus switch
IC6	IC	I/O expander
Q1	FET	DC switch
Q2	FET	DC switch (KEY Illumination)
Q3,4,6	Transistor	DC switch (TX/BUSY)
Q8	FET	DC switch (LCD backlight)
D1,2	Diode	Surge protection
D3-6	LED	KEY Illumination
D9,10	LED	LCD backlight
D11,12	LED	KEY Illumination
D15,16	LED	LCD backlight
D17,18	LED	KEY Illumination
D20	LED	TX/BUSY LED
D21	Zener diode	Over voltage protection
D22	Diode	Reverse current protection
D24	Zener diode	Over voltage protection
D26	Zener diode	Over voltage protection
D27	Diode	Over current protection
D28	Zener diode	Over voltage protection
D30	Zener diode	Over voltage protection
D32	Zener diode	Over voltage protection
D33,34	LED	KEY Illumination

2.5.3 Module(BT/GPS) unit (XC2-0040-10)

Ref. No.	Part Name	Use / Function
IC1	IC	Level conversion
IC2	IC	Voltage regulator (18BT)
IC3	IC	Voltage regulator (33BT)
IC4	IC	Voltage regulator (33GPS)
IC5	IC	GPS/Bluetooth
IC6,7	IC	Level conversion
Q1	FET	DC switch
D17,18	Diode	Over voltage protection

2.6 TERMINAL FUNCTION

2.6.1 TX-RX unit (XC1-182K-00,XC1-183K-XX)

Pin No.	Name	I/O	Function
CN1			
1	GND	-	Ground
2	GND	-	Ground
3	GND	-	Ground
4	NC	-	No connection
5	SP+	O	Speaker output
6	SP+	O	Speaker output
7	SP+	O	Speaker output
8	NC	-	No connection
9	GND	-	Ground
10	GND	-	Ground
11	GND	-	Ground
12	GND	-	Ground
13	IGN	-	Ignition sense input
14	SB1	O	Switched power supply
15	SB1	O	Switched power supply
16	SB1	O	Switched power supply
17	SB1	O	Switched power supply
18	NC	-	No connection
19	54M	O	5.4V output
20	NC	-	No connection
21	32M	O	3.2V output
22	NC	-	No connection
23	18M	O	1.8V output
24	NC	-	No connection
25	GND	-	Ground
26	USB_D+	I/O	USB0 PHY data plus
27	GND	-	Ground
28	USB_D-	I/O	USB0 PHY data minus
29	GND	-	Ground
30	NC	-	No connection
31	MIC/VBUS	I	MIC signal input / USB VBUS Detection

Pin No.	Name	I/O	Function
32	ME	-	MIC ground
33	/PTT	I	PTT input
34	DM	I/O	MIC data detection
35	/PSW	I	Detection signal input of power switch
36	TXD	O	Serial data output
37	RXD	I	Serial data input
38	GND	-	Ground
39	I2CDT	I/O	I2C serial data
40	I2CCK	O	I2C serial clock
41	/KEYINT	I	Key state change signal
42	P_TEMP	I	Temperature detection signal
43	/CS	O	LCD driver chip-select signal
44	LCDRST	O	LCD driver reset signal
45	/RD	O	LCD driver RD signal
46	D[7]	O	LCD driver data output
47	D[6]	O	LCD driver data output
48	D[5]	O	LCD driver data output
49	D[4]	O	LCD driver data output
50	D[3]	O	LCD driver data output
51	D[2]	O	LCD driver data output
52	D[1]	O	LCD driver data output
53	D[0]	O	LCD driver data output
54	/WR	O	LCD driver WR signal
55	A23	O	LCD driver data/command switch signal
56	GND	-	Ground
57	R_SET2	I	Radio setting signal 2
58	R_SET1	I	Radio setting signal 1
59	R_SET0	I	Radio setting signal 0
60	GND	-	Ground
CN2			
1	GPS_PWR	I	Antenna power supply detection
2	GPS_ALM	I	Antenna open/short detection
3	GND	-	Ground
4	GND	-	Ground
5	GPS_ANT_SW	O	Enable signal for 33GPS
6	GPS_PA_EN	O	GPS receiver part switching signal output
7	/BT_SHUTDOWN	O	Shutdown signal output
8	WCLK	O	Audio serial data bus word clock output
9	BCLK	O	Audio serial data bus bit clock output
10	BT_AUD_DI	I	Audio signal input
11	BT_AUD_DO	O	Audio signal output
12	RTS2	O	Serial data output

Pin No.	Name	I/O	Function
13	CTS2	I	Serial data input
14	G_RXD2	I	Serial data input
15	G_TXD2	O	Serial data output
16	BT_SW	O	Enable signal for 33BT and 18BT
17	GPSBT_DET	I	BT/GPS unit detection
18	GND	-	Ground
19	54M	O	5.4V output
20	54M	O	5.4V output

2.6.2 Module (BT/GPS) unit (XC2-0040-10)

Pin No.	Name	I/O	Function
CN1			
1	54M	I	5.4V input
2	54M	I	5.4V input
3	GND	-	Ground
4	GPSBT_DET	O	BT/GPS unit detection (Ground)
5	BT_SW	I	Enable signal for 33BT and 18BT
6	G_TXD2	I	Serial data input
7	G_RXD2	O	Serial data output
8	CTS2	O	Serial data output
9	RTS2	I	Serial data input
10	BT_AUD_DO	I	Audio signal input
11	BT_AUD_DI	O	Audio signal output
12	BCLK	I	Audio serial data bus bit clock input
13	WCLK	I	Audio serial data bus word clock input
14	/BT_SHUTDOWN	I	Shutdown signal input
15	GPS_PA_EN	I	GPS receiver part switching signal input
16	GPS_ANT_SW	I	Enable signal for 33GPS
17	GND	-	Ground
18	GND	-	Ground
19	GPS_ALM	O	Antenna open/short detection
20	GPS_PWR	O	Antenna power supply detection

2.6.3 Sub unit (XC3-050M-00)

Pin No.	Name	I/O	Function
J1			
1	DM	I/O	MIC data detection
2	HOOK/RXD/D-	I/O	Hook detection / Serial data input / USB PHY data minus
3	MIC/VBUS	I	MIC signal input
4	ME	-	MIC ground
5	PTT/TXD	I/O	PTT input / Serial data output
6	GND	-	Ground
7	SB	O	Switched power supply

Pin No.	Name	I/O	Function
8	BLC/D+	I/O	Back light control signal / USB PHY data plus
CN3			
1	GND	-	Ground
2	S8	I	Switch 8
3	S9	I	Switch 9
4	S10	I	Switch 10
5	S7	I	Switch 7
6	S6	I	Switch 6
7	S5	I	Switch 5
8	S4	I	Switch 4
9	S1	I	Switch 1
10	S2	I	Switch 2
11	S3	I	Switch 3
12	/PSW	I	Detection signal input of power switch
CN6			
1	ESD	-	Ground
2	A0	O	LCD driver data/command switch signal
3	/WR	O	LCD driver WR signal
4	D0	O	LCD driver data output
5	D1	O	LCD driver data output
6	D2	O	LCD driver data output
7	D3	O	LCD driver data output
8	D4	O	LCD driver data output
9	D5	O	LCD driver data output
10	D6	O	LCD driver data output
11	D7	O	LCD driver data output
12	/RD	O	LCD driver RD signal
13	RSTB	O	LCD driver reset signal
14	CSB	O	LCD driver chip-select signal
15	VDDI	O	1.8V output
16	VD1	-	LCD Driver Internal power supply
17	VSS	-	Ground
18	VDD	O	3.2V output
19	VM	-	VM is the non-select voltage level of COM-drivers
20	V0	-	V0 is the LCD driving voltage for common circuits at positive frame
21	XV0	-	XV0 is the LCD driving voltage for common circuits at negative frame
22	VG	-	VG is the LCD driving voltage for segment circuits
23	ESD	-	Ground
CN5			
1	SP+	O	Speaker output
2	SPG	-	Speaker ground

Pin No.	Name	I/O	Function
CN7			
1	GND	-	Ground
2	R_SET0	O	Radio setting signal 0
3	R_SET1	O	Radio setting signal 1
4	R_SET2	O	Radio setting signal 2
5	GND	-	Ground
6	A23	I	LCD driver data/command switch signal
7	/WR	I	LCD driver WR signal
8	D[0]	I	LCD driver data input
9	D[1]	I	LCD driver data input
10	D[2]	I	LCD driver data input
11	D[3]	I	LCD driver data input
12	D[4]	I	LCD driver data input
13	D[5]	I	LCD driver data input
14	D[6]	I	LCD driver data input
15	D[7]	I	LCD driver data input
16	/RD	I	LCD driver RD signal
17	LCDRST	I	LCD driver reset signal
18	/CS	I	LCD driver chip-select signal
19	P_TEMP	O	Temperature detection signal
20	/KEYINT	O	Key state change signal
21	I2CCK	I	I2C serial clock
22	I2CDT	I/O	I2C serial data
23	GND	-	Ground
24	RXD	O	Serial data output
25	TXD	I	Serial data input
26	/PSW	O	Detection signal input of power switch
27	DM	I/O	MIC data detection
28	/PTT	O	PTT input
29	ME	-	MIC ground
30	MIC/VBUS	O	MIC signal input / USB VBUS Detection
31	NC	-	No connection
32	GND	-	Ground
33	USB_D-	I/O	USB0 PHY data minus
34	GND	-	Ground
35	USB_D+	I/O	USB0 PHY data plus
36	GND	-	Ground
37	NC	-	No connection
38	18M	I	1.8V input
39	NC	-	No connection
40	32M	I	3.2V input
41	NC	-	No connection
42	54M	I	5.4V input
43	NC	-	No connection

Pin No.	Name	I/O	Function
44	SB1	O	Switched power supply
45	SB1	O	Switched power supply
46	SB1	O	Switched power supply
47	SB1	O	Switched power supply
48	NC	-	No connection
49	GND	-	Ground
50	GND	-	Ground
51	GND	-	Ground
52	GND	-	Ground
53	NC	-	No connection
54	SP+	I	Speaker input
55	SP+	I	Speaker input
56	SP+	I	Speaker input
57	NC	-	No connection
58	GND	-	Ground
59	GND	-	Ground
60	GND	-	Ground

2.6.4 D-Sub 15-pin Connector Specification

Pin No.	Pin Name	I/O	Modification	Signal Type	Description	Rating and Condition					
						Parameter	Min	Typ	Max	Unit	
1	SB	O	No	Power	Switched B Output	Voltage	This parameter depends on Battery Voltage				
						Supply Current	-	-	2.0	A	
2	IGN	I	No	Digital	Active High	Input Voltage Range	0	-	30	V	
						Threshold High	6.0	-	-	V	
						Threshold Low	-	5.0	-	V	
3	SP2/PA	O	No	Analog	Speaker output	Audio Output	3	4	-	W	
						Coupling Capacitor	-	330	-	uF	
						RL	3.0	-	-	ohm	
						Allowable Frequency	300.0	-	3000	Hz	
4	DETO	O	Yes	Analog	FM detector output	Output Level	-	0.24	-	Vp-p	
						Coupling Capacitor	-	10	-	uF	
						Allowable Load	-	600	-	ohm	
						Output Impedance	-	100	-	ohm	
	AFO	O			RX Audio output	Output Level	-	0.6	-	Vp-p	
						Coupling Capacitor	-	10	-	uF	
						Allowable Load	-	600	-	ohm	
						Output Impedance	-	100	-	ohm	
5	DATAI	I	Yes	Analog	External Modulation input	Input Voltage Range	-	0.5	-	Vp-p	
						Input Impedance	-	45	-	kohm	
	MI2	I			Analog	External MIC AF Input	Input Voltage Range	-	5.0	-	mVrms
							Allowable Frequency	300	-	3000	Hz
						Input Impedance	-	600	-	ohm	


Pin No.	Pin Name	I/O	Modification	Signal Type	Description	Rating and Condition				
						Parameter	Min	Typ	Max	Unit
6	FNC1 COM1_TXD	I/O	Yes	Digital	Programmable I/O	VIH	4.0	-	5.2	V
						VIL	-0.5	-	1.0	V
						VOH(Io=-1.5mA)	4.0	-	5.2	V
						VOL(Io=1.5mA)	-	-	1.1	V
	TXD (RS-232C)	O	Digital	RS-232C Serial port (TXD)	Voltage Swing	±5	±5.2		V	
					Baud Rate		-	300k	bps	
7	FNC2 COM1_RXD	I/O	Yes	Digital	Programmable I/O	VIH	4.0	-	5.2	V
						VIL	-0.5	-	1.0	V
						VOH(Io=-1.5mA)	4.0	-	5.2	V
						VOL(Io=1.5mA)	-	-	1.1	V
	RXD (RS-232C)	I	Digital	RS-232C Serial port (RXD)	Input Voltage Range	-30.0	-	30.00	V	
					Threshold Low	0.51	1.326	-	V	
					Threshold High	-	1.632	2.448	V	
					Baud Rate	-	-	300k	bps	
					CL	-	100	-	pF	
8	FNC3	I/O	Yes	Digital	Programmable I/O	VIH	4.0	-	5.2	V
						VIL	-0.5	-	1.0	V
						VOH(Io=-1.5mA)	4.0	-	5.2	V
						VOL(Io=1.5mA)	-	-	1.1	V
	RTS(RS232C)	O	Digital	RS-232C Serial port (RTS)	Voltage Swing	±5	±5.2	-	V	
9	FNC4	I/O	Yes	Digital	Programmable I/O	VIH	4.0	-	5.2	V
						VIL	-0.5	-	1.0	V
						VOH(Io=-1.5mA)	4.0	-	5.2	V
						VOL(Io=1.5mA)	-	-	1.1	V
	CTS (RS232C)	I	Digital	RS-232C Serial port (CTS)	Input Voltage Range	-30.0		30.00	V	
					Threshold Low	0.5	1.3		V	
				Threshold High		1.75	2.6	V		
10	FNC5	I/O	No	Digital	Programmable I/O	VIH	4.0	-	5.2	V
						VIL	-0.5	-	1.0	V
						VOH(Io=-1.5mA)	4.0	-	5.2	V
						VOL(Io=1.5mA)	-	-	1.1	V
11	FNC6	I/O	No	Digital	Programmable I/O	VIH	4.0	-	5.2	V
						VIL	-0.5	-	1.0	V
						VOH(Io=-1.5mA)	4.0	-	5.2	V
						VOL(Io=1.5mA)	-	-	1.1	V
12	50AC	O	No	Power	5V DC Power supply	Output Voltage	4.5	5	5.25	V
						Output Current	-	-	100.0	mA
13	HR1	I	Yes	Analog	Horn alert signal input	Input Voltage	5	-	16	V
						Input Current	-	-	2.0	A
	COM2_TXD	O	Digital	TXD	VOH(Io=-1.5mA)	4.0	-	5.2	V	
					VOL(Io=1.5mA)	-0.5	-	1.0	V	

Pin No.	Pin Name	I/O	Modification	Signal Type	Description	Rating and Condition				
						Parameter	Min	Typ	Max	Unit
14	HR2	O	Yes	Analog	Horn alert signal output	Output Voltage	This parameter depends on HR1 Voltage			
						Output Voltage Loss	-	-	1.0	V
						Output Current	-	-	2.0	A
	COM2_RXD	I	No	Digital	RXD	VIH	2.8	-	5.2	V
					VIL	-0.5	-	0.5	V	
15	GND	-	No	GND	Ground		-	-	-	-



SECTION 3 DISASSEMBLY

3.1 Disassembly Procedure


- (1) Remove the cabinet, top packing and shielding plate of the transceiver.




- (2) To remove the panel assembly, first turn the transceiver upside down. Then, insert a flat-head screwdriver into the holes of the chassis and tilt it in the direction as shown by the arrow.




- (3) Disconnect the flat cable from connector of the panel assembly.




- (4) Remove the speaker lead from the holder hook. <1> Remove the speaker connector from the display unit connector. <2> Insert a flat-head screwdriver at the stamp position (arrow mark) in the speaker holder. <3>




- Tilt the screwdriver in the figure direction <4>, then remove the speaker holder from the front panel.



- (5) When removing the TX-RX PCB, then remove the solder of the antenna hot pin and positive terminal of the DC cord. Remove the 15 screws from the TX-RX PCB, power module, and audio amp.




- (6) Pull it out behind the chassis by rotating the bush <c> of the DC cord 90 degrees in the direction of the arrow after the screw <a> in the negative terminal is removed, and the positive terminal is removed from the chassis.




3.2 Precautions for Reassembly

- (1) Push the upper tabs of speaker holder (stamped mark <1> side) into the front panel first. Then push the lower tabs (stamped mark <2> side) into the front panel.




There are stamped marks <1> or <2> on the four corners of the speaker holder.

- (2) When mounting the panel assembly, pass the flat cable through the hole of the chassis as shown below then connect the flat cable to connector of the panel assembly.



- (3) Fit the panel assembly into the two tabs of the chassis top side first. Then, fit the panel assembly into the two tabs of the chassis bottom side by turning the panel assembly.



3.3 Precautions for Reassembly


3.3.1 Assembly Information (Sheet/Cushion)

When "Main Parts" is changed (ordered), "Assembled Sheet / Cushion" should also be changed (ordered) together. The Sticker and Sheet etc are non-reusable parts. It requires the new one to get the radio's performance after repairs.


Main Parts		Assembled Sheet/ Cushion	
Part Name	Part Number	Part Name	Part Number
CHASSIS	A1A-0096-00	NAME PLATE	B72-2283-04
		CAUTION STICKER	B41-1837-04
		SHEET	G11-4578-04
TX-RX UNIT (NX-3720H K)	XCA-033K-00	SHEET	G11-4611-04
TX-RX UNIT (NX-3720 E)	XCA-033E-01	SHIELDING COVER	F1B-0086-00
TX-RX UNIT (NX-3820H K)	XCA-034K-00		
TX-RX UNIT (NX-3820H K2)	XCA-034K-01		
TX-RX UNIT (NX-3820 E)	XCA-034E-01		
MODULE UNIT	XC2-0040-10	SHIELDING COVER	F10-3225-05
ILL.GUIDE	B1B-0101-00	OPTI.DIFFUSER	B1B-0102-00
MOUNTING	J2B-0341-00	FLEX P.BOARD	J8C-0018-00
PANEL ASSY	A6C-0067-00	KENWOOD BADGE	B4D-0044-00
		CAUTION STICKER	B4B-0008-00
SHIELDING CASE	F10-3112-13	CONDUCTIVE CUSHION	G13-2101-14
SUB UNIT	XC3-050M-00	REF.SHEET	B1B-0103-00

SECTION 4 ADJUSTMENT

4.1 NX-3720H(G)/3720H K TYPE Controls



KMC-36 (OPTION)



4.1.1 Preparations for checking/tuning the transceiver

Before attempting to check/tune the transceiver, connect the unit to a suitable power supply.

Whenever the transmitter is turned on, the unit must be connected to a suitable dummy load (i.e. power meter).

The speaker output connector must be terminated with an 40hm dummy load and connected to an AC voltmeter and an audio distortion meter or a SINAD measurement meter at all times during checking/tuning.

4.2 Panel Test Mode

4.2.1 Test mode operation features

This transceiver has a test mode. To enter test mode, press and hold the [↵] button while turning the transceiver power ON or press the [☐] button and select the "Panel Test". Before the transceiver enters test mode, the frequency version information appears on the LCD momentarily. Test mode can be inhibited by programming. To exit test mode, turn the transceiver power OFF. The following functions are available in test mode.

- When the panel test mode is activated, the last used channel and signaling numbers are displayed. When the panel test mode is activated for the first time, the channel and signaling numbers are 1.

4.2.2 Button operation

Button	"Func" not appears on the sub LCD display	
	Function	Display
[+]	Push: Volume up Hold: Volume up continuously	-
[-]	Push: Volume down Hold: Volume down continuously	-
[▲]	Push: Test channel up Hold: Test channel up continuously	Channel No.
[▼]	Push: Test channel down Hold: Test channel down continuously	Channel No.
[◀]	Push: Squelch level up *1 Hold: Squelch off	Squelch level Squelch off: 🗣 icon appears
[▶]	Wide/Narrow/ Very Narrow	Wide: "w" Narrow: "n" Very Narrow: "v"
[☐]	Shift to panel tuning mode	-
[↵]	Function on	"Func" appears on the sub LCD display
[🏠]	Push: Test signaling up Hold: Test signaling up continuously	Signaling No.
[△(AUX)]	MSK 1200bps and 2400bps *1	2400bps: [✉] icon appears
[PTT]	Transmit	-
[0] to [9] and [#], [*]	-	-


*1: When the mode is selected as Analog, this function is enabled.

Button	"Func" appears on the sub LCD display	
	Function	Display
[+]	Function off	-
[-]	Function off	-
[▲]	-	-
[▼]	Mode selection Analog/NXDN/DMR	Analog: "A" NXDN: "N" DMR: "D"
[◀]	Function off	-
[▶]	Button/LCD check	The contents of the pressed button etc., appear.
[☐]	High power/Medium power/Low power	High:[H] icon appears Medium:[M] icon appears Low:[L] icon appears
[↵]	Function off	-

Button	"Func" appears on the sub LCD display	
	Function	Display
[]	External Speaker on/off	On: icon appears
[(AUX)]	Compander on/off	On: [] icon appears
[PTT]	Transmit	-
[0] to [9] and [#], [*]	Function off	-

- **LED indicator**
Red LED Lights during transmission.
Green LED Lights when there is carrier.
- **Sub LCD indicator**
"Func" Appears at function on.

• **LCD display in panel test mode**



4.2.3 Frequency and Signaling

The transceiver has been adjusted for the frequencies shown in the following table. When required, readjust them following the adjustment procedure to obtain the frequencies you want in actual operation.

(1) Test frequency

CH	RX (MHz)	TX (MHz)
1	155.05000	155.10000
2	136.05000	136.10000
3	173.95000	173.90000
4	155.00000	155.00000
5	155.20000	155.20000
6	155.40000	155.40000
7~16	-	-

(2) Signaling

■ **Analog Type Signaling**

No.	RX	TX
1	None	None
2	None	Square Wave
3	LTR Data	LTR Data
4	QT:67.0Hz	QT:67.0Hz
5	QT:151.4Hz	QT:151.4Hz
6	QT:210.7Hz	QT:210.7Hz
7	QT:254.1Hz	QT:254.1Hz
8	DQT:D023N	DQT:D023N
9	DQT:D754I	DQT:D754I
10	DTMF Decode (CODE: 159D)	DTMF Encode (CODE: 159D)
11	None	DTMF Encode (CODE: 9)
12	2-tone Decode (A: 304.7Hz, B: 3106.0Hz)	2-tone Encode (A: 304.7Hz, B: 3106.0Hz)
13	Single Tone Decode (979.9Hz)	Single Tone Encode (979.9Hz)
14	None	Single Tone Encode (1000Hz)
15	None	MSK PN9
16	MSK Decode	MSK Encode

■NXDN Type Signaling

No.	RX	TX
1	RAN1	RAN1
2	None	PN9
3	RAN1	Maximum Deviation Pattern
7	FSW + PN9	FSW + PN9
9	Tone Pattern (1031Hz)	Tone Pattern (1031Hz)


RAN: Radio Access Number
 PN9: Pseudo-Random Pattern
 No.7, 9 Item: PC test mode only



■DMR Type Signaling

No.	RX	TX
1	CC 00 Burst	CC 00 Burst
2	PN9	PN9
3	CC 00 Burst	Maximum Deviation Pattern
4	CC 00 Burst	1/3 Deviation Pattern
5	CC 00 Burst	0 Continuous Pattern
6	SYNC (Each Slot) + PN9 Burst Pattern	SYNC (Each Slot) + PN9 Burst Pattern
7	SYNC (Super Frame) + PN9 Burst Pattern	SYNC (Super Frame) + PN9 Burst Pattern
8	CC 00 Burst	0 Burst Pattern
9	Tone Pattern	Tone Test Burst Pattern
10	Silence Pattern	Silence Burst Pattern
11	Audio Test Pattern	Audio Test Burst Pattern
12	Vocoder Loop	None


4.3 Panel Tuning Mode

4.3.1 Transceiver tuning (To enter tuning mode)

To enter tuning mode, press the [] button while the transceiver is in test mode. Use the [Δ (AUX)] button to write tuning data through tuning modes, and the [\blacktriangle]/[\blacktriangledown] button to adjust tuning requirements (1 to 4096 appears on the LCD).




Use the [] button to select the adjustment item through tuning modes. Use the [] button to adjust 5 or 9 reference level adjustments, and use the [\blacktriangleright] button to switch between Wide/Narrow.

- LCD display in panel tuning mode



*1: Wide 4k is displayed only when the PC test mode is used. However, it aims at production for factory, or a operation verification of the transceiver. It is not necessary in operation of the transceiver to adjust.

4.3.2 Button operation

Button	Function	
	Push	Hold (1 second)
[+]	Volume up	Continuation up
[-]	Volume down	Continuation down
[\blacktriangle]	Adjustment value up	Continuation up
[\blacktriangledown]	Adjustment value down	Continuation down
[\blacktriangleleft]	Auto adjustment start	Output tone pattern change of balance adjustment (A change is possible only during balance adjustment.)
[\blacktriangleright]	Wide/Narrow/NXDN/DMR	-
[]	Shift to panel test mode	-
[]	To enter 5 or 9 reference level adjustments	-
[]	Go to next adjustment item	Back to last adjustment item (At the time of 5 or 9 point adjustment: Adjustment point change)
[Δ (AUX)]	Writes the adjustment value	-
[PTT] (MIC)	Transmit	
[0] to [9] and [#],[*] (MIC)	-	

4.3.3 5 or 9 reference level adjustments frequency

Maximum Transmit Power, High Transmit Power, Medium Transmit Power, Low Transmit Power, Balance, Maximum Deviation, NXDN High Deviation, DMR High Deviation, QT Deviation, DQT Deviation, LTR Deviation, DTMF Deviation, Single Tone Deviation, MSK Deviation, CW ID Deviation, IQ Phase, RSSI Reference, Squelch Open, Squelch Tight, Low RSSI, High RSSI

Tuning point	Display	RX (MHz)	TX (MHz)
1	L1	136.05000	136.10000
2	L3	145.55000	145.60000
3	C2	155.05000	155.10000
4	H1	164.55000	164.60000
5	H3	173.95000	173.90000

VCO Assist

Tuning point	Display	RX (MHz)	TX (MHz)
1	L1	136.05000	136.10000
2	L2	140.80000	140.85000
3	L3	145.55000	145.60000
4	C1	150.30000	150.35000
5	C2	155.05000	155.10000
6	C3	159.80000	159.85000
7	H1	164.55000	164.60000
8	H2	169.30000	169.35000
9	H3	173.95000	173.90000

4.3.4 Adjustment item supplement

Adjustment Item	Description
LCD Contrast	The contrast of LCD display can be changed.
VCO Assist	The lock voltage of VCO is adjusted. This item must be adjusted before receiver and transmitter adjustment items.
Frequency	Frequency is adjusted under receiving condition with SSG. The SSG needs 0.001ppm accuracy so please use a standard oscillator if necessary. This item can be adjusted only in PC Test Mode so that the adjustment value is not changed easily.
RTC Correction	Real Time Clock is adjusted. This item uses the internal clock. (Any measurement equipment is not required.)
Maximum Transmit Power	Maximum Transmit Power is adjusted.
High Transmit Power	High Transmit Power is adjusted.
Mid Transmit Power	Medium Transmit Power is adjusted.
Low Transmit Power	Low Transmit Power is adjusted.
Ramp Offset	Adjust this item to the optimal Ramp voltage.
Balance	The transmit modulation frequency response is adjusted. This item is adjusted so that the deviation of 2kHz becomes the same deviation of 20Hz. This item must be adjusted before all adjustment items for deviations are adjusted.
Maximum Deviation (Analog Wide 5k/ Wide 4k/Narrow)	Maximum Deviation of Analog (Wide 5k/ Wide 4k/Narrow) is adjusted. This item must be adjusted before all adjustment items for tone deviations are adjusted.
High Deviation	NXDN/DMR high deviation is adjusted.

Adjustment Item	Description
QT Deviation	QT deviation is adjusted.
DQT Deviation	DQT deviation is adjusted.
LTR Deviation	LTR deviation is adjusted.
DTMF Deviation	DTMF deviation is adjusted.
Single Tone Deviation	The deviation of Single Tone used in "2-tone" and "5-tone" is adjusted.
MSK Deviation	MSK deviation is adjusted.
CW ID Deviation	CWID tone deviation is adjusted. CWID is used to inform the others who is transmitting on a 6.25-kHz spacing channel. (In FCC rule, Analog mode or CWID is required for each channel-spacing.)
IQ Phase	Correction of phase difference shift between I and Q.
RSSI Reference	The minimum RSSI level for scan stop is adjusted.
Squelch Open	The squelch level at level "1" is adjusted.
Squelch Tight	The squelch level at level "9" is adjusted.
Low RSSI	RSSI display level "1" is adjusted.
High RSSI	Both "Low RSSI" and "High RSSI" must be adjusted. (The curve data of RSSI level is applied.)

4.3.5 Adjustment item and Display

Order	Adjustment item	Main LCD display	Sub LCD display	AW	AS *2	AN	Nn	Nv	D	Adjust item Number
				(Analog Wide)	(Analog Wide 4k)	(Analog Narrow)	(NXDN Narrow)	(NXDN Very Narrow)	(DMR)	
				Adjustment range						
1	LCD Contrast	CNTR	-	1 point ADJ						Common Section 2
				1~256						
2	VCO Assist	AST	(CV voltage)	-	-	9	-	-	-	Common Section 3
				1~4096						
3	RTC Correction	RTC	-	-						Common Section 5
				-2.00 ~ -0.01 ,0.00 ,+0.01 ~ +2.00						
4	Maximum Transmit Power	MAX_P	-	-	-	5	-	-	-	Transmitter Section 1
				1~256						
5	High Transmit Power	H_PWR	-	-	-	5	-	-	-	Transmitter Section 2
				1~1024						
6	Medium Transmit Power	M_PWR	-	-	-	5	-	-	-	Transmitter Section 3
				1~1024						
7	Low Transmit Power	L_PWR	-	-	-	5	-	-	-	Transmitter Section 4
				1~1024						
8	Ramp Offset	RAMP	(ADC measurement value)	1 point ADJ						Transmitter Section 5
				1~1024						
9	Balance	BAL	(Encode frequency)	-	-	5	-	-	-	Transmitter Section 6
				1~1024						
10	Maximum Deviation	ADEV	-	5	5 *2	5	-	-	-	Transmitter Section 7
				1~1024						
11	NXDN High Deviation	NDEV	-	-	-	-	5	5	-	Transmitter Section 8
				1~1024						
12	DMR High Deviation	DDEV	-	-	-	-	-	-	5	Transmitter Section 9
				1~1024						
13	QT Deviation	QT	-	5	5 *2	5	-	-	-	Transmitter Section 10
				1~1024						
14	DQT Deviation	DQT	-	5	5 *2	5	-	-	-	Transmitter Section 11
				1~1024						
15	LTR Deviation	LTR	-	5	5 *2	5	-	-	-	Transmitter Section 12
				1~1024						
16	DTMF Deviation	DTMF	-	5	5 *2	5	-	-	-	Transmitter Section 13
				1~1024						
17	Single Tone Deviation	TONE	-	5	5 *2	5	-	-	-	Transmitter Section 14
				1~1024						
18	MSK Deviation	MSK	-	5	5 *2	5	-	-	-	Transmitter Section 15
				1~1024						
19	CW ID Deviation	CWID	-	-	-	5	-	-	-	Transmitter Section 16
				1~1024						
20	IQ Phase	IQ	(RSSI DSP(Receive) measurement value)	-	-	5	-	-	-	Receive Section 2
				1~63						
21	RSSI Reference 1 DSP (Receive)	RSSI1	(RSSI DSP(Receive) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						


Order	Adjustment item	Main LCD display	Sub LCD display	AW	AS *2	AN	Nn	Nv	D	Adjust item Number
				(Analog Wide)	(Analog Wide 4k)	(Analog Narrow)	(NXDN Narrow)	(NXDN Very Narrow)	(DMR)	
				Adjustment range						
22	RSSI Reference 2 RF IC(Receive)	RSSI2	(RSSI RF IC(Receive) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
23	RSSI Reference 3 DSP (Standby)	RSSI3	(RSSI DSP (Standby) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
24	RSSI Reference 4 RF IC (Standby)	RSSI4	(RSSI RF IC (Standby) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
25	Squelch Open	SQL	(ASQDET measurement value)	5	5 *2	5	5	5	5	Receive Section 4
				1~256						
26	Squelch Tight	SQLT	(ASQDET measurement value)	5	5 *2	5	-	-	-	Receive Section 5
				1~256						
27	Low RSSI	LRSSI	(RSSI DSP (Receive) measurement value)	-	-	5	-	-	-	Receive Section 6
				1~256						
28	High RSSI	HRSSI	(RSSI DSP (Receive) measurement value)	-	-	5	-	-	-	Receive Section 7
				1~256						

*2: Wide 4k can be set up only when the PC test mode is used.

4.3.6 Panel tuning mode flow chart


Note:

* In this Panel tuning mode flow chart, the Adjustment item name is modified.



4.4 Adjustment point

TX-RX UNIT (XC1-182)
Component Side




4.5 Test Equipment Required for Alignment


Test Equipment	Major Specifications	
1. Standard Signal Generator (SSG)	Frequency Range	100 to 900MHz
	Modulation Output	Frequency modulation and external modulation -127dBm/0.1uV to greater than -20dBm/22.4mV
	When performing the Frequency adjustment, the following accuracy is necessary. • 0.003ppm Use a standard oscillator for adjustments, if necessary.	
2. Power Meter	Input Impedance	50ohm
	Operation Frequency	100 to 900MHz
	Measurement Capability	Vicinity of 100W
3. Deviation Meter	Frequency Range	100 to 900MHz
4. Digital Volt Meter (DVM)	Measuring Range	10mV to 20V DC
	Input Impedance	High input impedance for minimum circuit loading
5. Oscilloscope		DC through 30MHz
6. Frequency Counter	Frequency Range	10Hz to 1000MHz
	Frequency Stability	0.2ppm or less
	To measure the oscillating frequency of the internal clock 32766.00Hz~32770.00Hz for RTC Correction Resolution 0.01Hz is better for accuracy adjustment.	
7. Ammeter		20A or more
8. AF Volt Meter (AF VM)	Frequency Range	50Hz to 10kHz
	Voltage Range	1mV to 10V
9. Audio Generator (AG)	Frequency Range	50Hz to 5kHz or more
	Output	0 to 1V
10. Distortion Meter	Capability	3% or less at 1kHz
	Input Level	50mV to 10Vrms
11. Spectrum Analyzer	Measuring Range	DC to 1GHz or more
12. 4ohm Dummy Load		Approx. 4ohm, 10W
13. Regulated Power Supply		13.6V, approx. 20A (adjustable from 9V to 17V) Useful if ammeter equipped

*The test equipment which is not used for adjustment is contained in this table.

■ Test cable for microphone input (E30-3360-28)



■ MIC connector (Front panel view)



- 1 : BLC
- 2 : +B
- 3 : GND
- 4 : PTT/TXD (PC serial data from radio)
- 5 : MICE
- 6 : MIC
- 7 : HOOK/RXD (PC serial data to radio)
- 8 : DM

■ Tuning cable (E30-7754-05)

Adapter cable (E30-7754-05) is required for injecting an audio if PC tuning is used.
See "PC Mode" section for the connection.

4.6 Radio check Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Frequency check	1)CH-Sig: 1-1 PTT: ON	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	f. counter	Panel	ANT			Check an internal temperature of radio from 20°C to 33°C.	±0.25ppm ±38.7Hz @155.1MHz
2. High power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	45W~55W 13.0A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
3. Medium power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	25W~35W 10A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
4. Low power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	3.5W~6.5W 7.0A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
5. MIC sensitivity check	1)CH-Sig: 1-1 AG: 1kHz PTT: ON	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 AG: 1kHz PTT: Press [Transmit] button.	Deviation meter Oscilloscope AG AF VM	Panel	ANT MIC jack			Adjust AG input to get a standard MOD.	5mV ±1mV

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
6. Sensitivity check	1)CH-Sig: 1-1 SSG output Wide: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/ ±1.5kHz)	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 SSG output Wide: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/±1.5kHz)	SSG AF VM Oscilloscope Distortion meter 4ohm Dummy load	Panel	ANT Ext. SP connector			Check	12dB SINAD or more

4.7 Common Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Setting	1) DC voltage:13.6V 2) SSG standard modulation [Wide] MOD:1kHz,DEV:3kHz [Narrow] MOD:1kHz,DEV:1.5kHz								
2.LCD Contrast	1) Adj item [CNTR] Adjust:[****] Press [△] button to store the adjustment value.	1) Adj item [LCD Contrast] Data: [****] Press [Apply] button to store the adjustment value.				Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 280 (Reference value)	
3. VCO Assist	1) Adj item: [AST] Adjust:[****] 2) Adj item: [L1]→ [L2]→ [L3]→ [C1]→ [C2]→ [C3]→ [H1]→ [H2]→ [H3]→ Adjust:[****] Press [△] button to store the adjustment value.	1) Adj item: [VCO Assist] 2) Adj item: [Low1],[Low2], [Low3], [Center1], [Center2], [Center3], [High1],[High2] [High3] Press [Apply] button to store the adjustment value.				Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] 1) Press [Autotune] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] [V] Indicator on the PC window shows VCO lock voltage. Change the adjustment value to get VCO lock voltage within the limit of the specified voltage. Note: Confirm the VCO lock voltage approximately 3 seconds after the adjustment value is changed.	2.5V±0.1V [Automatic Adjustment] After the automatic adjustment is performed, verify that the VCO lock voltage is within the voltage range which is specified by the manual adjustment. [Manual Adjustment] Press [Apply] button to store the adjustment value after all adjustment points have been adjusted. Adjustment value range: 300 - 3000

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
4. Frequency	*The Frequency adjustment can be performed only in PC test mode.	1) Adj item: [Frequency] SSG output: -20dBm (22.4mV) (CW (without modulation)) Caution: Perform the frequency adjustment under the following conditions. • Temperature range of +20°C to +33°C (+68.0°F to +91.4°F). (The temperature is displayed on the Frequency adjustment screen of the KPG-D3/ D3N and the LCD of the transceiver.) • Use an accuracy of 0.003ppm for the SSG. (Use a standard oscillator if necessary.)	SSG	Panel	ANT		[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] Press [Start] button of "Auto Tuning". Press [Apply] button to store the adjustment value after the automatic adjustment has finished.	[PC test mode] "IF20" value = Within 0±10 digits. The value of "IF20" will become around "0" after the adjustment has finished. Remark: "Frequency" is adjusted under receiving condition with SSG.
5. RTC Correciton	1) Adj item: [RTC] Adjust:[****] Press [▲] button to store the adjustment value.	1) Adj item: [RTC Correction] Data: [****] Press [Apply] button to store the adjustment value.	Frequency Counter	TX-RX	TEST POINT (CN55)				Remark: The adjustment value should input the display of a Frequency Counter.

4.8 Transmitter Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Maximum Transmit Power	1) Adj item: [MAX_P] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] PTT : ON Press [▲] button to store the adjustment value.	1) Adj item: [Maximum Transmit Power] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	57.5W	±2.5W 15A or less

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
2. High Transmit power	1) Adj item: [H_PWR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [High Transmit Power] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	50W	±1W 13A or less
3. Medium Transmit power	1) Adj item: [M_PWR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Medium Transmit Power] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	30W	±1W 10A or less
4. Low Transmit power	1) Adj item: [L_PWR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Low Transmit Power] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	5W	±0.5W 7A or less

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
5. Ramp Offset	1)Adj item: [RAMP] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Ramp Offset] Press [Autotune(TX Starts)] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] 1) Press [Autotune(TX starts)] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. 3) Check Ramp Offset Monitor Value Over 60. [Manual Adjustment] 1) Set the adjustment value to "1". 2) Press [Transmit] button and increase the adjustment value slowly while monitoring the offset monitor value. 3) Set the adjustment value when the offset monitor value exceed "75".	
6. Balance	1) Adj item: [An BAL] Adjust:[****] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Balance] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	The Deviation of 20Hz frequency is fixed. Change the 2kHz adjustment value to become the same deviation of 20Hz within the specified range. [Panel tuning mode] PTT:ON While PTT:ON, press the [◀] button to change the 20Hz/ 2kHz. [PC test mode] PTT: Press [Transmit] button. While PTT:ON, click the check box "2kHz Sine Wave" to change the 20Hz/2kHz.	2kHz Tone deviation is within ± 1.0% of 20Hz tone deviation.

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
7. Maximum Deviation [Analog Wide]	1) Adj item: [Aw ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Wide)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 4150Hz and 4250Hz. Deviation meter LPF: 15kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	4150~4250Hz
[Analog Narrow]	1) Adj item: [An ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 2050Hz and 2150Hz. Deviation meter LPF: 15kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2050~2150Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
8. NXDN High Deviation [NXDN Narrow]	1) Adj item: [Nn NDEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [NXDN High Deviation (NXDN Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 2995Hz and 3117Hz. Deviation meter LPF: 3kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2995~3117Hz
[NXDN Very Narrow]	1) Adj item: [Nv NDEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [NXDN High Deviation (NXDN Very Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope					Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 1311Hz and 1363Hz. Deviation meter LPF: 3kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	1311~1363Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
9. DMR High Deviation	1) Adj item: [D DDEV] Adjust: [****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DMR High Deviation (DMR Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope					Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 2695Hz and 2803Hz. Deviation meter LPF: 3kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2695~2803Hz
10. QT Deviation [Analog Wide]	1) Adj item: [Aw QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Wide)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	0.75kHz±0.05 kHz
[Analog Narrow]	1) Adj item: [An QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	0.35kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
11. DQT Deviation [Analog Wide]	1) Adj item: [Aw DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Wide)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 430 (Reference value)	0.75kHz±0.05 kHz
[Analog Narrow]	1) Adj item: [An DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 430 (Reference value)	0.35kHz±0.05 kHz
12. LTR Deviation [Analog Wide]	1) Adj item: [Aw LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Wide)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	1.00kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	0.75kHz±0.05 kHz
13. DTMF Deviation [Analog Wide]	1) Adj item: [Aw DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Wide)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 555 (Reference value)	2.50kHz±0.05 kHz
[Analog Narrow]	1) Adj item: [An DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 555 (Reference value)	1.25kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
14. Single Tone Deviation [Analog Wide]	1) Adj item: [Aw TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Wide)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	3.00kHz±0.05 kHz
[Analog Narrow]	1) Adj item: [An TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	1.50kHz±0.05 kHz
15. MSK Deviation [Analog Wide]	1) Adj item: [Aw MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Wide)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	3.00kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	1.50kHz±0.05 kHz
16. CWID Deviation [Analog Narrow]	1) Adj item: [An CWID] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [CWID Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	1.10kHz±0.10 kHz

4.8.1 Necessary Deviation adjustment item for each signaling and mode

The following shows the necessary adjustment items for each signaling deviation. Please read the following table like the following example. In the case of the signaling "QT (Analog Wide)", this signaling is composed of three elements [Balance, Maximum Deviation (Analog Wide) and QT Deviation (Analog Wide)]. Please adjust Balance and Maximum Deviation (Analog Wide) before adjusting QT Deviation (Analog Wide).

Mode	Signaling	Necessary adjustment and order		
		Wide	Narrow	Very Narrow
Analog	Audio	1. Balance adjust 2. Maximum Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow]	-
	QT	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. QT Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. QT Deviation [Analog Narrow]	-
	DQT	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. DQT Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. DQT Deviation [Analog Narrow]	-
	LTR	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. LTR Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. LTR Deviation [Analog Narrow]	-
	DTMF	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. DTMF Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. DTMF Deviation [Analog Narrow]	-
	2TONE	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. Single Tone Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. Single Tone Deviation [Analog Narrow]	-
	MSK (Fleet sync)	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. MSK Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. MSK Deviation [Analog Narrow]	-
NXDN	Audio	-	1. Balance adjust 2. NXDN High Deviation [NXDN Narrow]	1. Balance adjust 2. NXDN High Deviation [NXDN Very Narrow]
	CWID	-	-	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. CWID Deviation [Analog Narrow]
DMR	Audio	-	1. Balance adjust 2. DMR High Deviation	-

- Balance is common with all the above deviation adjustments. If Balance (Transmitter Section 6) has already adjusted, please skip Step1 and adjust from Step2.
- Maximum Deviation (Analog Wide/Narrow) is common with all the analog signaling deviations and CWID Deviation (NXDN Very Narrow).
If Balance and Maximum Deviation (Analog Wide /Narrow) (Transmitter Section 7) have already adjusted, please skip Step2 and adjust from Step3.

4.9 Receiver Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. AF level setting	[Panel test mode] 1) CH-Sig: 1-1 SSG output: -47dBm (1mV) (MOD: 1kHz/ ±1.5kHz)	1) Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 SSG output: -47dBm (1mV) (MOD:1kHz/ ±1.5kHz)	SSG DVM AF VM Dummy load	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Volume Up/Down knob to obtain 1.41V AF output. (0.5W @ 4ohm load)	1.41V ±0.1V
2. IQ Phase	1) Adj item: [An IQ] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: Freq: Tune Freq +8kHz level: -53dBm (500μV) (MOD:OFF)	1) Adj item: [IQ Phase] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: Freq: Tune Freq +8kHz level: -53dBm (500μV) (MOD:OFF)	SSG	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] After input signal from SSG, 1) Press [Autotune] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] Adjust RSSI Level(DSP Normal Power Mode) Value to the minimum.	
3. RSSI reference [DSP (Receive)]	1) Adj item: [An RSSI 1] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 1 DSP (Receive)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] After input signal from SSG, press [▲] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.		
[RF IC (Receive)]	1) Adj item: [An RSSI 2] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 2 RF IC (Receive)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] After input signal from SSG, press [▲] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.		


Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[DSP (Standby)]	1) Adj item: [An RSSI 3] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 3 DSP (Standby)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[RF IC (Standby)]	1) Adj item: [An RSSI 4] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 4 RF IC (Standby)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
4. Squelch Open [Analog Wide]	1) Adj item: [Aw SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±3kHz)	1) Adj item: [Squelch Open (Analog Wide)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±3kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Squelch Open (Analog Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[NXDN Narrow]	1) Adj item: [Nn SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level at Analog Narrow -5dB (MOD: 400Hz/ ±1.5kHz)	1) Adj item: [Squelch Open (NXDN Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level at Analog Narrow -5dB (MOD: 400Hz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[NXDN Very Narrow]	1) Adj item: [Nv SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level at Analog Narrow -2dB (MOD: 400Hz/ ±1.5kHz)	1) Adj item: [Squelch Open (NXDN Very Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level at Analog Narrow -2dB (MOD: 400Hz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	


Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[DMR]	1) Adj item: [D SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level at Analog Narrow -4dB (MOD: 400Hz/ ±1.8kHz)	1) Adj item: [Squelch Open (DMR)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level at Analog Narrow -4dB (MOD: 400Hz/ ±1.8kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
5. Squelch Tight [Analog Wide]	1) Adj item: [Aw SQLT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±3kHz)	1) Adj item: [Squelch Tight (Analog Wide)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±3kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[Analog Narrow]	1) Adj item: [An SQLT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Squelch Tight (Analog Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
6. Low RSSI	1) Adj item: [An LRSSI] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: -118dBm (0.28μV) (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Low RSSI (Analog Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: -118dBm (0.28μV) (MOD: 1kHz/ ±1.5kHz)	SSG	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
7. High RSSI	1) Adj item: [An HRSSI] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: -80dBm (22.4μV) (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [High RSSI (Analog Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: -80dBm (22.4μV) (MOD: 1kHz/ ±1.5kHz)	SSG	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

4.10 NX-3720(G)/3720 E TYPE Controls



KMC-36 (OPTION)



4.10.1 Preparations for checking/tuning the transceiver

Before attempting to check/tune the transceiver, connect the unit to a suitable power supply.

Whenever the transmitter is turned on, the unit must be connected to a suitable dummy load (i.e. power meter).

The speaker output connector must be terminated with an 4ohm dummy load and connected to an AC voltmeter and an audio distortion meter or a SINAD measurement meter at all times during checking/tuning.

4.11 Panel Test Mode

4.11.1 Test mode operation features

This transceiver has a test mode. To enter test mode, press and hold the [↵] button while turning the transceiver power ON or press the [☐] button and select the "Panel Test". Before the transceiver enters test mode, the frequency version information appears on the LCD momentarily. Test mode can be inhibited by programming. To exit test mode, turn the transceiver power OFF. The following functions are available in test mode.


- When the panel test mode is activated, the last used channel and signaling numbers are displayed. When the panel test mode is activated for the first time, the channel and signaling numbers are 1.

4.11.2 Button operation

Button	"Func" not appears on the sub LCD display	
	Function	Display
[+]	Push: Volume up Hold: Volume up continuously	-
[-]	Push: Volume down Hold: Volume down continuously	-
[▲]	Push: Test channel up Hold: Test channel up continuously	Channel No.
[▼]	Push: Test channel down Hold: Test channel down continuously	Channel No.
[◀]	Push: Squelch level up *1 Hold: Squelch off	Squelch level Squelch off: 📴 icon appears
[▶]	Wide 5k/Wide 4k/Narrow/ Very Narrow	Wide 5k: "w" Wide 4k: "s" Narrow: "n" Very Narrow: "v"
[☐]	Shift to panel tuning mode	-
[↵]	Function on	"Func" appears on the sub LCD display
[🏠]	Push: Test signaling up Hold: Test signaling up continuously	Signaling No.
[△(AUX)]	MSK 1200bps and 2400bps *1	2400bps: [✉] icon appears
[PTT]	Transmit	-
[0] to [9] and [#], [*]	-	-


*1: When the mode is selected as Analog, this function is enabled.

Button	"Func" appears on the sub LCD display	
	Function	Display
[+]	Function off	-
[-]	Function off	-
[▲]	-	-
[▼]	Mode selection Analog/NXDN/DMR	Analog: "A" NXDN: "N" DMR: "D"
[◀]	Function off	-
[▶]	Button/LCD check	The contents of the pressed button etc., appear.
[☐]	High power/Medium power/Low power	High:[H] icon appears Medium:[M] icon appears Low:[L] icon appears
[↵]	Function off	-
[🏠]	External Speaker on/off	On: 📢 icon appears

Button	"Func" appears on the sub LCD display	
	Function	Display
[△(AUX)]	Compander on/off	On: [] icon appears
[PTT]	Transmit	-
[0] to [9] and [#], [*]	Function off	-

- **LED indicator**
Red LED Lights during transmission.
Green LED Lights when there is carrier.
- **Sub LCD indicator**
"Func" Appears at function on.

• **LCD display in panel test mode**



4.11.3 Frequency and Signaling

The transceiver has been adjusted for the frequencies shown in the following table. When required, readjust them following the adjustment procedure to obtain the frequencies you want in actual operation.

(1) Test frequency

CH	RX (MHz)	TX (MHz)
1	155.05000	155.10000
2	136.05000	136.10000
3	173.95000	173.90000
4	155.00000	155.00000
5	155.20000	155.20000
6	155.40000	155.40000
7~16	-	-

(2) Signaling

■ **Analog Type Signaling**

No.	RX	TX
1	None	None
2	None	Square Wave
3	LTR Data	LTR Data
4	QT:67.0Hz	QT:67.0Hz
5	QT:151.4Hz	QT:151.4Hz
6	QT:210.7Hz	QT:210.7Hz
7	QT:254.1Hz	QT:254.1Hz
8	DQT:D023N	DQT:D023N
9	DQT:D754I	DQT:D754I
10	DTMF Decode (CODE: 159D)	DTMF Encode (CODE: 159D)
11	None	DTMF Encode (CODE: 9)
12	2-tone Decode (A: 304.7Hz, B: 3106.0Hz)	2-tone Encode (A: 304.7Hz, B: 3106.0Hz)
13	Single Tone Decode (979.9Hz)	Single Tone Encode (979.9Hz)
14	None	Single Tone Encode (1000Hz)
15	None	MSK PN9
16	MSK Decode	MSK Encode

■NXDN Type Signaling

No.	RX	TX
1	RAN1	RAN1
2	None	PN9
3	RAN1	Maximum Deviation Pattern
7	FSW + PN9	FSW + PN9
9	Tone Pattern (1031Hz)	Tone Pattern (1031Hz)




RAN: Radio Access Number
 PN9: Pseudo-Random Pattern
 No.7, 9 Item: PC test mode only




■DMR Type Signaling

No.	RX	TX
1	CC 00 Burst	CC 00 Burst
2	PN9	PN9
3	CC 00 Burst	Maximum Deviation Pattern
4	CC 00 Burst	1/3 Deviation Pattern
5	CC 00 Burst	0 Continuous Pattern
6	SYNC (Each Slot) + PN9 Burst Pattern	SYNC (Each Slot) + PN9 Burst Pattern
7	SYNC (Super Frame) + PN9 Burst Pattern	SYNC (Super Frame) + PN9 Burst Pattern
8	CC 00 Burst	0 Burst Pattern
9	Tone Pattern	Tone Test Burst Pattern
10	Silence Pattern	Silence Burst Pattern
11	Audio Test Pattern	Audio Test Burst Pattern
12	Vocoder Loop	None


4.12 Panel Tuning Mode

4.12.1 Transceiver tuning (To enter tuning mode)





To enter tuning mode, press the [] button while the transceiver is in test mode. Use the [] button to write tuning data through tuning modes, and the [] button to adjust tuning requirements (1 to 4096 appears on the LCD).

Use the [] button to select the adjustment item through tuning modes. Use the [] button to adjust 5 or 9 reference level adjustments, and use the [] button to switch between Wide5k/Wide4k/Narrow.

• LCD display in panel tuning mode



4.12.2 Button operation

Button	Function	
	Push	Hold (1 second)
[+]	Volume up	Continuation up
[-]	Volume down	Continuation down
[▲]	Adjustment value up	Continuation up
[▼]	Adjustment value down	Continuation down
[◀]	Auto adjustment start	Output tone pattern change of balance adjustment (A change is possible only during balance adjustment.)
[▶]	Wide 5k/Wide 4k/Narrow/NXDN/DMR	-
[]	Shift to panel test mode	-
[]	To enter 5 or 9 reference level adjustments	-
[]	Go to next adjustment item	Back to last adjustment item (At the time of 5 or 9 point adjustment: Adjustment point change)
[]	Writes the adjustment value	-
[PTT] (MIC)	Transmit	
[0] to [9] and [#],[*] (MIC)	-	

4.12.3 5 or 9 reference level adjustments frequency

Maximum Transmit Power, High Transmit Power, Medium Transmit Power, Low Transmit Power, Balance, Maximum Deviation, NXDN High Deviation, DMR High Deviation, QT Deviation, DQT Deviation, LTR Deviation, DTMF Deviation, Single Tone Deviation, MSK Deviation, CW ID Deviation, IQ Phase, RSSI Reference, Squelch Open, Squelch Tight, Low RSSI, High RSSI

Tuning point	Display	RX (MHz)	TX (MHz)
1	L1	136.05000	136.10000
2	L3	145.55000	145.60000
3	C2	155.05000	155.10000
4	H1	164.55000	164.60000
5	H3	173.95000	173.90000

VCO Assist

Tuning point	Display	RX (MHz)	TX (MHz)
1	L1	136.05000	136.10000
2	L2	140.80000	140.85000
3	L3	145.55000	145.60000
4	C1	150.30000	150.35000
5	C2	155.05000	155.10000
6	C3	159.80000	159.85000
7	H1	164.55000	164.60000
8	H2	169.30000	169.35000
9	H3	173.95000	173.90000

4.12.4 Adjustment item supplement

Adjustment Item	Description
LCD Contrast	The contrast of LCD display can be changed.
VCO Assist	The lock voltage of VCO is adjusted. This item must be adjusted before receiver and transmitter adjustment items.
Frequency	Frequency is adjusted under receiving condition with SSG. The SSG needs 0.001ppm accuracy so please use a standard oscillator if necessary. This item can be adjusted only in PC Test Mode so that the adjustment value is not changed easily.
RTC Correction	Real Time Clock is adjusted. This item uses the internal clock. (Any measurement equipment is not required.)
Maximum Transmit Power	Maximum Transmit Power is adjusted.
High Transmit Power	High Transmit Power is adjusted.
Mid Transmit Power	Medium Transmit Power is adjusted.
Low Transmit Power	Low Transmit Power is adjusted.
Ramp Offset	Adjust this item to the optimal Ramp voltage.
Balance	The transmit modulation frequency response is adjusted. This item is adjusted so that the deviation of 2kHz becomes the same deviation of 20Hz. This item must be adjusted before all adjustment items for deviations are adjusted.
Maximum Deviation (Analog Wide 5k/ Wide 4k/Narrow)	Maximum Deviation of Analog (Wide 5k/ Wide 4k/Narrow) is adjusted. This item must be adjusted before all adjustment items for tone deviations are adjusted.
High Deviation	NXDN/DMR high deviation is adjusted.

Adjustment Item	Description
QT Deviation	QT deviation is adjusted.
DQT Deviation	DQT deviation is adjusted.
LTR Deviation	LTR deviation is adjusted.
DTMF Deviation	DTMF deviation is adjusted.
Single Tone Deviation	The deviation of Single Tone used in "2-tone" and "5-tone" is adjusted.
MSK Deviation	MSK deviation is adjusted.
CW ID Deviation	CWID tone deviation is adjusted. CWID is used to inform the others who is transmitting on a 6.25-kHz spacing channel. (In FCC rule, Analog mode or CWID is required for each channel-spacing.)
IQ Phase	Correction of phase difference shift between I and Q.
RSSI Reference	The minimum RSSI level for scan stop is adjusted.
Squelch Open	The squelch level at level "1" is adjusted.
Squelch Tight	The squelch level at level "9" is adjusted.
Low RSSI	RSSI display level "1" is adjusted.
High RSSI	Both "Low RSSI" and "High RSSI" must be adjusted. (The curve data of RSSI level is applied.)

4.12.5 Adjustment item and Display


Order	Adjustment item	Main LCD display	Sub LCD display	AW	AS	AN	Nn	Nv	D	Adjust item Number
				(Analog Wide 5k)	(Analog Wide 4k)	(Analog Narrow)	(NXDN Narrow)	(NXDN Very Narrow)	(DMR)	
Adjustment range										
1	LCD Contrast	CNTR	-	1 point ADJ 1~256						Common Section 2
2	VCO Assist	AST	(CV voltage)	-	-	9	-	-	-	Common Section 3
3	RTC Correction	RTC	-	- -2.00 ~ -0.01 ,0.00 ,+0.01 ~ +2.00						Common Section 5
4	Maximum Transmit Power	MAX_P	-	-	-	5	-	-	-	Transmitter Section 1
5	High Transmit Power	H_PWR	-	-	-	5	-	-	-	Transmitter Section 2
6	Medium Transmit Power	M_PWR	-	-	-	5	-	-	-	Transmitter Section 3
7	Low Transmit Power	L_PWR	-	-	-	5	-	-	-	Transmitter Section 4
8	Ramp Offset	RAMP	(ADC measurement value)	1 point ADJ 1~1024						Transmitter Section 5
9	Balance	BAL	(Encode frequency)	-	-	5	-	-	-	Transmitter Section 6
10	Maximum Deviation	ADEV	-	5	5	5	-	-	-	Transmitter Section 7
11	NXDN High Deviation	NDEV	-	-	-	-	5	5	-	Transmitter Section 8
12	DMR High Deviation	DDEV	-	-	-	-	-	-	5	Transmitter Section 9
13	QT Deviation	QT	-	5	5	5	-	-	-	Transmitter Section 10
14	DQT Deviation	DQT	-	5	5	5	-	-	-	Transmitter Section 11
15	LTR Deviation	LTR	-	5	5	5	-	-	-	Transmitter Section 12
16	DTMF Deviation	DTMF	-	5	5	5	-	-	-	Transmitter Section 13
17	Single Tone Deviation	TONE	-	5	5	5	-	-	-	Transmitter Section 14
18	MSK Deviation	MSK	-	5	5	5	-	-	-	Transmitter Section 15
19	CW ID Deviation	CWID	-	-	-	5	-	-	-	Transmitter Section 16
20	IQ Phase	IQ	(RSSI DSP(Receive) measurement value)	1~63						Receive Section 2
21	RSSI Reference 1 DSP (Receive)	RSSI1	(RSSI DSP(Receive) measurement value)	1~256						Receive Section 3

Order	Adjustment item	Main LCD display	Sub LCD display	AW (Analog Wide 5k)	AS (Analog Wide 4k)	AN (Analog Narrow)	Nn (NXDN Narrow)	Nv (NXDN Very Narrow)	D (DMR)	Adjust item Number
				Adjustment range						
22	RSSI Reference 2 RF IC(Receive)	RSSI2	(RSSI RF IC(Receive) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
23	RSSI Reference 3 DSP (Standby)	RSSI3	(RSSI DSP (Standby) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
24	RSSI Reference 4 RF IC (Standby)	RSSI4	(RSSI RF IC (Standby) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
25	Squelch Open	SQL	(ASQDET measurement value)	5	5	5	5	5	5	Receive Section 4
				1~256						
26	Squelch Tight	SQLT	(ASQDET measurement value)	5	5	5	-	-	-	Receive Section 5
				1~256						
27	Low RSSI	LRSSI	(RSSI DSP (Receive) measurement value)	-	-	5	-	-	-	Receive Section 6
				1~256						
28	High RSSI	HRSSI	(RSSI DSP (Receive) measurement value)	-	-	5	-	-	-	Receive Section 7
				1~256						

4.12.6 Panel tuning mode flow chart


Note:

* In this Panel tuning mode flow chart, the Adjustment item name is modified.



4.13 Adjustment points

TX-RX UNIT (XC1-182)
Component Side




4.14 Test Equipment Required for Alignment


Test Equipment	Major Specifications	
1. Standard Signal Generator (SSG)	Frequency Range	100 to 900MHz
	Modulation Output	Frequency modulation and external modulation -127dBm/0.1uV to greater than -20dBm/22.4mV
	When performing the Frequency adjustment, the following accuracy is necessary. • 0.003ppm Use a standard oscillator for adjustments, if necessary.	
2. Power Meter	Input Impedance	50ohm
	Operation Frequency	100 to 900MHz
	Measurement Capability	Vicinity of 100W
3. Deviation Meter	Frequency Range	100 to 900MHz
4. Digital Volt Meter (DVM)	Measuring Range	10mV to 20V DC
	Input Impedance	High input impedance for minimum circuit loading
5. Oscilloscope		DC through 30MHz
6. Frequency Counter	Frequency Range	10Hz to 1000MHz
	Frequency Stability	0.2ppm or less
	To measure the oscillating frequency of the internal clock 32766.00Hz~32770.00Hz for RTC Correction Resolution 0.01Hz is better for accuracy adjustment.	
7. Ammeter		20A or more
8. AF Volt Meter (AF VM)	Frequency Range	50Hz to 10kHz
	Voltage Range	1mV to 10V
9. Audio Generator (AG)	Frequency Range	50Hz to 5kHz or more
	Output	0 to 1V
10. Distortion Meter	Capability	3% or less at 1kHz
	Input Level	50mV to 10Vrms
11. Spectrum Analyzer	Measuring Range	DC to 1GHz or more
12. 4ohm Dummy Load		Approx. 4ohm, 10W
13. Regulated Power Supply		13.2V, approx. 20A (adjustable from 9V to 17V) Useful if ammeter equipped

*The test equipment which is not used for adjustment is contained in this table.

■ Test cable for microphone input (E30-3360-28)



■ MIC connector (Front panel view)



- 1 : BLC
- 2 : +B
- 3 : GND
- 4 : PTT/TXD (PC serial data from radio)
- 5 : MICE
- 6 : MIC
- 7 : HOOK/RXD (PC serial data to radio)
- 8 : DM

■ Tuning cable (E30-7754-05)

Adapter cable (E30-7754-05) is required for injecting an audio if PC tuning is used.
See "PC Mode" section for the connection.

4.15 Radio check Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Frequency check	1)CH-Sig: 1-1 PTT: ON	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	f. counter	Panel	ANT			Check an internal temperature of radio from 20°C to 33°C.	±0.25ppm ±38.7Hz @155.1MHz
2. High power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	21W~29W 10A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
3. Low power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	3.5W~6.5W 7.0A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
4. MIC sensitivity check	1)CH-Sig: 1-1 AG: 1kHz PTT: ON	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 AG: 1kHz PTT: Press [Transmit] button.	Deviation meter Oscilloscope AG AF VM	Panel	ANT MIC jack			Adjust AG input to get a standard MOD.	5mV ±1mV
5. Sensitivity check	1)CH-Sig: 1-1 SSG output Wide 5k: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Wide 4k: -117dBm (0.32μV) (MOD: 1kHz/ ±2.4kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/ ±1.5kHz)	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 SSG output Wide 5k: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Wide 4k: -117dBm (0.32μV) (MOD: 1kHz/±2.4kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/±1.5kHz)	SSG AF VM Oscilloscope Distortion meter 4ohm Dummy load	Panel	ANT Ext. SP connector			Check	12dB SINAD or more

4.16 Common Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Setting	1) DC voltage:13.2V 2) SSG standard modulation [Wide 5k] MOD:1kHz,DEV:3kHz [Wide 4k] MOD:1kHz,DEV:2.4kHz [Narrow] MOD:1kHz,DEV:1.5kHz								
2.LCD Contrast	1) Adj item [CNTR] Adjust:[****] Press [Δ] button to store the adjustment value.	1) Adj item [LCD Contrast] Data: [****] Press [Apply] button to store the adjustment value.				Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 280 (Reference value)	
3. VCO Assist	1) Adj item: [AST] Adjust:[****] 2) Adj item: [L1]→ [L2]→ [L3]→ [C1]→ [C2]→ [C3]→ [H1]→ [H2]→ [H3]→ Adjust:[****] Press [Δ] button to store the adjustment value.	1) Adj item: [VCO Assist] 2) Adj item: [Low1],[Low2], [Low3], [Center1], [Center2], [Center3], [High1],[High2] [High3] Press [Apply] button to store the adjustment value.				Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] 1) Press [Autotune] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] [V] Indicator on the PC window shows VCO lock voltage. Change the adjustment value to get VCO lock voltage within the limit of the specified voltage. Note: Confirm the VCO lock voltage approximately 3 seconds after the adjustment value is changed.	2.5V±0.1V [Automatic Adjustment] After the automatic adjustment is performed, verify that the VCO lock voltage is within the voltage range which is specified by the manual adjustment. [Manual Adjustment] Press [Apply] button to store the adjustment value after all adjustment points have been adjusted. Adjustment value range: 300 - 3000

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
4. Frequency	*The Frequency adjustment can be performed only in PC test mode.	1) Adj item: [Frequency] SSG output: -20dBm (22.4mV) (CW (without modulation)) Caution: Perform the frequency adjustment under the following conditions. • Temperature range of +20°C to +33°C (+68.0°F to +91.4°F). (The temperature is displayed on the Frequency adjustment screen of the KPG-D3/ D3N and the LCD of the transceiver.) • Use an accuracy of 0.003ppm for the SSG. (Use a standard oscillator if necessary.)	SSG	Panel	ANT		[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] Press [Start] button of "Auto Tuning". Press [Apply] button to store the adjustment value after the automatic adjustment has finished.	[PC test mode] "IF20" value = Within 0±10 digits. The value of "IF20" will become around "0" after the adjustment has finished. Remark: "Frequency" is adjusted under receiving condition with SSG.
5. RTC Correciton	1) Adj item: [RTC] Adjust:[****] Press [▲] button to store the adjustment value.	1) Adj item: [RTC Correction] Data: [****] Press [Apply] button to store the adjustment value.	Frequency Counter	TX-RX	TEST POINT (CN55)				Remark: The adjustment value should input the display of a Frequency Counter.

4.17 Transmitter Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Maximum Transmit Power	1) Adj item: [MAX_P] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Maximum Transmit Power] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	57.5W	±2.5W 15A or less
2. High Transmit power	1) Adj item: [H_PWR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust: [****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [High Transmit Power] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	25W	±1W 10A or less
3. Low Transmit power	1) Adj item: [L_PWR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust: [****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Low Transmit Power] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	5W	±0.5W 7A or less

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
4. Ramp Offset	1)Adj item: [RAMP] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Ramp Offset] Press [Autotune(TX starts)] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] 1) Press [Autotune(TX starts)] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. 3) Check Ramp Offset Monitor Value Over 60. [Manual Adjustment] 1) Set the adjustment value to "1". 2) Press [Transmit] button and increase the adjustment value slowly while monitoring the offset monitor value. 3) Set the adjustment value when the offset monitor value exceed "75".	
5. Balance	1) Adj item: [An BAL] Adjust:[****] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Balance] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	The Deviation of 20Hz frequency is fixed. Change the 2kHz adjustment value to become the same deviation of 20Hz within the specified range. [Panel tuning mode] PTT:ON While PTT:ON, press the [◀] button to change the 20Hz/ 2kHz. [PC test mode] PTT: Press [Transmit] button. While PTT:ON, click the check box "2kHz Sine Wave" to change the 20Hz/2kHz.	2kHz Tone deviation is within ± 1.0% of 20Hz tone deviation.

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
6. Maximum Deviation [Analog Wide 5k]	1) Adj item: [Aw ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Wide 5k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 4150Hz and 4250Hz. Deviation meter LPF: 15kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	4150~4250Hz
[Analog Wide 4k]	1) Adj item: [As ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Wide 4k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 3310Hz and 3410Hz. Deviation meter LPF: 15kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	3310~3410Hz
[Analog Narrow]	1) Adj item: [An ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 2050Hz and 2150Hz. Deviation meter LPF: 15kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2050~2150Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
7. NXDN High Deviation [NXDN Narrow]	1) Adj item: [Nn NDEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [NXDN High Deviation (NXDN Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 2995Hz and 3117Hz. Deviation meter LPF: 3kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2995~3117Hz
[NXDN Very Narrow]	1) Adj item: [Nv NDEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [NXDN High Deviation (NXDN Very Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 1311Hz and 1363Hz. Deviation meter LPF: 3kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	1311~1363Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
8. DMR High Deviation	1) Adj item: [D DDEV] Adjust: [****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DMR High Deviation (DMR Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope					Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 2695Hz and 2803Hz. Deviation meter LPF: 3kHz HPF: OFF 500(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2695~2803Hz
9. QT Deviation [Analog Wide 5k]	1) Adj item: [Aw QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Wide 5k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	0.75kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Wide 4k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	0.60kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	0.35kHz±0.05 kHz
10. DQT Deviation [Analog Wide 5k]	1) Adj item: [Aw DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Wide 5k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 430 (Reference value)	0.75kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Wide 4k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 430 (Reference value)	0.60kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 430 (Reference value)	0.35kHz±0.05 kHz
11. LTR Deviation [Analog Wide 5k]	1) Adj item: [Aw LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Wide 5k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	1.00kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Wide 4k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	0.90kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	0.75kHz±0.05 kHz
12. DTMF Deviation [Analog Wide 5k]	1) Adj item: [Aw DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Wide 5k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 555 (Reference value)	2.50kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Wide 4k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 555 (Reference value)	2.00kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 555 (Reference value)	1.25kHz±0.05 kHz
13. Single Tone Deviation [Analog Wide 5k]	1) Adj item: [Aw TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Wide 5k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	3.00kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Wide 4k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	2.40kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	1.50kHz±0.05 kHz
14. MSK Deviation [Analog Wide 5k]	1) Adj item: [Aw MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Wide 5k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	3.00kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Wide 4k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	2.40kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	1.50kHz±0.05 kHz
15. CWID Deviation [Analog Narrow]	1) Adj item: [An CWID] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [CWID Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 512 (Reference value)	1.10kHz±0.10 kHz

4.17.1 Necessary Deviation adjustment item for each signaling and mode

The following shows the necessary adjustment items for each signaling deviation. Please read the following table like the following example. In the case of the signaling "QT (Analog Wide 5k)", this signaling is composed of three elements [Balance, Maximum Deviation (Analog Wide 5k) and QT Deviation (Analog Wide 5k)]. Please adjust Balance and Maximum Deviation (Analog Wide 5k) before adjusting QT Deviation (Analog Wide 5k).

Mode	Signaling	Necessary adjustment and order			
		Wide 5k	Wide 4k	Narrow	Very Narrow
Analog	Audio	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow]	-
	QT	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. QT Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. QT Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. QT Deviation [Analog Narrow]	-
	DQT	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. DQT Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. DQT Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. DQT Deviation [Analog Narrow]	-
	LTR	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. LTR Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. LTR Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. LTR Deviation [Analog Narrow]	-
	DTMF	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. DTMF Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. DTMF Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. DTMF Deviation [Analog Narrow]	-
	5STONE	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. Single Tone Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. Single Tone Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. Single Tone Deviation [Analog Narrow]	-
	MSK (Fleet sync)	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. MSK Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. MSK Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. MSK Deviation [Analog Narrow]	-
NXDN	Audio	-	-	1. Balance adjust 2. NXDN High Deviation [NXDN Narrow]	1. Balance adjust 2. NXDN High Deviation [NXDN Very Narrow]
	CWID	-	-	-	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. CWID Deviation [Analog Narrow]
DMR	Audio	-	-	1. Balance adjust 2. DMR High Deviation	-

- Balance is common with all the above deviation adjustments. If Balance (Transmitter Section 6) has already adjusted, please skip Step1 and adjust from Step2.
- Maximum Deviation (Analog Wide 5k/Wide 4k/Narrow) is common with all the analog signaling deviations and CWID Deviation (NXDN Very Narrow).
If Balance and Maximum Deviation (Analog Wide 5k /Wide 4k/Narrow) (Transmitter Section 7) have already adjusted, please skip Step2 and adjust from Step3.

4.18 Receiver Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. AF level setting	[Panel test mode] 1) CH-Sig: 1-1 SSG output: -47dBm (1mV) (MOD: 1kHz/ ±1.5kHz)	1) Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 SSG output: -47dBm (1mV) (MOD:1kHz/ ±1.5kHz)	SSG DVM AF VM Dummy load	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Volume Up/Down knob to obtain 1.41V AF output. (0.5W @ 4ohm load)	1.41V ±0.1V
2. IQ Phase	1) Adj item: [An IQ] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: Freq: Tune Freq +8kHz level: -53dBm (500μV) (MOD:OFF)	1) Adj item: [IQ Phase] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: Freq: Tune Freq +8kHz level: -53dBm (500μV) (MOD:OFF)	SSG	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] After input signal from SSG, 1) Press [Autotune] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] Adjust RSSI Level(DSP Normal Power Mode) Value to the minimum.	
3. RSSI reference [DSP (Receive)]	1) Adj item: [An RSSI 1] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 1 DSP (Receive)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] After input signal from SSG, press [▲] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.		
[RF IC (Receive)]	1) Adj item: [An RSSI 2] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 2 RF IC (Receive)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] After input signal from SSG, press [▲] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.		


Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[DSP (Standby)]	1) Adj item: [An RSSI 3] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 3 DSP (Standby)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[RF IC (Standby)]	1) Adj item: [An RSSI 4] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 4 RF IC (Standby)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
4. Squelch Open [Analog Wide 5k]	1) Adj item: [Aw SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±3kHz)	1) Adj item: [Squelch Open (Analog Wide 5k)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±3kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Wide 4k]	1) Adj item: [As SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±2.4kHz)	1) Adj item: [Squelch Open (Analog Wide 4k)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±2.4kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[Analog Narrow]	1) Adj item: [An SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Squelch Open (Analog Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[NXDN Narrow]	1) Adj item: [Nn SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level at Analog Narrow -5dB (MOD: 400Hz/ ±1.5kHz)	1) Adj item: [Squelch Open (NXDN Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level at Analog Narrow -5dB (MOD: 400Hz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	


Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[NXDN Very Narrow]	1) Adj item: [Nv SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level at Analog Narrow -2dB (MOD: 400Hz/ ±1.5kHz)	1) Adj item: [Squelch Open (NXDN Very Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level at Analog Narrow -2dB (MOD: 400Hz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[DMR]	1) Adj item: [D SQL] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level at Analog Narrow -4dB (MOD: 400Hz/ ±1.8kHz)	1) Adj item: [Squelch Open (DMR)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level at Analog Narrow -4dB (MOD: 400Hz/ ±1.8kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
5. Squelch Tight [Analog Wide 5k]	1) Adj item: [Aw SQLT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±3kHz)	1) Adj item: [Squelch Tight (Analog Wide 5k)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±3kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Wide 4k]	1) Adj item: [As SQLT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±2.4kHz)	1) Adj item: [Squelch Tight (Analog Wide 4k)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±2.4kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[Analog Narrow]	1) Adj item: [An SQLT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Squelch Tight (Analog Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
6. Low RSSI	1) Adj item: [An LRSSI] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: -118dBm (0.28μV) (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Low RSSI (Analog Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: -118dBm (0.28μV) (MOD: 1kHz/ ±1.5kHz)	SSG	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
7. High RSSI	1) Adj item: [An HRSSI] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [C2]→ [H1]→ [H3] SSG output: -80dBm (22.4μV) (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [High RSSI (Analog Narrow)] 2) Adj item: [Low1]→ [Low3]→ [Center2]→ [High1]→ [High3] SSG output: -80dBm (22.4μV) (MOD: 1kHz/ ±1.5kHz)	SSG	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

4.19 NX-3820H(G)/3820H K,K2 TYPE Controls



KMC-36 (OPTION)



4.19.1 Preparations for checking/tuning the transceiver

Before attempting to check/tune the transceiver, connect the unit to a suitable power supply.

Whenever the transmitter is turned on, the unit must be connected to a suitable dummy load (i.e. power meter).

The speaker output connector must be terminated with an 4ohm dummy load and connected to an AC voltmeter and an audio distortion meter or a SINAD measurement meter at all times during checking/tuning.

4.20 Panel Test Mode

4.20.1 Test mode operation features

This transceiver has a test mode. To enter test mode, press and hold the [↵] button while turning the transceiver power ON or press the [☐] button and select the "Panel Test". Before the transceiver enters test mode, the frequency version information appears on the LCD momentarily. Test mode can be inhibited by programming. To exit test mode, turn the transceiver power OFF. The following functions are available in test mode.

- When the panel test mode is activated, the last used channel and signaling numbers are displayed. When the panel test mode is activated for the first time, the channel and signaling numbers are 1.

4.20.2 Button operation

Button	"Func" not appears on the sub LCD display	
	Function	Display
[+]	Push: Volume up Hold: Volume up continuously	-
[-]	Push: Volume down Hold: Volume down continuously	-
[▲]	Push: Test channel up Hold: Test channel up continuously	Channel No.
[▼]	Push: Test channel down Hold: Test channel down continuously	Channel No.
[◀]	Push: Squelch level up *1 Hold: Squelch off	Squelch level Squelch off: [🔊] icon appears
[▶]	Wide/Narrow/ Very Narrow	Wide : "w" Narrow: "n" Very Narrow: "v"
[☐]	Shift to panel tuning mode	-
[↵]	Function on	"Func" appears on the sub LCD display
[🏠]	Push: Test signaling up Hold: Test signaling up continuously	Signaling No.
[△(AUX)]	MSK 1200bps and 2400bps *1	2400bps: [✉] icon appears
[PTT]	Transmit	-
[0] to [9] and [#], [*]	-	-


*1: When the mode is selected as Analog, this function is enabled.

Button	"Func" appears on the sub LCD display	
	Function	Display
[+]	Function off	-
[-]	Function off	-
[▲]	-	-
[▼]	Mode selection Analog/NXDN/DMR	Analog: "A" NXDN: "N" DMR: "D"
[◀]	Function off	-
[▶]	Button/LCD check	The contents of the pressed button etc., appear.
[☐]	High power/Medium power/Low power	High:[H] icon appears Medium:[M] icon appears Low:[L] icon appears
[↵]	Function off	-
[🏠]	External Speaker on/off	On: [🔊] icon appears
[△(AUX)]	Compander on/off	On: [🔊] icon appears
[PTT]	Transmit	-

Button	"Func" appears on the sub LCD display	
	Function	Display
[0] to [9] and [#], [*]	Function off	-

- **LED indicator**
Red LED Lights during transmission.
Green LED Lights when there is carrier.
- **Sub LCD indicator**
"Func" Appears at function on.

• **LCD display in panel test mode**



4.20.3 Frequency and Signaling

The transceiver has been adjusted for the frequencies shown in the following table. When required, readjust them following the adjustment procedure to obtain the frequencies you want in actual operation.

(1) Test frequency

CH	K		K2	
	RX (MHz)	TX (MHz)	RX (MHz)	TX (MHz)
1	485.05000	485.10000	435.05000	435.10000
2	450.05000	450.10000	400.05000	400.10000
3	519.95000	519.90000	469.95000	469.90000
4	485.00000	485.00000	435.00000	435.00000
5	485.20000	485.20000	435.20000	435.20000
6	485.40000	485.40000	435.40000	435.40000
7~16	-		-	

(2) Signaling

■ **Analog Type Signaling**

No.	RX	TX
1	None	None
2	None	Square Wave
3	LTR Data	LTR Data
4	QT:67.0Hz	QT:67.0Hz
5	QT:151.4Hz	QT:151.4Hz
6	QT:210.7Hz	QT:210.7Hz
7	QT:254.1Hz	QT:254.1Hz
8	DQT:D023N	DQT:D023N
9	DQT:D754I	DQT:D754I
10	DTMF Decode (CODE: 159D)	DTMF Encode (CODE: 159D)
11	None	DTMF Encode (CODE: 9)
12	2-tone Decode (A: 304.7Hz, B: 3106.0Hz)	2-tone Encode (A: 304.7Hz, B: 3106.0Hz)
13	Single Tone Decode (979.9Hz)	Single Tone Encode (979.9Hz)
14	None	Single Tone Encode (1000Hz)
15	None	MSK PN9
16	MSK Decode	MSK Encode

■NXDN Type Signaling

No.	RX	TX
1	RAN1	RAN1
2	None	PN9
3	RAN1	Maximum Deviation Pattern
7	FSW + PN9	FSW + PN9
9	Tone Pattern (1031Hz)	Tone Pattern (1031Hz)

RAN: Radio Access Number

PN9: Pseudo-Random Pattern

No.7, 9 Item: PC test mode only

■DMR Type Signaling

No.	RX	TX
1	CC 00 Burst	CC 00 Burst
2	PN9	PN9
3	CC 00 Burst	Maximum Deviation Pattern
4	CC 00 Burst	1/3 Deviation Pattern
5	CC 00 Burst	0 Continuous Pattern
6	SYNC (Each Slot) + PN9 Burst Pattern	SYNC (Each Slot) + PN9 Burst Pattern
7	SYNC (Super Frame) + PN9 Burst Pattern	SYNC (Super Frame) + PN9 Burst Pattern
8	CC 00 Burst	0 Burst Pattern
9	Tone Pattern	Tone Test Burst Pattern
10	Silence Pattern	Silence Burst Pattern
11	Audio Test Pattern	Audio Test Burst Pattern
12	Vocoder Loop	None

4.21.2 Button operation

Button	Function	
	Push	Hold (1 second)
[+]	Volume up	Continuation up
[-]	Volume down	Continuation down
[▲]	Adjustment value up	Continuation up
[▼]	Adjustment value down	Continuation down
[◀]	Auto adjustment start	Output tone pattern change of balance adjustment (A change is possible only during balance adjustment.)
[▶]	Wide/Narrow/NXDN/DMR	-
[□]	Shift to panel test mode	-
[↶]	To enter 5,9 or 17 reference level adjustments	-
[⬆]	Go to next adjustment item	Back to last adjustment item (At the time of 5, 9 or 17 point adjustment: Adjustment point change)
[Δ(AUX)]	Writes the adjustment value	-
[PTT] (MIC)	Transmit	
[0] to [9] and [#],[*] (MIC)	-	


4.21 Panel Tuning Mode

4.21.1 Transceiver tuning (To enter tuning mode)

To enter tuning mode, press the [□] button while the transceiver is in test mode. Use the [Δ(AUX)] button to write tuning data through tuning modes, and the [▲]/[▼] button to adjust tuning requirements (1 to 4096 appears on the LCD).

Use the [⬆] button to select the adjustment item through tuning modes. Use the [↶] button to adjust 5, 9 or 17 reference level adjustments, and use the [▶] button to switch between Wide/Narrow.

- LCD display in panel tuning mode



*1: Wide 4k is displayed only when the PC test mode is used. However, it aims at production for factory, or a operation verification of the transceiver. It is not necessary in operation of the transceiver to adjust.

4.21.3 5, 9 or 17 reference level adjustments frequency

Maximum Transmit Power, High Transmit Power, Medium Transmit Power, Low Transmit Power, IQ Phase, RSSI Reference, Squelch Open, Squelch Tight, Low RSSI, High RSSI

Tuning point	Display	K		K2	
		RX (MHz)	TX (MHz)	RX (MHz)	TX (MHz)
1	L1	450.050000	450.100000	400.050000	400.100000
2	L5	467.550000	467.600000	417.550000	417.600000
3	C3	485.050000	485.100000	435.050000	435.100000
4	H2	502.550000	502.600000	452.550000	452.600000
5	H6	519.950000	519.900000	469.950000	469.900000

Balance, Maximum Deviation , NXDN High Deviation, DMR High Deviation, QT Deviation, DQT Deviation, LTR Deviation, DTMF Deviation, Single Tone Deviation, MSK Deviation, CW ID Deviation

Tuning point	Display	K		K2	
		RX (MHz)	TX (MHz)	RX (MHz)	TX (MHz)
1	L1	450.050000	450.100000	400.050000	400.100000
2	L3	458.850000	458.900000	408.850000	408.900000
3	L5	467.550000	467.600000	417.550000	417.600000
4	C1	476.350000	476.400000	426.350000	426.400000
5	C3	485.050000	485.100000	435.050000	435.100000
6	C5	493.850000	493.900000	443.850000	443.900000
7	H2	502.550000	502.600000	452.550000	452.600000
8	H4	511.350000	511.400000	461.350000	461.400000
9	H6	519.950000	519.900000	469.950000	469.900000

VCO Assist

Tuning point	Display	K		K2	
		RX (MHz)	TX (MHz)	RX (MHz)	TX (MHz)
1	L1	450.050000	450.100000	400.050000	400.100000
2	L2	454.450000	454.500000	404.450000	404.500000
3	L3	458.850000	458.900000	408.850000	408.900000
4	L4	463.250000	463.300000	413.250000	413.300000
5	L5	467.550000	467.600000	417.550000	417.600000
6	L6	471.950000	472.000000	421.950000	422.100000
7	C1	476.350000	476.400000	426.350000	426.400000
8	C2	480.750000	480.800000	430.750000	430.800000
9	C3	485.050000	485.100000	435.050000	435.100000
10	C4	489.450000	489.500000	439.450000	439.500000
11	C5	493.850000	493.900000	443.850000	443.900000
12	H1	498.250000	498.300000	448.250000	448.300000
13	H2	502.550000	502.600000	452.550000	452.600000
14	H3	506.950000	507.000000	456.950000	457.100000
15	H4	511.350000	511.400000	461.350000	461.400000
16	H5	515.750000	515.800000	465.750000	465.800000
17	H6	519.950000	519.900000	469.950000	469.900000

4.21.4 Adjustment item supplement

Adjustment Item	Description
LCD Contrast	The contrast of LCD display can be changed.
VCO Assist	The lock voltage of VCO is adjusted. This item must be adjusted before receiver and transmitter adjustment items.
Frequency	Frequency is adjusted under receiving condition with SSG. The SSG needs 0.001ppm accuracy so please use a standard oscillator if necessary. This item can be adjusted only in PC Test Mode so that the adjustment value is not changed easily.
RTC Correction	Real Time Clock is adjusted. This item uses the internal clock. (Any measurement equipment is not required.)
Maximum Transmit Power	Maximum Transmit Power is adjusted.
High Transmit Power	High Transmit Power is adjusted.
Mid Transmit Power	Medium Transmit Power is adjusted.
Low Transmit Power	Low Transmit Power is adjusted.
Ramp Offset	Adjust this item to the optimal Ramp voltage.
Balance	The transmit modulation frequency response is adjusted. This item is adjusted so that the deviation of 2kHz becomes the same deviation of 20Hz. This item must be adjusted before all adjustment items for deviations are adjusted.
Maximum Deviation (Analog Wide 5k/ Wide 4k/Narrow)	Maximum Deviation of Analog (Wide 5k/ Wide 4k/Narrow) is adjusted. This item must be adjusted before all adjustment items for tone deviations are adjusted.
High Deviation	NXDN/DMR high deviation is adjusted.
QT Deviation	QT deviation is adjusted.
DQT Deviation	DQT deviation is adjusted.
LTR Deviation	LTR deviation is adjusted.
DTMF Deviation	DTMF deviation is adjusted.
Single Tone Deviation	The deviation of Single Tone used in "2-tone" and "5-tone" is adjusted.
MSK Deviation	MSK deviation is adjusted.
CW ID Deviation	CWID tone deviation is adjusted. CWID is used to inform the others who is transmitting on a 6.25-kHz spacing channel. (In FCC rule, Analog mode or CWID is required for each channel-spacing.)

Adjustment Item	Description
IQ Phase	Correction of phase difference shift between I and Q.
RSSI Reference	The minimum RSSI level for scan stop is adjusted.
Squelch Open	The squelch level at level "1" is adjusted.
Squelch Tight	The squelch level at level "9" is adjusted.
Low RSSI	RSSI display level "Y" is adjusted.
High RSSI	Both "Low RSSI" and "High RSSI" must be adjusted. (The curve data of RSSI level is applied.)

4.21.5 Adjustment item and Display

Order	Adjustment item	Main LCD display	Sub LCD display	AW	AS *2	AN	Nn	Nv	D	Adjust item Number
				(Analog Wide)	(Analog Wide 4k)	(Analog Narrow)	(NXDN Narrow)	(NXDN Very Narrow)	(DMR)	
				Adjustment range						
1	LCD Contrast	CNTR	-	1 point ADJ 1~256						Common Section 2
2	VCO Assist	AST	(CV voltage)	-	-	17	-	-	-	Common Section 3
3	RTC Correction	RTC	-	- -2.00 ~ -0.01 ,0.00 ,+0.01 ~ +2.00						Common Section 5
4	Maximum Transmit Power	MAX_P	-	-	-	5	-	-	-	Transmitter Section 1
5	High Transmit Power	H_PWR	-	-	-	5	-	-	-	Transmitter Section 2
6	Medium Transmit Power	M_PWR	-	-	-	5	-	-	-	Transmitter Section 3
7	Low Transmit Power	L_PWR	-	-	-	5	-	-	-	Transmitter Section 4
8	Ramp Offset	RAMP	(ADC measurement value)	1 point ADJ 1~1024						Transmitter Section 5
9	Balance	BAL	(Encode frequency)	-	-	9	-	-	-	Transmitter Section 6
10	Maximum Deviation	ADEV	-	9	9 *2	9	-	-	-	Transmitter Section 7
11	NXDN High Deviation	NDEV	-	-	-	-	9	9	-	Transmitter Section 8
12	DMR High Deviation	DDEV	-	-	-	-	-	-	9	Transmitter Section 9
13	QT Deviation	QT	-	9	9 *2	9	-	-	-	Transmitter Section 10
14	DQT Deviation	DQT	-	9	9 *2	9	-	-	-	Transmitter Section 11
15	LTR Deviation	LTR	-	9	9 *2	9	-	-	-	Transmitter Section 12
16	DTMF Deviation	DTMF	-	9	9 *2	9	-	-	-	Transmitter Section 13
17	Single Tone Deviation	TONE	-	9	9 *2	9	-	-	-	Transmitter Section 14
18	MSK Deviation	MSK	-	9	9 *2	9	-	-	-	Transmitter Section 15
19	CW ID Deviation	CWID	-	-	-	9	-	-	-	Transmitter Section 16
20	IQ Phase	IQ	(RSSI DSP(Receive) measurement value)	- 1~63						Receive Section 2
21	RSSI Reference 1 DSP (Receive)	RSSI1	(RSSI DSP(Receive) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						


Order	Adjustment item	Main LCD display	Sub LCD display	AW	AS *2	AN	Nn	Nv	D	Adjust item Number
				(Analog Wide)	(Analog Wide 4k)	(Analog Narrow)	(NXDN Narrow)	(NXDN Very Narrow)	(DMR)	
				Adjustment range						
22	RSSI Reference 2 RF IC(Receive)	RSSI2	(RSSI RF IC(Receive) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
23	RSSI Reference 3 DSP (Standby)	RSSI3	(RSSI DSP (Standby) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
24	RSSI Reference 4 RF IC (Standby)	RSSI4	(RSSI RF IC (Standby) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
25	Squelch Open	SQL	(ASQDET measurement value)	5	5 *2	5	5	5	5	Receive Section 4
				1~256						
26	Squelch Tight	SQLT	(ASQDET measurement value)	5	5 *2	5	-	-	-	Receive Section 5
				1~256						
27	Low RSSI	LRSSI	(RSSI DSP (Receive) measurement value)	-	-	5	-	-	-	Receive Section 6
				1~256						
28	High RSSI	HRSSI	(RSSI DSP (Receive) measurement value)	-	-	5	-	-	-	Receive Section 7
				1~256						

*2: Wide 4k can be set up only when the PC test mode is used.

4.21.6 Panel tuning mode flow chart

Note:


* In this Panel tuning mode flow chart, the Adjustment item name is modified.



4.22 Adjustment points

TX-RX UNIT (XC1-183)

Component Side




4.23 Test Equipment Required for Alignment


Test Equipment	Major Specifications	
1. Standard Signal Generator (SSG)	Frequency Range Modulation Output	100 to 900MHz Frequency modulation and external modulation -127dBm/0.1uV to greater than -20dBm/22.4mV
	When performing the Frequency adjustment, the following accuracy is necessary. • 0.001ppm Use a standard oscillator for adjustments, if necessary.	
2. Power Meter	Input Impedance Operation Frequency Measurement Capability	50ohm 100 to 900MHz Vicinity of 100W
3. Deviation Meter	Frequency Range	100 to 900MHz
4. Digital Volt Meter (DVM)	Measuring Range Input Impedance	10mV to 20V DC High input impedance for minimum circuit loading
5. Oscilloscope		DC through 30MHz
6. Frequency Counter	Frequency Range Frequency Stability	10Hz to 1000MHz 0.2ppm or less
	To measure the oscillating frequency of the internal clock 32766.00Hz~32770.00Hz for RTC Correction Resolution 0.01Hz is better for accuracy adjustment.	
7. Ammeter		20A or more
8. AF Volt Meter (AF VM)	Frequency Range Voltage Range	50Hz to 10kHz 1mV to 10V
9. Audio Generator (AG)	Frequency Range Output	50Hz to 5kHz or more 0 to 1V
10. Distortion Meter	Capability Input Level	3% or less at 1kHz 50mV to 10Vrms
11. Spectrum Analyzer	Measuring Range	DC to 1GHz or more
12. 4ohm Dummy Load		Approx. 4ohm, 10W
13. Regulated Power Supply		13.6V, approx. 20A (adjustable from 9V to 17V) Useful if ammeter equipped

*The test equipment which is not used for adjustment is contained in this table.

■ Test cable for microphone input (E30-3360-28)



■ MIC connector (Front panel view)



- 1 : MBL
- 2 : +B
- 3 : GND
- 4 : PTT/TXD (PC serial data from radio)
- 5 : MICE
- 6 : MIC
- 7 : HOOK/RXD (PC serial data to radio)
- 8 : DM

■ Tuning cable (E30-7754-05)

Adapter cable (E30-7754-05) is required for injecting an audio if PC tuning is used.

See "PC Mode" section for the connection.

4.24 Radio check Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Frequency check	1)CH-Sig: 1-1 PTT: ON	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	f. counter	Panel	ANT			Check an internal temperature of radio from 20°C to 33°C.	±0.25ppm ±106.2Hz @435.1MHz (K2) ±121.2Hz @485.1MHz (K)
2. High power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	40W~50W 13A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
3. Medium power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	25W~35W 10A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
4. Low power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	3.5W~6.5W 7.0A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Type: Analog Signaling: 1 PTT: Press [Transmit] button.							
5. MIC sensitivity check	1)CH-Sig: 1-1 AG: 1kHz PTT: ON	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 AG: 1kHz PTT: Press [Transmit] button.	Deviation meter Oscilloscope AG AF VM	Panel	ANT MIC jack			Adjust AG input to get a standard MOD.	5mV ±1mV

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
6. Sensitivity check	1)CH-Sig: 1-1 SSG output Wide: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/ ±1.5kHz)	1)Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 SSG output Wide: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/±1.5kHz)	SSG AF VM Oscilloscope Distortion meter 4ohm Dummy load	Panel	ANT Ext. SP connector			Check	12dB SINAD or more

4.25 Common Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Setting	1) DC voltage:13.6V 2) SSG standard modulation [Wide] MOD:1kHz,DEV:3kHz [Narrow] MOD:1kHz,DEV:1.5kHz								
2.LCD Contrast	1) Adj item [CNTR] Adjust:[****] Press [△] button to store the adjustment value.	1) Adj item [LCD Contrast] Data: [****] Press [Apply] button to store the adjustment value.				Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 280 (Reference value)	
3. VCO Assist	1) Adj item: [AST] Adjust:[****] 2) Adj item: [L1]→ [L2]→ [L3]→ [L4]→ [L5]→ [L6]→ [C1]→ [C2]→ [C3]→ [C4]→ [C5]→ [H1]→ [H2]→ [H3]→ [H4]→ [H5]→ [H6] Adjust:[****] Press [△] button to store the adjustment value.	1) Adj item: [VCO Assist] 2) Adj item: [Low1],[Low2], [Low3],[Low4], [Low5], [Low6] [Center1], [Center2], [Center3], [Center4], [Center5], [High1],[High2] [High3],[High4], [High5][High6] Press [Apply] button to store the adjustment value.				Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] 1) Press [Autotune] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] [V] Indicator on the PC window shows VCO lock voltage. Change the adjustment value to get VCO lock voltage within the limit of the specified voltage. Note: Confirm the VCO lock voltage approximately 3 seconds after the adjustment value is changed.	2.5V±0.1V [Automatic Adjustment] After the automatic adjustment is performed, verify that the VCO lock voltage is within the voltage range which is specified by the manual adjustment. [Manual Adjustment] Press [Apply] button to store the adjustment value after all adjustment points have been adjusted. Adjustment value range: K: 1200 - 4096 K2: 500 - 1950

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
4. Frequency	*The Frequency adjustment can be performed only in PC test mode.	1) Adj item: [Frequency] SSG output: -20dBm (22.4mV) (CW (without modulation)) Caution: Perform the frequency adjustment under the following conditions. • Temperature range of +20°C to +33°C (+68.0°F to +91.4°F). (The temperature is displayed on the Frequency adjustment screen of the KPG-D3/ D3N and the LCD of the transceiver.) • Use an accuracy of 0.001ppm for the SSG. (Use a standard oscillator if necessary.)	SSG	Panel	ANT		[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] Press [Start] button of "Auto Tuning". Press [Apply] button to store the adjustment value after the automatic adjustment has finished.	[PC test mode] "IF20" value = Within 0±30 digits. The value of "IF20" will become around "0" after the adjustment has finished. Remark: "Frequency" is adjusted under receiving condition with SSG.
5. RTC Correciton	1) Adj item: [RTC] Adjust:[****] Press [▲] button to store the adjustment value.	1) Adj item: [RTC Correction] Data: [****] Press [Apply] button to store the adjustment value.	Frequency Counter	TX-RX	TEST POINT (CN55)				Remark: The adjustment value should input the display of a Frequency Counter.

4.26 Transmitter Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Maximum Transmit Power	1) Adj item: [MAX_P] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] PTT : ON Press [▲] button to store the adjustment value.	1) Adj item: [Maximum Transmit Power] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	57.5W	±2.5W 15A or less

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
2. High Transmit power	1) Adj item: [H_PWR] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [High Transmit Power] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	45W	±1W 13A or less
3. Medium Transmit power	1) Adj item: [M_PWR] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Medium Transmit Power] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	30W	±1W 10A or less
4. Low Transmit power	1) Adj item: [L_PWR] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Low Transmit Power] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	5W	±0.5W 7A or less

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
5. Ramp Offset	1) Adj item: [RAMP] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Ramp Offset] Press [Autotune(TX starts)] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] 1) Press [Autotune(TX starts)] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. 3) Check Ramp Offset Monitor Value Over 50. [Manual Adjustment] 1) Set the adjustment value to "1". 2) Press [Transmit] button and increase the adjustment value slowly while monitoring the offset monitor value. 3) Set the adjustment value when the offset monitor value exceed "60".	
6. Balance	1) Adj item: [An BAL] Adjust:[****] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Balance] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	The Deviation of 20Hz frequency is fixed. Change the 2kHz adjustment value to become the same deviation of 20Hz within the specified range. [Panel tuning mode] PTT:ON While PTT:ON, press the [◀] button to change the 20Hz/ 2kHz. [PC test mode] PTT: Press [Transmit] button. While PTT:ON, click the check box "2kHz Sine Wave" to change the 20Hz/2kHz.	2kHz Tone deviation is within ± 1.0% of 20Hz tone deviation.

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
7. Maximum Deviation [Analog Wide]	1) Adj item: [Aw ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2V]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Wide)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 4150Hz and 4250Hz. Deviation meter LPF: 15kHz HPF: OFF K:500(Reference value) K2:496(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	4150~4250Hz
[Analog Narrow]	1) Adj item: [An ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 2050Hz and 2150Hz. Deviation meter LPF: 15kHz HPF: OFF K:500(Reference value) K2:493(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2050~2150Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
8. NXDN High Deviation [NXDN Narrow]	1) Adj item: [Nn NDEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [NXDN High Deviation (NXDN Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 2995Hz and 3117Hz. Deviation meter LPF: 3kHz HPF: OFF K:503(Reference value) K2:498(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2995~3117Hz
[NXDN Very Narrow]	1) Adj item: [Nv NDEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [NXDN High Deviation (NXDN Very Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 1311Hz and 1363Hz. Deviation meter LPF: 3kHz HPF: OFF K:503(Reference value) K2:498(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	1311~1363Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
9. DMR High Deviation	1) Adj item: [D DDEV] Adjust: [****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DMR High Deviation (DMR Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 2695Hz and 2803Hz. Deviation meter LPF: 3kHz HPF: OFF K:503(Reference value) K2:496(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2695~2803Hz
10. QT Deviation [Analog Wide]	1) Adj item: [Aw QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Wide)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:520(Reference value) K2:529(Reference value)	0.75kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:520(Reference value) K2:529(Reference value)	0.35kHz±0.05 kHz
11. DQT Deviation [Analog Wide]	1) Adj item: [Aw DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Wide)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:414(Reference value) K2:426(Reference value)	0.75kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:414(Reference value) K2:426(Reference value)	0.35kHz±0.05 kHz
12. LTR Deviation [Analog Wide]	1) Adj item: [Aw LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Wide)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:508(Reference value) K2:518(Reference value)	1.00kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:494(Reference value) K2:518(Reference value)	0.75kHz±0.05 kHz
13. DTMF Deviation [Analog Wide]	1) Adj item: [Aw DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Wide)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:545(Reference value) K2:542(Reference value)	2.50kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:540(Reference value) K2:542(Reference value)	1.25kHz±0.05 kHz
14. Single Tone Deviation [Analog Wide]	1) Adj item: [Aw TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Wide)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:514(Reference value) K2:511(Reference value)	3.00kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:510(Reference value) K2:511(Reference value)	1.50kHz±0.05 kHz
15. MSK Deviation [Analog Wide]	1) Adj item: [Aw MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Wide)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:503(Reference value) K2:500(Reference value)	3.00kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:500(Reference value) K2:500(Reference value)	1.50kHz±0.05 kHz
16. CWID Deviation [Analog Narrow]	1) Adj item: [An CWID] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [CWID Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. K:506(Reference value) K2:508(Reference value)	1.10kHz±0.10 kHz

4.26.1 Necessary Deviation adjustment item for each signaling and mode

The following shows the necessary adjustment items for each signaling deviation. Please read the following table like the following example. In the case of the signaling "QT (Analog Wide)", this signaling is composed of three elements [Balance, Maximum Deviation (Analog Wide) and QT Deviation (Analog Wide)]. Please adjust Balance and Maximum Deviation (Analog Wide) before adjusting QT Deviation (Analog Wide).

Mode	Signaling	Necessary adjustment and order		
		Wide	Narrow	Very Narrow
Analog	Audio	1. Balance adjust 2. Maximum Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow]	-
	QT	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. QT Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. QT Deviation [Analog Narrow]	-
	DQT	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. DQT Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. DQT Deviation [Analog Narrow]	-
	LTR	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. LTR Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. LTR Deviation [Analog Narrow]	-
	DTMF	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. DTMF Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. DTMF Deviation [Analog Narrow]	-
	2TONE	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. Single Tone Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. Single Tone Deviation [Analog Narrow]	-
	MSK (Fleet sync)	1. Balance adjust 2. Maximum Deviation [Analog Wide] 3. MSK Deviation [Analog Wide]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. MSK Deviation [Analog Narrow]	-
NXDN	Audio	-	1. Balance adjust 2. NXDN High Deviation [NXDN Narrow]	1. Balance adjust 2. NXDN High Deviation [NXDN Very Narrow]
	CWID	-	-	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. CWID Deviation [Analog Narrow]
DMR	Audio	-	1. Balance adjust 2. DMR High Deviation	-

- Balance is common with all the above deviation adjustments. If Balance (Transmitter Section 6) has already adjusted, please skip Step1 and adjust from Step2.
- Maximum Deviation (Analog Wide/Narrow) is common with all the analog signaling deviations and CWID Deviation (NXDN Very Narrow).
If Balance and Maximum Deviation (Analog Wide /Narrow) (Transmitter Section 7) have already adjusted, please skip Step2 and adjust from Step3.

4.27 Receiver Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. AF level setting	[Panel test mode] 1) CH-Sig: 1-1 SSG output: -47dBm (1mV) (MOD: 1kHz/ ±1.5kHz)	1) Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 SSG output: -47dBm (1mV) (MOD:1kHz/ ±1.5kHz)	SSG DVM AF VM Dummy load	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Volume Up/Down knob to obtain 1.41V AF output. (0.5W @ 4ohm load)	1.41V ±0.1V
2. IQ Phase	1) Adj item: [An IQ] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: Freq: Tune Freq +8kHz level: -53dBm (500μV) (MOD:OFF)	1) Adj item: [IQ Phase] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: Freq: Tune Freq +8kHz level: -53dBm (500μV) (MOD:OFF)	SSG	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] After input signal from SSG, 1) Press [Autotune] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] Adjust RSSI Level(DSP Normal Power Mode) Value to the minimum.	
3. RSSI reference [DSP (Receive)]	1) Adj item: [An RSSI 1] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 1 DSP (Receive)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] After input signal from SSG, press [▲] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.		
[RF IC (Receive)]	1) Adj item: [An RSSI 2] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 2 RF IC (Receive)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] After input signal from SSG, press [▲] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.		


Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[DSP (Standby)]	1) Adj item: [An RSSI 3] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 3 DSP (Standby)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[RF IC (Standby)]	1) Adj item: [An RSSI 4] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 4 RF IC (Standby)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
4. Squelch Open [Analog Wide]	1) Adj item: [Aw SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±3kHz)	1) Adj item: [Squelch Open (Analog Wide)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±3kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Squelch Open (Analog Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[NXDN Narrow]	1) Adj item: [Nn SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level at Analog Narrow -5dB (MOD: 400Hz/ ±1.5kHz)	1) Adj item: [Squelch Open (NXDN Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level at Analog Narrow -5dB (MOD: 400Hz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[NXDN Very Narrow]	1) Adj item: [Nv SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level at Analog Narrow -2dB (MOD: 400Hz/ ±1.5kHz)	1) Adj item: [Squelch Open (NXDN Very Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level at Analog Narrow -2dB (MOD: 400Hz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	


Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[DMR]	1) Adj item: [D SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level at Analog Narrow -4dB (MOD: 400Hz/ ±1.8kHz)	1) Adj item: [Squelch Open (DMR)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level at Analog Narrow -4dB (MOD: 400Hz/ ±1.8kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
5. Squelch Tight [Analog Wide]	1) Adj item: [Aw SQLT] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±3kHz)	1) Adj item: [Squelch Tight (Analog Wide)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±3kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[Analog Narrow]	1) Adj item: [An SQLT] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Squelch Tight (Analog Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
6. Low RSSI	1) Adj item: [An LRSSI] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: -118dBm (0.28μV) (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Low RSSI (Analog Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: -118dBm (0.28μV) (MOD: 1kHz/ ±1.5kHz)	SSG	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
7. High RSSI	1) Adj item: [An HRSSI] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: -80dBm (22.4μV) (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [High RSSI (Analog Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: -80dBm (22.4μV) (MOD: 1kHz/ ±1.5kHz)	SSG	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

4.28 NX-3820(G)/3820 E TYPE Controls



KMC-36 (OPTION)



4.28.1 Preparations for checking/tuning the transceiver

Before attempting to check/tune the transceiver, connect the unit to a suitable power supply.

Whenever the transmitter is turned on, the unit must be connected to a suitable dummy load (i.e. power meter).

The speaker output connector must be terminated with an 4ohm dummy load and connected to an AC voltmeter and an audio distortion meter or a SINAD measurement meter at all times during checking/tuning.

4.29 Panel Test Mode

4.29.1 Test mode operation features

This transceiver has a test mode. To enter test mode, press and hold the [↵] button while turning the transceiver power ON or press the [☐] button and select the "Panel Test". Before the transceiver enters test mode, the frequency version information appears on the LCD momentarily. Test mode can be inhibited by programming. To exit test mode, turn the transceiver power OFF. The following functions are available in test mode.


- When the panel test mode is activated, the last used channel and signaling numbers are displayed. When the panel test mode is activated for the first time, the channel and signaling numbers are 1.

4.29.2 Button operation

Button	"Func" not appears on the sub LCD display	
	Function	Display
[+]	Push: Volume up Hold: Volume up continuously	-
[-]	Push: Volume down Hold: Volume down continuously	-
[▲]	Push: Test channel up Hold: Test channel up continuously	Channel No.
[▼]	Push: Test channel down Hold: Test channel down continuously	Channel No.
[◀]	Push: Squelch level up *1 Hold: Squelch off	Squelch level Squelch off: 📻 icon appears
[▶]	Wide 5k/Wide 4k/Narrow/ Very Narrow	Wide 5k: "w" Wide 4k: "s" Narrow: "n" Very Narrow: "v"
[☐]	Shift to panel tuning mode	-
[↵]	Function on	"Func" appears on the sub LCD display
[🏠]	Push: Test signaling up Hold: Test signaling up continuously	Signaling No.
[△(AUX)]	MSK 1200bps and 2400bps *1	2400bps: [✉] icon appears
[PTT]	Transmit	-
[0] to [9] and [#], [*]	-	-


*1: When the mode is selected as Analog, this function is enabled.

Button	"Func" appears on the sub LCD display	
	Function	Display
[+]	Function off	-
[-]	Function off	-
[▲]	-	-
[▼]	Mode selection Analog/NXDN/DMR	Analog: "A" NXDN: "N" DMR: "D"
[◀]	Function off	-
[▶]	Button/LCD check	The contents of the pressed button etc., appear.
[☐]	High power/Medium power/Low power	High:[H] icon appears Medium:[M] icon appears Low:[L] icon appears
[↵]	Function off	-
[🏠]	External Speaker on/off	On: 📢 icon appears

Button	"Func" appears on the sub LCD display	
	Function	Display
[△(AUX)]	Compander on/off	On: [] icon appears
[PTT]	Transmit	-
[0] to [9] and [#], [*]	Function off	-

- **LED indicator**
Red LED Lights during transmission.
Green LED Lights when there is carrier.
- **Sub LCD indicator**
"Func" Appears at function on.

• **LCD display in panel test mode**



4.29.3 Frequency and Signaling

The transceiver has been adjusted for the frequencies shown in the following table. When required, readjust them following the adjustment procedure to obtain the frequencies you want in actual operation.

(1) Test frequency

CH	RX (MHz)	TX (MHz)
1	435.05000	435.10000
2	400.05000	400.10000
3	469.95000	469.90000
4	435.00000	435.00000
5	435.20000	435.20000
6	435.40000	435.40000
7~16	-	-

(2) Signaling

■ **Analog Type Signaling**

No.	RX	TX
1	None	None
2	None	Square Wave
3	LTR Data	LTR Data
4	QT:67.0Hz	QT:67.0Hz
5	QT:151.4Hz	QT:151.4Hz
6	QT:210.7Hz	QT:210.7Hz
7	QT:254.1Hz	QT:254.1Hz
8	DQT:D023N	DQT:D023N
9	DQT:D754I	DQT:D754I
10	DTMF Decode (CODE: 159D)	DTMF Encode (CODE: 159D)
11	None	DTMF Encode (CODE: 9)
12	2-tone Decode (A: 304.7Hz, B: 3106.0Hz)	2-tone Encode (A: 304.7Hz, B: 3106.0Hz)
13	Single Tone Decode (979.9Hz)	Single Tone Encode (979.9Hz)
14	None	Single Tone Encode (1000Hz)
15	None	MSK PN9
16	MSK Decode	MSK Encode

■NXDN Type Signaling

No.	RX	TX
1	RAN1	RAN1
2	None	PN9
3	RAN1	Maximum Deviation Pattern
7	FSW + PN9	FSW + PN9
9	Tone Pattern (1031Hz)	Tone Pattern (1031Hz)

RAN: Radio Access Number
 PN9: Pseudo-Random Pattern
 No.7, 9 Item: PC test mode only

■DMR Type Signaling

No.	RX	TX
1	CC 00 Burst	CC 00 Burst
2	PN9	PN9
3	CC 00 Burst	Maximum Deviation Pattern
4	CC 00 Burst	1/3 Deviation Pattern
5	CC 00 Burst	0 Continuous Pattern
6	SYNC (Each Slot) + PN9 Burst Pattern	SYNC (Each Slot) + PN9 Burst Pattern
7	SYNC (Super Frame) + PN9 Burst Pattern	SYNC (Super Frame) + PN9 Burst Pattern
8	CC 00 Burst	0 Burst Pattern
9	Tone Pattern	Tone Test Burst Pattern
10	Silence Pattern	Silence Burst Pattern
11	Audio Test Pattern	Audio Test Burst Pattern
12	Vocoder Loop	None


4.30 Panel Tuning Mode

4.30.1 Transceiver tuning (To enter tuning mode)

To enter tuning mode, press the [] button while the transceiver is in test mode. Use the [Δ(AUX)] button to write tuning data through tuning modes, and the [▲]/[▼] button to adjust tuning requirements (1 to 4096 appears on the LCD).

Use the [] button to select the adjustment item through tuning modes. Use the [] button to adjust 5, 9 or 17 reference level adjustments, and use the [] button to switch between Wide5k/Wide4k/Narrow.

- LCD display in panel tuning mode



4.30.2 Button operation

Button	Function	
	Push	Hold (1 second)
[+]	Volume up	Continuation up
[-]	Volume down	Continuation down
[▲]	Adjustment value up	Continuation up
[▼]	Adjustment value down	Continuation down
[◀]	Auto adjustment start	Output tone pattern change of balance adjustment (A change is possible only during balance adjustment.)
[▶]	Wide 5k/Wide 4k/Narrow/NXDN/DMR	-
[]	Shift to panel test mode	-
[↶]	To enter 5,9 or 17 reference level adjustments	-
[]	Go to next adjustment item	Back to last adjustment item (At the time of 5, 9 or 17 point adjustment: Adjustment point change)
[Δ(AUX)]	Writes the adjustment value	-
[PTT] (MIC)	Transmit	
[0] to [9] and [#],[*] (MIC)	-	

4.30.3 5, 9 or 17 reference level adjustments frequency Maximum Transmit Power, High Transmit Power, Medium Transmit Power, Low Transmit Power, IQ Phase, RSSI Reference, Squelch Open, Squelch Tight, Low RSSI, High RSSI

Tuning point	Display	RX (MHz)	TX (MHz)
1	L1	400.05000	400.10000
2	L5	417.55000	417.60000
3	C3	435.05000	435.10000
4	H2	452.55000	452.60000
5	H6	469.95000	469.90000

Balance, Maximum Deviation, NXDN High Deviation, DMR High Deviation, QT Deviation, DQT Deviation, LTR Deviation, DTMF Deviation, Single Tone Deviation, MSK Deviation, CW ID Deviation

Tuning point	Display	RX (MHz)	TX (MHz)
1	L1	400.05000	400.10000
2	L3	408.85000	408.90000
3	L5	417.55000	417.60000
4	C1	426.35000	426.40000
5	C3	435.05000	435.10000
6	C5	443.85000	443.90000

Tuning point	Display	RX (MHz)	TX (MHz)
7	H2	452.55000	452.60000
8	H4	461.35000	461.40000
9	H6	469.95000	469.90000

VCO Assist

Tuning point	Display	RX (MHz)	TX (MHz)
1	L1	400.05000	400.10000
2	L2	404.45000	404.50000
3	L3	408.85000	408.90000
4	L4	413.25000	413.30000
5	L5	417.55000	417.60000
6	L6	421.95000	422.10000
7	C1	426.35000	426.40000
8	C2	430.75000	430.80000
9	C3	435.05000	435.10000
10	C4	439.45000	439.50000
11	C5	443.85000	443.90000
12	H1	448.25000	448.30000
13	H2	452.55000	452.60000
14	H3	456.95000	457.10000
15	H4	461.35000	461.40000
16	H5	465.75000	465.80000
17	H6	469.95000	469.90000

4.30.4 Adjustment item supplement

Adjustment Item	Description
LCD Contrast	The contrast of LCD display can be changed.
VCO Assist	The lock voltage of VCO is adjusted. This item must be adjusted before receiver and transmitter adjustment items.
Frequency	Frequency is adjusted under receiving condition with SSG. The SSG needs 0.001ppm accuracy so please use a standard oscillator if necessary. This item can be adjusted only in PC Test Mode so that the adjustment value is not changed easily.
RTC Correction	Real Time Clock is adjusted. This item uses the internal clock. (Any measurement equipment is not required.)
Maximum Transmit Power	Maximum Transmit Power is adjusted.
High Transmit Power	High Transmit Power is adjusted.
Mid Transmit Power	Medium Transmit Power is adjusted.
Low Transmit Power	Low Transmit Power is adjusted.

Adjustment Item	Description
Ramp Offset	Adjust this item to the optimal Ramp voltage.
Balance	The transmit modulation frequency response is adjusted. This item is adjusted so that the deviation of 2kHz becomes the same deviation of 20Hz. This item must be adjusted before all adjustment items for deviations are adjusted.
Maximum Deviation (Analog Wide 5k/ Wide 4k/Narrow)	Maximum Deviation of Analog (Wide 5k/ Wide 4k/Narrow) is adjusted. This item must be adjusted before all adjustment items for tone deviations are adjusted.
High Deviation	NXDN/DMR high deviation is adjusted.
QT Deviation	QT deviation is adjusted.
DQT Deviation	DQT deviation is adjusted.
LTR Deviation	LTR deviation is adjusted.
DTMF Deviation	DTMF deviation is adjusted.
Single Tone Deviation	The deviation of Single Tone used in "2-tone" and "5-tone" is adjusted.
MSK Deviation	MSK deviation is adjusted.
CW ID Deviation	CWID tone deviation is adjusted. CWID is used to inform the others who is transmitting on a 6.25-kHz spacing channel. (In FCC rule, Analog mode or CWID is required for each channel-spacing.)
IQ Phase	Correction of phase difference shift between I and Q.
RSSI Reference	The minimum RSSI level for scan stop is adjusted.
Squelch Open	The squelch level at level "1" is adjusted.
Squelch Tight	The squelch level at level "9" is adjusted.
Low RSSI	RSSI display level "1" is adjusted.
High RSSI	Both "Low RSSI" and "High RSSI" must be adjusted. (The curve data of RSSI level is applied.)

4.30.5 Adjustment item and Display


Order	Adjustment item	Main LCD display	Sub LCD display	AW	AS	AN	Nn	Nv	D	Adjust item Number
				(Analog Wide 5k)	(Analog Wide 4k)	(Analog Narrow)	(NXDN Narrow)	(NXDN Very Narrow)	(DMR)	
				Adjustment range						
1	LCD Contrast	CNTR	-	1 point ADJ						Common Section 2
				1~256						
2	VCO Assist	AST	(CV voltage)	-	-	17	-	-	-	Common Section 3
				1~4096						
3	RTC Correction	RTC	-	-						Common Section 5
				-2.00 ~ -0.01 ,0.00 ,+0.01 ~ +2.00						
4	Maximum Transmit Power	MAX_P	-	-	-	5	-	-	-	Transmitter Section 1
				1~256						
5	High Transmit Power	H_PWR	-	-	-	5	-	-	-	Transmitter Section 2
				1~1024						
6	Medium Transmit Power	M_PWR	-	-	-	5	-	-	-	Transmitter Section 3
				1~1024						
7	Low Transmit Power	L_PWR	-	-	-	5	-	-	-	Transmitter Section 4
				1~1024						
8	Ramp Offset	RAMP	(ADC measurement value)	1 point ADJ						Transmitter Section 5
				1~1024						
9	Balance	BAL	(Encode frequency)	-	-	9	-	-	-	Transmitter Section 6
				1~1024						
10	Maximum Deviation	ADEV	-	9	9	9	-	-	-	Transmitter Section 7
				1~1024						
11	NXDN High Deviation	NDEV	-	-	-	-	9	9	-	Transmitter Section 8
				1~1024						
12	DMR High Deviation	DDEV	-	-	-	-	-	-	9	Transmitter Section 9
				1~1024						
13	QT Deviation	QT	-	9	9	9	-	-	-	Transmitter Section 10
				1~1024						
14	DQT Deviation	DQT	-	9	9	9	-	-	-	Transmitter Section 11
				1~1024						
15	LTR Deviation	LTR	-	9	9	9	-	-	-	Transmitter Section 12
				1~1024						
16	DTMF Deviation	DTMF	-	9	9	9	-	-	-	Transmitter Section 13
				1~1024						
17	Single Tone Deviation	TONE	-	9	9	9	-	-	-	Transmitter Section 14
				1~1024						
18	MSK Deviation	MSK	-	9	9	9	-	-	-	Transmitter Section 15
				1~1024						
19	CW ID Deviation	CWID	-	-	-	9	-	-	-	Transmitter Section 16
				1~1024						
20	IQ Phase	IQ	(RSSI DSP(Receive) measurement value)	-	-	5	-	-	-	Receive Section 2
				1~63						
21	RSSI Reference 1 DSP (Receive)	RSSI1	(RSSI DSP(Receive) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						

Order	Adjustment item	Main LCD display	Sub LCD display	AW	AS	AN	Nn	Nv	D	Adjust item Number
				(Analog Wide 5k)	(Analog Wide 4k)	(Analog Narrow)	(NXDN Narrow)	(NXDN Very Narrow)	(DMR)	
				Adjustment range						
22	RSSI Reference 2 RF IC(Receive)	RSSI2	(RSSI RF IC(Receive) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
23	RSSI Reference 3 DSP (Standby)	RSSI3	(RSSI DSP (Standby) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
24	RSSI Reference 4 RF IC (Standby)	RSSI4	(RSSI RF IC (Standby) measurement value)	-	-	5	-	-	-	Receive Section 3
				1~256						
25	Squelch Open	SQL	(ASQDET measurement value)	5	5	5	5	5	5	Receive Section 4
				1~256						
26	Squelch Tight	SQLT	(ASQDET measurement value)	5	5	5	-	-	-	Receive Section 5
				1~256						
27	Low RSSI	LRSSI	(RSSI DSP (Receive) measurement value)	-	-	5	-	-	-	Receive Section 6
				1~256						
28	High RSSI	HRSSI	(RSSI DSP (Receive) measurement value)	-	-	5	-	-	-	Receive Section 7
				1~256						

4.30.6 Panel tuning mode flow chart


Note:

* In this Panel tuning mode flow chart, the Adjustment item name is modified.



4.31 Adjustment points

TX-RX UNIT (XC1-183)
Component Side




4.32 Test Equipment Required for Alignment


Test Equipment	Major Specifications	
1. Standard Signal Generator (SSG)	Frequency Range Modulation Output	100 to 900MHz Frequency modulation and external modulation -127dBm/0.1uV to greater than -20dBm/22.4mV
	When performing the Frequency adjustment, the following accuracy is necessary. • 0.001ppm Use a standard oscillator for adjustments, if necessary.	
2. Power Meter	Input Impedance Operation Frequency Measurement Capability	50ohm 100 to 900MHz Vicinity of 100W
3. Deviation Meter	Frequency Range	100 to 900MHz
4. Digital Volt Meter (DVM)	Measuring Range Input Impedance	10mV to 20V DC High input impedance for minimum circuit loading
5. Oscilloscope		DC through 30MHz
6. Frequency Counter	Frequency Range Frequency Stability	10Hz to 1000MHz 0.2ppm or less
	To measure the oscillating frequency of the internal clock 32766.00Hz~32770.00Hz for RTC Correction Resolution 0.01Hz is better for accuracy adjustment.	
7. Ammeter		20A or more
8. AF Volt Meter (AF VM)	Frequency Range Voltage Range	50Hz to 10kHz 1mV to 10V
9. Audio Generator (AG)	Frequency Range Output	50Hz to 5kHz or more 0 to 1V
10. Distortion Meter	Capability Input Level	3% or less at 1kHz 50mV to 10Vrms
11. Spectrum Analyzer	Measuring Range	DC to 1GHz or more
12. 4ohm Dummy Load		Approx. 4ohm, 10W
13. Regulated Power Supply		13.2V, approx. 20A (adjustable from 9V to 17V) Useful if ammeter equipped

*The test equipment which is not used for adjustment is contained in this table.

■ Test cable for microphone input (E30-3360-28)



■ MIC connector (Front panel view)



- 1 : BLC
- 2 : +B
- 3 : GND
- 4 : PTT/TXD (PC serial data from radio)
- 5 : MICE
- 6 : MIC
- 7 : HOOK/RXD (PC serial data to radio)
- 8 : DM

■ Tuning cable (E30-7754-05)

Adapter cable (E30-7754-05) is required for injecting an audio if PC tuning is used.
See "PC Mode" section for the connection.

4.33 Radio check Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Frequency check	1)CH-Sig: 1-1 PTT: ON	1)Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.	f. counter	Panel	ANT			Check an internal temperature of radio from 20°C to 33°C.	±0.25ppm ±106.2Hz @435.1MHz
2. High power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	21W~29W 10A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.							

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel test mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
3. Low power check	1)CH-Sig: 1-1 PTT: ON TA: OFF	1)Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter	Panel	ANT			Check	3.5W~6.5W 7.0A or less
	2)CH-Sig: 2-1 PTT: ON TA: OFF	2)Test Channel Channel: 2 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3)CH-Sig: 3-1 PTT: ON TA: OFF	3)Test Channel Channel: 3 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.							
4. MIC sensitivity check	1)CH-Sig: 1-1 AG: 1kHz PTT: ON	1)Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 AG: 1kHz PTT: Press [Transmit] button.	Deviation meter Oscilloscope AG AF VM	Panel	ANT MIC jack			Adjust AG input to get a standard MOD.	5mV ±1mV
5. Sensitivity check	1)CH-Sig: 1-1 SSG output Wide 5k: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Wide 4k: -117dBm (0.32μV) (MOD: 1kHz/ ±2.4kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/ ±1.5kHz)	1)Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 SSG output Wide 5k: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Wide 4k: -117dBm (0.32μV) (MOD: 1kHz/±2.4kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/±1.5kHz)	SSG AF VM Oscilloscope Distortion meter 4ohm Dummy load	Panel	ANT Ext. SP connector			Check	12dB SINAD or more

4.34 Common Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Setting	1) DC voltage:13.2V 2) SSG standard modulation [Wide 5k] MOD:1kHz,DEV:3kHz [Wide 4k] MOD:1kHz,DEV:2.4kHz [Narrow] MOD:1kHz,DEV:1.5kHz								
2.LCD Contrast	1) Adj item [CNTR] Adjust:[****] Press [Δ] button to store the adjustment value.	1) Adj item [LCD Contrast] Data: [****] Press [Apply] button to store the adjustment value.				Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 280 (Reference value)	
3. VCO Assist	1) Adj item: [AST] Adjust:[****] 2) Adj item: [L1]→ [L2]→ [L3]→ [L4]→ [L5]→ [L6]→ [C1]→ [C2]→ [C3]→ [C4]→ [C5]→ [H1]→ [H2]→ [H3]→ [H4]→ [H5]→ [H6] Adjust:[****] Press [Δ] button to store the adjustment value.	1) Adj item: [VCO Assist] 2) Adj item: [Low1],[Low2],[Low3],[Low4],[Low5], [Low6] [Center1],[Center2],[Center3],[Center4],[Center5],[High1],[High2] [High3],[High4],[High5][High6] Press [Apply] button to store the adjustment value.				Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] 1) Press [Autotune] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] [V] Indicator on the PC window shows VCO lock voltage. Change the adjustment value to get VCO lock voltage within the limit of the specified voltage. Note: Confirm the VCO lock voltage approximately 3 seconds after the adjustment value is changed.	2.5V±0.1V [Automatic Adjustment] After the automatic adjustment is performed, verify that the VCO lock voltage is within the voltage range which is specified by the manual adjustment. [Manual Adjustment] Press [Apply] button to store the adjustment value after all adjustment points have been adjusted. Adjustment value range: 500 - 1950

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
4. Frequency	*The Frequency adjustment can be performed only in PC test mode.	1) Adj item: [Frequency] SSG output: -20dBm (22.4mV) (CW (without modulation)) Caution: Perform the frequency adjustment under the following conditions. • Temperature range of +20°C to +33°C (+68.0°F to +91.4°F). (The temperature is displayed on the Frequency adjustment screen of the KPG-D3/ D3N and the LCD of the transceiver.) • Use an accuracy of 0.001ppm for the SSG. (Use a standard oscillator if necessary.)	SSG	Panel	ANT		[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] Press [Start] button of "Auto Tuning". Press [Apply] button to store the adjustment value after the automatic adjustment has finished.	[PC test mode] "IF20" value = Within 0±30 digits. The value of "IF20" will become around "0" after the adjustment has finished. Remark: "Frequency" is adjusted under receiving condition with SSG.
5. RTC Correciton	1) Adj item: [RTC] Adjust:[****] Press [▲] button to store the adjustment value.	1) Adj item: [RTC Correction] Data: [****] Press [Apply] button to store the adjustment value.	Frequency Counter	TX-RX	TEST POINT (CN55)				Remark: The adjustment value should input the display of a Frequency Counter.

4.35 Transmitter Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Maximum Transmit Power	1) Adj item: [MAX_P] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Maximum Transmit Power] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	57.5W	±2.5W 15A or less
2. High Transmit power	1) Adj item: [H_PWR] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [High Transmit Power] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	25W	±1W 10A or less
3. Low Transmit power	1) Adj item: [L_PWR] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Low Transmit Power] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	5W	±0.5W 7A or less

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
4. Ramp Offset	1)Adj item: [RAMP] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Ramp Offset] Press [Autotune(TX starts)] button. Press [Apply] button to store the adjustment value.	Power meter Ammeter	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] 1) Press [Autotune(TX starts)] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. 3) Check Ramp Offset Monitor Value Over 50. [Manual Adjustment] 1) Set the adjustment value to "1". 2) Press [Transmit] button and increase the adjustment value slowly while monitoring the offset monitor value. 3) Set the adjustment value when the offset monitor value exceed "60".	
5. Balance	1) Adj item: [An BAL] Adjust:[****] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Balance] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	The Deviation of 20Hz frequency is fixed. Change the 2kHz adjustment value to become the same deviation of 20Hz within the specified range. [Panel tuning mode] PTT:ON While PTT:ON, press the [◀] button to change the 20Hz/ 2kHz. [PC test mode] PTT: Press [Transmit] button. While PTT:ON, click the check box "2kHz Sine Wave" to change the 20Hz/2kHz.	2kHz Tone deviation is within ± 1.0% of 20Hz tone deviation.

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
6. Maximum Deviation [Analog Wide 5k]	1) Adj item: [Aw ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2V]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Wide 5k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 4150Hz and 4250Hz. Deviation meter LPF: 15kHz HPF: OFF 496(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	4150~4250Hz
[Analog Wide 4k]	1) Adj item: [As ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2V]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Wide 4k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 3310Hz and 3410Hz. Deviation meter LPF: 15kHz HPF: OFF 496(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	3310~3410Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An ADEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Maxmum Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the deviation is between 2050Hz and 2150Hz. Deviation meter LPF: 15kHz HPF: OFF 493(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2050~2150Hz
7. NXDN High Deviation [NXDN Narrow]	1) Adj item: [Nn NDEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [NXDN High Deviation (NXDN Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 2995Hz and 3117Hz. Deviation meter LPF: 3kHz HPF: OFF 498(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2995~3117Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[NXDN Very Narrow]	1) Adj item: [Nv NDEV] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [NXDN High Deviation (NXDN Very Narrow] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 1331Hz 1311Hz and 1363Hz. Deviation meter LPF: 3kHz HPF: OFF 498(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	1311~1363Hz
8. DMR High Deviation	1) Adj item: [D DDEV] Adjust: [****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DMR High Deviation (DMR Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write fixed value for each adjustment point. (The value is written below.) Transmit at each adjustment point and check that the Analog deviation is between 2695Hz and 2803Hz. Deviation meter LPF: 3kHz HPF: OFF 496(Reference value) [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2695~2803Hz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
9. QT Deviation [Analog Wide 5k]	1) Adj item: [Aw QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Wide 5k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 529(Reference value)	0.75kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Wide 4k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 529(Reference value)	0.60kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An QT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [QT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 529(Reference value)	0.35kHz±0.05 kHz
10. DQT Deviation [Analog Wide 5k]	1) Adj item: [Aw DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Wide 5k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 426(Reference value)	0.75kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Wide 4k]	1) Adj item: [As DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Wide 4k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 426(Reference value)	0.60kHz±0.05 kHz
[Analog Narrow]	1) Adj item: [An DQT] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 426(Reference value)	0.35kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
11. LTR Deviation [Analog Wide 5k]	1) Adj item: [Aw LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Wide 5k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 518(Reference value)	1.00kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Wide 4k)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 518(Reference value)	0.90kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An LTR] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 518(Reference value)	0.75kHz±0.05 kHz
12. DTMF Deviation [Analog Wide 5k]	1) Adj item: [Aw DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Wide 5k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 542(Reference value)	2.50kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Wide 4k]	1) Adj item: [As DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Wide 4k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 542(Reference value)	2.00kHz±0.05 kHz
[Analog Narrow]	1) Adj item: [An DTMF] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 542(Reference value)	1.25kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
13. Single Tone Deviation [Analog Wide 5k]	1) Adj item: [Aw TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Wide 5k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 511(Reference value)	3.00kHz±0.05 kHz
[Analog Wide 4k]	1) Adj item: [As TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [Δ] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Wide 4k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 511(Reference value)	2.40kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Narrow]	1) Adj item: [An TONE] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 511(Reference value)	1.50kHz±0.05 kHz
14. MSK Deviation [Analog Wide 5k]	1) Adj item: [Aw MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Wide 5k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 500(Reference value)	3.00kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Wide 4k]	1) Adj item: [As MSK] Adjust:[****] [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Wide 4k)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 500(Reference value)	2.40kHz±0.05 kHz
[Analog Narrow]	1) Adj item: [An MSK] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 500(Reference value)	1.50kHz±0.05 kHz

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
15. CWID Deviation [Analog Narrow]	1) Adj item: [An CWID] Adjust:[****] 2) Adj item: [L1]→ [L3]→ [L5]→ [C1]→ [C3]→ [C5]→ [H2]→ [H4]→ [H6] Adjust:[****] PTT : ON Press [△] button to store the adjustment value.	1) Adj item: [CWID Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF 2) Adj item: [Low1]→ [Low3]→ [Low5]→ [Center1]→ [Center3]→ [Center5]→ [High2]→ [High4]→ [High6] Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	Panel	ANT	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Write the value as followings. 508(Reference value)	1.10kHz±0.10 kHz

4.35.1 Necessary Deviation adjustment item for each signaling and mode

The following shows the necessary adjustment items for each signaling deviation. Please read the following table like the following example. In the case of the signaling "QT (Analog Wide 5k)", this signaling is composed of three elements [Balance, Maximum Deviation (Analog Wide 5k) and QT Deviation (Analog Wide 5k)]. Please adjust Balance and Maximum Deviation (Analog Wide 5k) before adjusting QT Deviation (Analog Wide 5k).

Mode	Signaling	Necessary adjustment and order			
		Wide 5k	Wide 4k	Narrow	Very Narrow
Analog	Audio	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow]	-
	QT	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. QT Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. QT Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. QT Deviation [Analog Narrow]	-
	DQT	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. DQT Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. DQT Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. DQT Deviation [Analog Narrow]	-
	LTR	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. LTR Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. LTR Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. LTR Deviation [Analog Narrow]	-
	DTMF	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. DTMF Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. DTMF Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. DTMF Deviation [Analog Narrow]	-
	5TONE	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. Single Tone Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. Single Tone Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. Single Tone Deviation [Analog Narrow]	-
	MSK (Fleet sync)	1. Balance adjust 2. Maximum Deviation [Analog Wide 5k] 3. MSK Deviation [Analog Wide 5k]	1. Balance adjust 2. Maximum Deviation [Analog Wide 4k] 3. MSK Deviation [Analog Wide 4k]	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. MSK Deviation [Analog Narrow]	-
NXDN	Audio	-	-	1. Balance adjust 2. NXDN High Deviation [NXDN Narrow]	1. Balance adjust 2. NXDN High Deviation [NXDN Very Narrow]
	CWID	-	-	-	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. CWID Deviation [Analog Narrow]
DMR	Audio	-	-	1. Balance adjust 2. DMR High Deviation	-

- Balance is common with all the above deviation adjustments. If Balance (Transmitter Section 6) has already adjusted, please skip Step1 and adjust from Step2.
- Maximum Deviation (Analog Wide 5k/Wide 4k/Narrow) is common with all the analog signaling deviations and CWID Deviation (NXDN Very Narrow).
If Balance and Maximum Deviation (Analog Wide 5k/Wide 4k /Narrow) (Transmitter Section 7) have already adjusted, please skip Step2 and adjust from Step3.

4.36 Receiver Section

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. AF level setting	[Panel test mode] 1) CH-Sig: 1-1 SSG output: -47dBm (1mV) (MOD: 1kHz/ ±1.5kHz)	1) Test Channel Channel: 1 Test Signaling Type: Analog Signaling: 1 SSG output: -47dBm (1mV) (MOD:1kHz/ ±1.5kHz)	SSG DVM AF VM Dummy load	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	Volume Up/Down knob to obtain 1.41V AF output. (0.5W @ 4ohm load)	1.41V ±0.1V
2. IQ Phase	1) Adj item: [An IQ] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: Freq: Tune Freq +8kHz level: -53dBm (500µV) (MOD:OFF)	1) Adj item: [IQ Phase] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: Freq: Tune Freq +8kHz level: -53dBm (500µV) (MOD:OFF)	SSG	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] [▲], [▼] [PC test mode] [+], [-]	[PC test mode] [Automatic Adjustment] After input signal from SSG, 1) Press [Autotune] button. 2) Press [Apply] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] Adjust RSSI Level(DSP Normal Power Mode) Value to the minimum.	
3. RSSI reference [DSP (Receive)]	1) Adj item: [An RSSI 1] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 1 DSP (Receive)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] After input signal from SSG, press [▲] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.		
[RF IC (Receive)]	1) Adj item: [An RSSI 2] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 2 RF IC (Receive)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel	[Panel tuning mode] After input signal from SSG, press [▲] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.		

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[DSP (Standby)]	1) Adj item: [An RSSI 3] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 3 DSP (Standby)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[RF IC (Standby)]	1) Adj item: [An RSSI 4] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow) 4 RF IC (Standby)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
4. Squelch Open [Analog Wide 5k]	1) Adj item: [Aw SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±3kHz)	1) Adj item: [Squelch Open (Analog Wide 5k)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±3kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Wide 4k]	1) Adj item: [As SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±2.4kHz)	1) Adj item: [Squelch Open (Analog Wide 4k)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±2.4kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[Analog Narrow]	1) Adj item: [An SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Squelch Open (Analog Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[NXDN Narrow]	1) Adj item: [Nn SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level at Analog Narrow -5dB (MOD: 400Hz/ ±1.5kHz)	1) Adj item: [Squelch Open (NXDN Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level at Analog Narrow -5dB (MOD: 400Hz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[NXDN Very Narrow]	1) Adj item: [Nv SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level at Analog Narrow -2dB (MOD: 400Hz/ ±1.5kHz)	1) Adj item: [Squelch Open (NXDN Very Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level at Analog Narrow -2dB (MOD: 400Hz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[DMR]	1) Adj item: [D SQL] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level at Analog Narrow -4dB (MOD: 400Hz/ ±1.8kHz)	1) Adj item: [Squelch Open (DMR)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level at Analog Narrow -4dB (MOD: 400Hz/ ±1.8kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
5. Squelch Tight [Analog Wide 5k]	1) Adj item: [Aw SQLT] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±3kHz)	1) Adj item: [Squelch Tight (Analog Wide 5k)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±3kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [△] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

Item	Condition		Measurement			Adjustment			Specifications /Remarks
	Panel tuning mode	PC test mode	Test-equipment	Unit	Terminal	Unit	Parts	Method	
[Analog Wide 4k]	1) Adj item: [As SQLT] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±2.4kHz)	1) Adj item: [Squelch Tight (Analog Wide 4k)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±2.4kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
[Analog Narrow]	1) Adj item: [An SQLT] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Squelch Tight (Analog Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: 12dB SINAD level +6dB (MOD: 1kHz/ ±1.5kHz)	SSG Distortion meter Oscilloscope	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
6. Low RSSI	1) Adj item: [An LRSSI] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: -118dBm (0.28μV) (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [Low RSSI (Analog Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: -118dBm (0.28μV) (MOD: 1kHz/ ±1.5kHz)	SSG	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	
7. High RSSI	1) Adj item: [An HRSSI] Adjust:[****] 2) Adj item: [L1]→ [L5]→ [C3]→ [H2]→ [H6] SSG output: -80dBm (22.4μV) (MOD: 1kHz/ ±1.5kHz)	1) Adj item: [High RSSI (Analog Narrow)] 2) Adj item: [Low1]→ [Low5]→ [Center3]→ [High2]→ [High6] SSG output: -80dBm (22.4μV) (MOD: 1kHz/ ±1.5kHz)	SSG	Panel	ANT Ext. SP connector	Panel		[Panel tuning mode] After input signal from SSG, press [Δ] button to store the adjustment value. [PC test mode] After input signal from SSG, 1) Press [Acquire Monitored Value] button. 2) Press [Apply] button to store the adjustment value.	

SECTION 5 TROUBLESHOOTING

5.1 Fault Diagnosis of the BGA (Ball Grid Array) IC

■ Overview

A flowchart for determining whether or not the transceiver can be powered on (the LCD does not function even if the power switch is turned on) due to broken BGA parts.

■ BGA parts


MPU/DSP(IC404), mobile DDR(IC402), Flash Memory(IC401)


When the BGA IC is problematic, please bring the printed circuit board (XCA-033K-00/XCA-033E-01/XCA-034K-00/XCA-034K-01/XCA-034E-01) in for service. Various ESN/ default adjustment values are written on the printed circuit board for service.

Additionally various ESN stickers are included. (Please refer to "5.4 Replacing TX-RX Unit".)

After the printed circuit board has been readjusted, please attach any ESN stickers to the chassis. When "ESN Validation" is used, you must modify the ESN register.

- Checking power supply voltage






■ Descriptions of signal names


1) /RST	: MPU/DSP reset signal	LOW → Reset
2) /BINT	: Battery final voltage monitoring	LOW → Final voltage
3) /OVRB_OUT	: Battery overvoltage monitoring	LOW → Overvoltage
4) /PSW_OUT	: Power switch signal	LOW → ON
5) /IGN_OUT	: Ignition switch signal	LOW → ON
6) /FRST	: Flash Memory reset signal	HIGH → Reset
7) /CS_F	: Flash Memory chip select signal	LOW → Active
8) SBC	: Switch +B control	HIGH → ON
9) PRST	: LCD reset signal	HIGH → Reset
10) /CS_LCD	: LCD controller chip select signal	LOW → Active

*1 If 12M, 18M or 32M has still an abnormal voltage after the implementation of each procedure above, 54M(IC25),12M(IC24),18M(IC12),32M(IC20) or one of these peripheral circuit is broken.
 54M(normally 5.4V at L13) has an abnormal voltage, check the MSP430(IC22) according to the following procedure.


● Checking the operation of the MSP430




*2 ● Checking the operation of the MSP430 (/RST)




● Checking the operation of MSP430 (/BINT)




● Checking the operation of MSP430 (/OVRB_OUT)



- Checking the operation of MSP430 (/PSW and /IGN)
Check that the signal /PSW(IC22 - 10pin) and /PSW_OUT(IC22 - 15pin) are linked with the power button on KCH-19 in power on state.



If the ignition function is enabled, check that the signal /IGN(IC22 - 8pin) and /IGN_OUT(IC22 - 9pin) are linked with the ignition sense.



■ Remarks related to MSP430

- When MSP430(IC22) is replaced, IC22 must be replaced to "MSP430G25KGCA"(This MSP430 is written the program.).
- OMAP communicates with MSP430 by serial communication at startup of deck.
Only firmware version of MSP430 is confirmed by OMAP in serial communication.
Even when firmware version of MSP430 can not be acquired, the system of MSP430 is started.
- If there is the difference of firmware version of MSP430 between MSP430 and OMAP, the firmware version of MSP430 is updated with the serial communication by OMAP.
"WAIT..." is displayed on the LCD during the firmware update. When the firmware update fails, the system of MSP430 is started and OMAP is trying to update again at next startup.



5.2 Failure diagnosis of the GPS section (GPS model only)


Overview:


When the GPS function does not operate, use this flowchart to determine the problem.


Major parts for a GPS circuit


- GPS active antenna: KRA-40 (option)
- Coaxial cable: E0E-0003-00
- SAW Filter (L9)
- Bluetooth/GPS IC (IC5)
- Level conversion IC (IC6, IC7)
- TCXO 19.2MHz (X1)
- 32.768 kHz clock (X2)
- 33BT Regulator (IC3)
- 18BT Regulator (IC2)
- 33GPS Regulator (IC4)
- MPU/DSP IC (IC404)











■ Descriptions of signal names

- 1) 33BT: BT/GPS IC 3.3V power supply
- 2) 18BT: BT/GPS IC 1.8V power supply
- 3) 33GPS: BT/GPS IC 3.3V power supply
- 4) TXD2: BT/GPS serial data line connected to UART TX of MPU/DSP IC (MPU/DSP to BT/GPS IC)
- 5) RXD2: BT/GPS serial data line connected to UART RX of MPU/DSP IC (MPU/DSP to BT/GPS IC)
- 6) 18BT_HCI_RX: BT/GPS serial data line connected to UART RX of BT/GPS IC (MPU to BT/GPS IC)
- 7) 18BT_HCI_TX: BT/GPS serial data line connected to UART TX of GPS IC (BT/GPS IC to MPU)
- 8) /BT_SHUTDOWN: BT/GPS active control of MPU/DSP IC (MPU/DSP to BT/GPS IC) High→Active, Low→Reset



5.3 Failure diagnosis of the Bluetooth section


Overview:


When the Bluetooth function does not operate, use this flowchart to determine the problem.


Major parts for a Bluetooth circuit

- Bluetooth antenna (Pattern Antenna)
- LC filter (L11)
- Bluetooth/GPS IC (IC5)
- Level conversion IC (IC6, IC7)
- TCXO 19.2MHz (X1)
- 32.768 kHz clock (X2)
- 33BT Regulator (IC3)
- 18BT Regulator (IC2)
- MPU/DSP IC (IC404: TX-RX Unit)









■ Descriptions of signal names


- 1) 33BT: BT/GPS IC 3.3V power supply
- 2) 18BT: BT/GPS IC 1.8V power supply
- 3) TXD2: BT/GPS serial data line connected to UART TX of MPU/DSP IC (MPU/DSP to BT/GPS IC)
- 4) RXD2: BT/GPS serial data line connected to UART RX of MPU/DSP IC (MPU/DSP to BT/GPS IC)
- 5) 18BT_HCI_RX: BT/GPS serial data line connected to UART RX of BT/GPS IC (MPU to BT/GPS IC)
- 6) 18BT_HCI_TX: BT/GPS serial data line connected to UART TX of GPS IC (BT/GPS IC to MPU)
- 7) /BT_SHUTDOWN: BT/GPS active control of MPU/DSP IC (MPU/DSP to BT/GPS IC) High→ Active, Low→Reset

5.4 Replacing TX-RX Unit

■TX-RX unit Information

Model Name	Original TX-RX unit Number	For Service TX-RX unit Number
NX-3720H(G)/3720H (K)	XC1-182K-00	XCA-033K-00
NX-3720(G)/3720 (E)	XC1-182K-00	XCA-033E-01
NX-3820H(G)/3820H (K)	XC1-183K-00	XCA-034K-00
NX-3820H(G)/3820H (K2)	XC1-183K-01	XCA-034K-01
NX-3820(G)/3820 (E)	XC1-183K-01	XCA-034E-01

■Method of confirming “Original TX-RX unit” and “Service TX-RX unit”



The following marking seals are affixed on the shield cover of the service TX-RX unit (XCA-033K-00/XCA-033E-01/ XCA-034K-00/XCA-034K-01/XCA-034E-01).

Model Name	Marking seal
NX-3720H(G)/3720H (K)	XCA-033K-00
NX-3720(G)/3720 (E)	XCA-033E-01
NX-3820H(G)/3820H (K)	XCA-034K-00
NX-3820H(G)/3820H (K2)	XCA-034K-01
NX-3820(G)/3820 (E)	XCA-034E-01

■Supplied Accessories of “Service TX-RX unit”

Item (Including Parts Number)	Quantity
TX-RX Unit (XC1-182, XC1-183)	1
KENWOOD ESN/ NXDN ESN/ Product Number/ MPT ESN Label	1

■“Service TX-RX unit” Data

The following data is written on the service unit:

Data Type	Description
KENWOOD ESN	NX-3720, NX-3720H Model name: [XCA-033] NX-3720S (K, E) Type:K, E The same number as the KENWOOD ESN label is written.
	NX-3820, NX-3820H Model name: [XCA-034] NX-3820S (K, K2, E) Type:K, K2, E The same number as the KENWOOD ESN label is written.
NXDN ESN/ MPT ESN/ Product number	The same number as the NXDN ESN/ MPT ESN/ Product Number label is written.

■After Changing the PCB


- (1) After changing the printed circuit board, write the up-to-date Firmware following the instructions in the “2.2 REALIGNMENT - 2.2.6 Firmware Programming Mode”.
 - Write the Firmware in accordance to the Market. If you write different Market Firmware, there are times communication with the FPU is not possible.
- (2) Using the KPG-D3/D3N, select your desired item (Model Name) from the Radio Configuration> Product Information menu, then use Read/ Write > Write Configuration to the Transceiver to write the FPU data (PC Programming mode). When writing to the transceiver, a Warning Message, corresponding to the item selected, appears. Click [OK] to continue writing the data.
- (3) Tools > Test/Tuning, then adjust the various adjustment data (PC Test Mode) as described in the “SECTION 4 ADJUSTMENT”.
- (4) Attach the new labels corresponding to the new printed circuit board. (Refer to the images below for label placement.)
- (5) If necessary, write the FPU data used by the customer with the KPG-D3/D3N.

Note:

- When using the ESN Validation function of NXDN Trunking, the NXDN ESN number changes when the circuit board is changed (the number is written on the circuit board); the NXDN Trunking System cannot be accessed.
Use the KPG-110SM on the NXDN Trunking System side to reprogram the NXDN ESN number.

- When a new printed circuit board is used, the KENWOOD ESN changes, as does the Transceiver Information display of the KPG-D3/D3N, but this does not have any effect on the operation of the transceiver.
- If changing to the original ESN, please contact our service center.
- KPG-D3N can't be used for E type.

■ESN Label Layout



ESN Label

- NX-3720H(G)[K], NX-3720(G)[E], NX-3720[E], NX-3820H(G)[K], NX-3820H[K], NX-3820H(G)[K2], NX-3820(G)[E], NX-3820[E]



- NX-3720H[K], NX-3820H[K2]



Note:
Cut a ESN Label at dotted line.

5.5 Operating Method of Enforced Firmware Overwriting Mode

Enforced firmware overwriting mode is a mode to forcibly overwrite the transceiver firmware when the operations as instructed in Section 2.2.2 "How to Enter Each Mode" does not allow the transceiver to enter the firmware programming mode, for instance, when the transceiver fails to start up due to the transceiver failure.

(1) Prepare the followings:


- Transceiver (NX-3720, NX-3720H, NX-3820 or NX-3820H)
- Regulated DC power supply
- Programming interface cable (KPG-46U or KPG-46X)
- Power cable

(2) Remove the cabinet, top packing and shielding plate of the transceiver.

Connect a transceiver, regulated DC power supply, programming interface cable (KPG-46U or KPG-46X) and power cable.



(3) While FLDM terminal has a short-circuit with GND terminal on the PCB, turn its power ON.




Left: FLDM terminal
Right: GND terminal

- (4) Upon startup of FLDM loader, "FIRMWARE PROG" appears on an LCD screen.
- (5) Start KFL up, select the desired firmware you wish to overwrite, select the COM port number and baud rate, and then click the "Write" button.

Note:

Configuring "Auto" for baud rate automatically apply the maximal speed of baud rate allowed for a programming cable connected to the selected COM port number.

Upon start of overwriting on the transceiver, "LOADING" appears on an LCD screen.



- (6) Upon completion of the firmware overwriting, "CHECKSUM xxxx" appears on an LCD screen.


PRECAUTIONS ON SCHEMATIC DIAGRAMS

- * Due to the improvement in performance, some part numbers shown in the circuit diagrams may not agree with those indicated in the Parts List.
- * The parts numbers, values and rated voltage etc. in the Schematic Diagrams are for reference only.
- * Since the circuit diagrams are standard ones, the circuits and circuit constants may be subject to change for improvement without any notice.
- * The parts of the symbol with " * " may vary depending on model. Refer to the parts list for details.
- * The parts of the symbol with " \$ " are unmounted parts.

PRINTED CIRCUIT BOARD


■ TX-RX UNIT (XC1-182K-00 (NX-3720H(G), NX-3720H, NX-3720(G), NX-3720))

--- Component side view (J7C-0192-00) ---




■ TX-RX UNIT (XC1-182K-00 (NX-3720H(G), NX-3720H, NX-3720(G), NX-3720))

--- Foil side view (J7C-0192-00) ---




■ TX-RX UNIT (XC1-183K-00 (NX-3820H(G), NX-3820H, NX-3820(G), NX-3820))

--- Component side view (J7C-0193-00) ---




■ TX-RX UNIT (XC1-183K-00 (NX-3820H(G), NX-3820H, NX-3820(G), NX-3820))

--- Foil side view (J7C-0193-00) ---




■ SUB UNIT (XC3-050M-00)

--- Component side view (J7C-0194-00) ---



--- Foil side view (J7C-0194-00) ---



● ADDRESS TABLE OF BOARD PARTS
Each address may have an address error by one interval.





REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	
IC		R28	A- 4A	C22	B- 3B	
IC1	B- 1B	R29	A- 1B	C24	A- 3A	
IC3	B- 1A	R30	A- 1B	C25	A- 4A	
IC4	B- 1B	R31	A- 4B	C26	A- 1B	
IC5	B- 1A	R32	A- 3A	C28	B- 1B	
IC6	B- 2B	R33	A- 3A	C30	B- 1B	
		R36	B- 1B	C33	B- 1A	
TRANSISTOR						
Q1	B- 2B	R37	B- 1B	C34	B- 1B	
Q2	A- 1B	R38	B- 1B	C35	B- 1A	
Q3	B- 1B	R39	B- 1B	C36	B- 2A	
Q4	B- 1B	R40	B- 1B	C37	B- 2A	
Q6	B- 1B	R41	B- 1B	C38	B- 2A	
Q8	A- 3A	R42	B- 1B	C39	B- 1B	
		R43	B- 1A	C40	B- 1A	
DIODE						
D1	B- 3B	R44	B- 1B	C41	B- 1A	
D2	B- 3B	R45	B- 1B	C45	B- 1B	
D3	A- 4B	R46	B- 2B	C46	B- 1B	
D4	A- 4A	R47	B- 1A	C47	B- 3A	
D5	A- 4A	R48	B- 1B	C49	B- 2A	
D6	A- 2A	R49	B- 1A	C50	B- 2A	
D9	A- 1A	R50	B- 1A	C51	B- 2A	
D10	A- 4A	R51	B- 1A	C52	B- 2A	
D11	A- 3A	R56	B- 1A	C53	B- 2A	
D12	A- 2A	R57	B- 1A	C54	B- 2A	
D15	A- 1B	R58	B- 1A	C55	B- 2A	
D16	A- 4B	R60	B- 1B	C56	B- 2A	
D17	A- 3A	R61	B- 1A	C57	B- 2A	
D18	A- 3A	R62	B- 1A	C58	B- 2A	
D20	A- 1B	R63	B- 1B	C59	B- 1A	
D21	B- 1A	R64	B- 2B	C61	B- 3A	
D22	B- 1A	R66	B- 2A	C62	B- 3A	
D24	B- 1A	R67	B- 2A	C64	B- 3A	
D26	B- 1A	R68	B- 2A	C65	A- 3A	
D27	B- 1A	R69	B- 2A	C66	B- 3A	
D28	B- 1A	R70	B- 2A	C67	B- 3B	
D30	B- 1A	R71	B- 2A	C68	B- 3A	
D32	B- 1A	R72	B- 2A	C70	B- 1A	
D33	A- 1B	R73	B- 2A	C71	B- 1A	
D34	A- 1A	R74	B- 2A	C72	B- 1A	
		R75	B- 2A	C73	B- 1A	
		R77	A- 3A			
		R79	B- 2B	OTHER		
		R80	B- 2B	CN3	B- 2A	
R1	B- 3B	R81	B- 2A	CN5	B- 2A	
R2	B- 3B	R82	B- 1A	CN6	B- 3A	
R4	B- 3B	R83	B- 1A	CN7	B- 3B	
R5	B- 3B	R84	B- 1A			
R6	B- 3B	R85	B- 2B	J1	A- 1A	
R7	B- 3B	R86	B- 2B			
R8	A- 4B	R87	B- 3B	L1	B- 2B	
R9	A- 4A			L2	B- 3B	
R10	A- 4A	CAPACITOR			L3	B- 2B
R11	A- 2A	C1	B- 3A	L6	B- 2A	
R12	A- 1B	C2	B- 2B	L8	B- 3A	
R13	A- 1A	C3	B- 2B	L9	B- 2B	
R14	B- 3B	C6	B- 2B	L10	B- 3A	
R15	B- 3B	C7	B- 2B	L11	B- 1B	
R16	B- 1A	C8	B- 2B	L12	B- 1A	
R17	B- 1A	C9	B- 3B	L13	B- 1A	
R18	B- 3A	C11	B- 3B	L14	B- 1A	
R19	B- 3B	C12	B- 3B			
R20	B- 3A	C13	B- 2B			
R21	B- 3B	C14	B- 2B			
R22	A- 1B	C15	B- 3B			
R23	A- 4A	C16	B- 3B			
R24	A- 3A	C17	B- 3B			
R25	A- 2A	C20	B- 3B			
R27	A- 3A	C21	B- 3B			

■ MODULE (BT/GPS) UNIT (XC2-0040-10 (NX-3720H(G), NX-3720(G), NX-3820H(G), NX-3820(G)))

--- Component side view (J7C-0037-10) ---

--- Foil side view (J7C-0037-10) ---



1

2

3

3

2

1


● ADDRESS TABLE OF BOARD PARTS

Each address may have an address error by one interval.



REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION
IC		R7	B-3A	CAPACITOR	C21	A-2B	C45	B-3B			
IC1	B-2A	R8	B-3B	C1	B-3B	C22	A-2B	C46	B-2A	CP1	B-3B
IC2	B-3B	R9	A-1B	C2	B-3B	C23	B-1B	C47	B-2A	CP2	B-2B
IC3	B-3A	R10	A-1B	C3	B-3A	C24	B-1B	C48	B-3B		
IC4	B-3A	R11	B-3A	C4	A-1B	C25	B-1B	C49	B-2B	E1	A-2B
IC5	A-2B	R12	A-1B	C5	B-3A	C26	B-1B	C50	B-2B		
IC6	B-3B	R13	A-1B	C6	B-3A	C27	B-1B	C68	A-2A	L1	B-3B
IC7	B-3B	R14	B-3A	C7	B-3A	C28	A-2B			L2	B-3A
		R15	B-1B	C8	A-1B	C29	B-1B			L3	B-3A
TRANSISTOR		R16	B-1B	C9	A-1B	C30	A-2B	X1	A-1B	L4	A-1B
Q1	A-1B	R18	A-2B	C10	A-1B	C31	A-2B	X2	A-2B	L5	A-1B
		R19	B-1B	C11	A-2B	C32	A-2B			L6	B-1A
DIODE		R21	A-2B	C12	A-1B	C33	A-2B	CN1	B-3B	L7	A-2B
D17	B-1B	R22	B-3A	C13	A-1B	C34	A-2B	CN2	B-2B	L8	A-2B
D18	B-1B	R23	B-1B	C14	A-1B	C35	A-2B	CN3	B-2B	L9	A-1B
		R24	B-1A	C15	A-1B	C36	A-2B	CN4	A-2B	L11	A-2B
RESISTOR		R25	B-2A	C16	A-2B	C37	A-2B	CN5	B-1A	L13	B-3B
R1	B-3A	R26	A-1B	C17	A-1B	C38	A-1B	CN6	A-1A	L14	B-3B
R2	B-2A	R27	B-2A	C18	A-1B	C39	A-2B	CN7	B-2A	L15	A-2A
R3	B-3A	R29	B-2B	C19	A-1B	C40	B-1A	CN8	B-1B		
R4	B-3A			C20	A-2B	C44	B-3B	CN9	B-2B		


INTERCONNECTION DIAGRAM



LEVEL DIAGRAM


■ NX-3720/3720H

Receiver Section



To make measurements in the AF section, connect the AC level meter.
 (ANT input: -53dBm, 1kHz FM, 3kHz DEV (Wide). SP output: 4W@4ohm Load)
 In the RF section, use 1000pF coupling capacitor.
 (The display shows the SSG input value required to obtain 12dB SINAD.)


Transmitter Section



* Transmit frequency : 155MHz


■ NX-3820/3820H

Receiver Section



To make measurements in the AF section, connect the AC level meter.
 (ANT input: -53dBm, 1kHz FM, 3kHz DEV (Wide). SP output: 4W@4ohm Load)
 In the RF section, use 470pF coupling capacitor.
 (The display shows the SSG input value required to obtain 12dB SINAD.)


Transmitter Section




* Transmit frequency : 435MHz (K2,E), 485MHz (K)

SCHEMATIC DIAGRAM

SUB UNIT (XC3-050M-00)




MODULE (BT/GPS) UNIT (XC2-0040-10 (NX-3720H(G), NX-3720(G), NX-3820H(G), NX-3820(G)))



SCHEMATIC DIAGRAM


■ TX-RX UNIT (XC1-182K-00 (NX-3720H(G), NX-3720H, NX-3720(G), NX-3720))



Destination

PWR	R1	R2	R3	R4

TX-RX UNIT (XC1-183K-00 (NX-3820H(G), NX-3820H, NX-3820(G), NX-3820))




Destination

R1	R2	R3	R4
F1	F2		


BLOCK DIAGRAM

■ TX-RX UNIT (NX-3720H(G), NX-3720H, NX-3720(G), NX-3720)

TX-RX Unit (XC1-182)




TX-RX UNIT (NX-3820H(G), NX-3820H, NX-3820(G), NX-3820)



TX-RX UNIT
XC1-183

Sub (Display) Unit (XC3-050)



10
9
8
7
6
5
4
3
2
1

A B C D E F G H I J K L M N O P Q

MEMO

PARTS LIST

[NX-3720H(G), NX-3720H, NX-3720(G), NX-3720,
NX-3820H(G), NX-3820H, NX-3820(G), NX-3820]

* SAFETY PRECAUTION

Parts identified by the \triangle symbol are critical for safety. Replace only with specified part numbers.

* BEWARE OF BOGUS PARTS

Parts that do not meet specifications may cause trouble in regard to safety and performance. We recommend that genuine parts be used.


* (x_) in a description column shows the number of the used part.

- Contents -

Exploded view of general assembly and parts list	3-2
Electrical parts list	3-4
Packing materials and accessories parts list	3-21

Exploded view of general assembly and parts list

Block No.M1MM



General assembly

Block No. [M][1][M][M]

△ Symbol No.	Part No.	Part Name	Description	Local
1	A0C-0166-00	PLASTIC CABINET		
3	A6C-0067-10	PANEL ASSY		
4	B4D-0044-00	KENWOOD BADGE	PANEL	
5	B09-0732-03	CAP	DSUB	
6	B1B-0101-00	ILL.GUIDE	LCD	
7	B1B-0102-00	OPTI.DIFFUSER	UPPER ILL-GUIDE	
8	B1B-0103-00	REF.SHEET	LOWER ILL-GUIDE	
9	B3H-0058-00	LCD ASSY	304X100 DOT	
10	E04-0454-15	C.RECEPTACLE-BN	ANT BNC	3720E,3720GE,3820E,3820GE
10	E04-0167-15	C.RECEPTACLE-M	ANT M	3720HGK,3720HK,3820HGK,3820HGK2,3820HK,3820HK2
11	E30-7684-35	DC CORD	RADIO	
12	E3A-0390-00	CORD W.CON.	SP	
13	E3G-0042-00	FFC WIRE	60P	
14	F10-3112-13	SHIELDING CASE	PM	
15	F1A-0027-00	SHIELDING PLATE	TOP	
16	F1B-0086-00	SHIELDING COVER	BLS(DCDC,VCO)(x2)	
17	F1E-0040-00	SHADE	TX-BUSY	
19	G11-4578-04	SHEET	W/O GPS	3720E,3720HK,3820E,3820HK,3820HK2
20	G11-4611-04	SHEET	DSUB	
21	G13-1837-04	CUSHION	TOP SHIELD	
22	G13-2101-14	CONDUCT CUSHION	PM	
23	G1D-0191-00	CUSHION	LCD	
24	G53-1643-04	PACKING	DC CORD	
25	G53-1675-04	PACKING	ANT BNC	3720E,3720GE,3820E,3820GE
25	G53-1662-04	PACKING	ANT M	3720HGK,3720HK,3820HGK,3820HGK2,3820HK,3820HK2
26	G53-1820-03	PACKING	FRONT	
27	G5D-0117-00	PACKING	TOP	
28	G5D-0127-00	PACKING	SP	
29	J1K-0456-00	HOLDER	DISP PCB	
30	J2B-0341-00	MOUNTING	LCD	
31	K2K-0242-00	KEY TOP		
32	T07-0757-35	SPEAKER	60HM/5.5W/7W	
33	W09-0971-05	LITHIUM CELL		
34	B09-0754-05	CAP	SMA	3720GE,3720HGK,3820GE,3820HGK,3820HGK2
35	E0E-0003-00	C.RECEPTACLE-SM	SMA	3720GE,3720HGK,3820GE,3820HGK,3820HGK2
36	E3F-0017-10	FLAT CABLE	20P BT/GPS	3720GE,3720HGK,3820GE,3820HGK,3820HGK2
37	F10-3225-05	SHIELDING COVER	BLS(BT/GPS)	3720GE,3720HGK,3820GE,3820HGK,3820HGK2
38	G53-1768-04	PACKING	SMA	3720GE,3720HGK,3820GE,3820HGK,3820HGK2
41	J8C-0018-00	FLEX P.BOARD	KEY	
42	B41-1837-04	CAUTION STICKER	HOT SURFACE	
43	B4B-0008-00	CAUTION STICKER	FCC(PANEL)	3720HGK,3720HK,3820HGK,3820HGK2,3820HK,3820HK2
44	G0B-0104-00	EARTH SPRING	PANEL HOLDER	
A	N67-3010-48	P.H.SEMS SCREW	PM,AMP,DC(GND)(x5)	
B	N87-2608-48	BR.HEAD T.SCREW	PCB,ANT,SMA(x17)	3720E,3720HK,3820E,3820HK,3820HK2
B	N87-2608-48	BR.HEAD T.SCREW	PCB,ANT,SMA(x19)	3720GE,3720HGK,3820GE,3820HGK,3820HGK2
C	N83-2005-48	P.HEAD T.SCREW	BT/GPS(x3)	3720GE,3720HGK,3820GE,3820HGK,3820HGK2
-	XC3-050M-00	SUB UNIT	DISPLAY	
-	XC2-0040-10	MODULE UNIT	BT/GPS	3720GE,3720HGK,3820GE,3820HGK,3820HGK2
-	XCA-033K-00	TX-RX UNIT	SERVICE UNIT	3720HGK,3720HK
-	XCA-033E-01	TX-RX UNIT	SERVICE UNIT	3720E,3720GE
-	XCA-034E-01	TX-RX UNIT	SERVICE UNIT	3820E,3820GE
-	XCA-034K-00	TX-RX UNIT	SERVICE UNIT	3820HGK,3820HK
-	XCA-034K-01	TX-RX UNIT	SERVICE UNIT	3820HGK2,3820HK2

Electrical parts list

TX-RX UNIT

**XC1-182K-00 (NX-3720E,NX-3720GE,
NX-3720HGK,NX-3720HK)**

***Note : This part cannot be replaced. Therefore,
this part is not supplied as a service part.**

Block No. [0][1]

△ Symbol No.	Part No.	Part Name	Description	Local
IC1	BA00DD0WHFP	IC		
IC12	LXDC2HN18F163	IC		
IC13	BU31TD2WNVX	IC		
IC14	TPS61041DRVR	IC		
IC15	XC6215B122N-G	IC		
IC16	XC6209B502P-G	IC		
IC17	NJM2878F4-32	IC		
IC18	XC61CN5002N-G	IC		
IC19	XC6223D321G-G	IC		
IC20	XC6223D321P-G	IC		
IC21	XC8102AA07-G	IC		
IC22	MSP430G2533P0	IC		
IC23	XC6221D501G-G	IC		
IC24	LXDC2XQ12A-252	IC		
IC25	MP2560DQ-LF-Z	IC		
IC26	XC6221D501G-G	IC		
IC101	NJM2904CRB1	IC		
IC202	BGU6104	IC		
IC203	BA3472FVM	IC		
IC205	AD8315ARM	IC		
IC301	NJG1608KB2	IC		
IC302	AK2401	IC		
IC401	-----	IC	*Note	
IC402	-----	IC	*Note	
IC403	TC7SZ08FE	IC		
IC404	-----	IC	*Note	
IC405	BD11600NUX	IC		
IC406	BD11600NUX	IC		
IC407	TC7SET125FUF	IC		
IC408	TC7SZ08FE	IC		
IC409	TCA9555RTWR	IC		
IC410	ADS7961SRHB	IC		
IC411	DAC124S085CIS	IC		
IC412	R2A20178NP	IC		
IC413	XC61CN5002N-G	IC		
IC414	BU7462NUX	IC		
IC602	TC7WT126FU-F	IC		
IC603	TC7WH126FK	IC		
IC604	TCA9555RTWR	IC		
IC605	ADM3202ARUZ	IC		
IC606	TC7SET125FUF	IC		
IC607	TLV32AIC3104I	IC		
IC608	BU7462NUX	IC		
IC609	XC6221D501G-G	IC		
Q11	LTC014EEBFS8	DIGI TRANSISTOR		
Q12	TPCP8107-F	FET		
Q13	LTC014EEBFS8	DIGI TRANSISTOR		
Q14	LTC014TEBFS8	DIGI TRANSISTOR		
Q15	LSCR523EBFS8	TRANSISTOR		
Q16	LSAR523UBFS8	TRANSISTOR		
Q17	TPCP8107-F	FET		
Q18	LTC014EEBFS8	DIGI TRANSISTOR		
Q19	VT6M1	FET		
Q20	SSM3J334R	FET		
Q21	LTC014EEBFS8	DIGI TRANSISTOR		
Q22	SSM3J334R	FET		
Q23	LTC014EEBFS8	DIGI TRANSISTOR		
Q25	EMD9	DIGI TRANSISTOR		
Q103	EM6M2	FET		
Q104	2SD2654/W/	TRANSISTOR		
Q105	MCH3914-H/8/	FET		
Q106	2SC5108FT/Y/	TRANSISTOR		
Q107	2SC5108FT/Y/	TRANSISTOR		
Q201	RFM01U7PF	FET		
Q202	LSCR523EBFS8	TRANSISTOR		

△ Symbol No.	Part No.	Part Name	Description	Local
Q204	LSCR523EBFS8	TRANSISTOR		
Q205	EMD9	DIGI TRANSISTOR		
Q206	VT6M1	FET		
Q301	SSM3K15AMFV	FET		
Q401	2SC4617/S/	TRANSISTOR		
Q402	SSM3K15AMFV	FET		
Q403	SSM3K15AMFV	FET		
Q404	LTC014TEBFS8	DIGI TRANSISTOR		
Q601	SSM6N15AFEM	DUAL FET		
Q602	LTC014TEBFS8	DIGI TRANSISTOR		
Q603	TPCP8107-F	FET		
Q604	LTC014TEBFS8	DIGI TRANSISTOR		
Q605	SSM6N15AFEM	DUAL FET		
Q606	SSM3J334R	FET		
D1	ST70-27F-572	ZENER DIODE		
D13	EDZV5.6B	ZENER DIODE		
D14	RB521CM-30	DIODE		
D15	1SS400SM	DIODE		
D16	RB060M-40	DIODE		
D17	RB561VM-40	SCHOTTKY DIODE		
D18	RB521CM-30	DIODE		
D19	RB521CM-30	DIODE		
D20	EDZV18B	ZENER DIODE		
D21	RB520SM-30	DIODE		
D22	EDZV8.2B	ZENER DIODE		
D24	RB520SM-30	DIODE		
D26	RB521CM-30	DIODE		
D27	RB521CM-30	DIODE		
D101	EDZV8.2B	ZENER DIODE		
D102	SMV1270-079LF	VARI CAP DIODE		
D103	1SV282-F	VARI CAP DIODE		
D104	1SV282-F	VARI CAP DIODE		
D105	1SV282-F	VARI CAP DIODE		
D106	1SV282-F	VARI CAP DIODE		
D107	1SS400SM	DIODE		
D108	SMV1130-079LF	VARI CAP DIODE		
D201	EDZV5.6B	ZENER DIODE		
D202	RN142S	DIODE		
D204	RB706F-40	DIODE		
D205	L8104	DIODE		
D206	L8104	DIODE		
D207	L8104	DIODE		
D208	RN142S	DIODE		
D209	RN142S	DIODE		
D301	1SS390	DIODE		
D302	1SS390	DIODE		
D303	1SS400SM	DIODE		
D304	1SS400SM	DIODE		
D401	RB521CM-30	DIODE		
D402	SPC10501A01	VARISTOR		
D403	SPC10501A01	VARISTOR		
D404	SPC10501A01	VARISTOR		
D405	SPC10501A01	VARISTOR		
D406	SPC10501A01	VARISTOR		
D407	EDZV8.2B	ZENER DIODE		
D408	RB521CM-30	DIODE		
D409	RB521CM-30	DIODE		
D410	RB521CM-30	DIODE		
D601	EDZV5.6B	ZENER DIODE		
D602	RB521CM-30	DIODE		
D603	EDZV6.8B	ZENER DIODE		
D604	EDZV6.8B	ZENER DIODE		
D605	EDZV6.8B	ZENER DIODE		
D606	EDZV6.8B	ZENER DIODE		
D607	EDZV6.8B	ZENER DIODE		
D608	EDZV6.8B	ZENER DIODE		
D609	RB521CM-30	DIODE		
D610	RB521CM-30	DIODE		
D611	EDZV6.8B	ZENER DIODE		
D612	DA204U	MULTIPLE DIODE		
D613	DA204U	MULTIPLE DIODE		
D614	RB521CM-30	DIODE		
D615	RB521CM-30	DIODE		
D616	AVRM10270K101	VARISTOR		
D617	AVRM10270K101	VARISTOR		

△ Symbol No.	Part No.	Part Name	Description	Local
L19	LB73G0AK-001	CHIP FERRITE		
L107	LB73H0AV-003	CHIP FERRITE		
L108	L41-2785-53	CHIP INDUCTOR		
L109	LB73H0AV-003	CHIP FERRITE		
L110	L41-2785-53	CHIP INDUCTOR		
L111	L41-2785-53	CHIP INDUCTOR		
L112	L41-2785-53	CHIP INDUCTOR		
L113	L41-2785-53	CHIP INDUCTOR		
L115	L41-2785-53	CHIP INDUCTOR		
L116	L41-2785-53	CHIP INDUCTOR		
L117	LB73H0AY-004	CHIP FERRITE		
L118	LK73H0AM47NJ	M.CHIP INDUCTOR	47nH	
L119	LB73H0AY-004	CHIP FERRITE		
L121	LK73H0AM27NJ	M.CHIP INDUCTOR	27nH	
L123	LK73H0AM27NJ	M.CHIP INDUCTOR	27nH	
L124	LK73H0AM56NJ	M.CHIP INDUCTOR	56nH	
L207	LB73H0AY-004	CHIP FERRITE		
L208	LB73H0AY-004	CHIP FERRITE		
L209	LK73H0AM56NJ	M.CHIP INDUCTOR	56nH	
L210	L41-2785-53	CHIP INDUCTOR		
L211	LK73H0AM56NJ	M.CHIP INDUCTOR	56nH	
L212	LK73H0AM56NJ	M.CHIP INDUCTOR	56nH	
L213	LK73H0AM47NJ	M.CHIP INDUCTOR	47nH	
L214	L41-8275-53	CHIP INDUCTOR		
L215	LB73F0AW-002	CHIP FERRITE		
L217	LB73H0AV-003	CHIP FERRITE		
L218	LB73G0BA-004	CHIP FERRITE		
L219	LB73Z0DF-001	CHIP FERRITE		
L220	LB73Z0DF-001	CHIP FERRITE		
L221	LB73Z0DF-001	CHIP FERRITE		
L222	L41-2775-53	CHIP INDUCTOR		
L223	LR77Z0AAR27J	CHIP INDUCTOR	0.27uH	
L224	LR79Z0GJR56G	CHIP INDUCTOR		
L225	LB73H0AY-004	CHIP FERRITE		
L226	LB73H0AV-003	CHIP FERRITE		
L302	LK73H0AMR10J	M.CHIP INDUCTOR	0.1uH	
L303	LR79G0CQ56NG	CHIP INDUCTOR		
L304	LR79G0CQ47NG	CHIP INDUCTOR		
L305	LR79G0CQ82NG	CHIP INDUCTOR		
L306	LR79G0CQ8N2C	CHIP INDUCTOR		
L307	LR79G0CQR22G	CHIP INDUCTOR		
L308	LR79G0CQR12G	CHIP INDUCTOR		
L309	LR79G0CQ68NG	CHIP INDUCTOR	68nH	
L310	LR79G0CQ82NG	CHIP INDUCTOR		
L311	LR79G0CQR33G	CHIP INDUCTOR		
L312	LK73H0AMR10J	M.CHIP INDUCTOR	0.1uH	
L313	LR79G0CQ56NG	CHIP INDUCTOR		
L314	LK73H0AMR27J	M.CHIP INDUCTOR		
L315	LR79G0CQR10G	CHIP INDUCTOR		
L317	LK73H0AM33NJ	M.CHIP INDUCTOR	33nH	
L401	LB73G0AK-001	CHIP FERRITE		
L402	LB73H0AV-003	CHIP FERRITE		
L403	LB73G0AK-001	CHIP FERRITE		
L404	LR77Z0AE4R7J	CHIP INDUCTOR	4.7uH	
L405	LB73G0AM-004	CHIP FERRITE		
L406	L92-1101-05	CHIP FERRITE		
L407	L92-1101-05	CHIP FERRITE		
L408	L92-1101-05	CHIP FERRITE		
L409	L92-1101-05	CHIP FERRITE		
L410	LB73G0AK-001	CHIP FERRITE		
L411	LB73G0AK-001	CHIP FERRITE		
L412	LB73G0AK-001	CHIP FERRITE		
L413	LB73G0AK-001	CHIP FERRITE		
L414	LB73H0AV-002	CHIP FERRITE		
L415	L79-1984-05	FILTER		
L416	L79-1984-05	FILTER		
L417	LB73H0AY-002	CHIP FERRITE		
L418	LB73H0AY-002	CHIP FERRITE		
L419	L79-1984-05	FILTER		
L420	L92-1101-05	CHIP FERRITE		
L601	LB73H0AV-003	CHIP FERRITE		
L602	LB73H0AV-003	CHIP FERRITE		
L603	LB73H0AV-003	CHIP FERRITE		
CN1	EC720AA-0560A	FFC FPC CONNE		
CN2	E40-6862-05	F.C.CONNECTOR		
CN3	J19-5386-05	HOLDER		
CP301	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	

△ Symbol No.	Part No.	Part Name	Description	Local
CP302	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	
CP303	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	
CP401	RK74HB1J103J	NET RESISTOR	10kΩ 1/16W J	
CP402	RK74HB1J222J	NET RESISTOR	2.2kΩ 1/16W J	
CP403	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	
CP404	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	
CP405	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	
CP406	RK74HB1J101J	NET RESISTOR	100Ω 1/16W J	
CP407	RK74HB1J101J	NET RESISTOR	100Ω 1/16W J	
CP408	RK74HB1J101J	NET RESISTOR	100Ω 1/16W J	
CP409	RK74HB1J101J	NET RESISTOR	100Ω 1/16W J	
CP410	RK74HB1J101J	NET RESISTOR	100Ω 1/16W J	
CP411	RK74HB1J101J	NET RESISTOR	100Ω 1/16W J	
CP412	RK74HB1J470J	NET RESISTOR	47Ω 1/16W J	
CP413	RK74HB1J470J	NET RESISTOR	47Ω 1/16W J	
CP414	RK74HB1J470J	NET RESISTOR	47Ω 1/16W J	
CP601	RK74HB1J472J	NET RESISTOR	4.7kΩ 1/16W J	
CP602	RK74HB1J472J	NET RESISTOR	4.7kΩ 1/16W J	
CP604	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	
CP605	RK74HB1J101J	NET RESISTOR	100Ω 1/16W J	
E11	F1B-0085-00	SHIELDING CASE		
E101	F1B-0085-00	SHIELDING CASE		
F1	F53-0286-05	FUSE		
F2	F53-0286-05	FUSE		
F3	F53-0286-05	FUSE		
F4	FZA10BS-5R0	FUSE (CC)		
F5	FZA10BS-5R0	FUSE (CC)		
F6	F53-0286-05	FUSE		
IC201	RA60H1317A501	MOS IC		
IC601	LA4631VC-XE	ANALOG IC		
J1	E58-0567-05	SUB SOCKET D		
J2	E1B-0001-00	3.5D PHONE JACK		
TH201	NCU15WF104F6S	N THERMISTOR		
TH202	NCU15WF104F6S	N THERMISTOR		
TH203	NCU15WF104F6S	N THERMISTOR		
TH401	NCU15WF104F6S	N THERMISTOR		
X401	L7H-0076-00	TCXO		
X402	L77-1802-05	QUARTZ CRYSTAL		

TX-RX UNIT

**XC1-183K-01 (NX-3820E,NX-3820GE,
NX-3820HGK2,NX-3820HK2)**

XC1-183K-00 (NX-3820HGK,NX-3820HK)

***Note : This part cannot be replaced. Therefore,
this part is not supplied as a service part.**

Block No. [0][2]


△ Symbol No.	Part No.	Part Name	Description	Local
IC1	BA00DD0WHFP	IC		
IC12	LXDC2HN18F163	IC		
IC13	BU31TD2WNVX	IC		
IC14	TPS61041DRVR	IC		
IC15	XC6215B122N-G	IC		
IC16	XC6209B502P-G	IC		
IC17	NJM2878F4-32	IC		
IC18	XC61CN5002N-G	IC		
IC19	XC6223D321G-G	IC		
IC20	XC6223D321P-G	IC		
IC21	XC8102AA07-G	IC		
IC22	MSP430G2533P0	IC		
IC23	XC6221D501G-G	IC		
IC24	LXDC2XQ12A-252	IC		
IC25	MP2560DQ-LF-Z	IC		
IC26	XC6221D501G-G	IC		
IC101	NJM2904CRB1	IC		
IC202	BGU6104	IC		
IC203	BA3472FVM	IC		
IC205	AD8315ARM	IC		
IC301	NJG1608KB2	IC		
IC302	AK2401	IC		

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
IC401	-----	IC	*Note		D105	1SV282-F	VARI CAP DIODE		
IC402	-----	IC	*Note		D106	1SV282-F	VARI CAP DIODE		
IC403	TC7SZ08FE	IC			D107	1SS400SM	DIODE		
IC404	-----	IC	*Note		D108	SMV1130-079LF	VARI CAP DIODE		
IC405	BD11600NUX	IC			D201	EDZV5.6B	ZENER DIODE		
IC406	BD11600NUX	IC			D202	RN142S	DIODE		
IC407	TC7SET125FUF	IC			D204	RB706F-40	DIODE		
IC408	TC7SZ08FE	IC			D205	L8104	DIODE		
IC409	TCA9555RTWR	IC			D206	L8104	DIODE		
IC410	ADS7961SRHB	IC			D207	L8104	DIODE		
IC411	DAC124S085CIS	IC			D208	RN142S	DIODE		
IC412	R2A20178NP	IC			D209	RN142S	DIODE		
IC413	XC61CN5002N-G	IC			D301	1SS390	DIODE		
IC414	BU7462NUX	IC			D302	1SS390	DIODE		
IC602	TC7WT126FU-F	IC			D303	1SS400SM	DIODE		
IC603	TC7WH126FK	IC			D304	1SS400SM	DIODE		
IC604	TCA9555RTWR	IC			D401	RB521CM-30	DIODE		
IC605	ADM3202ARUZ	IC			D402	SPC10501A01	VARISTOR		
IC606	TC7SET125FUF	IC			D403	SPC10501A01	VARISTOR		
IC607	TLV32AIC3104I	IC			D404	SPC10501A01	VARISTOR		
IC608	BU7462NUX	IC			D405	SPC10501A01	VARISTOR		
IC609	XC6221D501G-G	IC			D406	SPC10501A01	VARISTOR		
Q11	LTC014EEBFS8	DIGI TRANSISTOR			D407	EDZV8.2B	ZENER DIODE		
Q12	TPCP8107-F	FET			D408	RB521CM-30	DIODE		
Q13	LTC014EEBFS8	DIGI TRANSISTOR			D409	RB521CM-30	DIODE		
Q14	LTC014TEBFS8	DIGI TRANSISTOR			D410	RB521CM-30	DIODE		
Q15	LSCR523EBFS8	TRANSISTOR			D601	EDZV5.6B	ZENER DIODE		
Q16	LSAR523UBFS8	TRANSISTOR			D602	RB521CM-30	DIODE		
Q17	TPCP8107-F	FET			D603	EDZV6.8B	ZENER DIODE		
Q18	LTC014EEBFS8	DIGI TRANSISTOR			D604	EDZV6.8B	ZENER DIODE		
Q19	VT6M1	FET			D605	EDZV6.8B	ZENER DIODE		
Q20	SSM3J334R	FET			D606	EDZV6.8B	ZENER DIODE		
Q21	LTC014EEBFS8	DIGI TRANSISTOR			D607	EDZV6.8B	ZENER DIODE		
Q22	SSM3J334R	FET			D608	EDZV6.8B	ZENER DIODE		
Q23	LTC014EEBFS8	DIGI TRANSISTOR			D609	RB521CM-30	DIODE		
Q25	EMD9	DIGI TRANSISTOR			D610	RB521CM-30	DIODE		
Q101	2SC5108FT/Y/	TRANSISTOR			D611	EDZV6.8B	ZENER DIODE		
Q102	2SC5108FT/Y/	TRANSISTOR			D612	DA204U	MULTIPLE DIODE		
Q103	EM6M2	FET			D613	DA204U	MULTIPLE DIODE		
Q104	2SD2654/W/	TRANSISTOR			D614	RB521CM-30	DIODE		
Q105	MCH3914-H/8/	FET			D615	RB521CM-30	DIODE		
Q106	2SC5108FT/Y/	TRANSISTOR			D616	AVRM10270K101	VARISTOR		
Q201	RFM01U7PF	FET			D617	AVRM10270K101	VARISTOR		
Q202	LSCR523EBFS8	TRANSISTOR			D618	RB520SM-30	DIODE		
Q204	LSCR523EBFS8	TRANSISTOR			D619	RB521CM-30	DIODE		
Q205	EMD9	DIGI TRANSISTOR			C1	CE32EJ1E102M	E CAPACITOR	1000uF 25V M	
Q206	VT6M1	FET			C2	C92-0906-05	E CAPACITOR	330uF 10V	
Q301	SSM3K15AMFV	FET			C3	C92-0906-05	E CAPACITOR	330uF 10V	
Q401	2SC4617/S/	TRANSISTOR			C4	CE32BY1E470M	E CAPACITOR	47uF 25V M	
Q402	SSM3K15AMFV	FET			C5	C92-0968-05	E CAPACITOR	470uF 25V	
Q403	SSM3K15AMFV	FET			C11	CK73HB1E104K	C CAPACITOR	0.10uF 25V K	
Q404	LTC014TEBFS8	DIGI TRANSISTOR			C12	CK73HBB1H102K	C CAPACITOR	1000pF 50V K	
Q601	SSM6N15AFEM	DUAL FET			C14	CK73FB1C106K	C CAPACITOR	10uF 16V K	
Q602	LTC014TEBFS8	DIGI TRANSISTOR			C15	CK73HB1E104K	C CAPACITOR	0.10uF 25V K	
Q603	TPCP8107-F	FET			C16	C93-1959-05	C CAPACITOR	0.1uF 16V	
Q604	LTC014TEBFS8	DIGI TRANSISTOR			C17	CK73HB1A474K	C CAPACITOR	0.47uF 10V K	
Q605	SSM6N15AFEM	DUAL FET			C18	CK73HB1C105K	C CAPACITOR	1.0uF 16V K	
Q606	SSM3J334R	FET			C19	CK73HB1H103K	C CAPACITOR	10000pF 50V K	
D1	ST70-27F-572	ZENER DIODE			C20	CK73HBB1H471K	C CAPACITOR	470pF 50V K	
D13	EDZV5.6B	ZENER DIODE			C21	CK73HBB1H471K	C CAPACITOR	470pF 50V K	
D14	RB521CM-30	DIODE			C22	CK73HBB1H471K	C CAPACITOR	470pF 50V K	
D15	1SS400SM	DIODE			C24	CK73HB1C105K	C CAPACITOR	1.0uF 16V K	
D16	RB060M-40	DIODE			C25	CK73HBB1H102K	C CAPACITOR	1000pF 50V K	
D17	RB561VM-40	SCHOTTKY DIODE			C26	CC73HCH1H101J	C CAPACITOR	100pF 50V J	
D18	RB521CM-30	DIODE			C27	CK73HBB1H102K	C CAPACITOR	1000pF 50V K	
D19	RB521CM-30	DIODE			C28	CK73GB1H105K	C CAPACITOR	1uF 50V K	
D20	EDZV18B	ZENER DIODE			C29	CK73HBB1H222K	C CAPACITOR	2200pF 50V K	
D21	RB520SM-30	DIODE			C30	CK73EB1H475KM	C CAPACITOR	4.7uF 50V M	
D22	EDZV8.2B	ZENER DIODE			C31	CK73HB1C105K	C CAPACITOR	1.0uF 16V K	
D24	RB520SM-30	DIODE			C32	CK73EB1H475KM	C CAPACITOR	4.7uF 50V M	
D26	RB521CM-30	DIODE			C33	CK73GB1H105K	C CAPACITOR	1uF 50V K	
D27	RB521CM-30	DIODE			C34	CK73EB1H475KM	C CAPACITOR	4.7uF 50V M	
D101	EDZV8.2B	ZENER DIODE			C35	CK73HB1E104K	C CAPACITOR	0.10uF 25V K	
D102	SMV1270-079LF	VARI CAP DIODE			C36	CK73HBB1H471K	C CAPACITOR	470pF 50V K	
D103	1SV282-F	VARI CAP DIODE			C37	CK73GB1H105K	C CAPACITOR	1uF 50V K	
D104	1SV282-F	VARI CAP DIODE			C38	CK73FB1C106K	C CAPACITOR	10uF 16V K	
					C39	CK73HBB1H471K	C CAPACITOR	470pF 50V K	

Symbol No.	Part No.	Part Name	Description	Local
R24	RK73HB1J000J	MG RESISTOR	0Ω 1/16W J	
R25	RK73HB1J103J	MG RESISTOR	10kΩ 1/16W J	
R26	RK73HB1J000J	MG RESISTOR	0Ω 1/16W J	
R27	RK73HB1J000J	MG RESISTOR	0Ω 1/16W J	
R29	RK73HB1J000J	MG RESISTOR	0Ω 1/16W J	
L1	LB73H0AV-002	CHIP FERRITE		
L2	LB73G0AK-001	CHIP FERRITE		
L3	LB73G0BJ-002	CHIP FERRITE		
L4	L92-0487-05	CHIP FERRITE		
L5	L92-0487-05	CHIP FERRITE		
L6	LK73H0AG27NJ	M.CHIP INDUCTOR	27nH	
L7	LK73H0AM10NJ	M.CHIP INDUCTOR	10nH	
L8	L92-0487-05	CHIP FERRITE		
L9	L7K-0059-00	FILTER		
L11	L79-1987-05	FILTER		
L13	L92-0487-05	CHIP FERRITE		
L14	L92-0487-05	CHIP FERRITE		
L15	L40-2263-71	CHIP INDUCTOR		
CN1	E40-6879-05	F.C.CONNECTOR		
CN5	E0E-0012-00	RF C.RECEPTACLE		
CP1	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	
CP2	RK74HB1J100J	NET RESISTOR	10Ω 1/16W J	
E1	F10-3226-05	SHIELDING CASE		
X1	L77-3123-05	TCXO		
X2	L77-3121-05	QUARTZ CRYSTAL		

Packing materials and accessories parts list

Block No.M2MM



Packing and accessories

Block No. [M][2][M][M]

△ Symbol No.	Part No.	Part Name	Description	Local
1	H5A-0946-00	ITEM CARTON		
2	H1C-0152-00	PACKING FIXTURE	(x2)	
3	-----	PROTECTION BAG		
4	J19-1584-15	HOLDER	ACC	3720HGK,3720HK,3820HGK,3820HGK2,3820HK,3820HK2
5	J29-0726-03	BRACKET	ACC	
6	T91-0639-85	MICROPHONE	KMC-35	3720HGK,3720HK,3820HGK,3820HGK2,3820HK,3820HK2
7	B5A-1680-00	INST.MANUAL	9 LANGUAGES	3720E,3720GE,3820E,3820GE
7	B5A-1562-00	INST.MANUAL	3 LANGUAGES	3720HGK,3720HK,3820HGK,3820HGK2,3820HK,3820HK2
8	-----	PAMPHLET	DOC	3720E,3720GE,3820E,3820GE
9	E30-7523-65	DC CORD ASSY	ACC BLADE	
10	N99-2039-05	SCREW SET	ACC	
11	FZB10AU-150	BLADE FUSE	15A BLADE(ACC)(x2)	



KENWOOD

JVC KENWOOD Corporation
Communications Systems Division

(No.RA054<Rev.001>)

Printed in Japan
JKS