

UHF DIGITAL TRANSCEIVER


# NX-820H(G)/820H

## SERVICE MANUAL

# KENWOOD

JVC KENWOOD Corporation

© 2012-9 PRINTED IN JAPAN  
B53-7033-00 (Y) 672



## CONTENTS

GENERAL.....	2	TERMINAL FUNCTION .....	56
SYSTEM SET-UP .....	4	PC BOARD	
REALIGNMENT .....	4	DISPLAY UNIT (X54-3830-10) .....	60
INSTALLATION.....	7	TX-RX UNIT (X57-8240-1X).....	62
DISASSEMBLY FOR REPAIR .....	9	INTERCONNECTION DIAGRAM.....	66
CIRCUIT DESCRIPTION .....	11	SCHEMATIC DIAGRAM .....	67
COMPONENTS DESCRIPTION .....	17	BLOCK DIAGRAM.....	78
PARTS LIST .....	19	LEVEL DIAGRAM.....	81
EXPLODED VIEW .....	29	OPTIONAL ACCESSORIES	
PACKING .....	30	KRA-40.....	82
TROUBLE SHOOTING .....	31	SPECIFICATIONS.....	
ADJUSTMENT .....	35	BACK COVER	

# NX-820H(G)/820H

## Document Copyrights

Copyright 2012 by JVC KENWOOD Corporation. All rights reserved.

No part of this manual may be reproduced, translated, distributed, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, for any purpose without the prior written permission of JVC KENWOOD Corporation.

## Disclaimer

While every precaution has been taken in the preparation of this manual, JVC KENWOOD Corporation assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein. JVC KENWOOD Corporation reserves the right to make changes to any products herein at any time for improvement purposes.

## Firmware Copyrights

The title to and ownership of copyrights for firmware embedded in KENWOOD product memories are reserved for JVC KENWOOD Corporation. Any modifying, reverse engineering, copy, reproducing or disclosing on an Internet website of the firmware is strictly prohibited without prior written consent of JVC KENWOOD Corporation. Furthermore, any reselling, assigning or transferring of the firmware is also strictly prohibited without embedding the firmware in KENWOOD product memories.

Transceivers containing AMBE+2™ Vocoder:

The AMBE+2™ voice coding technology is embedded in the firmware under the license of Digital Voice Systems, Inc.

# GENERAL

## INTRODUCTION

### SCOPE OF THIS MANUAL

This manual is intended for use by experienced technicians familiar with similar types of commercial grade communications equipment. It contains all required service information for the equipment and is current as of the publication date. Changes which may occur after publication are covered by either Service Bulletins or Manual Revisions. These are issued as required.

## ORDERING REPLACEMENT PARTS

When ordering replacement parts or equipment information, the full part identification number should be included. This applies to all parts : components, kits, or chassis. If the part number is not known, include the chassis or kit number of which it is a part, and a sufficient description of the required component for proper identification.

## PERSONAL SAFETY

The following precautions are recommended for personal safety:

- DO NOT transmit if someone is within two feet (0.6 meter) of the antenna.
- DO NOT transmit until all RF connectors are secure and any open connectors are properly terminated.
- SHUT OFF this equipment when near electrical blasting caps or while in an explosive atmosphere.
- All equipment should be properly grounded before power-up for safe operation.
- This equipment should be serviced by only qualified technicians.

## PRE-INSTALLATION CONSIDERATIONS

### 1. UNPACKING

Unpack the radio from its shipping container and check for accessory items. If any item is missing, please contact KENWOOD immediately.

### 2. PRE-INSTALLATION CHECKOUT

#### 2-1. Introduction

Each radio is adjusted and tested before shipment. However, it is recommended that receiver and transmitter operation be checked for proper operation before installation.

#### 2-2. Testing

The radio should be tested complete with all cabling and accessories as they will be connected in the final installation. Transmitter frequency, deviation, and power output should be checked, as should receiver sensitivity, squelch operation, and audio output. Signalling equipment operation should be verified.

### 3. PLANNING THE INSTALLATION

#### 3-1. General

Inspect the vehicle and determine how and where the radio antenna and accessories will be mounted.

Plan cable runs for protection against pinching or crushing wiring, and radio installation to prevent overheating.

#### 3-2. Antenna

The favored location for an antenna is in the center of a large, flat conductive area, usually at the roof center. The trunk lid is preferred, bond the trunk lid and vehicle chassis using ground straps to ensure the lid is at chassis ground.

# NX-820H(G)/820H

## GENERAL

### 3-3. Radio

The universal mount bracket allows the radio to be mounted in a variety of ways. Be sure the mounting surface is adequate to support the radio's weight. Allow sufficient space around the radio for air cooling. Position the radio close enough to the vehicle operator to permit easy access to the controls when driving.

### 3-4. DC Power and wiring

1. This radio may be installed in negative ground electrical systems only. Reverse polarity will cause the cable fuse to blow. Check the vehicle ground polarity before installation to prevent wasted time and effort.
2. Connect the positive power lead directly to the vehicle battery positive terminal. Connecting the Positive lead to any other positive voltage source in the vehicle is not recommended.
3. Connect the ground lead directly to the battery negative terminal.
4. The cable provided with the radio is sufficient to handle the maximum radio current demand. If the cable must be extended, be sure the additional wire is sufficient for the current to be carried and length of the added lead.

## 4. INSTALLATION PLANNING – CONTROL STATIONS

### 4-1. Antenna system

Control station. The antenna system selection depends on many factors and is beyond the scope of this manual. Your KENWOOD dealer can help you select an antenna system that will best serve your particular needs.

### 4-2. Radio location


Select a convenient location for your control station radio which is as close as practical to the antenna cable entry point. Secondly, use your system's power supply (which supplies the voltage and current required for your system). Make sure sufficient air can flow around the radio and power supply to allow adequate cooling.

## SERVICE

This radio is designed for easy servicing. Refer to the schematic diagrams, printed circuit board views, and alignment procedures contained in this manual.


## NOTE

If you do not intend to use the speaker 3.5-mm jack and the D-sub 15-pin connector, fit the supplied speaker-jack cap and ACC cap to stop dust and sand from getting in.




# NX-820H(G)/820H

## SYSTEM SET-UP



## REALIGNMENT

### 1. Modes



Mode	Function
User mode	For normal use.
Panel test mode	Use by the dealer to check the fundamental characteristics.
Panel tuning mode	Used by the dealer to tune the transceiver.
PC mode	Used for communication between the transceiver and PC.
Data programming mode	Used to read and write frequency data and other features to and from the transceiver.
PC test mode	Used to check the transceiver using the PC. This feature is included in the FPU.
PC tuning mode	Used to tune the transceiver using the PC.
Firmware programming mode	Used when changing the main program of the flash memory.
Clone mode	Used to transfer programming data from one transceiver to another.
Firmware version information	Used to confirm the internal firmware version.

### 2. How to Enter Each Mode

Mode	Operation
User mode	Power ON
Panel test mode	[A]+Power ON
Panel tuning mode	Panel test mode+[s]
PC mode	Received commands from PC
Firmware programming mode	[Δ]+Power ON
Clone mode	[<B>]+Power ON (One second)
Firmware version information	[s]+Power ON

### 3. Panel Test Mode

Setting method refer to ADJUSTMENT.

### 4. Panel Tuning Mode

Setting method refer to ADJUSTMENT.

### 5. PC Mode

#### 5-1. Preface

The transceiver is programmed using a personal computer, a programming interface (KPG-46A/46U) and FPU (programming software).

The programming software can be used with a PC. Figure 1 shows the setup of a PC for programming.

# NX-820H(G)/820H

## REALIGNMENT

### 5-2. Connection procedure

1. Connect the transceiver to the computer using the interface cable.

#### Note:

- You must install the KPG-46U driver in the computer to use the USB programming interface cable (KPG-46U).

2. When the Power is switched on, user mode can be entered immediately. When the PC sends a command, the transceiver enters PC mode, and "PROGRAM" is displayed on the LCD.

When data is transmitting from the transceiver, the red LED blinks.

When data is receiving by the transceiver, the green LED blinks.

#### Note:

The data stored in the computer must match the "Model Name" when it is written into the EEPROM.

### 5-3. KPG-46A description

#### (PC programming interface cable: Option)

The KPG-46A is required to interface the transceiver to the computer. It has a circuit in its D-sub connector (KPG-46A: 9-pin) case that converts the RS-232C logic level to the TTL level.

The KPG-46A connects the 8-pin microphone connector of the transceiver to the RS-232C serial port of the computer.

### 5-4. KPG-46U description

#### (USB programming interface cable: Option)

The KPG-46U is a cable which connects to a USB port on a computer.

When using the KPG-46U, install the supplied CD-ROM (with driver software) in the computer. The KPG-46U driver runs under Windows XP, Vista or 7.

The latest version of the USB driver is available for download from the following URL:

<http://www.kenwood.com/usb-com/>

(This URL may change without notice.)

### 5-5. Programming Software : KPG-141D (ver.3.00 or later) description

The FPU is the programming software for the transceiver supplied on a CD-ROM. This software runs under Windows XP, Vista or 7 on a PC.

The data can be input to or read from the transceiver and edited on the screen. The programmed or edited data can be printed out. It is also possible to tune the transceiver.




Fig. 1

## 6. Firmware Programming Mode

### 6-1. Preface

Flash memory is mounted on the transceiver. This allows the transceiver to be upgraded when new features are released in the future. (For details on how to obtain the firmware, contact Customer Service.)

### 6-2. Connection procedure

Connect the transceiver to the personal computer using the interface cable (KPG-46A/46U). (Connection is the same as in the PC Mode.)

### 6-3. Programming

1. Start up the firmware programming software (Fpro.exe(ver. 6.1 or later)). The Fpro.exe exists in the KPG-141D installed holder.
2. Set the communications speed (normally, 115200 bps) and communications port in the configuration item.
3. Set the firmware to be updated by File name item.
4. Press and hold the [ $\Delta$ ] key while turning the transceiver power ON. Then, the orange LED on the transceiver lights and "FIRM PRG" is displayed.
5. Check the connection between the transceiver and the personal computer, and make sure that the transceiver is in the Program mode.
6. Press "write" button in the window. When the transceiver starts to receive data, the "LOADING" display lights.
7. If writing ends successfully, the checksum is calculated and a result is displayed.
8. If you want to continue programming other transceivers, repeat steps 4 to 7.

# NX-820H(G)/820H

## REALIGNMENT

### 6-4. Function

If you press the [ $\Delta$ ] key while "FIRM PRG" is displayed, the checksum is calculated, and a result is displayed. If you press the [ $\Delta$ ] key again while the checksum is displayed, "FIRM PRG" is redisplayed.

#### Note:

- This mode cannot be entered if the Firmware Programming mode is set to Disable in the Programming software.
- Normally, write in the high-speed mode.

## 7. Clone Mode

Programming data can be transferred from one transceiver to another by connecting them via their modular microphone jacks. The operation is as follows (the transmit transceiver is the source and the receive transceiver is a target).

#### Note :

Clone mode should be enabled.

1. Turn the source transceiver power ON with the [ $<B$ ] key held down (1 second), "CLONE MODE" is displayed on the LCD.
2. Power on the target transceiver.
3. Connect the cloning cable (No. E30-3382-05) to the modular microphone jacks on the source and target.
4. Press the [s] key on the source transceiver.  
The data of the source is sent to the target. While the source is sending data, red LED blinked. While the target is receiving the data, "PROGRAM" is displayed and green LED blinked. When cloning of data is completed, the source displays "END", and the source red LED turned off, and the target automatically operates in the User mode. The target can then be operated by the same program as the source.
5. The other target can be continuously cloned. Carry out the operation in step 2 to 4.

### 7-1. Adding the data password

If the read authorization password is set in the optional feature menu, you must enter the password (Source transceiver) to activate a clone mode.

You can use 0~9 to configure the password. The maximum length of the password is 6 digits.

1. [ $<B$ ]+Power ON.
2. "CLONE LOCK" is displayed on the LCD.
3. If the [ $\wedge$ ] and [ $\vee$ ] keys is pressed while "CLONE LOCK" is displayed, numbers (0 to 9) are displayed flashing. When you press the [s] key, the currently selected number is determined. If you press the [s] key after entering the password in this procedure, "CLONE MODE" is displayed if the entered password is correct. If the password is in-

correct, "CLONE LOCK" is redisplayed.





Fig. 2

### 7-2. Flow chart (Source transceiver)



## 8. Firmware Version Information

Press and hold the [s] key while turning the transceiver power ON and then keep pressing and holding the [s] key, the firmware version information appears on the LCD.

# NX-820H(G)/820H

## INSTALLATION


### 1. Connection Cable (KCT-60: Option)

The KCT-60 connection cable kit is used to connect the transceiver to a Horn alert cable, KCT-18 (Ignition sense cable), KES-5 (External speaker), or through the KCT-36 extension cable.

#### 1-1. Installing the KCT-60 (Connection cable) in the transceiver

1. Remove the ACC. cap on the rear of the transceiver.
2. Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
3. Connect the 15-pin connector of the KCT-60 to a Horn alert cable, KCT-18, KES-5, or through a KCT-36 extension cable.

**Note:** You must setup using the KPG-141D.



#### 1-2. Terminal function

D-sub 15-pin Pin No.	Function	Molex 15-pin Pin No.
1	SB	1
2	IGN	2
3	PA or EXT-SP	12
4	DO	4
5	DI	5
6	FNC1	9
7	FNC2	11
8	FNC3	7
9	FNC4	6
10	FNC5	8
11	FNC6	10
12	5C	-
13	HR1	13
14	HR2	14
15	GND	3


### 2. Horn Alert Function

The Horn alert function (max. 2A drive) is enabled by installing the KCT-60 in the transceiver.


#### 2-1. Installation Procedure

1. Remove the ACC. cap on the rear of the transceiver.
2. Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
3. Insert the two crimp terminals of the Horn alert cable to pins 13 and 14 of the square plug.
4. Connect the square plug to the 15-pin connector of the KCT-60.
5. Connect the remaining two Horn alert cables to your car Horn alert signal control.

The internal FET switch can be controlled by turning the HA function on/off and by using a signaling decode output. The maximum current of HA is 2A. This switch is the FETswitch of P-channel type. Therefore, a DC power supply is necessary to use the HR1. The voltage range is from 5V to 16V.




**Note:** You must set up using the KPG-141D.



#### 3. Ignition Sense Cable (KCT-18: Option)

The KCT-18 is an optional cable for enabling the ignition function. The ignition function lets you turn the transceiver power on and off with the car ignition key.

#### 3-1. Installing the KCT-18 (Ignition sense cable) in the transceiver



# NX-820H(G)/820H

## INSTALLATION

### 4. External Speaker (Option)

#### 4-1. KES-5

External speaker KES-5 can be installed for KCT-60.


##### ■ Connection procedure

1. Remove the ACC. cap on the rear of the transceiver.
2. Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
3. Insert the two crimp terminals of the KES-5 to pins 3 and 12 of the square plug.
4. Connect the square plug to the 15-pin connector of the KCT-60.

##### Note:

You must set up using the KPG-141D.

Before the external speaker can be used, you must assign one of the keys as "External Speaker", using the KPG-141D.



### 5. Changing Serial Port Level

#### 5-1. Change FNC1 (TXD) and FNC2 (RXD) of D-SUB 15-pin connector from TTL level to RS-232C level


FNC1 (TXD /6pin ) and FNC2 (RXD /7pin ) of D-SUB 15-pin connector are configured at the TTL level as the default value. But you can change these serial port level to RS-232C level through the RS-232C level converter IC (IC516) by configuring the port.

Remove the R664, R635 and R662 chip jumpers and solder the chip jumpers to R666, R633 and R665.

#### 5-2. Change FNC1 (TXD), FNC2 (RXD), FNC3 (RTS) and FNC4 (CTS) of D-SUB 15-pin connector from TTL level to RS-232C level

FNC1 (TXD /6pin ), FNC2 (RXD /7pin ), FNC3 (RTS /8pin ) and FNC4 (CTS /9pin ) of D-SUB 15-pin connector are configured at the TTL level as the default value. But you can change these serial port level to RS-232C level through the RS-232C level converter IC (IC516) by configuring the port.

Remove the R664, R635, R662, R659, R658 and R632 chip jumpers and solder the chip jumpers to R666, R633, R665, R663, R660 and R630.



##### ■ In the case of 5-1.

###### [TTL level]

R664, R635 and R662: 0Ω chip jumper.

R666, R633 and R665: open.

###### [RS-232C level]

R666, R633 and R665: 0Ω chip jumper.

R664, R635 and R662: open.

##### ■ In the case of 5-2.

###### [TTL level]

R664, R635, R662, R659, R658 and R632: 0Ω chip jumper.

R666, R633, R665, R663, R660 and R630: open.

###### [RS-232C level]

R666, R633, R665, R663, R660 and R630: 0Ω chip jumper.

R664, R635, R662, R659, R658 and R632: open.

### 6. Changing of Signal Type

#### 6-1. Change signal output of D-SUB connector from DEO to AFO

The output (4pin) of D-SUB 15-pin connector is configured at the DEO as the default value.

Remove the R796 chip jumper and solder the clip jumper to R798.

#### 6-2. Change signal input of D-SUB connector from DI to MI2

The input (5pin) of D-SUB 15-pin connector is configured at the DI as the default value.


Remove the R797 chip jumper and solder the clip jumper to R799.

# NX-820H(G)/820H

## DISASSEMBLY FOR REPAIR


### 1. Disassembly Procedure

1. Remove the cabinet, top packing and shielding plate of the transceiver.




2. To remove the panel assembly, first turn the transceiver upside down.


Then, insert a flat-head screwdriver into the holes of the chassis and tilt it in the direction as shown by the arrow.



3. Disconnect the flat cable from connector of the panel assembly.




4. Hook the finger to hole and while pulling the speaker holder to this side, expand the panel side of ① to ③, and remove the speaker holder from the front panel.



5. When removing the TX-RX PCB, first remove the top packing.

Then, remove the solder of the antenna hot pin and positive terminal of the DC cord.

Remove the 16 screws from the TX-RX PCB, power module, and audio amp.




# NX-820H(G)/820H


## DISASSEMBLY FOR REPAIR

### Note:

When you supply power to the TX-RX PCB after removing the TX-RX PCB from the chassis, solder the positive and ground terminals of the DC cord (Recommendation: E30-3448-25) to the + and GND terminals of the TX-RX PCB.




6. Pull it out behind the chassis by rotating the bush ③ of the DC cord 90 degrees in the direction of the arrow after the screw ① in the negative terminal is removed, and the positive terminal ② is removed from the chassis.




## 2. Precautions for Reassembly

1. The tab from ① to ③ is applied the front panel first. And, ④ to ⑥ tabs inside the front panel is pushed.




2. When mounting the panel assembly, pass the flat cable through the hole of the chassis as shown below then connect the flat cable to connector of the panel assembly.




3. Fit the panel assembly into the two tabs of the chassis top side first.

Then, fit the panel assembly into the two tabs of the chassis bottom side by turning the panel assembly.



## 3. Correspondence when replacing the LED (D22 and D23)

When replacing the LED (D22 and D23), it makes it to length.



# NX-820H(G)/820H


## CIRCUIT DESCRIPTION

### 1. Overview

The NX-820 is a UHF Mobile transceiver designed to operate in the frequency range of 450 to 520MHz(K-type) or 400 to 470MHz(K2-type). The unit consists of a receiver, transmitter, phase-locked loop (PLL) frequency synthesizer, base band parts, power supply, and control circuits.

### 2. Frequency Configuration

The receiver is a double-conversion super-heterodyne using a first intermediate frequency (IF) of 49.95MHz and a second IF of 450kHz. Incoming signals from the antenna are mixed with the local signal from the PLL circuit to produce the first IF of 49.95MHz. This is then mixed with the 50.4MHz second local oscillator output to produce the 450kHz second IF. The transmit signal frequency is generated by the PLL VCO, and modulated by the signal from the DSP. It is then amplified and fed to the antenna.



**Fig.1 Frequency configuration**

### 3. Receiver System

#### 3-1. RF circuit

An incoming RF signal from the antenna terminal is passed through the antenna switch (D110, 111 and 107) and then the bandpass filter (L215, 216 and 210). The bandpass filter is adjusted by a variable capacitor. The input voltage to the variable capacitor is regulated by the voltage output from the D/A converter (IC712). The signal is amplified by an RF amplifier (Q202), and passed through the bandpass filter (L207, 208, 209 and 211). The resulting signal is applied to the first mixer (Q201) where it is mixed with the first local oscillator signal output from the frequency synthesizer to produce the first IF (49.95MHz).


#### 3-2. IF circuit

The first IF signal is passed through a four-pole monolithic crystal filter (XF1) to reject the adjacent channel signal. The filtered first IF signal is amplified by the first IF amplifier (Q305) and then applied to the IF system IC (IC303). The IF system IC provides a second mixer, AGC amplifier , and RSSI (Received Signal Strength Indicator).

The second mixer mixes the first IF signal with the 50.4MHz of the second local oscillator output and produces the second IF signal of 450kHz.

The second IF signal is passed through the ceramic filter (CF1) to reject the adjacent channel signal. The filtered second IF signal is amplified by the AGC amplifier.

The signal from the AGC amplifier is input to an AD converter in ASIC (IC507) through the ceramic filter (CF2).



**Fig.2 Receiver System**

# NX-820H(G)/820H

## CIRCUIT DESCRIPTION

### 3-3. Audio amplifier circuit

Audio processing (high-pass filter, low-pass filter, de-emphasized and so on) in FM mode and decoding in NXDN mode are processed by the DSP (IC502). Audio signals from the ASIC (IC507), IC502 goes through the amplifier (IC711). The signal then goes through the D/A converter (IC712) and an amplifier (IC714).

### 3-4. Squelch Circuit

This circuit amplifies the demodulated noise signal from the ASIC (IC507) after filtering through a LPF and HPF circuit. The amplified signal is then converted to a DC signal by the detection circuit. The converted signal is fed back to IC507.




Fig. 3 Squelch Circuit

## 4. Transmitter System

### 4-1. Audio Band Circuit

The signal from the microphone is amplified by IC703 (1/2) and limited by the AGC circuit composed of D703, D704, Q703 and Q704. IC703 (2/2) works as an anti-aliasing LPF filter.




Fig. 4 Transmitter System




Fig. 5 APC Circuit

### 4-2. Base Band Circuit

The audio signal output from the Audio band circuit is converted to digital data with a sampling frequency of 48 kHz. This digital data is sent to the DSP (IC502), and voice signals of 300Hz or lower and frequencies of 3kHz or higher are cut off so that an audio range 300Hz to 3kHz is extracted. The audio signal is then pre-emphasized in FM mode and synthesized with the signals, such as QT and DQT, as required, and is then output from the ASIC (IC507). In Digital mode, the audio signal is converted to the 4-Level FSK base band signal and is output from IC507. The DTMF and MSK base band signals are also generated by the DSP and output from IC507.

LPF (IC701) works as smoothing filter. The output level according to the transmit carrier is fine-adjusted according to each modulation method.

### 4-3. Drive and Final amplifier

The signal from the T/R switch (D17 is on) is amplified by the drive amplifier (Q102) to 16~17dBm. The output of the drive amplifier is amplified by the final amplifier module (IC102) to 45W (5.0W when the power is low). The output of the final amplifier module is then passed through the harmonic filter (LPF) and antenna switch (D110, D111 are on) and directional coupler and is applied to the antenna terminal.

### 4-4. APC circuit

The Automatic transmission power control (APC) circuit stabilizes the transmitter output power at a predetermined level by detecting the power module output with the directional COUPLER and diode detector (D104 and D105). The diode detector (D104 and D105) applies the detected voltage to the DC amplifier IC103 (2/2).

The APC circuit is configured to protect over-current of the power module due to fluctuations of the load at the antenna end and to stabilize transmission output at voltage and temperature variations.

# NX-820H(G)/820H

## CIRCUIT DESCRIPTION

### 5. PLL Frequency Synthesizer

#### 5-1. TCXO (X1)

The TCXO (X1) generates a reference frequency of 16.8MHz for the PLL frequency synthesizer. This reference frequency is applied to pin 9 of the PLL IC (IC2) and is connected to the IF circuit as a 2nd local signal through the Tripler.

The frequency adjustment is achieved by switching the ratio of the dividing frequency. The resolution of the adjusting frequency is approximately 4Hz.

#### 5-2. VCO

There is an RX VCO and a TX VCO.

The TX VCO (Q6) generates a transmit carrier and the RX VCO (Q5) generates the 1st local signal. For the VCO oscillation frequency, the transmit carrier is 450 to 520 MHz (K-type) or 400 to 470MHz (K2-type) and the 1st local signal is 400.05 to 470.05MHz (K-type) or 350.05 to 420.05MHz (K2-type).

The VCO oscillation frequency is determined by one system of operation switching terminal "T/R" and two systems of voltage control terminals "CV" and "ASSIST".

The operation switching terminal, "T/R", is controlled by the control line (/T\_R) output from the ASIC (IC507). When the /T\_R logic is low, the VCO outputs the transmit carrier and when it is high, it outputs the 1st local receive signal.

The voltage control terminals, "CV" and "ASSIST", are controlled by the PLL IC (IC2) and ASIC (IC507) and the output frequency changes continuously according to the applied voltage. For the modulation input terminal, "VCO\_MOD", the output frequency changes according to the applied voltage. This is used to modulate the VCO output. "VCO\_MOD" works only when "/T\_R" is low.

#### 5-3. PLL IC (IC2)

The PLL IC compares the differences in phases of the VCO oscillation frequency and the TCXO reference frequency, returns the difference to the VCO CV terminal and realizes the "Phase Locked Loop" for the return control. This allows the VCO oscillation frequency to accurately match (lock) the desired frequency.

When the frequency is controlled by the PLL, the frequency convergence time increases as the frequency difference increases when the set frequency is changed. To supplement this, the ASIC (IC507) is used before control by the PLL IC to bring the VCO oscillation frequency close to the desired frequency. As a result, the VCO CV voltage does not change and is always stable at approximately 2.5V.

The desired frequency is set for the PLL IC by the ASIC (IC507) through the 3-line "SDO1", "P\_SCK1", "/PCS\_RF" serial bus. Whether the PLL IC is locked or not is monitored by the ASIC through the "PLD" signal line. If the VCO is not the desired frequency (unlocked), the "PLD" logic is low.

The modulation signal of the Low-speed-Data is applied to pin 23 of the PLL IC (IC2).

The modulation signal that is digital data of a sampling frequency of 96 kHz is set for the PLL IC by the DSP (IC502) through the "PLL\_MOD" line.

#### 5-4. Local Switch (D16, D17)

The connection destination of the signal output from the buffer amplifier (Q11) is changed with the diode switch (D17) that is controlled by the transmission power supply, HSW, and the diode switch (D16) that is controlled by the reception power supply, 50R. If the HSW logic is high, it is connected to a transmit-side drive (Q102). If the HSW logic is low, it is connected to a receive-side mixer (Q202).




Fig. 6 PLL circuit

# NX-820H(G)/820H

## CIRCUIT DESCRIPTION

### 6. Control Circuit

The control circuit consists of the ASIC (IC507) and its peripheral circuits. IC507 mainly performs the following:

- 1) Switching between transmission and reception via the PTT signal input.
- 2) Reading system, zone, frequency, and program data from the memory circuit.
- 3) Sending frequency program data to the PLL.
- 4) Controlling the squelch on/off using the DC voltage from the squelch circuit.
- 5) Controlling the audio mute circuit using the decode data input.

#### 6-1. ASIC

The ASIC (IC507) is a 32bit RISC processor, equipped with a peripheral function and ADC/DAC.

This ASIC operates at 18.432MHz clock and 3.3V /1.5V DC. It controls the flash memory, SRAM, DSP, the receive circuit, the transmitter circuit, the control circuit, and the display circuit and transfers data to or from an external device.

#### 6-2. Memory Circuit

The memory circuit consists of the ASIC (IC507), the SRAM (IC503) and the flash memory (IC501). The flash memory has a capacity of 32Mbit which contains the transceiver control program for the ASIC and stores the data. It also stores the data for the transceiver channels and operating parameters that are written by the FPU. This program can be easily written from external devices. The SRAM has a capacity of 1Mbit which contains the work area and data area.

#### ■ Flash memory

**Note :** The flash memory stores the data that is written by the FPU (KPG-141D), tuning data (Deviation, Squelch, etc.) and firmware program (User mode, Test mode, Tuning mode, etc.). This data must be rewritten when replacing the flash memory.

#### ■ SRAM (static memory)

**Note :** The SRAM has a temporary data area and work area.

#### 6-3. Display Unit

The display unit is composed of the LCD driver IC (IC1), the LCD & Key backlight, etc.

The LCD is controlled using the 4 serial lines (LCDDI,LCDCE,LCDCL,LCDDO) from the ASIC (IC507).

#### 6-4. Key Detection Circuit

The keys are detected using an LCD driver IC (IC1). If a pressed key is detected by IC1, the information is passed to IC507 through the serial line.

### 6-5. DSP

The DSP circuit consists of a DSP (IC502) and processes the base band signal. The DSP operates on an external clock of 18.432MHz (the same as the IC507), the I/O section operates at 3.3V and the core section operates at 1.5V. The DSP carries out the following processes:

- 4 level FSK processing
- Analog FM pre-emphasis/de-emphasis
- Vocoder processing between the audio codec and modulation/demodulation
- CAI processing, such as error correction encoding
- QT/DQT encoding/decoding
- DTMF encoding/decoding
- MSK encoding/decoding
- 2-tone encoding/decoding
- Compressor/expander processing
- Voice scrambler processing
- Transmit/receive audio filtering processing
- Microphone amplifier AGC processing
- Audio mute processing
- Modulation level processing

### 7. Power Supply Circuit

+B is connected to the Final amplifier and the DC/DC converter IC (IC405). IC405 regulates the +B voltage to 5.0V (50M). 50M operates whenever +B is supplied. IC401 (33M) and IC408 (15M) are enabled while the 50M is operating.

33M and 15M provide the power to the ASIC (IC507), DSP (IC502), and Flash memory. At this time the ASIC starts working. The voltage detector IC (IC402) watches the +B voltage. If the +B voltage is higher than 8.6V, IC402 (/BINT) outputs High. If the /BINT signal is high, Q403 (SB SW) is turned on by the SBC signal from the ASIC. (High : SBC=ON, Low : SBC=OFF). When the SB is turned on, IC1 (80C), IC404 (50C), Q402 (80ANT), Q404 (80T), Q415, 416 (150C), Q417 (50R) and Q408 (50CS) start working. IC409, Q409 and Q410 are controlled by the SBC signal. If the SBC signal becomes High, IC409 (33C) operates, and Q409 (33A\_2) and Q410 (50MC SW) turn on.

The ASIC sets the TXC signal to High during transmission to the supply power (80T) for the transmission circuit. The ASIC sets the signals (RXC) to High during reception to the supply power (50R) for the reception circuit.

When the ASIC detects the PSW (Power switch) signal, IGN (Ignition sense) signal or /BINT signal, it sets the SBC signal to Low, and turns the transceiver power (SB) off. When D401 and Q401 detect an over-voltage condition, they turn Q403 (SB SW) off, but the ASIC continues to function.

# NX-820H(G)/820H

## CIRCUIT DESCRIPTION




Fig. 16 Power supply circuit

# NX-820H(G)/820H

## CIRCUIT DESCRIPTION

### 8. Signaling Circuit

#### 8-1. Encode (QT/DQT/DTMF/2TONE/MSK)

Each signaling data signal of the QT, DQT, DTMF, 2TONE and MSK is generated by the DSP circuit, superposed on a modulation signal and output from the ASIC (IC507). Each deviation of the TX QT, DQT, DTMF, 2TONE and MSK tones are adjusted by changing the output level of the DSP (IC502) and the resulting signal is routed to the VCO and PLL.

#### 8-2. Decode (QT/DQT/DTMF/2TONE/MSK)

The audio signal is removed from the FM detection signal sent to the DSP circuit and the resulting signal is decoded by the DSP.

### 9. Compander Circuit

The term "compander" means compressor and expander. The compander reduces noise by utilizing a compressor and an expander. The DSP (IC502) performs this operation. The compander can be turned on or off using the FPU.

### 10. GPS Circuit (GPS model only)

The GPS information function can be used by setting it through the FPU. The GPS signal of 1575.42MHz received with the GPS active antenna (with a built-in LNA) is processed by the GPS module (A801) and input to the ASIC (IC507) through the UART port. The ASIC (IC507) processes the GPS data (NMEA) and sends the resulting information to the LCD.

# NX-820H(G)/820H

## COMPONENTS DESCRIPTION

### Display unit (X54-3830-10)

Ref.No	Part Name	Description
IC1	IC	LCD Driver
Q3	TRANSISTOR	TX/Busy LED Switch
Q6	TRANSISTOR	TX/Busy LED Switch
Q8	TRANSISTOR	LCD Backlight Switch
Q9	TRANSISTOR	Backlight Switch
Q10	TRANSISTOR	Status LED Switch
Q11	TRANSISTOR	Backlight Switch
D2	Diode	Line Protection
D5-9	LED	Key Backlight
D11-21	LED	LCD Backlight
D22	LED	Status LED
D23	LED	TX/Busy LED
D24	LED	LCD Backlite
D25	VARISTOR	Line Protection
D26	Diode	Key Control
D27	Zener diode	Over DC Supply Protection

### TX-RX unit (X57-8240-1X)

Ref.No	Part Name	Description
IC1	IC	AVR(80C)
IC2	IC	PLL System
IC3	IC	DC AMP(CV/Assist)
IC102	IC	TX Power Module
IC103	IC	OP AMP(APC)
IC201	IC	DC AMP(BPF)
IC301	IC	AND Gate
IC303	IC	FM System
IC304	IC	DC AMP(RSSI)
IC401	IC	AVR(33M)
IC402	IC	Voltage Detector(BINT)
IC404	IC	AVR(50C)
IC405	IC	DC/DC Converter(50M)
IC406	IC	AVR(33A)
IC407	IC	AVR(33GPS)
IC408	IC	AVR(15M)
IC409	IC	AVR(33C)
IC501	IC	Flash Memory
IC502	IC	DSP
IC503	IC	SRAM
IC504	IC	Reset
IC506	IC	Buffer AMP(Clock)
IC507	IC	ASIC
IC508	IC	AND Gate
IC509	IC	Dual BUS Buffer(HOOK/RXD/MKEYI)
IC511	IC	BUS Buffer
IC512	IC	Leval Shift
IC513	IC	Dual BUS Buffer(FNC3/FNC1)
IC514	IC	Dual BUS Buffer(FNC2/FNC4)
IC515	IC	I/O Expander
IC516	IC	RS-232C Driver
IC701	IC	VCO MOD/VREF
IC702	IC	LPF(APC/DMO)
IC703	IC	MIC SUM AMP/LPF(DI)
IC705	IC	BRF/Buffer AMP(SQ)
IC711	IC	RX SUM AMP/LPF(RX AF)
IC712	IC	D/A Converter
IC713	IC	MIC/RX Selector
IC714	IC	AF Power AMP
IC716	IC	Dual BUS Buffer(TXD1/MKEO)
IC801	IC	Dual BUS Buffer(TXD2/RXD2)

# NX-820H(G)/820H

## COMPONENTS DESCRIPTION

Ref. No	Part Name	Description
Q1	Transistor	DC Switch(Assist)
Q2	FET	DC Switch(Assist)
Q4	Transistor	Ripple Filter
Q5	Transistor	Buffer AMP(PLL Fin)
Q6	FET	RX VCO
Q7	FET	TX VCO
Q8,9	FET	T/R VCO Switch
Q10,11	Transistor	Buffer AMP
Q102	Transistor	TX Drive AMP
Q105	FET	DC Switch(H/L Power)
Q106	Transistor	DC Switch(50C)
Q201	FET	RX 1st Mixer
Q202	Transistor	LNA
Q303	Transistor	Tripler
Q305	Transistor	1st IF AMP
Q401	Transistor	DC Switch(Over DC Supply Protection)
Q402	Transistor	DC Switch(80ANT)
Q403	FET	DC Switch(SB)
Q404	Transistor	DC Switch(80T)
Q405	Transistor	DC Switch(80ANT)
Q407	Transistor	DC Switch(50MC)
Q408	Transistor	DC Switch(50CS)
Q409	FET	DC Switch(33A_2)
Q410	Transistor	DC Switch(50MC)
Q411	Transistor	DC Switch(80T)
Q412	Transistor	DC Switch(80ANT)
Q414	Transistor	DC Switch(150C)
Q415,416	Transistor	DC/DC Converter
Q417	Transistor	DC Switch(50R)
Q418	FET	DC Switch(SB)
Q501	FET	DC Switch(System)
Q502	Transistor	DC Switch(Horn Alert)
Q503	FET	DC Switch(Horn Alert)
Q504	Transistor	DC Switch(IGN)
Q701	FET	SQL Noise BW Switch
Q702	Transistor	Noise AMP
Q703,704	Transistor	MIC AGC
Q705	FET	Mute(MI1)
Q706	FET	Mute(MI2)
Q708	Transistor	Pop Noise prevention switch
Q709	FET	AF Mute Switch

Ref. No	Part Name	Description
D2	Zener Diode	Over Voltage Protection
D4	Variable Capacitance Diode	RX VCO Frequency Control
D5	Variable Capacitance Diode	TX VCO Frequency Control
D6	Variable Capacitance Diode	PLL f-in BPF Tune
D7	Variable Capacitance Diode	RX VCO Assist Tune
D8	Variable Capacitance Diode	TX VCO Assist Tune
D9,10	Variable Capacitance Diode	RX VCO Assist Tune
D11	Variable Capacitance Diode	TX VCO Assist Tune
D13	Variable Capacitance Diode	PLL f-in BPF Tune
D14	Diode	Speed up
D15	Variable Capacitance Diode	FM Modulation
D16,17	Diode	T/R Switch
D101	Zener Diode	Over Voltage Protection
D102	Diode	Voltage Shift
D103	Diode	Reverse Current Provention
D104,105	Diode	TX Power Detection
D106	Diode	Reverse Current Provention
D107	Diode	Antenna Switch
D108,109	Diode	Over DC Supply Protection
D110,110	Diode	Antenna Switch
D112-114	Diode	Over DC Supply Protection
D202-207	Variable Capacitance Diode	RX BPF Tune
D401	Zener Diode	Over DC Supply Protection
D403,404	Diode	Reverse Current Provention
D405	Diode	Discharge
D406	Diode	DC/DC Converter
D407	Diode	DC/DC Converter(50M)
D408,409	Diode	DC/DC Converter
D410	Surge Absorption	Surge Protection
D411	Diode	Reverse Current Provention
D502	Diode	Reverse Current Provention
D504	Diode	Reverse Current Provention
D505-510	Diode	Line Protection
D511-513	Diode	Reverse Current Provention
D601	Diode	Line Protection
D701	Diode	Reverse Current Provention
D702	Diode	Noise Detector
D703,704	Diode	AF Detector
D705,706	Diode	Line Protection
D801,801	Diode	Over DC Supply Protection

# NX-820H(G)/820H

## PARTS LIST

\* New Parts. △indicates safety critical components.

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

L : Scandinavia  
Y : PX (Far East, Hawaii)  
C : China

K : USA  
T : England  
X : Australia

P : Canada  
E : Europe  
M : Other Areas

NX-820H(G) / 820H  
DISPLAY UNIT (X54-3830-10)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation
<b>NX-820H(G)/820H</b>					
1	1B		A02-4073-21	PLASTIC CABINET	
2	2B	*	A10-4161-01	CHASSIS	
3	3A	*	A62-1200-03	PANEL ASSY	
5	2B		B09-0732-03	CAP(D-SUB)	
6	2B		B09-0754-05	CAP(SMA)	
7	3A		B43-1675-04	BADGE	
8	1C	*	B62-2421-00	INSTRUCTION MANUAL(E/S/F)	
9	3B	*	E29-1244-14	RELAY HARDWARE	
10	2B		E04-0167-15	RF COAXIAL RECEPTACLE(M)	
11	2B		E04-0492-05	RF COAXIAL RECEPTACLE(SMA)	
12	1C		E30-7523-55	DC CORD ASSY ACCESSORY	
13	1C		E30-7684-15	DC CORD	
14	2A		E37-1461-05	FLAT CABLE(30P)	
15	2B	*	F10-3183-03	SHIELDING CASE(POWER MODULE)	
16	1B	*	F10-3184-03	SHIELDING COVER(TOP)	
17	1B	*	F10-3203-02	SHIELDING CASE(LPF)	
18	1C		F52-0024-05	FUSE(15A/BLADE) ACCESSORY	
19	1A		G11-4353-04	SHEET(SHIELDING/BOTTOM)	
20	2B		G11-4578-04	SHEET(FOR W/O SMA)	
21	1B		G11-4611-04	SHEET(D-SUB)	
22	1B		G13-2102-04	CONDUCTIVE CUSHION	
23	3B		G13-2363-04	CUSHION(PANELHOLDER)	
24	1B		G13-2389-04	CUSHION(SHIELDING/TOP)	
25	2B		G13-2395-04	CUSHION(X57)	
26	2B		G53-1643-04	PACKING(D CORD)	
27	2B		G53-1662-04	PACKING(M ANT)	
28	2B		G53-1768-04	PACKING(SMA)	
31	1B		G53-1819-21	PACKING(CHASSIS)	
32	3A		G53-1820-03	PACKING(PANEL)	
33	3A		G53-1858-03	PACKING(SP)	
40	2D	*	H12-4345-12	PACKING FIXTURE	
41	2D	*	H12-4346-12	PACKING FIXTURE	
42	2D	*	H52-2568-02	ITEM CARTON CASE	
43	3C		J19-1584-15	HOLDER(MIC) ACCESSORY	
46	3A		J19-5542-02	HOLDER(PANEL)	
47	1D		J29-0726-03	BRACKET ACCESSORY	
48	3A		K29-9479-01	KEY TOP	
A	2B		N30-2605-48	PAN HEAD MACHINE SCREW(SMA)	
B	2A,2B		N67-3008-48	PAN HEAD SEMS SCREW	
C	2A,2B		N87-2608-48	BRAZIER HEAD TAPTIKE SCREW	
50	2C		N99-2039-05	SCREW SET ACCESSORY	
51	3A		T07-0785-15	SPEAKER	
52	2C		T91-0639-55	MICROPHONE(KMC-35) ACCESSORY	
			X57-8240-14	TX-RX UNIT(FOR SERVICE)	
			X57-8240-15	TX-RX UNIT(FOR SERVICE)	
			X57-8240-16	TX-RX UNIT(FOR SERVICE)	
			X57-8240-17	TX-RX UNIT(FOR SERVICE)	

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation
<b>DISPLAY UNIT (X54-3830-10)</b>					
101	2A		B11-1885-03	ILLUMINATION GUIDE	
102	2A		B38-0936-05	LCD	
D5 -9			B30-2337-05	LED(YELLOW)	
D11 -21			B30-2337-05	LED(YELLOW)	
D22	3A		B30-2321-05	LED(BLUE)	
D23	3A		B30-2151-05	LED(RED/GREEN)	
D24			B30-2337-05	LED(YELLOW)	
C1			CC73HCH1H101J	CHIP C 100PF	J
C2 ,3			CC73HCH1H221J	CHIP C 220PF	J
C4			CC73HCH1H101J	CHIP C 100PF	J
C5			CC73HCH1H221J	CHIP C 220PF	J
C6			CK73HB1H471K	CHIP C 470PF	K
C7			CK73HB1H102K	CHIP C 1000PF	K
C10			CK73HB1H102K	CHIP C 1000PF	K
C11			CC73HCH1H221J	CHIP C 220PF	J
C12			CC73HCH1H101J	CHIP C 100PF	J
C13			CK73HB1E103K	CHIP C 0.010UF	K
C14 ,15			CK73HB1H102K	CHIP C 1000PF	K
C21			CK73HB1E103K	CHIP C 0.010UF	K
C23			CK73HB1H102K	CHIP C 1000PF	K
C24 ,25			CK73HB1E103K	CHIP C 0.010UF	K
C27			CK73HB1A105K	CHIP C 1.0UF	K
C31			CK73HB1H102K	CHIP C 1000PF	K
C32 ,33			CK73HB1C473K	CHIP C 0.047UF	K
C34			CC73HCH1H470J	CHIP C 47PF	J
C35 ,36			CC73HCH1H221J	CHIP C 220PF	J
103	3A		E29-1231-15	INTER CONNECTOR(LCD)	
CN1			E40-6924-05	FLAT CABLE CONNECTOR(30P)	
J1	3A		E58-0535-05	MODULAR JACK(MIC)	
104	2A		J21-8629-03	MOUNTING HARDWARE(LCD)	
L1			L92-0138-05	CHIP FERRITE	
L2 ,3			L92-0140-05	CHIP FERRITE	
CP1			RK74HB1J101J	CHIP-COM 100	J 1/16W
R1			RK73HB1J101J	CHIP R 100	J 1/16W
R2 -4			RK73HB1J103J	CHIP R 10K	J 1/16W
R5			RK73HB1J102J	CHIP R 1.0K	J 1/16W
R7			RK73HB1J000J	CHIP R 0	J 1/16W
R9			RK73HB1J000J	CHIP R 0	J 1/16W
R12			RK73HB1J101J	CHIP R 100	J 1/16W
R14			RK73HB1J122J	CHIP R 1.2K	J 1/16W
R15			RK73HB1J000J	CHIP R 0	J 1/16W
R17			RK73HB1J000J	CHIP R 0	J 1/16W
R18			RK73GB2A331J	CHIP R 330	J 1/10W
R19			RK73GB2A221J	CHIP R 220	J 1/10W
R20			RK73HB1J000J	CHIP R 0	J 1/16W
R22			RK73HB1J000J	CHIP R 0	J 1/16W
R23			RK73HB1J473J	CHIP R 47K	J 1/16W
R24 ,25			RK73HB1J332J	CHIP R 3.3K	J 1/16W
R26			RK73HB1J472J	CHIP R 4.7K	J 1/16W
R28			RK73FB2B121J	CHIP R 120	J 1/8W
R29			RK73FB2B221J	CHIP R 220	J 1/8W
R34 -37			RK73GB2A271J	CHIP R 270	J 1/10W

# NX-820H(G)/820H

## PARTS LIST

DISPLAY UNIT (X54-3830-10)  
TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description			Desti-nation	Ref. No.	Address	New parts	Parts No.	Description			Desti-nation
R38-40			RK73HB1J472J	CHIP R	4.7K	J	1/16W	C55			CK73HB0J105K	CHIP C	1.0UF	K	
R41			RK73HB1J101J	CHIP R	100	J	1/16W	C56			CC73HCH1H060B	CHIP C	6.0PF	B	
R42			RK73HB1J272J	CHIP R	2.7K	J	1/16W	C57 ,58			CK73HB1H471K	CHIP C	470PF	K	
R43			RK73HB1J103J	CHIP R	10K	J	1/16W	C59			CC73HCH1H200G	CHIP C	20PF	G	HGK,HK
R44			RK73HB1J222J	CHIP R	2.2K	J	1/16W	C59			CC73HCH1H240G	CHIP C	24PF	G	HGK2,HK2
R45			RK73HB1J472J	CHIP R	4.7K	J	1/16W	C61			CC73HCH1H0R5B	CHIP C	0.5PF	B	HGK,HK
D1			DZ2J062(M)	ZENER DIODE				C63			CC73HCH1H0R5B	CHIP C	0.5PF	B	
D2			DA3S101F	DIODE				C64			CK73FB1A106K	CHIP C	10UF	K	
D25			MINSMDC020F	VARISTOR				C65			CK73HB1H471K	CHIP C	470PF	K	
D26			HN2S03FE	DIODE				C66			CC73HCH1H060B	CHIP C	6.0PF	B	HGK,HK
D27			DZ2J062(M)	ZENER DIODE				C66			CC73HCH1H070B	CHIP C	7.0PF	B	HGK2,HK2
IC1			LC75857W-E	MOS-IC				C67			CC73HCH1H040B	CHIP C	4.0PF	B	HGK,HK
Q3			KTC4075E(Y,GR)	TRANSISTOR				C67			CC73HCH1H050B	CHIP C	5.0PF	B	HGK2,HK2
Q6			KTC4075E(Y,GR)	TRANSISTOR				C68			CC73HCH1H030B	CHIP C	3.0PF	B	HGK,HK
Q8			KTC4075E(Y,GR)	TRANSISTOR				C68 ,69			CC73HCH1H060B	CHIP C	6.0PF	B	HGK2,HK2
Q9			QST7	TRANSISTOR				C69			CC73HCH1H060B	CHIP C	6.0PF	B	HGK,HK
Q10			LTC014EEBFS8	TRANSISTOR				C70			CK73GB1E105K	CHIP C	1.0UF	K	
Q11			KTC4075E(Y,GR)	TRANSISTOR				C71			CC73HCH1H180G	CHIP C	18PF	G	
<b>TX-RX UNIT (X57-8240-XX) -10:HGK -11:HK -12:HGK2 -13:HK2</b>															
C1			CK73HB1E103K	CHIP C	0.010UF	K		C72			CC73HCH1H040B	CHIP C	4.0PF	B	HGK2,HK2
C2			CC73HCH1H101J	CHIP C	100PF	J		C73			CC73HCH1H050B	CHIP C	5.0PF	B	HGK,HK
C3 ,4			CK73HB1H103K	CHIP C	0.010UF	K		C74			CK73HB1H471K	CHIP C	470PF	K	
C5 ,6			CC73HCH1H100B	CHIP C	10PF	B		C76			CC73HCH1H0R5B	CHIP C	0.5PF	B	
C7			CK73HB1H103K	CHIP C	0.010UF	K		C78			CK73HB1H471K	CHIP C	470PF	K	
C8			CK73HB1H471K	CHIP C	470PF	K		C80			CK73HB1H471K	CHIP C	470PF	K	
C9			CC73HCH1H100B	CHIP C	10PF	B		C81			CC73HCH1H070B	CHIP C	7.0PF	B	
C10 ,11			CK73HB1H103K	CHIP C	0.010UF	K		C82			CK73HB1H471K	CHIP C	470PF	K	
C12			CC73HCH1H050B	CHIP C	5.0PF	B		C83			CC73HCH1H100B	CHIP C	10PF	B	
C12			CC73HCH1H070B	CHIP C	7.0PF	B		C84			CC73HCH1H030B	CHIP C	3.0PF	B	
C16 -21			CC73HCH1H101J	CHIP C	100PF	J		C85 ,87			CK73HB1H471K	CHIP C	470PF	K	
C22			CK73HB1A104K	CHIP C	0.10UF	K		C88			CK73HB1A104K	CHIP C	0.10UF	K	
C23			CC73HCH1H101J	CHIP C	100PF	J		C89			CC73HCH1H060B	CHIP C	6.0PF	B	
C25 ,26			CC73HCH1H101J	CHIP C	100PF	J		C90			CC73HCH1H070B	CHIP C	7.0PF	B	HGK,HK
C28			CC73HCH1H101J	CHIP C	100PF	J		C90			CC73HCH1H100B	CHIP C	10PF	B	HGK2,HK2
C29			CS77MA1VR15M	CHIP TNTL	0.15UF		35WV	C91			C93-0787-05	CHIP C	0.1UF	J	
C30			CK73GB1E105K	CHIP C	1.0UF	K		C102			CK73HB1H471K	CHIP C	470PF	K	
C31			CC73HCH1H470J	CHIP C	47PF	J		C103			CK73HB1H103K	CHIP C	0.010UF	K	
C32			CS77BA1D100M	CHIP TNTL	10UF		20WV	C104			CK73HB1H471K	CHIP C	470PF	K	
C33			CK73HB1H103K	CHIP C	0.010UF	K		C104,107			CK73FB1E475K	CHIP C	4.7UF	K	
C34			C93-1906-05	CHIP FILM	0.047UF	J		C108			C109	CHIP C	6.0PF	B	
C36			CC73HCH1H101J	CHIP C	100PF	J		C110,111			CK73HB1H471K	CHIP C	470PF	K	
C39			CC73HCH1H330J	CHIP C	33PF	J		C113			CC73HCH1H101J	CHIP C	100PF	J	
C41			CK73HB1H471K	CHIP C	470PF	K		C116			CC73HCH1H101J	CHIP C	100PF	J	
C43			CK73HB1H471K	CHIP C	470PF	K		C117,118			CK73HB1H471K	CHIP C	470PF	K	
C46			CC73HCH1H050B	CHIP C	5.0PF	B		C119			CC73HCH1H060B	CHIP C	6.0PF	B	
C47			CC73HCH1H030B	CHIP C	3.0PF	B		C124			CC73HCH1H060B	CHIP C	6.0PF	B	
C47			CC73HCH1H040B	CHIP C	4.0PF	B		C124			CC73HCH1H070B	CHIP C	7.0PF	B	HGK2,HK2
C48			CC73HCH1H050B	CHIP C	5.0PF	B		C125			CK73HB1H471K	CHIP C	470PF	K	
C49			CC73HCH1H100B	CHIP C	10PF	B		C127			CC73HCH1H220J	CHIP C	22PF	J	
C49			CC73HCH1H180G	CHIP C	18PF	G		C128			CC73HCH1H470J	CHIP C	47PF	J	
C50			CC73HCH1H151J	CHIP C	150PF	J		C129			CC73HCH1H060B	CHIP C	6.0PF	B	HGK,HK
C50			CC73HCH1H271J	CHIP C	270PF	J		C129			CC73HCH1H070B	CHIP C	7.0PF	B	HGK2,HK2
C51			CC73HCH1H271J	CHIP C	270PF	J		C131			CC73HCH1H101J	CHIP C	100PF	J	
C51			CK73HB1H471K	CHIP C	470PF	K		C133			CC73HCH1H221J	CHIP C	220PF	J	HGK2,HK2
C53			CC73HCH1H050B	CHIP C	5.0PF	B		C134,135			CK73HB1H471K	CHIP C	470PF	K	HGK,HK
C53 ,54			CC73HCH1H050B	CHIP C	5.0PF	B		C136			CK73HB1H471K	CHIP C	470PF	K	HGK2,HK2
C54			CC73HCH1H080B	CHIP C	8.0PF	B		C137			CK73FB1H471K	CHIP C	470PF	K	
								C140			CC73HCH1H101J	CHIP C	100PF	J	
											CS77LA1C4R7M	CHIP TNTL	4.7UF	16WV	

# NX-820H(G)/820H

## PARTS LIST

TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation	Ref. No.	Address	New parts	Parts No.	Description	Desti-nation	
C142			CC73HCH1H220J	CHIP C 22PF	J HGK2,HK2	C219			CK73HB1H471K	CHIP C 470PF	K HGK,HK	
C144			CC73HCH1H470J	CHIP C 47PF	J HGK2,HK2	C220			CC73HCH1H120G	CHIP C 12PF	G HGK2,HK2	
C145			CK73HB1A104K	CHIP C 1.5PF	K HGK2,HK2	C220			CC73HCH1H150G	CHIP C 15PF	G HGK,HK	
C146			C93-0550-05	CHIP C 1.0PF	C HGK,HK	C221			CC73HCH1H040B	CHIP C 4.0PF	B HGK,HK	
C148			CC73HCH1H101J	CHIP C 100PF	J HGK2,HK2	C221			CC73HCH1H080B	CHIP C 8.0PF	B HGK2,HK2	
C149			CC73HCH1H220J	CHIP C 22PF	J HGK,HK	C222			CC73HCH1H020B	CHIP C 2.0PF	B HGK,HK	
C149			CK73HB1H471K	CHIP C 470PF	K HGK2,HK2	C222			CC73HCH1H100B	CHIP C 10PF	B HGK2,HK2	
C150			CK73GB1E105K	CHIP C 1.0UF	K HGK2,HK2	C223			CK73HB1H471K	CHIP C 470PF	K HGK,HK	
C151			C93-0551-05	CHIP C 1.5PF	C HGK,HK	C224			CC73HCH1H130G	CHIP C 13PF	G HGK,HK	
C151			C93-0553-05	CHIP C 3.0PF	C HGK2,HK2	C224			CC73HCH1H150G	CHIP C 15PF	G HGK2,HK2	
C152			C92-0875-05	ELECTRO 47UF	25WV	C225			CC73HCH1H040B	CHIP C 4.0PF	B HGK2,HK2	
C154			CK73HB1E223K	CHIP C 0.022UF	K	C225			CC73HCH1H080B	CHIP C 8.0PF	B HGK,HK	
C155			CK73HB1H471K	CHIP C 470PF	K	C226			CC73HCH1H040B	CHIP C 4.0PF	B HGK,HK	
C156			CC73HCH1H101J	CHIP C 100PF	J	C226			CC73HCH1H050B	CHIP C 5.0PF	B HGK2,HK2	
C157			CK73HB1H102K	CHIP C 1000PF	K	C227,228			CK73HB1H471K	CHIP C 470PF	K HGK2,HK2	
C158			CK73HB1H471K	CHIP C 470PF	K	C230			CC73HCH1H100B	CHIP C 10PF	B HGK2,HK2	
C161			CC73GCH1H040C	CHIP C 4.0PF	C	C230,231			CC73HCH1H080B	CHIP C 8.0PF	B HGK,HK	
C165			CK73HB1H471K	CHIP C 470PF	K	C231			CC73HCH1H050B	CHIP C 5.0PF	B HGK2,HK2	
C167			CC73GCH1H040C	CHIP C 4.0PF	C	C232			CC73HCH1H050B	CHIP C 5.0PF	B HGK,HK	
C168			CK73HB1H471K	CHIP C 470PF	K	C232			CC73HCH1H090B	CHIP C 9.0PF	B HGK2,HK2	
C169			CK73HB1H102K	CHIP C 1000PF	K	C233			CK73HB1H471K	CHIP C 470PF	K HGK2,HK2	
C171			CC73HCH1H101J	CHIP C 100PF	J	C234			CC73HCH1H100B	CHIP C 10PF	B HGK,HK	
C172,173			CK73HB1H471K	CHIP C 470PF	K	C239			CK73GB1H104K	CHIP C 0.10UF	K HGK2,HK2	
C175			CC73FCH1H020B	CHIP C 2.0PF	B HGK,HK	C240			CK73GB1E105K	CHIP C 1.0UF	K HGK,HK	
C175			CC73FCH1H060B	CHIP C 6.0PF	B HGK2,HK2	C246			CK73HB1H471K	CHIP C 470PF	K HGK2,HK2	
C177			C93-1871-05	CHIP C 100PF	250WV	C250			CK73HB1H471K	CHIP C 470PF	K HGK2,HK2	
C179			C93-0553-05	CHIP C 3.0PF	C HGK,HK	C251			CC73HCH1H070B	CHIP C 7.0PF	B HGK,HK	
C179			C93-0554-05	CHIP C 4.0PF	C HGK2,HK2	C252,253			CK73HB1H471K	CHIP C 470PF	K HGK2,HK2	
C180			C93-0555-05	CHIP C 5.0PF	C HGK,HK	C254			CC73HCH1H040B	CHIP C 4.0PF	B HGK2,HK2	
C180			C93-0556-05	CHIP C 6.0PF	D HGK2,HK2	C254			CC73HCH1H050B	CHIP C 5.0PF	B HGK,HK	
C183			C93-1852-05	CHIP C 6.0PF	250WV	C255			CC73HCH1H020B	CHIP C 2.0PF	B HGK,HK	
C184			C93-0557-05	CHIP C 7.0PF	D HGK2,HK2	C256			CC73HCH1H180G	CHIP C 18PF	G HGK2,HK2	
C187,188			CK73HB1H102K	CHIP C 1000PF	K	C256			CC73HCH1H220G	CHIP C 22PF	G HGK,HK	
C190			CC73HCH1H070B	CHIP C 7.0PF	B	C263			CC73HCH1H070B	CHIP C 7.0PF	B HGK,HK	
C191			CC73GCH1H220J	CHIP C 22PF	J	C263			CC73HCH1H100B	CHIP C 10PF	B HGK2,HK2	
C192			CC73GCH1H120J	CHIP C 12PF	J	C289			CC73HCH1H101J	CHIP C 100PF	J HGK2,HK2	
C193			CC73GCH1H330J	CHIP C 33PF	J	C290			CC73HCH1H030B	CHIP C 3.0PF	B HGK,HK	
C194			CC73GCH1H100D	CHIP C 10PF	D	C290,291			CC73HCH1H020B	CHIP C 2.0PF	B HGK2,HK2	
C197			C93-1855-05	CHIP C 7.0PF	250WV	HGK,HK	C291			CC73HCH1H020B	CHIP C 2.0PF	B HGK2,HK2
C197			C93-1857-05	CHIP C 8.0PF	250WV	HGK2,HK2	C292			CC73HCH1H080B	CHIP C 8.0PF	B HGK2,HK2
C201,202			CK73HB1E103K	CHIP C 0.010UF	K	C292			CC73HCH1H100B	CHIP C 10PF	B HGK,HK	
C203			CK73HB1H471K	CHIP C 470PF	K	C293			CK73HB1H471K	CHIP C 470PF	K HGK2,HK2	
C204			CK73FB1E475K	CHIP C 4.7UF	K	C294			CC73HCH1H100B	CHIP C 10PF	B HGK2,HK2	
C205			CK73HB1H471K	CHIP C 470PF	K	C295			CC73HCH1H060B	CHIP C 6.0PF	B HGK2,HK2	
C206			CC73HCH1H1R5B	CHIP C 1.5PF	B	C296			CC73HCH1H180G	CHIP C 18PF	G HGK2,HK2	
C207			CK73HB1H471K	CHIP C 470PF	K	C296,297			CC73HCH1H101J	CHIP C 100PF	J HGK,HK	
C208			CC73HCH1H040B	CHIP C 4.0PF	B HGK,HK	C297			CC73HCH1H101J	CHIP C 100PF	J HGK2,HK2	
C208			CC73HCH1H060B	CHIP C 6.0PF	B HGK2,HK2	C299			CK73HB1H471K	CHIP C 470PF	K HGK2,HK2	
C209			CC73HCH1H120J	CHIP C 12PF	J	C306			CK73HB1E103K	CHIP C 0.010UF	K HGK2,HK2	
C210			CK73HB1E103K	CHIP C 0.010UF	K	C307			CK73HB1A104K	CHIP C 0.10UF	K HGK2,HK2	
C211			CC73HCH1H010B	CHIP C 1.0PF	B	C309			CC73HCH1H100B	CHIP C 10PF	B HGK2,HK2	
C212			CC73HCH1H080B	CHIP C 8.0PF	B	C312			CK73HB1H103K	CHIP C 0.010UF	K HGK2,HK2	
C212			CC73HCH1H120G	CHIP C 12PF	G	C313			CK73HB1A104K	CHIP C 0.10UF	K HGK2,HK2	
C213			CC73HCH1H020B	CHIP C 2.0PF	B	C315			CK73HB1E103K	CHIP C 0.010UF	K HGK2,HK2	
C214			CC73HCH1H070B	CHIP C 7.0PF	B	C316			CC73HCH1H100B	CHIP C 10PF	B HGK2,HK2	
C214			CC73HCH1H080B	CHIP C 8.0PF	B	C317			CC73HCH1H101J	CHIP C 100PF	J HGK2,HK2	
C215,216			CK73HB1H471K	CHIP C 470PF	K	C322			CC73HCH1H101J	CHIP C 100PF	J HGK2,HK2	
C217			CC73HCH1H020B	CHIP C 2.0PF	B	C323			CC73HCH1H151J	CHIP C 150PF	J HGK2,HK2	
C218			CC73HCH1H050B	CHIP C 5.0PF	B	C324			CC73HCH1H330G	CHIP C 33PF	G HGK2,HK2	
C218			CC73HCH1H060B	CHIP C 6.0PF	B	C325			CC73HCH1H680G	CHIP C 68PF	G HGK2,HK2	

# NX-820H(G)/820H

## PARTS LIST

TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description			Desti-nation	Ref. No.	Address	New parts	Parts No.	Description			Desti-nation
C326			CC73HCH1H100B	CHIP C	10PF	B		C453			CK73HB1H103K	CHIP C	0.010UF	K	
C327			CK73HB1A104K	CHIP C	0.10UF	K		C454,455			CK73GB1C225K	CHIP C	2.2UF	K	
C330			CK73HB1A104K	CHIP C	0.10UF	K		C456			CK73HB1H103K	CHIP C	0.010UF	K	
C332-335			CK73HB1A104K	CHIP C	0.10UF	K		C457,458			CC73HCH1H101J	CHIP C	100PF	J	
C336			CK73FB1A106K	CHIP C	10UF	K		C460			CC73HCH1H101J	CHIP C	100PF	J	
C337			CK73HB1A104K	CHIP C	0.10UF	K		C461			CK73HB1A105K	CHIP C	1.0UF	K	
C338			CK73FB1A106K	CHIP C	10UF	K		C462			CK73GB1E105K	CHIP C	1.0UF	K	
C339			CK73HB1A104K	CHIP C	0.10UF	K		C463			CC73HCH1H101J	CHIP C	100PF	J	
C340			CK73HB1H103K	CHIP C	0.010UF	K		C464			CK73HB1A105K	CHIP C	1.0UF	K	
C341			CK73HB1A104K	CHIP C	0.10UF	K		C465,466			CK73GB1E105K	CHIP C	1.0UF	K	
C342			CK73HB1A105K	CHIP C	1.0UF	K		C468			CK73HB1H103K	CHIP C	0.010UF	K	
C343-345			CK73HB1A104K	CHIP C	0.10UF	K		C469			CK73HB1A105K	CHIP C	1.0UF	K	
C346			CK73HB1A105K	CHIP C	1.0UF	K		C471			CC73HCH1H101J	CHIP C	100PF	J	
C347			CK73HB1H103K	CHIP C	0.010UF	K		C472			CK73HB1H102K	CHIP C	1000PF	K	
C348			CC73HCH1H470J	CHIP C	47PF	J		C475			CK73GB1E105K	CHIP C	1.0UF	K	
C350			CK73HB1H103K	CHIP C	0.010UF	K		C476			CK73HB1A104K	CHIP C	0.10UF	K	
C351			CC73HCH1H101J	CHIP C	100PF	J		C477			CK73GB1H104K	CHIP C	0.10UF	K	
C357			CC73HCH1H0R5B	CHIP C	0.5PF	B		C501-504			CK73HB1A104K	CHIP C	0.10UF	K	
C358			CC73HCH1H100B	CHIP C	10PF	B		C505-507			CK73GB0J106K	CHIP C	10UF	K	
C359-361			CK73HB1E103K	CHIP C	0.010UF	K		C508,509			CK73HB1A105K	CHIP C	1.0UF	K	
C363			CC73HCH1H220G	CHIP C	22PF	G		C510			CK73HB1A104K	CHIP C	0.10UF	K	
C366			CK73HB1E103K	CHIP C	0.010UF	K		C512			CK73HB1A104K	CHIP C	0.10UF	K	
C367			CK73HB1H103K	CHIP C	0.010UF	K		C514-516			CK73HB1A104K	CHIP C	0.10UF	K	
C368			CK73HB1H471K	CHIP C	470PF	K		C518-520			CK73HB1A104K	CHIP C	0.10UF	K	
C369			CK73HB1H103K	CHIP C	0.010UF	K		C521			CC73HCH1H101J	CHIP C	100PF	J	
C371			CK73HB1H103K	CHIP C	0.010UF	K		C522,523			CK73HB1A104K	CHIP C	0.10UF	K	
C401			C92-0968-05	ELECTRO	470UF	25WV		C524			CK73HB1A105K	CHIP C	1.0UF	K	
C403			CK73HB1H471K	CHIP C	470PF	K		C525-531			CK73HB1A104K	CHIP C	0.10UF	K	
C405			CK73HB1H103K	CHIP C	0.010UF	K		C532			CK73HB1H103K	CHIP C	0.010UF	K	
C408,409			CK73HB1H103K	CHIP C	0.010UF	K		C533			CK73GB0J106K	CHIP C	10UF	K	
C410			CK73GB1C225K	CHIP C	2.2UF	K		C534			CK73HB1A104K	CHIP C	0.10UF	K	
C411			CK73GB1H104K	CHIP C	0.10UF	K		C535			CK73HB1H272K	CHIP C	2700PF	K	
C413			CC73HCH1H101J	CHIP C	100PF	J		C536			CK73HB1A104K	CHIP C	0.10UF	K	
C416			CK73HB1H103K	CHIP C	0.010UF	K		C537			CK73HB1H102K	CHIP C	1000PF	K	
C417			CC73HCH1H101J	CHIP C	100PF	J		C541			CK73HB1A104K	CHIP C	0.10UF	K	
C420			CK73GB1E105K	CHIP C	1.0UF	K		C542			CK73HB1H103K	CHIP C	0.010UF	K	
C422			CK73HB1H102K	CHIP C	1000PF	K		C543,544			CK73HB1A104K	CHIP C	0.10UF	K	
C423,424			CC73HCH1H101J	CHIP C	100PF	J		C545			CK73FB1A106K	CHIP C	10UF	K	
C425			CK73HB1H103K	CHIP C	0.010UF	K		C546			CK73HB1H103K	CHIP C	0.010UF	K	
C427			CK73GB1H473K	CHIP C	0.047UF	K		C547			CC73HCH1H101J	CHIP C	100PF	J	
C428			CK73HB1A104K	CHIP C	0.10UF	K		C548			CK73HB1H103K	CHIP C	0.010UF	K	
C429			CK73HB1H471K	CHIP C	470PF	K		C549			CK73HB1A104K	CHIP C	0.10UF	K	
C430			CK73FB1E475K	CHIP C	4.7UF	K		C551			CK73HB1A104K	CHIP C	0.10UF	K	
C431			CC73HCH1H101J	CHIP C	100PF	J		C552			CK73HB1H103K	CHIP C	0.010UF	K	
C432			CK73GB1H104K	CHIP C	0.10UF	K		C553			CK73HB1A105K	CHIP C	1.0UF	K	
C433,434			CK73FB1E475K	CHIP C	4.7UF	K		C555,556			CK73HB1H103K	CHIP C	0.010UF	K	
C435			CK73GB1C225K	CHIP C	2.2UF	K		C558			CK73HB1A104K	CHIP C	0.10UF	K	
C436			CK73HB1H103K	CHIP C	0.010UF	K		C559			CK73FB1A106K	CHIP C	10UF	K	
C437			CK73FB1E475K	CHIP C	4.7UF	K		C560			CC73HCH1H030B	CHIP C	3.0PF	B	
C438,439			CK73GB1H104K	CHIP C	0.10UF	K		C563			CC73HCH1H101J	CHIP C	100PF	J	
C440			C92-0875-05	ELECTRO	47UF	25WV		C565-568			CK73HB1A104K	CHIP C	0.10UF	K	
C441			CK73GB1C225K	CHIP C	2.2UF	K		C569			CK73HB1H103K	CHIP C	0.010UF	K	
C442			CK73HB1H103K	CHIP C	0.010UF	K		C570			CK73HB1A105K	CHIP C	1.0UF	K	
C443			CK73GB1E105K	CHIP C	1.0UF	K		C572-576			CK73HB1A104K	CHIP C	0.10UF	K	
C445,446			CK73HB1H103K	CHIP C	0.010UF	K		C577			CK73HB1H103K	CHIP C	0.010UF	K	
C447			CK73GB1E105K	CHIP C	1.0UF	K		C578			CK73HB1A105K	CHIP C	1.0UF	K	
C448			CK73HB1H103K	CHIP C	0.010UF	K		C579-581			CK73HB1H103K	CHIP C	0.010UF	K	
C449			CK73GB1E105K	CHIP C	1.0UF	K		C602			CK73HB1H103K	CHIP C	0.010UF	K	
C450,451			CK73FB1A106K	CHIP C	10UF	K		C603			CC73HCH1H101J	CHIP C	100PF	J	
C452			CS77LA1C4R7M	CHIP TNTL	4.7UF	16WV		C604			CK73HB1H102K	CHIP C	1000PF	K	

# NX-820H(G)/820H

## PARTS LIST

TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation	Ref. No.	Address	New parts	Parts No.	Description	Desti-nation
C605			CC73HCH1H101J	CHIP C 100PF J		C762			CK73HB1H103K	CHIP C 0.010UF K	
C607			CC73HCH1H101J	CHIP C 100PF J		C765			CC73HCH1H220J	CHIP C 22PF J	
C609-611			CC73HCH1H470J	CHIP C 47PF J		C766,767			CK73GB0J475K	CHIP C 4.7UF K	
C612			CC73HCH1H101J	CHIP C 100PF J		C769			CK73HB1E103K	CHIP C 0.010UF K	
C613			CK73HB1H103K	CHIP C 0.010UF K		C770			CK73HB1A104K	CHIP C 0.10UF K	
C614-618			CC73HCH1H101J	CHIP C 100PF J		C771			CK73HB1H122K	CHIP C 1200PF K	
C620			CC73HCH1H101J	CHIP C 100PF J		C773			CK73HB1E103K	CHIP C 0.010UF K	
C621			CK73HB1H102K	CHIP C 1000PF K		C774			CK73HB1A104K	CHIP C 0.10UF K	
C622-624			CK73HB1H103K	CHIP C 0.010UF K		C775			CC73HCH1H101J	CHIP C 100PF J	
C625			CK73HB1A104K	CHIP C 0.10UF K		C776			CK73HB1A393K	CHIP C 0.039UF K	
C626			CK73GB1H103K	CHIP C 0.010UF K		C777			CK73HB1A104K	CHIP C 0.10UF K	
C627-630			CK73GB1E105K	CHIP C 1.0UF K		C778			CK73HB1A105K	CHIP C 1.0UF K	
C632			CK73HB1H102K	CHIP C 1000PF K		C779,780			CC73HCH1H101J	CHIP C 100PF J	
C633-642			CC73HCH1H101J	CHIP C 100PF J		C782			CK73HB1A104K	CHIP C 0.10UF K	
C643			CK73HB1E223K	CHIP C 0.022UF K		C784			CK73FB1A106K	CHIP C 10UF K	
C644			CC73HCH1H101J	CHIP C 100PF J		C786			CK73HB1A104K	CHIP C 0.10UF K	
C645			CK73GB1H103K	CHIP C 0.010UF K		C788			CK73FB1E475K	CHIP C 4.7UF K	
C646			CC73HCH1H101J	CHIP C 100PF J		C790,791			CK73FB1A106K	CHIP C 10UF K	
C647			CK73HB1H103K	CHIP C 0.010UF K		C796			CK73GB1E105K	CHIP C 1.0UF K	
C648			CK73GB1H104K	CHIP C 0.10UF K		C797,798			CK73GB1C224K	CHIP C 0.22UF K	
C649			CK73GB1H103K	CHIP C 0.010UF K		C801			C92-0875-05	ELECTRO 47UF 25WV	
C650-652			CK73HB1A104K	CHIP C 0.10UF K		C802			CK73HB1H102K	CHIP C 1000PF K	
C660			CC73HCH1H101J	CHIP C 100PF J		C803,804			C92-0906-05	ELECTRO 330UF 16WV	
C661			CC73HCH1H470J	CHIP C 47PF J		C805			CK73HB1H102K	CHIP C 1000PF K	
C680			CK73HB1A104K	CHIP C 0.10UF K		C806			CK73GB1E105K	CHIP C 1.0UF K	
C701			CK73HB1H682K	CHIP C 6800PF K		C807			CK73HB1C473K	CHIP C 0.047UF K	
C702			CK73HB1H102K	CHIP C 1000PF K		C808			CK73HB1A683K	CHIP C 0.068UF K	
C704			CK73HB1A105K	CHIP C 1.0UF K		C809			CK73HB1H102K	CHIP C 1000PF K	
C705			CC73HCH1H470J	CHIP C 47PF J		C810			CK73FB1E475K	CHIP C 4.7UF K	
C706			CK73HB1A104K	CHIP C 0.10UF K		C811			CK73HB1H102K	CHIP C 1000PF K	
C707			CK73HB1H681K	CHIP C 680PF K		C812			CK73FB1A106K	CHIP C 10UF K	
C708			CK73HB1H102K	CHIP C 1000PF K		C813			CK73GB0J106K	CHIP C 10UF K	
C709			CC73HCH1H270J	CHIP C 27PF J		C813,814			CK73GB0J106K	CHIP C 10UF K	
C711			CC73HCH1H331J	CHIP C 330PF J		C815			CK73HB1A104K	CHIP C 0.10UF K	
C712			CC73HCH1H181J	CHIP C 180PF J		C816			CK73HB1H102K	CHIP C 1000PF K	
C714			CC73HCH1H680J	CHIP C 68PF J		C820			CK73HB1A104K	CHIP C 0.10UF K	
C716			CC73HCH1H101J	CHIP C 100PF J		C821,822			CC73HCH1H180J	CHIP C 18PF J	
C718			CK73HB1A104K	CHIP C 0.10UF K		C823			CK73HB1H102K	CHIP C 1000PF K	
C719			CC73HCH1H101J	CHIP C 100PF J		C824,825			CC73HCH1H180J	CHIP C 18PF J	
C720			CK73HB1A104K	CHIP C 0.10UF K		C826			CK73HB1A104K	CHIP C 0.10UF K	
C722			CK73HB1A104K	CHIP C 0.10UF K		C829			CK73GB0J106K	CHIP C 10UF K	
C723			CC73HCH1H470J	CHIP C 47PF J		C830,831			CK73HB1A104K	CHIP C 0.10UF K	
C725			CC73HCH1H121J	CHIP C 120PF J		C832,833			CK73HB1H102K	CHIP C 1000PF K	
C728			CK73HB1H821K	CHIP C 820PF K					CK73HB1H102K	CHIP C 1000PF K	
C729			CK73HB1H681K	CHIP C 680PF K					CK73HB1A104K	CHIP C 0.10UF K	
C732			CK73HB1H102K	CHIP C 1000PF K		CN10-12					
C733			CK73FB1E475K	CHIP C 4.7UF K		CN10-15			E23-1278-05	TERMINAL	
C734			CK73HB1H472K	CHIP C 4700PF K		CN14,15			E23-1278-05	TERMINAL	
C735			CK73GB0J106K	CHIP C 10UF K		CN203-206			E23-1278-05	TERMINAL	
C738			CK73HB1A104K	CHIP C 0.10UF K		CN514			E40-6847-05	FLAT CABLE CONNECTOR	
C739			CK73HB1A105K	CHIP C 1.0UF K		CN801					
C740			CK73HB1H102K	CHIP C 1000PF K		J501			E04-0410-05	PIN SOCKET(3P)	
C741			CK73HB1A224K	CHIP C 0.22UF K		J701			E58-0536-05	D-SUB SOCKET(15P)	
C743			CC73HCH1H470J	CHIP C 47PF J		F401			E11-0425-05	3.5D PHONE JACK(EXT-SP)	
C744			CK73HB1A224K	CHIP C 0.22UF K		F501					
C746			CK73HB1A104K	CHIP C 0.10UF K		F502,503			F53-0328-15	FUSE(5A)	
C747			CC73HCH1H221J	CHIP C 220PF J		F701			F53-0324-15	FUSE(2.5A)	
C749			CK73HB1H102K	CHIP C 1000PF K					F53-0315-15	FUSE(250MA)	
C752,753			CK73HB1A104K	CHIP C 0.10UF K					F53-0324-15	FUSE(2.5A)	
C758			CC73HCH1H101J	CHIP C 100PF J		L1					
						L2			L41-4795-39	SMALL FIXED INDUCTOR(4.7U/2520)	

# NX-820H(G)/820H

## PARTS LIST

TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation	Ref. No.	Address	New parts	Parts No.	Description	Desti-nation
L3			L92-0163-05	BEADS CORE		L302			L40-5681-86	SMALL FIXED INDUCTOR(0.56UH)	
L5			L92-0163-05	BEADS CORE		L304			L40-5675-92	SMALL FIXED INDUCTOR(56NH)	
L6 ,7			L40-1001-86	SMALL FIXED INDUCTOR(10UH)		L307			L40-2291-86	SMALL FIXED INDUCTOR(2.2UH)	
L9			L40-5675-71	SMALL FIXED INDUCTOR(56NH)		L309			L40-1085-57	SMALL FIXED INDUCTOR(100NH)	
L11			L40-2285-92	SMALL FIXED INDUCTOR(220NH)	HGK2,HK2	L310			L92-0138-05	CHIP FERRITE	
L11 -16			L40-1885-92	SMALL FIXED INDUCTOR(180NH)	HGK,HK	L312			L41-1585-14	SMALL FIXED INDUCTOR(150NH)	
L12			L40-1885-92	SMALL FIXED INDUCTOR(180NH)	HGK2,HK2	L315			L41-3985-39	SMALL FIXED INDUCTOR(0.39UH)	
L13			L40-2285-92	SMALL FIXED INDUCTOR(220NH)	HGK2,HK2	L316			L41-1885-39	SMALL FIXED INDUCTOR(0.18UH)	
L14 -16			L40-1885-92	SMALL FIXED INDUCTOR(180NH)	HGK2,HK2	L404			L92-0639-05	CHIP FERRITE	
L17			L34-4607-15	AIR-CORE COIL(6T)	HGK,HK	L405			L33-1496-05	SMALL FIXED INDUCTOR(22UH)	
L17			L34-4608-15	AIR-CORE COIL(7T)	HGK2,HK2	L501			L92-0138-05	CHIP FERRITE	
L18			L34-4608-15	AIR-CORE COIL(7T)	HGK,HK	L503			L92-0138-05	CHIP FERRITE	
L18			L34-4609-15	AIR-CORE COIL(8T)	HGK2,HK2	L504-506			L92-0162-05	BEADS CORE	
L19			L92-0163-05	BEADS CORE		L508			L92-0138-05	CHIP FERRITE	
L20			L40-1275-92	SMALL FIXED INDUCTOR(12NH)		L510			L92-0138-05	CHIP FERRITE	
L21			L40-1885-92	SMALL FIXED INDUCTOR(180NH)	HGK,HK	L801			L79-1958-05	FILTER	HGK,HGK2
L21			L40-2285-92	SMALL FIXED INDUCTOR(220NH)	HGK2,HK2	L802			L40-2775-57	SMALL FIXED INDUCTOR(27.0NH)	HGK,HGK2
L22			L92-0446-05	BEADS CORE		L805,806			L92-0138-05	CHIP FERRITE	HGK,HGK2
L23,24			L40-1885-92	SMALL FIXED INDUCTOR(180NH)	HGK,HK	X1			L77-3073-05	TCXO(16.8MHZ)	
L23,24			L40-2285-92	SMALL FIXED INDUCTOR(220NH)	HGK2,HK2	X501			L77-3015-05	TCXO(18.432MHZ)	
L25			L40-2775-71	SMALL FIXED INDUCTOR(27NH)		XF1			L71-0678-05	MCF(49.95MHZ)	
L26			L92-0163-05	BEADS CORE		CP1			RK74HB1J100J	CHIP-COM 10 J 1/16W	
L27			L40-3975-92	SMALL FIXED INDUCTOR(39NH)		CP501			RK74HB1J104J	CHIP-COM 100K J 1/16W	
L29			L40-2285-92	SMALL FIXED INDUCTOR(220NH)		CP502			RK74HA1J104J	CHIP-COM 100K J 1/16W	
L40 ,41			L92-0163-05	BEADS CORE		CP503			RK74HB1J104J	CHIP-COM 100K J 1/16W	
L101			L40-2275-92	SMALL FIXED INDUCTOR(22NH)		CP504			RK74HA1J101J	CHIP-COM 100 J 1/16W	
L102			L40-1875-92	SMALL FIXED INDUCTOR(18NH)		CP505			RK74HA1J104J	CHIP-COM 100K J 1/16W	
L103			L92-0140-05	CHIP FERRITE		CP506-508			RK74HB1J104J	CHIP-COM 100K J 1/16W	
L105			L92-0163-05	BEADS CORE		CP510			RK74HA1J104J	CHIP-COM 100K J 1/16W	
L106			L40-1875-92	SMALL FIXED INDUCTOR(18NH)		CP511			RK74HA1J101J	CHIP-COM 100 J 1/16W	
L107			L92-0140-05	CHIP FERRITE		CP512			RK74HA1J104J	CHIP-COM 100K J 1/16W	
L108-110			L92-0179-05	CHIP FERRITE		CP513			RK74HB1J104J	CHIP-COM 100K J 1/16W	
L111			L92-0163-05	BEADS CORE		CP514			RK74HA1J104J	CHIP-COM 100K J 1/16W	
L112			L34-4667-05	AIR-CORE COIL(9.5T)		CP515			RK74HA1J101J	CHIP-COM 100 J 1/16W	
L113			L34-4694-05	AIR-CORE COIL(1.5T)		CP516			RK74HB1J101J	CHIP-COM 100 J 1/16W	
L114			L34-4667-05	AIR-CORE COIL(9.5T)		CP701			RK74HB1J101J	CHIP-COM 100 J 1/16W	
L115			L34-4912-05	AIR-CORE COIL(1T)		CP703,704			RK74HB1J104J	CHIP-COM 100K J 1/16W	
L116,117			L34-4669-05	AIR-CORE COIL(2.5T)		CP705,706			RK74HA1J104J	CHIP-COM 100K J 1/16W	
L118			L40-2275-92	SMALL FIXED INDUCTOR(22NH)		CP707			RK74HB1J102J	CHIP-COM 1.0K J 1/16W	
L121			L40-1575-71	SMALL FIXED INDUCTOR(15NH)		R1			RK73HB1J000J	CHIP R 0 J 1/16W	HGK,HK
L201			L92-0138-05	CHIP FERRITE		R2			RK73HB1J000J	CHIP R 0 J 1/16W	HGK2,HK2
L202			L41-5685-39	SMALL FIXED INDUCTOR(0.56UH)		R5			RK73HB1J000J	CHIP R 0 J 1/16W	
L203			L41-2785-39	SMALL FIXED INDUCTOR(0.27UH)		R10			RK73HB1J100J	CHIP R 10 J 1/16W	
L204,205			L40-1575-71	SMALL FIXED INDUCTOR(15NH)	HGK,HK	R12			RK73HB1J683J	CHIP R 68K J 1/16W	
L204,205			L40-1875-71	SMALL FIXED INDUCTOR(18NH)	HGK2,HK2	R13 ,14			RK73HB1J473J	CHIP R 47K J 1/16W	
L206			L40-3975-71	SMALL FIXED INDUCTOR(39NH)	HGK,HK	R15			RK73HB1J100J	CHIP R 10 J 1/16W	
L206			L40-4775-71	SMALL FIXED INDUCTOR(47NH)	HGK2,HK2	R16			RK73HB1J102J	CHIP R 1.0K J 1/16W	
L207-209			L41-2778-14	SMALL FIXED INDUCTOR(27NH)	HGK,HK	R17			RK73HB1J104J	CHIP R 100K J 1/16W	
L207-209			L41-3378-14	SMALL FIXED INDUCTOR(33NH)	HGK2,HK2	R18			RK73HB1J102J	CHIP R 1.0K J 1/16W	
L210			L41-6878-14	SMALL FIXED INDUCTOR(68NH)	HGK,HK	R19 ,20			RK73HB1J000J	CHIP R 0 J 1/16W	
L210			L41-8278-14	SMALL FIXED INDUCTOR(82NH)	HGK2,HK2	R21			RK73HB1J470J	CHIP R 47 J 1/16W	
L211			L41-2778-14	SMALL FIXED INDUCTOR(27NH)	HGK,HK	R22			RK73HB1J181J	CHIP R 180 J 1/16W	
L211			L41-3378-14	SMALL FIXED INDUCTOR(33NH)	HGK2,HK2	R23			RK73HB1J100J	CHIP R 10 J 1/16W	
L212			L92-0138-05	CHIP FERRITE		R24			RK73HH1J391D	CHIP R 390 D 1/16W	
L213,214			L41-1878-14	SMALL FIXED INDUCTOR(18NH)	HGK,HK	R25			RK73HB1J104J	CHIP R 100K J 1/16W	
L213,214			L41-2278-14	SMALL FIXED INDUCTOR(22NH)	HGK2,HK2	R26			RK73HB1J102J	CHIP R 1.0K J 1/16W	
L215,216			L41-2778-14	SMALL FIXED INDUCTOR(27NH)	HGK,HK						
L215,216			L41-3378-14	SMALL FIXED INDUCTOR(33NH)	HGK2,HK2						
L228			L40-1875-92	SMALL FIXED INDUCTOR(18NH)	HGK,HK						
L228			L40-2763-92	SMALL FIXED INDUCTOR(2.7NH)	HGK2,HK2						

# NX-820H(G)/820H

## PARTS LIST

TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description			Desti-nation	Ref. No.	Address	New parts	Parts No.	Description			Desti-nation
R27			RK73HB1J103J	CHIP R	10K	J	1/16W	R125			RK73FB2B821J	CHIP R	820	J	1/8W
R28			RK73HB1J106J	CHIP R	10M	J	1/16W	R128			RK73HB1J221J	CHIP R	220	J	1/16W
R29			RK73HB1J470J	CHIP R	47	J	1/16W	R130			RK73HB1J153J	CHIP R	15K	J	1/16W
R30			RK73HB1J184J	CHIP R	180K	J	1/16W	R131			RK73HB1J103J	CHIP R	10K	J	1/16W
R31			RK73HB1J473J	CHIP R	47K	J	1/16W	R133			RK73HB1J123J	CHIP R	12K	J	1/16W
R33			RK73HB1J472J	CHIP R	4.7K	J	1/16W	R134			RK73GB2A121J	CHIP R	120	J	1/10W
R34 -36			RK73HB1J000J	CHIP R	0	J	1/16W	R135			RK73HB1J823J	CHIP R	82K	J	1/16W
R40 ,41			RK73HB1J000J	CHIP R	0	J	1/16W	R136			RK73GB2A151J	CHIP R	150	J	1/10W
R46			RK73HB1J330J	CHIP R	33	J	1/16W	R137			RK73HB1J104J	CHIP R	100K	J	1/16W
R46			RK73HB1J680J	CHIP R	68	J	1/16W	R138			RK73HB1J103J	CHIP R	10K	J	1/16W
R48			RK73HB1J472J	CHIP R	4.7K	J	1/16W	R139,140			RK73GB2A151J	CHIP R	150	J	1/10W
R49			RK73HB1J473J	CHIP R	47K	J	1/16W	R141			RK73HB1J333J	CHIP R	33K	J	1/16W
R50			RN73HH1J100D	CHIP R	10	D	1/16W	R142			RK73HB1J000J	CHIP R	0	J	1/16W
R52			RK73HB1J474J	CHIP R	470K	J	1/16W	R143			RK73HB1J104J	CHIP R	100K	J	1/16W
R53 ,54			RK73HB1J333J	CHIP R	33K	J	1/16W	R145			RK73GB2A100J	CHIP R	10	J	1/10W
R55			RN73HH1J151D	CHIP R	150	D	1/16W	R146			RK73HB1J393J	CHIP R	39K	J	1/16W
R55			RN73HH1J181D	CHIP R	180	D	1/16W	R147			RK73HB1J104J	CHIP R	100K	J	1/16W
R56			RK73HB1J000J	CHIP R	0	J	1/16W	R148			RK73HB1J000J	CHIP R	0	J	1/16W
R57			RN73HH1J151D	CHIP R	150	D	1/16W	R149			RK73HB1J103J	CHIP R	10K	J	1/16W
R57			RN73HH1J181D	CHIP R	180	D	1/16W	R150			RK73HB1J124J	CHIP R	120K	J	1/16W
R58			RN73HH1J100D	CHIP R	10	D	1/16W	R152			RK73HB1J102J	CHIP R	1.0K	J	1/16W
R59			RK73HB1J102J	CHIP R	1.0K	J	1/16W	R154			RK73HB1J000J	CHIP R	0	J	1/16W
R60			RK73HB1J473J	CHIP R	47K	J	1/16W	R155			RK73HB1J223J	CHIP R	22K	J	1/16W
R61			RK73HB1J154J	CHIP R	150K	J	1/16W	R157,158			RK73HB1J333J	CHIP R	33K	J	1/16W
R62			RK73HB1J101J	CHIP R	100	J	1/16W	R159,160			RK73HB1J000J	CHIP R	0	J	1/16W
R63			RK73HB1J682J	CHIP R	6.8K	J	1/16W	R161			RK73HB1J104J	CHIP R	100K	J	1/16W
R64			RK73HB1J103J	CHIP R	10K	J	1/16W	R167			RK73HB1J153J	CHIP R	15K	J	1/16W
R65			RK73HB1J221J	CHIP R	220	J	1/16W	R168,169			RK73EB2E241J	CHIP R	240	J	1/4W
R66			RK73HB1J391J	CHIP R	390	J	1/16W	R170			RK73GB2A000J	CHIP R	0	J	1/10W
R67			RK73HB1J101J	CHIP R	100	J	1/16W	R171			R92-1061-05	JUMPER REST	0 OHM		
R69			RK73HB1J102J	CHIP R	1.0K	J	1/16W	R176			RK73GB2A221J	CHIP R	220	J	1/10W
R70			RK73HB1J474J	CHIP R	470K	J	1/16W	R177,178			RK73HB1J000J	CHIP R	0	J	1/16W
R71			RK73HB1J101J	CHIP R	100	J	1/16W	R179,180			RK73HB1J333J	CHIP R	33K	J	1/16W
R72			RK73HB1J102J	CHIP R	1.0K	J	1/16W	R181			RK73HB1J000J	CHIP R	0	J	1/16W
R73			RK73GB2A000J	CHIP R	0	J	1/10W	R183			RK73HB1J103J	CHIP R	10K	J	1/16W
R75			RK73HB1J100J	CHIP R	10	J	1/16W	R184,185			RK73HB1J471J	CHIP R	470	J	1/16W
R76			RK73HB1J000J	CHIP R	0	J	1/16W	R184,185			RK73HB1J821J	CHIP R	820	J	1/16W
R80 -85			RK73GB2A000J	CHIP R	0	J	1/10W	R187			RK73HB1J473J	CHIP R	47K	J	1/16W
R80 ,81			RK73GB2A000J	CHIP R	0	J	1/10W	R188			RK73GB2A120J	CHIP R	12	J	1/10W
R83 ,84			RK73GB2A000J	CHIP R	0	J	1/10W	R188			RK73GB2A5R6J	CHIP R	5.6	J	1/10W
R86			RK73HB1J000J	CHIP R	0	J	1/16W	R201			RK73HB1J470J	CHIP R	47	J	1/16W
R87			RK73HB1J000J	CHIP R	0	J	1/16W	R203			RK73HB1J681J	CHIP R	680	J	1/16W
R90			RK73HB1J105J	CHIP R	1.0M	J	1/16W	R204			RK73HB1J472J	CHIP R	4.7K	J	1/16W
R101			RK73HB1J332J	CHIP R	3.3K	J	1/16W	R205			RK73HB1J151J	CHIP R	150	J	1/16W
R102			RK73HB1J221J	CHIP R	220	J	1/16W	R207			RK73HB1J104J	CHIP R	100K	J	1/16W
R102			RK73HB1J471J	CHIP R	470	J	1/16W	R208			RK73HB1J184J	CHIP R	180K	J	1/16W
R103			RK73HB1J120J	CHIP R	12	J	1/16W	R209			RK73HB1J104J	CHIP R	100K	J	1/16W
R103			RK73HB1J220J	CHIP R	22	J	1/16W	R210			RK73HB1J224J	CHIP R	220K	J	1/16W
R104			RK73HB1J221J	CHIP R	220	J	1/16W	R213-217			RK73HB1J104J	CHIP R	100K	J	1/16W
R104			RK73HB1J471J	CHIP R	470	J	1/16W	R218			RK73HB1J000J	CHIP R	0	J	1/16W
R108			RK73GB2A680J	CHIP R	68	J	1/10W	R223			RK73HB1J000J	CHIP R	0	J	1/16W
R109			RK73HB1J221J	CHIP R	220	J	1/16W	R230			RK73HB1J000J	CHIP R	0	J	1/16W
R110			RK73GB2A220J	CHIP R	22	J	1/10W	R233			RK73HB1J274J	CHIP R	270K	J	1/16W
R111			RK73HB1J272J	CHIP R	2.7K	J	1/16W	R234			RK73HB1J104J	CHIP R	100K	J	1/16W
R112			RK73HB1J681J	CHIP R	680	J	1/16W	R235			RK73HB1J103J	CHIP R	10K	J	1/16W
R113			RK73GB2A150J	CHIP R	15	J	1/10W	R241			RK73HB1J103J	CHIP R	10K	J	1/16W
R114			RK73HB1J471J	CHIP R	470	J	1/16W	R242			RK73HB1J274J	CHIP R	270K	J	1/16W
R120			RK73HB1J153J	CHIP R	15K	J	1/16W	R243			RK73HB1J104J	CHIP R	100K	J	1/16W
R121			RK73FB2B821J	CHIP R	820	J	1/8W	R245			RK73HB1J102J	CHIP R	1.0K	J	1/16W
R122,123			RK73FB2B120J	CHIP R	12	J	1/8W	R247			RK73HB1J470J	CHIP R	47	J	1/16W

# NX-820H(G)/820H

## PARTS LIST

TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description			Desti-nation	Ref. No.	Address	New parts	Parts No.	Description			Desti-nation		
R249,250			RK73HB1J183J	CHIP R	18K	J	1/16W				R429		RK73HB1J000J	CHIP R	0	J	1/16W
R255-257			RK73HB1J104J	CHIP R	100K	J	1/16W				R430		RK73HB1J102J	CHIP R	1.0K	J	1/16W
R259			RK73HB1J000J	CHIP R	0	J	1/16W				R431		RK73HB1J000J	CHIP R	0	J	1/16W
R290			RK73HB1J000J	CHIP R	0	J	1/16W				R432		RK73HB1J103J	CHIP R	10K	J	1/16W
R291,292			RK73GB2A000J	CHIP R	0	J	1/10W	HGK,HK			R433		RK73HB1J274J	CHIP R	270K	J	1/16W
R303-305			RK73HB1J102J	CHIP R	1.0K	J	1/16W				R434		RK73HB1J103J	CHIP R	10K	J	1/16W
R306			RK73HB1J334J	CHIP R	330K	J	1/16W				R435		RK73HB1J000J	CHIP R	0	J	1/16W
R307			RK73HB1J561J	CHIP R	560	J	1/16W				R438		RK73GB2A100J	CHIP R	10	J	1/10W
R308			RK73HB1J000J	CHIP R	0	J	1/16W				R439		RK73HB1J474J	CHIP R	470K	J	1/16W
R315			RK73HB1J000J	CHIP R	0	J	1/16W				R440		RK73HB1J000J	CHIP R	0	J	1/16W
R316			RK73HB1J332J	CHIP R	3.3K	J	1/16W				R441		RK73HB1J272J	CHIP R	2.7K	J	1/16W
R323			RK73HB1J000J	CHIP R	0	J	1/16W				R501		RK73HB1J220J	CHIP R	22	J	1/16W
R324			RK73HB1J183J	CHIP R	18K	J	1/16W				R503,504		RK73HB1J104J	CHIP R	100K	J	1/16W
R326			RK73GB2A331J	CHIP R	330	J	1/10W				R505,506		RK73GB2A000J	CHIP R	0	J	1/10W
R328			RK73HB1J183J	CHIP R	18K	J	1/16W				R508-511		RK73HB1J101J	CHIP R	100	J	1/16W
R329			RK73HB1J100J	CHIP R	10	J	1/16W				R512		RK73HB1J104J	CHIP R	100K	J	1/16W
R332			RK73HB1J000J	CHIP R	0	J	1/16W				R513		RK73HB1J000J	CHIP R	0	J	1/16W
R336,337			RK73HB1J102J	CHIP R	1.0K	J	1/16W				R515-517		RK73HB1J000J	CHIP R	0	J	1/16W
R338			RK73HB1J473J	CHIP R	47K	J	1/16W				R518		RK73HB1J101J	CHIP R	100	J	1/16W
R339			RK73HB1J153J	CHIP R	15K	J	1/16W				R519		RK73HB1J000J	CHIP R	0	J	1/16W
R340			RK73HB1J274J	CHIP R	270K	J	1/16W				R521,522		RK73HB1J104J	CHIP R	100K	J	1/16W
R341			RK73HB1J103J	CHIP R	10K	J	1/16W				R524		RK73HB1J000J	CHIP R	0	J	1/16W
R342			RK73HB1J104J	CHIP R	100K	J	1/16W				R525		RK73HB1J474J	CHIP R	470K	J	1/16W
R343			RK73HB1J223J	CHIP R	22K	J	1/16W				R526		RK73HB1J104J	CHIP R	100K	J	1/16W
R344			RK73HB1J272J	CHIP R	2.7K	J	1/16W				R531		RK73HB1J104J	CHIP R	100K	J	1/16W
R345			RK73HB1J000J	CHIP R	0	J	1/16W				R532		RK73HB1J000J	CHIP R	0	J	1/16W
R350			RK73HB1J103J	CHIP R	10K	J	1/16W				R533,534		RK73HB1J473J	CHIP R	47K	J	1/16W
R351			RK73HB1J104J	CHIP R	100K	J	1/16W				R536		RK73HB1J000J	CHIP R	0	J	1/16W
R355			RK73HB1J000J	CHIP R	0	J	1/16W				R541		RK73HB1J101J	CHIP R	100	J	1/16W
R357			RK73HB1J104J	CHIP R	100K	J	1/16W				R546		RK73HB1J000J	CHIP R	0	J	1/16W
R358			RK73HB1J333J	CHIP R	33K	J	1/16W				R549		RK73HB1J103J	CHIP R	10K	J	1/16W
R368			RK73HB1J221J	CHIP R	220	J	1/16W				R550		RK73HB1J104J	CHIP R	100K	J	1/16W
R378			RK73HB1J394J	CHIP R	390K	J	1/16W				R552,553		RK73HB1J472J	CHIP R	4.7K	J	1/16W
R379			RK73HB1J222J	CHIP R	2.2K	J	1/16W				R554		RK73HB1J332J	CHIP R	3.3K	J	1/16W
R381			RK73HB1J221J	CHIP R	220	J	1/16W				R555		RK73HB1J102J	CHIP R	1.0K	J	1/16W
R390			RK73HB1J103J	CHIP R	10K	J	1/16W				R556		RK73HB1J220J	CHIP R	22	J	1/16W
R394			RK73HB1J181J	CHIP R	180	J	1/16W				R557		RK73HB1J153J	CHIP R	15K	J	1/16W
R401			RK73HB1J471J	CHIP R	470	J	1/16W				R558		RK73HB1J220J	CHIP R	22	J	1/16W
R402			RK73HB1J103J	CHIP R	10K	J	1/16W				R559		RK73HB1J392J	CHIP R	3.9K	J	1/16W
R403			RK73HH1J274D	CHIP R	270K	D	1/16W				R560		RK73HB1J474J	CHIP R	470K	J	1/16W
R404			RK73HH1J104D	CHIP R	100K	D	1/16W				R561		RK73HB1J000J	CHIP R	0	J	1/16W
R405,406			RK73HB1J103J	CHIP R	10K	J	1/16W				R566		RK73HB1J474J	CHIP R	470K	J	1/16W
R407			RK73HB1J472J	CHIP R	4.7K	J	1/16W				R567		RK73HB1J102J	CHIP R	1.0K	J	1/16W
R408			RK73HB1J684J	CHIP R	680K	J	1/16W				R568,569		RK73HB1J000J	CHIP R	0	J	1/16W
R409			RK73HB1J104J	CHIP R	100K	J	1/16W				R571,572		RK73HB1J000J	CHIP R	0	J	1/16W
R410			RK73GB2AA4R7J	CHIP R	4.7	J	1/10W				R580		RK73HB1J332J	CHIP R	3.3K	J	1/16W
R411			RK73HB1J473J	CHIP R	47K	J	1/16W				R581		RK73HB1J104J	CHIP R	100K	J	1/16W
R412,413			RK73GB2A100J	CHIP R	10	J	1/10W				R583		RK73HH1J104D	CHIP R	100K	D	1/16W
R414,415			RK73HB1J103J	CHIP R	10K	J	1/16W				R584		RK73HB1J473J	CHIP R	47K	J	1/16W
R417			RK73HB1J104J	CHIP R	100K	J	1/16W				R599		RK73HB1J104J	CHIP R	100K	J	1/16W
R418			RK73HB1J000J	CHIP R	0	J	1/16W				R603		RK73HB1J474J	CHIP R	470K	J	1/16W
R419			RK73HB1J272J	CHIP R	2.7K	J	1/16W				R606		RK73HB1J105J	CHIP R	1.0M	J	1/16W
R421			RK73HB1J472J	CHIP R	4.7K	J	1/16W				R610		RK73HB1J474J	CHIP R	470K	J	1/16W
R422			RK73HB1J474J	CHIP R	470K	J	1/16W				R611		RK73HB1J103J	CHIP R	10K	J	1/16W
R423			RK73HB1J472J	CHIP R	4.7K	J	1/16W				R612		RK73HB1J102J	CHIP R	1.0K	J	1/16W
R424			RK73HB1J103J	CHIP R	10K	J	1/16W				R613		RK73HB1J103J	CHIP R	10K	J	1/16W
R425			RK73HH1J124D	CHIP R	120K	D	1/16W				R614		RK73HB1J000J	CHIP R	0	J	1/16W
R426			RK73HH1J183D	CHIP R	18K	D	1/16W				R615		RK73HB1J472J	CHIP R	4.7K	J	1/16W
R427			RK73HH1J223D	CHIP R	22K	D	1/16W				R616		RK73HB1J474J	CHIP R	470K	J	1/16W
R428			RK73HB1J102J	CHIP R	1.0K	J	1/16W				R617		RK73HB1J000J	CHIP R	0	J	1/16W

# NX-820H(G)/820H

## PARTS LIST

TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description			Desti-nation	Ref. No.	Address	New parts	Parts No.	Description			Desti-nation
R620			RK73HB1J103J	CHIP R	10K	J	1/16W	R748,749			RK73HB1J104J	CHIP R	100K	J	1/16W
R621-624			RK73HB1J104J	CHIP R	100K	J	1/16W	R750			RK73HB1J393J	CHIP R	39K	J	1/16W
R626			RK73HB1J101J	CHIP R	100	J	1/16W	R751			RK73HB1J104J	CHIP R	100K	J	1/16W
R627,628			RK73HB1J682J	CHIP R	6.8K	J	1/16W	R752			RK73HB1J394J	CHIP R	390K	J	1/16W
R629			RK73HB1J104J	CHIP R	100K	J	1/16W	R754			RK73HB1J563J	CHIP R	56K	J	1/16W
R631			RK73HB1J104J	CHIP R	100K	J	1/16W	R755			RK73HB1J224J	CHIP R	220K	J	1/16W
R632			RK73GB2A000J	CHIP R	0	J	1/10W	R756			RK73HB1J102J	CHIP R	1.0K	J	1/16W
R634			RK73HB1J101J	CHIP R	100	J	1/16W	R769			RK73HB1J684J	CHIP R	680K	J	1/16W
R635			RK73GB2A000J	CHIP R	0	J	1/10W	R770,771			RK73HB1J473J	CHIP R	47K	J	1/16W
R636			RK73HB1J474J	CHIP R	470K	J	1/16W	R772			RK73HB1J153J	CHIP R	15K	J	1/16W
R637,638			RK73FB2B102J	CHIP R	1.0K	J	1/8W	R773			RK73HB1J000J	CHIP R	0	J	1/16W
R639			RK73HB1J471J	CHIP R	470	J	1/16W	R775			RK73HB1J562J	CHIP R	5.6K	J	1/16W
R641			RK73GB2A000J	CHIP R	0	J	1/10W	R776,777			RK73HB1J103J	CHIP R	10K	J	1/16W
R643			RK73GB2A000J	CHIP R	0	J	1/10W	R778			RK73HB1J273J	CHIP R	27K	J	1/16W
R657			RK73HB1J472J	CHIP R	4.7K	J	1/16W	R779			RK73HB1J223J	CHIP R	22K	J	1/16W
R658,659			RK73GB2A000J	CHIP R	0	J	1/10W	R781			RK73HB1J000J	CHIP R	0	J	1/16W
R661			RK73HB1J473J	CHIP R	47K	J	1/16W	R783			RK73HB1J154J	CHIP R	150K	J	1/16W
R662			RK73GB2A000J	CHIP R	0	J	1/10W	R785			RK73HB1J000J	CHIP R	0	J	1/16W
R664			RK73GB2A000J	CHIP R	0	J	1/10W	R786			RK73HB1J563J	CHIP R	56K	J	1/16W
R667			RK73GB2A101J	CHIP R	100	J	1/10W	R787			RK73HB1J123J	CHIP R	12K	J	1/16W
R668			RK73HB1J471J	CHIP R	470	J	1/16W	R796,797			RK73GB2A000J	CHIP R	0	J	1/10W
R669-671			RK73HB1J101J	CHIP R	100	J	1/16W	R800			RK73HB1J104J	CHIP R	100K	J	1/16W
R672			RK73GB2A471J	CHIP R	470	J	1/10W	R801			RK73HB1J102J	CHIP R	1.0K	J	1/16W
R673			RK73HB1J104J	CHIP R	100K	J	1/16W	R801,802			RK73HB1J102J	CHIP R	1.0K	J	1/16W
R674			RK73HB1J105J	CHIP R	1.0M	J	1/16W	R803,804			RK73HB1J472J	CHIP R	4.7K	J	1/16W
R677-680			RK73GB2A000J	CHIP R	0	J	1/10W	R805,806			RK73HB1J102J	CHIP R	1.0K	J	1/16W
R681			RK73HB1J000J	CHIP R	0	J	1/16W	R810			RK73HB1J123J	CHIP R	12K	J	1/16W
R682,683			RK73GB2A000J	CHIP R	0	J	1/10W	R811			RK73HB1J103J	CHIP R	10K	J	1/16W
R684			RK73HB1J473J	CHIP R	47K	J	1/16W	R813			RK73HB1J102J	CHIP R	1.0K	J	1/16W
R685			RK73HB1J103J	CHIP R	10K	J	1/16W	R814			RK73HB1J391J	CHIP R	390	J	1/16W
R686			RK73HB1J223J	CHIP R	22K	J	1/16W	R816			RK73HB1J123J	CHIP R	12K	J	1/16W
R687			RK73HB1J103J	CHIP R	10K	J	1/16W	R818			RK73HB1J332J	CHIP R	3.3K	J	1/16W
R688			RK73HB1J102J	CHIP R	1.0K	J	1/16W	R819,820			RK73HB1J222J	CHIP R	2.2K	J	1/16W
R690			RK73HB1J102J	CHIP R	1.0K	J	1/16W	R821,822			RK73GB2A000J	CHIP R	0	J	1/10W
R701			RK73HB1J103J	CHIP R	10K	J	1/16W	R823			RK73HB1J123J	CHIP R	12K	J	1/16W
R702			RK73HB1J222J	CHIP R	2.2K	J	1/16W	R824			RK73HB1J332J	CHIP R	3.3K	J	1/16W
R703			RK73HB1J563J	CHIP R	56K	J	1/16W	R825			RK73HB1J000J	CHIP R	0	J	1/16W
R704			RK73HB1J153J	CHIP R	15K	J	1/16W	R826			RK73HB1J103J	CHIP R	10K	J	1/16W
R705			RK73HB1J683J	CHIP R	68K	J	1/16W	R827			RK73HB1J823J	CHIP R	82K	J	1/16W
R706			RK73HB1J823J	CHIP R	82K	J	1/16W	R831,832			RK73HB1J683J	CHIP R	68K	J	1/16W
R707			RK73HB1J182J	CHIP R	1.8K	J	1/16W	R833			RK73HB1J101J	CHIP R	100	J	1/16W
R708			RK73HB1J333J	CHIP R	33K	J	1/16W	R834			RK73HB1J102J	CHIP R	1.0K	J	1/16W
R709			RK73HB1J104J	CHIP R	100K	J	1/16W	R835			RK73HB1J100J	CHIP R	10	J	1/16W
R710			RK73HB1J563J	CHIP R	56K	J	1/16W	R837			RK73HB1J562J	CHIP R	5.6K	J	1/16W
R711			RK73HB1J104J	CHIP R	100K	J	1/16W	R838			RK73HB1J332J	CHIP R	3.3K	J	1/16W
R712			RK73HB1J473J	CHIP R	47K	J	1/16W	R839			RK73EB2E100J	CHIP R	10	J	1/4W
R713			RK73HB1J223J	CHIP R	22K	J	1/16W	R842-844			RK73HB1J000J	CHIP R	0	J	1/16W
R716			RK73HB1J104J	CHIP R	100K	J	1/16W	R845			RK73HB1J101J	CHIP R	100	J	1/16W
R720			RK73HB1J334J	CHIP R	330K	J	1/16W	R846,847			RK73HB1J223J	CHIP R	22K	J	1/16W
R722			RK73HB1J104J	CHIP R	100K	J	1/16W	D2			DZ2J091(M)			ZENER DIODE	
R724			RK73HB1J473J	CHIP R	47K	J	1/16W	D3 ,4			1SV323F			VARIABLE CAPACITANCE DIODE	
R728			RK73HB1J393J	CHIP R	39K	J	1/16W	D7 -12			1SV282-F			VARIABLE CAPACITANCE DIODE	
R730			RK73HB1J473J	CHIP R	47K	J	1/16W	D13			1SV278F			VARIABLE CAPACITANCE DIODE	
R738			RK73HB1J103J	CHIP R	10K	J	1/16W	D14			DA2S101			DIODE	
R739			RK73HB1J334J	CHIP R	330K	J	1/16W	D16 ,17			RKS151KJ			DIODE	
R741			RK73HB1J470J	CHIP R	47	J	1/16W	D101			DZ2J056(M)			ZENER DIODE	
R742			RK73HB1J332J	CHIP R	3.3K	J	1/16W	D102			DA3S101F			DIODE	
R743			RK73HB1J471J	CHIP R	470	J	1/16W	D103			RKS151KJ			DIODE	
R745			RK73HB1J104J	CHIP R	100K	J	1/16W	D104,105			HSB88AS-E			DIODE	
R746			RK73HB1J103J	CHIP R	10K	J	1/16W							HGK2,HGK2	

# NX-820H(G)/820H

## PARTS LIST


TX-RX UNIT (X57-8240-XX)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation	Ref. No.	Address	New parts	Parts No.	Description	Desti-nation
D106			DZ2J056(M)	ZENER DIODE		IC705			BU7242NUX	MOS-IC	
D107			RKP351KW-1P2	DIODE		IC711			BU7462NUX	MOS-IC	
D108,109			RB520SM-30	DIODE		IC712			R2A20178NP	DAC IC	
D110,111			L407CDB	DIODE (50V/1W)		IC713			TC7W53FK(F)	MOS-IC	
D112-114			RN142S	DIODE		IC714	2A		LA4600	BI-POLAR IC	
D201-206			1SV278F	VARIABLE CAPACITANCE DIODE		IC716			TC7WT126FU-F	MOS-IC	
D401			DZ2J180(M)	ZENER DIODE		IC801			TC7WH126FU-F	MOS-IC	HGK,HGK2
D403			RB520SM-30	DIODE		Q1			LTC014EEBFS8	TRANSISTOR	
D404			DA2S101	DIODE		Q2			2SJ648-A	FET	
D405			DB2S310	DIODE		Q4			2SC5383-T111	TRANSISTOR	
D406			DB22306	DIODE		Q5 ,6			MCH3914(8)-H	FET	
D407			RB520SM-30	DIODE		Q8			EM6M1	FET	
D408,409			DB2S310	DIODE		Q9			SSM3J15FS	FET	
D410			22ZR-10D	SURGE ABSORBER		Q10 ,11			2SC5108(Y)F	TRANSISTOR	
D411			DSA3A1	DIODE		Q101			2SC3356-A(R24)	TRANSISTOR	
D502			DB2S310	DIODE		Q102			2SC3357-A	TRANSISTOR	
D504			DB2S310	DIODE		Q105			FK330301	FET	
D505-510			MC2850	DIODE		Q106			EMD5	TRANSISTOR	
D511-513			DB2S310	DIODE		Q201			3SK318	FET	
D601			DB2S310	DIODE		Q202			NESG240034	TRANSISTOR	
D701			DA2S101	DIODE		Q303			2SC5108(Y)F	TRANSISTOR	
D702			1SS422	DIODE		Q305			2SC4215-F(Y)	TRANSISTOR	
D703,704			DA3S101F	DIODE		Q401			LTC014EEBFS8	TRANSISTOR	
D705,706			EMZ6.8N	ZENER DIODE		Q402			2SA1955A-F	TRANSISTOR	
D801,802			RN142S	DIODE	HGK,HGK2	Q403			MTM981400BF	FET	
IC1			TA7808F-NQ	ANALOGUE IC		Q404			2SA1955A-F	TRANSISTOR	
IC2			SKY72310-362	MOS-IC		Q405			LTC014EEBFS8	TRANSISTOR	
IC3			BD7542FVM	MOS-IC		Q407			FK330301	FET	
IC102	2B		RA60H40471101	POWER MODULE	HGK2,HK2	Q408			EMD5	TRANSISTOR	
IC102	2B		RA60H44521101	POWER MODULE	HGK,HK	Q409			EM6M1	FET	
IC103			NJM12904RB1	MOS-IC		Q410			2SA1955A-F	TRANSISTOR	
IC201			BD7542FVM	MOS-IC		Q411,412			LTC014EEBFS8	TRANSISTOR	
IC301			TC7SH08FU-F	MOS-IC		Q414			EMD9	TRANSISTOR	
IC303			TK10931VTL-G	ANALOGUE IC		Q415			2SC4738(GR)F	TRANSISTOR	
IC304			BU7445HFV	MOS-IC		Q416			2SA1832(GR)F	TRANSISTOR	
IC401			XC6209B332M-G	MOS-IC		Q417			EMD5	TRANSISTOR	
IC402			XC6118C23CMR	MOS-IC		Q418			LTC014EEBFS8	TRANSISTOR	
IC404			XC6209B502P-G	MOS-IC		Q501			FK330301	FET	
IC405			LT1616ES6-PBF	ANALOGUE IC		Q502			LTC014TEBFS8	TRANSISTOR	
IC406			XC6209B332M-G	MOS-IC		Q503			MTM981400BF	FET	
IC407			NJM2878F4-33	BI-POLAR IC		Q504			LTC014TEBFS8	TRANSISTOR	
IC408			XCE205B152P-G	MOS-IC		Q701			FK330301	FET	
IC409			NJM2878F4-33	BI-POLAR IC		Q702			KTC4075E(Y,GR)	TRANSISTOR	
IC501			Note1(BGA)	ROM IC		Q703			2SA1832(GR)F	TRANSISTOR	
IC502			Note1(BGA)	ASIC		Q704			2SC4738(GR)F	TRANSISTOR	
IC503			Note1(BGA)	SRAM IC		Q705,706			SSM3J15FS	FET	
IC504			BD5329FVE	MOS-IC		Q708			LTC014EEBFS8	TRANSISTOR	
IC506			SM5023CNHDH-G	MOS-IC		Q709			SSM6N37FE	FET	
IC507			Note1(BGA)	MOS-IC		TH1			ERTJ0EV104H	THERMISTOR(100K)	
IC508			TC7SH08FU-F	MOS-IC		TH1 ,2			ERTJ0EV104H	THERMISTOR(100K)	HGK,HK2
IC509			TC7WH126FU-F	MOS-IC		TH101			ERTJ0EV104H	THERMISTOR(100K)	
IC511			TC74VHCT244AFK	MOS-IC		TH103			ERTJ0EV104H	THERMISTOR(100K)	
IC512			TC7WBD125AFK	MOS-IC		TH701			ERTJ0EV104H	THERMISTOR(100K)	
IC513			TC7WT126FU-F	MOS-IC		A801			W02-3768-05	GPS MODULE	HGK,HGK2
IC514			TC7WH126FU-F	MOS-IC							
IC515			PCA9535BS	MOS-IC							
IC516			ADM202EARNZ	MOS-IC							
IC701			BU7462NUX	MOS-IC							
IC702			BU7242NUX	MOS-IC							
IC703			BU7462NUX	MOS-IC							

If a part reference number is listed in a shaded box, that part does not come with the PCB.  
 Note 1: This part cannot be replaced. Therefore, this part is not supplied as a service part.

# NX-820H(G)/820H

## EXPLODED VIEW




Parts with the exploded numbers larger than 700 are not supplied.

If a part reference number is listed in a box on the exploded view of the PCB, that part does not come with the PCB.  
 These parts must be ordered separately.

# NX-820H(G)/820H

## PACKING



# NX-820H(G)/820H

## TROUBLE SHOOTING

### Fault Diagnosis of the BGA (Ball Grid Array) IC

#### ■ Overview

A flowchart for determining whether or not the transceiver can be powered on (the LCD does not function even if the power switch is turned on) due to broken BGA parts.

#### ■ BGA parts

ASIC (IC507), DSP (IC502), FLASH (IC501), SRAM (IC503)

When the BGA IC is problematic, please bring the printed circuit board (X57-8240-14 /-15 /-16 /-17) in for service. Various ESN/default adjustment values are written on the printed circuit board for service.

Additionally various ESN stickers are included.

After the printed circuit board has been readjusted, please attach any ESN stickers to the chassis. When "ESN Validation" is used with Trunking, you must modify the ESN register.

- Checking power supply voltage

Checking voltage	
Points to be checked	Normal voltage
33M IC401 (5 pin)	3.3V
15M IC408 (5 pin)	1.5V
33A IC406 (5 pin)	3.3V

Power supply of each device is connected through the coil.  
[ASIC]  
33M: L508, 15M: L510, 33A: R571  
[DSP]  
33M: L503, 15M: R505  
[FLASH]  
33M: L501  
[SRAM]  
33BU: L504

When an abnormal value is confirmed.

#### Checking for an abnormal point

33M has an abnormal voltage.  
[ASIC]  
Remove L508 to check the voltage of the 33M.  
If the voltage becomes normal, the ASIC is broken.  
[DSP]  
Remove L503 to check the voltage of the 33M.  
If the voltage becomes normal, the DSP is broken.  
[FLASH]  
Remove L501 to check the voltage of the 33M.  
If the voltage becomes normal, the FLASH is broken.  
[SRAM]  
Remove L504 to check the voltage of the 33M.  
If the voltage becomes normal, the SRAM is broken.

- Checking the clock

Checking the clock	
Points to be checked	Normal voltage (3.3V)
18.432MHz IC506 (4 pin)	18.432MHz

When an abnormal value is confirmed.

15M has an abnormal voltage.  
[ASIC]  
Remove L510 to check the voltage of the 15M.  
If the voltage becomes normal, the ASIC is broken.  
[DSP]  
Remove R505 to check the voltage of the 15M.  
If the voltage becomes normal, the DSP is broken.

- Checking the Reset/Control signal

Checking the control signal input to the ASIC	
Points to be checked	Normal voltage
RST (RESET) IC504 (1 pin)	3.3V
/BINT IC402 (1 pin)	3.3V
/OVRB D403 (Cathode side)	3.3V

When an abnormal value is confirmed.

Remove the R556 . If it oscillates normally, the DSP and ASIC may be broken.  
Remove the R501. If it oscillates normally, the DSP and ASIC may be broken.

- Checking the ASIC input switch signal  
The POWER key is pressed and held.

Points to be checked	Confirmed voltage
POWER R690	ON: 0V OFF: 3.3V
The ignition key is kept ON.	Confirmed voltage ON: 0V OFF: 3.3V

When an abnormal value is confirmed.

The BGA parts are not broken.  
Check the other point then BGA parts.

- Checking the output signal from the ASIC

Points to be checked	Normal voltage
/FRST R516	3.3V


When an abnormal value is confirmed.

If the /FRST is always 0V, the ASIC is broken.

If the /FRST repeats 3.3V and 0V at intervals, the ASIC, FLASH and SRAM may be broken.

# NX-820H(G)/820H

## TROUBLE SHOOTING



# NX-820H(G)/820H

## TROUBLE SHOOTING

### Failure diagnosis of the GPS section.(Built-in GPS model only)


Overview: When the GPS function does not operate, use this flowchart to determine the problem.

#### Note:

The transceiver supplies the voltage to the GPS antenna and the voltage is checked when the transceiver is turned "ON".

When the voltage is lower than the specified value, "G ANT FAIL" is displayed for 2 seconds before entering user mode.

(At this time, the expected defect of the GPS antenna is a short. This error message does not appear when the expected defect is an open.)



### Replacing TX-RX Unit

#### ■ TX-RX unit Information

Model Name	Frequency Range [MHz]	Original TX-RX unit Number	For Service TX-RX unit Number
NX-820H(G) (GPS model) : K	450 - 520	X57-8240-10	X57-8240-14
NX-820H : K	450 - 520	X57-8240-11	X57-8240-15
NX-820H(G) (GPS model) : K2	400 - 470	X57-8240-12	X57-8240-16
NX-820H : K2	400 - 470	X57-8240-13	X57-8240-17

# NX-820H(G)/820H

## TROUBLE SHOOTING

- Method of confirming "Original TX-RX unit" and "Service TX-RX unit"

### SUPPLIED ACCESSORIES


ESN Label .....	1
• KENWOOD ESN	
• NXDN ESN	
• MPT ESN	
Addendum (this pamphlet) .....	1

### PRINTED CIRCUIT BOARD DATA

The following data is written on the printed circuit board:

Data Type	Description
Firmware	NX-720/820 K type firmware
FPU Data (PC programming mode)	X57-823 : NX-720 Kx type data
	X57-824 : NX-820 Kx type data
Voice Language	English
Various Adjustment Data (PC Test mode)	General adjustment values for the X57-823 (NX-720), and X57-824 (NX-820).
KENWOOD ESN	<p>Model Name: • [X57-823] NX-720S • [X57-824] NX-820S</p> <p>Type : Kx</p> <p>The same number as the KENWOOD ESN label is written.</p>
NXDN ESN/ MPT ESN	The same number as the NXDN ESN/MPT ESN label is written.

### ATTACHING THE ESN LABEL



### AFTER CHANGING THE ESN

- After changing the printed circuit board, write the up-to-date Firmware following the instructions in the service manual.
  - Write the Firmware in accordance to the Market. If you write different Market Firmware, there are times communication with the FPU is not possible.
- Using the KPG-141D, select your desired item (Model Name and Frequency) from the Model > Product Information menu, then use Program > Write Data to the Transceiver to write the FPU data (PC Programming mode). When writing to the transceiver, a Warning Message, corresponding to the item selected, appears. Click [OK] to continue writing the data.
- Enter Program > Test Mode, then adjust the various adjustment data (PC Test mode) as described in the service manual.
- Attach the new labels corresponding to the new printed circuit board. (Refer to the images below for label placement.)
- If necessary, write the FPU data used by the customer with the KPG-141D.


#### Note:

- When using the ESN Validation function of Trunking, the ESN number changes when the circuit board is changed (the number is written on the circuit board); the Trunking system cannot be accessed. Maintain the ESN data of the Trunking System following the new ESN.
- When a new printed circuit board is used, the KENWOOD ESN changes, as does the Transceiver Information display of the KPG-141D, but this does not have any effect on the operation of the transceiver.
- If changing to the original ESN, please contact our service center.

# NX-820H(G)/820H

## ADJUSTMENT

### Controls



### ■ Key operation

Key	“—” not appears on the LCD display	
	Function	Display
[ $\wedge$ ]/[ $\vee$ ]	Test channel up/down	Channel No.
[ $\Delta$ ]	Push: Squelch level up Hold: Squelch off	Squelch level Squelch off:  icon appears
[ $\blacksquare$ ]	Wide/Narrow/Very narrow	Wide: "W" Narrow: "N" Very narrow: "V"
[ $\text{S}$ ]	Shift to panel tuning mode	-
[ $\text{A}$ ]	Function on	“—” appears on the LCD display
[ $<\text{B}$ ]	MSK 1200bps and 2400bps	2400bps:  icon appears
[ $\text{C}>$ ]	Push: Test signaling up Hold: Test signaling up continuously	Signaling No.
[ $\wedge$ ]/[ $\vee$ ]	Volume level up/down	
[PTT] (MIC)	Transmit	-
[0] to [9] and [ $\#$ ], [ $*$ ] (MIC)	Use as the DTMF keypad. If a key is pressed during transmission, the DTMF corresponding to the key that was pressed is sent.	-

Key	“—” appears on the LCD display	
	Function	Display
[ $\wedge$ ]	Function off	-
[ $\vee$ ]	Analog /NXDN	Analog: "A", NXDN: "N"
[ $\Delta$ ]	Function off	-
[ $\blacksquare$ ]	LCD all lights	LCD all point appears
[ $\text{S}$ ]	High /Mid /Low power	High: icon not appears Mid: “—” icon appears Low: “—” icon appears
[ $\text{A}$ ]	Function off	-
[ $<\text{B}$ ]	Comander on/off	On:  icon appears
[ $\text{C}>$ ]	Beat shift on/off	On:  icon appears
[ $\wedge$ ]/[ $\vee$ ]	Volume level up/down	
[PTT] (MIC)	Transmit	-
[0] to [9] and [ $\#$ ], [ $*$ ] (MIC)	Function off	-

### ■ Preparations for checking/tuning the transceiver

Before attempting to check/tune the transceiver, connect the unit to a suitable power supply.

Whenever the transmitter is turned on, the unit must be connected to a suitable dummy load (i.e. power meter).

The speaker output connector must be terminated with a  $4\Omega$  dummy load and connected to an AC voltmeter and an audio distortion meter or a SINAD measurement meter at all times during checking/tuning.

### Panel Test Mode

#### ■ Test mode operation features

This transceiver has a test mode. To enter test mode, press and hold the [ $\text{A}$ ] key while turning the transceiver power ON. Before the transceiver enters test mode, the frequency version information appears on the LCD momentarily. Test mode can be inhibited by programming. To exit test mode, turn the transceiver power OFF. The following functions are available in test mode.

# NX-820H(G)/820H

## ADJUSTMENT

### • LED indicator

Red LED      Lights during transmission.  
Green LED      Lights when there is carrier.


### • LCD display in panel test mode

(Power ON)



Market code

Frequency range  
"UHF F1": 450~520MHz  
"UHF F2": 400~470MHz




(After 2sec.)

Function

Low power

### • Test frequency

CH	K		K2	
	RX (MHz)	TX (MHz)	RX (MHz)	TX (MHz)
1	485.05000	485.10000	435.05000	435.10000
2	450.05000	450.10000	400.05000	400.10000
3	519.95000	519.90000	469.95000	469.90000
4	485.00000	485.00000	435.00000	435.00000
5	485.20000	485.20000	435.20000	435.20000
6	485.40000	485.40000	435.40000	435.40000
7~16	-	-	-	-



Squelch level

Signaling No.

Channel No.

AW : Analog wide mode

AN : Analog narrow mode

NN : NXDN narrow mode

NV : NXDN very narrow mode

### • Analog mode signaling

No.	RX	TX
1	None	None
2	None	100Hz Square Wave
3	LTR Data: AREA=0, GOTO=12 HOME=12 ID=47, FREE=25	LTR Data: AREA=0, GOTO=12 HOME=12 ID=47, FREE=25
4	QT: 67.0Hz	QT: 67.0Hz
5	QT: 151.4Hz	QT: 151.4Hz
6	QT: 210.7Hz	QT: 210.7Hz
7	QT: 254.1Hz	QT: 254.1Hz
8	DQT: D023N	DQT: D023N
9	DQT: D754I	DQT: D754I
10	DTMF: 159D	DTMF: 159D
11	None	DTMF Code 9
12	2-tone: A: 304.7Hz, B: 3106.0Hz	2-tone: A: 304.7Hz, B: 3106.0Hz
13	Single Tone: 979.9Hz	Single Tone: 979.9Hz
14	None	Single Tone: 1000Hz
15	None	MSK
16	MSK	MSK

# NX-820H(G)/820H

## ADJUSTMENT

### • NXDN mode signaling

No.	RX	TX
1	RAN1	RAN1
2	None	PN9
3	RAN1	Maximum deviation pattern
7	None	FSW+PN9 (PC test mode only)

RAN: Radio Access Number

PN9: Pseudo-Random Pattern (for production only)


### Panel Tuning Mode

#### ■ Transceiver tuning (To enter tuning mode)

To enter tuning mode, press the [S] key while the transceiver is in test mode. Use the [**<B>**] key to write tuning data through tuning modes, and the [**▲/▼**] to adjust tuning requirements (1 to 4096 appears on the LCD).

Use the [**C>**] key to select the adjustment item through tuning modes. Use the [**A**] key to adjust 5 reference level adjustments, and use the [**■**] key to switch between Wide/Narrow/Very narrow.

#### • LCD display in panel tuning mode



### ■ Key operation

Key	Function	
	Push	Hold (1 second)
[ <b>▲/▼</b> ]	Adjustment value up/down	
[ <b>△</b> ]	20Hz/2kHz (During transmission in balance adjustment)	-
[ <b>■</b> ]	Wide/Narrow/Very narrow	-
[ <b>S</b> ]	Shift to panel test mode	-
[ <b>A</b> ]	To enter 5 reference level adjustments	-
[ <b>&lt;B&gt;</b> ]	Writes the adjustment value	-
[ <b>C&gt;</b> ]	Go to next adjustment item	Back to last adjustment item
[ <b>^/▼</b> ]	Volume level up/down	
[PTT]	Transmit	
[0] to [9] and [#, [*]	-	

### ■ 5 reference level adjustments frequency

Tuning point	K		K2	
	RX (MHz)	TX (MHz)	RX (MHz)	TX (MHz)
Low	450.05000	450.10000	400.05000	400.10000
Low'	467.55000	467.60000	417.55000	417.60000
Center	485.05000	485.10000	435.05000	435.10000
High'	502.55000	502.60000	452.55000	452.60000
High	519.95000	519.90000	469.95000	469.90000

### ■ 9 reference level adjustments frequency

Tuning point	K		K2	
	RX (MHz)	TX (MHz)	RX (MHz)	TX (MHz)
Low1	450.05000	450.10000	400.05000	400.10000
Low2	458.80000	458.85000	408.80000	408.85000
Low3	467.55000	467.60000	417.55000	417.60000
Center1	478.30000	478.35000	426.30000	426.35000
Center2	485.05000	485.10000	435.05000	435.10000
Center3	493.80000	493.85000	443.80000	443.85000
High1	502.55000	502.60000	452.55000	452.60000
High2	511.30000	511.35000	461.30000	461.35000
High3	519.95000	519.90000	469.95000	469.90000

Note: This table can be adjusted only in PC Test Mode.

# NX-820H(G)/820H

## ADJUSTMENT

### ■ Adjustment item supplement

Adjustment Item	Description
Receive Assist	The lock voltage of VCO (Receive) is adjusted. This item must be adjusted before all adjustment items for receiver section are adjusted. This item can be adjusted only in PC Test Mode.
Transmit Assist	The lock voltage of VCO (Transmit) is adjusted. This item must be adjusted before all adjustment items for transmitter section are adjusted. This item can be adjusted only in PC Test Mode.
Frequency	Frequency stability is adjusted under receiving condition with SSG. The SSG needs 0.001ppm accuracy so please use a standard oscillator if necessary. This item can be adjusted only in PC Test Mode so that the adjustment value is not changed easily.
High Transmit Power Limit	High Transmit Power Limit is adjusted.
Mid Transmit Power Limit	Mid Transmit Power Limit is adjusted.
Low Transmit Power Limit	Low Transmit Power Limit is adjusted.
High Transmit Power	High Transmit Power is adjusted.
Mid Transmit Power	Mid Transmit Power is adjusted.
Low Transmit Power	Low Transmit Power is adjusted.
Balance	The transmit audio frequency response is adjusted. This item is adjusted so that the deviation of 2kHz becomes the same deviation of 20Hz. This item must be adjusted before all adjustment items for deviations are adjusted.
Maximum Deviation (NXDN Narrow/Very Narrow)	Maximum Deviation of NXDN (Narrow/Very Narrow) is adjusted.
Maximum Deviation (Analog Wide/Narrow)	Maximum Deviation of Analog (Wide/Narrow) is adjusted. This item must be adjusted before all adjustment items for tone deviations are adjusted. Note: "Maximum Deviation (Analog Narrow)" must be adjusted before "CW ID Deviation (NXDN Very Narrow)" is adjusted.
QT Deviation	QT tone deviation is adjusted.
DQT Deviation	DQT tone deviation is adjusted.
LTR Deviation	LTR tone deviation is adjusted.
DTMF Deviation	DTMF tone deviation is adjusted.
Single Tone Deviation	The deviation of Single Tone used in "2-tone" is adjusted.
MSK Deviation	MSK tone deviation is adjusted.
CW ID Deviation	CW ID tone deviation is adjusted. CW ID is used to inform the others who is transmitting on a 6.25 kHz spacing channel. (In FCC rule, Analog mode or CW ID is required for each channel-spacing.)
Sensitivity 1	Band-Pass Filter is adjusted. The performance of Receive Sensitivity and unwanted signal rejection are improved. This item can be adjusted only in PC Test Mode.
Sensitivity 2	Band-Pass Filter is adjusted. The performance of Receive Sensitivity and unwanted signal rejection are improved. This item can be adjusted only in PC Test Mode.
RSSI Reference	The minimum RSSI level for scan stop is adjusted.
Open Squelch	The squelch level at level "5" is adjusted.
Low RSSI	RSSI display level "Y" is adjusted. Both "Low RSSI" and "High RSSI" must be adjusted.
High RSSI	(The curve data of RSSI level is applied.)
Tight Squelch	The squelch level at level "9" is adjusted.

# NX-820H(G)/820H

## ADJUSTMENT

### ■ Adjustment item and Adjustment range

Order	Adjustment item	Panel tuning	PC test	AW (Analog Wide)	AN (Analog Narrow)	NN (NXDN Narrow)	NV (NXDN Very Narrow)	Adjust item Number	
				Adjustment range					
1	Receive Assist		✓	9 point ADJ					
				1~4096					
2	Transmit Assist		✓	9 point ADJ					
				1~4096					
3	Frequency		✓	1 point ADJ					
				1~4096					
4	High Transmit Power Limit		✓	✓	-	5	-	-	
					1~256				
5	Mid Transmit Power Limit		✓	✓	-	5	-	-	
					1~256				
6	Low Transmit Power Limit		✓	✓	-	5	-	-	
					1~256				
7	High Transmit Power		✓	✓	-	5	-	-	
					1~1024				
8	Mid Transmit Power		✓	✓	-	5	-	-	
					1~1024				
9	Low Transmit Power		✓	✓	-	5	-	-	
					1~1024				
10	Balance		✓	✓	-	5	-	-	
					1~1024				
11	Maximum Deviation (NXDN)		✓	✓	-	-	5	5	
					1~1024				
12	Maximum Deviation (Analog)		✓	✓	5	5	-	-	
					1~1024				
13	QT Deviation		✓	✓	1	1	-	-	
					1~1024				
14	DQT Deviation		✓	✓	1	1	-	-	
					1~1024				
15	LTR Deviation		✓	✓	1	1	-	-	
					1~1024				
16	DTMF Deviation		✓	✓	1	1	-	-	
					1~1024				
17	Single Tone Deviation		✓	✓	1	1	-	-	
					1~1024				
18	MSK Deviation		✓	✓	1	1	-	-	
					1~1024				
19	CW ID Deviation		✓	✓	-	-	-	1	
					1~1024				
20	Sensitivity 1		✓	✓	-	5	-	-	
					1~256				
21	Sensitivity 2		✓	✓	-	5	-	-	
					1~256				

# NX-820H(G)/820H


## ADJUSTMENT

Order	Adjustment item	Panel tuning	PC test	AW (Analog Wide)	AN (Analog Narrow)	NN (NXDN Narrow)	NV (NXDN Very Narrow)	Adjust item Number
				Adjustment range				
22	RSSI Reference	✓	✓	5	5	- *1	5	Receiver Section 4
				1~256				
23	Open Squelch	✓	✓	5	5	- *1	5	Receiver Section 5
				1~256				
24	Low RSSI	✓	✓	5	5	- *1	5	Receiver Section 6
				1~256				
25	High RSSI	✓	✓	5	5	- *1	5	Receiver Section 7
				1~256				
26	Tight Squelch	✓	✓	5	5	-	-	Receiver Section 8
				1~256				

\*1: Because NXDN Narrow is adjusted by adjusting Analog Narrow, it is not necessary to adjust NXDN Narrow.


### ■ Panel tuning mode flow chart

Note: In this Panel tuning mode flow chart, the Adjustment item name is modified.



# NX-820H(G)/820H

## ADJUSTMENT




# NX-820H(G)/820H

## ADJUSTMENT

### Test Equipment Required for Alignment


Test Equipment	Major Specifications	
1. Standard Signal Generator (SSG)	Frequency Range Modulation Output When performing the Frequency adjustment, the following accuracy is necessary. • 0.001ppm Use a standard oscillator for adjustments, if necessary.	100 to 520MHz Frequency modulation and external modulation –127dBm/0.1µV to greater than –20dBm/22.4mV
2. Power Meter	Input Impedance Operation Frequency Measurement Capability	50Ω 100 to 520MHz Vicinity of 100W
3. Deviation Meter	Frequency Range	100 to 520MHz
4. Digital Volt Meter (DVM)	Measuring Range Input Impedance	10mV to 20V DC High input impedance for minimum circuit loading
5. Oscilloscope		DC through 30MHz
6. High Sensitivity Frequency Counter	Frequency Range Frequency Stability	10Hz to 1000MHz 0.01ppm or less
7. Ammeter		20A or more
8. AF Volt Meter (AF VM)	Frequency Range Voltage Range	50Hz to 10kHz 1mV to 10V
9. Audio Generator (AG)	Frequency Range Output	50Hz to 5kHz or more 0 to 1V
10. Distortion Meter	Capability Input Level	3% or less at 1kHz 50mV to 10Vrms
11. 4Ω Dummy Load		Approx. 4Ω, 10W
12. Regulated Power Supply		13.6V, approx.20A (adjustable from 9V to 17V) Useful if ammeter equipped
13. Spectrum Analyzer	Frequency Range Input Level Input Sensitivity Resolution Bandwidth Video Bandwidth	40MHz to 520MHz Up to +20dBm –100dBm 100Hz 100Hz
14. Tracking Generator	Frequency Range Output Level	40MHz to 520MHz –30dBm to 0dBm

### ■ Test cable for microphone input (E30-3360-28)



### ■ Tuning cable (E30-3383-05)

Adapter cable (E30-3383-05) is required for injecting an audio if PC tuning is used.  
See "PC Mode" section for the connection.



### ■ MIC connector (Front panel view)



# NX-820H(G)/820H

## ADJUSTMENT

### Radio check Section

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Frequency check	1) CH-Sig : 1-1 PTT : ON	1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.	f. counter		ANT				Check an internal temperature of radio from 20°C to 26°C.  +/-0.25ppm +/-121Hz:K +/-108Hz:K2 @485.1MHz:K @435.1MHz:K2
2. High power check	1) CH-Sig : 1-1 PTT : ON	1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.	Power meter Ammeter					Check	40.0W~50.0W(UHF) 13A or less
	2) CH-Sig : 2-1 PTT : ON	2) Test Channel Channel: 2 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3) CH-Sig : 3-1 PTT : ON	3) Test Channel Channel: 3 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.							
3. Low power check	1) CH-Sig : 1-1 PTT : ON	1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.						3.5W~6.5W 7A or less	
	2) CH-Sig : 2-1 PTT : ON	2) Test Channel Channel: 2 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.							
	3) CH-Sig : 3-1 PTT : ON	3) Test Channel Channel: 3 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button.							
4. MIC sensitivity check	1) CH-Sig: 1-1 AG: 1kHz PTT: ON	1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 AG: 1kHz PTT: Press [Transmit] button.	Deviation meter Oscilloscope AG AF VTVM					Adjust AG input to get a standard MOD.	Dev 3.0kHz at 5mV±1.0mV

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
5. Sensitivity check	1) CH-Sig: 1-1 SSG output Wide 5k: -117dBm (0.32μV) (MOD: 1kHz/±3kHz)  Narrow: -117dBm (0.32μV) (MOD: 1kHz/±1.5kHz)	1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1  SSG output Wide 5k: -116dBm (0.35μV) (MOD: 1kHz/±3kHz)  Narrow: -115dBm (0.40μV) (MOD: 1kHz/±1.5kHz)	SSG AF VTVM Oscilloscope Distortion meter 4ohm Dummy load		ANT Ext.SP connector			Check	12dB SINAD or more

### Common Section

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. Setting	1) DC voltage:13.6V 2) SSG standard modulation [Wide] MOD:1kHz,DEV:3kHz [Narrow] MOD:1kHz,DEV:1.5kHz								
2. Receive Assist	*This adjustment can be performed only PC test mode.	1) Adj item: [Receive Assist] 2) Adj item: [Low1],[Low2], [Low3],[Center1], [Center2], [Center3 ],[High1],[High2],[High3]  Press [Apply All] button to store the adjustment value.				[PC test mode] [◀],[▶]	[PC test mode] [Automatic Adjustment ] Press [ Tune Assist Voltage ] button. Press [ Apply All ] button to store the adjustment value after the automatic adjustment has finished. [ Manual Adjustment ] [ V ] indicator on the PC window shows VCO lock voltage. Change the adjustment value to get VCO lock voltage within the limit of the specified voltage.	2.5V±0.1V  [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted.  Check! The assist adjustment value must be between from 340 to 3550.	
3. Transmit Assist	*This adjustment can be performed only PC test mode.	1) Adj item: [Transmit Assist] 2) Adj item: [Low1],[Low2], [Low3],[Center1], [Center2], [Center3 ],[High1],[High2],[High3]  PTT: Press [Transmit] button.  Press [Apply All] button to store the adjustment value.					Note: Confirm the VCO lock voltage approximately 3 seconds after the adjustment value is changed.		

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/Remarks
			Test-equipment	Unit	Ter-minal	Unit	Parts	Method	
4. Frequency	* The Frequency adjustment can be performed only in PC test mode.	<p>1) Adj item:            [Frequency]            SSG output            :-20dBm (22.4mV)            (CW (without modulation))            Caution:            Perform the frequency adjustment under the following conditions.</p> <ul style="list-style-type: none"> <li>• Temperature range of +20°C to +26°C (+68.0°F to +78.8°F). (The temperature is displayed on the Frequency adjustment screen of the KPG-141D and the LCD of the transceiver.)</li> <li>• Use an accuracy of 0.003ppm for the SSG. (Use a standard oscillator if necessary.)</li> </ul>	SSG		ANT				<p>[PC test mode]            Press [Start] button of "Auto Tuning". Press [Apply] button to store the adjustment value after the automatic adjustment was finished.</p> <p>Remark:            "Frequency" is adjusted under receiving condition with SSG.</p>

# NX-820H(G)/820H

## ADJUSTMENT

### Transmitter Section

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test- equipment	Unit	Termini- nal	Unit	Parts	Method	
1. High Transmit power Limit	1) Adj item: <b>[HLMT]</b> Adjust:[****] 2) Adj item: <b>[H.L.MT_]</b> → <b>[H.L.MT_]</b> → <b>[H.L.M.T_]</b> → <b>[H.L.M.T_]</b> → <b>[H.L.M.T_]</b> → 3) PTT : ON 4) Press [ <b>&lt;B</b> ] key to store the adjustment value	1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit Press [Apply All] button to store the adjustment value.	Power meter Ammeter	ANT		[Panel tuning mode]  [PC test mode] 	48.0W	±2.0W	
Mid Transmit power Limit	1) Adj item: <b>[MLMT]</b> Adjust:[****] 2) Adj item: <b>[M.L.MT_]</b> → <b>[M.L.MT_]</b> → <b>[M.L.M.T_]</b> → <b>[M.L.M.T_]</b> → <b>[M.L.M.T_]</b> → 3) PTT : ON 4) Press [ <b>&lt;B</b> ] key to store the adjustment value	1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit Press [Apply All] button to store the adjustment value.					33.0W		
Low Transmit power Limit	1) Adj item: <b>[LLMT]</b> Adjust:[****] 2) Adj item: <b>[L.L.MT_]</b> → <b>[L.L.MT_]</b> → <b>[L.L.M.T_]</b> → <b>[L.L.M.T_]</b> → <b>[L.L.M.T_]</b> → 3) PTT : ON 4) Press [ <b>&lt;B</b> ] key to store the adjustment value	1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit Press [Apply All] button to store the adjustment value.					10W		

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
2.High Transmit Power	1) Adj item: [HPWR] Adjust:[****] 2) Adj item: [H.PWR_] → [H.P.WR_] → [H.P.W.R_] → [H.P.W.R._] → [H.P.W.R._.] → 3) PTT : ON 4) Press [ <b>B</b> ] key to store the adjustment value	1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit  Press [Apply All] button to store the adjustment value.	Power meter Ammeter	ANT	[Panel tuning mode]  [PC test mode] 	45.0W	±1.0W 13.0A or less	[PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted.	
Mid Transmit power	1) Adj item: [MPWR] Adjust:[****] 2) Adj item: [M.PWR_] → [M.P.WR_] → [M.P.W.R_] → [M.P.W.R._] → [M.P.W.R._.] → 3) PTT : ON 4) Press [ <b>B</b> ] key to store the adjustment value	1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit  Press [Apply All] button to store the adjustment value.							
Low Transmit power	1) Adj item: [LPWR] Adjust:[****] 2) Adj item: [L.PWR_] → [L.P.WR_] → [L.P.W.R_] → [L.P.W.R._] → [L.P.W.R._.] → 3) PTT : ON 4) Press [ <b>B</b> ] key to store the adjustment value	1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit  Press [Apply All] button to store the adjustment value.							
3. Balance adjust	1) Adj item:[BAL] Adjust:[***] Deviation meter LPF : 3kHz HPF : OFF 2) Adj item: [B.AL_] [B.A.L_] [B.A.L._] [B.A.L._.] [B.A.L._.]	1) Adj item: [Balance] Deviation meter LPF : 3kHz HPF : OFF 2) Adj item: [Low], [Low'], [Center], [High'], [High]  PTT: Press [Transmit] button.  Press [Apply All] button to store the adjustment value. [2kHz Sine Wave Check box]: Check while transmitting change to 2kHz.	Deviation meter Oscilloscope	ANT	[Panel tuning mode]  [PC test mode] 	The Deviation of 20Hz frequency is fixed. Change the 2kHz adjustment value to become the same deviation of 20Hz within the specified range.	2kHz Tone deviation is within ±1.0% of 20Hz tone deviation.	[PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted.	

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
4. Maximum Deviation (NXDN) adjust	Adj item: [NDEV] Adjust:[****.] Deviation meter LPF : 3kHz HPF : OFF  PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [Maximum Deviation (NXDN Narrow)] Deviation meter LPF: 3kHz HPF: OFF  PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value.	Deviation meter Oscilloscope				[Panel tuning mode] [◀],[▶]  [PC test mode] [◀],[▶]	Write fixed value "513" for each adjustment point. Transmit at each adjustment point and check that the Analog deviation is between 2995Hz and 3117Hz.  Deviation meter LPF: 3kHz HPF: OFF  [Panel tuning mode] PTT: ON  [PC test mode] PTT: Press [Transmit] button	2995~3117Hz  [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted.
[Very Narrow]	Adj item: [NDEV] Adjust:[****]  PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [Maximum Deviation (NXDN Very Narrow)]  PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value.						Write fixed value "513" for each adjustment point. Transmit at each adjustment point and check that the Analog deviation is between 1331Hz and 1363Hz.  Deviation meter LPF: 3kHz HPF: OFF  [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	1311~1363Hz  [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted.

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
5. Maximum Deviation (Analog) adjust [Narrow]	Adj item: [ADEV] Adjust:[****.] Deviation meter LPF : 15kHz HPF : OFF  PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [Maximum Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value.	Deviation meter Oscilloscope	ANT		[Panel tuning mode] [,]  [PC test mode] [,]	Write fixed value "513" for each adjustment point. Transmit at each adjustment point and check that the Analog deviation is between 2050Hz and 2150Hz. Deviation meter LPF: 15kHz HPF: OFF [Panel tuning mode] PTT: ON [PC test mode] PTT: Press [Transmit] button	2050~2150Hz  [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted.	
	[Wide]	Adj item: [ ADEV] Adjust:[**.*.*.]  PTT : ON Press [ <b>B</b> ] key to store the adjustment value.							
6. QT Deviation adjust [Narrow]	1) Adj item:[QT] Adjust:[****.] Deviation meter LPF : 3kHz HPF : OFF  PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [QT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	ANT		[Panel tuning mode] [,]  [PC test mode] [,]	Write the value 513 (Reference value)	0.35kHz±0.05kHz	
	[Wide]	1) Adj item:[QT] Adjust:[**.*.*.]  PTT : ON Press [ <b>B</b> ] key to store the adjustment value.							

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
7. DQT Deviation adjust [Narrow]	1) Adj item:[DQT] Adjust:[****.] Deviation meter LPF : 3kHz HPF : OFF  PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscillo-scope	ANT		[Panel tuning mode] [,]  [PC test mode] [,]	Write the value 430 (Reference value)		0.35kHz±0.05kHz
[Wide]	1) Adj item:[DQT] Adjust:[**.*.*.]  PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [DQT Deviation (Analog Wide)] PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.				[Panel tuning mode] [,]  [PC test mode] [,]	Write the value 430 (Reference value)		0.75kHz±0.05kHz
8. LTR Deviation adjust [Narrow]	1) Adj item:[LTR] Adjust:[****.] Deviation meter LPF : 3kHz HPF : OFF PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscillo-scope	ANT		[Panel tuning mode] [,]  [PC test mode] [,]	Write the value 465 (Reference value)		0.75kHz±0.05kHz
[Wide]	1) Adj item:[LTR] Adjust:[**.*.*.] PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [LTR Deviation (Analog Wide)] PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.				[Panel tuning mode] [,]  [PC test mode] [,]	Write the value 465 (Reference value)		1.00kHz±0.05kHz
9. DTMF Deviation adjust [Narrow]	Adj item: [DTMF] Adjust:[****.] Deviation meter LPF : 15kHz HPF : OFF PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscillo-scope	ANT		[Panel tuning mode] [,]  [PC test mode] [,]	Write the value 648 (Reference value)		1.5kHz±0.05kHz
[Wide]	Adj item: [DTMF] Adjust:[**.*.*.] PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [DTMF Deviation (Analog Wide)] PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.				[Panel tuning mode] [,]  [PC test mode] [,]	Write the value 648 (Reference value)		3.0kHz±0.05kHz

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
10. Single TONE Deviation adjust [Narrow]	Adj item: [TONE] Adjust:[****.] Deviation meter LPF : 15kHz HPF : OFF PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [Single Tone Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	ANT		[Panel tuning mode] [,] [PC test mode] [,]	Write the value 513 (Reference value)	1.50kHz±0.05kHz	
11. MSK Deviation adjust [Narrow]	1) Adj item:[MSK] Adjust:[****.] Deviation meter LPF : 15kHz HPF : OFF PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	ANT		[Panel tuning mode] [,] [PC test mode] [,]	Write the value 513 (Reference value)	1.50kHz±0.05kHz	
[Wide]	1) Adj item:[MSK] Adjust:[**.*.*.] PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [MSK Deviation (Analog Wide)] PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.				[Panel tuning mode] [,] [PC test mode] [,]	Write the value 513 (Reference value)	3.00kHz±0.05kHz	
12. CWID Deviation adjust [Very Narrow]	Adj item: [CVID] Adjust:[****] Deviation meter LPF : 15kHz HPF : OFF PTT : ON Press [ <b>B</b> ] key to store the adjustment value.	1) Adj item: [CW ID Deviation (NXDN Very Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value.	Deviation meter Oscilloscope	ANT		[Panel tuning mode] [,] [PC test mode] [,]	Write the value 376(Reference value)	1.00kHz±0.10kHz	

# NX-820H(G)/820H

## ADJUSTMENT

\*3 Necessary Deviation adjustment item for each signaling and mode

The following shows the necessary adjustment items for each signaling deviation. Please read the following table like the following example. In the case of the signaling "QT (Wide 5k)", this signaling is composed of three elements [Balance, Maximum Deviation (Analog Wide 5k) and QT Deviation (Wide 5k)]. Please adjust Balance and Maximum Deviation (Analog Wide 5k) before adjusting QT Deviation (Wide 5k).

Mode	Signaling	Necessary adjustment and order		
		Wide	Narrow	Very Narrow
Analog	Audio	1. Balance adjust 2. Maximum Deviation adjust [Wide]	1. Balance adjust 2. Maximum Deviation adjust [Narrow]	-
	QT	1. Balance adjust 2. Maximum Deviation adjust [Wide] 3. QT Deviation adjust [Wide]	1. Balance adjust 2. Maximum Deviation adjust [Narrow] 3. QT Deviation adjust [Narrow]	-
	DQT	1. Balance adjust 2. Maximum Deviation adjust [Wide] 3. DQT Deviation adjust [Wide]	1. Balance adjust 2. Maximum Deviation adjust [Narrow] 3. DQT Deviation adjust [Narrow]	-
	LTR	1. Balance adjust 2. Maximum Deviation adjust [Wide] 3. LTR Deviation adjust [Wide]	1. Balance adjust 2. Maximum Deviation adjust [Narrow] 3. LTR Deviation adjust [Narrow]	-
	DTMF	1. Balance adjust 2. Maximum Deviation adjust [Wide] 3. DTMF Deviation adjust [Wide]	1. Balance adjust 2. Maximum Deviation adjust [Narrow] 3. DTMF Deviation adjust [Narrow]	-
	2TONE	1. Balance adjust 2. Maximum Deviation adjust [Wide] 3. Single TONE Deviation adjust [Wide]	1. Balance adjust 2. Maximum Deviation adjust [Narrow] 3. Single TONE Deviation adjust [Narrow]	-
	MSK (Fleet sync)	1. Balance adjust 2. Maximum Deviation adjust [Wide] 3. MSK Deviation adjust [Wide]	1. Balance adjust 2. Maximum Deviation adjust [Narrow] 3. MSK Deviation adjust [Narrow]	-
NXDN	Audio	-	1. Balance adjust 2. Maximum Deviation [NXDN Narrow]	1. Balance adjust 2. Maximum Deviation adjust [NXDN Very Narrow]
	CWID	-	-	1. Balance adjust 2. Maximum Deviation [Analog Narrow] 3. CWID Deviation adjust [Very Narrow]

### Receiver Section

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
1.AF level setting	[Panel test mode] 1) CH-Sig: 1-1 SSG output: -47dBm (1mV) (MOD: 1kHz/±1.5kHz) Wide 5k/Narrow: Narrow Beat Shift: Uncheck Comander: Uncheck	1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 Wide 5k/Narrow: Narrow Beat Shift: Uncheck Comander: Uncheck SSG output: -47dBm (1mV) (MOD: 1kHz/±1.5kHz)	SSG DVM AF VTVM 4ohm Dummy load	ANT Ext.SP connector		[Panel tuning mode] [],[] [PC test mode] [],[]	Volume Up/Down Knob to obtain 2.83V AF output. (2.0W @ 4ohm load)	2.83V±0.3V  ( Volume Button in PC test mode screen)	

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test- equipment	Unit	Terminal	Unit	Parts	Method	
2. Sensitivity 1 adjust	*This adjustment can be performed only PC test mode.	1) Adj item: [Sensitivity 1]  2) Adj item: [Low], [Low'], [Center], [High'], [High] Press [Apply All] button to store the adjustment value.	SSG AF VTVM 4ohm Dummy load	ANT Ext.SP connector		[PC test mode] [◀],[▶]	Write the value as followings :K [L SENS1] / [Low]: 30 (Fixed) [L' SENS1] / [Low']: 96 (Fixed) [C SENS1] / [Center]: 134 (Fixed) [H' SENS1] / [High']: 167 (Fixed) [H SENS1] / [High]: 200 (Preset) :K2 [L SENS1] / [Low]: 34 (Preset) [L' SENS1] / [Low']: 75 (Preset) [C SENS1] / [Center]: 117 (Fixed) [H' SENS1] / [High']: 155 (Fixed) [H SENS1] / [High]: 192 (Fixed)		
3. Sensitivity2 adjust	*This adjustment can be performed only PC test mode.	1) Adj item: [Sensitivity 2]  2) Adj item: [Low], [Low'], [Center], [High'], [High]  Press [Apply All] button to store the adjustment value.	SSG AF VTVM 4ohm Dummy load	ANT Ext.SP connector		[PC test mode] [◀],[▶]	Write the value as follows :K [L SENS2] / [Low] : 80 (Preset) [L' SENS2] / [Low'] : 119 (Preset) [C SENS2] / [Center] : 158(Preset) [H' SENS2] / [High'] : 190(Preset) [H SENS2] / [High] : 225(Preset) :K2 [L SENS2] / [Low] : 59 (Preset) [L' SENS2] / [Low'] : 98 (Preset) [C SENS2] / [Center] : 137 (Preset) [H' SENS2] / [High'] : 179 (Preset) [H SENS2] / [High] : 209 (Preset)	[Readjustment method 1] If the sensitivity is less than -118.5dBm, decrease the digit of [O SENS2] (each channel), to get 12dB SINAD. SSG output : -118.5dBm(0.266uV) (Mod: 1kHz / ±1.5kHz) [Readjustment method 2:K] If the sensitivity is still NG for fH by using method 1, change the digit of [H SENS2] from 225 to 240, and carry out the automatic ad- justment for [H SENS1]. SSG output : -90dBm (Mod: 1kHz / ±1.5kHz) and then, decrease the digit of [H SENS2] to get 12dB SINAD. SSG output : -118.5dBm(0.266uV) (Mod: 1kHz / ±1.5kHz) [Readjustment method 2:K] If the sensitivity is still NG for fL & fL' by using method 1, change the digit as follows. [L SENS1] : 34 → 54 [L' SENS1]:75 → 95 [L SENS2] : 59 → 69 [L' SENS2] : 98 → 108 And then, decrease the digit of [L SENS1] & [L' SENS1] to get 12dB SINAD. SSG output : -118.5dBm(0.266uV) (Mod: 1kHz / ±1.5kHz)	

# NX-820H(G)/820H

## ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test-equipment	Unit	Terminal	Unit	Parts	Method	
4. RSSI reference adjust	1) Adj item: [RSSI] Adjust:[***] 2) Adj item: [R.RSS] [R.R.SS] [R.R.S.S] [R.R.S.S.] [R.R.S.S._.] SSG output:12dB SINAD level -3dB (MOD:1kHz/±1.5kHz)	1) Adj item: [RSSI Reference (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz)	SSG Distortion meter Oscilloscope	ANT Ext.SP connector		[PC test mode] [◀],[▶]	[Panel tuning mode] After input signal from SSG, press [ <b>B</b> ] key to store the adjustment value.  [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value.	Note: Wide, very narrow (NVDN) values are same value as narrow.	
5.Squelch (Squelch level 5 adjust) [Analog Narrow]	*This adjustment can be performed only PC test mode.	1) Adj item: [Open Squelch (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] Press [Apply] button to store the adjustment value.	SSG Distortion meter Oscilloscope	ANT Ext.SP connector	[PC test mode] [◀],[▶]	Write the value as followings , · Analog Narrow, Wide [S.QL] → 138 [S.Q.L] → 138 [S.Q.L.] → 138 [S.Q.L._.] → 138 [S.Q.L._._.] → 138			
[Analog Wide]		1) Adj item: [Open Squelch (Analog Wide)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] Press [Apply] button to store the adjustment value.							
[NXDN Very Narrow]		1) Adj item: [Open squelch (NXDN Very Narrow)] 2) Adj item: [Low],[Low'], [Center],[High'], [High] Press [Apply] button to store the adjustment value.					· NXDN very Narrow [S.QL] → 171 [S.Q.L] → 171 [S.Q.L.] → 171 [S.Q.L._.] → 171 [S.Q.L._._.] → 171		
6. Low RSSI at -118dBm adjust	1) Adj item: [LRSS] Adjust:[***] 2) Adj item: [L.RSS] [L.R.SS] [L.R.S.S] [L.R.S.S.] [L.R.S.S._.] SSG output : -118dBm(0.28uV) (MOD:1kHz/±1.5kHz)	1) Adj item: [Low RSSI (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -118dBm (0.28μV) (MOD: 1kHz/±1.5kHz)	SSG	ANT Ext.SP connector	[PC test mode] [◀],[▶]	[Panel tuning mode] After input signal from SSG, press [ <b>B</b> ] key to store the adjustment value.  [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value.	Note: Wide, very narrow (NVDN) values are same value as narrow.		

# NX-820H(G)/820H ADJUSTMENT

Item	Panel test mode	PC test mode	Measurement			Adjustment			Specifications/ Remarks
			Test- equipment	Unit	Terminal	Unit	Parts	Method	
7.High RSSI at -80dBm adjust	1) Adj item: [HRSS] Adjust:[***]] 2) Adj item: [H.RSS] [H.R.SS] [H.R.S.S] [H.R.S.S.] [H.R.S.S._] SSG output : -80dBm(22.4μV) (MOD:1kHz/±1.5kHz)	1) Adj item: [High RSSI (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -80dBm (22.4μV) (MOD:1kHz/±1.5kHz)	SSG		ANT Ext.SP connector			[Panel tuning mode] After input signal from SSG, press [ <b>&lt;B</b> ] key to store the adjustment value.  [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value.	Note: Wide, very narrow (NVDN) values are same value as narrow.
8. Squelch(Tight) [Analog Narrow]	*This adjustment can be performed only PC test mode.	1) Adj item: [Tight Squelch (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High]  Press [Apply All] button to store the adjustment value.	SSG		ANT Ext.SP connector	[PC test mode] [◀],[▶]		Write the value as Followings UHF F1/F2.  • Analog Narrow [S.QLT] → 248 [S.Q.LT] → 248 [S.Q.L.T] → 248 [S.Q.L.T.] → 248 [S.Q.L.T._] → 248	
	[Analog Wide]	1) Adj item: [Tight Squelch (Analog Wide)] 2) Adj item: [Low], [Low'], [Center], [High'], [High]  Press [Apply All] button to store the adjustment value.						• Analog Wide [S.QLT] → 255 [S.Q.LT] → 255 [S.Q.L.T] → 255 [S.Q.L.T.] → 255 [S.Q.L.T._] → 255	

# NX-820H(G)/820H

## TERMINAL FUNCTION

### Display unit (X54-3830-10)

Pin No.	Name	I/O	Function
CN1 (to TX-RX unit CN514)			
1	SB	I	Battery voltage DC supply
2	SB	I	Battery voltage DC supply
3	SP-	I	Speaker input –
4	SP-	I	Speaker input –
5	SP+	I	Speaker input +
6	SP+	I	Speaker input +
7	BLC	I	LCD backlight control signal input
8	MBL	I	MIC backlight control signal input
9	RLED	I	Red LED control signal input
10	GLED	I	Green LED control signal input
11	BLED	I	Blue LED control signal input
12	GND	-	Ground
13	GND	-	Ground
14	GND	-	Ground
15	EMG	O	Emergency key detection
16	GND	-	Ground
17	NC	-	No connection
18	50C	I	5V DC power supply
19	LCDDI	I	LCD data input
20	LCDCE	I	LCD enable input
21	LCDCL	I	LCD clock input
22	LCDDO	O	LCD data output
23	GND	-	Ground
24	GND	-	Ground
25	MIC	O	MIC signal output
26	ME	-	MIC ground
27	HOOK/ RXD	O	HOOK/PC serial data
28	PTT/TXD	I/O	PTT/PC serial data
29	MKEY	I/O	MIC data detection
30	POWER	O	Detection output of power switch
J1 (MIC jack)			
1	MBL	O	MIC backlight control
2	SB	O	Battery voltage DC supply
3	GND	-	Ground
4	PTT	I/O	PTT/ PC serial data from radio
5	ME	-	MIC ground
6	MIC	I	MIC signal input
7	HOOK	I	HOOK/ PC serial data to radio
8	DM	I/O	MIC data detection

### TX-RX unit (X57-8240-1x)

Pin No.	Name	I/O	Function
CN514 (to Disply unit CN1)			
1	SB	O	Battery voltage DC supply
2	SB	O	Battery voltage DC supply
3	SP-	O	Speaker output –
4	SP-	O	Speaker output –
5	SP+	O	Speaker output +
6	SP+	O	Speaker output +
7	BLC	O	LCD backlight control signal output
8	MBL	O	MIC backlight control signal output
9	RLED	O	Red LED control signal output
10	GLED	O	Green LED control signal output
11	BLED	O	Blue LED control signal output
12	GND	-	Ground
13	GND	-	Ground
14	GND	-	Ground
15	EMG	I	Emergency key detection
16	GND	-	Ground
17	NC	-	No connection
18	50C	O	5V DC power supply
19	LCDDI	O	LCD data output
20	LCDCE	O	LCD enable output
21	LCDCL	O	LCD clock output
22	LCDDO	I	LCD data input
23	GND	-	Ground
24	GND	-	Ground
25	MIC	I	MIC signal input
26	ME	-	MIC ground
27	HOOK/ RXD	I	HOOK/PC serial data
28	PTT/TXD	I/O	PTT/PC serial data
29	MKEY	I/O	MIC data detection
30	POWER	I	Detection input of power switch

# NX-820H(G)/820H

## TERMINAL FUNCTION

### 8pin Modular Connector Specification

Pin No.	Pin Name	I/O	Signal Type	Description/port type	Item and Condition	Min	Typ	Max	Unit	Note
1	MBL	O	Digital	CMOS output	VOH	3.7		5.2	V	
					VOL	-		1.1	V	
2	SB	O	Power	Switched B output	Output Voltage	This parameter depends on Battery voltage.				
					Output Current			200	mA	
3	GND	O	GND	Ground	-					
4	PTT	I	Digital	CMOS input (Pull Up : 5.0V/10kΩ)	VIH	2.7		5.2	V	
					VIL	-0.3		0.5	V	
4	TXD	O	Digital	CMOS 3-State Buffer output (Pull Up : 5.0V/22kΩ)	VOH	3.7		5.2	V	
					VOL	-		1.1	V	
					Baud rate	-		19200	bps	
5	ME	-	GND	MIC Ground	MIC Groud	This is ground port for Microphone.				
6	MIC	I	Analog	Audio input	Aoutput		5	-	mVrms	
					Copling Capacitor		10	-	uF	
					Input impednce		600	-		
					Allowable Frequency	300		3000	Hz	
7	HOOK/RXD	I	Digital	Digital transistor input (Pull Up : 5.0V/4.7kΩ)	VIH	2.7		5.2	V	
					VIL	-0.3		0.9	V	
					Baud rate	-		115200	bps	
8	DM	I	Digital	CMOS input (Pull Up : 5.0V/47kΩ)	VIH	2.7		5.2	V	
					VIL	-0.3		0.5	V	
					VOH	3.7		5.2	V	
		O	Digital		VOL	-		1.1	V	

### 15pin D-sub Connector Specification

Pin No.	Pin Name	I/O	Signal Type	Description	Item and Condition	Min	Typ	Max	Unit	Note
1	SB	-	Power	Switched B output	Voltage	This parameter depends on Battery voltage.			V	
					Supply Current	-	-	2.0	A	
					(with KCT-60)	-	-	0.5	A	
2	IGN	I	Digital	Ignition sense input	Input Voltage	10.8	-	16	V	
3	SP2	O	Analog	Speaker output	Audio output	3	4	-	W	at 4Ω,10%Distortion
					Coupling Capacitor	-	330	-	uF	
					RL	4	-	-	Ω	
					Allowable Frequency	300	-	3000	Hz	

# NX-820H(G)/820H

## TERMINAL FUNCTION

Pin No.	Pin Name	I/O	Signal Type	Description	Item and Condition	Min	Typ	Max	Unit	Note	
4	DETO	O	Analog	FM detector output	Output Level	-	0.28	-	Vp-p		
					Coupling Capacitor	-	4.7	-	uF		
					Allowable Load	600	-	-	Ω		
	AFO	O		RX Audio output	Output Level	-	0.24	-	Vp-p		
					Coupling Capacitor	-	4.7	-	uF		
					Allowable Load	600	-	-	Ω		
5	DATAI	I	External Modulation input	Input Voltage Range	-	0.5	1.98-	Vp-p	Standard deviation		
					Input Impedance	-	100	-	kΩ		
	MI2	I	External MIC AF Input	Input Voltage Range	-	5	-	mVrms	MM2 SW : ON		
					Allowable Frequency	300	-	3000	Hz		
					Input Impedance	-	600	-	Ω		
6	FNC1/ TXD	I/O	Digital	Programmable I/O	VIH	4.0	-	5.2	V		
					VIL	-0.5	-	1.0	V		
					VOH( $Io=-1.5mA$ )	4.0	-	5.2	V		
					VOL( $Io=1.5mA$ )	-	-	1.1	V		
	TXD (RS- 232C)	O		RS-232C Serial port (TXD)	Voltage Swing	+/-5	+/-9	-	V	3kΩ Load	
					Baud Rate		1920		bps		
					CL		100		pF		
7	FNC2/ RXD	I/O	Digital	Programmable I/O	VIH	4.0	-	5.2	V		
					VIL	-0.5	-	1.0	V		
					VOH( $Io=-1.5mA$ )	4.0	-	5.2	V		
					VOL( $Io=1.5mA$ )	-	-	1.1	V		
	RXD (RS- 232C)	I		RS-232C Serial port (RXD)	Input Voltage Range	-30	-	30	V		
					Threshold Low	0.5	1.3	-	V		
					Threshold High	-	1.75	2.6	V		
8	FNC3	I/O	Digital	Programmable I/O	VIH	4.0	-	5.2	V		
					VIL	-0.5	-	1.0	V		
					VOH( $Io=-1.5mA$ )	4.0	-	5.2	V		
					VOL( $Io=1.5mA$ )	-	-	1.1	V		
	RTS (RS- 232C)	O		RS-232C Serial port (RTS)	Voltage Swing	+/-5	+/-9	-	V	3kΩ Load	
9	FNC4	I/O	Digital	Programmable I/O	VIH	4.0	-	5.2	V		
					VOH	-0.5	-	1.0	V		
					VOH( $Io=-1.5mA$ )	4.0	-	5.2	V		
					VOL( $Io=1.5mA$ )	-	-	1.1	V		
	CTS (RS- 232C)	I		RS-232C Serial port (RTS)	Input Voltage Range	-30	-	30	V		
					Threshold Low	0.5	1.3	-	V		
					Threshold High	-	1.75	2.6	V		
10	FNC5	I/O	Digital	Programmable I/O	VIH	4.0	-	5.2	V		
					VOH	-0.5	-	1.0	V		
					VOH( $Io=-1.5mA$ )	4.0	-	5.2	V		
					VOL( $Io=1.5mA$ )	-	-	1.1	V		


# NX-820H(G)/820H

## TERMINAL FUNCTION


Pin No.	Pin Name	I/O	Signal Type	Description	Item and Condition	Min	Typ	Max	Unit	Note	
11	FNC6	I/O	Digital	Programmable I/O	VIH	4.0	-	5.2	V		
					VIL	-0.5	-	1.0	V		
					VOH( $I_o = -1.5\text{mA}$ )	4.0	-	5.2	V		
					VOL( $I_o = 1.5\text{mA}$ )	-	-	1.1	V		
12	50MC	O	Power	5V DC Power supply	Output Voltage	4.5	5.0	5.25	V		
					Output Current	-	-	100	mA		
13	HR1	I	Analog	Horn alert signal input	Input Voltage	5	-	16	V		
					Input Current	-	-	2.0	A		
					Rds (ON)	-	55	108	$\text{m}\Omega$		
	TXD2 (TTL)	O	Digital		VOH( $I_o = -1.5\text{mA}$ )	4.0	-	5.2	V		
	VOL( $I_o = 1.5\text{mA}$ )	-	-		1.1	V					
14	HR2	O	Analog	Horn alert signal output	Output Voltage	-	-	16	V		
					Output Current	-	-	2.0	A		
	RXD2 (TTL or RS-232C)	I	Digital		Input Range	-30	-	30	V		
					Threshold Low	-	-	0.6	V		
					Threshold High	-	1.75	2.6	V		
15	GND	-	-	Ground					-		

# NX-820H(G)/820H PC BOARD

DISPLAY UNIT (X54-3830-10) Component side view (J79-0345-09)



DISPLAY UNIT (X54-3830-10) Foil side view (J79-0345-09)



J

K

L

M

N

O

P

Q


R

S


## PC BOARD

NX-820H(G)/820H

DISPLAY UNIT (X54-3830-10) Component side view (J79-0345-09)




DISPLAY UNIT (X54-3830-10) Foil side view (J79-0345-09)



# NX-820H(G)/820H PC BOARD

## **TX-RX UNIT (X57-8240-1X) Component side view (J79-0344-09)**



J

K

L

M

N

O

P

Q


R

S

## PC BOARD


## NX-820H(G)/820H

**TX-RX UNIT (X57-8240-1X)**  
**Component side view (J79-0344-09)**



Ref. No.	Address	Ref. No.	Address
IC2	9K	Q703	9F
IC3	10L	Q704	9F
IC103	7K	Q705	8E
IC201	11P	Q706	8F
IC303	12L	Q708	9D
IC402	8D	Q709	8D
IC404	7E	D2	10L
IC409	8J	D101	7I
IC509	11E	D102	7J
IC511	11D	D111	7K
IC512	9D	D201	10N
IC515	9E	D202	10O
IC701	11H	D203	10O
IC702	9G	D205	10O
IC703	9G	D404	7C
IC705	9H	D410	6C
IC711	10H	D411	6D
IC712	8H	D502	11E
IC713	9I	D505	7H
IC716	11D	D506	7H
IC801	5C	D507	7H
Q1	10L	D508	7G
Q2	9L	D509	7G
Q105	8K	D510	7G
Q402	7E	D511	11D
Q404	8E	D512	5E
Q405	8E	D513	5E
Q408	7F	D601	5E
Q411	8F	D701	9I
Q412	8E	D702	9I
Q417	7F	D703	9G
Q504	6D	D704	9G
Q701	10H	D801	7C
Q702	10H	D802	7C

Component side




Foil side

J79-0344-09

**NX-820H(G)/820H PC BOARD**

**TX-RX UNIT (X57-8240-1X)  
Foil side view (J79-0344-09)**

Ref. No.	Address	Ref. No.	Address
IC1	7Q	Q418	5Q
IC301	11M	Q501	12M
IC304	12H	Q502	3O
IC401	9M	Q503	3N
IC405	7O	D3	10H
IC406	9M	D4	11I
IC407	8P	D7	10H
IC408	8N	D8	10J
IC501	11P	D9	10H
IC502	9P	D10	10H
IC503	11Q	D11	10J
IC504	12Q	D12	10J
IC506	9N	D13	10I
IC507	11N	D14	9I
IC508	12M	D16	8H
IC513	8L	D17	8H
IC514	8K	D103	6E
IC516	7L	D104	5C
Q4	9I	D105	6E
Q5	10H	D106	6E
Q6	10I	D107	8E
Q8	9I	D108	10L
Q9	9I	D109	10L
Q10	9H	D110	8F
Q11	9H	D112	8F
Q101	7I	D113	8F
Q102	7J	D114	8F
Q106	7I	D204	9D
Q201	10G	D206	9D
Q202	9C	D401	6Q
Q303	10K	D403	6P
Q305	11F	D405	9M
Q401	6P	D406	7N
Q403	6R	D407	7O
Q407	8O	D408	11K
Q409	9L	D409	11K
Q410	8O	D504	9K
Q414	11L	D705	5N
Q415	11L	D706	5N
Q416	11L		




### Component side

Layer 1
Layer 2
Layer 3
Layer 4
Layer 5
Layer 6

Foil side

# PC BOARD NX-820H(G)/820H


**TX-RX UNIT (X57-8240-1X)  
Foil side view (J79-0344-09)**



J79-0344-09


# NX-820H(G)/820H

## INTERCONNECTION DIAGRAM




# **SCHEMATIC DIAGRAM NX-820H(G)/820H**

TX-RX UNIT(X57-8240-1X)




# NX-820H(G)/820H SCHEMATIC DIAGRAM

TX-RX UNIT (X57-8240-1X)




# **SCHEMATIC DIAGRAM NX-820H(G)/820H**

TX-RX UNIT (X57-8240-1X)



# NX-820H(G)/820H SCHEMATIC DIAGRAM


TX-RX UNIT (X57-8240-1X)



U V W X Y

# SCHEMATIC DIAGRAM NX-820H(G)/820H


TX-RX UNIT (X57-8240-1X)



# NX-820H(G)/820H SCHEMATIC DIAGRAM


*1	X57-823X-XX	A801	CN801	C809	C814	C815	C816	C820	C821	C822	C823	C824	C825	C826	D801	L801	L802	L805	L806	R561	R802	R835	R839	R842	R843	R844	IC801
	0-10..0-12	NX-820H(G)	KK2	YES	YES	YES	YES	NO	YES	YES	YES	YES	YES	YES													
	0-11..0-13	NX-820H	KK2	NO																							

TX-RX UNIT (X57-8240-1X)



# SCHEMATIC DIAGRAM NX-820H(G)/820H

TX-RX UNIT (X57-8240-1X)




# NX-820H(G)/820H SCHEMATIC DIAGRAM

---

TX-RX UNIT (X57-8240-1X)


THP1

THP1



B-BUS

B-BUS



SP-

SP-




# **SCHEMATIC DIAGRAM**

# NX-820H(G)/820H


X57-824X-XX	C124	C129	C133	C135	C137	C142	C144	C145	C148	C149	C150	C175	C179	C180	C254	C255	C256	C263	C290	C292	C296	CN13	D102	L210	L213	L215	L228	R102	R103	R104	R130	R184	R185	R186	R291	R292	
0-0.10-11 NS-820H(G)/B20H K	6p	6p	NO	2p	3p	5p	5p	2p	2p	7p	2p	10p	10p	10p	E217-285	NO	68n	18n	0	0																	
0-0.12-13 NS-820H(G)/B20H K2	7p	7p	220p	470p	100p	470p	100p	1.1u	100p	470p	1u	6e	4p	6p	4p	NO	18p	10p	3p	18p	18p	18p	DA315/F	82n	22n	33n	2.7n	22n	22	22	22	150	470	470	12	NO	NO

TX-RX UNIT (X57-8240-1X)




# NX-820H(G)/820H SCHEMATIC DIAGRAM

X57-824X-XX		C183	C184	C197	R1	R2	
0-10..0-11	NX-820H(G)/820H	K	6.0p	N0	7p	0	N0
0-12..0-13	NX-820H(G)/820H	K2	N0	7p	8p	N0	0




# SCHEMATIC DIAGRAM NX-820H(G)/820H

DISPLAY UNIT (X54-3830-10)




# NX-820H(G)/820H

## BLOCK DIAGRAM




# NX-820H(G)/820H

## BLOCK DIAGRAM



# NX-820H(G)/820H


## BLOCK DIAGRAM



# NX-820H(G)/820H

## LEVEL DIAGRAM


### Receiver Section



To make measurements in the AF section, connect the AC level meter. (ANT input: -53dB, 1kHz FM, 3kHz DEV (Wide))  
In the RF section, use a 1000pF coupling capacitor.

(The display shows the SSG input value required to obtain 12dB SINAD without local level.)

### Transmitter Section



MIC input : 3kHz DEV.(Wide), 1.5kHz DEV.(Narrow) at 1kHz MOD.  
Transmitting frequency : Center frequency

# NX-820H(G)/820H

## OPTIONAL ACCESSORIES

### KRA-40 (GPS ACTIVE ANTENNA)

#### ■ Specifications

Supply Voltage .....	3.0±0.3V
Current Consumption .....	Typ. 19mA
Center Frequency .....	1575.42MHz
Gain .....	30±7dBi (Elevation : 90°) ..... 23±7dBi (Elevation : 10°)
Output Impedance .....	50Ω

#### ■ External View



# NX-820H(G)/820H

## MEMO

# NX-820H(G)/820H

## SPECIFICATIONS

### GENERAL

Frequency Range .....	450~520MHz : K	400~470MHz : K2
Number of Channels.....	512	
Zones.....	128	
Max. Channels per Zone .....	250	
Channel Spacing .....	Analog: 12.5/25 kHz	Digital: 6.25/12.5 kHz
Operating Voltage .....	11.6~15.7V	
Operating Temperature Range .....	-22°F~+140°F (-30°C~+60°C)	
Frequency Stability .....	±1.0ppm	
Antenna Impedance .....	50Ω	
Dimensions (W x H x D) .....	6.30 x 1.69 x 5.35 in. (160 x 43 x 136 mm) (Projections not included)	
Weight .....	3.03 lbs. (1.38 kg)	

### RECEIVER

Sensitivity .....	Digital @6.25kHz (3% BER): 0.20µV	Digital @12.5kHz (3% BER): 0.28µV
	Analog 12dB SINAD: 0.25µV	
Selectivity .....	Analog @25kHz: -80dB	Analog @12.5kHz: -70dB
Intermodulation Distortion .....	Analog @25kHz: -75dB	Analog @12.5kHz: -75dB
Spurious Response .....	Analog: -85dB	
Audio Distortion .....	Less than 3%	
Audio Output .....	4W/4Ω	

### TRANSMITTER

RF Power Output.....	1~45W
Spurious Response .....	75dB
FM Hum and Noise (Typ).....	Analog @25kHz: 50dB
Modulation .....	Analog @12.5kHz: 45dB 16K0F3E, 14K4F1D, 11K0F3E, 8K30F1E, 8K30F1D, 8K30F7W, 4K00F1E, 4K00F1D, 4K00F7W, 4K00F2D

Analog measurements made per TIA/EIA 603 and specifications shown are typical.

JVC KENWOOD Corporation reserves the right to change specifications without prior notice or obligation.

### JVC KENWOOD Corporation

3-12, Moriyacho, Kanagawa-ku, Yokohama-shi,  
Kanagawa, 221-0022 Japan

#### Kenwood U.S.A. Corporation

P.O. BOX 22745, 2201 East Dominguez Street, Long Beach,  
CA 90801-5745, U.S.A.

#### Kenwood Electronics Canada Inc.

6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

#### Kenwood Electronics Deutschland GmbH

Rembrücker Str. 15, 63150 Heusenstamm, Germany

#### Kenwood Electronics Belgium N.V.

Leuvensesteenweg 248 J, 1800 Vilvoorde, Belgium

#### Kenwood Electronics France S.A.

L'Etoile Paris Nord 2, 50 Allée des Impressionnistes,  
Bp 58416 Villepinte, 95944 Roissy Ch De Gaulle Cedex

#### Kenwood Electronics UK Limited

Kenwood House, Dwight Road, Watford, Herts.,  
WD18 9EB United Kingdom

#### Kenwood Electronics Europe B.V.

Amsterdamseweg 37, 1422 AC Uithoorn, The Netherlands

#### Kenwood Electronics Italia S.p.A.

Via G. Sirtori, 7/9 20129 Milano, Italy

#### Kenwood Ibérica, S.A.

Carretera de Rubí, 88 Planta 1 A 08174 Sant Cugat del Vallès  
Barcelona, Spain

#### JVCKENWOOD Australia Pty. Ltd.

Talavera Business Park Building A, 4 Talavera Road,  
North Ryde NSW 2113 Australia

#### Kenwood Electronics (Hong Kong) Ltd.

Suite 2504, 25/F, Tower 2, Nina Tower, No. 8 Yeung Uk Road,  
Tsuen Wan, New Territories, Hong Kong

#### Kenwood Electronics Singapore Pte Ltd


1 Ang Mo Kio Street 63, Singapore 569110

# NX-820H(G)/820H PC BOARD

# PC BOARD NX-820H(G)/820H


DISPLAY UNIT (X54-3830-10) Component side view (J79-0345-09)

DISPLAY UNIT (X54-3830-10) Component side view (J79-0345-09)



DISPLAY UNIT (X54-3830-10) Foil side view (J79-0345-09)

DISPLAY UNIT (X54-3830-10) Foil side view (J79-0345-09)



# NX-820H(G)/820H PC BOARD


TX-RX UNIT (X57-8240-1X)

Component side view (J79-0344-09)


# PC BOARD NX-820H(G)/820H

TX-RX UNIT (X57-8240-1X)

Component side view (J79-0344-09)




Ref. No.	Address	Ref. No.	Address
IC2	9K	Q703	9F
IC3	10L	Q704	9F
IC103	7K	Q705	8E
IC201	11P	Q706	8F
IC303	12L	Q708	9D
IC402	8D	Q709	8D
IC404	7E	D2	10L
IC409	8J	D101	7I
IC509	11E	D102	7J
IC511	11D	D111	7K
IC512	9D	D201	10N
IC515	9E	D202	10O
IC701	11H	D203	10O
IC702	9G	D205	10O
IC703	9G	D404	7C
IC705	9H	D410	6C
IC711	10H	D411	6D
IC712	8H	D502	11E
IC713	9I	D505	7H
IC716	11D	D506	7H
IC801	5C	D507	7H
Q1	10L	D508	7G
Q2	9L	D509	7G
Q105	8K	D510	7G
Q402	7E	D511	11D
Q404	8E	D512	5E
Q405	8E	D513	5E
Q408	7F	D601	5E
Q411	8F	D701	9I
Q412	8E	D702	9I
Q417	7F	D703	9G
Q504	6D	D704	9G
Q701	10H	D801	7C
Q702	10H	D802	7C



# NX-820H(G)/820H PC BOARD

TX-RX UNIT (X57-8240-1X)  
Foil side view (J79-0344-09)


Ref. No.	Address	Ref. No.	Address
IC1	7Q	Q418	5Q
IC301	11M	Q501	12M
IC304	12H	Q502	3O
IC401	9M	Q503	3N
IC405	7O	D3	10H
IC406	9M	D4	11I
IC407	8P	D7	10H
IC408	8N	D8	10J
IC501	11P	D9	10H
IC502	9P	D10	10H
IC503	11Q	D11	10J
IC504	12Q	D12	10J
IC506	9N	D13	10I
IC507	11N	D14	9I
IC508	12M	D16	8H
IC513	8L	D17	8H
IC514	8K	D103	6E
IC516	7L	D104	5C
Q4	9I	D105	6E
Q5	10H	D106	6E
Q6	10I	D107	8E
Q8	9I	D108	10L
Q9	9I	D109	10L
Q10	9H	D110	8F
Q11	9H	D112	8F
Q101	7I	D113	8F
Q102	7J	D114	8F
Q106	7I	D204	9D
Q201	10G	D206	9D
Q202	9C	D401	6Q
Q303	10K	D403	6P
Q305	11F	D405	9M
Q401	6P	D406	7N
Q403	6R	D407	7O
Q407	8O	D408	11K
Q409	9L	D409	11K
Q410	8O	D504	9K
Q414	11L	D705	5N
Q415	11L	D706	5N
Q416	11L		



# PC BOARD NX-820H(G)/820H

TX-RX UNIT (X57-8240-1X)  
Foil side view (J79-0344-09)

J79-0344-09



## TX-RX UNIT(X57-8240-1X)

