




MOTOROLA

Radius i20R
Repeater Controller

Service Manual



6880904Z40-A
August, 1996

Table Of Contents

Foreword

| | |
|---|-----|
| Scope of Manual | iii |
| Model and Kit Identification | iii |
| Service..... | iii |
| Replacement Parts Ordering | iii |
| Notice Concerning FCC Approval..... | iii |
| General Safety Information..... | iv |
| General System Lightning Protection Considerations..... | iv |
| Safe Handling of CMOS Integrated Circuit Devices..... | v |
| General Specifications | vi |

Servicing Information

| | |
|--|-----|
| Basic Operation | 1-1 |
| Description..... | 1-1 |
| Installation..... | 1-1 |
| Mounting | 1-1 |
| Uni-Directional Operation (Normal Repeat Mode) | 1-2 |
| Bi-Directional Operation | 1-2 |
| Transparent Repeat Mode | 1-2 |
| TPL/DPL Cross Coding | 1-3 |
| Level Setting | 1-3 |
| Accessories | 1-4 |
| Temporary Repeater | 1-4 |
| Connector Charts..... | 1-4 |
| Optional Functions..... | 1-5 |
| Serial Billing Interface..... | 1-5 |
| Operator Instructions..... | 1-5 |
| Repeater Enable/Disable..... | 1-5 |
| Remote Repeater Disable or Enable..... | 1-5 |

| | |
|-------------------------------|------|
| Internal Diagnostics | 1-5 |
| Test 1 | 1-6 |
| Test 2 | 1-6 |
| Test 3 | 1-6 |
| Test 4 | 1-7 |
| Test 5 | 1-7 |
| Test 6 | 1-7 |
| Test 7 | 1-8 |
| Theory of Operation | 1-9 |
| Microcontroller | 1-9 |
| Audio Paths | 1-9 |
| TPL/DPL Functions | 1-9 |
| DC Power Supply | 1-9 |
| VOX Operation | 1-10 |
| Miscellaneous Functions | 1-10 |
| Programming Interface | 1-10 |

Appendix A

| | |
|------------------------|-----|
| Schematics | A-2 |
| Component Layout | A-8 |
| Parts List | A-9 |

Appendix B

GR300, M120 and i20R Setup

| | |
|-------------------------------|-----|
| GR300 Repeater Assembly | B-1 |
| Programming | B-1 |
| Transmit Radio | B-1 |
| Receive Radio | B-2 |
| i20R Controller | B-2 |
| i20R Adjustments | B-3 |

List of Tables

| | |
|--|-----|
| Table 1-1. Standard Repeat Modes with TPL/DPL Regeneration | 1-2 |
| Table 1-2. Transparent Repeat Mode | 1-3 |
| Table 1-3. DPL Code Chart | 1-8 |
| Table B-1. Radio Jumper Settings | B-1 |

List of Figures

| | |
|-------------------------------|-----|
| Figure 1-1. Front Panel | 1-1 |
| Figure 1-2. Locking Tab | 1-2 |

Scope of Manual

This manual is intended for use by experienced technicians familiar with similar types of equipment. It contains all service information required for the equipment described and is current as of the printing date. Changes which occur after the printing date are incorporated by instruction manual revisions. These revisions are added to the manuals as the engineering changes are incorporated into the equipment.

Model and Kit Identification

This equipment is specifically identified by an overall model number on the rear panel. If additional options are ordered, the option will be indicated either on the circuit board if a hardware option, or on a sticker affixed to an EPROM if a firmware option.

Service

Motorola's National Service organization offers one of the finest nationwide installation and maintenance programs available to communication equipment users. This organization includes:

Well over 900 authorized Motorola Service Subcontractors (MSS's) and Company- Owned Service Centers (COCS's) nationwide.

- A staff of highly trained technicians who are thoroughly up-to-date on Motorola systems and products.
- Local Service Representatives who initiate, maintain and nurture customer service relationships.
- Local Service management teams who promote service consistency throughout the national service network.

Should you wish to purchase a service agreement which ensures timely preventative maintenance, priority response to emergencies and has pre-established

rates for parts and labor to simplify budgeting, contact your local Service Representative or write to:

National Service Manager

Motorola Communications and
Electronics, Inc.
Schaumburg, Illinois 60196

Replacement Parts Ordering

When ordering replacement parts or equipment information, the complete identification number should be included. This applies to all components, kits, and chassis. If the component part number is not known, the order should include the number of the chassis or kit of which it is a part and sufficient description of the desired component to identify it. Parts should be ordered from:

Service Parts Manager

Instrument Associates
2455 Harbor Avenue
P.O. Box 13127
Memphis, TN 38113
1-800-442-4782

Notice Concerning FCC Approval

WARNING:

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user, at his own expense, will be required to take whatever measure necessary to correct the interference.

General Safety Information

The United States Department of Labor, through the provisions of the Occupational Safety and Health Act of 1970 (OSHA), has established an electromagnetic energy safety standard which applies to the use of this equipment. Proper precautions in the use of this equipment will result in exposure below the OSHA limit. The following precautions are recommended:

1. DO NOT operate the transmitter of a mobile radio when someone outside the vehicle is within two feet (0.6 meters) of the antenna.
2. DO NOT operate the transmitter of a fixed radio (base station, microwave, and rural telephone RF equipment) or marine radio when someone is within two feet (0.6 meters) of the antenna.
3. DO NOT operate the transmitter of any radio unless all RF connectors are secure and any open connectors are properly terminated.

In addition:

DO NOT operate this equipment near electrical caps or in an explosive atmosphere.

All equipment must be properly grounded according to Motorola installation instructions for safe operation.

All equipment should be serviced only by a qualified technician.

Refer to General System Lightning Protection Considerations and Safe Handling of CMOS Integrated Circuit Devices for additional pertinent safety information.

General System Lightning Protection Considerations

The damage done by lightning is due to potential differences developed between equipment, between equipment and the power source, between equipment and the outside telephone line, and between equipment and earth ground. Two things are imperative if lightning damage is to be minimized.

1. All equipment at a site should be bonded frame-to-frame with adequately sized conductors. This common ground should be bonded to the utility entrance ground cable and the telephone entrance ground, if different from the utility entrance ground. Bear in mind that lightning is essentially RF and, as such, does not like long leads and will not tolerate sharp bends, as it "sees" this as a high impedance. If a tower is used, it is essential that the common ground system also be bonded to the tower. At a site where these various components are encountered (tower, utility ground, telephone ground), it is suggested that #6 bare copper be used as a minimum.
2. After bonding, the degree of insurance against lightning is almost directly related to the **resistance** of the earth ground(s) used. All grounds connected in parallel (tower, utility, and telephone, if independent) contribute to lowering the net ground resistance. For "hot" sites (sites where lightning is known to cause damage regularly) it is well to use multiple ground rods spaced several feet apart and bonded together with #6 or better wire. If the soil is sandy or rocky, the local utility company can usually provide excellent advice if their engineering office is contacted relative to the local methods used to obtain a low resistance ground. Many times these utility engineering departments will measure your site effective ground resistance with their specialized equipment, if approached in the right way. Remember — the potential of lightning is what does the damage, and the lower the ground resistance, the lower the lightning potential.

Safe Handling of CMOS Integrated Circuit Devices

Many of the integrated circuit devices used in communications equipment are of the CMOS (Complementary Metal Oxide Semiconductor) type. Because of their high open circuit impedance, CMOS ICs are vulnerable to damage from static charges. Care must be taken handling, shipping, and servicing them and the assemblies in which they are used.

Even though protection devices are provided in CMOS IC inputs, the protection is effective only against overvoltage in the hundreds of volts range such as is encountered in an operating system. In a system, circuit elements distribute static charges and load the CMOS circuits, decreasing the chance of damage. However, CMOS circuits can be damaged by improper handling of the modules, even in a system.

To avoid damage to circuits, observe the following handling, shipping, and servicing precautions:

1. Prior to and while servicing a circuit module, particularly after moving within the service area, momentarily touch both hands to a bare metal, earth-grounded surface. This will discharge any static charge which may have accumulated on the person doing the servicing.

Note

Wearing Conductive Wrist Strap (Motorola No. RSX-4015A) will minimize static build-up during servicing.

2. Whenever possible, avoid touching any electrically conductive parts of the circuit module with your hands.
3. Power down the unit before installing or removing a circuit module.

4. When servicing a circuit module, avoid carpeted areas, dry environments, and certain types of clothing (silk, nylon, etc.) because they contribute to static build-up.
5. All electrically powered test equipment should be grounded. Apply the ground lead from the test equipment to the circuit module before connecting the test probe.

Similarly, disconnect the test probe prior to removing the ground lead.

6. If a circuit module is removed from the system, it is desirable to lay it on a conductive surface (such as a sheet of aluminum foil) which is connected to ground through 100k of resistance.

WARNING

If the aluminum foil is connected directly to ground, be cautious of possible electrical shock from contacting the foil at the same time as other electrical circuits.

7. When soldering, be sure the soldering iron is grounded.
8. Prior to connecting jumpers, replacing circuit components, or touching CMOS pins (if this becomes necessary in the replacement of an integrated circuit device), be sure to discharge any static build-up as described in procedure 1.

Since voltage differences can exist across the human body, it is recommended that only one hand be used if it is necessary to touch pins on the CMOS device and associated board wiring.

9. When replacing a CMOS integrated circuit device, leave the device in its conductive rail container or conductive foam until it is to be inserted into the printed circuit module.
10. All low impedance test equipment (such as pulse generators, etc.) should be connected to CMOS device inputs after power is applied to the CMOS circuitry. Similarly, such low impedance equipment should be disconnected before power is turned off.
11. Replacement modules shipped separately from the factory will be packaged in a conductive material. Any modules being transported from one area to another should be wrapped in a similar material (aluminum foil may be used). **Never use non-conductive material** for packaging these modules.

General Specifications

- **DC input voltage:**
10.5 to 16VDC
- **Input from radio receiver:**
typical 300mV RMS
- **Output level to transmitter:**
80mV RMS nominal
- **DC input current:**
less than 100mA
- **Audio frequency response:**
±3dB, 300-3000Hz from 1kHz ref.
- **Hum and noise:**
-45dB from 1kHz ref. using 30kHz LPF,
300mV RMS into RX audio input(s)
- **Audio distortion:**
3% max., 1kHz tone
- **Humidity range:**
95% relative humidity at 50° C
- **Weight:**
3 pounds max.
- **Dimensions:**
7"w x 5.2"d x 1.5"h

Appendix A

Schematics, Layouts and Parts List

| | |
|--|-----|
| Controller, Part 1 | A-2 |
| Controller, Part 2 | A-3 |
| Radio Interface, Part 1 | A-4 |
| Radio Interface, Part 2 | A-5 |
| Radio Interface, Part 3 | A-6 |
| Audio Block Diagram | A-7 |
| Component Layout for RC2 Circuit Board | A-8 |
| RC2 Parts List | A-9 |

Basic Operation

Description

The i20R is an enhanced repeater controller designed to interface between two Radius GM300 mobile radios in the GR-series repeater housings. The repeater can operate in either uni-directional mode, or bi-directional mode. The repeater can be "in-band" (UHF-UHF) or "cross band" (UHF-VHF). A temporary or emergency repeater may also be quickly assembled by plugging two mobiles, via their modular microphone connectors into the modular jacks located on the rear of the i20R.

Features include programmable time-out timer, "over" beep, battery power indicator beep, drop-out timer, TPL/DPL cross-coding, and automatic CWID. All features are programmable via Radio Service Software (RSS). The i20R supports up to 10 TPL or DPL codes for multiple group usage.

Front panel LEDs indicate the status of Power, COR/TX, and RPTR (refer to Figure 1-1).




Figure 1-1. Front Panel

Installation

Mounting

The i20R can be mounted in any of the GR-series housings, using the supplied mounting hardware. Before permanently mounting, it is recommended that the i20R remain unmounted for operational tests. It is also imperative that JU551, inside the GM300 receive radio, is in the "A" position for any application where the i20R will be decoding TPL/DPL. This is also required in the transmit radio, for bi-directional repeaters, where the i20R is required to decode TPL/DPL signals.

Additionally, 16 channel GM300, and M200 radios must be properly programmed (operating frequencies, COR, TPL/DPL codes, etc.) prior to placing into service.

Connect the cable from the receive radio to the 16 pin connector marked RX, on the rear of the i20R (PR5). Connect the cable from the transmit radio to the connector marked TX, on the rear of the i20R (PR3). The cables are supplied as part of the GR-series repeater package.

After the system is tested and operational, slide the i20R into the top position of the GR-series repeater housing and secure with the 2 machine screws provided. The radios are mounted in a similar manner in the slots below the i20R.

CAUTION

Install connectors with locking tabs "UP" Refer to Figure 1-2. Ensure the i20R connectors, RX and TX, are programmed to match the radios before connection. Failure to do so could damage the i20R and/or the radios.




Figure 1-2. Locking Tab

Uni-Directional Operation (Normal Repeat Mode)

In this mode, the i20R operates as a normal split-channel repeater (both receiver and transmitter in the same VHF or UHF band). Parameter programming is made via RSS. TPL or DPL will not be retransmitted through the repeater.

| Table 1-1. Standard Repeat Modes with TPL/DPL Regeneration | | |
|--|--|--|
| GM300 Jumper | Transmit Radio Jumper Position | Receive Radio Jumper Position |
| JU551 | "A" for Bi-directional repeat "x" for Uni-directional | "A" |
| JU651 | "A" | "A" for Bi-directional repeat "x" for Uni-directional |
| JU701 | "B" | "A" for Bi-directional repeat "x" for Uni-directional |
| "x" = jumper may be in either "A" or "B" position | | |

Bi-Directional Operation

In this mode, both radios operate as cross-band transceivers. That is, one radio typically operates on a VHF frequency, while the other operates on a UHF frequency. Parameter programming is made via RSS.

Note

The drop-out timer should be programmed in RSS to the minimum of 100ms for both forward and reverse repeater drop-out time.

Programming Radio Jumpers

If it is required that the i20R regenerate DPL, or TPL, jumper JU701 on the Expanded Logic Board should be in the "B" position. This will be considered the norm for most installations. Refer to Table 1-1 for jumper settings.

i20R programming

The i20R must also be programmed to determine the operating mode. Select "Repeat Method" from the Unidirectional/Forward Repeater Table screen in Radio Service Software (RSS). If Bi-directional mode is used you must also select "Repeat Method" from the Reverse Repeater Table screen.

Select either "Strip RX PL and Repeat" or "Repeat w/Alternate PL". Selecting "Strip RX PL and Repeat" will cause the i20R to regenerate received TPL/DPL codes. Selecting "Repeat w/Alternate PL" allows TPL/DPL cross-coding (a different code is transmitted than is received).

Transparent Repeat Mode

Description

This method should be used for special applications when it is not required to regenerate TPL or DPL.

Table 1-2. Transparent Repeat Mode

| GM300 Jumper | Transmit Radio Jumper Position | Receive Radio Jumper Position |
|---|--|--|
| JU551 | "A" for Bi-directional repeat "x" for Uni-directional | "A" for Uni-directional and Bi-directional |
| JU651 | "A" | "A" for Bi-directional repeat "x" for Uni-directional |
| JU701 | "A" | "A" for Bi-directional repeat "x" for Uni-directional |
| "x" = jumper may be in either "A" or "B" position | | |

Radio Jumpers

When it is desired to use the repeater in the Transparent Repeat Mode, the GM300 Expanded Logic Board Jumper JU701 must be in the "A" position. Also, the receiver radio logic board jumper, JU551, should be in the "A" position to supply discriminator (not de-emphasized and muted) receiver audio. The radio is shipped with jumper JU551 in the "B" position. Do not place radio transmit radio logic board jumper JU701 in the "B" position for Transparent Repeat Mode as the supplied level will be insufficient for full modulation. Refer to Table 1-2 for jumper settings.

i20R Programming

The transmit radio must be programmed for carrier squelch (CSQ) using RSS. This allows the data that is received to be re-transmitted, without introducing an added TPL/DPL code. To enable Transparent Repeat, using RSS, select "Transparent Repeat" under "Repeat Method" parameter. Selecting Transparent Repeat will disable the receive de-emphasis in the i20R and pass the audio essentially unaltered to the flat input of the repeater transmitter. The range of the levels will be reduced to accommodate the levels required for the GM300 radio when the logic board jumper JU701 is set for the "A" position.

TPL/DPL Cross Coding

The i20R may be programmed to cross code a received TPL or DPL code. This function may be enabled in Uni-Directional or Bi-Directional operation. Cross coding allows a different TPL or DPL code to be sent to a mobile. Received input can be a TPL code and transmitted output a DPL code, or vice-versa. If regeneration of the desired TPL/DPL signal is desired, the i20R can be programmed to encode the same code it receives.

If operating in Unidirectional mode, program RSS parameters in the Unidirectional/Forward Repeater table.

If operating in Bi-Directional mode, program RSS parameters in the Reverse Repeater table.

Level Setting

Normal Repeat Level Setting

If "Strip RX PL and Repeat" (or "Strip PL and Repeat with Alternate PL") has been selected in the RSS, the level of the TPL or DPL modulation should be adjusted after POT3 FWD RPTR LVL, and POT1, REV RPTR LVL (if used), has been set. Modulate an RF generator, on to the forward receiver frequency, with a 1000Hz tone, at 60% system deviation. Enter Diagnostics Test 1. Adjust POT3 for the 60% system modulation from the forward transmitter.

If reverse repeat is also required, enter Internal Diagnostic Test 2 and perform a procedure similar to the one above, injecting the RF signal into the reverse receiver. While monitoring the reverse transmitter, adjust POT1 for 60% system modulation.

Turn off the 1000Hz tone before setting the TPL/DPL level. Enter Diagnostic Test 3 for FORWARD TPL, or Test 4 for FORWARD DPL, and set the TPL or DPL modulation with POT2 for approximately ± 750 Hz deviation, as indicated on a Communications Service monitor.

Transparent Repeat Level Setting

Pot 2 adjusts the level of the flat audio to the repeater transmitter. It should normally be set to produce a 1:1 repeat ratio in the Transparent mode. Cause the system to repeat, by generating a modulated carrier (1kHz tone) on the receive frequency. While monitoring the transmitter with a Communications Service monitor set to measure deviation, adjust POT2 to produce ± 3 kHz deviation of the transmitter, for ± 3 kHz deviation from the generator, in a ± 5 kHz system.

Note

If either TPL or DPL is also to be repeated transparently (not regenerated by the i20R), POT2 should be adjusted to produce a repeat ratio of 60/50.

Example: In a 5kHz system, setup an FM RF generator as follows:

± 3 kHz deviation of a 1000Hz tone

RF level at 1000 micro-volts

Adjust POT2 to produce ± 2.5 kHz deviation of the transmitter.

Accessories

If an accessory, such as a TRA100R, or Local Control Deskset is used, insert the cable connector into PR4, marked ACC, on the rear of the unit.

CAUTION

Before connecting any device to the ACC connector, ensure the connector is configured as required using Radio Service Software (RSS). Failure to do so might damage the i20R and/or accessory device.

A local control dispatch microphone or handset may be plugged into the front panel 8-pin modular connector. This connector conforms to the standard Motorola pin-out.

Temporary Repeater

The i20R may be assembled as a limited capability (emergency) repeater.

Note

The i20R must be programmed for VOX operation to validate mobile carrier using RSS. Jumpers in the radio must provide muted, post de-emphasized audio to the i20R (JU551 in the "B" position for the GM300 radios).

Connect the 8 pin modular microphone port interface cable, between the front panel microphone jack (J11) and P1 RX. Connect another 8 pin modular microphone port interface cable between the front panel microphone jack of the transmitter radio, and P2 TX located on the rear panel of the unit.

Connector Charts

The following charts list the default, programmable pin functions for PR5, PR3, and PR4 of the i20R.

PR5 - RX connector

| Pin # | Default Function |
|-------|------------------|
| 3 | PTT |
| 4 | External Alarm |
| 6 | null input |
| 8 | RX COR |
| 9 | Emergency Switch |
| 12 | null input |
| 14 | null input |

PR3 - TX connector

| Pin # | Default Function |
|-------|------------------|
| 3 | PTT |
| 4 | null input |
| 6 | null input |
| 8 | null input |
| 9 | null input |
| 12 | null input |
| 14 | TX COR |

PR4 - Accessory Connector

| Pin # | Default Function |
|-------|---|
| 6 | output follows state of pin PR5-6 |
| 8 | output follows state of pin PR5-8 (RX COR) |
| 12 | output follows state of pin PR5-12 |
| 14 | output - follows state of pin PR5-14 |

Optional Functions

Serial Billing Interface

Serial Billing Interface identifies radio users in both forward and reverse operations. Serial output is via the 8 pin modular program connector, which uses standard Motorola RIB logic levels.

The output is a 9600 BPS serial format. The output will be displayed in the following format:

| | |
|-----------------------------|----|
| Forward/Unidirectional Mode | Fx |
| (where x is the user #) | |
| Reverse Mode | Rx |
| (where x is the user #) | |

The end user is responsible for providing PC software to utilize this data for billing purposes.

Operator Instructions

Repeater Enable/Disable

The front panel contains a manual override for repeater "enable" or "disable" ("disable" does not prevent local control operation of the station). Pressing the RPTR button will enable or disable the repeater. The status of the repeater is indicated by the amber LED on the front panel. If the LED is lit, the repeater is enabled, if the LED is not lit, the repeater is disabled.

Remote Repeater Disable or Enable

Remote Repeater Disable

To remotely disable a repeater that is enabled, the mobile initiates a RapidCall Call Alert to the receive radio, using the receive radio's ID number. If the receive radio has been programmed to transmit an Emergency Alert (using RSS), the alert will be transmitted to indicate that the repeater is disabled. If the receive radio has not been programmed to transmit an Emergency Alert, no indication will be sent to the mobile.

Remote Repeater Enable

To remotely enable a repeater that is disabled, the mobile initiates a Call Alert to the receive radio, using the receive radio's ID number. No acknowledgment will be sent to the mobile radio, however, the repeater being operational will confirm its enabled state.

Note:

For remote repeater controller, the receive radio must be programmed to transmit on the receive frequency with RapidCall enabled.

Internal Diagnostics

The i20R has been designed with several diagnostic tests to assist you in set-up and troubleshooting. Enter the diagnostic mode by pressing the TEST button.

To step to another test once the diagnostic mode has been entered, press the TEST button again.

Each time a new test is selected, a test timer is set to 15 minutes. If this timer reaches zero, the unit resets itself to idle.

Test 1

Test 1 performs the following tasks:

1. Forward audio (RX audio from RX radio) is repeated based on programming. If repeater is programmed for VOX operation, PTT is activated based on VOX detection. If repeater is programmed for logic carrier detect, PTT is activated based on COR detection.
2. RPTR button is used to toggle between VOX based repeat and COR based repeat.
3. EXTERNAL ALARM input, when active, causes transparent repeat operation (when not in VOX operation). When EXTERNAL ALARM is inactive, audio is routed to mic input of TX radio.

Note

The EXTERNAL ALARM function must be programmed into an input pin of PR5 to allow selecting transparent repeat operation.

4. LED functions (refer to Figure 1-1):
 - PWR LED on when in VOX repeat mode
 - COR/TX LED on when not in VOX mode and repeat audio is being high-pass filtered (non-transparent repeat operation)
 - RPTR LED on when in VOX operation and VOX detected
5. The reference voltage for VOX detection is set by the user. The user must enter "SET VOX" from PC running terminal emulation software, with the RIB connected. When the i20R has set the VOX threshold, the unit will reset. During this test, no audio should be input to PR3-11 or through the modular connector (J2).

Test 2

Test 2 performs the following tasks:

1. Reverse audio (RX audio from TX radio) is repeated based on programming. If repeater is programmed for VOX operation, PTT is activated based on VOX detection, if repeater is programmed for logic carrier detect, PTT is activated based on COR detection.
2. RPTR button is used to toggle between VOX based repeat and COR based repeat.
3. EXTERNAL ALARM input, when active, causes transparent repeat operation (when not in VOX operation). When EXTERNAL ALARM is inactive, audio is routed to mic input of RX radio.

Note

The EXTERNAL ALARM function must be programmed into an input in of PR5 to allow selecting transparent repeat operation.

4. LED functions (refer to Figure 1-1):
 - PWR LED on when in VOX repeat mode
 - COR/TX LED on when not in VOX mode and repeat audio is being high-pass filtered (non-transparent repeat operations)
 - RPTR LED on when in VOX operation and VOX detected

Test 3

Test 3 performs the following tasks:

1. Forward audio (RX audio from RX radio) is constantly repeated from PR5-11 to PR3-2 (high-pass filtered & de-emphasized).
2. The i20R generates TPL and adds it to the forward audio.
3. The i20R decodes TPL on the RX channel. If the TPL decoded matches the TPL being generated, the RPTR LED is lit.

Note

To decode TPL, JU551 in the receive radio must be in the "A" position.

4. Pressing the RPTR button will cause the i20R to step to generating the next TPL tone frequency.
5. If the EXTERNAL ALARM input is active, the generated TPL signalling will be phase shifted 180 degrees. (**Note:** This requires that one of the PR5 input pins be programmed for the EXTERNAL ALARM function.)

Test 4

Test 4 performs the following tasks:

1. Forward audio (RX audio from RX radio) is constantly repeated from PR5-11 to PR3-2 (high-pass filtered & de-emphasized).
2. The i20R generates DPL and adds it to the forward audio.
3. The i20R decodes DPL on the RX channel. If the DPL decoded matches the DPL being generated, the RPTR LED is lit and the DPL digits are transmitted through the programming port.

Note

To decode DPL, JU551 in the receive radio must be in the "A" position.

4. Pressing the RPTR button will cause the i20R to step to generating the next DPL code from Table 1-3.
5. If the EXTERNAL ALARM input is active, the generated DPL signalling will be inverted. (**Note:** This requires that one of the PR5 input pins be programmed for the EXTERNAL ALARM function.)

Note

The EXTERNAL ALARM function must be programmed into an input pin of PR5 to allow setting LOW BATTERY threshold.

Test 5

Test 5 performs the following tasks:

1. Beep tone is transmitted from TX radio.
2. Pressing the RPTR button will raise the beep tone frequency by 100Hz (the range is 400-2000Hz).
3. RS232 data (alternating 0xaa and 0x55 values) will be looped from TX to RX SCI ports. If the received data matches the transmitted data, the PWR LED will be lit.
4. If the power supply voltage falls below the programmed LOW BATTERY voltage threshold, the RPTR LED will light.
5. Activating the EXTERNAL ALARM input will force the unit to sample the power supply threshold and set it as the new LOW BATTERY voltage threshold

Note

The EXTERNAL ALARM function must be programmed into an input pin of PR5 to allow setting LOW BATTERY threshold.

Test 6**WARNING**

The i20R must be disconnected from the radios during Test 6. Failure to do so could cause damage to both the i20R and the radios.

Note

During this test, PR5-4 must be connected to PR5-9 with a pull-up on PR5-9. Also, PR3-4 must be connected to PR3-9 with a pull-up on PR3-9.

Test 6 performs the following functions:

1. All connector pins are tested. The LEDs give a binary representation of the connector being tested (PR5 or PR3). PR4-6, 8 are tested with PR5; PR4-12, 14 are tested with PR3.

2. The test consists of writing a value to the pins and verifying that the same value is read back in. This is done 10 times.
3. The connector being tested toggles between PR3 and PR5 by pressing the RPTR button.
4. If an error is detected during this test, the LEDs will begin flashing. The pins which have produced the error will be listed via data output through the programming port.

Test 7

Test 7 performs the following:

1. Decodes TPL and DPL on the selected radio.

Note

To decode TPL, JU551 in the receive radio must be in the "A" position.

2. LED functions (refer to Figure 1-1):
 - PWR LED lit steadily if decoding from RX radio, flashing if decoding from TX radio
 - CORTX LED lit if TPL has been decoded on the channel
 - RPTR LED lit if DPL has been decoded on the channel
3. If the i20R is programmed for bi-directional repeat operation, pressing the RPTR button before TPL is decoded will switch to decoding the opposite radio.
4. Pressing the RPTR button after TPL is decoded will store decoded TPL into the first entry of the applicable repeater table (forward or reverse) and reset the unit.

Table 1-3. DPL Code Chart

| | | | |
|----------|----------|----------|-----------|
| 0 = 023 | 27 = 172 | 54 = 431 | 81 = 734 |
| 1 = 025 | 28 = 174 | 55 = 432 | 82 = 743 |
| 2 = 026 | 29 = 205 | 56 = 445 | 83 = 754 |
| 3 = 031 | 30 = 223 | 57 = 464 | 84 = 036 |
| 4 = 032 | 31 = 226 | 58 = 465 | 85 = 053 |
| 5 = 043 | 32 = 243 | 59 = 466 | 86 = 122 |
| 6 = 047 | 33 = 244 | 60 = 503 | 87 = 145 |
| 7 = 051 | 34 = 245 | 61 = 506 | 88 = 212 |
| 8 = 054 | 35 = 251 | 62 = 516 | 89 = 225 |
| 9 = 065 | 36 = 261 | 63 = 532 | 90 = 246 |
| 10 = 071 | 37 = 263 | 64 = 546 | 91 = 252 |
| 11 = 072 | 38 = 265 | 65 = 565 | 92 = 255 |
| 12 = 073 | 39 = 271 | 66 = 606 | 93 = 266 |
| 13 = 074 | 40 = 306 | 67 = 612 | 94 = 274 |
| 14 = 114 | 41 = 311 | 68 = 624 | 95 = 325 |
| 15 = 115 | 42 = 315 | 69 = 627 | 96 = 332 |
| 16 = 116 | 43 = 331 | 70 = 631 | 97 = 356 |
| 17 = 125 | 44 = 343 | 71 = 632 | 98 = 446 |
| 18 = 131 | 45 = 346 | 72 = 645 | 99 = 452 |
| 19 = 132 | 46 = 351 | 73 = 654 | 100 = 454 |
| 20 = 134 | 47 = 364 | 74 = 662 | |
| 21 = 143 | 48 = 365 | 75 = 664 | |
| 22 = 152 | 49 = 371 | 76 = 703 | |
| 23 = 155 | 50 = 411 | 77 = 712 | |
| 24 = 156 | 51 = 412 | 78 = 723 | |
| 25 = 162 | 52 = 413 | 79 = 731 | |
| 26 = 165 | 53 = 423 | 80 = 732 | |

Theory of Operation

Microcontroller

The i20R utilizes a 68HC11 MCU to manage timing, audio paths, DPL decoding, and status/CWID tone generation. Customizing the i20R for individual system requirements is accomplished using Radio Service Software (RSS). Operating parameters are stored in a non-volatile EEPROM contained within the 68HC11.

Microcontroller U1, clocked from Y1, is divided internally deriving the 4MHz E-clock. Power-up reset, to initialize the HC11, is provided by U5c, U5d, D1, D104, and associated components. As long as B+ remains above the zener voltage of D104 (plus threshold of U5-13), the reset line remains high. If B+ drops, C4 is discharged through D1, twice inverted and buffered by Schmitt-trigger U5f and e, which results in RES_D being pulled low, causing an MCU reset. Upon power up, C4 is recharged through R24, and the RES_D input is high, allowing MCU initialization. U1 operates in "normal expanded" mode, determined by pull-up resistors R2 and R3 on the MODA and MODB pins. This allows the processor to be used with external memory.

Audio Paths

Audio path control is derived from serial-in, parallel-out data latch U10, under MCU control, via the serial peripheral interface (SPI) bus. This serial bus is also used to communicate with U3, sub-audible processor module and the radio I/O connections.

In the conventional repeat path, receive audio enters the controller via PR5-11 and is routed through analog multiplexer U14A to U3 (a sub-audio signaling processor). U3 generates and decodes the TPL under MCU control. It also performs filtering and data conditioning for TPL tones and DPL data (below 300Hz).

Filtered audio from U3-11, is gated by U13 and combined with tones (beeps, CWID, or status) in summing amplifier U11a. Q7, Q8 and Q9 comprise an audio gate, for the audio path to the forward repeater transmitter.

Q10, Q11, and Q12 perform a similar function for the reverse repeater transmit path. In the "transparent repeat" mode, receive audio originating from either station receiver discriminator, is routed to the flat input of the station transmitter as selected through analog multiplexers U13b, U14a and U14b, where it becomes input to U11b. From there it becomes input to the "flat" input of the transmitter.

Forward repeat audio level is set manually by POT1, while reverse repeat audio level is set by POT3. The transparent repeat audio level is set by POT2.

Accessory transmit audio is routed, either to the flat modulation input, or the pre-emphasized input (EIA) of the station transmitter, via Jumper JU11. Accessory receive audio is derived directly from the station receiver (PR5-11) or "transmitter" RX audio (PR3-11) via selection of jumper JU11.

TPL/DPL Functions

U3, a sub-audible signal processor, decodes the CTCSS (TPL) tones from the system mobiles. It also generates the required CTCSS (TPL) tone derived from ECLK. DPL data originates from the MCU and is conditioned by U3 and output at U3-9. TPL or DPL is gated by U14B/G2 where it becomes an input to U11b. DPL data polarity is determined by U14-9/G3, selecting either the inverting or non-inverting input of U11b.

Data Modulation inverter/buffer U11b, provides up to 200mV RMS into a high impedance load. There it becomes an input to the "FLAT" (non-preemphasized) input of the station transmitter. The required TPL/DPL level is set manually by potentiometer POT2.

DC Power Supply

DC input power is surge protected by R130 and reverse voltage protected by D101. Over-voltage protection is provided by D103.

Series pass transistors Q13, and Q14 regulate the 5V digital source, under control of U12d. Reference is provided by D102. R140 and C32 filter the 5VD source, providing a pure 5V analog source.

A 2.5V reference, provided by U3, is buffered by U12b. R4, and C3 provide a filtered VRH (Volts Reference High) at 5V for the analog to digital (A-D) converter inputs to the MCU.

Low battery sense is provided by sampling the DC input voltage via precision network R87, R88, and R89, then routing it to the internal A-D converter within U1. This will cause low battery alarm tones to be generated, if enabled with RSS.

VOX Operation

Precision rectifiers U12a and U12b comprise VOX detectors for the forward and reverse repeat paths respectively. A sample of the receive audio, derived from the station receiver(s), is referenced against the 2.5V, becoming an input to the MCU FWD_VOX and REV_VOX, where it is validated. If VOX is selected with RSS, and there is no other inhibit, then, a PTT is generated by the MCU to the opposite radio.

Miscellaneous Functions


Each LED has its own driver, Q4-Q6, all under MCU control. Button presses normally pulled high by R26 and R28, are detected by MCU logic inputs PE4 and PE5.


ESD and surge protection for all I/O lines is provided by an extensive complement of diodes (eg. D10 D15 for analog I/Os), while zener diodes protect logic I/Os (eg. D40 D56, etc). RFI/EMI protection is provided on all processor I/O bus lines, by a low-pass filter consisting of RD1 RD22, and CD1 CD25. Digital 5V supply decoupling is provided by L1 and CU1 2.

Programming Interface

J6 is normally used for a local dispatch microphone or handset. Programming and reading of system parameters is also through J6. RSS programming data is interfaced through the Radio Interface Box (RIB) by the Serial Communications Interface port (SCI), a bi-directional, "wired Or" serial port formed by U5a and Q3. Parameters are stored in the MCU's nonvolatile EEPROM.

EMI decoupling boundary






RC2 CONTROLLER
PART 1
SCHEMATIC DIAGRAM SHEET 1


RC2E.SCH 2-19-96

(SHEET 3)




(SHEET 1)


(SHEET 4)




UNUSED SECTIONS




SPI BUS






RADIO I/O CTRL
(SHEET 2)



PR5
RX


PR3



RC2 RADIO INTERFACE
 PART 1
 SCHEMATIC DIAGRAM SHEET 3
 RC2E.SCH 2-19-96


SPI BUS

(SHEET 1)




(SHEET 1)

(SHEET 1)




(SHEET 1)


(SHEET 1)




RC2 RADIO INTERFACE
 PART 2
 SCHEMATIC DIAGRAM SHEET 4
 RC2E.SCH 2-19-96



RC2 RADIO INTERFACE
PART 3
SCHEMATIC DIAGRAM SHEET 5
RC2E.SCH 2-19-96






RC2 CONTROLLER
AUDIO BLOCK DIAGRAM

RC2E.SCH

2-19-96



RC2 parts list

| Reference No. | IAI Part No. | Part Name |
|----------------------------|---------------|-------------------------|
| integrated circuits | | |
| U1 | 9201-10268-04 | 68hc11f1cfna |
| U2 | 3311-30028-00 | ico-286-s8a-t 28pin |
| U2 | 4601-10190-00 | 27c256-25 256k eprom |
| U3 | 9201-50026-00 | mx805alh |
| U4 | 9201-10165-00 | 74hc00adr2 |
| U5 | 9201-10112-00 | 74hc14 |
| U6 | 9201-50016-00 | tpicb595 |
| U7 | 9201-50013-00 | 74hc597 |
| U8 | 9201-50016-00 | tpicb595 |
| U9 | 9201-50013-00 | 74hc597 |
| U10 | 9201-50007-00 | see 9201-10170-00 |
| U11 | 9201-10214-00 | 3403 quad op amp |
| U12 | 9201-10214-00 | 3403 quad op amp |
| U13 | 9201-10021-00 | 4053 analog multiplexer |
| U14 | 9201-10021-00 | 4053 analog multiplexer |
| U15 | 9201-10225-00 | mc3458 |

resistors, fixed: $\pm 5\%$, 1/4w

| | | |
|------------|---------------|---------------|
| R16, R40 | 9203-04702-10 | 47k 0805 pkg |
| R80 | 9203-04702-10 | 47k 0805 pkg |
| R170, R171 | 9203-04702-10 | 47k 0805 pkg |
| R20, R131 | 9203-03300-12 | 330 1206 pkg |
| R132 | 9203-03300-12 | 330 1206 pkg |
| R191, R192 | 9203-03300-12 | 330 1206 pkg |
| R2, R3, R5 | 9203-04701-10 | 4.7k 0805 pkg |
| R9, R11 | 9203-04701-10 | 4.7k 0805 pkg |
| R17, 18 | 9203-04701-10 | 4.7k 0805 pkg |
| R21 | 9203-04701-10 | 4.7k 0805 pkg |
| R19, R37 | 9203-01001-10 | 1k 0805 pkg |
| R155 | 9203-01001-10 | 1k |
| RD1, RD23 | 9203-01001-10 | 1k 0805 pkg |
| RD3 | 9203-01001-10 | 1k 0805 pkg |
| RD4, RD5 | 9203-01001-10 | 1k 0805 pkg |
| RD6 | 9203-01001-10 | 1k 0805 pkg |
| RD7, RD8 | 9203-01001-10 | 1k 0805 pkg |
| RD9 | 9203-01001-10 | 1k 0805 pkg |
| RD10, RD14 | 9203-01001-10 | 1k 0805 pkg |
| RD15 | 9203-01001-10 | 1k 0805 pkg |
| RD16, RD17 | 9203-01001-10 | 1k 0805 pkg |
| RD18 | 9203-01001-10 | 1k 0805 pkg |
| RD191 | 9203-01001-10 | 1k 0805 pkg |
| RD201 | 9203-01001-10 | 1k 0805 pkg |
| RD21 | 9203-01001-10 | 1k 0805 pkg |
| RD25 | 9203-01001-10 | 1k 0805 pkg |
| R8, R38 | 9203-02202-10 | 22k 0805 pkg |
| R25, R27 | 9203-01000-12 | 100 1206 pkg |
| R140 | 9203-01000-12 | 100 1206 pkg |
| RD11, RD12 | 9203-01000-12 | 100 1206 pkg |
| RD13 | 9203-01000-12 | 100 1206 pkg |
| RD22, RD24 | 9203-01001-10 | 1k 0805 pkg |
| RD23 | 9203-01001-10 | 1k 0805 pkg |

RC2 parts list

| Reference No. | IAI Part No. | Part Name |
|---|---------------|---------------|
| resistors, fixed: $\pm 5\%$, 1/4w | | |
| R138, R139 | 9203-00100-12 | 10 1206 pkg |
| R24, R331 | 9203-02203-10 | 220k 0805 pkg |
| R121 | 9203-02203-10 | 220k 0805 pkg |
| R122, R123 | 9203-02203-10 | 220k 0805 pkg |
| R124 | 9203-02203-10 | 220k 0805 pkg |
| R166, R167 | 9203-02203-10 | 220k 0805 pkg |
| R125, R126 | 9203-01004-10 | 1M 0805 pkg |
| R130 | 9203-00010-10 | 1 ohm |
| R93, R94 | 9203-03301-10 | 3.3k 0805 pkg |
| R104 | 9203-03301-10 | 3.3k 0805 pkg |
| R113 | 9203-03301-10 | 3.3k 0805 pkg |
| R31 | 9203-03903-10 | 390k 0805 pkg |
| R136 | 9203-06801-10 | 6.8k 0805 pkg |
| R1 | 9203-01005-10 | 10M 0805 pkg |
| R153 | 9203-03302-10 | 33k 0805 pkg |
| R160, R162 | 9203-04700-12 | 470 1206 pkg |
| R92 | 9203-08201-10 | 8.2k |
| R168, R169 | 9203-08201-10 | 8.2k |
| R172, R173 | 9203-08201-10 | 8.2k |
| R175, R176 | 9203-08201-10 | 8.2k |
| R177, R178 | 9203-08201-10 | 8.2k |
| R174 | 9203-05600-12 | 560 |

resistors, fixed: $\pm 1\%$, 1/4w
unless otherwise specified

| | | |
|------------|---------------|---------------|
| R34, R39 | 9204-01003-10 | 100k 0805 pkg |
| R30, R41 | 9204-01003-10 | 100k 0805 pkg |
| R42, R43 | 9204-01003-10 | 100k 0805 pkg |
| R44 | 9204-01003-10 | 100k 0805 pkg |
| R45, R46 | 9204-01003-10 | 100k 0805 pkg |
| R47 | 9204-01003-10 | 100k 0805 pkg |
| R48, R49 | 9204-01003-10 | 100k 0805 pkg |
| R50 | 9204-01003-10 | 100k 0805 pkg |
| R51, R52 | 9204-01003-10 | 100k 0805 pkg |
| R53 | 9204-01003-10 | 100k 0805 pkg |
| R54, R55 | 9204-01003-10 | 100k 0805 pkg |
| R56 | 9204-01003-10 | 100k 0805 pkg |
| R70, R71 | 9204-01003-10 | 100k 0805 pkg |
| R72 | 9204-01003-10 | 100k 0805 pkg |
| R73, R74 | 9204-01003-10 | 100k 0805 pkg |
| R76 | 9204-01003-10 | 100k 0805 pkg |
| R77, R78 | 9204-01003-10 | 100k 0805 pkg |
| R79 | 9204-01003-10 | 100k 0805 pkg |
| R82, R83 | 9204-01003-10 | 100k 0805 pkg |
| R84 | 9204-01003-10 | 100k 0805 pkg |
| R85, R86 | 9204-01003-10 | 100k 0805 pkg |
| R96, R97 | 9204-01003-10 | 100k 0805 pkg |
| R98, R99 | 9204-01003-10 | 100k 0805 pkg |
| R101 | 9204-01003-10 | 100k 0805 pkg |
| R116, R117 | 9204-01003-10 | 100k 0805 pkg |

transistors

| | | |
|----------|---------------|--------|
| Q12 | 9209-44030-00 | 2n4403 |
| Q21, Q22 | 9209-44030-00 | 2n4403 |
| Q23, Q26 | 9209-44030-00 | 2n4403 |
| Q24, Q25 | 9209-44010-00 | 2n4401 |
| Q27, Q28 | 9209-44010-00 | 2n4401 |

miscellaneous

| | | |
|------------|---------------|--------------------------|
| LED1 | 4602-01503-00 | green LED |
| LED2 | 3306-00750-00 | red LED |
| LED3 | 4602-01400-00 | yellow LED |
| J1, J2, J6 | 4611-52025-14 | 8pin modjack |
| JU11 | 4611-10003-10 | 3pin connector |
| JU20, JU21 | 4611-10002-10 | 2pin header |
| PB1, PB2 | 4612-01210-00 | kslov211 |
| PB1, PB2 | 4612-00750-49 | switch cap for kslov211 |
| PR3, PR4 | 4621-80923-01 | 16pin pcb mt 28-80323v01 |
| PR5 | 4621-80923-01 | 16pin pcb mt 28-80323v01 |
| POT1, 3 | 3305-01002-10 | 10k pot |
| POT2 | 3305-05001-00 | 5k pot |
| L1 | 3307-00099-40 | choke bead 2673000701 |

Appendix B

GR300, M120 and i20R Setup

GR300 Repeater Assembly

The procedures that follow will help you assemble the Radius GR300 repeater with the M120 radios and the i20R Onsite Repeater Controller. Before assembling your GR300 repeater, the following steps should be performed:

1. Place the jumpers inside the radios in the correct positions. Please refer to Table B-1.

| Jumper | Default | Receive Radio | Transmit Radio |
|--------|---------|---------------|----------------|
| JU551 | B | A | A or B |
| JU651 | A | A or B | A |

2. Place the switch on the bottom of the power supply in the proper position (115 Vac or 230 Vac).
3. Place jumper JU20 in the i20R in the "N" position (default).

Refer to the "GR300/GR500 Repeater Stations" service manual (6880903Z42) for the assembly of your GR300.

Programming

Motorola GM300/GR300 RSS (HVN8177) is used to program the radios. Please refer to the "Radius M120/M10 Mobile Radios RSS Manual" (6880903Z28). Instrument Associates RSS (HVN9085) is used to program the i20R. Please refer to the "Radius i20R Repeater Controller RSS Manual" (6880904Z55).

Transmit Radio

1. Connect the RIB programming cable to the transmit radio. Turn on the GR300 power supply. Start the GM300/GR300 RSS.
2. From the "Main Menu" press F3 (GET/SAVE) then press F2 (READ CODEPLUG).
3. When the computer has finished reading the codeplug, press ESC to return to the "MAIN MENU"
4. Press F4 (CHANGE/VIEW CODEPLUG MENU) then press F5 (MODE).
5. In the appropriate highlights:
 - a. Enter the receive frequency, equal to the transmit frequency
 - b. Enter the transmit frequency for the repeater.
 - c. Set the "Rx Squelch Type" and the "Tx Squelch Type" to "CSQ"
 - d. Set the "Time Out Timer (s)" to OFF (enter "000" seconds).

6. Press **Esc** to return to the "MAIN MENU"
7. Press **F3** (GET SAVE).
8. Press **F8** (PROGRAM CODEPLUG) then press **F2** (CONTINUE) to program the transmit radio.
9. Press **F7** (SAVE FILE). Press **F8** to save the data to a disk file.

Receive Radio

1. Move the RIB programming cable to the receive radio.
2. From the "Main Menu", press **F3** (GET/SAVE) then press **F2** (READ CODEPLUG).
3. When the computer has finished reading the codeplug, press **ESC** to return to the "MAIN MENU"
4. Press **F4** (CHANGE/VIEW CODEPLUG MENU) then press **F5** (MODE).
 - a. Enter the receive frequency.
 - b. Enter the transmit frequency as "BLANK"
 - c. Set the "Rx Squelch Type" to "CSQ"
 - d. Use "Local" mode instead of "DX" mode to reduce interference ("IM hits").
5. Press **Esc** to return to the "MAIN MENU" screen.
6. Press **F3** (GET SAVE).
7. Press **F8** (PROGRAM CODEPLUG) then press **F2** (CONTINUE) to program the receive radio.
8. Press the **F7** (SAVE FILE). Press **F8** to save the data to a disk file.

i20R Controller

1. Move the RIB programming cable to the i20R. Start the i20R RSS.
2. From the "Main Menu" press **F3** (GET/SAVE), press **F2** (READ Data) then press **F8** (READ i20R).
3. When the computer has finished reading the codeplug, press **ESC** to return to the "MAIN MENU"
4. Press **F4** (CHANGE/VIEW MENU), press **F3** (Installation Parameters) then press **F3** (Radio Characteristics).
5. Set the "Operational Mode:" to "Uni Dir" and the "Carrier Detect Type" to "Log Carr Dct" The "Time-Out Timer" and "DPL from RX Radio is Inverted" are application dependent. Press **F10** (EXIT).
6. Press **F4** (Radio Connector Settings), then press **F3** (RX Radio Connector). Define pin 8 as "RX Carr Dct" with "ACT LEVEL" as "Low" Press **F10** (EXIT).
7. Press **F5** (TX Radio Connector). Define pin 8 as "TX Carr Dct" with "ACT LEVEL" as "Low" and pin 14 as "Null Input" Press **F10** (EXIT) twice to return to the "Installation Parameters" menu.
8. Press **F5** (REPEATER SETTINGS). To ^(H.A.S.I.K.T.O.) enable TPL/DPL decode by the i20R or more than one user for the repeater operation, set the "Forward Carrier Repeat Operation:" to "Disabled" The other parameters are dependent upon your application. Press **F10** (EXIT).
9. Press **F6** (Unidirectional/Forward Repeater Table). To add a user, press **F4**(ADD ENTRY). To remove a user, press **F3** (DELETE ENTRY). To change the information of a user, select the user (highlight the user number with the up/down arrow keys) and press **F7** (EDIT ENTRY).

10. If the i20R is to regenerate the same TPL or DPL that the field radios transmit to the repeater, in the "Unidirectional/Forward Repeater Table" select "Repeat Method:" as Repeat w/ Alternate PL" You must then complete the information that appears at the bottom of the screen.
11. From the "CHANGE/VIEW MENU" you can select **F4** (Battery Parameters) for a battery revert/backup system, **F5** (Dispatcher Settings) for local operation with a desk microphone or, **F6** (CWID Settings) to define the operation of the Morse Code Station Identification.
12. When you have finished defining the parameters, press **Esc** to return to the "MAIN MENU"
13. Press **F3** (GET/SAVE).
14. Press **F8** (PROGRAM Data) then press **F8** (Program Target i20R) to program the i20R.
15. Press **F7** (SAVE FILE). Press **F8** to save the data to a disk file.

i20R Adjustments

The following steps should be performed with a Communications Service Analyzer (CSA) that is capable of generating a duplex signal at the frequency of the receive radio while monitoring the output frequency of the transmit radio. Such a piece of equipment is the Motorola R2000 series.

1. Place the i20R in test/setup mode #1 by pressing the "TEST" push-button on the front panel one time.
2. Modulate the duplex signal with a 1 kHz tone at 60% rated system peak deviation. Adjust the "FWD" Audio Level on the i20R for 50% peak deviation of the transmit radio. The lower deviation of the repeated audio is necessary to prevent "clipping" of the TPL or DPL signal in the transmit radio. Turn off the 1 kHz tone.
3. Press the "TEST" push-button two more times to place the i20R into test/setup mode #3.
4. Adjust the "SIG" Audio Level potentiometer for 750 Hz peak deviation of the test TPL tone.
5. Simultaneously press the "TEST" and "RPTR" push-buttons to end the test/setup modes.