
Wiltron

Software Version: 1.04

**MODEL
372XXA
VECTOR NETWORK ANALYZER
OPERATION MANUAL**

WILTRON Company has prepared this manual for use by WILTRON Company personnel and customers as a guide for the proper installation, operation and maintenance of WILTRON Company equipment and computer programs. The drawings, specifications, and information contained herein are the property of WILTRON Company, and any unauthorized use or disclosure of these drawings, specifications, and information is prohibited; they shall not be reproduced, copied, or used in whole or in part as the basis for manufacture or sale of the equipment or software programs without the prior written consent of WILTRON Company.

NOTICE

V Connector and K Connector are registered trademarks of WILTRON Company.
GPC-7 is a registered trademark of Amphenol Corporation.
ANACAT is a registered trademark of Esot, Inc.
Ink Jet and Think Jet are registered trademarks of Hewlett-Packard Co.
MS-DOS is a registered trademark of Microsoft Corporation.

TRADEMARK ACKNOWLEDGMENTS

The foregoing warranty does not apply to WILTRON connectors that have failed due to normal wear. Also, the warranty does not apply to defects resulting from improper or inadequate maintenance by the Buyer, unauthorized modification or misuse, or operation outside of the environmental specifications of the product. No other warranty is expressed or implied, and the remedies provided herein are the Buyer's sole and exclusive remedies.

LIMITATION OF WARRANTY

The WILTRON product(s) listed on the title page is (are) warranted against defects in materials and workmanship for one year from the date of shipment.
WILTRON's obligation covers repairing or replacing products which prove to be defective during the warranty period. Buyers shall prepay transportation charges for equipment returned to WILTRON for warranty repairs. Obligation is limited to the original purchaser. WILTRON is not liable for consequential damages.

WARRANTY

Table Of Contents

Chapter 1 — General Information
This chapter provides a general description of the WILTRON Model 372XXA Vector Network Analyzer System and its major units: network analyzer, test set, and frequency source. It also provides descriptions for the precision component kits, and equipment options. Additionally, it contains the listing of recommended test equipment.

Chapter 2 — Installation
This chapter provides instructions for performing an initial inspection, preparing the equipment for use; setting up for operation over the IEEE-488.2 (GPIB) Bus, using a printer; and preparing the units for storage and/or shipment. It also provides a listing of WILTRON Customer Service Centers.

Chapter 3 — Network Analyzers, A Primer
This chapter provides an introduction to network analysis and the types of measurements that can be made using them. It provides general and introductory description.

Chapter 4 — Front Panel Operation
This chapter describes the front panel controls and provides flow diagrams for the menus called up using the front panel controls. It contains the following subchapters:

- Front Panel Control-Group Descriptions
- Calibration Keys and Indicators, Detailed Description
- Save/Recall Menu Key and Menus, Key Description and Menu Flow
- Measurement Keys and Menus, Key Descriptions and Menu Flow
- Channel Keys and Menu, Key Descriptions and Menu Flow
- Display Keys and Menus, Key Descriptions and Menu Flow
- Enhancement Keys and Menus, Key Descriptions and Menu Flow
- Output Keys and Menus, Key Descriptions and Menu Flow
- System State Keys and Menus, Key Descriptions and Menu Flow
- Markers/limits Keys and Menus, Key Descriptions and Menu Flow
- Disk Storage Interface, Detailed Description

Chapter 5 — Error And Status Messages
This chapter describes the type of error messages you may encounter during operation and provides a tabular listing. This listing describes and defines the error types.

Chapter 6 — Data Displays
This chapter provides a detailed description of the various data displays. It describes the graph types, frequency markers, measurement limit lines, status displays, and data display controls.

Chapter 7 — Measurement Calibration
This chapter provides a discussion and tutorial on measurement calibration. It contains step-by-step calibration procedures for the Standard (OSL), Offset-Short, and LRL/LRM methods. It also has a procedure for calibrating using a sliding termination.

Chapter 8 — Measurements
This chapter discusses measurements with the 372XXA VNA. It contains subchapters that provide a detailed descriptions for the following measurement types.

- Transmission and Reflection
- Low Level and Gain
- Group Delay
- Active Device
- Dual Source Control

Chapter 9 — Time Domain
This chapter describes the Option 2, Time Domain feature. It provides an operational procedure and a flowchart of the time domain menus.

Chapter 10 — Operational Checkout Procedures
This chapter provides a procedure for operational checkout.

Appendix A — Front Panel Menus, Alphabetical Listing
This appendix shows all of the menus that are called up using the front panel controls. It provides a replica of the menu and descriptive text for all of the various menu choices. The listing is alphabetical by the menu call letters mentioned and/or illustrated in Chapter 4.

Appendix B — Model 372XXA VNA Rear Panel Connectors
This appendix describes the rear panel connectors. It also provides pinout listing.

Appendix C — Performance Specifications
This appendix provides system performance specifications.


Index

Chapter 1
General Information

Table of Contents

SCOPE OF MANUAL	1-1
INTRODUCTION	1-2
IDENTIFICATION NUMBER	1-3
SYSTEM DESCRIPTION	1-4
PRECISION COMPONENT KITS	1-5
OPTIONS	1-6
PERFORMANCE SPECIFICATIONS	1-7
RECOMMENDED TEST EQUIPMENT	1-8

Figure 1-1. Model 372XXA Vector Network Analyzer System



Chapter 1 General Information

I-1 SCOPE OF MANUAL

This manual provides general information, installation, and operating information for the Model 372XXA Vector Network Analyzer (VNA) system. (Throughout this manual, the terms 372XXA VNA and 372XXA will be used interchangeably to refer to the system.) Manual organization is shown in the table of contents.

I-2 INTRODUCTION

This section provides general information about the 372XXA VNA system and one or more precision-component calibration or performance verification kits. The section also provides a listing of recommended test equipment.

I-3 IDENTIFICATION NUMBER

All WILTRON instruments are assigned a unique six-digit ID number, such as "401001." This number is affixed to a decal on the rear panel of each unit. In any correspondence with WILTRON Customer Service, please use this number.

I-4 SYSTEM DESCRIPTION

The 372XXA Network Analyzer (Figure 1-1) is a single-instrument system that contains a built-in source, test set, and analyzer. It is produced in five models that cover a range of from 22.5 MHz to 40 GHz. It provides up to 1601 measurement data points, a built-in hard-disk drive for storing and recalling front panel setups and measurement and calibration data. It provides an on-screen display of total operational time and date of last frequency and ALC calibration, and the number of power-off cycles since the last calibration. It supports operation over the IEEE 488.2 General Purpose Interface Bus (GPIB).

1-5 PRECISION COMPONENT KITS

Two types of precision-component kits are available: calibration and verification. Calibration kits contain components used to identify and separate error sources inherent in microwave test setups. Verification kits consist of components with characteristics traceable to the National Institute of Standards and Technology (NIST). This type of kit is usually kept in the metrology laboratory where it provides the most dependable means of checking system accuracy. Each of these kits contains a microfloppy disk providing coefficient or measurement data for each component. Details of these kits are described in the following paragraphs.

The 3650 Calibration Kit (Figure 1-2) contains all the precision components and tools required to calibrate the 372XXA VNA for 12-term error-corrected measurements of test devices with SMA or 3.5 mm connectors. Components are included for calibrating both male and female test ports. The kit supports calibration with broadband loads. Option 1 adds sliding loads. Kit consists of the following components:

- 23S50 Short, SMA/3.5 mm Male
- 23SF50 Short, SMA/3.5 mm Female
- 24S50 Open, SMA/3.5 mm Male
- 24SF50 Open, SMA/3.5 mm Female
- 28S50-2 Termination, SMA/3.5 mm Male, 2 ea. (dc-26.5 GHz)
- 28SF50-2 Termination, SMA/3.5 mm Female, 2 ea. (dc-26.5 GHz)
- 33SFSF50 Insertable, SMA/3.5 mm Female/Fe-male, 2 ea.
- 33SS50 Insertable, SMA/3.5 mm Male/Male
- 33SSSF50 Insertable, SMA/3.5 mm Male/Fe-male, 2 ea.
- 34ASF50-2 Adapter, GPC-7 to SMA/3.5 mm Male, 2 ea.
- 34ASF50-2 Adapter, GPC-7 to SMA/3.5 mm Fe-male, 2 ea.
- 01-201 Torque Wrench
- 01-210 Reference Flat
- 01-222 Connector Gauge
- 01-223 Gauge Kit Adapter
- Data Disk

Option 1: Adds 17S50 Sliding Load, SMA/3.5 mm Male; 17SF50 Sliding Load, SMA/3.5 mm Female; 01-211 Female Flush Short; and 01-212 Male Flush Short.




Figure 1-2. Typical Model 365X Calibration Kit

**Model 3650
SMA/3.5 mm
Calibration
Kit**

The 3651 Calibration Kit (Figure 1-2) contains all the precision components and tools required to calibrate the 372XXA for 12-term error-corrected measurements of test devices with GPC-7 connectors. The kit supports calibration with broadband loads. Option 1 adds a sliding load and a pin depth gauge. Kit consists of the following components:

- 23A50 Short, GPC-7
- 24A50 Open, GPC-7
- 28A50-2 Termination, GPC-7, 2 ea.
- (dc-18 GHz)
- 01-200 Torque Wrench
- 01-221 Collet Extractor Tool and Vial of 4 Collets
- Data Disk

Option 1: Adds 17A50 Sliding Load, GPC-7; and 01-220 GPCP-7 Connector Gauge; and 01-210 Reference Flat.

The 3652 Calibration Kit (Figure 1-2) contains all the precision components and tools required to calibrate the 372XXA for 12-term error-corrected measurements of test devices with K Connectors. Components are included for calibrating both male and female test ports. The kit supports calibration with broadband loads. Option 1 adds sliding loads. Kit consists of the following components:

- 23K50 Short, K Male
 - 23KF50 Short, K Female
 - 24K50 Open, K Male
 - 24KF50 Open, K Female
 - 28K50 Termination, K Male, 2 ea.
 - (dc-40 GHz)
 - 28KF50 Termination, K Female, 2 ea.
 - (dc-40 GHz)
 - 33KK50 Insertable, K Male/Male
 - 33KFKF50 Insertable K Female/Female, 2 ea.
 - 33KKF50 Insertable, K Male/Female, 2 ea.
 - 34AK50 Adapter, GPC-7/K Male, 2 ea.
 - 34AKF50 Adapter, GPC-7/K Female, 2 ea.
 - 01-201 Torque Wrench
 - 01-210 Reference Flat
 - 01-222 Connector Gauge
 - 01-223 Gauge Kit Adapter
 - Data Disk
- Option 1:** Adds 17K50 Sliding Load, K Male; 17KFF50 Sliding Load, K Female; 01-211 Female Flush Short; and 01-212 Male Flush Short.

**Model 3651
GPC-7 Cali-
bration Kit**



**Figure 1-2. Typical Model 365X
Calibration Kit (Repeated)**

**Model 3652 K
Connector®
Calibration
Kit**


The 3653 Calibration Kit (Figure 1-2) contains all the precision components and tools required to calibrate the 372XXA for 12-term error-corrected measurements of test devices with Type N connectors. Components are included for calibrating both male and female test ports. The kit supports calibration with broadband loads. Option 1 for sliding loads is not available in this calibration kit. Kit consists of the following components:

- 23NF50 Short, N Male
- 23NF50 Short, N Female
- 24NF50 Open, N Male
- 24NF50 Open, N Female
- 28NF50-2 Termination, N Male, 2 ea. (dc-18 GHz)
- 28NF50-2 Termination, N Female, 2 ea. (dc-18 GHz)
- 34ANF50-2 Adapter, GPC-7/N Male, 2 ea.
- 34ANF50-2 Adapter, GPC-7/N Female, 2 ea.
- 01-213 Type N Reference Gauge
- 01-224 Type N Connector Gauge
- Data Disk

The 3666 Verification Kit (Figure 1-3) contains precision 3.5 mm components with characteristics that are traceable to the NIST. Used primarily by the metrology laboratory, these components provide the most dependable means of determining system accuracy. A disk containing factory-measured test data for all components is supplied for comparison with customer-measured data.


- The 3666 consists of the following components:
- 19S50-7.5 cm Air Line
 - 19S50-7B 7.5 cm Stepped Impedance Air Line (Beatty Standard)
 - 42S-20 20 dB Attenuator
 - 42S-50 50 dB Attenuator

**Model 3653
Type N Cali-
bration Kit**



**Figure 1-2. Typical Model 365X
Calibration Kit (Repeated)**

**Model 3666
3.5 mm Verifi-
cation Kit**



**Figure 1-3. Model 3666
Verification Kit**

Model 3667
GPC-7 Verification Kit

The 3667 Verification Kit (Figure 1-4) contains precision GPC-7 components with characteristics that are traceable to the NIST. Used primarily by the metrology laboratory, these components provide the most dependable means of determining system accuracy. A disk containing factory-measured test data for each component is supplied for comparison with customer-measured data. Kit consists of the following components:

- 18A50-10B 10 cm Stepped Impedance Air Line (Beatty Standard)
- 18A50-10 10 cm Air Line
- 42A-20 20 dB Attenuator
- 42A-50 50 dB Attenuator

The 3668 Verification Kit (Figure 1-5) contains precision K Connector components with characteristics that are traceable to the NIST. Used primarily by the metrology laboratory, these components provide the most dependable means of determining system accuracy. A disk containing factory-measured test data for each component is supplied for comparison with customer-measured data. Kit consists of the following components:

- 19K50-7 7.5 cm Air Line
- 19K50-7B 7.5 cm Stepped Impedance Air Line (Beatty Standard)
- 42K-20 20 dB Attenuator
- 42K-50 50 dB Attenuator

The following options are available.

- Option 2: Time (Distance) Domain Measurement Capability
- Option 3: 1 Hz Frequency Resolution
- Option 4: External SCSI II Hard Disk
- Option 6: Port 2 Test Step Attenuator
- Option 10: Ovenized Timebase
- Option 11: Reference Loop Extension Cables

System performance specifications are provided in Appendix C.

Table 1-1 lists the recommended test equipment for maintaining and servicing the 372XXA VNA system.

1-6 OPTIONS

Figure 1-5. Model 3668 Verification Kit





Figure 1-4. Model 3667 Verification Kit



1-8 RECOMMENDED TEST EQUIPMENT

1-7 PERFORMANCE SPECIFICATIONS

Table 1-1. Recommended Test Equipment

Instrument	Critical Specification	Recommended Manufacturer/Model
Spectrum Analyzer, with Diplexer and External Mixers	Frequency: 0.01 to 40 GHz Resolution: 10 Hz	Tektronix, Inc. Model 2794P, with External Mixers: WM 780K (18 to 26.5 GHz) WM 780A (26.5 to 40 GHz) Diplexer PN: 015-0385-00
Power Meter, with Power Sensors	Range: -30 to +20 dBm (1 μ W to 100 mW) Other: GPIB-controllable	Hewlett-Packard Model 437B, with Power Sensors: HP 8487A (0.05 to 50 GHz)
Digital Multimeter	Resolution: 4-1/2 digits DC Accuracy: 0.002% +2 counts DC Input Z: 10 M Ω AC Accuracy: 0.07% +100 counts (to 20 kHz) AC Input Z: 1 M Ω	John Fluke, Inc. Model 8840A, with Option 8840A-09 (True RMS AC)
Frequency Counter, with External Mixers	Range: 0.01 to 40 GHz Input Z: 50 Ω Resolution: 1 Hz Other: External Time Base Input	EIP Microwave, Inc. Model 578A, with External Mixers: Option 91 (26.5 to 40 GHz)
Oscilloscope	Bandwidth: DC to 150 MHz Vertical Sensitivity: 2 mV/division Horizontal Sensitivity: 50 ns/division	Tektronix, Inc. Model 2445
Function Generator	Output Voltage Range: 300 mV to 10V Functions: 200 Hz Sine Wave 100 Hz Square Wave	Hewlett-Packard Model 3325B

Chapter 2 Installation

Table of Contents

INTRODUCTION	2-1
INITIAL INSPECTION	2-2
PREPARATION FOR USE	2-3
GPIB SETUP AND INTERCONNECTION	2-4
SYSTEM GPIB INTERCONNECTION	2-5
EXTERNAL MONITOR CONNECTOR	2-6
PREPARATION FOR STORAGE AND/OR SHIPMENT	2-7
2-5	

Chapter 2 Installation

2-1 INTRODUCTION

This chapter provides information for the initial inspection and preparation for use of the 372XXA Vector Network Analyzer. Information for interfacing the 372XXA to the IEEE-488 General Purpose Interface Bus and reshipment and storage information is also included.

2-2 INITIAL INSPECTION

Inspect the shipping container for damage. If the container or cushioning material is damaged, retain until the contents of the shipment have been checked against the packing list and the instrument has been checked for mechanical and electrical operation.

If the 372XXA is damaged mechanically, notify your local sales representative or WILTRON Customer Service. If either the shipping container is damaged or the cushioning material shows signs of stress, notify the carrier as well as WILTRON. Keep the shipping materials for the carrier's inspection.

2-3 PREPARATION FOR USE

No initial setup is required. After unpacking, the 372XXA is ready for use. The 372XXA is equipped with automatic line-power sensing, and will operate with any of the following line voltages: 100V, 120V, 220V, 240V +5%, -10%, 48-63 Hz, 350 VA.

2-4 GPIB SETUP AND INTERCONNECTION

All functions of the 372XXA (except power on/off and initialization of the hard disk) can be controlled remotely by an external computer/controller via the IEEE-488.2 GPIB. The information in this section pertains to interface connections and cable requirements for the rear panel GPIB connector. Refer to the Model 372XXA Programming Manual, Wiltron Part Number 10410-00151, for information about remote operation of the 372XXA using the GPIB.

The 372XXA GPIB operates with any IBM XT, AT, or PS/2 compatible computer/controller equipped with a National Instruments GPIB-PCII/IIA interface card and NI-488 MS-DOS Handler Software.

The 372XXA GPIB interface can be configured to control a suitable external plotter (refer to Chapter 6—Data Displays). In this mode of operation, the GPIB is dedicated to this application and only the 372XXA and the plotter are connected to the GPIB. Standard GPIB cables are used to interconnect to the plotter.

GPIB Interface to an External Plotter

There are two rear panel GPIB IEEE-488 connectors. The IEEE 488.2 connector used to interface the 372XXA to an external computer/controller via a standard GPIB cable. The dedicated GPIB connector is used to interface to plotters and a second source for multiple operation via a standard GPIB cable. The WILTRON Part numbers for standard GPIB cables of various lengths are listed in Chapter 1.

2-5 SYSTEM GPIB INTERCONNECTION

For low EMI applications, the GPIB cable should be a fully shielded type, with well-grounded metal-shell connectors.

NOTE

- No more than 15 instruments may be installed on the bus.
- Total accumulative cable length in meters may not exceed two times the number of bus instruments or 20 meters—whichever is less.

The GPIB system can accommodate up to 15 instruments at any one time. To achieve design performance on the bus, proper timing and voltage level relationships must be maintained. If either the cable length between separate instruments or the accumulated cable length between all instruments is too long, the data and control lines cannot be driven properly and the system may fail to perform. Cable length restrictions are as follows:

Cable Length Restrictions

Interface between the 372XXA and other devices on the GPIB is via a standard 24-wire GPIB interface cable. This cable uses a double-sided connector; one connector face is a plug, the other a receptacle. These double-function connectors allow parallel connection of two or more cables to a single instrument connector. The pin assignments for the rear panel GPIB connector are shown in Figure B-1, located in Appendix B.

Interface Connector

GPIB Address
The 372XXA leaves the factory with the default GPIB address set to 6. This address may be changed using the GP7 menu (see Appendix A).

2-6 EXTERNAL MONITOR CONNECTOR

The rear panel EXTERNAL MONITOR connector allows the internal display information of the 372XXA to be connected to an external VGA monitor (either color or monochrome). The pinout of this 15-pin Type D connector is shown in Figure B-4, located in Appendix B.

2-7 PREPARATION FOR STORAGE AND/OR SHIPMENT

The following paragraphs describe the procedure for preparing the 372XXA for storage or shipment.

Preparation for Storage

Preparing the 372XXA for storage consists of cleaning the unit, packing the inside with moisture-absorbing desiccant crystals, and storing the unit in a temperature environment that is maintained between -40 and +70 degrees centigrade (-40 to 156 degrees Fahrenheit).

Preparation for Shipment

To provide maximum protection against damage in transit, the 372XXA should be repackaged in the original shipping container. If this container is no longer available and the 372XXA is being returned to WILTRON for repair, advise WILTRON Customer Service; they will send a new shipping container free of charge. In the event neither of these two options is possible, instructions for packaging and shipment are given below.

Use a Suitable Container

Obtain a corrugated cardboard carton with a 275-pound test strength. This carton should have inside dimensions of no less than six inches larger than the instrument dimensions to allow for cushioning.

Protect the Instrument

Surround the instrument with polyethylene sheeting to protect the finish.

Cushion the Instrument

Cushion the instrument on all sides by tightly packing damage or urethane foam between the carton and the instrument. Provide at least three inches of damage on all sides.

Address the Container
 If the instrument is being returned to WILTRON for service, mark the WILTRON address and your return address on the carton in one or more prominent locations. For international customers, use the address of your local representative (Table 2-1). For U.S.A. customers, use the WILTRON address shown below:

WILTRON Company
 ATTN: Customer Service
 490 Jarvis Drive
 Morgan Hill, CA 95037-2809

Seal the Container
 Seal the carton by using either shipping tape or an industrial stapler.

Table 2-1. WILTRON Service Centers

<p>JAPAN ANRITSU CORPORATION 1800 Onna Atsugi-shi Kanagawa-Prt, 243 Japan Telephone: 0462-23-1111 FAX: 0462-25-8379</p> <p>KOREA WILTRON CORPORATION #2103 Korea World Trade Center 159-1 Samsung-Dong Kangnam-ku, Seoul Telephone: (02) 551-2250 FAX: (02) 551-4941</p> <p>SWEDEN WILTRON AB Box 247 S-127 25 Skarholmen Telephone: (08) 74-05-840 Telex: (854) 81-35-089 FAX: (08) 71-09-960</p> <p>TAIWAN WILTRON CO., LTD. 8F, No. 96, Section 3 Chien Kuo N. Road Taipei, Taiwan, R.O.C. Telephone: (02) 515-6050 FAX: (02) 509-5519</p> <p>UNITED KINGDOM ANRITSU WILTRON LTD. 200 Capabillity Green Luton, Bedfordshire LU1 3LU, England Telephone: 05-82-41-88-53 Telex: (851) 826750 FAX: 05-82-31-303</p>	<p>CHINA WILTRON BEIJING SERVICE CENTER 416W Beijing Fortune Building 5 Dong San Huan Bei Lu Chao Yang Qu, Beijing 100004, China Telephone: 86-1-50-17-559 FAX: 86-1-50-17-558</p> <p>FRANCE ANRITSU WILTRON S.A 9 Avenue du Quebec Zone de Courtabœuf 91951 Les Ulis Cedex Telephone: 016-44-66-546 FAX: 016-44-61-065</p> <p>GERMANY ANRITSU WILTRON GmbH Rudolf Diesel Straße 17 8031 Garching Telephone: 08-10-58-055 Telex: (841) 528523 FAX: 08-10-51-700</p> <p>INDIA ACCUTROL SYSTEMS PRIVATE LIMITED Nirmal, 15th Floor Narimen Point Bombay 400 021 Telephone: 011-91-22-202-2220 FAX: 011-91-22-202-9403</p> <p>ISRAEL TECH-CENT, LTD Haarad St. No. 7, Ramat Haahayal Tel-Aviv 69701 Telephone: (03) 64-78-563 FAX: (03) 64-78-334</p> <p>ITALY ANRITSU WILTRON S.p.A Roma Office Via E. Vittorini, 129 00144 Roma EUR Telephone: (06) 50-22-666 FAX: (06) 50-22-4252</p>	<p>UNITED STATES WILTRON COMPANY 490 Jarvis Drive Morgan Hill, CA 95037-2809 Telephone: (408) 778-2000 Telex: 265227 WILTRON MH FAX: 408-778-0239</p> <p>ANRITSU WILTRON SALES COMPANY 685 Jarvis Drive Morgan Hill, CA 95037-2809 Telephone: (408) 776-8300 FAX: 408-776-1744</p> <p>ANRITSU WILTRON SALES COMPANY 10 Kingsbridge Road Fairfield, NJ 07004 Telephone: (201) 227-8999 FAX: 201-575-0092</p> <p>AUSTRALIA WILTRON PTY, LTD. Level 2, 410 Church Street North Parramatta NSW 2151 Australia Telephone: 026-30-81-66 Fax: 026-83-68-84</p> <p>BRAZIL ANRITSU-WILTRON Anritsu Electronica Ltda. Praia de Botafogo 440-Saia 2,401-Botafogo 2225 Rio de Janeiro RJ Brazil Telephone: 021-28-69-141 Fax: 021-53-71-456</p> <p>CANADA ANRITSU WILTRON INSTRUMENTS LTD. 215 Stafford Road, Unit 102 Nepean, Ontario K2H 9C1 Telephone: (613) 828-4090 FAX: (613) 828-5400</p>
--	---	--

Chapter 3
Network Analyzers,
A Primer

Table of Contents

3-1	INTRODUCTION	3-3
3-2	GENERAL DESCRIPTION	3-3
	Source Module	3-4
	Test Set Module	3-4
	Analyzer Module	3-5
3-3	NETWORK ANALYZERS	3-5
	Scalar Analyzer Comparison	3-5
	Vector Network Analyzer Basics	3-6
	Network Analyzer Measurements	3-9
	Measurement Error Correction	3-11
	Summary	3-11

Chapter 3 Network Analyzers, A Primer

3-1 INTRODUCTION

This section provides front panel operating and measurement application information and data. It includes discussions on the following topics:

- System description
- General discussion about network analyzers
- Basic measurements and how to make them
- Error correction
- General discussion on test sets

3-2 GENERAL DESCRIPTION

The Model 372XXA Vector Network Analyzer System measures the magnitude and phase characteristics of networks: amplifiers, attenuators, and antennas. It compares the incident signal that leaves the analyzer with either the signal that is transmitted through the device or the signal that is reflected from its input. Figures 3-1 and 3-2 illustrate the types of measurements that the 372XXA can make.




Figure 3-1. Transmission Measurements

The test set module routes the stimulus signal to the DUT and samples the reflected and transmitted signals. The type of connector used is important, as is the "Auto Reversing" feature. Auto Reversing means that it applies the stimulus signal in both the forward and reverse direction. The direction is reversed automatically. This saves you from having to reverse the test device physically to measure all four scattering parameters (S-parameters). Frequency conversion (1st and 2nd IFs) occurs in the test set.

Test Set Module

This module provides the stimulus to the device under test (DUT). The frequency range of the source and test set modules establish the frequency range of the system. The frequency stability of the source is an important factor in the accuracy (especially phase accuracy) of the network analyzer. Hence, the 372XXA always phase locks the source to an internal 10 MHz crystal reference.


Source Module

The 372XXA internal system modules perform the following functions:

- Analyzer
- Precision components required for calibration and performance verification.
- Optional use of WILTRON 67XXB or 681XXA/B as a second source.

The 372XXA is a self-contained, fully integrated measurement system that includes an optional time domain capability. The system hardware consists of the following:

Figure 3-2. Reflection Measurements



The analyzer module down-converts, receives, and interprets the 3rd IF signal for phase and magnitude data. It then displays the results of this analysis on a large, 190 mm (7-1/2 inch) diagonal color display. This display can show all four S-parameters simultaneously. In addition to the installed display, you can also view the measurement results on an external color monitor.

Analyzer Module

We will begin this discussion with a subject familiar to most WILTRON customers: scalar network analysis. After showing comparisons, we will proceed to the fundamentals of network analyzer terminology and techniques. This discussion serves as an introduction to topics presented in greater detail later in this section. This discussion will touch on new concepts that include the following:

- Reference Delay
- S-parameters: what they are and how they are displayed
- Complex Impedance and Smith Charts

Network Analyzers do everything that scalar analyzers do except display absolute power. In addition, they add the ability to measure the phase characteristics of microwave devices and allow greater dynamic range.

If all a Network Analyzer added was the capability for measuring phase characteristics, its usefulness would be limited. While phase measurements are important in themselves, it is the availability of this phase information that unlocks many new features for complex measurements. These features include Smith Charts, Time Domain, and Group Delay. Phase information also allows greater accuracy through *vector error correction* of the measured signal.

Scalar Analyzer Comparison




Figure 3-3. Scalar analyzer detection

First, let us look at scalar network analyzers (SNAs). SNAs measure microwave signals by converting them to a DC voltage using a diode detector (Figure 3-3). This DC voltage is proportional to the magnitude of the incoming signal. The detection process, however, ignores any information regarding the phase of the microwave signal.

In a network analyzer, access is needed to both the magnitude and phase of a microwave signal. There are several different ways to perform the measurement. The method WILTRON employs (called Har-

monic Sampling or Harmonic Mixing) is to down-con-
vert the signal to a lower intermediate frequency
(IF). This signal can then be measured directly by a
tuned receiver. The tuned receiver approach gives
the system greater dynamic range. The system is
also much less sensitive to interfering signals, in-
cluding harmonics.

**Vector
Network Ana-
lyzer Basics**

The network analyzer is a tuned receiver (Figure 3-
5, left). The microwave signal is down converted into
the passband of the IF. To measure the phase of this
signal, we must have a reference to compare it with.
If the phase of a signal is 90 degrees, it is 90 degrees
different from the reference signal (Figure 3-6, left).
The network analyzer would read this as -90 de-
grees, since the test signal is delayed by 90 degrees
with respect to the reference signal.

This phase reference can be obtained by splitting off
some of the microwave signal before the measure-




Figure 3-4. Splitting the microwave signal

The phase of the microwave signal after it has
passed through the device under test (DUT) is then
compared with the reference signal. A network ana-
lyzer test set automatically samples the reference
signal, so no external hardware is needed.

Let us consider for a moment that you remove the
DUT and substitute a length of transmission line

(Figure 3-7, left). Note that the path length of the
test signal is longer than that of the reference signal.
Now let us see how this affects our measurement.




Figure 3-5. Network analyzer is a
tuned receiver




Figure 3-6. Signals with a
90 degree phase difference




Figure 3-7. Split signal where a
length of line replaces the DUT

Assume that we are making a measurement at 1 GHz and that the difference in path-length between the two signals is exactly 1 wavelength. This means that test signal is lagging the reference signal by 360 degrees (Figure 3-8). We cannot really tell the difference between one sine wave maxima and the next (they are all identical), so the network analyzer would measure a phase difference of 0 degrees.

Now consider that we make this same measurement at 1.1 GHz. The frequency is higher by 10 percent so therefore the wavelength is shorter by 10 percent. The test signal path length is now 0.1 wavelength longer than that of the reference signal (Figure 3-9). This test signal is:

$$1.1 \times 360 = 396 \text{ degrees}$$

This is 36 degrees different from the phase measurement at 1 GHz. The network analyzer will display this phase difference as -36 degrees.

The test signal at 1.1 GHz is delayed by 36 degrees more than the test signal at 1 GHz.

You can see that if the measurement frequency is 1.2 GHz, we will get a reading of -72 degrees, -108 degrees for 1.3 GHz, etc. (Figure 3-10). There is an electrical delay between the reference and test signals. For this delay we will use the common industry term of reference delay. You also may hear it called phase delay. In older network analyzers you had to equalize the length of the reference arm with that of the test arm to make an appropriate measurement of phase vs. frequency.

To measure phase on a DUT, we want to remove this phase-change-vs.-frequency-due-to changes in the electrical length. This will allow us to view the actual phase characteristics. These characteristics may be much smaller than the phase-change-due-to-electrical-length difference.




Figure 3-8. Split signal where path length differs by exactly one wavelength




Figure 3-9. Split signal where path length is longer than one wavelength




Figure 3-10. Electrical Delay

There are two ways of accomplishing this. The most obvious way is to insert a length of line into the reference signal path to make both paths of equal length (Figure 3-11, below). With perfect transmission lines and a perfect splitter, we would then measure a constant phase as we change the frequency. The problem using this approach is that we must change the line length with each measurement setup.




Figure 3-11. Split signal where paths are of equal length

Another approach is to handle the path length difference in software. Figure 3-12 (left) displays the phase-vs.-frequency of a device. This device has different effects on the output phase at different frequencies. Because of these differences, we do not have a perfectly linear phase response. We can easily detect this phase deviation by compensating for the linear phase. The size of the phase difference increases linearly with frequency so we can modify the phase display to eliminate this delay.

The 372XXA offers automatic reference delay compensation with the push of a button. Figure 3-13 (left) shows the resultant measurement when we compensate path length. In a system application you can usually correct for length differences; however, the residual phase characteristics are critical.




Figure 3-12. Phase difference increases linearly with frequency




Figure 3-13. Resultant phase with path length compensation in place

Now let us consider measuring the DUT. Consider a two port device; that is, a device with a connector on each end. What measurements would be of interest?

Network Analyzer Measurements

First, we could measure the reflection characteristics at either end with the other end terminated into 50 ohms. If we designate one end as the normal place for the input that gives a reference. We can then define the reflection characteristics from the reference end as forward reflection, and those from the other end as reverse reflection (Figure 3-14).

Second, we can measure the forward and reverse transmission characteristics. However, instead of saying "forward," "reverse," "reflection," and "transmission" all the time, we use a shorthand. That is all that S-parameters are, a shorthand! The "S" stands for scattering. The first number is the port that the signal is being injected into, while the second is the port that the signal is leaving. S₁₁, therefore, is the signal being injected into port 1 relative to the signal leaving port 1. The four scattering parameters (Figure 3-15):

- S₁₁ Forward Reflection
- S₂₁ Forward Transmission
- S₂₂ Reverse Reflection
- S₁₂ Reverse Transmission

S-parameters can be displayed in many ways. An S-parameter consists of a magnitude and a phase. We can display the magnitude in dB, just like a scalar network analyzer. We often call this term *log magnitude*.

We can display phase as "linear phase" (Figure 3-16). As discussed earlier, we can't tell the difference between one cycle and the next. Therefore, after going through 360 degrees we are back to where we began. We can display the measurement from -180 to +180 degrees. The -180 to +180 approach is more common. It keeps the display discontinuity removed from the important 0 degree area used as the phase reference.




Figure 3-14. Forward and reverse measurements




Figure 3-15. S-parameters




Figure 3-16. Linear phase-with-frequency waveform

There are several ways in which all the information can be displayed on one trace. One method is a polar display (Figure 3-17). The radial parameter (distance from the center) is magnitude. The rotation around the circle is phase. We sometimes use polar displays to view transmission measurements, especially on cascaded devices (devices in series). The transmission result is the addition of the phase and log magnitude (dB) information of each device's polar display.

As we have discussed, the signal reflected from a

DUT has both magnitude and phase. This is because the impedance of the device has both a resistive and a reactive term of the form $r+jx$. We refer to the r as the real or resistive term, while we call x the imaginary or reactive term. The j , which we sometimes denote as i , is an imaginary number. It is the square root of -1 . If x is positive, the impedance is inductive, if x is negative the impedance is capacitive.

The size and polarity of the reactive component x is important in impedance matching. The best match to a complex impedance is the complex conjugate.

This complex-sounding term simply means an impedance with the same value of r and x , but with x of opposite polarity. This term is best analyzed using a Smith Chart (Figure 3-18), which is a plot of r and x .

To display all the information on a single S-parameter requires one or two traces, depending upon the format we want. A very common requirement is to view forward reflection on a Smith Chart (one trace) while observing forward transmission in Log Magnitude and Phase (two traces). Let us see how to accomplish this in the 372XXA.

The 372XXA has four channels. Each channel can display a complete S-parameter in any format on either one or two traces. All four S-parameters can be seen simultaneously in any desired format. A total of eight traces can be viewed at the same time. While this is a lot of information to digest, the 372XXA's large color display makes recognizing and analyzing the data surprisingly easy.




Figure 3-17. Polar display




Figure 3-18. Smith chart

A network analyzer is similar to a scalar network analyzer. The major difference is that it adds the capability for measuring phase as well as amplitude. With phase measurements comes scattering, or S-parameters, which are a shorthand method for identifying forward and reverse transmission and reflection characteristics. The ability to measure phase introduces two new displays, polar and Smith Chart. It also adds vector error correction to the measurement trace. With vector error correction, errors introduced by the measurement system are compensated for

Summary

To accomplish this error correction, we measure the magnitude and phase of each error signal (Figure 3-19). Magnitude and phase information appear as a vector that is mathematically applied to the measurement signal. This process is termed *vector error correction*.

We can correct for each of these six error terms in both the forward and reverse directions, hence the name 12-term error correction. Since 12-term error correction requires both forward and reverse measurement information, the test set must be *reversing*. "Reversing" means that it must be able to apply the measurement signal in either the forward or reverse direction.


- Source Test Port Match
- Load Test Port Match
- Directivity
- Isolation
- Transmission Frequency Response
- Reflection Frequency Response

Since we can measure microwave signals in both magnitude and phase, it is possible to correct for six major error terms:

Measurement Error Correction

Another important parameter we can measure when linear devices, the phase change through the DUT is linear with frequency. Thus, doubling the frequency also doubles the phase change. An important measurement, especially for communications systems users, is the rate of change-of-phase-vs.-frequency (group delay). If the rate of phase-change-vs.-frequency is not constant, the DUT is nonlinear. This nonlinearity can create distortion in communications systems.

Figure 3-19. Magnitude and phase measurements



and measurement uncertainty is minimized. Phase measurements also add the capability for measuring group delay, which is the rate of change-of-phase-vs.-frequency (group delay). All in all, using a network analyzer provides for making a more complete analysis of your test device.

Chapter 4

Front Panel Operation

Table of Contents

4-1	INTRODUCTION	4-3
4-2	FRONT PANEL KEY-GROUP DESCRIPTIONS	4-3
4-3	CALIBRATION KEY-GROUP, DESCRIPTIONS AND MENU FLOW	4-9
4-4	SAVE/RECALL MENU KEY, DESCRIPTION AND MENU FLOW	4-17
4-5	MEASUREMENT KEY-GROUP, DESCRIPTION AND MENU FLOW	4-18
4-6	CHANNELS KEY-GROUP, DESCRIPTION AND MENU FLOW	4-20
4-7	DISPLAY KEY-GROUP, DESCRIPTION AND MENU FLOW	4-21
4-8	ENHANCEMENT KEY-GROUP, DESCRIPTION AND MENU FLOW	4-25
4-9	HARD COPY KEY-GROUP, DESCRIPTION AND MENU FLOW	4-27
4-10	SYSTEM STATE KEY-GROUP, DESCRIPTION AND MENU FLOW	4-29
4-11	MARKERS/LIMITS KEY-GROUP, DESCRIPTION AND MENU FLOW	4-32
4-12	DISK STORAGE INTERFACE	4-36




Figure 4-1. Model 37247A Vector Network Analyzer Front Panel

Chapter 4 Front Panel Operation

4-1 INTRODUCTION

This chapter describes the front panel keys, controls, and menus. The chapter is organized into an overall description of the front panel key-groups and detailed descriptions of individual keys within the key-groups.

4-2 FRONT PANEL KEY-GROUP DESCRIPTIONS

The following pages provide descriptions of the front panel key-groups.

Index 1.

CRT display: Displays any or all of the four measurement channels, plus menus.

Index 2.

Power: Turns the 372XXA on and off. When on, the operating program runs a self test then recalls the parameters and functions in effect when powered down last.

Index 3.

GPB Indicators

Remote: Lights when the 372XXA switches to remote (GPB) control. It remains lit until the unit returns to local control.

Talk: Lights when you address the 372XXA to talk and remains lit until unaddressed.

Listen: Lights when you address the 372XXA to listen and remains lit until unaddressed.

SRQ: Lights when the 372XXA sends a Service Requests (SRQ) to the external controller. The LED remains lit until the 372XXA receives a serial poll or until the controller resets the SRQ function.

Local Lockout: Lights when a local lockout message is received. The LED remains lit until the message is rescinded. When lit, you cannot return the 372XXA to local control via the front panel.

Index 4. System State keys

Default Program: Resets the front panel to the factory-preset state and displays Menu SU1 or SU3. Pressing this key in conjunction with the "0" or "1" key resets certain internal memories and front panel key states (refer to paragraphs 4-5 and 4-10).

CAUTION

Use of this key will destroy front panel and calibration setup data, unless they have been saved to disk.

Utility Menu: Displays the first in a series of menus that let you perform diskette and other utility-type functions and operations.

Index 5.

Port 1 Test Connector: Provides an input test connection for the device-under-test (DUT).

Index 6.

Calibration keys

Begin Cal: Calls up the first in a sequence of menus that guide you through a measurement calibration. Refer to paragraph 4-3 for a detailed discussion of the calibration keys, indicators, and menus.

Apply Cal: Turns on and off the applied error correction and tune mode.

Index 7.

Save/Recall Menu Key: Displays the first of several menus that let you save the current calibration or front panel setup or recall a previously saved calibration or setup.

Index 8.

Hard Copy keys

Menu: Displays option menus that let you define what will happen each time you press the Start Print key. The displayed menu also selects disk I/O operations.

Start Print: Tells the printer or plotter to start output based on the current selections or plotting.

Stop Print: Immediately stops printing the data, clears the print buffer, and sends a form-feed command to the printer.

Markers/Limits keys

Index 9.

Marker Menu: Displays the first in a series of menus that let you set and manipulate marker frequencies, times, and distances.

Readout Marker: Displays a menu that lists all of the active markers. If no markers are active, the marker menu is displayed.

Limits: Displays one of the menus that let you manipulate the limit lines displayed on the CRT.

Port 2 Test Connector: Provides an input test connection for the device-under-test (DUT).

Display keys

Graph Type: Displays the two menus that let you choose the graph type for the active channel.

Set Scale: Displays the appropriate scaling menu, based on the graph type for the active channel.

Auto Scale: Automatically scales the active channel for optimum viewing.

S Params: Displays Menu SP (Appendix A), which lets you choose between S11, S12, S21, or S22. You may display the same parameter on two or more channels.

Ref Plane: Displays the first of two menus that let you set the reference plane for the active channel in time or distance. For a correct distance readout, you must set the dielectric constant to the correct value. Refer to the discussion in menu RD2 (Appendix A).

Trace Memory: Displays the menus that let you do any of the following. (1) Store the measured data in memory. (2) View the stored data. (3) Add, subtract, multiply, or divide the measured data from the stored data (normalize to the stored memory). (4) View both the measured and the stored data simultaneously on the active channel. (5) Store/Recall saved data to disk. Four memories exist — one for each channel. This lets you normalize the data in each channel independently. The LED on this button lights when the active channel is displaying memory data or measurement data normalized to memory.

Bias Input connectors *Index 12.*

Port 1: Provides for supplying a bias voltage for the Port 1 input.

Port 2: Provides for supplying a bias voltage for the Port 2 input.

Enhancement keys *Index 13.*

Option Menu: Displays a series of menus showing the choice of optional features.

Video IF BW: Displays a menu that lets you choose between 10 kHz, 1 kHz, 100 Hz, or 10 Hz intermediate frequency (IF) bandwidth filters.

Avg/Smooth Menu: Displays a menu that lets you enter values for Averaging and Smoothing.

Trace Smooth: Turns the trace smoothing function on and off.

Average: Turns the average function on and off.

Index 14.

Keyboard connector: Provides for connecting an external IBM-AT-type keyboard. All alphanumeric field entries can be input from this keyboard. These inputs include Device ID, Model, Date, Operator Identification, frequencies, filenames, as well as comment-type entries. The analog knob and keypad input for these entries remains active.

Index 15.

Diskette Drive: Provides a drive for the 3.5-inch, high-density (1.44 MB) floppy diskette used to store selected front panel setups and calibrations.

Index 16.

Channels keys

Channel Menu: Displays a menu that lets you select the format for the number of channels displayed.

Ch 1: Makes Channel 1 the active channel. The active channel is the one acted on by the keys in the Display section. Only one channel can be active at any one time.

Ch 2: Makes Channel 2 the active channel.

Ch 3: Makes Channel 3 the active channel.

Ch 4: Makes Channel 4 the active channel.

Index 17.

Measurement keys

Setup Menu: Displays the first of several menus that let you select functions affecting measurements.

Data Points: Displays a menu that lets you select between 1601, 801, 401, 201, 101, or 51 data points.

Hold: Toggles the instrument in and out of the hold mode; or it triggers a sweep, depending on the function selected in menu SU4 (Appendix A).

Domain: Displays the first in a series of menus that let you set the Time Domain display parameters. (This key is only active if your 372XXA is equipped with the Time Domain option.)

If already in the Domain menus, pressing this key will return to the first menu in the sequence.

If in the Domain menus and another (non-time domain) menu is displayed by pushing a menu key, the last displayed domain menu redisplay when the Domain key is next pressed.

Device ID: Displays a menu that lets you identify your test device.

Index 18.

Data Entry keys

Rotary Knob: Used to alter measurement values for the active parameter (Start Frequency, Stop Frequency, Offset, etc.).

Keypad: Provides for entering values for the active parameter. The active parameter is the one to which the menu cursor is pointing.

MHz/X1/ns/cm: Terminates a value entered on the keypad in the units shown—that is, megahertz for frequency, unity for dimensionless or angle entries, nanoseconds for time, or centimeters for length.

GHZ/10³/μs/m: Terminates a value entered on the keypad in the units shown—that is; gigahertz for frequency, 1X10³ power for dimensionless or angle entries, microseconds for time, or meters for length.

KHZ/10³/ps/mm: Terminates a value entered on the keypad in the units shown—that is; kilohertz for frequency, 1X10³ for dimensionless or angle entries, picoseconds for time, or millimeters for length.

Clear/Ret Loc:

- a. *Local (Non-GPIB) Mode:* (1) The key clears entries not yet terminated by one of the terminator keys above, which allows the previously displayed values to redisplay. Or (2) the key turns off the displayed menu, if you have not made any keypad entries needing termination.

- b. *GBIB Mode:* The key returns the instrument to local (front panel) control, unless the controller has sent a local lockout message (LLO) over the bus.

Menu keys


Arrow keys: They move the menu cursor up and down to select items appearing in the menu area of the CRT.

Enter: Implements the menu selection chosen using the arrow keys.

Index 19.

4-3 CALIBRATION KEY-GROUP, DESCRIPTIONS AND MENU FLOW


DESCRIPTIONS AND MENU FLOW



The Calibration keys (Begin Cal and Apply Cal, left) are described below. The calibration menus are diagrammed according to the method of calibration performed: Standard, Offset-Short, or LRL/LRM. The menu sequencing is complex and looping and can be said to have two parts: setup and calibration. The setup flow for the three calibration methods is diagrammed in Figures 4-2 thru 4-4. Each setup flow chart leads to the main calibration sequence, which is diagrammed in Figure 4-5. A full description of each menu is provided in Appendix A, where the menus are arranged in alphabetical order by call letter (C1, C2, C3, etc).

Begin Cal Key: This key displays a menu that lets you initiate the calibration sequence. That is, to begin a sequence of steps that corrects for errors inherent in a measurement setup.

Apply Cal Key: This key displays a menu (left) that lets you turn on and off the error correction that may be applied to the displayed channel(s) using the currently valid error-correction indicator. Additionally, the menu lets you turn tune mode on and off and change the number of forward sweeps between reverse sweeps (or reverse sweeps between forward sweeps).



NOTE
 Pressing the Clear key while in a calibration setup or sequencing will let you abort the calibration and return to the first setup menu.

Standard Calibration Setup Flow-Description


1. Pressing the Begin Cal key calls Menu C11.
2. With one exception, the flow is from left to right in the direction of the arrow head. The exception occurs in Menu C1, for the TIME DOMAIN choice. Here the flow direction reverses to Menu C2C then returns to a left-to-right flow on to Menu C3 or C3D.
3. Arrowheads that point both left and right indicate that the flow re- turns to the right-most menu after a choice had been made.
4. The group of menus to the left of Menu C3 and C3D are the initial selection set and are essentially the same for all three calibration types: Standard, Offset-Short, and LRL/RM.
5. The group of menus that follow Menu C3 or C3D are, for the most part, type specific. The selection of Menu C3 or C3D depends upon the choice made in Menu C11A: COAXIAL or MICROSTRIP. For the Standard Calibration, the WAVEGUIDE selection in Menu C11A is not used.

Offset-Short Calibration Setup Flow - Description

1. Pressing the Begin Cal key calls Menu C11.
2. With one exception, the flow is from left to right in the direction of the arrow head. The exception occurs in Menu C1, for the TIME DOMAIN choice. Here the flow direction reverses to Menu C2C then returns to a left-to-right flow on to Menu C3A, C3C, or C3B.
3. Arrowheads that point both left and right indicate that the flow returns to the right-most menu after a choice had been made.
4. The group of menus to the left of Menu C3A, C3C, or C3B are the initial selection set and are essentially the same for all three calibration types: Standard, Offset-Short, and LRL/LRM.
5. The group of menus that follow Menu C3A, C3C, or C3B are, for the most part, type specific. The selection of Menu C3A, C3C, or C3B depends upon the choice made in Menu C11A: COAXIAL, WAVEGUIDE, or MICROSTRIP.

LRL/LRM Calibration Setup flow - Description

1. Pressing the Begin Cal key calls Menu C11.
2. With one exception, the flow is from left to right in the direction of the arrow head. The exception occurs in Menu C1, for the TIME DOMAIN choice. Here the flow direction reverses to Menu C2C then returns to a left-to-right flow on to Menu C3E, C3G, or C3F.
3. Arrowheads that point both left and right indicate that the flow returns to the right-most menu after a choice had been made.
4. The group of menus to the left of Menu C3E, C3G, or C3F are the initial selection set and are essentially the same for all three calibration types: Standard, Offset-Short, and LRL/LRM.
5. The group of menus that follow Menu C3E, C3G, or C3F are, for the most part, type specific. The selection of Menu C3E, C3G, or C3F depends upon the choice made in Menu C11A: COAXIAL, WAVEGUIDE, or MICROSTRIP.



* Menu SU1/SU3 - See Figure 4-6
** Cal Seq (Calibration Sequence) - See Figure 4-5

Figure 4-4. Menu Sequencing, LRL/LRM Calibration




Figure 4-5. Calibration Sequence Menus


FRONT PANEL OPERATION

SAVE/RECALL MENU KEY DESCRIPTION AND MENU FLOW

4-4

SAVE/RECALL MENU KEY, DESCRIPTION AND MENU FLOW

Pressing this key displays the first of a menu set (below) that lets you save or recall control panel setups and calibration data. Full menu descriptions can be found in the alphabetically ordered Appendix A under the menu's call letters (SR1, SR2, SR3, etc).



4-5
MEASUREMENT
KEY-GROUP,
DESCRIPTION AND
MENU FLOW

The individual keys within the Measurement key-group are described below. Flowcharts of the Setup Key and Data Points key menus are shown in Figure 4-6. As described for the calibration menus, the flow is left-to-right and the double arrowheaded lines indicate that the flow returns to the calling menu once a selection has been made. Full menu descriptions can be found in the alphabetically ordered Appendix A under the menu's call letters (SU1, SU2, DF, etc).

Setup Menu Key: Pressing this key calls Sweep Setup Menu SU1 or SU3. Depending upon which menu items you select, additional menus may also be called.

Data Points Key: Pressing this key calls Menu SU9 or SU9A. Menu SU9 provides for data point selection. Menu SU9A is called if the C.W. MODE selection in Menu SU1 is on.

Hold Key: If the instrument is sweeping, pressing this key results in an immediate halt of the sweep at the current data point. The LED on the button lights, indicating that the Hold Mode is active.

If you restart the sweep after performing any recall-from-disk operations in the Hold Mode (sweep stopped at some data point), the sweep restarts from the beginning. The instrument may be taken out of the hold mode as follows:

- By pressing the Default Program button. This causes the 372XXA to revert to a predefined state.
- By pressing the BEGIN CAL key. This causes the 372XXA to resume sweeping and begin the Calibration Menu sequence.

NOTE

See the description for Menu SU4 for a discussion of the interaction between the Hold Mode and the selection of "Single Sweep" or "Restart Sweep"

Domain Key: This key function is fully described in paragraph 4-2 (page 4-7). Additionally, if the Time Domain option is installed, making a selection other than "Frequency Domain" lets you display measured data in the time domain. It also calls a further sequence of Time Domain Menus. Refer to paragraph 9-2 for additional details.

Device ID Key: Pressing this key calls a menu that lets you enter a name for the test device. This key has the same effect as selecting "Device ID" in the PM2 menu.




Figure 4-6. Measurement Key-Group


**4-6 CHANNELS KEY-GROUP,
DESCRIPTION AND
MENU FLOW**

The individual keys within the Channels key-group are described below.

Ch 1-4 Keys: These keys (left) define the active channel. One (and only one) must always be active as indicated by the associated LED. Pressing a button makes the indicated channel active. If channel indicated by the key is already active, pressing the key has no effect.

The active channel will be the channel acted upon by the S Params, Graph Type, Ref Plane, Trace Memory, Set Scale, Auto Scale, Markers/Limits and Domain keys. When in the single channel display mode, the active channel will be the one displayed.

Channel Menu : Pressing this key calls menu CM (below). Here, you select the number of channels to be displayed. When in the single display mode, only the active channel will be displayed. Full menu description can be found in the alphabetical listing (Appendix A) under the menu's call letters (CM).



**4-7
DISPLAY KEY-GROUP,
DESCRIPTION AND
MENU FLOW**

The individual keys within the Display key-group are described below. Menu flow diagrams are shown in Figure 4-7. Full menu description(s) for menu SF and all others mentioned below can be found in the Appendix A alphabetical listing under the menu's call letters (SF, GT1, RD1, etc).

Graph Type Key: Pressing this key calls menu GT1 or GT2. These menus let you select the type of display to appear on the active channel for the selected S-Parameter.

Set Scale Key: Pressing this key calls the appropriate scaling menu (SS1, SS2, SS3, etc.) depending upon the graph type being displayed on the active channel for the selected S-Parameter.

Auto Scale Key: Pressing this key autoscales the trace or traces for the active channel. The new scaling values are then displayed on the menu (if it is displayed) and graphic. The resolution will be selected from the normal sequence of values you have available using the knob. When the active channel has a Real and Imaginary type display, the larger of the two signals will be used to autoscale both the real and imaginary graphs. Both graphs will be displayed at the same resolution.

S Params Key: Pressing this key calls menu SP. This menu allows you to select the S-Parameter to be displayed by the active channel for the selected S-Parameter.

Ref Plane Key: Pressing this key calls menu RD1. This menu lets you input the reference plane in time or distance. You do this by selecting the appropriate menu item. For a correct distance readout, the dielectric constant must be set to the correct value. This is accomplished by selecting **SET DIELECTRIC**, which calls menu RD2.

On menu RD1, selecting **AUTO** automatically adjusts the reference delay to unwind the phase for the active channel.

The 372XXA unwinds the phase as follows:

- First, it sums the phase increments between each pair of measured data points, then it takes the average "Pdelta" over the entire set of points.
- Next, it corrects the phase data by applying the following formula:

$$P_{correct} = P_{measured} - NxP_{delta}$$


Where P = phase

Assuming there are fewer than 360 degrees of phase rotation between each data point, the operation described above removes any net phase offset. The endpoints of the phase display then fall at the same phase value.

Trace Memory Key: Pressing this key brings up menu NO1. This menu—which relates to the active channel—allows you to store data to memory, view memory, perform operations with the stored memory, and view both data and memory simultaneously. Four memories exist, one for each channel. This allows each channel to be stored and normalized independent of the other channels. Data from the trace memory may be stored on the disk or recalled from it.

NOTE

Trace memory will automatically be set to "VIEW DATA" (that is, turned off), if a sweep with a greater number of points is selected while operating on a stored trace.



* Appears for CAL_SSXX Menus

Figure 4-7. Display Key-Group Menus (1 of 2)




Figure 4-1. Display Key-Group Menus (2 of 2)

**4-8 ENHANCEMENT
KEY-GROUP
DESCRIPTION AND
MENU FLOW**


The individual keys within the Enhancement key-group are described below. Full menu description(s) for menu OPTNS and all others mentioned below can be found in the Appendix A alphabetical listing under the menu's call letters (SP, GT1, RDI, etc).

Option Menu Key: This key brings up the OPTNS menu. Depending on choices selected, this menu causes other menus to appear. A menu flow diagram for this key is shown in Figure 4-8.

Video IF BW Key: Pressing this produces a menu that lets you choose between four different IF bandwidths. This menu is shown below.

Avg/Smooth Menu Key: Pressing this key brings up the EM Menu. When pressed during the calibration sequence, it brings up the EM Cal Menu instead. This menu is shown below.

Trace Smooth and Average Keys: The Average and Trace Smooth keys select their respective functions on and off with the appropriate LED indicating when the function is selected.



This menu only appears during calibration

* Appears for Menu CAL_BW1




Figure 4.1. Enhancement Key-Group (Options Menu Key)

**4-9 HARD COPY
KEY-GROUP
DESCRIPTION AND
MENU FLOW**

The individual keys within the Hard Copy key-group are described below. Full descriptions for menus can be found in the alphabetical listing (Appendix A) under the menu's call letters (PM1, PM2, PM3, etc.)

Menu Key: Pressing this key brings up menu PM1. This menu allows you to define what will happen every time you press the Start Print key. A menu flow diagram is shown in Figure 4-9.

Start Print Key: Pressing this key starts outputting the measured data as defined by the setup defined by the selected MENU key.

Stop Print Key: Pressing this key can result in any of the following actions if the printer is selected

- If the 372XXA is not outputting data, the key sends a form feed command to the printer.
- If the printer is active, the key aborts the printing and sends a form feed command to the printer. Aborting the printing clears the print buffer.
- If the printer is not selected and another form of output is active, Pressing this key aborts printing but *does not* send a form feed to the printer.

Plotting Functions The 372XXA can plot an image of either the entire screen or subsets of it. Plots can be either full size or they can be quarter size and located in any of the four quadrants. You can select different pens for plotting different parts of the screen. You cannot, however, plot tabular data.




Figure 4-2. Hard Copy Key-Group Menus

**4-10 SYSTEM STATE
KEY-GROUP,
DESCRIPTION AND
MENU FLOW**

The individual keys within the System State key-group are described below. The menu flow for the Utility Menu key is shown in Figure 4-10. Full descriptions for menus can be found in the alphabetical listing (Appendix I) under the menu's call letters (U1, U2, U3, etc.)

Default Program Key: Pressing this key brings up the default menu. If pressed again, it recalls the factory selected default values for the control panel controls. The values are defined in Table 4-1.

Pressing this key then the 1 key resets front panel key states and internal memories 1 thru 10.

Pressing this key then the 0 key resets front panel key states, internal memories 1 thru 10, and certain hardware settings. Refer to paragraph 4-5 for additional information on this function.

CAUTION

Use of this key will destroy control panel and calibration setup data, unless they have been saved to disk.

Utility Menu Key: Pressing this key calls menu U1. This menu accesses subordinate menus to perform system, disk, and service utilities. The only functions performed directly from the U1 Menu are "Blank Frequency Information" and "Data Drawing."




Figure 4-3. System State Key-Group Menus

Table 4-1. Default Settings

Function	Default Setting
Instrument State	Measurement Setup Menu Displayed
Measurement	Maximum sweep range of source and test set Source Power: Model Dependent Resolution: Normal (401 points)
Channel	Quad (four-channel) display Channel 1 active
Display	Channel 1: S11, 1:1 Smith Chart Channel 2: S12, Log Magnitude and Phase Channel 3: S21, Log Magnitude and Phase Channel 4: S22, 1:1 Smith Chart Scale: 10 dB/Division or 90/Division Offset: 0.000dB or 0.00 degree Reference Position: Midscale Electrical Delay: 0.00 seconds Dielectric: Air (1.000649) Normalization: Off Normalization Sets: Erased
Enhancement	Video IF Bandwidth: Normal Averaging: Off Smoothing: Off
Calibration	Correction: Off and Calibration erased Connector: Model dependent Load: Broadband
Markers/Limits	Markers On/Off: All off Markers Enabled/Disabled: All enabled Marker Frequency: All set to the start-sweep frequency (or start-time distance Δ Reference: Off Limits: All set to reference position value (all off all enabled)
System State	GP1B Addresses: Unchanged Frequency Blanking : Disengaged, Error(s): GP1B SRQ errors are cleared, Service Log errors are not cleared Measurement: Restarted

The individual keys within the Markers/Limits key-group are described below. The menu flow for the Marker Menu key is shown on the facing page. Full descriptions for these menus can be found in the alphabetical listing (Appendix 1) under the menu's call letters (M1, M2, M3, etc.)

Marker Menu Key: Pressing the Marker Menu key calls Menu M1. This menu lets you toggle markers on and off and set marker frequencies, times, or distances.

Readout Marker Key: Pressing this key calls different menus, depending upon front panel key selections, as described below.

- It calls menu M1 if there are no markers available within the selected frequency range.
- It calls menu M3 if no Delta ref marker has been selected.
- It calls menu M4 if the Δ Reference mode is off and the selected marker is in the current sweep range (or time/distance).
- It calls menu M5 if the Δ Reference mode and marker are both on and the Δ Reference marker is in the selected sweep range (or time/distance).
- It calls menu M6 if ACTIVE MARKER ON ALL CHANNELS has been previously selected in menu M9.
- It calls menu M7 if SEARCH has been previously selected in menu M9.
- It calls menu M8 if FILTER PARAMETER has been previously selected in menu M9.

Marker Readout Functions This menu choice, which appears on several marker menus, provides for several filter-related measurements. It also allows for performing a marker-value search and for reading the active marker value on all displayed channels.

Limit Frequency Readout Function The 372XXA has a Limit-Frequency Readout function. This function allows frequency values to be read at a specified level (such as the 3 dB point) on the data trace. This function is available for all rectilinear graph-types.

The graph-type and their menu call letters are listed below

- Log Magnitude, Menu LF1
- Phase, Menu LF2
- Group Delay, Menu LF3
- Linear Magnitude, Menu LF4
- SWR, Menu LF5
- Real, Menu LF6
- Imaginary, menu LF7

Full menu descriptions can be found in the alphabetical listing (Appendix I) under the menu call letters (LF1, LF2, LF3, etc.)

Limits Key Pressing this key calls the appropriate Limit menu, based on the graph type selected using the Graph Type key and menu.





Figure 4-11. Markers/Limits Key-Group Menus (1 of 3)

**FRONT PANEL
OPERATION**

**MARKERS/LIMITS KEY-GROUP,
DESCRIPTION AND MENU FLOW**




Figure 4-11. Markers/Limits Key-Group Menus (2 of 3)

FRONT PANEL OPERATION

MARKERS/LIMITS DESCRIPTION AND MENU FLOW




Figure 4-11. Markers/Limits Key-Group Menus (3 of 3)

4-12 DISK STORAGE INTERFACE

The 372XXA has two internally mounted disk drives: a 256 MB hard and a 3.5 inch floppy. The format, files, and directory are compatible with MS-DOS, Version 5.0.

Disk Format Floppy diskettes are MS-DOS compatible and have a 1.44 MByte capacity.

Disk Files You may find any of the following file-types on the 372XXA disk.

- Program Files.** These are binary files used to load the operating program. They are provided on the hard drive, and a backup copy is provided on floppy diskettes. Applications programs cannot read them.

- Calibration Data Files:** These are binary files used to store and retrieve calibration and other data. Applications programs cannot read them. File size depends on calibration type.
- Tabular Measurement Data Files.** These are ASCII files used to store actual measurement data. They can be read by applications programs. File size depends on selected options.

- Trace Memory Files.** These are binary files used to store trace data. Applications programs cannot read them. You use them to perform trace math operations on data.
- Cal Kit File for Coax or Waveguide.**

Formatting a Data File Disk

You may format additional diskettes to hold calibration, tabular measurement, and trace-memory data files. Do this using the **FORMAT DISK** selection on the "Floppy Disk Utilities" menu. Using this selection will format the target disk and overwrite any existing data it contains.

A format hard disk utility is provided in case of hard disk failure. Using this feature overwrites your system software and requires booting from the backup floppy diskettes.

Use the COPY FILES selection on the "Floppy Disk Utilities" and "Hard Disk Utilities" menus to copy data files between hard and floppy diskettes.

**Copying
Data Files
From Disk to
Disk**

For best disk performance and reliability, the target-data-files diskette should always be formatted in the 372XXA internal disk drive.

NOTE

If you experience a read or write error during a disk operation, you should:

**Recovering
From Disk
Write/Read
Errors**

- Verify that the diskette has been properly formatted.
- Verify that the diskette is high density (1.44 MB). Low density (720 KB) diskettes are not supported.
- Verify that the write-protect tab on the disk is engaged.
- Retry the disk operation.

Repeated disk errors may indicate a defective diskette and format.

Chapter 5
Error and Status Messages

Table of Contents

5-1	INTRODUCTION	5-3
5-2	ERROR MESSAGES	5-3

Chapter 5 Error and Status Messages

5-1 INTRODUCTION

This chapter lists, describes, and provides corrective action for the error messages that point to problems that the operator can correct. Any error messages that appear on the display but do not appear in this chapter will require action by a qualified service representative.

Error messages are provided in Tables 5-1 and 5-2.

5-2 ERROR MESSAGES

Table 5-1. General Error Messages (1 of 4)

Error Message	Description	Corrective Action
ATTENUATOR UNAVAILABLE	Option 6 Port 2 Test Step Attenuator is not installed.	Install Option 6 Step Attenuator.
BANDS MUST SEQUENCE	Frequency bands in Multiple Source mode must sequence in a 1-2-3-4-5 order.	None, no skipping is allowed.
BOTH LIMITS MUST BE ON	Must have both limits activated.	Turn on limits.
DIFFERENT HW SETUP, RECALL ABORTED	Hardware is different from the recalled setup.	Reconfigure system to duplicate the hardware setup that was used to store the saved data.
DIFFERENT SW VERSION, RECALL ABORTED	Saved state not compatible with hardware or software version.	Load compatible software (SM) version and retry.
DISCRETE FREQS LOST	Change in frequency caused discrete fill frequencies to be lost.	None.
DISPERSIVE MEDIUM, ONLY TIME USED	Distance does not apply for dispersive media.	None.
FREQUENCIES HAVE REACHED UPPER LIMIT	Frequencies being defined in Multiple Source mode have reached upper limits of Sources.	Redefine frequencies to not exceed limits of Sources.
ILLEGAL IN C.W. MODE	Attempted to readout limit frequency.	None, no limit lines are permitted in CW mode.
ILLEGAL IN TIME DOMAIN	Attempted to readout limit frequency.	None.
MEAS DATA NOT AVAILABLE FOR STORAGE	Measurement data is not available for storage.	None.

**ERROR AND
STATUS MESSAGES**

ERROR MESSAGES

Table 5-1. General Error Messages (2 of 4)

Corrective Action	Description	Error Message
None. If problem reoccurs after storing a new setup, contact WILTRON Customer Service.	Requested memory location is corrupted.	MEMORY LOCATION CORRUPTED
Need to define and store frequency bands to turn on Multiple Source mode.	No frequency bands have been defined and stored.	NO BANDS ARE STORED
None.	No data is stored in memory.	NO STORED MEMORY DATA
None.	Selected an option that is not installed.	OPTION NOT INSTALLED
Change calibration range or re-enter values that are within the current range.	Entered values out of the selected calibration range.	OUT OF CAL RANGE
Re-enter values that are within range.	Entered value is out of the instrument's hardware range.	OUT OF HW RANGE
Re-enter values that are within range.	Entered value is out of range.	OUT OF RANGE
Re-enter frequency or power value.	Entered value is out of the instrument's range by greater than 10 percent.	OUT OF RANGE, 10 PERCENT MIN
Re-enter values that are within range, 0 to 20%.	Entered smoothing or group delay value exceeds the range by greater than 20 percent.	OUT OF RANGE, 20 PERCENT MAX
Re-enter frequency.	Entered a frequency that is out of the instrument sweep range.	OUT OF SWEEP RANGE
Re-enter marker to be within frequency start/stop range.	Attempted to set marker outside start to stop range.	OUT OF WINDOW RANGE
Re-enter frequency.	Equation defined in Multiple Source mode places receiver frequency out of range when attempting to store band.	RECEIVER OUT OF RANGE BY EQUATION
Re-enter frequency.	Equation defined in Multiple Source mode places Source 1 frequency out of range when attempting to store band.	SOURCE 1 OUT OF RANGE BY EQUATION
Re-enter frequency.	Equation defined in Multiple Source mode places Source 2 frequency out of range when attempting to store band.	SOURCE 2 OUT OF RANGE BY EQUATION

ERROR AND STATUS MESSAGES

ERROR AND STATUS MESSAGES

Error Message	Description	Corrective Action
STANDARD CAL NOT VALID FOR WAVEGUIDE	Cannot use waveguide when calibrating with the standard method.	Use the Offset Short method with waveguide.
START F FOLLOWS PREVIOUS STOP F	Start frequency of current band immediately follows stop frequency of previous band. Cannot be modified.	None.
START GREATER THAN STOP	Entered start frequency is greater than the stop frequency.	Re-enter frequency values such that the start frequency is lower than the stop frequency.
START MUST BE LESS THAN STOP	Entered start frequency is greater than the stop frequency.	Re-enter frequency values such that the start frequency is lower than the stop frequency.
STEP IS TOO LARGE	Entered discrete fill step extends the stop range.	Re-enter so that step is within range.
STOP IS OVER RANGE	Entered value exceeds the instrument's stop frequency.	Re-enter stop frequency.
SYSTEM BUS ADDRESSES MUST BE UNIQUE	GPiB address is being used by another bus instrument.	Select a different, unique GPiB address.
SYSTEM UNCALIBRATED	372XXA is uncalibrated for the selected measurement values.	Perform a measurement calibration.
TOO FEW POINTS, 2 MINIMUM	Entered too few discrete fill points, 2 is minimum.	Re-enter data points.
TOO MANY POINTS, 1601 MAXIMUM	Entered too many discrete fill points, 1601 points are the maximum allowed.	Re-enter data points.
UNDEFINED DIVIDE BY ZERO	Denominator cannot be zero in equation.	Make denominator a value other than zero.
WARNING: NO GPiB CONTROL OF SOURCE SWEEP	Neither Source power nor flat-port power can be modified when receiver mode is user-defined with NO Source GPiB control.	None.
WARNING: SET ON RECEIVER MODE	Phase-lock setting is undefined when VNA in Set-On Receiver mode.	None.
WARNING: SOURCE 2 DOES NOT EXIST	2nd, external, frequency source is not present.	Connect frequency source.
WINDOW TOO SMALL	Attempted to set start greater than or equal to stop.	Re-enter frequency values.

Table 5-1. General Error Messages (3 of 4)

ERROR AND STATUS MESSAGES

Table 5-2. Disk Error Messages (1 of 1)

Error Message	Description	Corrective Action
7140: FLOPPY DISK GENERAL ER-ROR	Invalid disk media or format.	Use 1.44 MB diskette and format in the 372XXA.
7142: FLOPPY DISK READ ERROR	Read error when accessing disk file.	Use 1.44 MB diskette and format in the 372XXA.
7143: DISK WRITE ERROR	Error in writing to disk file.	Use 1.44 MB diskette and format in the 372XXA.
7147: FLOPPY DISK UNAVAILABLE	Floppy disk is not available.	Install floppy diskette or floppy disk drive.
7170: HARD DISK GENERAL ER-ROR	General error in accessing hard disk.	Retry and if still fails, reformat the hard disk drive.
7172: HARD DISK READ ERROR	Read error when accessing disk file.	Retry and if still fails, reformat the hard disk drive.
7173: HARD DISK WRITE ERROR	Error in writing to disk file.	Retry and if still fails, reformat the hard disk drive.
7177: HARD DISK UNAVAILABLE	Hard disk is not available.	Install hard disk drive circuit board.
8140: GENERAL DISK BUFFER ER-ROR	Out of RAM.	Press the System State, Default Program key and retry.
FILE NOT FOUND	Disk file not found.	None.
FLOPPY DISK HAS NO ROOM FOR FILE	Floppy diskette is full.	Delete files or install new diskette.
FLOPPY DISK NOT READY	Floppy disk is not ready (or not installed).	Install diskette in floppy drive.


Chapter 6

Data Displays

Table of Contents

INTRODUCTION	6-1
DISPLAY MODES AND TYPES	6-2
FREQUENCY MARKERS	6-3
LIMITS	6-4
STATUS DISPLAY	6-5
DATA DISPLAY CONTROL	6-6
HARD COPY AND DISK OUTPUT	6-7
6-15	

Figure 6-1. Single Channel Display, Log Magnitude



This chapter provides discussion and examples of the various types of data displays.

The 37XXA displays measurement data using a "Channel Concept". This means that each channel can display both a different S-Parameter and a different graph type for each. As you select each channel the graph type, scaling, reference delay, S-Parameter, etc. associated with that channel appear on the screen. You can display the same S-Parameter on two or more channels.

Several graph-types are possible: polar, rectilinear, or Smith chart. The rectilinear graph-type may be magnitude, phase, magnitude and phase, SWR, group delay, real, imaginary, and real and imaginary. The Smith chart graph-type is specifically designed to plot complex impedances.

You select this display type (Figures 6-1 and 6-2) by choosing "Single Display" on Menu CM (Appendix A). Possible graph types are single, Smith, polar, rectilinear, or dual (split) rectilinear (magnitude and phase).


Single Channel Display—
Ch 1, 2, 3, 4

6-1 INTRODUCTION

6-2 DISPLAY MODES AND TYPES

Chapter 6
Data Displays

Figure 6-3. Dual Channel Display



Dual Channel Display—Ch 1 and 3 or Ch 2 and 4

If you have chosen a dual display of magnitude and phase, the affected area of the CRT screen is subdivided into two smaller portions (Figure 6-3). You select this display type by choosing "Dual Display" in Menu CM (Appendix A).

Figure 6-2. Single Channel Display, Magnitude and Phase





Figure 6-4. Four Channel Display



Four
Channel
Display—
Ch 1, 2, 3, 4

From four-to-eight graph types are displayed. In each quadrant, the graph type can be any of the possible choices listed in the GT menu (Appendix A). If you have chosen to display magnitude and phase on a channel, the quadrant displaying that channel is further subdivided as described above. You select this display type by choosing "All Four Channels" in Menu CM. An example of a four-channel display appears in Figure 6-4, below.

Dual Trace Overlay

For rectilinear graph types, two traces can be displayed, one overlaid (superimposed) on the other (Figure 6-5). By menu selection, the two traces can be Channel 1 overlaid on Channel 3 or Channel 2 overlaid on Channel 4. Each trace is in a different color. Channels 1 and 2 are displayed in red, while Channels 3 and 4 are displayed in yellow.




Figure 6-5. Dual Trace Overlay

The quantity group delay is displayed using a modified rectilinear-magnitude format. In this format the vertical scale is in linear units of time (ps-ns- μ s). With one exception, the reference value and reference line functions operate the same as they do with a normal magnitude display. The exception is that they appear in units of time instead of magnitude. Examples of graph-data types are shown in Figure 6-6 through 6-11, on the following pages.

- Complex Impedance; displayed on a Smith chart graph.
- Real and imaginary; displayed on a real and imaginary graph.
- Phase and magnitude components; displayed on a rectilinear (Cartesian) or polar graph.
- In addition to the above, the 372XXA can display the data as a group delay plot. In this graph-type, the group-delay measurement units are time. Those of the associated aperture are frequency and SWR.

The data types (real, imaginary, magnitude, phase) used in the displayed graph-types reflect the possible ways in which S-Parameter data can be represented in polar, Smith, or rectilinear graphs. For example: Complex data—that is, data in which both phase and magnitude are graphed—may be represented and displayed in any of the ways described below:

Graph Data Types

Figure 6-7. Dual Channel Rectilinear Graticule




Figure 6-6. Linear Polar Graticule




Figure 6-9. Normal Smith Chart




Figure 6-8. Log Polar Graticule




Figure 6-11. 20 dB Expanded Smith Chart






Figure 6-10. 3 dB Compressed Smith Chart



Depending on menu selection, you may designate a marker as the "active" or the "delta reference" marker. If you choose a marker to be active—indicated by its number being enclosed in a square box—you may change its frequency or time (distance) or point number in CW Draw) with the Data Entry key-pad or knob. If you have chosen it to be the delta-reference marker, a delta symbol (Δ) appears on character space above the marker number (or one character space below a "flipped" marker). If the marker is both active and the delta reference marker, the number and the delta symbol appear above (below) the marker. The delta symbol appears above (below) the number.

Marker Designation

Marker Annotation



The example below shows how the 372XXA annotation markers for the different graph-types. Each marker is identified with its own number. When a marker reaches the top of its graticule, it will flip over and its number will appear below the symbol. When markers approach the same frequency, they will overlap. Their number will appear as close to the marker as possible without overlapping.

Marker Annotation

6-3 FREQUENCY MARKERS

6-4 LIMITS

Limit lines function as settable maximum and minimum indicators for the value of displayed data. These lines are settable in the basic units of the measurement on a channel-by-channel basis. If the display is rescaled the limit line(s) will move automatically and thereby maintain their correct value(s).

Each channel has two limit lines (four for dual displays), each of which may take on any value. Limit lines are either horizontal lines in rectangular displays or concentric circles around the origin in Smith and polar displays.

Each channel can produce segmented limits. They allow different upper and lower limit values to be set at up to ten segments across the measurement range.


In addition to the gratitudes, data, markers, and marker annotation, the 372XXA displays certain instrument status information in the data display area. This information is described below.

Reference Position Marker
The Reference Position Marker indicates the location of the reference value. It is displayed at the left edge of each rectangular graph-type. It consists of a green triangular symbol similar to the cursor displayed in the menu area. You can center this symbol on one of the vertical graticule divisions and move it up or down using the "Reference Position" option. When you do this, the data trace moves accordingly. If you also select the reference value option, the marker will remain stationary and the trace will change from a full-screen display to half- or quarter-screen display, the marker will stay as close to the same position as possible.

Each measurement display is annotated with the scale resolution. For log-magnitude displays resolution ranges from 0.001 to 50 dB per division. Linear displays of magnitude range from 0.001 to 50 units per division. Cartesian phase displays can range from 0.01 to 90 degrees per division. The polar display is 45 degrees per display graticule.

Each measurement display is annotated with the frequency range of the measurement.

The 372XXA displays analog-instrument-status messages (in red when appropriate) in the upper right corner of the data-display area (left). They ap-



Display screen showing the data display and menu areas

Scale Resolution

Frequency Range

Analog Instrument Status

appear at the same vertical position as line 2 of the menu area. If more than one message appears, they stack up below that line.


The 372XXA displays measurement-status messages (in red when appropriate) in the upper-right corner of the graticule (channel) to which they apply.

Measurement Status

Sweep Indicator Marker

A blue sweep-indicator marker appears at the bottom of each displayed graph-type. It indicates the progress of the current sweep. When measuring quiet data—that is, data having few or no perturbations—this indicator assures that the instrument is indeed sweeping. Its position is proportional to the number of data points measured in the current sweep. If the sweep should stop for any reason, the position of the indicator will stop changing until the sweep resumes.

6-6 DATA DISPLAY CONTROL



Active Channel Algorithm

Active Channel Selection
The following figure shows the algorithm that the 372XXA uses to display the active channel.

S-Parameter Selection

If you select a new S-Parameter using Menu SP (Appendix A), it appears on the then-active channel in the same graph-type in which it was last displayed. The following table shows the displayable S-Parameters based on the correction type you have in place. If you attempt to display other S-Parameters, an error message displays. In cases when there is no last-displayed S-Parameter stored, the display will default as shown. If an S-Parameter is selected for which there was no last-displayed graph-type, the display defaults to S₂₁, S₁₂ Log Magnitude and Phase and S₁₁, S₂₂ Smith.

Correction Type	Displayable S-Parameters			
	CH1	CH2	CH3	CH4
None	All	S ₁₁	S ₁₂	S ₂₁ S ₂₂
Frequency Response	Reverse Transmission	S ₁₂	S ₁₂	S ₂₁
	Forward Transmission	S ₂₁	S ₂₁	S ₂₁
	Both	S ₁₂ , S ₂₁	S ₁₂	S ₂₁
Port 1 Reflection Only	S ₁₁	S ₁₁		S ₂₂
Port 2 Reflection Only	S ₂₂			S ₂₂
Reflection Only, Both	S ₁₁ , S ₂₂	S ₁₁		S ₂₂
Forward 1-Path 2-Port	S ₁₁ , S ₂₁	S ₁₁	S ₂₁	
Reverse 1-Path 2-Port	S ₁₂ , S ₂₂		S ₁₂	S ₂₂
12-Term	All	S ₁₁	S ₁₂	S ₂₁ S ₂₂

Data Display Update

When you change a control panel parameter that affects the appearance of the display, the entire display changes immediately to reflect that change. For example, if you press Autoscale, the entire display rescales immediately. You do not have to wait for the next sweep to see the results of the change. The following parameters are supported for this feature: Reference Delay, Offset, Scaling, Auto Scale, Auto Reference Delay, Trace Math, IF BW, and Smooth-ing. In the case of Averaging, the sweep restarts.

If the knob is used to vary any of the above parameters, the change occurs as the measurement progresses—that is, the continuing trace will reflect the new setting(s).

When you change a marker frequency or time (distance), the readout parameters will change. This change reflects the changes in measurement data at the marker's new frequency, using data stored from the previous sweep.

Display of Markers

Once you have selected a marker to display, it will appear on the screen. It does not matter what resolution you have selected. When you set a marker to another calibrated frequency and then lower the resolution, that frequency and the marker will continue to display. It will display even if its frequency is not consistent with the data points in the lower resolution sweep.

6-7 HARD COPY AND DISK OUTPUT

The selection and initiation of this output is controlled by the Hard Copy keys.

Tabular Printout

An example of a tabular format is shown in Figure 6-12. The tabular formats are used as follows:

- Tabular Printout Format*: Used when printing three or four channels.
- Alternate Data Format*: Used when printing one or two channels.

In tabular printouts, the 372XXA shifts the data columns to the left when an S-Parameter is omitted. Leading zeroes are always suppressed. The heading (Model, Device I/O, Date, Operator, Page) appears on each page. When using the WILTRON Model 2225C Ink Jet printer, place all of the rear panel MODE SELECT switches in the down (OFF) POSITION.

In a Screen-Image Printout, the exact data displayed on the screen is dumped to the printer. The dump is in the graphics mode, on a pixel-by-pixel basis.

The protocol used to control plotters is "HP-GL (Hewlett-Packard Graphics Language). HP-GL contains a comprehensive set of vector graphics type commands. These commands are explained in the Interfacing and Programming Manual for any current model Hewlett-Packard plotter, such as the 7470A.

When the plotter is selected as the output device, it is capable of drawing the graph shown on the screen or of drawing only the data trace(s), so that multiple traces may be drawn on a single sheet of paper (in different colors, if needed). An example of a plotter output is shown in Figure 6-13.

The 372XXA can write-to or read-from the disk all measured data. This data is stored as an ASCII file in the exact same format as that shown for the tabular printout in Figure 6-12. If read back from the disk, the data is output to the printer. There, it prints as tabular data.

Disk Output

Plotter Output

Screen-Image Printout

Figure 6-12. Example of a Tabular Printout

```


37247A
MODEL:
DEVICE ID:
DATE:
OPERATOR:

SWEEP DATA
START: 0.04000000 GHZ GATE START:
STOP: 20.00000000 GHZ GATE STOP:
STEP: 0.099800000 GHZ
WINDOW:
-----CH1-----
PARAMETER:
NORMALIZATION: OFF
REFERENCE PLANE: 0.0000 mm
SMOOTHING:
DELAY APERTURE:
MARKERS:
MKR # FREQ MAGNITUDE
      # GHZ dB
FREQUENCY POINTS:
PNT # FREQ MAGNITUDE
      # GHZ dB
1 0.04000000 0.04000000 -54.881
2 0.13980000 0.13980000 -60.875
3 0.23960000 0.23960000 -59.163
4 0.33940000 0.33940000 -55.751
5 0.43920000 0.43920000 -53.856
6 0.53900000 0.53900000 -53.139
7 0.63880000 0.63880000 -51.019
8 0.73860000 0.73860000 -49.457
9 0.83840000 0.83840000 -48.807
10 0.93820000 0.93820000 -48.195

192 19.10180000 -40.402
193 19.20160000 -41.421
194 19.30140000 -42.988
195 19.40120000 -45.713
196 19.50100000 -47.747
197 19.60080000 -48.829
198 19.70060000 -49.502
199 19.80040000 -47.618
200 19.90020000 -46.288

```

Figure 6-13. Example of a Plot



SELECT GRAPH TYPE
 LOG MAGNITUDE
 PHASE
 LOG MAGNITUDE AND PHASE
 SMITH CHART (IMPEDANCE)
 SWR
 GROUP DELAY
 MORE
 PRESS <ENTER> TO SELECT

MODEL: DATE: OPERATOR:
 DEVICE: DATE: OPERATOR:
 START: 2.03600000 GATE START: 0.09980000 WINDOW:
 STOP: 5.03000000 GATE STOP: 5.03000000 IF BNDWTH: MAXIMUM
 STEP: 0.09980000 AVERAGING: 1
 ERROR CORR: MINIMUM

MILTRON

37247A

Chapter 7
Measurement Calibration

Table of Contents

7-1	INTRODUCTION	7-3
7-2	MEASUREMENT CALIBRATION —DISCUSSION	7-3
7-3	MEASUREMENT CALIBRATION —SLIDING TERMINATION	7-14
7-4	MEASUREMENT CALIBRATION —STANDARD (OSL) PROCEDURE	7-20
7-5	MEASUREMENT CALIBRATION —OFFSET-SHORT PROCEDURE	7-29
7-6	MEASUREMENT CALIBRATION —LRL/LRM PROCEDURE	7-33

Chapter 7 Measurement Calibration

7-1 INTRODUCTION

This section provides discussion and examples for performing a measurement calibration. It also provides a detailed procedure for calibrating with a sliding termination.

7-2 MEASUREMENT CALIBRATION—DISCUSSION

Measurements always include a degree of uncertainty due to imperfections in the measurement system. The measured value is always a combination of the actual value plus the systematic measurement errors. Calibration, as it applies to network analysis, characterizes the systematic measurement errors and subtracts them from the measured value to obtain the actual value.

The calibration process requires that you establish the test ports, perform the calibration, and confirm its quality. Let us examine each of these steps.

Establishing the Test Ports

Figures 7-1 and 7-2 are two of the most common approaches used to make measurements on two-port devices. In many cases, you may need adapters to change between connector types (N, SMA, GPC-7, etc) or between genders (male [M] or female [F]).




Figure 7-1. Establishing the Test Port

The use of cables and/or adapters does not effect the final measurement result, if they were in place for the calibration process. The vector error corrections established during the calibration process eliminates cable and/or adapter effects as long as the ports used are stable and exhibit good repeatability, which is the case if good quality components are used. Figure 7-2 shows such a configuration




Figure 7-2. Using Adapters on the Test Port

Many calibration kits include adapters that are designed to have equal phase length. These parts are called phase equal adapters (PEA). Wiltron designs in-series adapters (e.g., K Connector M-M, M-F, F-F) to be phase insertable when technically possible.

When available, it is good practice to use PEAs to establish test ports (Figure 7-2A).




Figure 7-2A. Use of PEAs to Establish Test Ports

This approach offers two advantages:

- It minimizes wear on the more expensive test set and cable connectors.
- It provides a simple solution to measuring non-insertable devices (e.g., a filter with K female input and output connectors), by merely swapping PEAs after calibration. See Figure 7-3.

USING THE PHASE-EQUAL INSERTABLE (PEI)




Figure 7-3. Using Phase-Equal Insertables

NOTE

In this and other discussions, we will talk about "insertable" and "non-insertable" devices. Insertable devices have an insertable connector pair (i.e., male input and female output connectors) and can be measured after a through calibration. A non-insertable device has a non-insertable pair of connectors. This would be the case if it included female connectors on both ports or different connector types on each port. Therefore, "non-insertables" cannot be connected directly into the measurement path without an adapter.

**MEASUREMENT
CALIBRATION**

DISCUSSION

***Under-
standing the
Calibration
System***

Measurement errors must be reduced by a process that uses calibration standards. The standards most commonly used are Opens, Shorts, and Z₀ (Characteristic Impedance) Loads. In conjunction with a through connection, these standards can correct for the major errors in a microwave test system. These errors are Directivity, Source Match, Load Match, Isolation, and Frequency Tracking (reflection and transmission).

Calibration also corrects for many internal system errors, such as RF leakage, IR leakage, and system component interaction.

Random errors such as noise, temperature, connector repeatability, DUT sensitive leakages, frequency repeatability, and calibration variables are not completely correctable. However, some of them can be minimized by careful control. For instance: temperature effects can be reduced by room temperature control, calibration variables can be reduced through improved technique and training, and frequency errors can be virtually eliminated by the fully synthesized internal source.

We know that adapters and cables degrade the basic directivity of the system, but these errors are compensated by vector error correction.

In general, transmission measurement errors are source match, load match, and tracking; while reflection measurement errors are source match, directivity, and tracking.

ERRORS REDUCED BY CALIBRATION

- Directivity
- Source Match
- Load Match
- Frequency Sensitivity (Tracking)
- Internal System Errors

INTERNAL SYSTEM ERRORS

- RF Leakage
- IR Leakage
- System Interaction

RANDOM ERRORS

- Frequency

- Repeatability
- Noise

- Connector Repeatability

- Temperature/Environmental Changes

- Calibration Variables

**TRANSMISSION MEASUREMENT
ERRORS**

- Source Match

- Load Match

- Tracking

REFLECTION MEASUREMENT ERRORS

- Source Match
- Directivity
- Tracking

CALIBRATION TYPES

- Frequency Response
- Reflection Only—1 Port
- 1 Path, 2 Port
- 12 Term—2 Port, Both Directions

Error modeling and flowgraphs are techniques used to analyze the errors in a system. Error models describe the errors, while flowgraphs show how these errors influence the system. Error models (Figure 7-4, below) can become quite complex.

DIRECTIVITY, SOURCE MATCH,
AND TRACKING ERRORS
DISTORTED MEASUREMENT




Figure 7-4. Example of Error Modeling

The 372XXA offers a selection of calibration possibilities depending on the user's needs. These possibilities are as follows:

- Frequency Response
- Reflection Only—1 Port
- 1 Path, 2 Port
- 12 Term—2 Port, Both Directions

These calibration types are described below.


Frequency Response: Corrects for one or both of the forward-direction-error terms associated with a measurement of S_{21} and S_{11} .

Reflection Only: Corrects for the three error terms associated with an S_{11} measurement (EDF, ESF, and ERF).

1 Path, 2 Port: Corrects for the four forward-direction error terms (EDF, ESF, ERF, and ETF).

Full 12 Term: Corrects for all twelve error terms associated with a two-port measurement. A 12-Term error model is shown in Figure 7-5.

Figure 7-5. Error Models



Measurement calibration using the 372XXA is straightforward and menu directed. A short time spent in preparation and preplanning will make the process simple and routine. (Example: Adjusting the coaxial cables used in the measurement setup such that insertion of the DUT causes minimal flexing of these cables).

The screen prompts on the 372XXA guide you through the calibration process—a process that consists of connecting and disconnecting connectors and moving the slide on a sliding load (if one is used).

The most critical part of the calibration process is properly seating and torquing the connectors. Also, you will notice that the calibration takes longer when the ports are terminated with a load. This is intentional. It allows for more averaging during the isolation measurement.

Let us assume that we want to correct for three errors in the reflection measurement: source match, directivity, and tracking. We accomplish this using three standards.

Shorts are the easiest to visualize. They totally reflect all of the incident RF energy output at a precise phase. The terms zero-ohms impedance, voltage null, and 180° phase all define an RF Short.

Opens are similar to Shorts, but their response is more complex. The terms voltage maximum, infinite impedance, and 0° phase all define a perfect Open. A perfect Open, however, is only a concept. In reality Opens always have a small fringing capacitance.

To account for the fact that the Open will not predictably reflect impedance at an exact 0° phase reference, we alter its response using coefficients that accurately characterize the fringing capacitance. The coefficients are different for each coaxial line size, since each size has a different fringing capacitance. To maximize accuracy, ensure that these coefficients are installed prior to the calibration (Menu U3).

As Opens and Shorts provide two references for a full reflection, Z₀ terminations provide a zero-reflection reference.

CALIBRATING FOR A REFLECTION
MEASUREMENT USES THREE
STANDARDS:

- Short
- Open
- Termination

*Calibrating
for a
Measurement*

Ideal Z_0 terminations must consist of two parts, a perfect connector and an infinite-length perfect transmission line that absorbs all of the RF energy that enters it (no reflections).

Infinite length transmission lines are unwieldy at best, so you must use less-than-ideal terminations. For calibration purposes there are two common types: broadband loads and sliding terminations.

Broadband loads are widely used. An example is the WILTRON 28 Series Termination. These terminations are easy to use as calibration tools, and they are adequate for most applications.

Sliding Loads are the traditional vector network analyzer Z_0 calibration reference. They provide the best performance when the application requires high-precision return loss measurements. Sliding loads consist of a connector, a long section of precision transmission line, and a microwave load that is movable within the transmission line. One thing to remember with sliding loads is that they have a low-frequency limit and must be used with a fixed load below this cutoff frequency for full frequency coverage. WILTRON sliding loads cut off at 2 GHz. (V-connector sliding loads cut off at 4 GHz).

Pin depth—the relationship between the interface positions of the outer and center conductors—is the most critical parameter under your control in a sliding load. An example of its criticality is that an incorrect pin depth of 0.001 inch can cause a reflection return loss of 44 dB. And, since we are trying to calibrate to accurately measure a 40 dB return loss, correct pin depth makes a *big difference!*

Cables in the measurement system are another cause for concern. The main criteria for a cable are stability and repeatability. WILTRON offers two types of cables that meet these criteria: semi-rigid and flexible. Our semi-rigid cables provide maximum stability with limited flexibility of movement. Our flexible cables allow more freedom of movement (along with its associated degradation of phase stability).

IDEAL TERMINATIONS

- Reflectionless
- Perfect Connector
- Infinite-Length, Dimensionally Exact, Reflectionless Transmission Line

PRACTICAL Z_0 TERMINATIONS

- Broadband Load
- Sliding Termination

BROADBAND LOAD

- Easy to Use
- Inexpensive
- Adequate for Most Applications

SLIDING LOAD

- Connector
 - Long Transmission Line
 - Movable Microwave Load
-

*Evaluating
the Calibration*

The 372XXA provides an accurate representation of complex data. However, it can only provide accuracy to the extent of the supplied calibration data. For this reason, it is necessary to periodically verify the calibration data and the 372XXA system performance.

Calibration verification reveals problems such as a poor contact with one of the calibration components, improper torquing, or a test port out of specification. Problems like these can easily occur during a calibration procedure. Anyone who has experienced one of these problems and stored bad data—after having performed a complete calibration procedure—knows the frustration it can cause. Additionally, it can be very costly to use incorrectly taken measurement data for design or quality assurance purposes. The best way to confirm a calibration is to measure a precision, known-good device and confirm its specifications.

MEASUREMENT
CALIBRATION

DISCUSSION

Verification
Kits

WILTRON has developed several precision-component kits: for 3.5 mm connectors, for GPC-7 connectors, K Connectors® and V Connectors®. These are, respectively, the Models 3666, 3667, and 3668 and 3669 Verification Kits.

Each of the kits contain 20 dB and 50 dB attenuators, a 10 cm airline, and a 10 cm Beatty Standard. A Beatty Standard is a two-port mismatch similar to a beadless airline. It consists of a center conductor with a discontinuity in the middle providing the mismatch (Figure 7-6).




Figure 7-6. The Beatty Standard

- Used by Calibration and Metrology Labs

VERIFICATION KIT

Typically, these verification kits will be used by calibration or metrology labs. Each of the kits contain several precision components, all of which have been characterized at specified frequencies. The data on these components is stored on a disk provided with the verification kit.

The verification of the kit components is straight forward. The components are first measured with the 372XXA, then they are compared with the data recorded on the disk. If the measured data compares favorably with the recorded data (taking tolerances into consideration), then the system is known to be operating properly and providing accurate data.

There is one caution that you need to observe when using Verification Kits. Because the verification components have been characterized, you must handle them carefully so that you do not change their known characteristics. Consequently, you should not have them available for daily use. Rather, you should only use them for the accuracy verification checks taken every 6-to-12 months (or at any other time the system's integrity is in doubt). This completes the discussion on calibration. Refer to paragraph 7-3 for a procedure showing how to calibrate the sliding load.

Sliding terminations (loads) are the traditional Z_0 calibration-reference devices for vector network analyzer calibration. When correctly used and perfectly aligned, they can be more accurate than precision fixed loads. However, sliding terminations have a 2 GHz (4 GHz for V-conductor sliding loads) low-frequency limit and must be used with a fixed load for full frequency-range coverage.

Sliding terminations consist of a connector, a long section of precision transmission line, and a microwave load that is movable within the transmission line. Pin depth—the relationship between the interface positions of the outer and center conductors—is the most critical parameter that you can control in a sliding termination. An example of its criticality is that an incorrect pin depth of 0.001 inch can cause a reflection return loss of 44 dB. Since you are usually calibrating to accurately measure a greater than 40 dB return loss, correct pin depth is essential.

Since setting an accurate pin depth is so important, this discussion centers on describing how to set the pin depth for male and female sliding terminations. Calibration with the sliding termination is essentially the same as described below for the broadband load.

The procedure below uses the Model 3652 Calibration Kit and its 17KF50 and 17K50 Sliding Terminations. Calibration is similar for the Model 3650 SMA/3.5mm, Model 3651 GPC-7 and Model 3654 V connector kits. For the 3651, the procedure is simpler. Because the GPC-7 connector is sexless, there is only one sliding termination.


Procedure

Step 1.


Remove the Pin Depth Gauge from the kit, place it on the bench top.

NOTE


The meter is convertible between male and female. The following procedure describes the zeroing process for the female fitting. The procedure for the male fitting begins with step 16.




Step 2. Push the outer locking ring towards the gauge to expose the center pin.



Step 3. Take the 01-210 Ref Flat from the kit.



Step 4. While holding the gauge as shown, press the Ref Flat firmly against the end of the exposed center pin.




While pressing the Ref Flat against the center pin, check that the pointer aligns with the "0" mark. If it does not, loosen the bezel lock screw and rotate the bezel to align the pointer with the "0" mark. Tighten the bezel lock screw.

NOTE


Gently rock the Ref Flat against the center pin to ensure that it is fully depressed and you have accurately set the gauge for zero.

Remove the sliding termination with the female-connector (17KF50, for this example) from the kit, and slide the load all the way toward the end closest to the connector.


Step 5.




Step 6.



Step 7.




Step 8.



Cup the sliding termination in your palm, and support the barrel between your body and crooked elbow.


Remove the flush short by holding its body and unscrewing its connector.

Step 9.




Install the gauge onto the end of the sliding termination.

Step 10.



If the COARSE SET adjustment—which has been set at the factory—has not moved, the inner dial on the gauge will read "0." If it doesn't, perform the Coarse Set Adjustment in step 15.

Step 11.




Place the sliding termination, with the gauge attached, on the bench top.

Step 12.



Loosen the FINE LOCK ring and turn the FINE ADJ ring to position the gauge pointer 2-3 small divisions on the “-” side of zero.

Step 13.




Turn the FINE LOCK ring clockwise to both tighten the adjustment and place the pointer exactly to “0.” The Sliding Termination is now ready to use.

NOTES

- Ensure that the inner dial read “0.”
- The following step is not normally necessary. It needs to be done only if the adjustment has changed since it was set at the factory.

With the 01-211 Flush Short installed, loosen the COARSE LOCK and gently push the COARSE SET adjustment rod in as far as it will go. This coarsely sets the center conductor to be flush against the attached short. Return to step 2.


Step 15.



The procedure for adjusting the male-connector sliding termination is essentially the same as that described above. The only difference is that you must install the female adapter on the end of the gauge shaft, over the center conductor. To install this adapter, proceed as follows:


- Zero-set the gauge as described in step 2 above.
- Push the outer locking ring back toward the gauge and turn it clockwise onto the exposed threads.
- Loosen the lock ring one turn in a counterclockwise direction.

Step 16.




Step 17.

Remove the 01-223 Female Adapter ("F ADAPTER FOR PIN GAUGE") from the kit.



Step 18.

Install the female adapter over the center pin and screw it into the locking ring, and tighten the outer ring until it is snug against the housing.




Step 19.

Inspect the end of the adapter, you should see no more than two exposed threads. If so, repeat steps 7 thru 10, above.


Step 20.

Connect the gauge to the sliding termination and zero set the center pin using the FINE ADJ as previously described in step 2 above.



MENU C11
BEGIN CALIBRATION
KEEP EXISTING
CAL DATA
REPEAT
PREVIOUS CAL
CAL METHOD
STANDARD
TRANSMISSION
LINE TYPE:
XXXXXXXXXX
CHANGE CAL
METHOD AND
LINE TYPE
NEXT CAL STEP
PRESS <ENTER>
TO SELECT

- Step 1.** Press the Begin Cal key.
- Step 2.** Select **CHANGE CAL METHOD AND LINE TYPE**, in menu C11 (left). (This assumes **STANDARD** and **COAXIAL** are not presently shown in blue as being selected.)



Calibration Procedure
 A detailed, step-by-step procedure for performing a Open-Short-Load calibration is given below.

The standard calibration for the 372XXA Vector Network Analyzer system uses an Open, a Short, a Broadband and/or Sliding Load, and a throughline connection to categorize the inherent errors in the measurement system. These errors include those caused by connectors as well as internal system errors such as RF leakage, IF leakage, and component interaction. For maximum accuracy, install the capacitive coefficient (for the open device) using Menu U3.

7-4 STANDARD (OSL) CALIBRATION PROCEDURE

Step 3.

When menu C11A (left) appears, move cursor to the following:

a. **STANDARD**, then press Enter key. This selects Standard (OSL) as the calibration method.

b. **COAXIAL**, then press Enter key. This selects coaxial transmission line media.

c. **NEXT CAL STEP**, then press Enter key. This causes menu C11 to return to the screen.

When menu C11 reappears, confirm that the

STANDARD calibration method and **COAXIAL** line type have been selected. Select **NEXT CAL**

STEP and press the Enter key to proceed. This brings up menu C5.

Menu C5 (left) lets you select the type of calibration.

For this example, move the cursor to **FULL 12-TERM**

TERM and press the Enter key. This selection calibrates for all twelve error terms.

The next menu, C5D, lets you choose whether to include or exclude the error terms associated with leakage between measurement channels. For a normal calibration, you would choose to include these error terms. Therefore, move the cursor to **INCLUDE ISOLATION (STANDARD)** and press the Enter key.

MENU C11A
CHANGE
CAL METHOD
AND LINE TYPE
NEXT CAL STEP
CAL METHOD
STANDARD
(NOT USED FOR
WAVEGUIDE)
OFFSET SHORT
LR/LRM
TRANSMISSION
LINE TYPE
COAXIAL
WAVE GUIDE
MICROSTRIP
PRESS <ENTER>
TO SELECT

b.

a.

c.

Step 6.

MENU C5
CALIBRATION
TYPE
FULL 12-TERM
1 PATH
2 PORT
TRANSMISSION
FREQUENCY
RESPONSE
REFLECTION
ONLY
PRESS <ENTER>
TO SELECT

MENU C5D
SELECT USE
OF ISOLATION
IN CALIBRATION
INCLUDE
ISOLATION
(STANDARD)
EXCLUDE
ISOLATION
PRESS <ENTER>
TO SELECT

Step 7.

Next, menu C1 appears. It lets you select the number of frequency points at which calibration data is to be taken. The choices are:

- a. **NORMAL:** Data is taken at up to 1601 equally spaced frequencies across the calibration frequency range. Use this selection for this example.

- b. **C.W. FREQ:** Data is taken at one point. This choice brings up menu C2B (below) that lets you select the single CW frequency point.

MENU C1	
SELECT	CALIBRATION
DATA POINTS	
NORMAL	(1601 POINTS
MAXIMUM)	
C.W.	(1 POINT)
N-DISCRETE	FREQUENCIES
(2 TO 1601	POINTS)
TIME DOMAIN	(HARMONIC)
PRESS <ENTER>	TO SELECT

MENU C2B	
SINGLE POINT	CALIBRATION
C.W. FREQ	XX.XXXX GHZ
FINISHED	ENTRY, NEXT
CAL STEP	INPUT FREQ AND
PRESS <ENTER>	TO SELECT

Step 8.

- c. **N-DISCRETE FREQUENCIES:** This selection lets you specify a discrete number of frequency points, from 2 to 1601.

- d. **TIME DOMAIN:** This selection is the calibration mode for low-pass time-domain processing. It lets you select frequencies at integer (harmonic) multiples of the start frequency.

The next menu, C2 (left), lets you set your start and stop frequencies. For this example, move cursor to **START**, press 40 on keypad, and hit the MHz terminator key. Perform like operations for the **STOP** choice, except make entry read 20 GHz. After setting the frequencies, select **NEXT CAL STEP** and press the Enter key.

MENU C2	
FREQ RANGE OF	CALIBRATION
START	0.040000000GHZ
STOP	20.000000000 GHZ
201 DATA PTS	0.099800000 GHZ
STEP SIZE	
MAXIMUM NUMBER	OF DATA POINTS
1601 MAX PTS	801 MAX PTS
201 MAX PTS	401 MAX PTS
51 MAX PTS	NEXT CAL STEP
PRESS <ENTER>	TO SELECT

MEASUREMENT CALIBRATION

STANDARD (OSI) CALIBRATION PROCEDURE

When menu C3 (left) appears, if you want to change any of the parameters shown in blue letters, place the cursor on that parameter and press the Enter key. For this example, we will change them all, starting with the top one. Move the cursor to PORT 1 CONN and press the Enter key.

In menu C4 (below), which appears next, move the cursor to K CONN (M) and then press the Enter key. This choice presumes that you have a K-Female connector on the device-under-test (DUT). Remember, in this menu you choose the connector type on the test port, or the connector type that mates with the DUT connector. When menu C3 returns, observe that K CONN (M) is now shown in blue for the PORT 1 CONN choice.

Step 9.

MENU C3
CONFIRM
CALIBRATION
PARAMETERS
PORT 1 CONN
K CONN (M)
PORT 2 CONN
SMA (M)
REFLECTION
PAIRING
MIXED
LOAD TYPE
SLIDING
THROUGHLINE
PARAMETERS
REFERENCE
IMPEDANCE
TEST SIGNALS
START CAL
PRESS <ENTER>
TO SELECT
OR CHANGE

Step 10.

MENU C4
SELECT PORT 1
CONNECTOR TYPE
SMA (M)
SMA (F)
K:CONN (M)
K-CONN (F)
TYPE N (M)
TYPE N (F)
GPC-3.5 (M)
GPC-3.5 (F)
GPC-7
USER DEFINED
MORE
PRESS <ENTER>
TO SELECT

With menu C3 (left) displayed, move the cursor to **PORT 2 CONN** and press the Enter key. Following the procedure in step 10, select **K CONN (M)** for the Port 2 connector.

When menu C3 returns:

- a. Observe that **PORT 2 CONN** now reflects **K CONN (M)**.

- b. Move cursor to **REFLECTION PAIRING** and press the Enter key. This brings up menu C13 (below).

MENU C13
SELECT
REFLECTION
PAIRING
MIXED
(OPEN-SHORT)
(SHORT-OPEN)
MATCHED
(OPEN-OPEN)
(SHORT-SHORT)
PRESS <ENTER>
TO SELECT

Step 11.

MENU C3
CONFIRM
CALIBRATION
PARAMETERS
PORT 1 CONN
K CONN (M)
PORT 2 CONN
K CONN (M)
REFLECTION
PAIRING
MIXED
LOAD TYPE
SLIDING
THROUGH
PARAMETERS
REFERENCE
IMPEDANCE
TEST SIGNALS
START CAL
PRESS <ENTER>
TO SELECT
OR CHANGE

Step 12.

Reflection Pairing lets you mix or match the Open and Short reflection devices in the Calibration Sequence menus. The **MIXED** choice lets you calibrate using first an Open on one port and a Short on the other, then a Short on one port and an Open on the other. Conversely, **MATCHED** lets you calibrate first using an Open on both ports then using a Short on both ports. For this example, choose **MIXED** and press the Enter key.

Step 13.

When menu C3 returns:

- a. Observe that **REFLECTION PARIING** now reflects **MIXED**.
- b. Move cursor to **LOAD TYPE** and press the Enter key. This brings up menu C6 (below).

MENU C3
CONFIRM
CALIBRATION
PARAMETERS
PORT 1 CONN
TYPE N (M)
PORT 2 CONN
TYPE N (F)
REFLECTION
PARIING
MIXED
LOAD TYPE
BROADBAND
THROUGH
PARAMETERS
REFERENCE
IMPEDANCE
TEST SIGNALS
START CAL
PRESS <ENTER>
TO SELECT

MENU C6
SELECT
TYPE OF LOAD
BROADBAND
FIXED LOAD
SLIDING LOAD
(MAY ALSO
REQUIRE
BROADBAND
FIXED LOAD)
PRESS <ENTER>
TO SELECT

This menu lets you select either of two load types, broadband or sliding. Broadband loads are adequate for all but the most demanding reflection measurements. They are easier to use and less expensive than sliding loads. If you choose a sliding load, refer to paragraph 7-3 for a procedure on setting pin depth.

For this example, select **BROADBAND LOAD** and press the Enter key.

- c. The next menu to appear, C6A (left), prompts you to enter an impedance value. For this example, use the rotary knob to change the displayed value to 50 Ω. Alternatively, you can key in 50 ohms. That is, press 50 on the keypad and the X1 terminator key. If the value were 1 μΩ, you would key in .001 and press 10⁻³. Conversely, if the value was 1 MΩ, you would key in 1000 and press the 10³ terminator key.

MENU C6A
ENTER
BROADBAND LOAD
IMPEDANCE
50.000 Ω
BROADBAND LOAD
IMPEDANCE
PRESS <ENTER>
TO SELECT

When menu C3 again returns:

a. Observe that **LOAD TYPE** now shows **BROAD-BAND**.

b. Move cursor to **THROUGH PARAMETERS** and press the Enter key.

Menu C20 (left) appears next. It lets you define the length of the offset and the impedance of the throughline. For this example, enter 0 mm for length and 50 ohms for impedance.

When menu C3 reappears, move the cursor to **REFERENCE IMPEDANCE** and press the Enter key. This brings up menu C17 (left).

Move cursor to **REFERENCE IMPEDANCE** and use the rotary knob to change the displayed value to 50 Ω .

Press the Enter key when you have completed your value entry.

Step 14.

MENU C20
ENTER
THROUGH LINE PARAMETERS
OFFSET LENGTH 0.000 mm
THROUGHLINE IMPEDANCE 50.000 Ω
PRESS <ENTER> WHEN COMPLETE

Step 15.

Step 16.

Step 17.

MENU C17
ENTER
REFERENCE IMPEDANCE
REFERENCE IMPEDANCE 50.000 Ω
PRESS <ENTER> WHEN COMPLETE

When menu C3 returns, select **TEST SIGNALS** to bring up menu SU2 (left).

Step 18.

Menu SU2 lets you define the power level of the signals at the two test ports. Power delivered to the DUT by the test set must be such that the measured signals are well above the noise floor but below the 0.1 dB compression level of the Test Set samplers. (Noise floor and maximum signal into Port 2 levels are specified in Appendix C.)

Step 19.


For active device Test Sets, an optional Port 2 attenuator in the forward transmission path allows up to 1 Watt of power (30 dBm) before 0.1 dB compression occurs.

Determine the required input power level and the expected output RF power level from the DUT. Ideally, the Port 2 step attenuator should be set so that the input to the test sampler (left) is -10 dBm. For example, if the input to the DUT is set for -20 dBm and the device gain is 40 dB, set the **PORT 2 ATTN** menu option for 20 dB.

(If you needed to calibrate the test port for power flatness, you would move the cursor to **FLATNESS CORRECTION** and press the Enter key.

Finally, move the cursor to **PREVIOUS MENU** and press the Enter key. This returns you to menu SU1. When you get there, press the Enter key to return to menu C3.

MENU SU2
TEST SIGNALS
POWER CONTROL
0.0 dB
(0 TO -15)
PORT 1 ATTN
20 dB (0 - 70)
PORT 1 POWER
XX.XX dBm
PORT 2 ATTN
X0 dB (0-40)
CALIBRATE
FOR FLATNESS
(CAL EXISTS)
FLATNESS
CORRECTION
AT XX.X dBm
SOURCE 2 PWR
XX.X dBm
PREVIOUS MENU
PRESS <ENTER>
TO SELECT



When menu C3 reappears, select **START CAL** and press the Enter key to begin the calibration procedure. Continue the calibration sequence by following the prompts as they appear. Connect the appropriate Isolation Devices, Broadband Loads, Opens, Shorts, and Throughlines, when requested in the calibration sequence.

Step 20.


MENU C3
CONFIRM
CALIBRATION
PARAMETERS
PORT 1 CONN
TYPE N (M)
PORT 2 CONN
SMA (M)
REFLECTION
PAIRING
MIXED
LOAD TYPE
SLIDING
THROUGH
PARAMETERS
REFERENCE
IMPEDANCE
TEST SIGNALS
START CAL
PRESS <ENTER>
TO SELECT
OR CHANGE

7-5
OFFSET-SHORT
CALIBRATION
PROCEDURE

The Offset-Short calibration is the standard technique for waveguide. It uses an offset Short and a flush Short to categorize the inherent errors in the waveguide measurement system. These errors include those caused by connectors as well as internal system errors such as RF leakage, IF leakage, and component interaction.

Calibration Procedure
A detailed, step-by-step procedure for performing a Offset-Short calibration is given below.

Step 1. Press the Begin Cal key.



Step 2. Select **CHANGE CAL METHOD AND LINE TYPE**, in menu C11 (left). (This assumes **OFFSET SHORT** and **WAVEGUIDE** are not presently shown in blue as being selected.)

MENU C11
BEGIN CALIBRATION
KEEP EXISTING
CAL DATA
REPEAT
PREVIOUS CAL
CAL METHOD
XXXXXXXXXX
TRANSMISSION
LINE TYPE:
XXXXXXXXXX
CHANGE CAL
METHOD AND
LINE TYPE
NEXT CAL STEP
PRESS <ENTER>
TO SELECT

Step 3.

When menu C11A (left) appears, move cursor to the following:

- a. **OFFSET SHORT**, then press the Enter key. This selects Offset Short as the calibration method.

- b. **WAVEGUIDE**, then press the Enter key. This brings menu C5 (bottom left) to the screen.

- c. **NEXT CAL STEP**, then press the Enter key. This causes menu C11 to return to the screen.

When menu C11 reappears, confirm that the **OFF-SET SHORT** calibration method and **WAVEGUIDE** line-type have been selected. Select **NEXT CAL STEP** and press the Enter key to proceed.

Menu C5 appears next. This menu (bottom left) lets you select the type of calibration. For this example, move the cursor to **FULL 12-TERM** and press the Enter key.

Step 4.

The next menu, C5D (below), lets you choose whether to include or exclude the error terms associated with leakage between measurement channels. For a normal calibration, you would choose to include these error terms. Therefore, move the cursor to **INCLUDE ISOLATION (STANDARD)** and press the Enter key.

MENU C11A
CHANGE
CAL METHOD
AND LINE TYPE
NEXT CAL STEP
CAL METHOD
STANDARD
(NOT USED FOR
WAVEGUIDE)
OFFSET SHORT
LRL/LRM
TRANSMISSION
LINE TYPE
COAXIAL
WAVEGUIDE
MICROSTRIP
PRESS <ENTER>
TO SELECT

Step 5.

MENU C5
SELECT
CALIBRATION TYPE
FULL 12-TERM
1 PATH
2 PORT
TRANSMISSION
FREQUENCY
RESPONSE
REFLECTION
ONLY
PRESS <ENTER>
TO SELECT

Step 6.

MENU C5D
SELECT USE
OF ISOLATION
IN CALIBRATION
INCLUDE
ISOLATION
(STANDARD)
EXCLUDE
ISOLATION
PRESS <ENTER>
TO SELECT

MENU C1	SELECT CALIBRATION DATA POINTS
	NORMAL (1601 POINTS MAXIMUM)
	C.W. (1 POINT) N-DISCRETE FREQUENCIES (2 TO 1601 POINTS) TIME DOMAIN (HARMONIC) PRESS <ENTER> TO SELECT

Step 7.

Menu C1 (left), which appears next, lets you select the number of frequency points at which calibration data is to be taken. Of these choices, which were described in paragraph 7-4, choose **NORMAL (1601 POINTS MAXIMUM)** for this example.

The next menu, C2 (below), lets you set your start and stop frequencies. For this example, move cursor to **START**, press 40 on keypad, and hit MHz terminator key. Perform like operations for the **STOP** choice, except make entry read 20 GHz. After setting the frequencies, select **NEXT CAL STEP** and press the Enter key.

MENU C2	FREQ RANGE OF CALIBRATION
	START 0.040000000GHZ
	STOP 20.000000000 GHz
	201 DATA PTS 0.099800000 GHz STEP SIZE MAXIMUM NUMBER OF DATA POINTS 1601 MAX PTS 801 MAX PTS 401 MAX PTS 201 MAX PTS 101 MAX PTS 51 MAX PTS
	NEXT CAL STEP PRESS <ENTER> TO SELECT

Step 9.

When menu C3B (bottom left) appears, if you want to change any of the parameters shown in blue letters, place the cursor on that parameter and press the Enter key. (These choices operate the same as was described for menu C3 in paragraph 7-4.) For this example, we change the waveguide parameters. Move the cursor to **WAVEGUIDE PARAMETERS** and press the Enter key.

MENU C3B	CONFIRM CALIBRATION PARAMETERS
	LOAD TYPE BROADBAND THROUGH LINE PARAMETERS WAVEGUIDE PARAMETERS XXXXXXXXXX TEST SIGNALS START CAL
	PRESS <ENTER> TO SELECT OR CHANGE

Step 10.

When menu C15 (left) appears, move cursor to one of the two available choices and press the Enter key. These choices are described below.

- a. **USE INSTALLED WAVEGUIDE KIT:** Selecting this choice uses the values shown in blue for IDENTIFIER, CUTOFF FREQ, SHORT 1, and SHORT 2. Select this choice, for this example.
- b. **USER DEFINED:** Selecting this choice brings up menu C15A (below), which lets you specify waveguide parameters. After defining your waveguide parameters, you are returned to menu C3B.

```

MENU C15
SELECT
WAVEGUIDE
KIT TO USE
-INSTALLED KIT-
IDENTIFIER
XXXX
CUTOFF FREQ:
XXXXXXXXXXXX GHz
SHORT 1
XX.XXXX mm
SHORT 2
XX.XXXX mm
USE INSTALLED
WAVEGUIDE KIT
USER DEFINED
PRESS <ENTER>
TO SELECT
    
```

```

MENU C15A
ENTER
WAVEGUIDE
PARAMETERS
WAVEGUIDE
CUTOFF FREQ:
XXXXXXXXXXXX GHz
OFFSET LENGTH
OF SHORT 1
XX.XXXX mm
OFFSET LENGTH
OF SHORT 2
XX.XXXX mm
PRESS <ENTER>
WHEN COMPLETE
    
```

Step 11.

Continue the calibration sequence by following the prompts as they appear. Connect the appropriate Isolation Devices, Broadband Loads, Shorts, and Throughlines, when requested in the calibration sequence.

*LRMCalibrationMethodoRhodesscharwzGermany

7-6 LRL/LRM CALIBRATION PROCEDURE

MEASUREMENT CALIBRATION
LRL/LRM CALIBRATION PROCEDURE

The LRL/LRM (line-reflect-line/line-reflect-match) calibration* feature provides an enhanced capability for error compensation when making measurements in coaxial, microstrip and waveguide transmission media. Instead of using the standard Open, Short, and Load, the LRL/LRM calibration method uses two lines and a reflection or match. The difference in length between line 1 and line 2 creates the measurements necessary for the error solutions.

Because very high quality air lines are readily available, excellent directivity and source match are possible with this calibration. This calibration is excellent for measurements in transmission media, such as coax or waveguide, in which opens or precision terminations are difficult to realize.

The LRL/LRM calibration technique uses the characteristic impedance of a length of transmission line or a precision match as the calibration standard. A full LRL/LRM calibration consists of two transmission line measurements, a high reflection measurement, and an isolation measurement. Using this technique full 12-term error correction can be performed with the 372XXA.

Three line LRL/LRM calibration can also be selected. In a two-line LRL measurement, the difference in length between line 1 and line 2 is necessary for calibration but limits the frequency range to a 9:1 span. The use of three lines in the calibration extends the frequency range to an 81:1 span.

Through the use of LRL/LRM calibration and an external computer, in conjunction with ANACAT software, multiple-level de-embedding is possible. This calibration allows you to make semi-conductor chip measurements up to 60 GHz with a single test fixture.

In addition, any non-coaxial transmission media, including mixed media interconnects, can be accommodated. For example, a test device with a waveguide input and a coplanar microstrip output can be measured. Software automatically compensates for the microstrip dispersion.

A detailed procedure for calibrating for a measurement using the LRL/LRM method is provided in the following pages.

LRL/LRM Calibration (Microstrip)

Microstrip is a dispersive media. The 372XXA applies dispersion compensation during calibration for microstrip measurements. Because the 37XX2A must know the specific microstrip parameters, during the calibration procedure menus are available for entering the

- width of the strip
- thickness of the substrate
- substrate dielectric constant
- effective dielectric constant Z_c
- characteristic impedance (reference)


When testing microstrip devices it is necessary to launch from coax to microstrip. In production testing this launching must be temporary, so that the device can easily be installed in and be removed from the fixture. The requirement for launching to 60 GHz is met by the WIL-TRON Universal Test Fixture (UTF). The UTF provides accurate, repeatable launch to substrates from 5 to 70 mils thick, and from 0.15 to 2 inches long. Offset connections and right angles can be configured. DC bias probes can be mounted to the UTF to inject bias onto the substrate. UTF calibration/verification kits are available for alumina in 10 mil, 15 mil, and 25 mil microstrip, and for 25 mil coplanar waveguide. Although a UTF is not essential, the following calibration procedures presume its use.

Step 1.

Select the desired LRL line substrates from the appropriate microstrip calibration kit. When called for in the calibration sequence, mount the LRL line substrates on the UTF following the procedure given in the 3680 OMM.

Step 2.

Press the Begin Cal key.



MEASUREMENT CALIBRATION

LRL/LRM CALIBRATION PROCEDURE

Step 3.

Select **CHANGE CAL METHOD AND LINE TYPE**, in menu C11 (left). (This assumes **LRL** and **MICROSTRIP** are not presently shown in blue as being selected.)

Step 4.

When menu C11A (bottom left) appears, highlight the following selections.

a. **LRL/LRM** and press the Enter key.

b. **MICROSTRIP** and press the Enter key.

c. **NEXT CAL STEP** and press the Enter key.

Step 5.

When menu C11 reappears, confirm that the **LRL/LRM** calibration method and **MICROSTRIP** line-type have been selected. Select **NEXT CAL STEP** and press the Enter key to proceed.

Step 6.

Continue through the calibration sequence, and make the following selections from the menus that appear:

- INCLUDE ISOLATION (STANDARD)** (Menu C5D)
- NORMAL (1601 POINTS MAXIMUM)** (Menu C1)
- START** (Your start frequency) (Menu C2)
- STOP** (Your stop frequency) (Menu C2)

MENU C11
BEGIN CALIBRATION
KEEP EXISTING
CAL DATA
REPEAT
PREVIOUS CAL
CAL METHOD
XXXXXXXXXX
TRANSMISSION
LINE TYPE:
XXXXXXXXXX
CHANGE CAL
METHOD AND
LINE TYPE
NEXT CAL STEP
TO SELECT

a.

b.

c.

MENU C11A
CHANGE
CAL METHOD
AND LINE TYPE
NEXT CAL STEP
CAL METHOD
STANDARD
(NOT USED FOR
WAVEGUIDE)
OFFSET SHORT
EXCLUDE
TRANSMISSION
LINE TYPE
COAXIAL
WAVE GUIDE
MICROSTRIP
TO SELECT

MENU C5D
SELECT USE
OF ISOLATION
IN CALIBRATION
INCLUDE
ISOLATION
(STANDARD)
EXCLUDE
ISOLATION
PRESS <ENTER>
TO SELECT

MENU C1
SELECT
CALIBRATION
DATA POINTS
NORMAL
(1601 POINTS
MAXIMUM)
C.W.
(1 POINT)
N-DISCRETE
FREQUENCIES
(2 TO 1601
POINTS)
TIME DOMAIN
(HARMONIC)
PRESS <ENTER>
TO SELECT

MENU C2
FREQ RANGE OF
CALIBRATION
START
0.040000000GHZ
STOP
20.000000000 GHZ
201 DATA PTS
0.099800000 GHZ
STEPSIZE
MAXIMUM NUMBER
OF DATA POINTS
1601 MAX PTS
801 MAX PTS
401 MAX PTS
201 MAX PTS
101 MAX PTS
51 MAX PTS
NEXT CAL STEP
PRESS <ENTER>
TO SELECT



When menu C3G appears, if you want to change microstrip parameters to be different from those shown in blue, place cursor on **MICROSTRIP PARAMETERS** and press the Enter key.

When menu C16 (left) appears, move cursor to the **WILTRON 3680 UTF** calibration kit you wish to use or to **USER DEFINED**; then press the Enter key.

The calibration kit selections shown in menu C16 are for the following 3680 Connection Substrate

Kits:

- 10 MIL KIT — 36804B-10M
- 15 MIL KIT — 36804B-15M
- 25 MIL KIT — 36804B-25M

If you choose **USER DEFINED**, the next menu that appears (C16A), lets you characterize your parameters. Move cursor to each selection, key in a value, then press the Enter key to return to menu C16.

Step 7.

MENU C3G
CONFIRM CALIBRATION PARAMETERS
LRL/LRM PARAMETERS
PARAMETERS
MICROSTRIP PARAMETERS
PARAMETERS USER DEFINED
TEST SIGNALS
START CAL
PRESS <ENTER> TO SELECT OR CHANGE

Step 8.

MENU C16
SELECT MICROSTRIP KIT TO USE
10 MIL KIT
15 MIL KIT
25 MIL KIT
USER DEFINED
PRESS <ENTER> WHEN COMPLETE

MENU C16A
ENTER MICROSTRIP PARAMETERS
WIDTH OF STRIP
XX.XXXX mm
THICKNESS OF SUBSTRATE
XXXX.XXXX mm
Z ₀
XXX.XXX Ω
SUBSTRATE DIELECTRIC
XX.XX
EFFECTIVE DIELECTRIC
XX.XX
(RECOMMENDED 0.00)
PRESS <ENTER> WHEN COMPLETE

MEASUREMENT CALIBRATION

LRL/LRM CALIBRATION PROCEDURE

Step 9.

Select LRL/LRM PARAMETERS, when menu C3G returns.

MENU C3G
CONFIRM
CALIBRATION
PARAMETERS
LRL/LRM
PARAMETERS
CHANGE
MICROSTRIP
PARAMETERS
XXXXXXXXXX
START CAL
PRESS <ENTER>
TO SELECT

Step 10.

When menu C18 appears, you have two choices to make: whether your calibration is to be two-line or three-line, and where you want to have your reference plane.

- a. Select the reference plane: Highlight MIDDLE OF LINE 1 (REF) or ENDS OF LINE 1 (REF) and press the Enter key.
- b. Select the type of LRL/LRM calibration: Highlight ONE BAND, for a two-line calibration; or TWO BANDS, for a three-line calibration.

As mentioned earlier, in a two-line measurement, the difference in length between line 1 and line 2 is necessary for calibration but limits the frequency range to a 9:1 span. By using three lines in the calibration, you extend the frequency range to an 81:1 span.

If you select TWO BANDS, skip to Step 12.

EITHER/OR

EITHER/OR

MENU C18
CHANGE LRL/LRM
PARAMETERS
NEXT CAL STEP
NUMBER OF
BANDS USED
ONE BAND
TWO BANDS
LOCATION OF
REFERENCE
PLANES
MIDDLE OF
LINE 1 (REF)
ENDS OF
LINE 1 (REF)
PRESS <ENTER>
TO SELECT

When menu C18A (left) appears, make the following selections:

- a. Move the cursor to **DEVICE 1 LINE 1 (REF)** and key in the value.
- b. Move the cursor to **DEVICE 2 LINE/MATCH**. Here you have another decision to make: whether your calibration is to be LRL or LRM. For this selection, the Enter key acts as a toggle.
- c. If you toggle such that **LINE** turns red, then key in the value for line 2. This value depends on your frequency range.
- d. If you toggle **MATCH** red, observe that **FULL-BAND** appears. This indicates that your reflective device covers the full calibration range.
- e. When you have made both selections, move the cursor to **NEXT CAL STEP** and press the Enter key to produce the next menu. Skip to step 13.

Step II.
(2-Line Calibration)

b, c, d,

a,

e.

MENU C18A
CHANGE LRL/LRM PARAMETERS
NEXT CAL STEP
CHARACTERIZE CAL DEVICES
DEVICE 1 LINE 1 (REF) X.XXX mm
DEVICE 2 LINE/MATCH X.XXX mm
PRESS <ENTER> TO SELECT OR SWITCH

Step 12. (3-Line)

When menu C18B (left) appears, make the following selections:

a. Move the cursor to **DEVICE 1 LINE 1 (REF)** and key in the value (typically 1.00 cm). Press the ENTER key to select.

b. Move the cursor to **DEVICE 2 LINE/MATCH**. Both here, and for the next choice, you have another decision to make: whether your calibration is to be LRL or LRM. For this selection, the ENTER key acts as a toggle.

c. If you toggle such that **LINE** turns red, then key in the value for line 2. This value depends on your frequency range.

d. If you toggle **MATCH** red, observe that **LOW-BAND** appears. This indicates that your reflection device is a low-band load. This load must have a passband such that it passes all frequencies from the start to the breakpoint (see below).

e. Move the cursor to **DEVICE 3 LINE/MATCH**. If device 3 is a line, key in the value. If it is a match, the term **HIGHBAND** will appear. This indicates that your match is a high-band load. This load must have a passband such that it passes all frequencies from the breakpoint to the stop frequency.

f. Move the cursor to **BREAKPOINT** and enter your breakpoint frequency. For two-line LRL calibrations, select a breakpoint equal to the upper frequency of the low frequency LRL line. For a combined LRL and LRM calibration, select a breakpoint equal to the top frequency of the calibration divided by six; for instance, to cover the frequency range 0.04 to 60 GHz, select 10 GHz as the breakpoint.

g. When you have made all selections, move the cursor to **NEXT CAL STEP** and press Enter to produce the next menu.

	MENU C18B
	CHANGE LRL/LRM PARAMETERS
g.	NEXT CAL STEP
	CHARACTERIZE CAL DEVICES
a.	DEVICE 1 LINE 1 (REF) XX.XXX
b, c, d.	DEVICE 2 LINE/MATCH XX.XXX/LOWBAND
e.	DEVICE 3 LINE/MATCH XX.XXX/HIGHBAND
	FREQ AFTER WHICH THE USE OF DEVICE 2 AND DEVICE 3 IS EXCHANGED
f.	BREAKPOINT XXXXXXXXXX.GHZ
	PRESS <ENTER> TO SELECT OR SWITCH

The next menu, C19, gives you choices for your reflective device.

a. Move the cursor to **OFFSET LENGTH** and key in a value (typically 0.0000 mm).

b. Move the cursor to **GREATER THAN Zo** or **LESS THAN Zo**, depending on whether your reflective device is an Open or a Short. Press the ENTER key to select.

NOTE

Choose **GREATER THAN Zo** for an Open and **LESS THAN Zo** for a Short.

c. When you complete your choices, move the cursor to **NEXT CAL STEP** and press the Enter key.

When menu C3G reappears, move cursor to **START CAL** and press Enter.

Continue the calibration sequence by following the prompts as they appear. Mount the appropriate LRL line substrates when requested in the calibration sequence.

For the **REFLECTIVE DEVICE** and **BROAD-BAND LOAD** prompts, remove all substrates from the UTF and allow the lower jaws to short the center conductor. Separate the connector blocks by at least an inch. (The **BROADBAND LOAD** prompt only appears if you selected to include isolation in menu C5B.)

Store the calibration.

Step 13.

MENU C19	
CHANGE LRL/LRM	
PARAMETERS	
NEXT CAL STEP	
OFFSET LENGTH	
OF REFLECTIVE	
DEVICE	
OFFSET LENGTH	
X.XXXX mm	
TYPE OF	
REFLECTION	
GREATER	
THAN Zo	
LESS	
THAN Zo	
PRESS <ENTER>	
TO SELECT	

a.

b.

EITHER/OR

Step 14.

Step 15.

MENU C3G	
CONFIRM	
CALIBRATION	
PARAMETERS	
CHANGE	
LRL/LRM	
PARAMETERS	
CHANGE	
MICROSTIP	
PARAMETERS	
XXXXXXXXXX	
START CAL	
PRESS <ENTER>	
TO SELECT	

Step 16.

An LRL cal kit is necessary to perform the coaxial calibration. Calibration kits for GPC-7 are available from Maury Microwave and Hewlett Packard.

Two line lengths are used as the impedance standard. The calibration frequency range is limited by the difference in the lengths of the two lines. Their length must be different by approximately 90 degrees at the mid-band frequency. A good calibration can be achieved over the range of 18 degrees to 162 degrees making it possible to calibrate LRL over a 9:1 frequency range.

LRL calibration is very sensitive to uncalibrated source match. If some padding is placed at the test ports, the directivity and source match will be improved. If the goal is high level measurements, then padding should be included. If low level measurements are being performed, then the padding must be left out.

Same as Steps 1 through 6 in the Microstrip in menu C1A.

When menu C3E (left) appears, if you want to change line impedance, place cursor on **REFERENCE IMPEDANCE** and press the Enter key.

When menu C17 (left) appears, move cursor to **REFERENCE IMPEDANCE**, key in the value, then press the Enter key.

Same as Steps 9 through 16 in the microstrip procedure.

In the coaxial, three-line calibration there are factors you need to be aware of. Note that it is the line length differences that are important to the LRL calibration, namely (L2-L1) and (L3-L1) where L1 is the length of line 1, L2 is the length of line 2, and L3 is the length of line 3. Longer length differences are used for longer wavelengths (lower frequencies). For frequencies up to and including the breakpoint frequency, the larger absolute value of the (L2-L1) and (L3-L1) differences is used. At frequencies above the breakpoint, the smaller absolute value of the (L2-L1) and (L3-L1) differences is used.

MENU C3E
CONFIRM
CALIBRATION
PARAMETERS
LRL/LRM
PARAMETERS
REFERENCE
IMPEDANCE
TEST SIGNALS
START CAL
PRESS <ENTER>
TO SELECT
OR CHANGE

Step 2.

Step 3.

Step 4.

MENU C17
ENTER
REFERENCE
IMPEDANCE
REFERENCE
IMPEDANCE
50.000 Ω
PRESS <ENTER>
WHEN COMPLETE

Consideration must also be given to selecting the breakpoint frequency. Divide the frequency range to satisfy the 9:1 rule for any given pair of lines. The range is thus divided by the frequency breakpoint into the intervals [f1, f2] and [f2, f3]. Based on these intervals, next determine the appropriate length differences; the longer difference is associated with the lower interval [f1, f2]. Note that if the differences are equal to each other, concurrent frequency ranges are implied and only two lines need be used. Select a line 1 reference (L1) around which to place these two differences. Use any combination of positive or negative differences around line 1. The software selects which interval is associated with either of line 2 or line 3 by comparing the absolute values of the differences with line 1. Data from the two lines, which make up the larger absolute difference, are used for the interval [f1, f2]. Data from the two lines, which make up the smaller absolute difference, are used for the interval [f2, f3].

**LRL/LRM Calibration
(Waveguide)**

The waveguide procedure is very similar to the coaxial and microstrip procedures already described.

Step 1.

Same as Steps 1 through 6 in the Microstrip procedure, except choose **WAVEGUIDE** in menu C1A.

MENU C3F
CONFIRM CALIBRATION PARAMETERS
LRL/LRM PARAMETERS
WAVEGUIDE CUTOFF FREQ
TEST SIGNALS
START CAL
PRESS <ENTER> TO SELECT OR CHANGE

Step 2.

The only difference is with menu C3F. For a waveguide calibration, move the cursor to **WAVEGUIDE CUTOFF FREQ** and press Enter. This action calls menu C15B, which lets you enter the waveguide cutoff frequency. After doing, so you are returned to menu C3F.

Step 3.

When menu C3F reappears, place cursor on **CHANGE LRL/LRM PARAMETERS** and press the Enter key. Same as Steps 9 through 13 in the Microstrip procedure.

MENU C15B
ENTER WAVEGUIDE CUTOFF FREQUENCY
WAVEGUIDE CUTOFF FREQ XX.XXXX GHZ
PRESS <ENTER> WHEN COMPLETE

Chapter 8
Measurements

Table of Contents

INTRODUCTION	8-1
TRANSMISSION AND REFLECTION MEASUREMENTS	8-2
LOW LEVEL AND GAIN MEASUREMENTS	8-3
GROUP DELAY MEASUREMENTS	8-4
ACTIVE DEVICE MEASUREMENTS	8-5
MULTIPLE SOURCE CONTROL	8-6
8-29	

8-1 INTRODUCTION

8-2 TRANSMISSION AND REFLECTION MEASUREMENTS

APPLY POWER TO THE SYSTEM

- Then, Turn On the Analyzer

SETUP

- System Should Be Warmed Up for At Least 60 to 80 Minutes

DEFAULT PARAMETERS

- Known-Good Starting Point
- Selected With the Default Program Key

SWEEP TEST MENU

- Start and Stop Frequencies
- Source Power Level

Chapter 8 Measurements

This section discusses four typical measurements that can be made with the Model 372XXA Vector Network Analyzer.

This discussion provides information on general measurement considerations and transmission and reflection measurements using the 372XXA.

Setup and Calibration

To get started, apply power to the system. After turning on the power, allow the system to warm up for at least 60 minutes before operation.

In normal operation, the system comes on line in the state that it was in when last turned off. If you want to return the system to its default state, you can do so by pressing the Default Program key twice.

The default parameters provide a known starting point. For example, they reset the start and stop frequencies for maximum sweep width, the source control to 0 dB, and the display resolution to 401 data points.

The Sweep Setup menu should now appear on the display (it also can be displayed using the Setup Menu key). If you like, you can select a new start frequency, stop frequency, or source power.

You can further reduce the power level at Ports 1 and 2 with the built-in attenuators. Using the Reduced Test Signals option in the Sweep Setup menu, you can change the setting of the Port 1 source attenuator over a range of from 0 to 70 dB. The Port 2 test attenuator has a range of from 0 to 40 dB (in 10 dB steps) (if Option 6 is installed).

Install the calibration kit devices to the test ports as instructed by the U3 menu. Both the capacitance coefficients for the Open and the offset lengths for the Open and Short can be modified or defined.

Selecting the Begin Cal key starts the calibration process. The Calibration menus step you through the calibration process, as follows:

Select the type of calibration desired.

Select the frequency range of calibration. Using the Data Points key, you can choose between 1601 to 51 measurement data points.

When the calibration is completed, you can store the calibration data on a disk. You are now ready to install the test device and proceed with the measurement. At this point you have a number of

measurement options to consider such as displays, markers, limits, outputs, sweeps, and enhancements.

You can select any of the available graph types and display them for any calibrated parameter on any of the four channels (if a 12-term calibration was performed).

- Use the "Test Signals" Option to Add Attenuation

SWEEP SETUP MENU

- Select Begin Cal Key

CALIBRATION

- Select Type of Calibration
- Select Frequency Range of Calibration
- Install Calibration Kit Devices As Instructed by the Menu
- Modify the Capacitance Coefficients and the Offset Lengths, If Required
- Store the Calibration Data Internally or to Disk

MEASUREMENT OPTIONS

- Displays
- Markers
- Limits
- Outputs
- Sweeps
- Enhancements

DISPLAYS

- Four Channels
- Each Channel Can Display Up to Two Graph Types
- Calibration Parameters Can Be Selected By Any Channel

Up to six markers are available. Using the Marker Menu, you can set the frequency of each one, you can set each one in the delta marker mode, and you can set each marker's level to maximum or minimum.

In some cases—such as in a production environment—limit lines are desirable. Options within the menu called up using the Limits key, provide for one or two flat, sloped, or single-point-segmented limit lines for each channel. These limit lines function with all of the graph types, including Smith and admittance. The color of the limit lines (blue) differs from that of the measurement trace. This allows for easy analysis of results.

The Hard Copy Menu key menu (Figure 8-1) gives you a choice between a printer and a colored-pen plotter. It also lets you select menus from which you may choose from a variety of print or plot options.




Figure 8-1. Output Menu

To output the display, press the Start Print key. The default setting provides for a full display printout from the associated printer.

MARKERS

- Selectable User Marker Menu
- 6 Markers Available
- Delta And Max/Min Modes

LIMITS

- Selectable Using Limits Key
- Two Limit Lines Available for Each Channel
- Limit lines can be flat, sloped, or segmented with up to 10 discrete frequency segments
- Functions With All Graph Types

OUTPUT

- Select Start Print key to Output Display
- Use the Hard Copy Menu to Choose Output Type and Output Device

OUTPUT HEADERS

- Selected With Device ID Key or From the Output Menu Under the Setup Output Headers Option
- Labels Output With Device/Serial Number, Date, Operator's Name, and comments

To label the output, select Setup Output Headers in the Output Menu or press the Device ID key.

On the output to the printer, plotter, or disk, a menu then appears that lets you specify the device name/serial number, the date, the operator's name, and user comments (Figure 8-2).




Figure 8-2. Label Menus

Sweep frequencies can be changed with the calibration applied as long as the frequencies are between the calibration start and stop frequencies.

Additionally, a marker sweep can be selected from the Setup Menu. This allows you to sweep between any two active markers as long as the frequency of each falls between the calibrated start and stop frequencies.


Using the Data Points key, you can select the number of data points for optimal resolution-vs-speed.

- Start/Stop Frequencies Can Be Changed With Calibration Applied
- Marker Sweep Available From the Setup Menu
- Data Points Selectable Using the Data Points key

SWEEPS

These ratios are complex quantities that have magnitude and phase components. Using vector representation, the vector magnitude is the ratio of reflected-to-incident magnitude (or transmitted-to-incident magnitude), while the vector phase is the difference in phase between the incident energy and the reflected/transmitted energy (Figure 8-4).

Figure 8-3. Basic Measurement Principles



Before going any further, let us take a few moments to review some basic principles of network measurements. First, we apply incident energy to the input of a test device. If the device's input impedance differs from the measurement system's impedance, some of that energy is reflected. The remainder is transmitted through the device. We call the ratio of reflected-to-incident energy the reflection coefficient. The ratio of transmitted-to-incident energy we call the transmission coefficient (Figure 8-3).

Measurement Discussion

Finally, you can enhance the measurement data by reducing the IF bandwidth and using averaging and/or smoothing.

- Change the IF bandwidth by selecting the Video IF BW key.
- Set the averaging and smoothing values by selecting the Avg/Smooth Menu key.
- Turn on the averaging and smoothing using the Trace Smooth and Average keys, which have LEDs to let you know that the enhancement is being applied.

- Intermediate Frequency Bandwidth Changed Using the Video IFBW Key
- Averaging and Smoothing Values Set Using Ave/Smooth Menu Key
- Averaging and Smoothing Turned On or Off Using Trace Smooth and Average keys

ENHANCEMENTS

TRANSMISSION AND REFLECTION

MEASUREMENTS

- Defined At the Test Port Measurement Plane As
- Magnitude = 1
- Phase = 0 Degrees
- Established During Calibration

REFERENCE PLANE

- Log Magnitude
- Phase
- Smith Chart (Impedance)
- Group Delay (See paragraph 3-13)
- Admittance Smith Chart
- Linear Polar
- Log Polar
- Linear Magnitude
- Real and Imaginary

MEASUREMENTS

The measurement reference for the incident energy is the point at which the device connects to the measurement system. We call this point the reference plane. The incident energy at the reference plane is defined as having a magnitude of 1 and a phase of 0 degrees. We establish this during the calibration.

The ratio of reflected and transmitted energy to the incident energy can be represented by a number of different measurements and units, as shown below.

The default display for reflection measurements is the Smith chart. The default display for transmission measurements is the Log Magnitude and Phase graph.

The Smith chart is a convenient way to display device impedance and is a useful aid for the graphical design and analysis of microwave circuits (Figure 8-5).





Figure 8-5 Smith Chart Display 1

Figure 8-4. Magnitude/Phase Vector



DEFAULT DISPLAYS

- Reflection
- Smith Chart
- Transmission

- Log Magnitude and Phase Graph

Let us assume both that our system is already calibrated and that we have equalized the system for the test port in use. We would then

1. *Connect the Short.* A Short always appears as a dot at the left-most edge of the Smith chart's horizontal axis.

2. *Connect a Termination.* Now you will see another dot located at the center ($1+j0$) of the chart (this assumes a 50-ohm load).

3. *Connect the Open.* An Open appears as an arc on the chart's right edge. This is due to the fringing capacitance of the Open standard (Figure 8-6).




Figure 8-6 Smith Chart Display 2

Now let us perform a reflection measurement on a 20 dB attenuator over the 1-to-18 GHz range.

We need to determine the setup, calibration, and measurement requirements.

MEASUREMENTS

TRANSMISSION AND REFLECTION

A known good starting point is to reset with Default Program parameters. Since our measurement lies between 1 and 18 GHz, set the Start and Stop frequencies using the Sweep Setup menu that appears on the display following system reset.

Let us perform a simple calibration, Reflection Only, which uses an open, a short, and a broadband load. To do this, press the Begin Cal key and follow the directions in the menu area.

When you complete the calibration, the "CHANNEL 1 WITH S11" Smith chart appears on the display. Now:

1. Select the Log Magnitude display and install the attenuator.
2. Select Auto Scale to optimize the display data.
3. Use Markers 1 and 2 to find the maximum and minimum impedance.

REFLECTION MEASUREMENT
Example: 20 dB Attenuator

- Setup
- Calibration
- Measurement

SETUP

- Reset With the Default Parameters Key
- Set the Start Frequency to 1 GHz
- Set the Stop Frequency to 18 GHz

CALIBRATION

- Begin Cal Key
- Reflection Only

MEASUREMENT

- Select Log Magnitude Display
- Install DUT
- Autoscale
- Set Marker 1 to Max, Marker 2 to Min

Now let us perform a transmission measurement on the same 20 dB attenuator over the same frequency range. We will follow the same steps as before, but this time we will use additional features.

Once again, reset the system using the Default Program key.

In this calibration we will select the N-Discrete Frequencies menu option and step all frequencies in increments of 50 MHz.

When the calibration is complete, Channel 1 will display "S21 FORWARD TRANSMISSION WITH LOG MAGNITUDE AND PHASE." You can use Markers 1 and 2 to find the maximum and minimum values of the attenuators insertion loss.

TRANSMISSION MEASUREMENT

Example: 20 dB Attenuator

- Setup
- Calibration
- Measurement

SETUP

- Use Default Program Settings

CALIBRATION

- Begin Cal Key
- Frequency Response (Transmission Response Only)

The small signal response is limited by errors due to noise and leakage signals. The leakage signals are both from within the 372XXA and at the device-under-test (DUT) connectors.

Figure 8-7. Compression at 0.1 dB




Figure 8-7 shows the detected output signal as a function of the power level at the sampler. The 0.1 dB compression level is on the order of -10 dbm. The 372XXA is designed such that all other conversions compress at a much greater level, which leaves the samplers as the main source of nonlinearity.

Receiver Dynamic Range
The dynamic range of the 372XXA is limited by the 0.1 dB compression level of the samplers at high signal levels. It is further limited at low signal levels by leakage signals and noise.

The 372XXA system is limited in its ability to test low-signal levels by its dynamic range and signal-to-noise-power ratio. First we will discuss receiver dynamic range, which is the difference between the maximum and minimum acceptable signal levels (Receiver Dynamic Range = $P_{max} - P_{min}$).

This discussion provides methods and techniques for making gain and low-signal-level measurements. It is divided into 372XXA system considerations and test device considerations.

8-3 LOW LEVEL AND GAIN MEASUREMENTS

- DYNAMIC RANGE LIMITS**
- High Level Accuracy Limited by the Compression of the Receiver
 - Low Level Accuracy Limited by Noise and Leakage Signals

372XXA System Considerations

The detected signal is the vector sum of the desired signals, the noise signals, and the leakage signals. These signals introduce an error or uncertainty (Figure 8-8).




Figure 8-8. Amplitude and Phase Uncertainty

Some of the possible leakage paths for the 372XXA are the transfer switch, the frequency conversion module, and the DUT. The system limits these leakage to greater than 100 dB. The 12-term error correction can reduce this leakage to better than 110 dB at 18 GHz and 90 dB at 40 GHz.

The DUT connectors should have internally capped center pins. Those connectors which use external pins to captivate the center conductor should have silver loaded epoxy on the pins to reduce radiation to better than 80 dB.

Signal-to-Noise-Power Ratio

The signal-to-noise-power ratio for each of the test or reference channels is as shown. The "signal power" is the power level of the 80 kHz IF signal at the internal synchronous detectors, and the "noise power" is the total power contained within the bandwidth of the bandpass filter at 80 kHz.

LEAKAGE PATHS

- Transfer Switch (120 db)
- Frequency Conversion Module
- DUT Leakage

DUT LEAKAGE

- Should Be Greater Than 80 dB to Assure Accurate Measurements

Signal To Noise

$$S/N \text{ Ratio For Test or Reference Channel} = \frac{\text{Signal Power (dbm)}}{\text{Noise Power (dbm)}}$$

Figure 8-10. The Effect of S/N Ratio On Phase Measurements (Noise Only)





Figure 8-9. The Effect of S/N Ratio On Magnitude Measurements (Noise Only)



The uncertainty, or error, in a measurement is a function of the amplitude of leakage signals and of the noise level. The uncertainty in the measurement of magnitude and phase of the S-parameters are calculable and shown below in Figures 8-9- and 8-10.

MEASUREMENTS

LOW LEVEL AND GAIN

The most difficult types of measurements are those that exercise the full dynamic range of the 372XXA, such as filters (Figure 8-11). Filter measurements are examples of where one must observe both low-in-section loss (in the passband) and high attenuation (in the stop band).




Figure 8-11. Filter Measurements

There are two techniques that you can use to optimize the signal-to-noise ratio. They are (1) maximize the RF signal level and (2) using signal enhancement.

To maximize the RF signal level, use the default settings of the 372XXA.

The 372XXA provides two enhancements for improving the signal-to-noise ratio: IF bandwidth reduction and averaging.

Reducing the IF bandwidth is a primary method for enhancing accuracy. The 372XXA has a choice of four bandwidths available from the front panel: Maximum (10 kHz), Normal (1 kHz), Reduced (100 Hz), and Minimum (10 Hz). The noise level should decrease by a factor equal to the square root of the IF bandwidth. Using IF Bandwidth reduction makes for faster measurements than with the use of an equivalent amount of averaging.

- TECHNIQUES TO MAXIMIZE THE S/N RATIO**
- Maximize RF Signal Level
 - Signal Enhancement

MAXIMIZE RF SIGNAL LEVEL

- Maximum Dynamic Range
- Optimum Linearity

ENHANCEMENTS


- IF Bandwidth Reduction
- Averaging

IF BANDWIDTH REDUCTION

- Four Bandwidths Available
- Noise is Decreased
- Faster Than Averaging

Example: Using 1 kHz BW reduction and 10 averages, you would increase the signal-to-noise ratio by 7.6 dB but would lengthen the time required for the measurement by a factor of 4.3. This example assumes a constant signal power.

Figure 8-12. Reduction in Noise Using Averaging



Averaging is another way to improve accuracy. The improvement is proportional to the square root of the number of averages. The improvement from averaging, however, comes at the expense of increased sweep time. Figure 8-12 shows the measured reduction in noise due to bandwidth and averaging.

- Up to 4096 Averages
- Reduces Noise
- Increases Sweep Time

AVERAGING

LOW LEVEL AND GAIN

MEASUREMENTS

In order to test a device, the required input RF level and the expected device output RF level must be determined.

The RF level at Port 1 must be set for the device input RF power level required. Attenuation can be added in steps of 10 dB up to 70 dB using the built-in source attenuator.

The RF level into Port 2 should be kept to -10 dBm or less to ensure optimum linearity and to protect internal components from damage. The never-to-exceed RF level into either Port 1 or Port 2 is +20 dBm. You can add up to 40 dB of attenuation (in 10 dB steps) into Port 2 with Option 6.

If do not have the Option 6 built-in test attenuator, you should use external attenuators on Port 1 and Port 2 as needed. However, the use of external attenuators invalidates input and output match measurements; whereas, the built-in attenuator is compensated by the calibration and does not affect reflection measurements.

Before calibration, ensure that the test setup is correct by setting the power level and adding attenuation as needed.

**Test Device
(DUT) Considerations**

PORT 1 RF OUTPUT LEVEL

- -10 dBm
- Can Add Up to 70db Attenuation in 10 dB Steps

PORT 2 RF INPUT LEVEL

- -10 dBm Maximum
- Can Add Up to 40 dB Attenuation in 10 dB Steps

EXTERNAL ATTENUATORS

- Use Only if Internal Attenuator Is Not Available—They Invalidate DUT Match Data

MEASUREMENTS

**LOW LEVEL
AND GAIN**

The 372XXA uses enhancements in the calibration to ensure a wide dynamic range. It automatically selects 1 kHz IF bandwidth and varies the number of averages with the calibration device. Terminations require the most averages.

If desired, the Video IF bandwidth and number of averages can be specified for the calibration measurements. Using 100 averages (Avg = 100) appears to be sufficient for most measurements.

To obtain the maximum performance from the 372XXA for measurements of attenuation, you can use the capability of the N discrete frequency calibration to spot check measurements in the frequency band of interest.

The measurement procedure is straight forward, as shown below.

- Set Desired RF Signal Level
- Include Attenuation As Needed

CALIBRATION

- Video IF Bandwidth Reduced Setting
- Number of Averages Varies With Calibration Device Measurements

CALIBRATION

- Can Select the Desired IF Bandwidth and Averaging

CALIBRATION

- 10 dbm Source Power
- 100 Averages in Calibration
- 100 Averages in Measurement

TO MEASURE HIGH ATTENUATION

MEASUREMENT PROCEDURE

- Determine DUT I/O RF Levels
- Set Source RF Level
- Set Port 1 Source Attenuator and Port 2 Test Attenuator

EXAMPLE - FILTER

- No Attenuator Needed
- IF Bandwidth 1 kHz and 100 Averages

EXAMPLE - FET

- Set Port 1 Source Attenuator to 30 dB (for 37247A and below)
- No Port 2 Attenuator is Needed
- Calibrate
- Use IF Bandwidth and Averaging As Desired

EXAMPLE - AMPLIFIER

- No Port 1 Attenuator
- Port 2 Test Attenuator to 10dB

Wide Dynamic Range Device - Filter

Since you do both low-insertion-loss and high-attenuation measurements simultaneously, use the maximum RF signal level and no attenuation. Selecting the 1 kHz Video IF BW setting and 100 averages will likely suffice for this kind of measurement.

High Gain Device - FET

This device has a typical 15 dB gain and requires an input level of about -30 dBm. Set the Port 1 Source Attenuator to 30 dB. Since the device RF output level is -15 dBm (-30 dBm + 15 dB[Gain]) = -15 dBm) no attenuation is needed at Port 2.

Medium Power Device - Amplifier

Measure the small signal parameters of a 10 dB gain device that requires an input power level of 0 dBm. Here, Port 1 will have no attenuation. The device RF output level is 10 dBm. This level equals 10 dBm (0 dBm + 10 dB[Gain] = 10 dBm) into Port 2 and will cause compression in the measurement. At least 10 dB of test attenuation will be needed at Port 2, which will reduce the Port 2 RF level to 0 dB.

8-4 GROUP DELAY
MEASUREMENTS

Group delay is the measure of transit time through a device at a particular frequency. Ideally, we want to measure a constant—or relatively constant—transit time over frequency. The top waveform shown in Figure 8-13 is measured at one frequency. The bottom waveform is identical to the first, simply delayed in time.




Figure 8-13. Two Waveforms Delayed in Time

Referring to Figure 8-14, the first waveform shown is the original waveform. It is made up of many frequency components. After traveling through a device the signal is delayed in time. Some frequencies are delayed more than others and thus our waveform does not have exactly the same shape as before.





Figure 8-14. Waveform with Frequency Differences

NONLINEAR DELAY = DISTORTION

When delay is nonlinear, as shown above, distortion occurs. By measuring group delay with a network analyzer you can characterize the distortion that occurs from a signal traveling through your test device.

Figure 8-15. Waveforms With Aperture Differences



A wide aperture results in a loss of fine-grain variations but gives more sensitivity in the measurement of time delay. A small aperture gives better frequency resolution, but at the cost of lost sensitivity. Thus, for any comparison of group delay data you must know the aperture used to make the measurement (Figure 8-15).

$$\text{Aperture} = \frac{\# \text{ Of Data Points}}{\text{Frequency Range}}$$

To measure group delay the frequency aperture must be selected. Depending on the size of aperture, different levels of precision can result for the measurement of group delay.

$$\Delta f = \text{Aperture}$$

The change in frequency is referred to as an aperture.

What this equation shows is that group delay is a measure of the change in phase with relation to the change in frequency.

$$\tau = -\frac{d\omega}{d\theta} = -\frac{d}{d\theta} \frac{d\theta}{d\omega} = -\frac{d}{d\omega} \frac{d\omega}{d\theta} = \frac{1}{\Delta\theta} \frac{d\theta}{d\omega} = \frac{1}{\Delta f} \frac{df}{d\theta}$$

Group delay is mathematically represented by the following equations: Group delay is mathematically represented by the following equations:

When designing components it is important to measure group delay so that you can compensate for any distortion caused by the component. You may be able to tune the device so as to optimize the performance of group delay over the frequency range of interest. Outside of the specified frequency range, the group delay may or may not be linear. So how is group delay measured? Signals travel too fast to enable measuring the input and output times of each frequency component. Consequently, we must use mathematical calculations to derive the group delay from the phase slope.

GROUP DELAY	GROUP DELAY MEASURED
<ul style="list-style-type: none"> • Measure During Design • Avoid Distortion Later 	<ul style="list-style-type: none"> • Measure During Test • Optimize Performance


HOW IS GROUP DELAY MEASURED

Mathematical Representation of the Phase Slope

GROUP DELAY


MEASUREMENTS

Figure 8-17. Group Delay Screen Showing Aperture



The 372XXA automatically selects the frequency spacing between data points—that is, the aperture. Notice that this value is displayed on the screen with the measurement (Figure 8-17).

Figure 8-16. Group Delay-vs-Frequency Graph



Let us take a look at a group delay measurement made on the WIL-TRON 372XXA Vector Network Analyzer. Group delay, as a measurement option, can be found in the Graph Type menu. After selecting the option, the 372XXA displays the data in a time-vs-frequency graph, or to be more exact, a group-delay-vs-frequency graph (Figure 8-16).

The aperture defaults to the smallest setting for the frequency range and number of data points selected. This value is displayed in the a Set Scale key menu when measuring group delay (Figure 8-18).




Figure 8-18. 372XXA Aperture

GROUP DELAY APPLICATIONS

- Communications

Group delay applications are found throughout the microwave industry, although the majority of such measurements are made in the tele-

communications area. One occurrence of group delay that you may have experienced is with a long-distance telephone call. Occasionally a phone call can be disturbing because of the delay in time from when you speak and when the other person responds. If there is simply a delay, then time delay—or linear group delay—has occurred. But if the voices are also distorted, then non-linear group delay has occurred. It is this distortion that we must avoid. We can avoid linear group delay by measuring group delay both during the design and development stages and during recalibration in the field.

One final group-delay application is found in the development of components. In this application, group delay is measured for the transit time of a signal through the device. When time is of the essence in a fast switching system, as in a modern computer, the travel time through a device is critical.

8-5 ACTIVE DEVICE MEASUREMENTS

ACTIVE DEVICE MEASUREMENTS

Active devices are key components in microwave systems. The measurements that are made on active devices are similar to those made on passive devices.

Active devices come in many shapes and sizes. In most cases we are going to have to develop a fixture in which to mount the device. Active devices require bias voltages, and in many cases they are easily damaged. High gain amplifiers may saturate with input signals of -50 dBm! With active devices, we have a new set of measurement requirements.

The 372XXA has been designed to help you make these types of measurements. It includes one 70 dB step attenuator used to adjust the Port 1 power level. A second 40 dB step attenuator is also included (with Option 6) in the forward transmission path to allow measurement of high gain devices without sacrificing reverse transmission and reflection measurements (S₁₂, S₂₂). Bias tees on each port are used to bias the device via the test port center conductor. This approach to bias is useful for testing transistors; however, MMICs usually require bias injection at other points (Figure 8-19).




Figure 8-19. Bias Tee

ACTIVE DEVICES

- FETs
- Amplifiers
- MMICs

COMMON MEASUREMENTS

- S₁₁ Input Match
- S₂₁ Gain
- S₁₂ Reverse Isolation
- S₂₂ Output Match

WHAT'S DIFFERENT?

- Connectors
- There May Not Be Any Tabs-Leads-Pads Instead You Will See:

WHAT'S DIFFERENT?

- Voltage-Bias Requirements
- Signal Level Performance
- Power Output
- Max Input Level
- Non Linear
- Gain Compression




Figure 8-20. Active Device Test Fixture

Now we have an interesting situation. While we can measure the performance at the connector—which is the calibration plane—what we really want to know is how our device performs (Figure 8-21).




Figure 8-21. Test Device, What It Looks Like

You can consider the device embedded in the fixture and can measure the S-Parameters of the fixture with the device installed.

The most elementary situation is a system in which the test fixture is electrically ideal or transparent. In this case the solution is simple—merely move the reference plane out to the device (Figure 8-22).


DE-EMBEDDING
Remove or "De-embed" The Effects of the Fixture

Engineers have come to grips with the general problem. However, there is no established standard approach. Two of the more common approaches are to calibrate the fixture as a part of the analyzer, and to characterize the fixture and compute the desired result.

- Calibrate the Fixture As "Part of the Analyzer"
- Characterize the Fixture and Compute the Desired Result


**TWO APPROACHES ARE COMMON
WHAT DO WE DO?**

Figure 8-23. Coax-to-Substrate Transition



In some cases—depending on the fixture or the device being measured—this is satisfactory. But when it is not, we need to employ other techniques. One of the reasons that moving the reference plane out to the device does not always work, is that the test fixture includes a transition from coax to a structure such as microstrip, co-planar waveguide, or stripline (Figure 8-23).

Figure 8-22. Simple Example of De-Embedding



**APPROACH NUMBER 1
CALIBRATE THE FIXTURE**

- Special Calibration Devices Required

In the discussion on calibration we saw that the calibration components establish the reference plane and determine the quality of the measurement. If we have a good Open, Short and Z₀ load to place at the end of a microstrip line, we can calibrate the system at the point of measurement.

Figure 8-24 shows some of the special test-fixture calibration standards that are available.




Figure 8-24. Special Test Fixtures

These special calibration kits are far from perfect, but they are superior to our perfect transmission line assumption.

You may also have heard of the probe stations built to permit on-wafer calibration measurements.

The Open, Short, termination approach provides three known standards that permit the analyzer to solve for three unknowns (Figure 8-25).




Figure 8-25. Solving for Unknowns

SPECIAL CALIBRATION DEVICES PROB-LEMS

- Opens Are Difficult-Radiation Effects
- Good Terminations Are Hard to Find, 20-30 db Is Often the Best That We Can Do and This Determines the "Effective Directivity"


ON-WAFER CALIBRATION

Calibration Standards Are on a Wafer

-
- Model
 - Measure
 - Compute the Desired Result
-
- CHARACTERIZE THE FIXTURE**
APPROACH NUMBER 2
-

The second approach is to model the fixture. Modeling is elegant but of limited use due to the non-ideal characteristics of the fixture. Modeling can be accomplished in a CAD system like Touchstone or Compass. In summary, there are quite a variety of approaches—all with their own characteristic pitfalls. Engineers try to choose the most appropriate technique for their application.

Figure 8-26. Three Known Impedances




You should turn off or disconnect the bias supplies during the calibration, since you are using a Short as the calibration standard.

It is also possible to use three known impedances. For instance, a varactor with three voltages applied (Figure 8-26).

CAUTION

8-6 MULTIPLE SOURCE CONTROL

The Multiple Source Control mode permits independent control of the 372XXA source, receiver, and an external WILTRON synthesizer (67XXB, 68XXB), without the need of an external controller (Figure 8-1).



1. Remove loop between Reference Extension connectors RA In and RA Out.
2. Set up equipment as shown.
3. Normalize the data trace with the standard mixer installed.
4. Subsequent mixers can be tested for magnitude or phase match with respect to the "Standard Mixer."

Figure 8-1. Test Setup for Multiple Source Control Operation

Operation in this mode requires Option 11. Removing the reference loop lets you isolate the receiver from the source. This permits testing of frequency converters such as mixers.

The software lets the frequency ranges and output powers of the two sources be specified. A frequency sweep can comprise up to five separate bands, each with independent source and receiver settings for convenient testing of frequency translation devices such as mixers. Up to five sub-bands (harmonics) can be tested in one sweep.

Multiple Source control is specified as a displayed frequency range partitioned into from one-to-five consecutive bands. For each band Source 1, Source 2, and receiver frequencies may be interdependently specified per the formula:

$$Frequency = \left(\frac{Multiplier}{Divisor} \right) \times \left(\frac{Offset Frequency}{F} \right)$$

Control Formula

Bands

NOTE

When a formula results in an unachievable frequency, such as $1/3 \times 1 \text{ GHz}$, the result is rounded to the nearest achievable frequency, defined by the source frequency resolution. Frequency resolution is 1 kHz, except for 67XXB sources with a high-end frequency above 20 GHz. For these models, the resolution is 2 kHz.

- The following rules apply:
- Multiplier and Divisor are integer constants
 - F is the displayed frequency
 - Offset Frequency is the offset frequency constant
- Where:
- Multiplier and Divisor are integer constants
 - F is global, and is the same value in all formulas.
 - Each source or receiver may, if desired, be set to a CW frequency, removing F from the equation.

The displayed frequency range may be divided into up-to five bands. Band 1 must start at the beginning of the frequency range and end at either the user-specified stop frequency or the end of the frequency range. Band 2 must begin at the next point after band 1 ends, and it must end at either the user-specified stop frequency or the end of the frequency range. Band 5 must end at the end of the frequency range. Independent source and receiver control formulas may be specified for each band.


Procedures for performing preoperation and operation are given on pages 8-31 thru 8-34.

Operation Procedures

Multiple Source Control Preoperational Setup
 The two sources receive control information from the 372XXA VNA. The GPIB address assigned to the external source must be identical to the address contained in the data directed to the source by the 372XXA VNA. Assure source/VNA address compatibility as follows:

Step 1. Install Sources 1 and 2 on the GPIB (IEEE-488 bus).

Step 2. Press the Utility Menu key.



MENU U1	
SELECT UTILITY	
FUNCTION OPTIONS	
GPIB ADDRESSES	
DISPLAY	
INSTRUMENT	
STATE PARAMS	
GENERAL DISK	
UTILITIES	
CALIBRATION	
COMMENT	
UTILITIES	
COLOR	
CONFIGURATION	
DATA OFF	
DRAWING	
BLANKING	
FREQUENCY	
INFORMATION	
PRESS <ENTER>	
TO SELECT	
OR TURN ON/OFF	

MENU GP7	
GPIB ADDRESSES	
IEEE 488.2	
GPIB INTERFACE	
ADDRESS:	
6	
DEDICATED	
GPIB INTERFACE	
EXTERNAL SOURCE	
4	
PLOTTER	
8	
POWER METER	
13	
FREQUENCY COUNTER	
7	

Step 3. Move cursor to **GPIB ADDRESSES** and press Enter, when menu U1 (left) appears.

Step 4. When menu GP7 (left) appears, observe that the address number is correct. If necessary, use keypad to enter new address.



When menu GP7 (left) appears, observe that the address number is correct. If necessary, use keypad to enter new address.

DUAL SOURCE CONTROL

MEASUREMENTS

Multiple Source Control Operation

Step 5. Press the Option Menu key.




Step 6.

When menu OPTIONS (left) appears, move cursor to MULTIPLE SOURCE CONTROL and press Enter.

Step 7.

When menu OM1(left) appears, move cursor to DEFINE BANDS and press Enter. This brings menu OM 1 to the screen.



Step 8. Coincident with menu OM2 (left), the data display area of the screen presents a chart entitled "RANGES OF BANDS STORED." This chart shows the band start and band stop frequencies that have been stored for each of five bands. Using menu OM2, the displayed frequency range can be divided into one to five bands. Band 1 must start at the beginning of the frequency range and end at either the user-specified stop frequency or the end of the frequency range. Band 2 must begin at the next point after band 1 ends and end at either the user-specified stop frequency or the end of the frequency range.

Step 9. Move cursor to **BAND**; select **BAND 1** by entering "1" using the keypad or rotary knob. Move cursor to **BAND START F**, and use keypad or rotary knob to enter the band 1 start frequency. Move cursor to **BAND STOP F**, and enter the band 1 stop frequency.

Step 10. Move cursor to **EDIT SYSTEM EQUATIONS** and press Enter.

Step 11. When menu OM3 (left) appears, select **SOURCE 1**. Move cursor to **MULTIPLIER** and use keypad or rotary knob to enter desired multiplier for Source 1. This is the multiplier term in the following equation: $\text{Freq.} = (\text{Multiplier/Divisor}) \times (\text{F} + \text{Offset Frequency})$

Step 12. Move cursor to **DIVISOR** and use keypad or rotary knob to enter desired **DIVISOR** for source 1. This is the divisor term given in the above equation. Move cursor to either **OFFSET FREQUENCY**, and use keypad or rotary knob to enter desired offset frequency for Source 1; or **C.W.**, and press Enter to toggle C.W. to OFF.

Step 13. The Offset Frequency choice is the offset frequency given in the above equation. The C.W. choice re-moves F from the equation and places Source 1 in the CW mode.

MENU OM2
DEFINE BANDS
BAND 1
DISPLAYED
FREQ RANGE
BAND START F
XXX.XXXXXX XXX GHZ
BAND STOP F
XXX.XXXXXX XXX GHZ
BAND FUNCTIONS
EDIT SYSTEM
EQUATIONS
STORE BAND 1
BANDS STORED:
(1 2 3 4 5)
CLEAR ALL
DEFINITIONS
SET MULTIPLE
SOURCE MODE
PRESS <ENTER>
TO SELECT

MENU OM3
EDIT SYSTEM
EQUATIONS
TO EDIT
EQUATION
SOURCE 1
SOURCE 2
RECEIVER
EQUATION
SUMMARY
C.W. OFF
MULTIPLIER
XX
DIVISOR
XX
OFFSET FREQ
XXX.XXXXXX XXX GHZ
PREVIOUS MENU
PRESS <ENTER>
TO SELECT

Step 17. Move the cursor to **PREVIOUS MENU** and press Enter. This returns you to menu **OM2** (left).

Step 18. Move cursor to **STORE BAND 1** and press **ENTER**. This stores the band start frequency, the band stop frequency and the Source 1, Source 2 and Receiver equations.

Step 19. Note that the **BAND** number has incremented to 2.

Step 20. Repeat the above steps to define the start and stop frequencies for bands 2 thru 5. Set up the system equations for each band.

NOTE

Except for band 1, the system software constrains all start frequencies to follow the previous band's stop frequency. However, while frequency bands are being defined or the system equations are being edited, the system is automatically placed in the standby mode. In this mode, frequencies that may be entered are not supervised by the system software; any frequency can be entered and displayed. When the mode is switched to **ON** (in menu **OM1**, left), the system software restricts the frequencies to band limits. When the mode is switched to **OFF**, the frequencies are restricted to system limits.

MENU OM1
MULTIPLE SOURCE CONTROL
DEFINE BANDS
MULTIPLE SOURCE MODE
OFF
STANDBY
ON
PRESS <ENTER> TO SELECT

MENU OM2
DEFINE BANDS
BAND 2
DISPLAYED
FREQ RANGE
BAND START F
XX.XXXXXX GHZ
BAND STOP F
XX.XXXXXX GHZ
BAND FUNCTIONS
EDIT SYSTEM
EQUATIONS
STORE BAND 1
BANDS STORED:
(NONE)
CLEAR ALL
DEFINITIONS
SET MULTIPLE
SOURCE STATE
PRESS <ENTER> TO SELECT

Chapter 9

Time Domain

Table of Contents

INTRODUCTION	9-1
TIME DOMAIN MEASUREMENTS	9-2
OPERATING TIME DOMAIN	9-3
WINDOWING	9-4
GATING	9-5
GATING EXAMPLE	9-6
9-13	

Chapter 9 Time Domain

This chapter describes the optional Time Domain feature.

The Option 2, Time Domain feature provides a useful measurement tool for determining the location of impedance discontinuities. Some typical applications are identifying and analyzing circuit elements, isolating and analyzing a desired response, locating faults in cables, and measuring antennas.

The relationship between the frequency-domain response and the time-domain response of a network is described mathematically by the Fourier transform.

The 372XXA makes measurements in the frequency domain then calculates the inverse Fourier transform to give the time-domain response. The time-domain response is displayed as a function of time (or distance). This computational technique benefits from the wide dynamic range and the error correction of the frequency-domain data.

Let us examine the time-domain capabilities. Two measurement modes are available: lowpass and bandpass.

We use the lowpass mode with devices that have a dc or low-frequency response. In the lowpass mode two responses to the device-under-test (DUT) are available: impulse or step response.

The frequencies used for the test must be harmonically related (integer multiples) to the start frequency. The simplest way to calculate this relationship is to divide the highest frequency in the calibration by 1600 (the default number-of-points available); this is the start frequency. For example if the highest frequency is 40 GHz, the calculated start frequency is 0.025 GHz (40/1600).

9-2 TIME DOMAIN MEASUREMENTS

9-1 INTRODUCTION

TIME DOMAIN A USEFUL TOOL FOR:

- Identifying and Analyzing Circuit Elements

- Isolating a Desired Response

- Locating Faults

- Making Antenna Measurements

372XXA TIME DOMAIN MODES

- Lowpass Mode

- Bandpass Mode

LOWPASS MODE

- Either Impulse or Step Response Available

- Displays Impedance Information

- Requires Harmonically Related Frequencies


- Used When Device Has a DC or Low Frequency Path

The lowpass impulse response displays the location of discontinuities as well as information useful in determining the impedance (R, L, or C) of each discontinuity. If you are familiar with time-domain reflectometry

In the above example, the connectors at each end have been gated out (page 9-12), which lets you better observe the internal circuit response. Each displayed marker has been manually set to the peak of the response at each adjustable circuit element. In this way, the data display lets you make the adjustment in realtime, while the marker menu shows the magnitude of the response at each marker.

The lowpass step response displays the location of discontinuities as well as information useful in determining the impedance (R, L, or C) of each discontinuity. If you are familiar with time-domain reflectometry

Figure 9-2. Example of Lowpass Impulse Response



An example of using impulse response is circuit impedance analysis. With an impulse response, we can observe the circuit response of a passive device, such as a multielement step attenuator (Figure 9-2), and make final, realtime adjustments during the test.


The impulse response for a shunt capacitance is a negative-then-positive peak and for a series inductance is a positive-then-negative peak (Figure 9-1).

$$p = \frac{R - Z_0}{R + Z_0}$$

The impulse response is a peak that goes positive for $R > Z_0$ and negative for $R < Z_0$. The height of the response is equal to the reflection coefficient

The lowpass impulse response displays the location of discontinuities as well as information useful in determining the impedance (R, L, or C) of each discontinuity.

Figure 9-1. Lowpass Impulse Response



- Location of Discontinuities
 - Information on Type of Discontinuity
- LOWPASS IMPULSE RESPONSE

- LOWPASS STEP RESPONSE**
- TDR Measurement
 - Location of Discontinuities
 - Information on Type of Discontinuities




Figure 9-3. Lowpass Step Response

- BANDPASS MODE**
- Calculates Impulse or Phasor-Impulse Response
 - Uses Any Frequency Range
 - Used When Device Does Not Have a DC or Low-Frequency Path

(TDR) you may feel more comfortable with step response, as the displays are similar.

The lowpass step response for a resistive impedance is a positive level shift for $R > Z_0$ and a negative level shift for $R < Z_0$. The height of the response is equal to the reflection coefficient

$$\rho = \frac{R - Z_0}{R + Z_0}$$

The step response for a shunt capacitance is a negative peak, and for a series inductance it is a positive peak (Figure 9-3).

An example of using the lowpass step response is cable-fault location. In the frequency domain a cable with a fault exhibits a much worse match than a good cable. Using lowpass step response, both the location of the discontinuity and the information about its type are available (Figure 9-4).




Figure 9-4. Example of Lowpass Step Response

In the above example, the dip in the display shows the shunt-capacitive response caused by a crimp in the cable. The response at the end of the cable shows the step-up that is typical of an open (Figure 9-3). The 372XXA bandpass mode gives the response of the DUT to an RF-burst stimulus. Two types of response are available: impulse and phasor-impulse. An advantage of the bandpass mode is that any frequency range can be used. Use this mode with devices that do not have a dc or low-frequency path.

Use the bandpass-impulse response to show the location of a discontinuity in time or distance, as indicated by changes in its magnitude. Unlike the lowpass mode, no information as to the type of the discontinuity is available. A typical use for this mode is to measure devices—such as, filters, waveguide, high-pass networks, bandpass networks—where a low-frequency response is not available.

The bandpass-impulse response for various impedance discontinuities is shown in Figure 9-5. As we can see, no information about the type of discontinuity is available.

An example of using the bandpass-impulse response, is the pulse height, ringing, and pulse envelope of a bandpass filter (Figure 9-6). Use the phasor-impulse response with bandpass response to determine the type of an isolated impedance discontinuity.

BANDPASS IMPULSE RESPONSE

- Magnitude Measurement Only
- Location of Discontinuities
- No Information on Type of Discontinuities

CIRCUIT ELEMENTS




Figure 9-5. Bandpass Impulse Response

- Real and Imaginary Measurement
 - Information On Type of Discontinuity
- PHASOR IMPULSE BANDPASS RESPONSE**

After the bandpass-impulse response has been isolated, the phasor-impulse response for a resistive-impedance-level change is a peak that goes positive ($R > Z_0$) for the real part of S_{11} and negative for $R < Z_0$. The imaginary part remains relatively constant. In each case the peak is proportional to the reflection coefficient. The phasor-impulse response for a shunt capacitance is a negative-going peak in the imaginary part of S_{11} . For a series inductance, it is a positive going peak (Figure 9-7).

Figure 9-6. Example of Bandpass-Impulse Response





Figure 9-7. Complex Impedances



Next, let us look at a complex circuit. A resistive impedance change $R < Z_0$ and a shunt capacitance and series inductance. These impedance changes are shown in the time domain for the lowpass-impulse response, lowpass-step response, and bandpass-impulse response (Figure 9-8).




Figure 9-8. Bandpass Phasor Response

The 372XXA processes bandpass-impulse-response data to obtain phasor-impulse response. This becomes most advantageous where both a reactive reflection and an impedance change occur at the same location. The real part of the time-domain response shows the location of impedance level changes, while the imaginary part shows the type of reactive discontinuity. Phasor-impulse response displays one discontinuity at a time (Figure 9-9).




Figure 9-9. Phasor-Impulse Response Data

Figure 9-10. Domain Menu


DOMAIN FREQUENCY FREQUENCY WITH TIME GATE TIME LOWPASS MODE BANDPASS MODE DISPLAY TIME/DISTANCE SET RANGE SET GATE GATE ON/OFF HELP PRESS <ENTER> TO SELECT OR SWITCH	DOMAIN FREQUENCY FREQUENCY WITH TIME GATE TIME LOWPASS MODE BANDPASS MODE DISPLAY TIME/DISTANCE SET RANGE SET GATE GATE ON/OFF HELP PRESS <ENTER> TO SELECT OR SWITCH	DOMAIN FREQUENCY FREQUENCY WITH TIME GATE TIME LOWPASS MODE BANDPASS MODE DISPLAY TIME/DISTANCE SET RANGE SET GATE GATE ON/OFF HELP PRESS <ENTER> TO SELECT OR SWITCH
--	--	--

Figure 9-11. Reference Delay Menu

SET
 DIELECTRIC
 CONSTANT
 AIR
 (1.000649)
 POLYETHYLENE
 (2.26)
 TEFLON
 (2.10)
 MICROPOROUS
 TEFLON
 (1.69)
 OTHER
 XXXX.XX
 PRESS <ENTER>
 TO SELECT

If you select distance, be sure to set the dielectric constant in the Reference Delay menu (Figure 9-11).

NOTE



To operate in the time domain mode, press the Domain key (below). A domain menu (Figure 9-10) lets you select the frequency- or time-domain modes by simple cursor selection. The 372XXA defaults to the frequency domain.

Select time or distance for the horizontal axis. The 372XXA defaults to time axis.

9-3 OPERATING TIME DOMAIN

OPTION 2A TIME DOMAIN

OPTIONS

Select SET RANGE and use the START/STOP or GATE/SPAN selections to set the range (Figure 9-12).





Figure 9-12. Set Range Menu

For the lowpass mode select either IMPULSE or STEP Response and set the DC term. The 372XXA defaults to the IMPULSE Response and the AUTO EXTRAPOLATE mode for the DC term (Figure 9-13).

NOTE


The bandpass mode displays Bandpass Impulse Response unless we select Phasor Impulse Response.

Figure 9-14. Marker Range Menus



The Marker Range menu allows us to zoom in and display the range between two selected markers (Figure 9-14).

Figure 9-13. Response Menus



9-4 WINDOWING

Windowing is a frequency filter that we apply to the frequency-domain data when we convert it to time-domain data. This filtering rolls off the abrupt transition at F1 and F2. This effectively produces a time-domain response with lower sidelobes. Windowing allows a limited degree of control over the pulse shape, trading off ringing (sidelobes) for pulse width (Figure 9-15).

We select windowing from the Time Domain Setup menu. Four different windows are available: RECTANGLE, NOMINAL, LOW SIDELobe, and MINIMUM SIDELobe. The RECTANGLE option provides the narrowest pulse width, while the MINIMUM SIDELobe option provides the least ringing (fewest sidelobes). The 372XXA defaults to the NOMINAL option, which is acceptable for most measurements. Windowing menus are shown in Figure 9-16.




Figure 9-15. Windowing




Figure 9-16. Window Shape Menus

Convert the frequency domain data into the time domain using TIME BANDPASS MODE (Figure 9-20).

Step 1.




Figure 9-20. Time Gating

- DOMAIN
- FREQUENCY
- FREQUENCY WITH TIME
- GATE
- TIME LOWPASS MODE
- TIME BANDPASS MODE
- DISPLAY
- SET RANGE
- SET GATE
- GATE ON/OFF
- HELP
- PRESS <ENTER> TO SELECT OR SWITCH

Select SET GATE in the Domain menu (left) then GATE DISP in the Gate menu. This allows us to put the gate around the discontinuity of interest using the START, STOP, CENTER, or SPAN selections (Figure 9-21).

Step 2.





Figure 9-21. Gate Display

- GATE
- START XXX.XXX mm
- STOP XXX.XXX mm
- CENTER XXX.XXX mm
- SPAN XXX.XXX mm
- SET SHAPE
- NOMINAL
- GATE DISP
- PREVIOUS MENU
- PRESS <ENTER> TO SELECT


- SHAPE
- RECTANGULAR
- NOMINAL
- LOW SIDELOBE
- MIN SIDELOBE
- HELP
- PRESS <ENTER> TO SELECT

Figure 9-23. Response with PHASOR IMPULSE ON Selected



Step 4. Select PHASOR IMPULSE ON in the Bandpass menu. The real and imaginary responses of the Phasor Impulse Response are displayed. Based on the display, the device has a series inductance as well as resistance >50 ohms (Figure 9-23).

Figure 9-22. Response with GATE ON Selected




Step 3. Select GATE ON in the Gate menu and the unwanted responses are removed (Figure 9-22).

- MEASUREMENT CONSIDERATIONS
- Small Responses
 - Close Responses
 - Distant Responses


Finally, let's look at some measurement considerations and ways to optimize their time-domain results.

Figure 9-25. Antenna Measurements



An example of gating a transmission measurement is making an antenna measurement. Gating can remove unwanted ground or chamber reflections that interfere with characterizing an antenna's pattern (Figure 9-25).

Figure 9-24. Response FREQUENCY WITH TIME GATE Selected



Select FREQUENCY WITH TIME GATE in the Domain menu to display the frequency domain S11 forward reflection of the gated time domain response (Figure 9-24).

Step 5.

OPTIONS

**OPTION 2A
TIME DOMAIN**

SMALL RESPONSES

- Small Impedance Changes
- Long Lossy Devices
- High Insertion Loss Paths

OPTIMIZE FOR SMALL RESPONSES

- Use Averaging
- Use 100 Hz IF Bandwidth
- Use Window With Least Ringing

CLOSE RESPONSES

- Physically Close Elements
- Similar Length Transmission Paths

OPTIMIZE FOR CLOSE RESPONSES

- Use Widest Sweep
- Use Window with Narrowest Pulse Shape

DISTANT RESPONSES

- Use 1601 Points
- Use Minimum Required Frequency Range

**Optimizing
Time Domain
Results**

Small impedance changes cause small responses that can be lost in the noise floor. This is also true of long cable and waveguide runs with high insertion loss.

To optimize for small responses:

- Use averaging and 100 Hz IF bandwidth to lower the noise floor.
- Use maximum power to provide maximum dynamic range.
- Use the window with the lowest sidelobes to reduce ringing.

Elements that are physically close or have similar length transmission paths can have minimal or overlapping time domain responses.

To optimize for close-response measurements and attain the best resolution:

- Use the widest sweep.
- Use the window with the narrowest pulse shape.


To maximize the distance measurement capability without causing aliasing (false information), use the minimum-frequency-step size by selecting 1601 points and the minimum-required-frequency range.

In summary, the 372XXA Time Domain capability is a powerful and versatile tool in performing network analyzer measurements.

A flow diagram of the menus associated with the Time Domain Option is shown in foldout Figure 9-25. The menu choices are described in Appendix A. They appear in alphabetical order by their call letters: TD1, TD2, TD2d1, etc.

**Time Domain
Menus**

Figure 9-25. Time Domain Menu Flow



NOTE 1: For "DISPLAY = DISTANCE" and "TIME, LOWPASS MODE."
 NOTE 2: For "DISPLAY = TIME" and "TIME, LOWPASS MODE."
 NOTE 3: For "DISPLAY = DISTANCE" and "TIME, BANDPASS MODE."
 NOTE 4: For "DISPLAY = TIME" and "TIME, BANDPASS MODE" and "FREQUENCY" or "FREQUENCY WITH TIME GATE."



Chapter 10
Operational Checkout
Procedures

Table of Contents

10-1	INTRODUCTION	
10-2	REQUIRED EQUIPMENT	
10-3	SELF TESTS	
10-4	INITIAL SYSTEM SETUP	
10-5	SAMPLER EFFICIENCY TEST	
10-6	HIGH LEVEL NOISE TEST	
10-8	Test Setup	
10-9	Test Procedure	

Chapter 10 Operational Checkout Procedures

10-1 INTRODUCTION

This chapter provides quick operational checkout procedures that may be used by incoming inspectors to ensure that the Model 372XXA Vector Network Analyzer is operational. This is a quick-check procedure. For the full performance verification procedure, refer to the Series 372XXA Maintenance Manual, Wiltron Part Number 10410-00153.

10-2 REQUIRED EQUIPMENT

Flexible microwave cable (through line).
Short, Open


10-3 INITIAL SETUP

Perform the following steps before starting the performance tests.

- Press Power key (left) to On.


NOTE

Allow the system to warm up for at least 60 minutes to ensure operation to performance specifications.



10-4 SELF TEST


Perform an instrument self test to ensure that the 372XXA is operating properly. To start a self test, Press Option Menu key and make the menu choices shown in Figure 10-1.




This test verifies that each individual receiver channel operates properly. Measurement calibration of the system is *not* required for this test. This test requires that you press specified front panel keys and make choices from the displayed menu(s). The keys used in this test are shown below.

10-5 SAMPLER EFFICIENCY TEST

Figure 10-1. Performing a Self Test



Step 1. Connect Test Ports 1 and 2 together using a high-quality through line (below).
Setup 372XXA as described below.



Test Setup

Key	Menu Choice
Options	Non-Ratioed Parameters, see Figure 10-2
Setup	START: 1 GHz STOP: Table 10-1, High-End Frequency
Channel	FOUR CHANNELS
Graph	LOG MAGNITUDE (All channels)

Step 2. Reset the 372XXA using the Default Program key.
Step 3. Set up the 372XXA as shown in table at left.

Perform test as described below.

Step 1. Observe sweep indicators and allow at least one complete sweep to occur on all four channels.

Step 2. Verify that the maximum-value to minimum-value amplitude slope (Figure 10-3, page 10-7) meets the specifications shown below.

Model	High-End Frequency	Reference Channel Slope	Test Channels Slope
37211A	3 GHz	<5 dB	<8 dB
37217A	8.6 GHz	<5 dB	<10 dB
37225A	13.5 GHz	<7 dB	<9 dB
37247A	20 GHz	<7 dB	<9 dB
37269A	40 GHz	<16 dB	<18 dB

Test Procedure

Step 1. Press OPTION MENU key.

Step 2. Make menu choices as shown below.

Step 3. Press SETUP MENU key; set START frequency to 1 GHz.




Figure 10-2. Redefining Selected Parameter Automatically for Sampler Efficiency Testing

Step 3. Verify that the minimum amplitude meets the specifications shown below.

Model	Test Channels	Reference Channel
37211A	-25	-20
37217A	-28	-22
37225A	-30	-24
37247A	-31	-25
37269A	-40	-40

NOTE

Use the Marker Menu and Readout Marker keys (left) and menus to obtain precise frequency and amplitude values.





Figure 10-3. Sampler Efficiency Test Waveforms




10-6 HIGH LEVEL NOISE TEST

The following test verifies that the high-level signal noise in the 372XXA will not significantly affect the accuracy of subsequent measurements. Calibration of the system is *not* required for this test.

This test requires that you press specified front panel keys and make choices from the displayed menu(s). The keys used in this test are highlighted below.

Test Setup Setup 372XXA as described in table at left.

Key	Menu Choice	Setup Menu	Channel Menu	Graph Type	Scale	S-Params	Avg/Smooth Menu	Average	Data Points	Video IF BW	Limits		
		START: 40 MHz STOP: High-end frequency	DUAL CHANNELS 1-3	LOG MAGNITUDE (Both channels)	RESOLUTION: 0.020 dB/DIV REF VALUE: 0.0 dB (Both channels)	Channel 1 - S12 Channel 3 - S21	AVERAGING 128 MEAS. PER POINT	ON	401	NORMAL (1 kHz)	UPPER LIMIT ON 0.020 dB 37247A & below), or: 0.040 dB (37269A)	LOWER LIMIT ON -0.020 dB (37247A & below) or: -0.040 dB (37269A)	DISPLAY LIMITS ON



*Test
Procedure*

Perform test as described below.

Step 1. Connect Test Port 1 and Test Port 2 (top left) together.

Step 2. Press Ch 1 key.

Step 3. Press Trace Memory key.

Step 4. Choose **VIEW DATA** (Figure 10-4) from menu and press Enter key.

Step 5. While observing sweep indicators, allow at least two complete sweeps to occur.

Step 6. Choose **STORE DATA TO MEMORY** from menu and press Enter key.

Step 7. Choose **VIEW DATA / MEMORY** from menu and press Enter key.

Step 8. While observing sweep indicators, allow at least two complete sweeps to occur.

Step 9. Verify that the peak-to-peak High Level Noise falls within the area between the two limit lines (Figure 10-4).

Step 10. Press Ch 3 key.

Step 11. Repeat steps 4 thru 9 for channel 3.

Step 12. Press S Params key; set Ch 1 for S11 and Ch 3 for S22.

Step 13. Connect a Short to Test Port 1 and an Open to Test Port 2 (left).

Step 14. Repeat steps 2 thru 9.






Figure 10-4. High Level Noise Test Waveform



APPENDIX A FRONT PANEL MENUS, ALPHABETICAL LISTING

A-1 INTRODUCTION

This appendix provide description for all menu choices. Menus are arranged in alphabetical order by call sign (C1, SU2, DSK1, etc).

A-2 MENUS

A listing of all of the menus contained in this appendix is provided in the tabulation below. This listing gives the call sign, name, and page number of the menus.

Menu Call Letter and Name	Page Number
Menu BW1 or CAL_BW1, Select Video Bandwidth	A-6
Menu C1, Select Calibration Data Points	A-7
Menu C2, Frequency Range of Calibration	A-8
Menu C2A, Insert Individual Frequencies	A-9
Menu C2B, Single Point Calibration	A-10
Menu C2C, Calibration Range—Harmonic Cal for Time Domain	A-10
Menu C2D, Fill Frequency Ranges	A-11
Menu C3, Confirm Calibration Parameters	A-12
Menu C3A, Confirm Calibration Parameters	A-13
Menu C3B, Confirm Calibration Parameters	A-14
Menu C3C, Confirm Calibration Parameters	A-15
Menu C3D, Confirm Calibration Parameters	A-16
Menu C3E, Confirm Calibration Parameters	A-17
Menu C3F, Confirm Calibration Parameters	A-17
Menu C3G, Confirm Calibration Parameters	A-18
Menu C4_P1/C4_P2, Select Calibration Type	A-19
Menu C4A_P1/C4A_P2, Select Calibration Type	A-20
Menu C5, Select Calibration Type	A-21
Menu C5A, Select 1 Path 2 Port Calibration Type	A-22
Menu C5B, Select Transmission Freq Response Calibration Type	A-22
Menu C5C, Select Reflection Only Calibration Type	A-23
Menu C5D, Select Use of Isolation	A-23
Menu C6, Select Load Type	A-24
Menu C6A, Enter Broadband Load Impedance	A-24
Menu C7-Series, Begin Calibration Sequence	A-25
Menu C8, Slide Load to Position X	A-25
Menu C9, Connect Througline	A-26

Menu C9A, Connect Device 1, Line A-26
 Menu C9B, Connect Device 2, Line/Lowband A-27
 Menu C9C, Connect Device 2, Line A-27
 Menu C11, Begin Calibration A-28
 Menu C11A, Select Calibration Method A-29
 Menu C12_P1/C12_P2, Enter the Capacitance A-30
 Coefficients for Open Devices A-30
 Menu C12A_P1/C12A_P2, Enter the Offset Length A-31
 Menu C13, Set Reflection Pairing Menu A-31
 Menu C14, Enter Offset Lengths (Shorts) A-32
 Menu C15, Select Waveguide Kit to Use A-33
 Menu C15A, Enter Waveguide Parameters A-34
 Menu C15B, Enter Waveguide Parameters A-34
 Menu C16, Select Microstrip Parameters A-35
 Menu C16A, Enter Microstrip Parameters A-35
 Menu C17, Enter Line Impedance A-36
 Menu C18, Change LRL/LRM Parameters A-36
 Menu C18A, Change LRL/LRM Parameters A-37
 Menu C18B, Change LRL/LRM Parameters—Two Band Calibration A-38
 Menu C19, Change LRL/LRM Parameters A-39
 Menu C20, Change Through Parameters A-40
 Menu Cal_Compiled A-40
 Menu Cal_Applied A-41
 Menu Cal_EM, Enhancement Menu for Calibration A-41
 Menu CM, Select Display Mode A-42
 Menu DB1, PORT 1 or PORT 2 Select A-43
 Menu DF1, Discrete Fill A-44
 Menu DF2, Insert Individual Frequencies A-45
 Menu DFLT, Default Program Selected A-46
 Menu DG1, Diagnostics 1 A-47
 Menu DG2, Troubleshooting A-48
 Menu DG3, Diagnostics 3 A-49
 Menu DSK1-FD, Floppy Disk Utilities A-51
 Menu DSK1-HD, Hard Disk Utilities A-51
 Menu DSK2, Select File to Read A-52
 Menu DSK3, Select File to Overwrite A-53
 Menu DSK6, Type of Files to Delete A-54
 Menu DSK7, Select File to Delete A-55
 Menu DSK8, Type of Files to Copy A-56
 Menu DSK9, Select File to Copy A-57
 Menu DSK10, Capture Tabular Data A-60

Menu Call Letter and Name Page Number

Menu DSK11, Caution A-60

Menu EM, Enhancement Menu A-61

Menu GP5, Select Name A-62

Menu GP7, Display GPIB Status A-63

Menu GT1, Select Graph Type A-64

Menu GT2, Select Graph Type A-65

Menu L1, Set Limits—Magnitude and Phase A-66

Menu L2, Set Limits—Linear Polar A-67

Menu L3, Set Limits—Linear Polar/Smith Chart A-68

Menu L4, Set Limits—Log Magnitude A-69

Menu L5, Set Limits—Phase A-70

Menu L6, Set Limits—Log Polar A-71

Menu L7, Set Limits—Group Delay A-72

Menu L8, Set Limits—Linear Magnitude A-73

Menu L9, Set Limits—Linear Magnitude and Phase A-74

Menu L10, Set Limits—Real Values A-75

Menu L11, Set Limits—Imaginary Values A-76

Menu L12, Set Limits—Real and Imaginary Values A-77

Menu L13, Set Limits—SWR A-78

Menu LD1, Define Upper Limit A-79

Menu LD2, Define Lower Limit A-80

Menu LF1, Set Limit Frequencies—Log Mag A-81

Menu LF2, Set Limit Frequencies—Phase A-82

Menu LF3, Set Limit Frequencies—Group Delay A-83

Menu LF4, Set Limit Frequencies—Linear Mag A-84

Menu LF5, Set Limit Frequencies—SWR A-85

Menu LF6, Set Limit Frequencies—Real A-86

Menu LF7, Set Limit Frequencies—Imaginary A-87

Menu LSX, Segmented Limits A-88

Menu LTST, Test Limits A-89

Menu M1, Set Markers A-90

Menu M2, Select ARRF Marker A-91

Menu M3, Select Readout Marker A-91

Menu M4, Readout Marker A-92

Menu M5, Set ARRF Marker Readout A-93

Menu NO1, Trace Memory Functions A-94

Menu NO2, Select Trace Math A-95

Menu NO3, Trace Memory Disk Functions A-95

Menu OM1, Multiple Source Control Menu A-96

Menu OM2, Define Bands Menu A-97

Menu OM3, Edit System Equations A-98

Page Number

Menu Call Letter and Name

Page Number	Menu Call Letter and Name
A-99	Menu OPTNS, Select Options
A-100	Menu ORP1, Rear Panel Output Control
A-101	Menu ORP2, Select Output Mode
A-102	Menu PC1, Select Polar Chart Mode
A-103	Menu PL1, Plot Options
A-104	Menu PL2, Select Plot Size
A-105	Menu PL3, Select Pen Colors
A-106	Menu PM1, Select Data Output Type
A-107	Menu PM2, Data Output Headers
A-108	Menu PM3, Tabular Printer Output Format
A-109	Menu PM3A, Graphical Printer Output Format
A-110	Menu PM4, Disk Output Operations
A-111	Menu PM5, Printer Type, Options
A-112	Menu RCV1, Receiver Mode
A-112	Menu RCV2, User Defined Receiver Mode Menu
A-113	Menu RCV3, Standard Receiver Mode Warning Menu
A-113	Menu RCV4, User Defined Receiver Mode Warning Menu
A-114	Menu RD1, Set Reference Delay
A-115	Menu RD2, Set Dielectric Constant
A-116	Menu SP, Select S Parameter
A-116	Menu SR1, Save/Recall Front Panel Information
A-117	Menu SR2, Recall or Save
A-118	Menu SR3, Save to Internal memory
A-119	Menu SS1 or CAL_SS1, Set Scaling 1
A-120	Menu SS2 or CAL_SS2, Set Scaling 2
A-121	Menu SS3Z/SS3Y or CAL_SS3Z/CAL_SS3Y, Set Scaling 3
A-122	Menu SS4 or CAL_SS4, Set Scaling 4
A-123	Menu SS5 or CAL_SS5, Set Scaling 5
A-124	Menu SS6 or CAL_SS6, Set Scaling 6
A-125	Menu SS7 or CAL_SS7, Set Scaling 7
A-126	Menu SS8 or CAL_SS8, Set Scaling 8
A-127	Menu SS9 or CAL_SS9, Set Scaling 9
A-128	Menu SS10 or CAL_SS10, Set Scaling 10
A-129	Menu SS11 or CAL_SS11, Set Scaling 11
A-130	Menu SS12 or CAL_SS12, Set Scaling 12
A-131	Menu SS13 or CAL_SS13, Set Scaling 13
A-132	Menu SU1, Sweep Setup 1
A-133	Menu SU2 or CAL_SU2, Sweep Setup 2
A-134	Menu SU3, Single-Point Measurement Setup
A-135	Menu SU4, Select Function for Hold Button
A-136	Menu SU5, Frequency Marker Sweep

Menu SU6, Frequency Marker C.W. A-136

Menu SU8 or CAL_SU8, Calibrate For Flat Test Power A-138

Text Associated With Flat Power Calibration Menu SU8 A-139

Menu SU9, Number of Data Points A-140

Menu SU9A, Number of Data Points 2 A-141

Menu TD1, Domain (Frequency/Display) A-142

Menu TD2t1, Lowpass Time Domain Setup A-143

Menu TD2d1, Lowpass Distance Display Setup A-144

Menu TD2tb, Bandpass Time Domain Setup A-145

Menu TD2db, Bandpass Distance Display Setup A-146

Menu TD3b, Bandpass Time Domain Setup A-147

Menu TD3l, Lowpass Time Domain Setup A-147

Menu TD4d/t, Gate (Distance/Time) A-148

Menu TD5w, Shape A-149

Menu TD5g, Shape A-149

Menu TD6, Set D.C. Term for Low Pass Processing A-150

Menu TD7t, Time Marker Sweep. A-151

Menu TD7d, Distance Marker Range A-152

Menu TRIG, Triggers Measurement A-153

Menu U1, Utility Menu A-154

Menu U2, Display Instrument State A-155

Readout Text Associated With Menu U4 A-156

Menu U3, Calibration Component Utilities A-157

Menu U4, Display Installed Calibration A-158

Components Information 1 A-158

Menu U4A, Display Installed Calibration A-159

Components Information 2 A-159

Menu U5, Color Configuration A-159

Menu Call Letter and Name Page Number

Menu BW1 or CAL_BW1, Select Video Bandwidth

DESCRIPTION	MENU
<p>Selects video bandwidth to be 10 KHz.</p>	<p>SELECT VIDEO BANDWIDTH MAXIMUM (10 KHZ)</p>
<p>Selects video bandwidth to be 1 KHz.</p>	<p>NORMAL (1 KHZ)</p>
<p>Selects video bandwidth to be 100 Hz.</p>	<p>REDUCED (100 HZ)</p>
<p>Selects video bandwidth to be 10 Hz.</p>	<p>MINIMUM (10 HZ)</p>
<p>Pressing the ENTER key implements your selection. The "AND RESUME CAL" text appears when menu is accessed during calibration.</p>	<p>PRESS <ENTER> TO SELECT AND RESUME CAL</p>

Menu C1, Select Calibration Data Points

DESCRIPTION	MENU
<p>Selects the standard calibration from a start to a stop frequency that provides for up to 1601 equally spaced (except the last) points of data for the defined frequency range.</p> <p>Selects the single frequency (C.W.) calibration sequence that provides for 1 data point at a selected frequency.</p> <p>Selects the discrete frequency calibration mode that lets you input a list of 2 to 1601 individual data point frequencies.</p> <p>Selects the calibration mode for low-pass time-domain processing.</p> <p>Pressing the ENTER key implements your selection.</p>	<p>SELECT CALIBRATION DATA POINTS</p> <p>NORMAL (1601 POINTS MAXIMUM)</p> <p>C.W. (1 POINT)</p> <p>N-DISCRETE FREQUENCIES (2 TO 1601 POINTS)</p> <p>TIME DOMAIN (HARMONIC)</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C2, Frequency Range of Calibration (Start/Stop)

DESCRIPTION	MENU
<p>Enter the sweep-start frequency for calibration. If you desire, you can change this frequency for your measurement when you reach menu SU1, which follows the final calibration menu. The only restriction is that your start measurement frequency be greater than or equal to your start calibration frequency.</p> <p>Enter the sweep-stop frequency for calibration. Like the start frequency, this too can be changed for your measurement. The stop frequency must be lower than or equal to your stop calibration frequency. In other words, your measurement frequency span must be equal to or smaller than your calibration frequency span.</p> <p>Calls Menu C2_CENTER, which lets you enter a center frequency and span range.</p> <p>The program automatically sets the step size, based on the selected start and stop frequencies. The step size will be the smallest possible (largest number of points up to a maximum of 1601), based on the chosen frequency span.</p> <p>Displays the next menu in the calibration sequence.</p> <p>Pressing the ENTER key implements your menu selection.</p>	<p>FREQUENCY RANGE OF CALIBRATION</p> <p>START XXX.XXXXXXXXXXXGHZ</p> <p>STOP XXX.XXXXXXXXXXX GHZ</p> <p>SET CENTER/SPAN</p> <p>XXX DATA POINTS XXX.XXXXXXXXXXXGHZ STEP SIZE</p> <p>MAXIMUM NUMBER OF DATA POINT(S)</p> <p>1601 MAX PTS 801 MAX PTS 401 MAX PTS 201 MAX PTS 101 MAX PTS 51 MAX PTS</p> <p>NEXT CAL STEP</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C2_CENTER, Frequency Range of Calibration (Center/Span)

DESCRIPTION	MENU
<p>Enter the center frequency for calibration. If you desire, you can change this frequency for your measurement when you reach menu SU1_CENTER, which follows the final calibration menu.</p> <p>Enter the span width for calibration. Like the start frequency, this too can be changed for your measurement.</p> <p>Calls Menu C2, which lets you enter a start and stop frequency.</p> <p>The program automatically sets the step size, based on the selected center and span frequencies. The step size will be the smallest possible (largest number of points up to a maximum of 1601), based on the chosen frequency span.</p> <p>MAXIMUM NUMBER OF DATA POINT(S)</p> <p>1601 MAX PTS 801 MAX PTS 401 MAX PTS 201 MAX PTS 101 MAX PTS 51 MAX PTS</p> <p>ENTER THE CENTER FREQUENCY RANGE</p> <p>XXX.XXXXXXXXXXXGHZ</p> <p>SPAN</p> <p>XXX.XXXXXXXXXXX GHZ</p> <p>SET START/STOP</p> <p>XXX DATA POINTS</p> <p>XXX.XXXXXXXXXXXGHZ</p> <p>STEP SIZE</p> <p>TO SELECT</p> <p>PRESS <ENTER></p> <p>NEXT CAL STEP</p> <p>Displays the next menu in the calibration sequence.</p> <p>Pressing the ENTER key implements your menu selection.</p>	<p>CAL FREQ RANGE</p> <p>CENTER</p> <p>XXX.XXXXXXXXXXXGHZ</p> <p>SPAN</p> <p>XXX.XXXXXXXXXXX GHZ</p> <p>SET START/STOP</p> <p>XXX DATA POINTS</p> <p>XXX.XXXXXXXXXXXGHZ</p> <p>STEP SIZE</p> <p>MAXIMUM NUMBER OF DATA POINT(S)</p> <p>1601 MAX PTS 801 MAX PTS 401 MAX PTS 201 MAX PTS 101 MAX PTS 51 MAX PTS</p> <p>NEXT CAL STEP</p> <p>PRESS <ENTER></p> <p>TO SELECT</p>

Menu C2A, Insert Individual Frequencies

DESCRIPTION	MENU
<p>Move the cursor here and enter the next frequency for which you wish calibration data taken. If the AUTO INCR option is ON, pressing Enter automatically increments the calibration frequency by the interval in GHz that appears below the option.</p> <p>Shows the number of frequencies that you have entered and reports the value of the last frequency entered.</p> <p>Move the cursor here and press ENTER to switch the Auto-Increment mode on or off. If AUTO INCR is on, you may enter the frequency spacing.</p> <p>Calls menu C2D.</p> <p>Pressing Enter will cause actions as described above.</p>	<p>INSERT INDIVIDUAL FREQUENCIES</p> <p>INPUT A FREQ, PRESS <ENTER> TO INSERT</p> <p>NEXT FREQ. XXX.XXXXXXXXXXGHZ</p> <p>XXXX FREQS. ENTERED, LAST FREQ WAS XXX.XXXXXXXXXXGHZ</p> <p>AUTO INCR ON (OFF) XXX.XXXXXXXXXXGHZ</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu C2C, Calibration Range—Harmonic Cal for Time Domain

DESCRIPTION	MENU
<p>Move cursor here to enter the desired start frequency. This frequency also will be used as the frequency increment.</p> <p>Move the cursor here to enter the approximate desired stop frequency. The frequency will be adjusted to the nearest harmonic multiple of the start frequency.</p> <p>The program automatically indicates the number of data points and the true (harmonic) stop frequency.</p> <p>Move the cursor here and press Enter when finished.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CALIBRATION RANGE</p> <p>HARMONIC CAL FOR TIME DOMAIN</p> <p>START (STEP) XXX.XXXXXXXXXXGHZ</p> <p>APPROXIMATE STOP XXX.XXXXXXXXXX GHZ</p> <p>USING ABOVE START AND STOP WILL RESULT IN XXX DATA POINTS XXX.XXXXXXXXXX GHZ TRUE STOP FREQ</p> <p>NEXT CAL STEP</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C2B, Single Point Calibration

DESCRIPTION	MENU
<p>Move cursor here and enter the frequency for which calibration is to be done.</p> <p>Move cursor here and press ENTER when finished.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE POINT C.W. CALIBRATION C.W. FREQ XXX.XXXXXXXXXXGHZ</p> <p>NEXT CAL STEP</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C2D, Fill Frequency Ranges

DESCRIPTION	MENU
<p>This menu is used to create one or more ranges of discrete equally spaced frequency points for calibration.</p> <p>Enter the first frequency of the range.</p> <p>Enter the increment (step size) between one frequency and the next.</p> <p>Enter the number of frequency points in the range.</p> <p>Enter the stop frequency, in GHz.</p> <p>Moving the cursor here and pressing ENTER fills the range and shows the number of frequencies selected (in NUMBER OF PTS above).</p> <p>Calls menu C2A, which allows you to set the individual frequencies.</p> <p>Clears all entries displayed above.</p> <p>Calls menu C3, the next menu in the calibration sequence.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>DISCRETE FILL</p> <p>INPUT START, INCR, POINTS, THEN SELECT "FILL RANGE"</p> <p>START FREQ XXX.XXXXXXXXXX GHz</p> <p>INCREMENT XXX.XXXXXXXXXX GHz</p> <p>NUMBER OF PTS XXXX POINT(S)</p> <p>STOP FREQ XXX.XXXXXXXXXX GHz</p> <p>FILL RANGE (XXXX ENTERED)</p> <p>INDIVIDUAL FREQ INSERT</p> <p>CLEAR ALL</p> <p>FINISHED NEXT CAL STEP</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C3, Confirm Calibration Parameters

DESCRIPTION	MENU
<p>Used for Standard OSL method, coaxial line type.</p> <p>Calls Menu C4_P1 or C4A_P1, which displays the Port 1 test port connector type to be used during OSL calibration. This should agree with the connector type that both your calibration components and the test device mate with. Move cursor here and press Enter to display menu used to change connector type.</p> <p>Calls Menu C4_P2 or C4A_P2, which displays the Port 2 test port connector type to be used during OSL calibration. This should agree with the connector type that both your calibration components and the test device mate with. Move cursor here and press Enter to display menu used to change connector type.</p> <p>Calls menu C13, which lets you select the pairing (mixed or matched) for the types of reflection devices (open/short) that you will use on Ports 1 and 2 for calibration.</p> <p>Calls Menu C6, which displays type of load selected for calibration—broadband fixed or sliding. Move cursor here and press ENTER to display menu used to change load type.</p> <p>Calls Menu C20, which lets you enter throughline parameters—including offset length and loss equation coefficients.</p> <p>Calls Menu C17, which lets you choose the reference impedance value (1 $\mu\Omega$ to 1 kΩ) for the devices connected to Ports 1 and 2 for calibration. Default value is 50Ω.</p> <p>Calls menu CAL_SU2, which lets you enter calibrate Flat Test Port Power or change source power(s) and attenuator settings.</p> <p>Starts the standard (OSL) calibration sequence using coaxial standards. Pressing the Enter key implements your menu selection.</p>	<p>CONFIRM CALIBRATION PARAMETERS</p> <p>PORT 1 CONN XXXXXXXXXX</p> <p>PORT 2 CONN XXXXXXXXXX</p> <p>REFLECTION PAIRING XXXXXX</p> <p>LOAD TYPE XXXXXXXXXX</p> <p>THROUGH LINE PARAMETERS REFERENCE IMPEDANCE</p> <p>TEST SIGNALS</p> <p>START CAL PRESS <ENTER> TO SELECT OR CHANGE</p>

Menu C3A, Confirm Calibration Parameters

DESCRIPTION	MENU
<p>Used for Offset-Short method, coaxial line type.</p> <p>Calls Menu C4, which lets you change the offset lengths of the shorts used for coaxial calibration.</p> <p>Calls Menu C6, which displays type of load selected for calibration—broadband fixed or sliding. Move cursor here and press Enter to display menu used to change load type.</p> <p>Calls Menu C20, which lets you enter throughline parameters—including offset length and loss equation coefficients.</p> <p>Calls Menu C15, which lets you choose the reference impedance value (1 $\mu\Omega$ to 1 MΩ) for the devices connected to Ports 1 and 2 for calibration. Default value is 50Ω.</p> <p>Calls menu CAL_SU2, which lets you enter calibrate Flat Test Port Power or change source power(s) and attenuator settings.</p> <p>Starts the offset-short calibration sequence using coaxial standards. Pressing the Enter key implements your menu selection.</p>	<p>CONFIRM CALIBRATION PARAMETERS</p> <p>OFFSET LENGTHS OF SHORTS</p> <p>LOAD TYPE XXXXXXXXXX</p> <p>THROUGH LINE PARAMETERS</p> <p>REFERENCE IMPEDANCE</p> <p>TEST SIGNALS</p> <p>START CAL</p> <p>PRESS <ENTER> TO SELECT OR CHANGE</p>

Menu C3B, Confirm Calibration Parameters

DESCRIPTION	MENU
<p>Used for Offset-Short method, waveguide line type.</p> <p>Calls Menu C6, which displays type of load selected for calibration—broadband fixed or sliding.</p> <p>Calls Menu C20, which lets you enter throughline parameters—including offset length and loss equation coefficients.</p> <p>Calls Menu C15, which lets you enter waveguide parameters.</p> <p>Calls menu CAL_SU2, which lets you calibrate Flat Test Port Power or change source power(s) and attenuator settings.</p> <p>Starts the offset-short calibration sequence using waveguide standards.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CONFIRM CALIBRATION PARAMETERS</p> <p>LOAD TYPE XXXXXXXXXX</p> <p>THROUGH LINE PARAMETERS</p> <p>WAVEGUIDE PARAMETERS XXXXXXXXXX</p> <p>TEST SIGNALS</p> <p>START CAL</p> <p>PRESS <ENTER> TO SELECT OR CHANGE</p>

Menu C3C, Confirm Calibration Parameters

DESCRIPTION	MENU
Used for Offset-Short method, microstrip line type.	CONFIRM CALIBRATION PARAMETERS
Calls Menu C14, which lets you change offset lengths of shorts used for microstrip calibration.	OFFSET LENGTHS OF SHORTS
Calls Menu C6A, which lets you select an impedance type and/or enter an impedance value.	LOAD IMPEDANCES
Calls Menu C20, which lets you enter throughline parameters—including offset length and loss equation coefficients.	THROUGH LINE PARAMETERS
Calls Menu C16, which lets you change microstrip parameters.	MICROSTRIP PARAMETERS XXXXXXXXXXXX
Calls menu CAL_SU2, which lets you enter calibrate Flat Test Port Power or change source power(s) and attenuator settings.	TEST SIGNALS
Starts the offset-short calibration sequence using microstrip standards. Pressing the Enter key implements your menu selection.	START CAL PRESS <ENTER> TO SELECT OR CHANGE

Menu C3D, Confirm Calibration Parameters

DESCRIPTION	MENU
<p>Used for Standard OSL method, microstrip line type.</p>	<p>CONFIRM CALIBRATION PARAMETERS</p>
<p>Calls menu C12_P1, which is used to define the capacitive coefficients of the Open and offset length of the Short for Port 1.</p>	<p>PORT 1 OPEN/SHORT</p>
<p>Calls menu C12_P2, which is used to define the capacitive coefficients of the Open and offset length of the Short for Port 2.</p>	<p>PORT 2 OPEN/SHORT</p>
<p>Calls menu C13, which lets you select the pairing (mixed or matched) for the types of reflection devices (open/short) that you will use on Ports 1 and 2 for calibration.</p>	<p>REFLECTION PAIRING</p>
<p>Calls Menu C6A, which lets you select an impedance type and/or enter an impedance value.</p>	<p>LOAD IMPEDANCE XXXXXX</p>
<p>Calls Menu C20, which lets you enter throughline parameters—including offset length and loss equation coefficients.</p>	<p>THROUGH LINE PARAMETERS XXXXXXXXXXXX</p>
<p>Calls Menu C16, which lets you change microstrip parameters.</p>	<p>MICROSTRIP PARAMETERS XXXXXXXXXXXX</p>
<p>Calls menu CAL_SU2, which lets you enter calibrate Flat Test Port Power or change source power(s) and attenuator settings.</p>	<p>TEST SIGNALS</p>
<p>Starts the standard calibration sequence using microstrip standards.</p>	<p>START CAL</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>PRESS <ENTER> TO SELECT OR CHANGE</p>

Menu C3E, Confirm Calibration Parameters

DESCRIPTION	MENU
<p>Used for LRL/LRM method, coaxial line type.</p> <p>Calls Menu C18, which lets you change LRL/LRM parameters.</p> <p>Calls Menu C17, which lets you change the reference impedance of the coaxial line standard to other than 50 ohms (default).</p> <p>Calls menu CAL_SU2, which lets you enter calibrate Flat Test Port Power or change source power(s) and attenuator settings.</p> <p>Starts the LRL/LRM calibration sequence using coaxial standards.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CONFIRM CALIBRATION PARAMETERS</p> <p>LRL/LRM PARAMETERS</p> <p>REFERENCE IMPEDANCE</p> <p>TEST SIGNALS</p> <p>START CAL</p> <p>PRESS <ENTER> TO SELECT OR CHANGE</p>

Menu C3F, Confirm Calibration Parameters

DESCRIPTION	MENU
<p>Used for LRL/RM method, waveguide line type.</p> <p>Calls Menu C18, which lets you change LRL/RM parameters.</p> <p>Calls Menu 15B, which lets you enter a waveguide cutoff frequency.</p> <p>Calls menu CAL_SU2, which lets you enter calibrate Flat Test Port Power or change source power(s) and attenuator settings.</p> <p>Starts the LRL/RM calibration sequence using waveguide standards.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CONFIRM CALIBRATION PARAMETERS</p> <p>LRL/RM PARAMETERS</p> <p>WAVEGUIDE CUTOFF FREQ</p> <p>TEST SIGNALS</p> <p>START CAL</p> <p>PRESS <ENTER> TO SELECT OR CHANGE</p>

Menu C3G, Confirm Calibration Parameters

DESCRIPTION	MENU
<p>Used for LRL/RM method, microstrip line type.</p> <p>Calls Menu C18, which lets you change LRL/RM parameters.</p> <p>Calls Menu C16, which lets you change microstrip parameters.</p> <p>Calls menu GAL_SU2, which lets you enter calibrate Flat Test Port Power or change source power(s) and attenuator settings.</p> <p>Starts the LRL/RM calibration sequence using microstrip standards.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CONFIRM CALIBRATION PARAMETERS</p> <p>LRL/RM PARAMETERS</p> <p>MICROSTRIP PARAMETERS USER DEFINED</p> <p>TEST SIGNALS</p> <p>START CAL</p> <p>PRESS <ENTER> TO SELECT OR CHANGE</p>

Menu C4_P1/C4_P2, Select Connector Type

DESCRIPTION	MENU
<p>Applies the four capacitance-coefficient values to the Open and offset length to the Short. These values are needed to correct for an SMA connector being installed on the test device (male or female).</p> <p>Same as above, except for K connector.</p> <p>Same as above, except for TYPE N connector.</p> <p>Same as above, except for GPC-3.5 connector.</p> <p>Same as above, except for GPC-7 connector.</p> <p>Calls menu C12, which lets you specify the connector coefficients.</p> <p>Calls additional connector types to screen.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT PORT X CONNECTOR TYPE</p> <p>SMA (M)</p> <p>SMA (F)</p> <p>K-CONN (M)</p> <p>K-CONN (F)</p> <p>TYPE N (M)</p> <p>TYPE N (F)</p> <p>GPC-3.5 (M)</p> <p>GPC-3.5 (F)</p> <p>GPC-7</p> <p>USER DEFINED</p> <p>MORE</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C4A_P1/C4A_P2, Select Connector Type

DESCRIPTION	MENU
<p>Applies the four capacitance-coefficient values to the Open and offset length to the Short. These values are needed to correct for an SMA connector being installed on the test device (male or female).</p> <p>Same as above, except for TNC connector.</p> <p>Same as above, except for 2.4 mm connector.</p> <p>Calls Menu C12, which lets you specify the connector coefficients.</p> <p>Calls additional connector types to screen.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT PORT X CONNECTOR TYPE</p> <p>V-CONN (M)</p> <p>V-CONN (F)</p> <p>TNC (M)</p> <p>TNC (F)</p> <p>2.4 mm (M)</p> <p>2.4 mm (F)</p> <p>USER DEFINED</p> <p>MORE</p> <p>PRESS <ENTER> WHEN COMPLETE</p>

Menu C5, Select Calibration Type

MENU	DESCRIPTION
SELECT CALIBRATION TYPE FULL 12-TERM 1 PATH 2 PORT TRANSMISSION FREQUENCY RESPONSE REFLECTION ONLY PRESS <ENTER> TO SELECT	Select calibration using all 12 error terms EDF, ESF, ERF, ETF, ELF, (EXF), EDR, ESR, ERR, ETR, FLR, (EXR). Calls Menu C5A, which lets select a correction for forward- or reverse-direction error terms. Calls Menu C5B, which lets select a correction for frequency response error terms. Calls Menu C5C, which lets select a correction for reflection-only error terms. Pressing the Enter key implements your menu selection.

Menu C5B, Select Transmission Freq Response Calibration Type

DESCRIPTION	MENU
<p>For the calibration-correction of the forward transmission frequency-response error term, ETF, (EXF).</p> <p>For the calibration-correction of the reverse transmission-frequency-response error term, ETR, (EXR).</p> <p>For the calibration-correction of the forward and reverse transmission-frequency-response error terms ETF, ETR, (EXF, EXR).</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT TRANSMISSION FREQ RESPONSE CALIBRATION TYPE FORWARD PATH (S21) REVERSE PATH (S12) BOTH PATHS (S21, S12) PRESS <ENTER> TO SELECT</p>

Menu C5A, Select 1 Path 2 Port Calibration Type

DESCRIPTION	MENU
<p>For the calibration-correction of the forward transmission and reflection error term, ETF, EDF, ESF, ERF, (EXF).</p> <p>For the calibration-correction of the reverse transmission and reflection error term, EDR, ESR, ERR, ETR, (EXR).</p> <p>Pressing the Enter key implements your selection.</p>	<p>SELECT 1 PATH 2 PORT CALIBRATION TYPE FORWARD PATH (S11, S21) REVERSE PATH (S12, S22) PRESS <ENTER> TO SELECT</p>

Menu C5D, Select Use of Isolation

MENU	DESCRIPTION
SELECT USE OF ISOLATION IN CALIBRATION INCLUDE ISOLATION (STANDARD) EXCLUDE ISOLATION PRESS <ENTER> TO SELECT	Includes isolation term(s). Excludes isolation term(s). Pressing the Enter key implements your menu selection.

Menu C5C, Select Reflection Only Calibration Type

MENU	DESCRIPTION
SELECT REFLECTION ONLY CALIBRATION TYPE PORT 1 ONLY (S11) PORT 2 ONLY (S22) BOTH PORTS (S11, S22) PRESS <ENTER> TO SELECT	For the calibration-correction of the forward reflection-only error terms EDF, ESF, ERF. For the calibration-correction of the reverse reflection-only error terms EDR, ESR, ERR. For the calibration-correction of the forward and reverse reflection-only error terms EDF, ESF, ERF, EDR, ESR, ERR. Pressing the Enter key implements your menu selection.

Menu C6A, Enter Broadband Load Impedance

DESCRIPTION	MENU
<p>Enter the impedance of the load.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>ENTER BROADBAND LOAD IMPEDANCE</p> <p>BROADBAND LOAD IMPEDANCE XX.XXX Ω</p> <p>PRESS <ENTER> WHEN COMPLETE</p>

Menu C6, Select Load Type

DESCRIPTION	MENU
<p>Selects calibration based on the broadband load being used, then calls menu C6A.</p> <p>Selects calibration based on the sliding load being used. If your low-end frequency is below 2 GHz (4 GHz for V Connector), a fixed broadband load is also required.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT TYPE OF LOAD</p> <p>BROADBAND FIXED LOAD</p> <p>SLIDING LOAD (MAY ALSO REQUIRE BROADBAND FIXED LOAD)</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C8, Slide Load to Position X

DESCRIPTION	MENU
<p>Slide the load to the next position, then press the Enter key. Moving the slide to six different positions provides sufficient data for the program to accurately calculate the effective directivity of the system.</p> <p>Pressing the Enter key begins the measurement.</p>	<p>CALIBRATION SEQUENCE SLIDE LOAD TO POSITION X PRESS <ENTER> TO MEASURE DEVICE (S)</p>

Menu C7-Series, Begin Calibration Sequence

DESCRIPTION	MENU
<p>Connect the required component to Port 1.</p> <p>Connect the required component to Port 2.</p> <p>Pressing the Enter key sequentially measures the devices connected to Ports 1 and 2, beginning with Port 1.</p> <p>Pressing the 1 key, on the keypad, measures the device connected to Port 1.</p> <p>Pressing the 2 key, on the keypad, measures the device connected to Port 2.</p>	<p>CALIBRATION SEQUENCE CONNECT CALIBRATION DEVICE(S) PORT 1: XXXXXXXXXXXXXX PORT 2: XXXXXXXXXXXXXX PRESS <ENTER> TO MEASURE DEVICE(S) PRESS <1> FOR PORT 1 DEVICE PRESS <2> FOR PORT 2 DEVICE</p>

Menu C9A, Connect Device 1, Line

DESCRIPTION	MENU
<p>Prompts you to connect reference line 1 between test ports.</p> <p>Pressing the Enter key begins the measurement.</p>	<p>CALIBRATION SEQUENCE CONNECT DEVICE 1 LINE 1 (REF) XXXXXX BETWEEN TEST PORTS PRESS <ENTER> TO MEASURE DEVICE(S)</p>

Menu C9, Connect Thruhline

DESCRIPTION	MENU
<p>Connect Ports 1 and 2 together using the Thruhline standard (zero or non-zero length).</p> <p>Pressing the Enter key begins the measurement.</p>	<p>CALIBRATION SEQUENCE CONNECT THROUGHLINE XXXXXX BETWEEN TEST PORTS PRESS <ENTER> TO MEASURE DEVICE(S)</p>

Menu C9C, Connect Device 2, Line

DESCRIPTION	MENU
<p>Prompts you to connect the second line standard between the test ports.</p> <p>Pressing the Enter key begins the measurement.</p>	<p>CALIBRATION SEQUENCE CONNECT DEVICE 2 LINE XXXXX BETWEEN TEST PORTS PRESS <ENTER> TO MEASURE DEVICE(S)</p>

Menu C9B, Connect Device 2, Line/Lowband

DESCRIPTION	MENU
<p>Connect device 2 between the test ports. This will be a LINE for LRL measurements or LOWBAND MATCHES for LRM measurements.</p> <p>Pressing the Enter key begins the measurement.</p>	<p>CALIBRATION SEQUENCE CONNECT DEVICE 2 LINE/ LOWBAND MATCHES BETWEEN TEST PORTS PRESS <ENTER> TO MEASURE DEVICE(S)</p>

Menu C11, Begin Calibration

DESCRIPTION	MENU
<p>Keep existing calibration data</p>	<p>BEGIN CALIBRATION</p>
<p>Repeats the previous calibration.</p>	<p>KEEP EXISTING CAL DATA REPEAT</p>
<p>Displays the calibration method that you have selected—standard, offset short or LRL/LRM.</p>	<p>PREVIOUS CAL CAL METHOD XXXXXXXXXX</p>
<p>Indicates type of transmission line currently selected, e. g. coaxial, waveguide, microstrip.</p>	<p>TRANSMISSION LINE TYPE: XXXXXXXXXX</p>
<p>Calls menu C11A, which allows you to change calibration method and transmission line type.</p>	<p>CHANGE CAL METHOD AND LINE TYPE</p>
<p>Selects the next calibration step.</p>	<p>NEXT CAL STEP</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>PRESS <ENTER> TO SELECT</p>

Menu C1A, Select Calibration Method

DESCRIPTION	MENU
<p>Select next calibration step. Must move cursor to here after making below selections. Pressing the Enter key then moves you to the next step.</p>	<p>CHANGE CAL METHOD AND LINE TYPE NEXT CAL STEP</p>
<p>This option and the ones below allow you to select the method (procedure) to be used to calibrate. This method is independent of the calibration type, which may be 12 term, reflection only etc.</p> <p>Selects offset-short method.</p> <p>Selects LRL or LRM method</p>	<p>CAL METHOD STANDARD (NOT USED FOR WAVEGUIDE) OFFSET SHORT LRL/LRM</p>
<p>Selects coaxial cable as the transmission line type.</p> <p>Selects waveguide as the transmission line type.</p> <p>Selects microstrip as the transmission line type.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>TRANSMISSION LINE TYPE COAXIAL WAVEGUIDE MICROSTRIP PRESS <ENTER> TO SELECT</p>

DESCRIPTION	MENU
<p>Enter the capacitance-coefficient values needed to correct for your Open device. The capacitive phase shift of the Open is characterized by the equation: $C_{open} = C_0 + (C_1 \times f) + (C_2 \times f^2) + (C_3 \times f^3)$</p> <p>Enter the term 1 coefficient value ($\times 10^{-15}$ F).</p> <p>Enter the term 2 coefficient value ($\times 10^{-27}$ F/Hz).</p> <p>Enter the term 3 coefficient value ($\times 10^{-36}$ F/Hz²).</p> <p>Enter the term 4 coefficient value ($\times 10^{-45}$ F/Hz³).</p> <p>Select to enter and display offset length of Open.</p> <p>Pressing the Enter key calls C12A_P1/C12A_P2.</p>	<p>PORT X OPEN DEVICE</p> <p>ENTER THE CAPACITANCE COEFFICIENTS</p> <p>TERM 1-C0 ± XX.XXe- 15</p> <p>TERM 2-C1 ± XXX.XXe - 27</p> <p>TERM 3-C2 ±XXX.XXe - 36</p> <p>TERM 4-C3 ±XXX.XXe - 45</p> <p>ENTER THE OFFSET LENGTH</p> <p>OFFSET LENGTH ±XX.XXXX mm</p> <p>PRESS <ENTER> WHEN COMPLETE</p>

Menu C12_P1/C12_P2, Enter the Capacitance Coefficients for Open Devices

Menu C13, Set Reflection Pairing Menu

DESCRIPTION	MENU
<p>Selects different reflection devices (open/short or short/open) to be connected to Ports 1 and 2 for the calibration sequencing.</p> <p>Selects the same type of reflection device (open/open or short/short) to be connected to Ports 1 and 2 for the calibration sequencing.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SET REFLECTION PAIRING MIXED (OPEN-SHORT SHORT-OPEN) MATCHED (OPEN-OPEN SHORT-SHORT) PRESS <ENTER> TO SELECT</p>

Menu C12A_P1/C12A_P2, Enter the Offset Length

DESCRIPTION	MENU
<p>Select to enter the length that the Short is offset from the reference plane.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>PORT X SHORT DEVICE ENTER THE OFFSET LENGTH OFFSET LENGTH ± XX.XXXX mm PRESS <ENTER> WHEN COMPLETE</p>

Menu C14, Enter Offset Lengths (Shorts)

DESCRIPTION	MENU
Enter the length that Short 1 is offset from the reference plane.	ENTER OFFSET LENGTHS OF SHORTS PORT 1 SHORTS SHORT 1 XX.XXXX mm
Enter the length that Short 2 is offset from the reference plane.	SHORT 2 XX.XXXX mm PORT 2 SHORTS
Enter the length that Short 1 is offset from the reference plane.	SHORT 1 XX.XXXX mm
Enter the length that Short 2 is offset from the reference plane.	SHORT 2 XX.XXXX mm IF USING ONLY TWO SHORTS, PORT 2 OFFSETS SHOULD EQUAL PORT 1 OFFSETS PRESS <ENTER> WHEN COMPLETE
Pressing the Enter key implements your menu selection.	

Menu C15, Select Waveguide Kit to Use

DESCRIPTION	MENU
<p>The lines below indicate the characteristics of the installed waveguide calibration kit, if applicable.</p> <p>Displays the type of waveguide used.</p> <p>Displays the cutoff frequency of the waveguide.</p> <p>Displays the offset length of the first calibration short.</p> <p>Displays the offset length of the second calibration short.</p> <p>Move the cursor to this line and press Enter to use the displayed kit.</p> <p>Calls menu C15A, which lets you modify the parameters.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT WAVEGUIDE KIT TO USE</p> <p>-INSTALLED KIT-</p> <p>IDENTIFIER XXXX</p> <p>CUTOFF FREQ: XXXX.XXXXXXXX GHz</p> <p>SHORT 1 XX.XXXXXmm</p> <p>SHORT 2 XX.XXXXXmm</p> <p>USE INSTALLED WAVEGUIDE KIT</p> <p>USER DEFINED</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C15B, Enter Waveguide Parameters

DESCRIPTION	MENU
<p>Enter waveguide cutoff frequency.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>ENTER WAVEGUIDE CUTOFF FREQUENCY</p> <p>WAVEGUIDE CUTOFF FREQ XXX.XXXXXXXXXX GHZ</p> <p>PRESS <ENTER> WHEN COMPLETE</p>

Menu C15A, Enter Waveguide Parameters

DESCRIPTION	MENU
<p>Move cursor to this line then press Enter to bring up menu that allows you to enter waveguide cutoff frequency.</p> <p>Move the cursor to this line and enter the offset length of Short 1.</p> <p>Move the cursor to this line and enter the offset length of Short 2.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>ENTER WAVEGUIDE PARAMETERS</p> <p>WAVEGUIDE CUTOFF FREQ XXX.XXXXXXXXXX GHZ</p> <p>OFFSET LENGTH OF SHORT 1 XXXXX mm</p> <p>OFFSET LENGTH OF SHORT 2 XXXXX mm</p> <p>PRESS <ENTER> WHEN COMPLETE</p>

Menu C16A, Enter Microstrip Parameters

DESCRIPTION	MENU
<p>Move the cursor to this line and enter the width of the microstrip you are using.</p> <p>Move the cursor to this line and enter the thickness of the substrate you are using.</p> <p>Move the cursor to this line and enter the characteristic impedance of the microstrip.</p> <p>Move the cursor to this line and enter the relative dielectric constant of the substrate you are using.</p> <p>Move the cursor to this line and enter the effective dielectric constant of the microstrip. A recommended value will also be displayed.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>ENTER MICROSTRIP PARAMETERS</p> <p>WIDTH OF STRIP XX.XXXX mm</p> <p>THICKNESS OF SUBSTRATE XXXX.XXXX mm</p> <p>Z₀ XXX.XXX Ω</p> <p>SUBSTRATE DIELECTRIC XX.XX</p> <p>EFFECTIVE DIELECTRIC XX.XX (RECOMMENDED 1.00)</p> <p>PRESS <ENTER> WHEN COMPLETE</p>

Menu C16, Select Microstrip Parameters

DESCRIPTION	MENU
<p>Selects parameters for 10 mil UTF kit.</p> <p>Selects parameters for 15 mil UTF kit.</p> <p>Selects parameters for 25 mil UTF kit.</p> <p>Calls menu C16A, which lets you modify the parameters.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT MICROSTRIP KIT TO USE</p> <p>10 MIL KIT</p> <p>15 MIL KIT</p> <p>25 MIL KIT</p> <p>USER DEFINED</p> <p>PRESS <ENTER> TO SELECT</p>

Menu C18, Change LRL/LRM Parameters

DESCRIPTION	MENU
<p>Selects next calibration step. Must move cursor to here after making below selections. Pressing the Enter key then moves you to the next step. Calls menu C18A for one band or C18B for two bands.</p> <p>Selects a one-band LRL or LRM calibration.</p> <p>Selects a two-band LRL or LRM calibration (that is, a three-line LRL or concatenated LRL and LRM calibrations).</p> <p>LOCATION OF REFERENCE PLANES</p> <p>MIDDLE OF LINE 1 (REF)</p> <p>ENDS OF LINE 1 (REF)</p> <p>TO SELECT</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CHANGE LRL/LRM PARAMETERS</p> <p>NEXT CAL STEP</p> <p>NUMBER OF BANDS USED</p> <p>ONE BAND</p> <p>TWO BANDS</p> <p>LOCATION OF REFERENCE PLANES</p> <p>MIDDLE OF LINE 1 (REF)</p> <p>ENDS OF LINE 1 (REF)</p> <p>PRESS <ENTER></p>

Menu C17, Enter Line Impedance

DESCRIPTION	MENU
<p>Enter the reference impedance (Z_0) of the coaxial reference line standard.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>ENTER REFERENCE IMPEDANCE</p> <p>REFERENCE IMPEDANCE</p> <p>IMPEDANCE</p> <p>XXX.XXXΩ</p> <p>PRESS <ENTER> WHEN COMPLETE</p>

Menu C18A, Change LRL/RM Parameters

DESCRIPTION	MENU
<p>Selects next calibration step. Must move cursor to here after making below selections. Pressing the Enter key then moves you to the next step. Calls menu C19.</p> <p>Enter length of line 1.</p> <p>Select device 2—LINE or MATCH; if line is selected, enter length.</p> <p>Press Enter to select. If DEVICE 2 is chosen, pressing the Enter key toggles between LINE and MATCH.</p>	<p>CHANGE LRL/RM PARAMETERS NEXT CAL STEP CHARACTERIZE CAL DEVICES DEVICE 1 LINE 1 (REF) X.XXXX mm DEVICE 2 LINE /MATCH X.XXXX mm/FULLBAND PRESS <ENTER> TO SELECT OR SWITCH</p>

Menu C18B, Change LRL/RM Parameters—Two Band Calibration

DESCRIPTION	MENU
<p>Selects next calibration step. Must move cursor to here after making below selections. Pressing the Enter key then moves you to the next step. Calls menu C19.</p> <p>Enter length of line 1.</p> <p>Press Enter to toggle between LINE and MATCH. If LINE is selected, enter line length. If match is selected, LOWBAND is displayed. This indicates that device 2 is the lowband match.</p> <p>Press Enter to toggle between LINE and MATCH. If LINE is selected, enter line length. If match is selected, HIGHBAND is displayed. This indicates that device 3 is the high band match.</p> <p>Enter breakpoint frequency: end of band 1, beginning of band 2.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CHANGE LRL/RM PARAMETERS</p> <p>NEXT CAL STEP</p> <p>CHARACTERIZE CAL DEVICES</p> <p>DEVICE 1 LINE 1 (REF) XX.XXXX</p> <p>DEVICE 2 LINE/MATCH XX.XXXX/LOWBAND</p> <p>DEVICE 3 LINE/MATCH XX.XXXX/HIGHBAND</p> <p>FREQ AFTER WHICH THE USE OF DEVICE 2 AND DEVICE 3 IS EXCHANGED</p> <p>BREAKPOINT XXX.XXXXXXXXXXXGHZ</p> <p>PRESS <ENTER> TO SELECT OR SWITCH</p>

Menu C19, Change LRL/RM Parameters

DESCRIPTION	MENU
<p>Moves to the next calibration step. Must move cursor to here after making below selections. Pressing the Enter key then moves you to the next step.</p> <p>Enter the offset length of the reflective device.</p> <p>Specifies the reflection to have an impedance value greater than the reference impedance (Z_0). This is typically an open device.</p> <p>Selects the reflection to have an impedance value less than the reference impedance (Z_0). This is typically a short device.</p> <p>Pressing the Enter key implements the selection.</p>	<p>CHANGE LRL/RM PARAMETERS NEXT CAL STEP OFFSET LENGTH OF REFLECTIVE DEVICE OFFSET LENGTH X.XXXX mm TYPE OF REFLECTION GREATER THAN Z_0 LESS THAN Z_0 PRESS <ENTER> TO SELECT</p>

DESCRIPTION	MENU
<p>Enter offset length of through-line device.</p> <p>Enter the impedance of the through-line device.</p> <p>Pressing the Enter key brings the next calibration menu.</p>	<p>ENTER THROUGH LINE PARAMETERS OFFSET LENGTH X.XXXX mm THROUGHLINE IMPEDANCE X.XXXX Ω PRESS <ENTER> WHEN COMPLETE</p>

Menu C20, Change Through Parameters

DESCRIPTION	MENU
<p>Pressing the SAVE/RECALL MENU Key displays menu SR, which lets you save your calibration data onto a disk or recall previously saved calibration data from a disk. While this menu provides a convenient point at which to save the calibration data, it is not the only point allowed. You can use the SAVE/RECALL MENU key at any point in the measurement program.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CALIBRATION SEQUENCE COMPLETED PRESS <SAVE/RECALL> TO STORE CAL DATA ON DISK OR PRESS <ENTER> TO PROCEED</p>

Menu Cal Completed

Menu Cal_EM, Enhancement Menu for Calibration

MENU	DESCRIPTION
<p>DATA ENHANCEMENT AVERAGING XXXX MEAS. PER POINT PRESS <ENTER> TO RESUME CAL</p>	<p>Averages the measured data over time, as follows: 1. The sweep stops at the first frequency point and takes a number of readings, based on the selected number of points. 2. The program averages the readings and writes the average value for that frequency point in the displayed graph. 3. The sweep then advances to the next sequential frequency point and repeats the process. Pressing the Enter key implements your menu selection and returns you to the calibration setup or sequence.</p>

Menu Cal_Applied

MENU	DESCRIPTION
<p>APPLY FULL 12-TERM (S11, S21 S22, S12) APPLY ON (OFF) CALIBRATION TUNE MODE ON (OFF) NO. OF FWD (REV) SWEEPS BETWEEN REV (FWD) SWEEPS XXXXX SWEEPS (XXXXX REMAINING) PRESS <APPLY CAL> TO TURN ON/OFF PRESS <ENTER> TO TURN ON/OFF</p>	<p>Reflects the type of calibration presently stored in internal memory. Turns calibration on or off. For applied Full 12-Term calibration only. When turned off, the ratio of forward to reverse sweeps is set to the normal 1:1. When turned on, you can set the ratio of forward sweeps to reverse sweep from 1:1 to 10,000:1 (below). Lets you enter a value for the number of forward (or reverse) sweeps. Alternatively, this option displays the number of forward sweep (or reverse) remaining before a reverse sweep will occur. Press the Apply Cal key to apply the stored calibration. Press the Enter key to turn selected mode on/off.</p>

Menu CM, Select Display Mode

DESCRIPTION	MENU
<p>Selects a single channel for display. You select the type of display in menu GT1 or GT2.</p> <p>Selects Channels 1 and 3 for display. You select the type of display in menu GT1 or GT2.</p> <p>Lets you simultaneously view the Channel 1 data superimposed over the Channel 3 data on a single display. Channel 1 trace displays in red and Channel 3 in yellow.</p> <p>Selects Channels 2 and 4 for display. You select the type of display in menu GT1 or GT2.</p> <p>Lets you simultaneously view the Channel 2 data superimposed over the Channel 4 data on a single display. Channel 2 trace displays in red and Channel 4 in yellow.</p> <p>Selects all four channels for display. You select the type of display in menu GT1 or GT2.</p> <p>Pressing the Enter key implements your menu selection. The menu remains on the screen until another menu is selected for display or until the CLEAR/RET LOC key is pressed.</p>	<p>SELECT DISPLAY MODE</p> <p>SINGLE CHANNEL</p> <p>DUAL CHANNELS 1 & 3</p> <p>OVERLAY DUAL CHANNELS 1 & 3</p> <p>DUAL CHANNELS 2 & 4</p> <p>OVERLAY DUAL CHANNELS 2 & 4</p> <p>ALL FOUR CHANNELS</p> <p>PRESS <ENTER> TO SELECT</p>

Menu DF1, Discrete Fill

DESCRIPTION	MENU
<p>This menu is used to create one or more ranges of discrete equally spaced frequency points.</p>	<p>DISCRETE FILL</p>
<p>Enter the first frequency of the range.</p>	<p>INPUT START, INCR, POINTS, THEN SELECT "FILL RANGE"</p>
<p>Enter the increment (step size) between one frequency and the next.</p>	<p>START FREQ XXX.XXXXXXXXXX GHZ</p>
<p>Enter the number of frequency points in the range.</p>	<p>INCREMENT XXX.XXXXXXXXXX GHZ</p>
<p>Enter the stop frequency, in GHz.</p>	<p>NUMBER OF PTS XXXX POINT(S)</p>
<p>Moving the cursor here and pressing Enter fills the range and shows the number of frequencies selected (in NUM OF PTS above).</p>	<p>STOP FREQ XXX.XXXXXXXXXX GHZ</p>
<p>Calls menu DF2, which allows you to set the individual frequencies.</p>	<p>FILL RANGE (XXXX ENTERED)</p>
<p>Clears all entries displayed above.</p>	<p>INDIVIDUAL FREQ INSERT</p>
<p>Closes this menu.</p>	<p>CLEAR ALL</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>FINISHED RETURN TO SWP PRESS <ENTER> TO SELECT</p>

Menu DF2, Insert Individual Frequencies

DESCRIPTION	MENU
<p>Enter the start frequency, increment frequency, and number of points; then select the FILL RANGE menu option, below.</p> <p>Enter the sweep start frequency, in GHz.</p> <p>Enter the frequency, in GHz, by which you want to increment the start frequency.</p> <p>Enter the number of points.</p> <p>Enter the stop frequency, in GHz.</p> <p>Press the Enter key to implement your menu selection or to turn a selection on or off.</p>	<p>INSERT INDIVIDUAL FREQUENCIES</p> <p>INPUT A FREQ, PRESS <ENTER> TO INSERT</p> <p>NEXT FREQ XXX.XXXXXXXXXX GHz</p> <p>XXXX FREQS ENTERED LAST FREQ WAS XXX.XXXXXXXXXX GHz</p> <p>AUTO INCR ON (OFF) XXX.XXXXXXXXXX GHz</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> THEN SELECT OR TURN ON/OFF</p>

Menu DFLT, Default Program Selected

DESCRIPTION	MENU
<p>Pressing the DEFAULT PROGRAM key a second time resets the 372XXA to its default settings. Press the DEFAULT PROGRAM key, the "0" key, then the DEFAULT PROGRAM key again clears all internal memories. This keying method can be used to clear memories of data used for classified operations.</p> <p>Pressing the CLEAR key implements your menu selection.</p>	<p>WARNING</p> <p>DEFAULT PROGRAM SELECTED</p> <p>CONTINUING</p> <p>WILL ERASE CURRENT SETUP AND CALIBRATION</p> <p>PRESS <DEFAULT PROGRAM> TO CONFIRM</p> <p>PRESS <CLEAR> TO ABORT</p>

DESCRIPTION	MENU
<p>Starts a self test of the 372XXA.</p> <p>Calls Menu DG2, which gives you options for using the Service Log.</p> <p>Displays the fitted options.</p> <p>Calls Menu DG3, which provides tests for peripherals such as the CRT, front panel, external keyboard, printer and GPIB interfaces.</p> <p>Calls Menu DG4, which provides options for troubleshooting the 372XXA hardware. This menu is intended for use by a qualified service technician. Refer to the Model 372XXA Maintenance Manual for additional information.</p> <p>Calls Menu DG5, which provides for invoking calibration routines for use by a qualified service technician. Refer to the Model 372XXA Maintenance Manual for additional information.</p>	<p>DIAGNOSTICS</p> <p>START SELF TEST</p> <p>READ SERVICE LOG</p> <p>INSTALLED OPTIONS</p> <p>PERIPHERAL TESTS</p> <p>TROUBLESHOOTING (FOR SERVICE USE ONLY)</p> <p>HW CALIBRATIONS (FOR SERVICE USE ONLY)</p>

Menu DG1, Diagnostics 1

DESCRIPTION	MENU
<p>Displays the service log, which provides operational status information. The service log is a useful aid for troubleshooting a malfunctioning unit.</p> <p>Sends the service log to a printer.</p> <p>Saves the service log to a floppy disk file service log.</p> <p>Clears the service log error list.</p> <p>Returns to Menu DG1.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SERVICE LOG</p> <p>DISPLAY LOG</p> <p>PRINT LOG</p> <p>SAVE LOG TO FLOPPY DISK</p> <p>CLEAR LOG</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT</p>

Menu DG2, Troubleshooting

Menu DSK1_FD, Floppy Disk Utilities

MENU	DESCRIPTION
FLOPPY DISK UTILITIES DISPLAY DIRECTORY DELETE FILES COPY FILES TO HARD DISK FORMAT FLOPPY DISK HARD DISK UTILITIES PRESS <ENTER> TO SELECT	Directory displays in the screen's data area. Press <1> for previous page, <2> for next page, <0> for first page, and <3> for last page. Calls DSK6, which lets you delete data files. Calls DSK8, which lets you copy files to the hard disk. Formats the floppy disk. Calls DSK1-HD, which provides hard disk utilities. Pressing Enter implements your menu selection. You will be returned to the previous menu when your selection is made.

Menu DG3, Diagnostics 3

MENU	DESCRIPTION
PERIPHERAL TESTS CRT FRONT PANEL EXTERNAL KEYBOARD PRINTER INTERFACE GPIB INTERFACE PREVIOUS MENU PRESS <ENTER> TO SELECT	Provides a graphic display for evaluating screen colors and linearity. Provides for testing the front panel keys. Provides for testing the external keyboard connected to the keyboard connector on the front panel Provides for testing the printer interface. Provides for testing the GPIB interface. Returns to Menu DG1. Pressing the Enter key implements your menu selection.

Menu DSK1_HD, Hard Disk Utilities

DESCRIPTION	MENU
<p>Directory displays in the screen's data area. Press <1> for previous page, <2> for next page, <0> for first page, and <3> for last page. Calls DSK6, which lets you delete data files.</p> <p>Calls DSK8, which lets you copy files to the floppy disk.</p> <p>Formats the hard disk.</p> <p>Calls DSK1-FD, which provides floppy disk utilities.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>HARD DISK UTILITIES</p> <p>DISPLAY DIRECTORY</p> <p>DELETE FILES</p> <p>COPY FILES TO FLOPPY DISK</p> <p>FORMAT HARD DISK</p> <p>FLOPPY DISK UTILITIES</p> <p>PRESS <ENTER> TO SELECT</p>

Menu DSK2, Select File to Read

DESCRIPTION	MENU
Displays the data stored in file number 1.	FILE 1
Displays the data stored in file number 2.	FILE 2
Displays the data stored in file number 3.	FILE 3
Displays the data stored in file number 4.	FILE 4
Displays the data stored in file number 5.	FILE 5
Displays the data stored in file number 6.	FILE 6
Displays the data stored in file number 7.	FILE 7
Displays the data stored in file number 8.	FILE 8
Returns to the previous menu.	PREVIOUS MENU
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT
Pressing the "1" key on the keypad returns to the previous page.	PRESS <1> FOR PREVIOUS PAGE
Pressing the "2" key on the keypad produces the next page.	PRESS <2> FOR NEXT PAGE

Menu DSK3, Select File to Overwrite

DESCRIPTION	MENU
<p>Select file number 1 to be overwritten with new data.</p> <p>Select file number 2 to be overwritten with new data.</p> <p>Select file number 3 to be overwritten with new data.</p> <p>Select file number 4 to be overwritten with new data.</p> <p>Select file number 5 to be overwritten with new data.</p> <p>Select file number 6 to be overwritten with new data.</p> <p>Select file number 7 to be overwritten with new data.</p> <p>Select file number 8 to be overwritten with new data.</p> <p>Returns to the previous menu.</p> <p>Pressing the Enter key implements your menu selection.</p> <p>Pressing the "1" key on the keypad returns to the previous page.</p> <p>Pressing the "2" key on the keypad produces the next page.</p>	<p>SELECT FILE TO OVERWRITE</p> <p>CREATE NEW FILE</p> <p>FILE 1</p> <p>FILE 2</p> <p>FILE 3</p> <p>FILE 4</p> <p>FILE 5</p> <p>FILE 6</p> <p>FILE 7</p> <p>FILE 8</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT</p> <p>PRESS <1> FOR PREVIOUS PAGE</p> <p>PRESS <2> FOR NEXT PAGE</p>

Menu DSK6, Type of Files to Delete

DESCRIPTION	MENU
<p>Deletes the front panel and calibration data files.</p> <p>Deletes the trace data files.</p> <p>Deletes the tabular data files.</p> <p>Returns to the previous menu.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>TYPE OF FILES TO DELETE</p> <p>FRONT PANEL SETUP AND CAL DATA</p> <p>TRACE DATA</p> <p>TABULAR DATA</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT</p>

Menu DSK7, Select File to Delete

DESCRIPTION	MENU
Selects file number 1 data to be deleted.	FILE 1
Selects file number 2 data to be deleted.	FILE 2
Selects file number 3 data to be deleted.	FILE 3
Selects file number 4 data to be deleted.	FILE 4
Selects file number 5 data to be deleted.	FILE 5
Selects file number 6 data to be deleted.	FILE 6
Selects file number 7 data to be deleted.	FILE 7
Selects file number 8 data to be deleted.	FILE 8
Returns to the previous menu.	PREVIOUS MENU
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT
Pressing the "1" key on the keypad returns to the previous page.	PRESS <1> FOR PREVIOUS PAGE
Pressing the "2" key on the keypad produces the next page.	PRESS <2> FOR NEXT PAGE

Menu DSK8, Type of Files to Copy

DESCRIPTION	MENU
<p>Copy the front panel setup and calibration data files.</p> <p>Copy the trace data files.</p> <p>Copy the tabular data files.</p> <p>Returns to the previous menu.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>TYPE OF FILES TO COPY</p> <p>FRONT PANEL SETUP AND CAL DATA</p> <p>TRACE DATA</p> <p>TABULAR DATA</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT</p>

Menu DSK10, Capture Tabular Data

DESCRIPTION	MENU
Captures the tabular data to a file when the Enter key is pressed.	CAPTURE TABULAR DATA
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO CONTINUE

Menu DSK9, Select File to Copy

DESCRIPTION	MENU
Selects file number 1 data to be copied.	FILE 1
Selects file number 2 data to be copied.	FILE 2
Selects file number 3 data to be copied.	FILE 3
Selects file number 4 data to be copied.	FILE 4
Selects file number 5 data to be copied.	FILE 5
Selects file number 6 data to be copied.	FILE 6
Selects file number 7 data to be copied.	FILE 7
Selects file number 8 data to be copied.	FILE 8
Returns to the previous menu.	PREVIOUS MENU
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT
Pressing the "1" key on the keypad returns to the previous page.	PRESS <1> FOR PREVIOUS PAGE
Pressing the "2" key on the keypad produces the next page.	PRESS <2> FOR NEXT PAGE
	SELECT FILE TO COPY

Menu DSK12, Format Hard Disk

DESCRIPTION	MENU
<p>Assumes that the hard disk is ready to be formatted; press the Enter key to begin the formatting process.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CAUTION: ALL HARD DISK DATA WILL BE ERASED</p> <p>ASSUME HARD DISK READY TO FORMAT</p> <p>PRESS <ENTER> TO CONTINUE</p>

Menu DSK11, Format Floppy Disk

DESCRIPTION	MENU
<p>Ensure that you have the correct floppy diskette for formatting, then press the Enter key to begin the formatting process.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CAUTION: ALL FLOPPY DISK DATA WILL BE ERASED</p> <p>INSERT DISK TO FORMAT</p> <p>PRESS <ENTER> TO CONTINUE</p>

Menu EM, Enhancement Menu

DESCRIPTION	MENU
<p>Averages the measured data over time, as follows:</p> <ol style="list-style-type: none"> 1. The sweep stops at the first frequency point and takes a number of readings, based on the selected number of points. 2. The program averages the readings and writes the average value for that frequency point in the displayed graph. 3. The sweep then advances to the next sequential frequency point and repeats the process. <p>Lets you select a percentage of the sweep to receive smoothing. The smoothing process uses a raised Hamming window to average the data from a span of frequencies.</p>	<p>DATA ENHANCEMENT AVERAGING XXXX MEAS. PER POINT SMOOTHING X.X PERCENT OF SWEEP</p>

Menu GP5, Select Name

DESCRIPTION	MENU
<p>Name your file using the rotary knob to select letters, numbers, or both. A letter or number turns red to indicate that the letter/number has been chosen for selection. Pressing the Enter key selects the letter or number. The name you spell out displays in the area below "SELECT NAME." You are allowed up to eight characters for a file name and twelve characters for a label.</p> <p>Selecting "BKSP" deletes the last letter in the name displayed above. Selecting "CLR" deletes the entire name. Selecting "DONE" signals that you have finished writing the name.</p> <p>Use the rotary knob to indicate the letter or number you wish to select. You can use the up-arrow and down-arrow keys to move between rows. Pressing the Enter key implements your menu selection. The menu remains on the screen until another menu is selected for display or until the CLEAR/RET LOC key is pressed.</p> <p>You may also select numbers and decimals using the keypad.</p>	<p>SELECT LABEL ----- ABCDEFGHIJKLM NOPQRSTUWXYZ 0123456789() !#\$%&@^_~{ }~ BKSP CLR DONE TURN KNOB TO INDICATE CHARACTER OR FUNCTION PRESS <ENTER> TO SELECT NUMBERS MAY ALSO BE SELECTED USING KEYPAD</p>

Menu GP7, Display GPIB Status

DESCRIPTION	MENU
<p>Selects the GPIB address for the 372XXA analyzer. The default address is 6.</p>	<p>GPIB ADDRESSES IEEE 488.2 GPIB INTERFACE ADDRESS: 6</p>
<p>Selects the address for an external source. The default address is 4.</p>	<p>DEDICATED GPIB INTERFACE EXTERNAL SOURCE 4</p>
<p>Selects the address for a compatible plotter. The default address is 8.</p>	<p>PLOTTER 8</p>
<p>Selects the address for an HP4370 Power Meter. The default address is 13.</p>	<p>POWER METER 13</p>
<p>Selects the address for an external frequency counter. The default address is 7.</p>	<p>FREQUENCY COUNTER 7</p>

Menu GT1/CAL_GT1, Select Graph Type

DESCRIPTION	MENU
<p>Selects a log magnitude graph for display on the active channel's selected S-parameter. The active channel is indicated by its key (CH1, CH2, CH3, CH4) being lit.</p> <p>Selects a phase graph for display on the active channel.</p> <p>Selects log magnitude and phase graphs for display on the active channel.</p> <p>Selects a Smith chart for display on the active channel.</p> <p>Selects an SWR display for the active channel.</p> <p>Selects a Group Delay display for the active channel.</p> <p>Takes you to additional graph type selections on menu GT2.</p> <p>Pressing the Enter key implements your menu selection (and resumes the calibration from where it left off, if in the calibration mode).</p>	<p>SELECT GRAPH TYPE</p> <p>LOG MAGNITUDE</p> <p>PHASE</p> <p>LOG MAGNITUDE AND PHASE</p> <p>SMITH CHART (IMPEDANCE)</p> <p>SWR</p> <p>GROUP DELAY</p> <p>MORE</p> <p>PRESS <ENTER> TO SELECT AND RESUME CAL</p>

Menu GT2/CAL_GT2, Select Graph Type

DESCRIPTION	MENU
<p>Selects an Admittance Smith chart for display on the active channel's S-parameter.</p>	<p>SMITH CHART (ADMITTANCE)</p>
<p>Selects a Linear Polar graph for display on the active channel's S-parameter.</p>	<p>LINEAR POLAR</p>
<p>Selects a Log Polar graph for display on the active channel's S-parameter.</p>	<p>LOG POLAR</p>
<p>Selects a Linear Magnitude graph for display on the active channel's S-parameter.</p>	<p>LINEAR MAG</p>
<p>Selects Linear Magnitude and Phase graphs for display on the active channel's S-parameter.</p>	<p>LINEAR MAG AND PHASE</p>
<p>Selects Real data for display on the active channel's s-parameter.</p>	<p>REAL</p>
<p>Selects Imaginary data for display on the active channel's s-parameter.</p>	<p>IMAGINARY</p>
<p>Selects both Real and Imaginary data for display on the active channel's S-parameter.</p>	<p>REAL AND IMAGINARY</p>
<p>Takes you to additional graph type selections.</p>	<p>MORE</p>
<p>Pressing the Enter key implements your menu selection (and resumes the calibration from where it left off, if in the calibration mode).</p>	<p>PRESS <ENTER> TO SELECT AND RESUME CAL</p>

Menu L1, Set Limits—Magnitude and Phase

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Log Mag display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Log Mag display.</p> <p>Displays Menu LF1, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Turns the Upper Limit line on or off for the active channel on your Phase display.</p> <p>Turns the Lower Limit line on or off for the active channel on your Phase display.</p> <p>Displays Menu LF2, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both limit lines for the active channel on both the Log-Mag and Phase graphs.</p> <p>Calls Menu LST, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS</p> <p>—LOG MAG—</p> <p>UPPER LIMIT ON (OFF) XXX.XXX dB</p> <p>LOWER LIMIT ON(OFF) XXX.XXX dB</p> <p>READOUT LIMIT</p> <p>—PHASE—</p> <p>UPPER LIMIT ON (OFF) XXX.XXX °</p> <p>LOWER LIMIT ON(OFF) XXX.XXX °</p> <p>READOUT LIMIT</p> <p>UPPER LIMIT ON (OFF) XXX.XXX °</p> <p>LOWER LIMIT ON(OFF) XXX.XXX °</p> <p>TEST LIMITS</p> <p>SEGMENTED LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu L3, Set Limits—Linear Polar/Smith Chart

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Smith Chart display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Smith Chart.</p> <p>Enables both previously set limit lines to appear for the active channel on your Smith Chart.</p> <p>Calls Menu LTST, which provides choices for testing the limits.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS -SMITH CHART-</p> <p>UPPER LIMIT ON (OFF) XXX.XXX mU</p> <p>LOWER LIMIT ON(OFF) XXX.XXX mU</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu L2, Set Limits—Linear Polar

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Linear Polar display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Linear Polar display.</p> <p>Enables both previously set limit lines to appear for the active channel on your polar display.</p> <p>Calls Menu LTST, which provides choices for testing the limits.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS -LINEAR POLAR-</p> <p>UPPER LIMIT ON (OFF) XXX.XXX mU</p> <p>LOWER LIMIT ON(OFF) XXX.XXX mU</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu I4, Set Limits—Log Magnitude

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Log Mag display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Log Mag display.</p> <p>Displays Menu LF1, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both previously set limit lines to appear for the active channel on your Log Mag display.</p> <p>Calls Menu LST, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS</p> <p>-LOG MAG-</p> <p>UPPER LIMIT ON (OFF) XXX.XXX dB</p> <p>LOWER LIMIT ON(OFF) XXX.XXX dB</p> <p>READOUT LIMIT</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS</p> <p>SEGMENTED LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Phase display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Phase display.</p> <p>Displays Menu L_{F1}, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both limit lines for the active channel on a phase graph.</p> <p>Calls Menu LTST, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS</p> <p>-PHASE-</p> <p>UPPER LIMIT ON (OFF) ° XXX.XXX °</p> <p>LOWER LIMIT ON(OFF) ° XXX.XXX °</p> <p>READOUT LIMIT</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS</p> <p>SEGMENTED LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu L5, Set Limits—Phase

Menu L6, Set Limits—Log Polar

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Log Polar display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Log Polar display.</p> <p>Enables both previously set limit lines to appear for the active channel on your Log Polar display.</p> <p>Calls Menu LTST, which provides choices for testing the limits.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS</p> <p>-LOG POLAR-</p> <p>UPPER LIMIT ON (OFF) XXX.XXX dB</p> <p>LOWER LIMIT ON(OFF) XXX.XXX dB</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu L7, Set Limits—Group Delay

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Group Delay display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Group Delay display.</p> <p>Displays Menu L7, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both previously set limit lines to appear for the active channel on your Group Delay display.</p> <p>Calls Menu L7ST, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS</p> <p>--GROUP DELAY--</p> <p>UPPER LIMIT ON (OFF) XXX.XXX fs</p> <p>LOWER LIMIT ON(OFF) XXX.XXX fs</p> <p>READOUT LIMIT</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS</p> <p>SEGMENTED LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu L8, Set Limits—Linear Magnitude

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Linear Mag display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Linear Mag display.</p> <p>Displays Menu L-F1, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both previously set limit lines to appear for the active channel on your Linear Mag display.</p> <p>Calls Menu L-TST, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS</p> <p>-LINEAR MAG-</p> <p>UPPER LIMIT ON (OFF) XXX.XXX pu</p> <p>LOWER LIMIT ON(OFF) XXX.XXX pu</p> <p>READOUT LIMIT</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS</p> <p>SEGMENTED LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Linear Mag display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Linear Mag display.</p> <p>Displays Menu LF4, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your polar display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Phase display.</p> <p>Displays Menu LF2, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both previously set limit lines to appear for the active channel on your Phase display.</p> <p>Calls Menu LST1, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS</p> <p>-LINEAR MAG-</p> <p>UPPER LIMIT ON (OFF) XXX.XXX pu</p> <p>LOWER LIMIT ON(OFF) XXX.XXX pu</p> <p>READOUT LIMIT</p> <p>-PHASE-</p> <p>UPPER LIMIT ON (OFF) XXX.XXX °</p> <p>LOWER LIMIT ON(OFF) XXX.XXX °</p> <p>READOUT LIMIT</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS</p> <p>SEGMENTED LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu L9, Set Limits—Linear Magnitude and Phase

Menu L10, Set Limits—Real Values

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Real display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Real display.</p> <p>Displays Menu L₆, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both previously set limit lines to appear for the active channel on your Real values display.</p> <p>Calls Menu LTST, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS -REAL-</p> <p>UPPER LIMIT ON (OFF) XXX.XXX pu</p> <p>LOWER LIMIT ON(OFF) XXX.XXX pu</p> <p>READOUT LIMIT</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS</p> <p>SEGMENTED LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu L11, Set Limits—Imaginary Values

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your imaginary display beyond which the measured values are unacceptable.</p>	<p>SINGLE LIMITS -IMAGINARY- UPPER LIMIT ON (OFF) XXX.XXX pu</p>
<p>Turns the Lower Limit line on or off for the active channel on your imaginary display.</p>	<p>LOWER LIMIT ON(OFF) XXX.XXX pu</p>
<p>Displays Menu L7, which shows points where the current S-parameter intercepts the lower limit.</p>	<p>READOUT LIMIT</p>
<p>Enables both previously set limit lines to appear for the active channel on your imaginary values display.</p>	<p>DISPLAY ON (OFF) LIMITS</p>
<p>Calls Menu LTST, which provides choices for testing the limits.</p>	<p>TEST LIMITS</p>
<p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p>	<p>SEGMENTED LIMITS</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu L12, Set Limits—Real and Imaginary Values

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Real display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Real display.</p> <p>Displays Menu LF6, which shows points where the current S-parameter intercepts the lower limit.</p>	<p>-REAL- SINGLE LIMITS UPPER LIMIT ON (OFF) XXX.XXX pu LOWER LIMIT ON(OFF) XXX.XXX pu READOUT LIMIT</p>
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your Imaginary display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your Imaginary display.</p> <p>Displays Menu LF7, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both previously set limit lines to appear for the active channel on your Imaginary values display.</p> <p>Calls Menu LTST, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>UPPER LIMIT ON (OFF) XXX.XXX pu UPPER LIMIT ON (OFF) XXX.XXX pu LOWER LIMIT ON(OFF) XXX.XXX pu READOUT LIMIT DISPLAY ON (OFF) LIMITS TEST LIMITS SEGMENTED LIMITS PRESS TO SELECT OR TURN ON/OFF</p>

Menu L13, Set Limits—SWR

DESCRIPTION	MENU
<p>Turns the Upper Limit line on or off for the active channel. For your convenience, the arbitrarily set limit lines allow you to delineate a go/no go line on your SWR display beyond which the measured values are unacceptable.</p> <p>Turns the Lower Limit line on or off for the active channel on your SWR display.</p> <p>Displays Menu L5, which shows points where the current S-parameter intercepts the lower limit.</p> <p>Enables both previously set limit lines to appear for the active channel.</p> <p>Calls Menu LTST, which provides choices for testing the limits.</p> <p>Calls a menu in the LS series (LSX), which lets you set segmented limit lines.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE LIMITS</p> <p>—SWR—</p> <p>UPPER LIMIT ON (OFF) XXX.XXX pu</p> <p>LOWER LIMIT ON(OFF) XXX.XXX pu</p> <p>READOUT LIMIT</p> <p>DISPLAY ON (OFF) LIMITS</p> <p>TEST LIMITS</p> <p>SEGMENTED LIMITS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu LDI, Define Upper Limit Segment

DESCRIPTION	MENU
Define the upper limit segment.	DEFINE UPPER SEGS
Enter the segment number that you want to define, and turn it on or off.	SEGMENT ON (OFF) X
Enter the start horizontal value in GHz, seconds, meter, or points (domain dependent)	START POSITION HORIZONTAL XXX.XXXXXXXXXX GHz
Enter the start vertical value in dB, degrees, units, or seconds (graph-type dependent)	VERTICAL XX.XXXXX dB
Enter the stop horizontal value in GHz, seconds, meter, or points (domain dependent)	STOP POSITION HORIZONTAL XXX.XXXXXXXXXX GHz
Enter the stop vertical value in dB, degrees, units, or seconds (graph-type dependent)	VERTICAL XX.XXXXX dB
Turns the next segment on and sets its start and stop positions to the previous segment's stop position.	BEGIN NEXT
Turns the next segment on and sets its start positions to the previous segment's stop position.	ATTACH NEXT
Turns the current segment-to-define off and sets its start equal to its stop.	CLEAR SEGMENT
Returns to the previous menu.	PREVIOUS MENU
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT OR TURN ON/OFF

Menu LD2, Define Lower Limit Segment

DESCRIPTION	MENU
Define the upper limit segment. Enter the segment number that you want to define, and turn it on or off.	DEFINE LOWER SEGS SEGMENT ON (OFF) X
Enter the start horizontal value in GHz, seconds, meter, or points (domain dependent) Enter the start vertical value in dB, degrees, units, or seconds (graph-type dependent)	START POSITION HORIZONTAL XXX.XXXXXXXXXXX GHz VERTICAL XX.XXXX dB
Enter the stop horizontal value in GHz, seconds, meter, or points (domain dependent) Enter the stop vertical value in dB, degrees, units, or seconds (graph-type dependent)	STOP POSITION HORIZONTAL XXX.XXXXXXXXXXX GHz VERTICAL XX.XXXX dB
Turns the next segment on and sets its start and stop positions to the previous segment's stop position.	BEGIN NEXT
Turns the next segment on and sets its start positions to the previous segments' stop position.	ATTACH NEXT
Turns the current segment-to-define off and sets its start equal to its stop. Returns to the previous menu.	CLEAR SEGMENT PREVIOUS MENU PRESS <ENTER> TO SELECT OR TURN ON/OFF

Menu Lf1, Set Limit Frequencies—Log Mag

DESCRIPTION	MENU
<p>Lets you set the UPPER LIMIT (REF) limit line. Changing this value also moves the lower limit line by the LIMIT DIFFERENCE amount.</p> <p>Lets you set the LOWER LIMIT dB limit line. Changing this value also changes the LIMIT DIFFERENCE amount relative to the UPPER LIMIT (REF) value.</p> <p>Lets you set the LIMIT DIFFERENCE amount. Changing this value also changes the lower limit value relative to the UPPER LIMIT (REF) value.</p> <p>Displays at which frequencies the data intercepts the lower limit. May be interpolated.</p>	<p>READOUT LIMIT</p> <p>INTERCEPTS</p> <p>—LOG MAG—</p> <p>UPPER LIMIT (REF)</p> <p>XXX.XXX dB</p> <p>LOWER LIMITdB</p> <p>XXX.XXX dB</p> <p>LIMIT DIFFERENCE</p> <p>(UPPER-LOWER)</p> <p>XXX.XXX dB</p> <p>INTERCEPTS AT</p> <p>LOWER LIMIT</p> <p>XXX.XXXXXXXXXX GHZ</p> <p>XXX.XXXXXXXXXX GHZ</p> <p>XXX.XXXXXXXXXX GHZ</p> <p>XXX.XXXXXXXXXX GHZ</p> <p>XXX.XXXXXXXXXX GHZ</p> <p>XXX.XXXXXXXXXX GHZ</p>

Menu LF2, Set Limit Frequencies—Phase

DESCRIPTION	MENU
<p>Lets you set the UPPER LIMIT (REF) limit line. Changing this value also moves the lower limit line by the LIMIT DIFFERENCE amount.</p> <p>Lets you set the LOWER LIMIT dB limit line. Changing this value also changes the LIMIT DIFFERENCE amount relative to the UPPER LIMIT (REF) value.</p> <p>Lets you set the LIMIT DIFFERENCE amount. Changing this value also changes the lower limit value relative to the UPPER LIMIT (REF) value.</p> <p>Displays at which frequencies the data intercepts the lower limit. May be interpolated.</p>	<p>READOUT LIMIT INTERCEPTS -PHASE— UPPER LIMIT (REF) XXX.XXX ° LOWER LIMITdB XXX.XXX ° LIMIT DIFFERENCE (UPPER-LOWER) INTERCEPTS AT LOWER LIMIT XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ</p>

Menu LF3, Set Limit Frequencies—Group Delay

DESCRIPTION	MENU
<p>Lets you set the UPPER LIMIT (REF) limit line. Changing this value also moves the lower limit line by the LIMIT DIFFERENCE amount.</p> <p>Lets you set the LOWER LIMIT dB limit line. Changing this value also changes the LIMIT DIFFERENCE amount relative to the UPPER LIMIT (REF) value.</p> <p>Lets you set the LIMIT DIFFERENCE amount. Changing this value also changes the lower limit value relative to the UPPER LIMIT (REF) value.</p> <p>Displays at which frequencies the data intercepts the lower limit. May be interpolated.</p>	<p>READOUT LIMIT INTERCEPTS —GROUP DELAY— UPPER LIMIT (REF) XXX.XXX fs LOWER LIMIT XXX.XXX fs LIMIT DIFFERENCE (UPPER-LOWER) INTERCEPTS AT LOWER LIMIT XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ XXX.XXXXXXXX GHZ</p>

Menu LF4, Set Limit Frequencies—Linear Mag

DESCRIPTION	MENU
<p>Lets you set the UPPER LIMIT (REF) limit line. Changing this value also moves the lower limit line by the LIMIT DIFFERENCE amount.</p> <p>Lets you set the LOWER LIMIT dB limit line. Changing this value also changes the LIMIT DIFFERENCE amount relative to the UPPER LIMIT (REF) value.</p> <p>Lets you set the LIMIT DIFFERENCE amount. Changing this value also changes the lower limit value relative to the UPPER LIMIT (REF) value.</p> <p>Displays at which frequencies the data intercepts the lower limit. May be interpolated.</p>	<p>READOUT LIMIT INTERCEPTS —LINEAR MAG— UPPER LIMIT (REF) XXX.XXX pu LOWER LIMIT XXX.XXX pu LIMIT DIFFERENCE (UPPER-LOWER) XXX.XXX pu INTERCEPTS AT LOWER LIMIT XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ</p>

Menu LF5, Set Limit Frequencies—SWR

DESCRIPTION	MENU
<p>Lets you set the UPPER LIMIT (REF) limit line. Changing this value also moves the lower limit line by the LIMIT DIFFERENCE amount.</p> <p>Lets you set the LOWER LIMIT dB limit line. Changing this value also changes the LIMIT DIFFERENCE amount relative to the UPPER LIMIT (REF) value.</p> <p>Lets you set the LIMIT DIFFERENCE amount. Changing this value also changes the lower limit value relative to the UPPER LIMIT (REF) value.</p> <p>Displays at which frequencies the data intercepts the lower limit. May be interpolated.</p>	<p>SET LIMIT FREQUENCIES -SWR- UPPER LIMIT (REF) XXX.XXX pu LOWER LIMIT XXX.XXX pu LIMIT DIFFERENCE (UPPER-LOWER) XXX.XXX pu INTERCEPTS AT LOWER LIMIT XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ</p>

Menu LF6, Set Limit Frequencies—Real

DESCRIPTION	MENU
<p>Lets you set the UPPER LIMIT (REF) limit line. Changing this value also moves the lower limit line by the LIMIT DIFFERENCE amount.</p> <p>Lets you set the LOWER LIMIT dB limit line. Changing this value also changes the LIMIT DIFFERENCE amount relative to the UPPER LIMIT (REF) value.</p> <p>Lets you set the LIMIT DIFFERENCE amount. Changing this value also changes the lower limit value relative to the UPPER LIMIT (REF) value.</p> <p>Displays at which frequencies the data intercepts the lower limit. May be interpolated.</p>	<p>SET LIMIT FREQUENCIES -REAL-</p> <p>UPPER LIMIT (REF) XXX.XXX pu</p> <p>LOWER LIMIT XXX.XXX pu</p> <p>LIMIT DIFFERENCE (UPPER-LOWER)</p> <p>INTERCEPTS AT LOWER LIMIT</p> <p>XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ</p>

Menu LF7, Set Limit Frequencies—Imaginary

DESCRIPTION	MENU
<p>Lets you set the UPPER LIMIT (REF) limit line. Changing this value also moves the lower limit line by the LIMIT DIFFERENCE amount.</p> <p>Lets you set the LOWER LIMIT dB limit line. Changing this value also changes the LIMIT DIFFERENCE amount relative to the UPPER LIMIT (REF) value.</p> <p>Lets you set the LIMIT DIFFERENCE amount. Changing this value also changes the lower limit value relative to the UPPER LIMIT (REF) value.</p> <p>Displays at which frequencies the data intercepts the lower limit. May be interpolated.</p>	<p>SET LIMIT FREQUENCIES —IMAGINARY— UPPER LIMIT (REF) XXX.XXX pu LOWER LIMIT XXX.XXX pu LIMIT DIFFERENCE (UPPER-LOWER) INTERCEPTS AT LOWER LIMIT XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ XXX.XXXXXXXXXX GHZ</p>

Menu LSX, Segmented Limits

DESCRIPTION	MENU
Displays the currently active channel's graph type.	SEGMENTED LIMITS -XXXXXXX-
Turns the Upper Limit line on or off for the active channel.	UPPER LIMIT ON(OFF)
Calls menu LD1, which lets you define an upper segment value.	DEFINE UPPER
Turns the Lower Limit line on or off for the active channel.	LOWER LIMIT ON(OFF)
Calls menu LD2, which lets you define a lower segment value.	DEFINE LOWER
Enter the horizontal offset to be applied to all of the channel's segmented limits, in GHz, seconds, meters, or points (domain dependent)	SEGMENTED OFFSETS HORIZONTAL XXXX GHz
Enter the vertical offset to be applied to all of the channel's segmented limits, in dB, degrees, units, or seconds (graph-type dependent).	VERTICAL XXXX dB
Clears all segments.	CLEAR ALL
Toggle between on and off to display the active channel's limits.	DISPLAY ON (OFF) LIMITS
Calls menu LST, which lets test for limits.	TEST LIMITS
Returns to the appropriate single limits menu.	SINGLE LIMITS
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT OR TURN ON/OFF

DESCRIPTION	MENU
<p>Turns limit testing for all displayed channels on or off.</p> <p>Turns beeper on or off when limit test fails.</p> <p>Selects between a TTL high or TTL low to indicate that the limit test has failed.</p> <p>Displays result of Channel 1 limit test.</p> <p>Displays result of Channel 2 limit test.</p> <p>Displays result of Channel 3 limit test.</p> <p>Displays result of Channel 4 limit test.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>TEST LIMITS</p> <p>LIMIT ON (OFF) TESTING</p> <p>BEEP FOR ON (OFF) TEST FAILURE</p> <p>LIMIT TEST TTL FAIL CONDITION TTL LOW/TTL HIGH</p> <p>CHANNEL 1 TEST PASS (FAIL)</p> <p>CHANNEL 2 TEST PASS (FAIL)</p> <p>CHANNEL 3 TEST PASS (FAIL)</p> <p>CHANNEL 4 TEST PASS (FAIL)</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu LTST, Test Limits

Menu M1, Set Markers

DESCRIPTION	MENU
<p>Turns Marker 1 on or off (activates or deactivates). When on (active), the frequency, time, or distance may be set using the keypad or rotary knob.</p>	<p>MARKER 1 ON (OFF) XXX.XXXXXXXXXX GHZ</p>
<p>NOTE</p> <p>In this text, markers are referred to as being active and as being selected. Any marker that has been turned on and assigned a frequency is considered to be selected. The marker to which the cursor presently points is considered to be active. The active marker is the only one for which you can change the frequency.</p>	
<p>Turns Marker 2 on or off (activates or deactivates). When on (active), the frequency, time, or distance may be set using the keypad or rotary knob.</p>	<p>MARKER 2 ΔREF ON (OFF) XXX.XXXXXXXXXX GHZ</p>
<p>Turns Marker 3 on or off (activates or deactivates). When on (active), the frequency, time, or distance may be set using the keypad or rotary knob.</p>	<p>MARKER 3 ON (OFF) XXX.XXXXXXXXXX GHZ</p>
<p>Turns Marker 4 on or off (activates or deactivates). When on (active), the frequency, time, or distance may be set using the keypad or rotary knob.</p>	<p>MARKER 4 ON (OFF) XXX.XXXXXXXXXX GHZ</p>
<p>Turns Marker 5 on or off (activates or deactivates). When on (active), the frequency, time, or distance may be set using the keypad or rotary knob.</p>	<p>MARKER 5 ON (OFF) XXX.XXXXXXXXXX GHZ</p>
<p>Turns Marker 6 on or off (activates or deactivates). When on (active), the frequency, time, or distance may be set using the keypad or rotary knob.</p>	<p>MARKER 6 ON (OFF) XXX.XXXXXXXXXX GHZ</p>
<p>Displays selected markers.</p>	<p>DISPLAY ON (OFF) MARKERS</p>
<p>Selects the ΔREF Mode to be on or off.</p>	<p>ΔREF MODE ON (OFF)</p>
<p>Calls Menu M2, which lets you select the ΔREF Marker.</p>	<p>SELECT ΔREF MARKER</p>
<p>Calls Menu M9, which lets you select readout marker parameters.</p>	<p>READOUT MARKER FUNCTIONS</p>

DESCRIPTION	MENU
<p>Marker 1 only appears if it has been activated in Menu M1. Placing the cursor on Marker 1 and pressing the Enter key here selects it as the ΔREF marker. The ΔREF marker is the one from which the other active markers are compared and their difference frequency measured and displayed in Menu M3. The marker frequency may be set using the keypad or rotary knob.</p> <p>Same as above, but for Marker 3. This display is representative if Markers 1, 3, and 4 are selected. Markers 2, 5, and 6 would also show, if they had been selected.</p> <p>Same as above, but for Marker 4</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT ΔREF MARKER</p> <p>MARKER 1 XXX.XXXXXXXXXX GHZ</p> <p>MARKER 3 XXX.XXXXXXXXXX GHZ</p> <p>MARKER 4 XXX.XXXXXXXXXXGHZ</p> <p>PRESS <ENTER> TO SELECT</p>

Menu M2, Select ΔREF Marker

Menu M3, Select Readout Marker

DESCRIPTION	MENU
<p>Displays the frequency and S-Parameter value(s) of Marker 1 on all CRT-displayed graphs and Smith Charts. The frequency of Marker 1 also displays here. If Marker 1 was activated in Menu M2 as the REF marker, REF appears as shown for Marker M5 below.</p> <p>Same as above, but for Marker 2</p> <p>Same as above, but for Marker 5 This display is representative if Markers 1, 2, and 5 are selected. Markers 3, 4, and 6 would also show, if they had been selected.</p> <p>Indicates the status of the ΔREF mode.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>MARKER 1 XXX.XXXXXXXXXX GHZ</p> <p>MARKER 2 XXX.XXXXXXXXXX GHZ</p> <p>MARKER 5 XXX.XXXXXXXXXX GHZ</p> <p>ΔREF MODE IS ON (OFF)</p> <p>PRESS <ENTER> TO SELECT</p> <p>SELECT READOUT MARKER</p>

Menu M4, Readout Marker

DESCRIPTION	MENU
<p>Selects channel for readout</p> <p>The selected marker—that is, the one to which the cursor points in Menu M1—and its frequency, time, or distance display here. This could be any one of the six available markers: Marker 1 thru Marker 6.</p> <p>Causes the active marker to go to the frequency with the <i>greatest</i> S-Parameter value on the active channel.</p> <p>Causes the selected marker to go to the frequency with the <i>smallest</i> S-Parameter value on the active channel.</p> <p>Displays the frequency, magnitude, and phase of the active S-Parameter at marker 2, if the marker is enabled.</p> <p>Displays the frequency, magnitude, and phase of the active S-Parameter at marker 3, if the marker is enabled.</p> <p>Displays the frequency, magnitude, and phase of the active S-Parameter at marker 4, if the marker is enabled.</p> <p>Displays the frequency, magnitude, and phase of the active S-Parameter at marker 5, if the marker is enabled.</p> <p>Displays the frequency, magnitude, and phase of the active S-Parameter at marker 6, if the marker is enabled.</p> <p>Calls Menu M9, which lets you select readout marker parameters.</p>	<p>CH1 — S11</p> <p>REFERENCE PLANE X.XXXX mm</p> <p>MARKER 1 XXX.XXXXXXXX GHz XX.XXX dB XXX.XXX °</p> <p>MARKER TO MAX</p> <p>MARKER TO MIN</p> <p>2 XXX.XXXXXXXX GHz XX.XXX dB XXX.XXX °</p> <p>3 XXX.XXXXXXXX GHz XX.XXX dB XXX.XXX °</p> <p>4 XXX.XXXXXXXX GHz XX.XXX dB XXX.XXX °</p> <p>5 XXX.XXXXXXXX GHz XX.XXX dB XXX.XXX °</p> <p>6 XXX.XXXXXXXX GHz XX.XXX dB XXX.XXX °</p> <p>MARKER READOUT FUNCTIONS</p>

Menu M5, Set ΔREF Marker Readout

DESCRIPTION	MENU
<p>The REF marker, as activated in Menu M2, its frequency, its reference delay, and the channel on which it appears display here. The REF marker could be any one of the six available markers: M1-M6. The frequency of the REF marker can be changed using the keypad or rotary knob.</p> <p>The marker numbers of the REF marker and the next lowest-numbered selected marker appear between the parentheses. This example assumes Marker 1 as the Ref marker and Marker 2 as the next lowest-numbered selected marker. The lines below display the difference frequency, (or time/distance) and trace value(s) between these two markers on the active channel.</p> <p>Same as above, except Marker 3 is the next lowest-numbered selected marker.</p> <p>Same as above, except Marker 4 is the next lowest-numbered selected marker.</p> <p>Same as above, except Marker 5 is the next lowest-numbered selected marker.</p> <p>Same as above, except Marker 6 is the next lowest-numbered selected marker.</p> <p>Calls Menu M9, which lets you select readout marker parameters.</p>	<p>CH 1 - S11</p> <p>REFERENCE PLANE X.XXXX mm</p> <p>MARKER 1 ΔREF XXX.XXXXXXXX GHz</p> <p>MARKER TO MAX MARKER TO MIN</p> <p>Δ(1 - 2) XXX.XXXX dB XXX.XXXXXXXX GHz</p> <p>Δ(1 - 3) XXX.XXXX dB XXX.XXXXXXXX GHz</p> <p>Δ(1 - 4) XXX.XXXX dB XXX.XXXXXXXX GHz</p> <p>Δ(1 - 5) XXX.XXXX dB XXX.XXXXXXXX GHz</p> <p>Δ(1 - 6) XXX.XXXX dB XXX.XXXXXXXX GHz</p> <p>MARKER READOUT FUNCTIONS</p>

Menu M6, Marker X All Displayed Channels

DESCRIPTION	MENU
<p>Displays the active marker number. For each channel being displayed, the channel, S-Parameter, frequency, time, distance or point number, and the current readout value for the marker is shown (below). No marker information is provided for channels that are not displayed.</p> <p>Displays the measured value for the active marker on all channels currently being displayed. You can set the marker on the active channel in this menu. The active channel is displayed in GREEN; when not active it is displayed in BLUE.</p> <p>See above.</p> <p>See above.</p> <p>See above.</p> <p>Causes the active marker to go to the frequency with the <i>greatest</i> S-Parameter value on the active channel.</p> <p>Causes the selected marker to go to the frequency with the <i>smallest</i> S-Parameter value on the active channel.</p> <p>Calls Menu M9, which lets you select readout marker parameters.</p> <p>Pressing the Enter key implements menu selection.</p>	<p>MARKER X ALL DISPLAYED CHANNELS</p> <p>CH 1 — S11 XX.XXXXXXXX GHz -XXX.XXX dB -XXX.XX °</p> <p>CH 2 — S21 See above.</p> <p>CH 3 — S12 XX.XXXXXXXX GHz -XXX.XXX dB -XXX.XX °</p> <p>CH 4 — S22 MARKER TO MAX</p> <p>MARKER TO MIN</p> <p>MARKER READOUT FUNCTIONS PRESS <ENTER> TO SELECT</p>

Menu M7, Search

DESCRIPTION	MENU
<p>This menu provides control and readout for the marker search function. When this function is selected, the graph type for the active channel is automatically set to LOG MAGNITUDE (other graph types are not allowed), and taken out of time domain low pass or band pass display. Frequency with time gate display is allowed.</p> <p>Target search value. A value from -999.999 to 999.999 dB may be entered.</p> <p>These menu choices let you enter the reference value for the search. The reference may be:</p> <ul style="list-style-type: none"> -Graticule "0 dB" -Position of Delta Ref. Marker (Marker 1 is used as the Δ Ref Marker) -Maximum value in Passband (default selection). Marker 1 is used to indicate maximum. <p>Selects maximum value as the reference.</p> <p>Selects Δ Ref Marker (Marker 1) as the reference.</p> <p>Selects 0 dB as the reference.</p> <p>Displays the difference between the reference value and 0 dB.</p> <p>Goes to the next data point that is left (or right) of the search marker (Marker 2) and whose value is equal to VALUE plus the reference. If "TRACKING" is ON, Marker 2 will search both left and right, and go to the closest point whose value is equal to VALUE plus reference. If there is no such point, the message "VALUE NOT FOUND" is displayed in the data area. Otherwise the marker goes to that coordinate and the readout (under the search direction) is updated to reflect that frequency.</p> <p>When ON the active marker will change its frequency value after every sweep to maintain the user entered loss value. When OFF the marker stays at the same frequency and reads out the magnitude value at that frequency, except when a search is triggered.</p> <p>Calls Menu M9, which lets you select readout marker parameters. Pressing the Enter key implements menu selection, or toggles selected option on or off.</p>	<p>SEARCH</p> <p>VALUE -XXX.XXX dB</p> <p>REFERENCE</p> <p>MAXIMUM VALUE</p> <p>Δ REF MARKER</p> <p>0 dB</p> <p>VALUE AT REFERENCE -XXX.XXX dB</p> <p>SEARCH LEFT</p> <p>SEARCH RIGHT</p> <p>XX.XXXXXXXXXX GHz</p> <p>TRACKING ON (OFF)</p> <p>MARKER READOUT FUNCTIONS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu M8, Filter Parameters

DESCRIPTION	MENU
<p>Provides the readouts for the filter measurement functions, as well as some selections. When this function is selected, the graph type for the active channel is automatically set to LOG MAGNITUDE, and taken out of time domain low pass or band pass display. Frequency with time gate display is allowed</p> <p>Displays the value of Marker 2. Marker 1 displays the reference value (maximum filter response, or its set value if delta ref).</p> <p>Displays the difference between Markers 3 and 4.</p> <p>Displays the difference between the reference value and 0 dB.</p> <p>Displays the Q value.</p> <p>NOTE</p> <p>"Q" and "SHAPE FACTOR" are not displayed if they are toggled OFF in Menu M8A.</p> <p>Displays the Shape Factor value.</p> <p>When ON the active marker will change its frequency value after every sweep to maintain the user entered loss value. When OFF the marker stays at the same frequency and reads out the magnitude value at that frequency, except when a search is triggered.</p> <p>Calls Menu M8A, which lets you set filter parameters.</p> <p>Calls Menu M9, which lets you select readout marker parameters.</p> <p>Pressing the Enter key implements menu selection, or toggles selected option on or off.</p>	<p>FILTER PARAMETERS</p> <p>CENTER FREQ XX.XXXXXXXX GHZ</p> <p>BANDWIDTH XXX.XXX dB</p> <p>Δ REF MARKER XX.XXXXXXXX GHZ</p> <p>LOSS AT REF -XXX.XXX dB</p> <p>Q XX.XXX</p> <p>SHAPE FACTOR X.XXX</p> <p>TRACKING ON (OFF)</p> <p>FILTER SETUP</p> <p>MARKER READOUT FUNCTIONS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu M8A, Filter Setup

DESCRIPTION	MENU
<p>A "loss" is a positive number. A value of 0 to 999.999 dB may be entered. The search value for bandwidth will be REF minus (-) LOSS. By default, the loss value is set to 3 dB. These menu choices let you enter the reference value for the search. The reference may be: -Graticule "0 dB" -Position of Delta Ref. Marker. (Marker 1 is used as the Δ Ref Marker) -Maximum value in Passband (default selection). Marker 1 is used to indicate maximum. Selects maximum value as the reference. Selects Δ Ref Marker (Marker 1) as the reference. Selects 0 dB as the reference. Enter high and low values for the Shape Factor. The LOW entry must be less than the HIGH entry. A value of 0 to 999.999 dB may be entered. The defaults are +6 dB for the HIGH, and +60 dB for the LOW value Toggles Q on or off. Toggles the Shape Factor on or off. NOTE "Q" and "SHAPE FACTOR" are not displayed in Menu M8, if they are toggled to OFF. Returns to the M8 menu.</p>	<p>PREVIOUS MENU</p> <p>SHAPE ON (OFF) FACTOR</p> <p>Q ON (OFF)</p> <p>READOUTS</p> <p>LOW XXX.XXX dB</p> <p>HIGH XXX.XXX dB</p> <p>SHAPE FACTOR</p> <p>0 dB</p> <p>Δ REF MARKER</p> <p>MAXIMUM VALUE</p> <p>REFERENCE</p> <p>LOSS VALUE XXX.XXX dB</p> <p>BANDWIDTH</p> <p>FILTER SETUP</p>

Menu M9, Marker Readout Functions

DESCRIPTION	MENU
<p>Marker values are interpolated between data points, interpolated markers are allowed only when the horizontal axis of the display is FREQUENCY. Interpolated markers are not allowed in CW, Time Domain, or Power Sweep. If a channel has been set to interpolated markers and the sweep is changed to CW or Power Sweep, the markers will automatically revert to normal mode (DISCRETE). Time Domain will ignore CONTINUOUS mode. Interpolated markers are allowed in any graph type, as long as the sweep is by frequency. Markers are displayed only at actual measured data point values. Calls Menu M1, which lets you set marker parameters. Pressing the Enter key implements menu selection.</p> <p>Calls Menu M3 directly — or causes it to be displayed when the Readout Marker key is pressed — if there is no active marker. Or to it calls or causes Menu M4 to be displayed if there is an active marker. If in delta reference mod, Menu M5 menu is displayed. Calls Menu M6 directly — or causes it to be displayed when the Readout Marker key is pressed. Calls Menu M7 directly — or causes it to be displayed when the Readout Marker key is pressed. Calls Menu M8 directly — or causes it to be displayed when the Readout Marker key is pressed.</p>	<p>MARKER READOUT FUNCTIONS</p> <p>MARKERS ON ACTIVE CHANNEL</p> <p>ACTIVE MARKERS ON ALL CHANNELS</p> <p>SEARCH</p> <p>FILTER PARAMETERS</p> <p>MARKER MODE</p> <p>CONTINUOUS</p> <p>DISCRETE</p> <p>SET MARKERS</p> <p>PRESS <ENTER> TO SELECT</p>

Menu NO1, Trace Memory Functions

DESCRIPTION	MENU
<p>Displays measured data; that is, the data presently being taken.</p> <p>Displays stored data; that is, data that was previously taken and stored in memory.</p> <p>Displays measured data superimposed over stored data.</p> <p>Displays measured data combined with stored data using selected math.</p> <p>Takes you to menu NO2 for selection of the type of math operation to be performed.</p> <p>Stores the measured data to internal memory.</p> <p>Brings up menu NO3, which allows data to be stored to or recalled from the disk.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>TRACE MEMORY FUNCTIONS</p> <p>VIEW DATA</p> <p>VIEW MEMORY</p> <p>VIEW DATA AND MEMORY</p> <p>VIEW DATA (/) MEMORY</p> <p>SELECT</p> <p>TRACE MATH</p> <p>STORE DATA TO MEMORY (STORED) (NOT STORED)</p> <p>DISK OPERATIONS</p> <p>PRESS <ENTER> TO SELECT</p>

Menu NO3, Trace Memory Disk Functions

DESCRIPTION	MENU
<p>Indicates the channel to be used (active channel).</p> <p>Calls menu DSK3, which lets you save memory to the hard disk.</p> <p>Calls menu DSK3, which lets you save memory to the floppy disk.</p> <p>Calls menu DSK2, which lets you recall memory from the hard disk.</p> <p>Calls menu DSK2, which lets you recall memory from the floppy disk.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>TRACE MEMORY</p> <p>DISK OPERATIONS</p> <p>CHANNEL X</p> <p>SAVE MEMORY TO HARD DISK</p> <p>SAVE MEMORY TO FLOPPY DISK</p> <p>RECALL MEMORY FROM HARD DISK</p> <p>RECALL MEMORY FROM FLOPPY DISK</p> <p>PRESS <ENTER> TO SELECT</p>

Menu NO2, Select Trace Math

DESCRIPTION	MENU
<p>Selects DATA + MEMORY as the math function.</p> <p>Selects DATA - MEMORY as the math function.</p> <p>Selects DATA X MEMORY as the math function.</p> <p>Selects DATA ÷ MEMORY as the math function.</p> <p>Pressing the Enter key implements your menu selection.</p> <p>The menu returns to the NO1 menu.</p>	<p>SELECT</p> <p>TRACE MATH</p> <p>ADD (+)</p> <p>SUBTRACT (-)</p> <p>MULTIPLY (*)</p> <p>DIVIDE (/)</p> <p>PRESS <ENTER> TO SELECT</p>

Menu OM1, Multiple Source Control Menu

DESCRIPTION	MENU
<p>Calls menu OM1, which lets you define a frequency band.</p> <p>Turns multiple source operating mode off placing 372XXA VNA in normal operating mode.</p> <p>Sets multiple source mode to ON.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>MULTIPLE SOURCE CONTROL</p> <p>DEFINE BANDS</p> <p>MULTIPLE SOURCE MODE</p> <p>OFF</p> <p>DEFINE</p> <p>ON</p> <p>PRESS <ENTER> TO SELECT</p>

Menu OM2, Define Bands Menu

DESCRIPTION	MENU
<p>-Displays the band number being defined.</p>	<p>DEFINE BANDS BAND 1 DISPLAYED</p>
<p>Displays the start frequency for the band.</p>	<p>BAND START FREQ XX.XXXXXX GHZ</p>
<p>Displays the stop frequency for the band.</p>	<p>BAND STOP FREQ XX.XXXXXX GHZ</p>
<p>Band functions</p>	<p>BAND FUNCTIONS</p>
<p>Calls menu OM2, which lets you edit system equations.</p>	<p>EDIT SYSTEM EQUATIONS</p>
<p>Indicates the band that will be stored and, within the parenthesis, indicates the bands that have been stored.</p>	<p>STORE BAND 1 BANDS STORED: (1 2 3 4 5)</p>
<p>Clears all the band definitions that may have been previously stored.</p>	<p>CLEAR ALL DEFINITIONS</p>
<p>Selects Multiple Source Control menu OM0.</p>	<p>SET MULTIPLE SOURCE STATE</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>PRESS <ENTER> TO SELECT</p>

Menu OM3, Edit System Equations

DESCRIPTION	MENU
<p>Selects source 1 frequency equation for change.</p> <p>Selects source 2 frequency equation for change.</p> <p>Selects receiver frequency equation for change.</p> <p>Toggles frequency term (F) in equation ON or OFF.</p> <p>Enables changing multiplier term of frequency equation via key pad or rotary knob.</p> <p>Enables changing divisor term frequency equation via key pad or rotary knob.</p> <p>Enables changing offset frequency term frequency equation via key pad or rotary knob.</p> <p>Recalls menu OM1.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>EDIT SYSTEM EQUATIONS</p> <p>EQUATION TO EDIT</p> <p>SOURCE 1</p> <p>SOURCE 2</p> <p>RECEIVER</p> <p>EQUATION SUMMARY</p> <p>C.W. ON (OFF)</p> <p>MULTIPLIER XX</p> <p>DIVISOR XX</p> <p>OFFSET FREQ XXX.XXXXXXXXXX GHZ</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT</p>

Menu OPTNS, Select Options

DESCRIPTION	MENU
<p>Calls menu TRIG, which lets you define trigger source.</p> <p>Calls menu ORP1, which lets you select an output for the rear panel AUX I/O connector.</p> <p>Calls menu DG1, which lets you implement system diagnostics.</p> <p>Calls menu OM1, which lets you use and define multiple sources.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>OPTIONS</p> <p>TRIGGERS</p> <p>REAR PANEL OUTPUT</p> <p>DIAGNOSTICS</p> <p>MULTIPLE SOURCE CONTROL</p> <p>PRESS <ENTER> TO SELECT</p>

Menu ORP1, Rear Panel Output Control

DESCRIPTION	MENU
<p>Turns the rear panel ANALOG OUT output on or off.</p> <p>Calls menu ORP2, which lets you select an output mode.</p>	<p>REAR PANEL OUTPUT CONTROL OUTPUT ON (OFF) SELECT MODE XXXXXXXXXXXX</p>
<p>Lets you enter a voltage for the start/lock frequency. Value will be a frequency start voltage if SELECT MODE choice is HORIZONTAL. It will be a phase-lock voltage if SELECT MODE choice is PHASELOCK.</p>	<p>START/LOCK a1 X.XXXX V</p>
<p>Lets you enter a voltage for the start/lock frequency. Value will be a frequency stop voltage if SELECT MODE choice is HORIZONTAL. It will be a phase-lock voltage if SELECT MODE choice is PHASELOCK.</p>	<p>STOP/LOCK a2 X.XXXX V</p>
<p>Shows fixed value for VERTICAL mode.</p> <p>Shows fixed value for VERTICAL mode.</p>	<p>VERTICAL SCALING RESOLUTION 1.000 V/DIV REFERENCE VALUE 0.000 V/DIV</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu ORP2, Select Output Mode

DESCRIPTION	MENU
<p>Pressing Enter key selects horizontal drive for external chart recorder connected to ANALOG OUT connector.</p> <p>Pressing Enter key selects vertical drive for external chart recorder connected to ANALOG OUT connector.</p> <p>Pressing Enter key selects phase-lock for external chart recorder connected to ANALOG OUT connector.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT MODE FOR OUTPUT</p> <p>HORIZONTAL</p> <p>VERTICAL</p> <p>PHASE LOCK</p> <p>PRESS <ENTER> TO SELECT</p>

Menu PC1, Select Polar Chart Mode

DESCRIPTION	MENU
<p>Selects Polar Chart Display to show magnitude and phase for the full frequency range—from start frequency to stop frequency.</p> <p>Selects Polar Chart Display to show magnitude information only for the phase data that falls between the start and stop angles selected below.</p> <p>Sets the start and stop angles for the data display.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT POLAR CHART MODE</p> <p>MAGNITUDE, PHASE</p> <p>MAGNITUDE, SWP POSITION</p> <p>SET SWEEP POSITION</p> <p>BOUNDARIES</p> <p>START ANGLE X.XX°</p> <p>STOP ANGLE X.XX°</p> <p>PRESS <ENTER> TO SELECT</p>

DESCRIPTION	MENU
<p>The plotter will plot everything displayed on the screen (data traces, graticule, menu text) when START PRINT is pressed.</p>	<p>PLOT OPTIONS FULL PLOT OPTIONS TO PLOT</p>
<p>The plot will include an information header if this option is on and START PRINT is pressed.</p>	<p>HEADER ON (OFF)</p>
<p>The plot will include the menu text if this option is on and START PRINT is pressed.</p>	<p>MENU ON (OFF)</p>
<p>The plot will include any limit lines if this option is on and START PRINT is pressed.</p>	<p>LIMITS ON (OFF)</p>
<p>The plot will include the graticule and annotation if this option is on and START PRINT is pressed. The plotter plots the graticule.</p>	<p>GRATICULE ON (OFF)</p>
<p>The plot will include the data and any marker that are present if this option is on and START PRINT is pressed. The plotter plots the data.</p>	<p>DATA TRACE(S) ON(OFF) AND MARKERS</p>
<p>Calls menu PL2, which lets you select the size and location of the plot.</p>	<p>PLOT SIZE PLOT FORMAT</p>
<p>Calls menu PL3, which lets you select pen colors for the various elements of the plot: graticule, data traces, menu text and header. Also lets you select the relative pen speed.</p>	<p>PEN COLORS PLOT ORIENTATION</p>
<p>Select the orientation for your plot, either portrait or landscape. Pressing the Enter key implements your menu selection.</p>	<p>PORTRAIT LANDSCAPE PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu PL1, Plot Options

Menu PL2, Select Plot Size

DESCRIPTION	MENU
Selects a full size (page) plot.	PLOT SIZE
	FULL SIZE
	-QUARTER SIZE PLOTS-
Selects a quarter-size plot, upper-left quadrant.	UPPER LEFT
Selects a quarter-size plot, upper-right quadrant.	UPPER RIGHT
Selects a quarter-size plot, lower-left quadrant.	LOWER LEFT
Selects a quarter-size plot, lower-right quadrant.	LOWER RIGHT
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT

Menu PL3, Select Pen Colors

DESCRIPTION	MENU
<p>Selects the color in which the data will be plotted. The number of the pen displays where the "n" is shown.</p>	<p>DATA PEN n</p>
<p>Selects the color in which the 2nd trace in a dual trace overlay plot will be plotted. The number of the pen displays where the "n" is shown.</p>	<p>DATA TRACE OVERLAY PEN n</p>
<p>Selects the color in which the graticule will be plotted. The number of the pen displays where the "n" is shown.</p>	<p>GRATICULE PEN n</p>
<p>Selects the color in which the markers and limits will be plotted. The number of the pen displays where the "n" is shown.</p>	<p>MARKERS AND LIMITS PEN n</p>
<p>Selects the color in which the header information will be plotted. The number of the pen displays where the "n" is shown.</p>	<p>HEADER PEN n</p>
<p>Selects the pen's speed as a percentage of the plotter's maximum speed. (Used to optimize plots on transparencies or with worn pens.)</p>	<p>PEN SPEED 100 PERCENT OF MAXIMUM</p>
<p>Recalls menu PL1.</p>	<p>PREVIOUS MENU</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>PRESS <ENTER> TO SELECT</p>

Menu PM1, Select Data Output Type

DESCRIPTION	MENU
Selects the printer as your output device.	SELECT OUTPUT DEVICE
Selects the printer as your output device.	PRINTER
Selects the plotter as your output device. Calls menu PM2, which lets you define the output header information shown on printer/plotter output. Calls menu PM4, which lets you store/recall tabular data to/from disk. Calls menu PM5.	PRINTER PLOTTER OUTPUT OPTIONS SET UP OUTPUT HEADERS DISK OPERATIONS PRINT OPTIONS PLOT OPTIONS
Calls menu PL1.	

Menu PM2, Data Output Headers

DESCRIPTION	MENU
<p>Selecting <1>displays menu GP5, which lets you select the letters and/or numbers in your model identifier.</p> <p>Selecting <1>displays menu GP5, which lets you select the letters and/or numbers in your Device I.D. identifier.</p> <p>Selecting <1>displays menu GP5, which lets you select the letters and/or numbers in the date.</p> <p>Selecting <1> displays menu GP5, which lets you select the letters identifying the operator.</p> <p>Selecting <1> displays menu GP5, which lets you enter a comment.</p> <p>Pressing the Enter key selects between menu selections. Pressing the CLEAR/RET LOC key lets you change the between ON and OFF states</p> <p>Pressing <1> lets you enter the desired label in menu GP5.</p>	<p>MODEL ON (OFF) XXXXXXXXXXXXXXX</p> <p>DEVICE ID ON (OFF) XXXXXXXXXXXXXXX</p> <p>DATE ON (OFF) XXXXXXXXXXXXXXX</p> <p>OPERATOR ON (OFF) XXXXXXXXXXXXXXX</p> <p>COMMENT ON (OFF) XXXXXXXXXXXXXXX</p> <p>PRESS <ENTER> TO TURN ON/OFF PRESS > 1 > TO CHANGE</p>

Menu PM3, Tabular Printer Output Format

DESCRIPTION	MENU
<p>Provides for printing marker data.</p> <p>Provides for printing sweep data. If you choose to print the sweep data, you can then choose how many points of the total sweep to print.</p> <p>Provides for printing header and page-break data.</p> <p>Outputs one point every X points. Use the rotary knob to select total number of points to output. Skipping points will reduce the total number of printed points.</p> <p>Returns to menu PM5.</p> <p>Pressing the Enter key selects between menu selections. Pressing the CLEAR/RET LOC key lets you change the between ON and OFF states.</p>	<p>TABULAR PRINTER OUTPUT FORMAT</p> <p>MARKER DATA ON (OFF)</p> <p>SWEEP DATA ON (OFF)</p> <p>HEADER AND ON (OFF) PAGE BREAKS</p> <p>PRINT DENSITY</p> <p>XXX PRINT PT(S) OUTPUT PRINTS 1 POINT EVERY XXX POINT(S)</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p> <p>TURN KNOB TO CHANGE NUMBER OF POINTS</p>

Menu PM3A, Graphical Printer Output Format

DESCRIPTION	MENU
<p>Provides for printing header data.</p> <p>Prints the full-screen data, including the menus.</p> <p>Prints only the graph or Smith chart.</p> <p>Returns to menu PM5.</p> <p>Pressing the Enter key selects between menu selections. Pressing the CLEAR/RET LOC key lets you change the between ON and OFF states.</p>	<p>GRAPHICAL PRINTER OUTPUT FORMAT</p> <p>HEADER ON (OFF)</p> <p>SCREEN AREA TO OUTPUT</p> <p>FULL SCREEN</p> <p>GRAPH ONLY</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu PM4, Disk Output Operations

DESCRIPTION	MENU
<p>Outputs tabular data to the disk and takes you to GP1-3 or DSK 11 for selection of a file name.</p> <p>Outputs tabular data to the disk and takes you to DSK 11 for selection of a file name.</p> <p>Brings up DSK9 for selection of a measurement data file to be output to the printer.</p> <p>Brings up DSK9 for selection of a measurement data file to be output to the printer.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>DISK OPERATIONS</p> <p>TABULAR DATA TO HARD DISK</p> <p>TABULAR DATA TO FLOPPY DISK</p> <p>TABULAR DATA FROM HARD DISK TO PRINTER</p> <p>TABULAR DATA FROM FLOPPY DISK TO PRINTER</p> <p>PRESS <ENTER> TO SELECT</p>

Menu PM5, Printer Type, Options

DESCRIPTION	MENU
<p>Select when HP QuietJet or HP ThinkJet is connected to 372XXA VNA.</p> <p>Select when HP Deskjet (BM) or HP LaserJet II and III series is connected to 372XXA VNA.</p> <p>Select when Epson FX, Epson MX, or Epson 9-pin compatible is connected to 372XXA VNA.</p> <p>Prints only the graph or Smith chart, including any and all data it contains.</p> <p>Prints a tabulation of the measured data</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>PRINT OPTIONS</p> <p>PRINTER TYPE</p> <p>THINKJET</p> <p>DESKJET</p> <p>EPSON</p> <p>FORMAT OF PRINTER OUTPUT</p> <p>GRAPHICAL DATA</p> <p>TABULAR DATA</p> <p>PRESS <ENTER> TO SELECT</p>

Menu RD1, Set Reference Delay

DESCRIPTION	MENU
<p>Automatically sets the reference delay so that the cumulative phase shift is zero. This selection unwinds the phase in a Smith chart display or reduces the phase revolutions in a rectilinear display to less than one. Electrically repositions the measurement reference plane, as displayed on the active channel, by a distance value entered in millimeters. This selection lets you compensate for the phase reversals inherent in a length of transmission line connected between the test set's Port 1 connector and the device-under-test (DUT). Electrically repositions the measurement reference plane by a distance value that corresponds to the time in milliseconds. Displays menu RD2, which lets you enter a value for the dielectric constant of your transmission line. Pressing the Enter key implements your menu selection.</p>	<p>SET REFERENCE PLANE AUTO DISTANCE XXX.XXXX mm TIME XXX.XXXX ms SET DIELECTRIC XXX PRESS <ENTER> TO SELECT</p>

Menu RD2, Set Dielectric Constant

DESCRIPTION	MENU
Calculates reference delay based on dielectric constant of air (1.000649).	SET DIELECTRIC CONSTANT
Calculates reference delay based on dielectric constant of polyethylene (2.26).	POLYETHYLENE (2.26)
Calculates reference delay based on the dielectric constant of teflon (2.1).	TEFLON (2.10)
Calculates reference delay based on the dielectric constant of microporous teflon (1.69).	MICROPOROUS TEFLON (1.69)
Calculates reference delay based on the value you enter. Terminate your entry using any terminator and select with the Enter key.	OTHER XXXX.XX
Pressing the Enter key implements your menu selection and returns you to the RD1 menu.	PRESS <ENTER> TO SELECT

Menu SR1, Save/Recall Front Panel Information

DESCRIPTION	MENU
<p>Displays menu SR2, which asks you to select a storage location—internal memory or disk.</p> <p>Pressing the Enter key implements your selection.</p>	<p>SAVE/RECALL FRONT PANEL AND CAL DATA SAVE RECALL PRESS <ENTER> TO SELECT FUNCTION</p>

Menu SP, Select S Parameter

DESCRIPTION	MENU
<p>Selects the S21 parameter to be displayed on the active channel. The parameter can be displayed in any of the available formats.</p> <p>Selects the S11 parameter to be displayed on the active channel. The parameter can be displayed in any of the available formats.</p> <p>Selects the S12 parameter to be displayed on the active channel. The parameter can be displayed in any of the available formats.</p> <p>Selects the S22 parameter to be displayed on the active channel. The parameter can be displayed in any of the available formats.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT PARAMETER S21, STANDARD FWD TRANS S11, STANDARD FWD REFL S12, STANDARD REV TRANS S22, STANDARD REV REFL PRESS <ENTER> TO SELECT</p>

Menu SR2, Recall or Save

DESCRIPTION	MENU
<p>Calls menu SR3, which lets you save the front panel setup into or recall it from internal memory.</p> <p>Calls menu DKS2 or DSK3, which let you recall or save to hard disk memory.</p> <p>Calls menu DKS2 or DSK3, which let you recall or save to floppy disk memory.</p> <p>Pressing the Enter key implements your selection. The menu remains on the screen until another menu is selected for display or until the Clear/Ret Loc key is pressed.</p>	<p>RECALL (OR SAVE)</p> <p>FRONT PANEL SETUP IN INTERNAL MEMORY</p> <p>FRONT PANEL SETUP AND CAL DATA ON HARD DISK</p> <p>FRONT PANEL SETUP AND CAL DATA ON FLOPPY DISK</p> <p>PRESS <ENTER> TO SELECT</p>

Menu SR3, Save to Internal memory

DESCRIPTION	MENU
<p>Causes the current front panel setup to be saved to memory location 1. If an asterisk appears beside the selection, the memory is full. Select a different memory location.</p> <p>Same as above, except the setup saves to memory location 2.</p> <p>Same as above, except the setup saves to memory location 3.</p> <p>Same as above, except the setup saves to memory location 4.</p> <p>Same as above, except the setup saves to memory location 5.</p> <p>Same as above, except the setup saves to memory location 6.</p> <p>Same as above, except the setup saves to memory location 7.</p> <p>Same as above, except the setup saves to memory location 8.</p> <p>Same as above, except the setup saves to memory location 9.</p> <p>Same as above, except the setup saves to memory location 10.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SAVE FRONT PANEL SETUP TO (RECALL FRONT PANEL SETUP FROM) INTERNAL MEMORY</p> <p>MEMORY 1*</p> <p>MEMORY 2</p> <p>MEMORY 3</p> <p>MEMORY 4*</p> <p>MEMORY 5*</p> <p>MEMORY 6</p> <p>MEMORY 7</p> <p>MEMORY 8</p> <p>MEMORY 9</p> <p>MEMORY 10</p> <p>PRESS <ENTER> TO SELECT OR USE KEYPAD</p>

Menu SSI or CAL_SSI, Set Scaling 1

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the log-magnitude graph. The value can be set in increments of 0.001 dB using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement on the log-magnitude graph. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Sets the resolution for the vertical axis of the active channel's displayed phase graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the phase graph. The value can be set in increments of 0.001 dB using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's phase measurement on the phase graph. This is the line about which the phase expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Sets the value by which the active channel's phase measurement is shifted on the phase graph. The shift can be set in increments of 0.01 degrees using the keypad or rotary knob. This is useful when phase data is near the 180 degree rollover value.</p> <p>On the CAL_SSI menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE></p> <p>-LOG MAG-</p> <p>RESOLUTION XX.XXX dB/DIV</p> <p>REFERENCE VALUE XXX.XXX dB</p> <p>REFERENCE LINE X</p> <p>-PHASE-</p> <p>RESOLUTION XX.XX °/DIV</p> <p>REFERENCE VALUE XXX.XX °</p> <p>REFERENCE LINE X</p> <p>PHASE SHIFT X.XX °</p> <p>PRESS <ENTER> TO RESUME CAL</p>

Menu SS2 or CAL_SS2, Set Scaling 2

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob. The center is fixed at 0 units; therefore, changing the resolution also changes the reference value and vice versa.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 U using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Calls menu PC1, which lets you define the phase angles between which your polar chart will display data.</p> <p>Pressing the Enter key implements your menu selection and resumes the calibration from where it left off, if in the calibration mode.</p>	<p>SET SCALING OR PRESS <AUTOSCALE> -LINEAR POLAR- RESOLUTION XX.XXX U/DIV REFERENCE VALUE XXX.XXX U FIXED REFERENCE LINE SELECT POLAR CHART MODE MAGNITUDE PHASE PRESS <ENTER> TO SELECT AND RESUME CAL</p>

Menu SS3Z/SS3Y or CAL_SS3Z/CAL_SS3Y, Set Scaling 3

DESCRIPTION	MENU
Scales an Impedance Smith chart for display in the active channel.	SET SCALING OR PRESS <AUTOSCALE>
Selects a normal Smith chart for display in the active channel.	IMPEDANCE (ADMITTANCE) SMITH CHART NORMAL SMITH (REFL = 1.0000000 FULL SCALE)
Selects a 10 dB expansion of the Smith chart being displayed for the active channel.	EXPAND 10 dB (REFL = 0.3162278 FULL SCALE)
Selects a 20 dB expansion of the Smith chart being displayed for the active channel.	EXPAND 20 dB (REFL = 0.1000000 FULL SCALE)
Selects a 30 dB expansion of the Smith chart being displayed for the active channel.	EXPAND 30 dB (REFL = 0.0316228 FULL SCALE)
Selects a 3 dB compression of the Smith chart being displayed for the active channel.	COMPRESS 3 dB (REFL = 1.425375 FULL SCALE)
On the CAL_SS3Z or Y menu, pressing the Enter key returns you to the calibration setup or sequence.	PRESS <ENTER> TO SELECT AND RESUME CAL

Menu SS4 or CAL_SS4, Set Scaling 4

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 dB using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement on the log-magnitude graph. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>On the CAL_SS4 menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE></p> <p>-LOG MAG-</p> <p>RESOLUTION XX.XXX dB/DIV</p> <p>REFERENCE VALUE XXX.XXX dB</p> <p>REFERENCE LINE X</p> <p>PRESS <ENTER> TO RESUME CAL</p>

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.01 ° using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Sets the value by which the active channel's phase measurement is shifted on the phase graph. The shift can be set in increments of 0.01 degrees using the keypad or rotary knob. This is useful when phase data is near the 180 degree rollover value.</p> <p>On the CAL_S55 menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE> -PHASE- RESOLUTION XX.XXX °/DIV REFERENCE VALUE XXX.XXX ° X REFERENCE LINE PHASE SHIFT X.XX ° PRESS <ENTER> TO RESUME CAL</p>

Menu S55 or CAL_S55, Set Scaling 5

Menu SS6 or CAL_SS6, Set Scaling 6

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 dB using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Calls menu PC1, which lets you define the phase angles between which your polar chart will display data.</p> <p>Pressing the Enter key implements your menu selection and resumes the calibration from where it left off, if in the calibration mode.</p>	<p>SET SCALING OR PRESS <AUTOSCALE></p> <p>-LOG POLAR-</p> <p>RESOLUTION XX.XXX dB/DIV</p> <p>REFERENCE VALUE XXX.XXX dB</p> <p>FIXED REFERENCE LINE</p> <p>SELECT POLAR CHART MODE MAGNITUDE PHASE</p> <p>PRESS <ENTER> TO SELECT AND RESUME CAL</p>

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.0001 s using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Sets and displays the percent of frequency span over which group delay is calculated.</p> <p>On the CAL_SST menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE> -GROUP DELAY- RESOLUTION XX.XXX fs/DIV REF VALUE XXX.XXX fs X REFERENCE LINE APERTURE X.X PERCENT OF SWEEP PRESS <ENTER> TO RESUME CAL</p>

Menu SST or CAL_SST, Set Scaling 7

Menu SS8 or CAL_SS8, Set Scaling 8

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 U using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>On the CAL_SS8 menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE></p> <p>-LINEAR MAG-</p> <p>RESOLUTION XX.XXX U/DIV</p> <p>REFERENCE VALUE XXX.XXX pU</p> <p>REFERENCE LINE X</p> <p>PRESS <ENTER> TO RESUME CAL</p>

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 U using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Sets the resolution for the vertical axis of the active channel's displayed phase graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value by which the active channel's phase measurement is offset on the phase graph. The offset can be set in increments of 0.01 degrees using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's phase measurement on the phase graph. This is the line about which the phase expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Sets the value by which the active channel's phase measurement is shifted on the phase graph. The shift can be set in increments of 0.01 degrees using the keypad or rotary knob. This is useful when phase data is near the 180 degree rollover value.</p> <p>On the CAL_SS9 menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE></p> <p>-LINEAR MAG-</p> <p>RESOLUTION XX.XXX U/DIV</p> <p>REFERENCE VALUE XXX.XXX pU</p> <p>REFERENCE LINE X</p> <p>-PHASE-</p> <p>RESOLUTION XX.XX °/DIV</p> <p>REF VALUE XXX.XX °</p> <p>REFERENCE LINE X</p> <p>PHASE SHIFT X.XX °</p> <p>PRESS <ENTER> TO RESUME CAL</p>

Menu SS9 or CAL_SS9, Set Scaling 9

Menu SS10 or CAL_SS10, Set Scaling 10

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 U using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>On the CAL_SS10 menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE> -REAL- RESOLUTION XX.XXX U/DIV REFERENCE VALUE XXX.XXX pU REFERENCE LINE X PRESS <ENTER> TO RESUME CAL</p>

Menu SS11 or CAL_SS11, Set Scaling II

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 U using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>On the CAL_SS11 menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE> -IMAGINARY- RESOLUTION XX.XXX U/DIV REFERENCE VALUE XXX.XXX pU REFERENCE LINE X PRESS <ENTER> TO RESUME CAL</p>

Menu SS12 or CAL_SS12, Set Scaling 12

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 U using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value by which the active channel's phase measurement is offset on the phase graph. The offset can be set in increments of 0.01 degrees using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's phase measurement on the phase graph. This is the line about which the phase expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>On the CAL_SS12 menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE></p> <p>-REAL-</p> <p>RESOLUTION XX.XXX U/DIV</p> <p>REFERENCE VALUE XXX.XXX pU</p> <p>REFERENCE LINE X</p> <p>-IMAGINARY-</p> <p>RESOLUTION XX.XX %/DIV</p> <p>REFERENCE VALUE XXX.XX °</p> <p>REFERENCE LINE X</p> <p>PRESS <ENTER> TO RESUME CAL</p>

Menu SS13 or CAL_SS13, Set Scaling 13

DESCRIPTION	MENU
<p>Sets the resolution for the vertical axis of the active channel's displayed graph. Resolution can be set incrementally using the keypad or rotary knob.</p> <p>Sets the value at the reference line for the active channel amplitude measurement on the displayed graph. The value can be set in increments of 0.001 U using the keypad or rotary knob.</p> <p>Sets the reference line for the active channel's amplitude measurement. This is the line about which the amplitude expands with different resolution values. The reference line can be set to any vertical division using the rotary knob.</p> <p>On the CAL_SS13 menu, pressing the Enter key returns you to the calibration setup or sequence.</p>	<p>SET SCALING OR PRESS <AUTOSCALE></p> <p>-SWR-</p> <p>RESOLUTION XX.XXX U /</p> <p>REFERENCE VALUE XXX.XXX U</p> <p>REFERENCE LINE X</p> <p>PRESS <ENTER> TO RESUME CAL</p>

Menu SU1, Sweep Setup 1

DESCRIPTION	MENU
<p>Enter the sweep-start frequency in GHz. The start frequency must be lower than the stop frequency.</p> <p>Enter the sweep-stop frequency in GHz. The stop frequency must be higher than the start frequency.</p> <p>Calls menu SU1_CENTER, which lets you set values for center frequency and span width.</p> <p>Displays the number of frequency points and the spacing between points for the start and stop frequencies selected above. The number of points shown provides the finest frequency resolution possible, based on your Data Points key menu selection.</p> <p>Move cursor here and press Enter to enable the CW mode. Enter CW frequency for measurements.</p> <p>Move cursor here and press Enter to set the start and stop frequencies (menu SU5) of the CW frequency (menu SU6) to the values of any marker</p> <p>Calls Discrete Fill Menu (menu DF1).</p> <p>Calls menu SU4, which lets you set the action of the HOLD key.</p> <p>Calls menu SU2, which lets you set the source power and the values for the attenuators in the 372XXA. It also provides entry into the Flat Test Port Power calibration.</p> <p>Pressing the ENTER key implements your menu selection.</p>	<p>SWEEP SETUP</p> <p>START XXX.XXXXXXXXXX GHz</p> <p>STOP XXX.XXXXXXXXXX GHz</p> <p>SET CENTER/SPAN</p> <p>XXX DATA POINTS XXX.XXXXXXXXXX GHz</p> <p>STEP SIZE</p> <p>C.W. MODE ON (OFF) XXX.XXXXXXXXXX GHz</p> <p>MARKER SWEEP</p> <p>DISCRETE FILL</p> <p>HOLD BUTTON FUNCTION</p> <p>TEST SIGNALS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu SU1_CENTER, Sweep Setup 1

DESCRIPTION	MENU
<p>Enter the center frequency in GHz.</p> <p>Enter the span frequency in GHz.</p> <p>Calls menu SU1, which lets you set values for start and stop frequencies. Displays the number of frequency points and the spacing between points for the center and span frequencies selected above. The number of points shown provides the finest frequency resolution possible, based on your Data Points key menu selection.</p> <p>Move cursor here and press Enter to enable the CW mode. Enter CW frequency for measurements.</p> <p>Move cursor here and press Enter to set the start and stop frequencies (menu SU5) of the CW frequency (menu SU6) to the values of any marker</p> <p>Calls Discrete Fill Menu (menu DF1).</p> <p>Calls menu SU4, which lets you set the action of the HOLD key.</p> <p>Calls menu SU2, which lets you set the source power and the values for the attenuators in the 372XXA. It also provides entry into the Flat Test Port Power calibration.</p> <p>Pressing the ENTER key implements your menu selection.</p>	<p>SWEEP SETUP</p> <p>CENTER XXX.XXXXXXXXXX GHz</p> <p>SPAN XXX.XXXXXXXXXX GHz</p> <p>SET START/STOP</p> <p>XXX DATA POINT(S) XXX.XXXXXXXXXX GHz</p> <p>STEPSIZE XXX.XXXXXXXXXX GHz</p> <p>C.W. MODE ON (OFF) XXX.XXXXXXXXXX GHz</p> <p>MARKER SWEEP</p> <p>DISCRETE FILL</p> <p>HOLD BUTTON</p> <p>TEST SIGNALS</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu SU2 or CAL_SU2, Sweep Setup 2

DESCRIPTION	MENU
<p>Enter the delta-power level for the Port 1 output in dB.</p> <p>Attenuates the microwave source power at port 1 from 0 to 70 dB, in 10 dB steps. The power is attenuated before being applied to Port 1 for a forward transmission or reflection test (S₂₁ or S₁₁, respectively).</p> <p>Displays the Port 1 power, in dBm.</p> <p>Attenuates from 0 to 40 dB (10 dB steps) the microwave power being input to Port 2 from the device-under-test (DUT).</p> <p>Calls menu SU8 or CAL_SU8, depending on whether valid Flat Test Port Power calibration data exists. Both of these menus provide selection control for the Flat Test Port Power feature.</p> <p>Enter the power level, in dBm, of the 2nd, external frequency source.</p> <p>Returns you to the previous menu. (RESUME CAL may be used instead of PREVIOUS MENU, when accessed during a calibration.)</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>TEST SIGNALS</p> <p>POWER CONTROL +XX.X dB 0 TO -15.0 dB)</p> <p>PORT 1 ATTN XX10 dB (0 - 70)</p> <p>PORT 1 POWER -XX.XX dBm</p> <p>PORT 2 ATTN XX10 dB (0-X0)</p> <p>CALIBRATE FOR FLATNESS (CAL EXISTS)</p> <p>FLATNESS ON(OFF) CORRECTION AT XX.X dBm</p> <p>SOURCE 2 POWER -XX.XX dBm</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT</p>

Menu SU3, Single-Point Measurement Setup

DESCRIPTION	MENU
<p>Enter the measurement frequency in GHz for continuous wave (CW) operation.</p> <p>Calls menu SU4, which lets you set the action of the HOLD key.</p> <p>Calls menu SU2, which lets you set values for the source power and attenuators. It also provides entry into the Flat Test Power calibration.</p> <p>Move cursor here and press Enter to return to the F1-F2 sweep mode (Menu SU1).</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SINGLE POINT MEASUREMENT SETUP</p> <p>C.W. FREQ XXX.XXXXXXXXXX GHZ</p> <p>HOLD BUTTON FUNCTION</p> <p>TEST SIGNALS</p> <p>RETURN TO SWEEP MODE</p> <p>PRESS <ENTER> TO SELECT</p>

Menu SU4, Select Function for Hold Button

DESCRIPTION	MENU
<p>Causes the hold key (button) to stop and start the sweep.</p> <p>Causes the hold key to stop and restart the sweep.</p> <p>Causes the hold key to trigger a single sweep and hold when finished. (Two sweeps, one from Port 1 to 2 and another from Port 2 to 1, are accomplished for a 12-Term measurement.)</p> <p>Select bias to be on or off (test sets having bias input only) while system is in hold.</p> <p>Selects RF to be on or off while system is in hold.</p> <p>When on, a default reset places the system in hold with RF and bias turned off. This choice is initialized to OFF when the software version changes or after a Default Program key press, so that the system comes up in the sweep mode.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT FUNCTION FOR HOLD BUTTON</p> <p>HOLD/CONTINUE</p> <p>HOLD/RESTART</p> <p>SINGLE SWEEP AND HOLD</p> <p>BIAS/RF HOLD CONDITIONS</p> <p>BIAS ON (OFF)</p> <p>RF ON (OFF)</p> <p>DUT/AUT ON (OFF) PROTECTION DEFAULT RESET TURNS ON HOLD WITH BIAS/RF TURNED OFF</p> <p>PRESS <ENTER> TO SELECT</p>

Menu SU6, Frequency Marker C.W.

DESCRIPTION	MENU
<p>Pressing a number on the keypad causes the associated marker to be the C.W. frequency.</p> <p>Use the keypad to select markers 1, 2, 3, 4, 5, or 6.</p>	<p>FREQUENCY MARKER C.W.</p> <p>C.W. FREQ MARKER (n) XXX.XXXXXXXXXX GHZ</p> <p>USE KEYPAD TO SELECT MARKER (1-6)</p>

Menu SU5, Frequency Marker Sweep

DESCRIPTION	MENU
<p>Pressing a number on the keypad causes the associated marker to be the start frequency of the sweep.</p> <p>Pressing a number on the keypad causes the associated marker to be the stop frequency of the sweep.</p> <p>Use the keypad to select markers 1, 2, 3, 4, 5, or 6.</p>	<p>FREQUENCY MARKER SWEEP</p> <p>START SWEEP MARKER (n) XXX.XXXXXXXXXX GHZ</p> <p>STOP SWEEP MARKER (n) XXX.XXXXXXXXXX GHZ</p> <p>USE KEYPAD TO SELECT MARKER (1-6)</p>

Menu SU8 or CAL_SU8, Calibrate For Flat Test Port Power

DESCRIPTION	MENU
<p>Select the number of times (1 – 5) that the power point for each frequency is to be measured (swept).</p> <p>Displays the number of power points (0 – 50) to be skipped during the power sweep. The points not measured are interpolated to provide a flat sweep.</p> <p>Begins the calibration. If calibration is successful, you are returned to menu SU8. If the calibration unsuccessful due to a fatal error (Source or power meter inoperable or not connected), this menu remains displayed. At any time, you can abort the calibration by pressing the DEFAULT PROGRAM or CLEAR/RET LOC keys. All other keys are locked out.</p> <p>Returns you to previous menu.</p> <p>Pressing the Enter key implements your menu selection or turns the function on/off.</p>	<p>CALIBRATE FOR FLAT PORT POWER FORWARD DIRECTION ONLY NUMBER OF POWER SWEEPS X XXX POINTS MEASURE 1 PWR POINT EVERY XX POINT(S) START FLAT POWER CALIBRATION PREVIOUS MENU PRESS <ENTER> TO SELECT OR SWITCH TURN KNOB TO CHANGE NUMBER OF POINTS</p>

Text Associated With Flat Power Calibration Menu SUs

- 3. MEASURE 1 POWER POINT FOR EVERY DATA POINT.
- 2. SELECT AT LEAST 2 POWER SWEEP READINGS.
- 1. SET THE POWER CONTROL TO MAXIMUM POWER.

-FOR BEST RESULTS-



- 4. SELECT <START FLAT POWER CALIBRATION>.
- 3. CONNECT THE POWER METER TO THE DEDICATED GPIB INTERFACE BUS AND THE POWER SENSOR TO THE TEST PORT.
- 2. CREATE AND ACTIVATE THE POWER METER'S CAL FACTOR LIST FOR THE POWER SENSOR BEING USED.
- 1. PRESET, ZERO, AND CALIBRATE THE POWER METER.

-INSTRUCTIONS-

FLAT POWER CALIBRATION ADJUSTS THE SOURCE OUTPUT POWER AT EACH MEASUREMENT POINT ACROSS A FREQUENCY SPAN TO PROVIDE A CONSTANT POWER LEVEL AT THE SELECTED TEST PORT. (FORWARD DIRECTION ONLY)

-FLAT POWER CALIBRATION-

Menu SU9, Number of Data Points

DESCRIPTION	MENU
Selects measurement data points to be 1601.	1601 MAX PTS'
Selects measurement data points to be 801.	801 MAX PTS'
Selects measurement data points to be 401.	401 MAX PTS'
Selects measurement data points to be 201.	201 MAX PTS'
Selects measurement data points to be 101.	101 MAX PTS'
Selects measurement data points to be 51.	51 MAX PTS'
Pressing the Enter key implements you selection.	PRESS <ENTER> TO SELECT

Menu SU9A, Number of Data Points 2

MENU	DESCRIPTION
NUMBER OF DATA POINTS POINTS DRAWN IN C.W. XXXX POINT(S)	Displays the number of data point, when in the CW mode. This number can be between 1 and 1601.

Menu TD1, Domain (Frequency/Display)

DESCRIPTION	MENU
<p>Displays the data in normal frequency domain format.</p>	<p>FREQUENCY</p>
<p>Displays the data in the frequency domain after a specific time range has been sampled by the gate function.</p>	<p>FREQUENCY WITH TIME GATE</p>
<p>Displays the data in the time (distance) domain, using true lowpass processing. Data must be taken using a harmonic series calibration and sweep in order to use this mode.</p>	<p>TIME LOWPASS MODE</p>
<p>Displays the data in the time (distance) domain using bandpass processing. Any data sweep range using normal calibration can be used.</p>	<p>TIME BANDPASS MODE</p>
<p>Switches the mode of display between time and distance. This does not affect the actual displayed data, but only the annotation.</p>	<p>DISPLAY TIME/DISTANCE</p>
<p>Call a menu that lets you set range and other display parameters.</p>	<p>SET RANGE</p>
<p>Calls a menu that lets you set gate parameters.</p>	<p>SET GATE</p>
<p>Switches the gate on or off each time Enter is pressed.</p>	<p>GATE ON/OFF/DISP</p>
<p>Displays an informational help menu.</p>	<p>HELP</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>PRESS <ENTER> TO SELECT OR SWITCH</p>

Menu TD2_LP_TIME, Lowpass Time Domain Setup

DESCRIPTION	MENU
<p>Sets the start time of the display.</p> <p>Sets the stop time of the display..</p> <p>Sets the center time of the display.</p> <p>Sets the span (Stop - Start) of the display.</p> <p>Takes you to a menu that lets you set the display to a range determined by two of the markers.</p> <p>Switches between Impulse and Step response each time Enter is pressed.</p> <p>Takes you to a menu that contains additional selections for display setup.</p>	<p>LOWPASS TIME</p> <p>DOMAIN SETUP</p> <p>START</p> <p>XXX.XXX ps</p> <p>STOP</p> <p>XXX.XXX ps</p> <p>CENTER</p> <p>XXX.XXX ps</p> <p>SPAN</p> <p>XXX.XXX ps</p> <p>MARKER RANGE</p> <p>RESPONSE</p> <p>IMPULSE/STEP</p> <p>MORE</p>

Menu TD2_LP_DIST, Lowpass Distance Display Setup

DESCRIPTION	MENU
Sets the start time of the display.	START XXX.XXX mm
Sets the stop time of the display.	STOP XXX.XXX mm
Sets the center time of the display.	CENTER XXX.XXX mm
Sets the span (Stop - Start) of the display.	SPAN XXX.XXX mm
Takes you to a menu that lets you set the display to a range determined by two of the markers.	MARKER RANGE
Switches between Impulse and Step response each time Enter is pressed.	RESPONSE IMPULSE/STEP
Takes you to a menu that contains additional selections for display setup.	MORE
Indicates the relative velocity of light, as set by the dielectric constant in menu RD2.	RELATIVE VELOCITY X.X
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT

Menu TD2_BP_TIME, Bandpass Time Domain Setup

DESCRIPTION	MENU
Sets the start time of the display.	BANDPASS TIME DOMAIN SETUP
Sets the stop time of the display.	START XXX.XXX ps
Sets the center time of the display.	STOP XXX.XXX ps
Sets the span (Stop - Start) of the display.	CENTER XXX.XXX ps
Takes you to a menu that lets you set the display to a range determined by two of the markers.	SPAN XXX.XXX ps
Switches Phasor Impulse processing on or off each time Enter is pressed.	MARKER RANGE
Displays an informational help menu.	PHASOR ON/OFF IMPULSE
Takes you to a menu that contains additional selections for display setup.	HELP - PHASOR IMPULSE
Pressing the Enter key implements your menu selection.	MORE PRESS <ENTER> TO SELECT OR TURN ON/OFF

Menu TD2_BP_DIST, Bandpass Distance Display Setup

DESCRIPTION	MENU
Sets the start time of the display.	START XXX.XXX mm
Sets the stop time of the display.	STOP XXX.XXX mm
Sets the center time of the display.	CENTER XXX.XXX mm
Sets the span (Stop - Start) of the display.	SPAN XXX.XXX mm
Takes you to a menu that lets you set the display to a range determined by two of the markers.	MARKER RANGE
Switches Phasor Impulse processing on or off each time Enter is pressed.	PHASOR ON/OFF IMPULSE
Displays an informational help menu.	HELP - PHASOR IMPULSE
Takes you to a menu that contains additional selections for display setup.	MORE
Indicates the relative velocity of light, as set by the dielectric constant in menu RD2.	RELATIVE VELOCITY X X
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT OR TURN ON/OFF

Menu TD3_LP, Lowpass Time Domain Setup

DESCRIPTION	MENU
<p>Takes you to a menu that lets you change the window type.</p> <p>Takes you to a menu that lets you set the gate.</p> <p>Takes you to a menu that lets you set the D.C. term for lowpass processing.</p> <p>Returns you to the previous menu.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>LOWPASS TIME DOMAIN SETUP WINDOW SHAPE NOMINAL SET GATE D.C. TERM XXXXX XXXXXXXXXXXX PREVIOUS MENU PRESS <ENTER> TO SELECT</p>

Menu TD3_BP, Bandpass Time Domain Setup

DESCRIPTION	MENU
<p>Takes you to a menu that lets you change the window type.</p> <p>Takes you to a menu that lets you set the gate parameters.</p> <p>Returns you to the previous menu.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>BANDPASS TIME DOMAIN SETUP WINDOW SHAPE NOMINAL SET GATE PREVIOUS MENU PRESS <ENTER> TO SELECT</p>

Menu TD4_TIME & TD4_DIST, Gate (Distance/Time)

DESCRIPTION	MENU
<p>Sets the start time of the gate.</p> <p>Sets the stop time of the gate.</p> <p>Sets the center time of the gate.</p> <p>Sets the span (Stop - Start) of the gate.</p> <p>Takes you to a menu that lets you set the shape of the gate.</p> <p>Switches the gate on or off each time Enter is pressed.</p> <p>Takes you back to menu TD2_XX_XXXX (LP_TIME, LP_DIST, BP_TIME, BP_DIST), depending on the type of measurement you selected in menu TD1.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>GATE</p> <p>START XXX.XXX xx</p> <p>STOP XXX.XXX xx</p> <p>CENTER XXX.XXX xx</p> <p>SPAN XXX.XXX xx</p> <p>SET SHAPE XXXXXXXXXX</p> <p>GATE ON/OFF/DISP</p> <p>SET RANGE</p> <p>PRESS <ENTER> TO SELECT</p>

Menu TD5_GATE, Shape

DESCRIPTION	MENU
Selects a Rectangular (one-term) shape. Selects a two-term Hamming shape. Selects a three-term Blackman-Harris shape. Selects a four-term Blackman-Harris shape. Displays an informational help menu. Pressing the Enter key implements your menu selection.	SELECT WINDOW SHAPE RECTANGULAR NOMINAL LOW SIDELobe MIN SIDELobe HELP PRESS <ENTER> TO SELECT

Menu TD5_WINDOW, Shape

DESCRIPTION	MENU
Selects a Rectangular (one-term) shape. Selects a two-term Hamming shape. Selects a three-term Blackman-Harris shape. Selects a four-term Blackman-Harris shape. Displays an informational help menu. Pressing the Enter key implements your menu selection.	SELECT WINDOW SHAPE RECTANGULAR NOMINAL LOW SIDELobe MIN SIDELobe HELP PRESS <ENTER> TO SELECT

Menu TD6, Set D.C. Term for Low Pass Processing

DESCRIPTION	MENU
<p>Since it is impossible to measure the true D.C. term required for lowpass processing, a value must be estimated. This menu allows a choice between five different selections for this value.</p> <p>Sets the D.C. term to a value determined by extrapolating the data points near the zero frequency.</p> <p>Sets the D.C. term to the characteristic impedance of the transmission medium (Z_0).</p> <p>Sets the D.C. term to correspond to an open circuit.</p> <p>Sets the D.C. term to correspond to a short circuit.</p> <p>Sets the D.C. term to the value entered.</p> <p>Returns you to the previous menu.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SET D.C. TERM FOR LOWPASS PROCESSING</p> <p>AUTO EXTRAPOLATE</p> <p>LINE IMPEDANCE</p> <p>OPEN</p> <p>SHORT</p> <p>OTHER XXX.XXX (REFLECTION COEFFICIENT X.XXX pV)</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT</p>

DESCRIPTION	MENU
<p>Sets the start time to the value of the selected marker.</p> <p>Sets the stop time to the value of the selected marker.</p> <p>Returns the display to the original time range that was in effect before the marker range was selected.</p> <p>Returns you to the previous menu.</p> <p>Select marker number from keypad.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>MARKER SWEEP</p> <p>START TIME MARKER () XXX.XXX ns</p> <p>STOP TIME MARKER () XXX.XXX ns</p> <p>RESTORE ORIGINAL RANGE</p> <p>PREVIOUS MENU</p> <p>USE KEYPAD TO CHOOSE MARKER (1 - 6)</p> <p>PRESS <ENTER> TO SELECT</p>

Menu TD7_TIME, Time Marker Sweep.

DESCRIPTION	MENU
Sets the start time to the value of the selected marker.	DISTANCE MARKER SWEEP START DIST MARKER () XX.XXXX cm
Sets the stop time to the value of the selected marker.	STOP DIST MARKER () X.XXXX m
Returns the display to the original time range that was in effect before the marker range was selected.	RESTORE ORIGINAL RANGE
Returns you to the previous menu.	PREVIOUS MENU
Select marker number from keypad.	USE KEYPAD TO CHOOSE MARKER (1 - 6)
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT

Menu TD7_DIST, Distance Marker Range

Menu TRIG, Triggers Measurement

DESCRIPTION	MENU
<p>Internally triggers a point-by-point measurement. Choosing this option always turns AUTOMATIC I.F. CALIBRATION off.</p> <p>Provides for externally triggering a point-by-point measurement via the rear panel External Trigger connector. Choosing this option always turns AUTOMATIC I.F. CALIBRATION off.</p> <p>Turns on or off the timer for I.F. calibration. The timer automatically triggers an I.F. calibration at regular intervals for internal hardware calibrations. It can be set on or off when in either INTERNAL or EXTERNAL trigger measurement mode.</p> <p>Immediately triggers an I.F. calibration, which calibrates the internal hardware. A "CALIBRATING I.F.:" message is displayed.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>TRIGGERS MEASUREMENT</p> <p>INTERNAL</p> <p>EXTERNAL</p> <p>I.F. CALIBRATION</p> <p>AUTOMATIC ON (OFF)</p> <p>I.F. CAL</p> <p>TRIGGER</p> <p>I.F. CAL</p> <p>PRESS <ENTER> TO SELECT OR TURN ON/OFF</p>

Menu U1, Utility Menu

DESCRIPTION	MENU
<p>Calls menu GP7, which displays the current GPIB addresses of the various dedicated instruments.</p> <p>Calls menu U2, which lets you display the various instrument state parameters.</p> <p>Calls menu DSK1-FD, which lets you select between several disk utilities.</p> <p>Calls menu U3, which lets you select between several calibration--component utilities.</p> <p>Calls menu U5, which lets you configure the screen colors.</p> <p>Turns data drawing on or off for all channels.</p> <p>Blanks all frequency-identifier information from the 372XXA displays, if such information is presently being displayed. Hides the frequency value with X's, such as XXXXXXXXXXXX GHz.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>SELECT UTILITY</p> <p>FUNCTION OPTIONS</p> <p>GPIB ADDRESSES</p> <p>DISPLAY</p> <p>INSTRUMENT</p> <p>STATE PARAMS</p> <p>GENERAL DISK</p> <p>UTILITIES</p> <p>CALIBRATION</p> <p>COMPONENT</p> <p>UTILITIES</p> <p>COLOR</p> <p>CONFIGURATION</p> <p>DATA ON (OFF)</p> <p>DRAWING</p> <p>BLANKING</p> <p>FREQUENCY</p> <p>INFORMATION</p> <p>PRESS <ENTER></p> <p>TO SELECT</p> <p>OR TURN ON/OFF</p>

Menu U2, Display Instrument State

DESCRIPTION	MENU
<p>Displays all of the system parameters (Readout Text for U2, on the following pages).</p> <p>Displays the calibration parameters.</p> <p>Displays the global operating parameters.</p> <p>Displays the Channel 1-2 operating parameters.</p> <p>Displays the Channel 3-4 operating parameters.</p> <p>Alternately displays Readout Text U3 a thru e.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>DISPLAY INSTRUMENT STATE PARAMETERS</p> <p>SYSTEM</p> <p>CALIBRATION</p> <p>OPERATING</p> <p>CHANNEL 1 & 2</p> <p>CHANNEL 3 & 4</p> <p>NEXT PARAM PAGE</p> <p>PRESS <ENTER> TO SELECT</p>

Readout Text U2, Global Operating Parameters

Parameter	Display Format
Number of Points	xx.x dB
Power Control	xx.x dB
Port 1 Attenuation	xx.x dB
Port 2 Attenuation	xx.x dB
Source 2 Power	xx.x dB
Reference Impedance	xx.xxx Ω
Averaging	xxx Meas. per point
Smoothing	Off/On
	x.x percent of sweep
	Off/On

Readout Text U2, Channel Parameters

Parameter	Display Format
Number of Points	xx.x dB
Power Control	xx.x dB
Port 1 Attenuation	xx.x dB
Port 2 Attenuation	xx.x dB
Source 2 Power	xx.x dB
Reference Impedance	xx.xxx Ω
Averaging	xxx Meas. per point
Smoothing	Off/On
	x.x percent of sweep
	Off/On

Readout Text U2, System Parameters

Parameter	Display Format
WILTRON Model	xxxxxxxxxx
Serial Number	xxx
Software Version	xxxxxxxxxx
Options	xxxxxxxxxx
IEEE 488.2 GPIB Interface	xx
Address	xx
Enable Registers	xx
Service Request	xx
Standard Event Status	xxxxxx
Parallel Poll	xxxxxx
Extended Event Status	xxxxxx
Limits Testing Status	xxxxxx
Dedicated GPIB Interface	xxxxxx
External Source Address	xxxxxx
Plotter Address	xxxxxx
Power Meter Address	xxxxxx
Frequency Counter	xxxxxx
Measurement Trigger	xxxxxx
Automatic I.F. Calibration	xxxxxx
Diagnostic Mode	xxx
Troubleshooting	xxxxxxxxxxxxxx
Receiver Mode	xxx
Search for Lock	xxx

Readout Text U2, Calibration Parameters

Parameter	Display Format
Cal Method	xxxxxxx
Line Type Medium	xxxxxxx
Cal Type	xxxxxxx
Number of Points	xxxxxxx
Start Freq	xxxxxxx
Stop Freq	xxxxxxx
Power Control	xx.x dB
Port 1 Attenuator	xx.x dB
Port 2 Attenuator	xx.x dB
Source 2 Power	xx.x dB
Load Type	xxxxxxx
Through Offset	xxxxxxx

Menu U3, Calibration Component Utilities

DESCRIPTION	MENU
<p>Reads into memory the coefficient data from the calibration-components disk supplied with the calibration kits.</p> <p>Calls menu U4 and U4A, which lets you display the connector information for the various coaxial connectors supported.</p> <p>Displays the waveguide information loaded from the floppy diskette.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>CALIBRATION COMPONENT UTILITIES</p> <p>INSTALL KIT INFORMATION FROM FLOPPY DISK</p> <p>DISPLAY COAXIAL INFORMATION</p> <p>DISPLAY WAVEGUIDE INFORMATION</p> <p>PRESS <ENTER> TO SELECT</p>

Menu U4, Display Installed Calibration Components Information 1

DESCRIPTION	MENU
<p>This menu lets you view coefficient data on components. The data appears in the display area of the screen (See readout text on next page).</p>	<p>DISPLAY INSTALLED TEST PORT CONNECTOR INFORMATION</p>
<p>Select to display coefficient data for the SMA male components.</p>	<p>SMA (M)</p>
<p>Select to display coefficient data for the SMA female components.</p>	<p>SMA (F)</p>
<p>Select to display coefficient data for the K Connector™ male components.</p>	<p>K – CONN (M)</p>
<p>Select to display coefficient data for the K Connector female male components.</p>	<p>K – CONN (F)</p>
<p>Select to display coefficient data for the Type N male components.</p>	<p>TYPE N (M)</p>
<p>Select to display coefficient data for the Type N female components.</p>	<p>TYPE N (F)</p>
<p>Select to display coefficient data for the GPC-3.5 male components.</p>	<p>GPC - 3.5 (M)</p>
<p>Select to display coefficient data for the GPC-3.5 female components.</p>	<p>GPC - 3.5 (F)</p>
<p>Select to display coefficient data for the sexless GPC-7 components.</p>	<p>GPC - 7</p>
<p>Cycles through selections SMA (M) to GPC 7.</p>	<p>NEXT CONNECTOR</p>
<p>Calls up menu U4A and lets you select more connectors.</p>	<p>MORE CONNECTORS</p>
<p>Displays menu U3.</p>	<p>PREVIOUS MENU</p>
<p>Pressing the Enter key implements your menu selection.</p>	<p>PRESS <ENTER> TO SELECT</p>

Menu U4A, Display Installed Calibration Components Information 2

DESCRIPTION	MENU
<p>This menu lets you view coefficient data for connectors. The data appears in the display area of the screen.</p> <p>Select to display coefficient data for the V Connector™ male components.</p> <p>Select to display coefficient data for the V Connector female components.</p> <p>Select to display coefficient data for the TNC male components.</p> <p>Select to display coefficient data for the TNC female male components.</p> <p>Select to display coefficient data for the 2.4 mm male components.</p> <p>Select to display coefficient data for the 2.4 mm female components.</p> <p>Cycles through selections V Connector to 2.4 mm (F).</p> <p>Calls up menu U4A and lets you select more connectors.</p> <p>Returns you to menu U3.</p> <p>Pressing the Enter key implements your menu selection.</p>	<p>DISPLAY INSTALLED CALIBRATION COMPONENT INFORMATION</p> <p>V-CONN (M)</p> <p>V-CONN (M)</p> <p>TNC (M)</p> <p>TNC (F)</p> <p>2.4 mm (M)</p> <p>2.4 mm (F)</p> <p>NEXT CONNECTOR</p> <p>MORE CONNECTORS</p> <p>PREVIOUS MENU</p> <p>PRESS <ENTER> TO SELECT</p>

Menu U5, Color Configuration

DESCRIPTION	MENU
Sets the color for the data drawn on the CRT. Use rotary knob to cycle between the available colors. Default color is shown.	DATA 10 RED
Sets the color for the overlay data drawn on the CRT. Use rotary knob to cycle between the available colors. Default color is shown.	OVERLAY DATA 15 YELLOW
Sets the color for the memory data drawn on the CRT. Use rotary knob to cycle between the available colors. Default color is shown.	MEMORY DATA 24 GREEN
Sets the color for the markers and limits drawn on the CRT. Use rotary knob to cycle between the available colors. Default color is shown.	MARKERS AND LIMITS 32 CYAN
Sets the color for the CRT graticule. Use rotary knob to cycle between the available colors. Default color is shown.	GRATICULE 24 GREEN
Sets the color for the annotation and menu text. Use rotary knob to cycle between the available colors. Default color is shown.	ANNOTATION AND MENU TEXT 24 GREEN
Sets the color for the menu headers and information. Use rotary knob to cycle between the available colors. Default color is shown.	MENU HEADERS (TTLES & INFO) 32 CYAN
Resets colors to the default values.	RESET COLORS
Pressing the Enter key implements your menu selection.	PRESS <ENTER> TO SELECT

**APPENDIX B
MODEL 372XXA VECTOR NETWORK ANALYZER
REAR PANEL CONNECTORS**

B-1 INTRODUCTION

This appendix provides descriptions and pinout diagrams for the 372XXA rear panel connectors.

B-2 372XXA REAR PANEL


The 372XXA rear panel connectors are described on page B-2 and B-3.

B-3 CONNECTOR PINOUT DIAGRAMS

Figures B-1 through B-4 provide pinout diagrams for the rear panel connectors.

- 1 CRT Degauss:** Momentary-on pushbutton that degausses the internal color monitor. It has no effect on an external monitor.
- 2 VGA OUT:** 15-pin connector provides VGA output of 372XXA video display. Figure B-4 provides a pinout diagram.
- 3 CRT Brt:** Adjustment for CRT brightness. Counterclockwise rotation increases brightness.
- 4 External I/O:** Provide I/O access for Channel 1 through 4 limit and Port 1 and 2 bias voltages. Figure B-3 provides a pinout diagram.
- 5 Bias Fuses, Port 1:** Fuse, 0.5A, 3AG, 250V, provides protection for external bias being applied to the active device connected to test port 1 without disturbing the accuracy of the 372XXA measurement.
- 6 Bias Fuses, Port 2:** Fuse, 0.5A, 3AG, 250V, provides protection for external bias being applied to the active device connected to test port 2 without disturbing the accuracy of the 372XXA measurement.

- 7 Reference Extension, RA In to RA Out:** Loop allows external reference to be used as a receiver. This provides for custom-defined user parameters with any combination of channels.
- 8 Line Voltage Input:** Three-prong ac plug that provides input for the input-line power. The line voltage must be between 85 and 264 Vac rms, 43 to 63 Hz.
- 9 Reference Extension, RB In to RB Out:** Loop allows external reference to be used as a receiver. This provides for custom-defined user parameters with any combination of channels.
- 10 Line Fuse:** 3 AG fuse cartridge that protects for an input overcurrent condition. The fuse is slow blow, 8A, 250V.



REAR PANEL CONNECTORS

MODEL 372XXA VECTOR NETWORK ANALYZER

REAR PANEL CONNECTORS

MODEL 372XXA VECTOR NETWORK ANALYZER

- 11 External Trigger:** Allows an external signal to synchronize the 372XXA measurements; $\pm 1V$ trigger.
- 12 External Anlg Out:** Provides an up-to- $\pm 10V$ signal for use in driving an external plotter or antenna (CW draw).
- 13 10 MHz Ref Out 0dBm 50 Ω :** BNC connector that allows the internal 10 MHz reference to be used to phase lock an external counter or other measuring instrument. Level is typically 0 dBm into 50 Ω impedance.
- 14 10 MHz Ref In 0dBm 50 Ω :** BNC connector that allows an external 10 MHz signal (-5 to $+5$ dBm) to be used as the frequency reference for phase locking the source frequency. 50 Ω impedance.
- 15 External SCSI-2 Hard Disk Drive:** Provides for connecting an external SCSI-2 hard disk drive.
- 16 Ext Anlg In:** Provides input to the A5 A/D Converter PCB. BNC connector allows an external dc voltage
- to be measured by the internal analog-to-digital converter circuit. Intended for use in troubleshooting by a qualified service technician.
- 17 Ethernet:** Provides for connecting the 372XXA to a network using an Ethernet-type connector.
- 18 Printer Out:** 36-pin connector that provides a parallel interface to the companion printer. Figure B-2 describes the signal lines and shows the connector pinout.
- 19 Dedicated GPIB:** IEEE 488 standard 24-pin connector that allows the 372XXA to remotely control a 2nd frequency source, an external plotter, analyzer, or other peripheral. Figure B-1 provides a pinout diagram.
- 20 IEEE 488.2 GPIB:** IEEE 488 standard 24-pin connector that provides for remotely controlling the 372XXA from an external computer/controller via the IEEE-488 bus (GPIB). Figure B-1 provides a pinout diagram.

Figure B-1. Pinout Diagram, GPIB and Dedicated GPIB Connectors

PIN	NAME	DESCRIPTION
1-4	DIO 1 thru DIO 4	Data Input/Output. Bits are HIGH with the data is logical 0 and LOW when the data is logical 1.
5	EOL	End Or Identify. A low-true state indicates that the last byte of a multibyte message has been placed on the line.
6	DAV	Data Valid. A low-true state indicates that the talker has (1) sensed that NRFD is LOW, (2) placed a byte of data on the bus, and (3) waited an appropriate length of time for the data to settle.
7	NRFD	Not Ready For Data. A high-true state indicates that valid data has not yet been accepted by a listener.
8	NDAC	Not Data Accepted. A high-false state indicates that the current data byte has been accepted for internal processing by a listener.
9	IFC	Interface Clear. A low-true state places all bus instruments in a known state—such as, unaddressed to talk, unaddressed to listen, and service request idle.
10	SRQ	Service Request. A low-true state indicates that a bus instrument needs service from the controller.
11	ATN	Attention. A low-true state enables the controller to respond to both its own listen/talk address and to appropriate interface messages — such as, device clear and serial poll.
12	Shield	Chassis ground.
13-16	DIO 5 thru DIO 8	Data Input/Output. Bits are high with the data is logical 0 and LOW when the data is logical 1.
17	REN	Remote Enable. A low-true state enables bus instruments to be operated remotely; when addressed.
18-24	GND	Logic ground.

Pinout Diagram




Figure B-2. Pinout Diagram, Printer Connector (1 of 2)

PIN	NAME	DESCRIPTION
1	<u>STROBE</u>	Printer Strobe. A low-true pulse that tells the printer valid data has been placed on the bus.
2-9	DATA1 thru DATA8	Data Lines. Bits are HIGH when the data is logical 1 and LOW when the data is a logical 0.
10	<u>ACK NLG</u>	Printer Acknowledgment. A low-true (it varies from printer to printer) pulse sent back by the printer to acknowledge that the data has been accepted and the printer is ready to accept more data.
11	BUSY	Printer Busy. High-true level sent by the printer to indicate that it is not available. This line is HIGH at the following times: (1) During data entry. (2) While printing. (3) When off-line. (4) When a printer-error has been signaled.
12	PE	Printer Error. High-true level sent by the printer to indicate that it is out of paper.
13	SLOT	Select. A high-true logic level.
14	<u>AUTO FEED XT</u>	Automatic Paper Feed. A low-true level that tells the printer to feed the paper automatically.
15	NC	No Connection.
16	OV	Logic GND Level.
17	CHASSIS GND	Chassis ground, which is isolated from logic ground.
18	NC	No Connection.
19	<u>STROBE RTN</u>	Return line for <u>STROBE</u> signal.
20-27	DATA RTN	Return lines for DATA1 thru DATA8 lines.




Figure B-2. Pinout Diagram, Printer Connector (2 of 2)

PIN	NAME	DESCRIPTION
28	ACKNLG RTN	Return line for ACKNLG signal.
29	BUSY RTN	Return line for BUSY signal.
30	PE RTN	Return line for PE signal.
31	INIT	Printer Initial State. A low-true pulse that tells the printer to assume its initial state and clear its print buffer.
32	ERROR	Printer Error. A low-true signal that indicates the printer is (1) out of paper, (2) off-line, or (3) in an error state.
33	GND	Ground level.
34	NC	No Connection.
35	+5V	+5V dc level.
36	SLCT IN	Printer Select Input. A low-true level that permits the printer to accept data.

REAR PANEL CONNECTORS
EXTERNAL I/O CONNECTOR PINOUT DIAGRAM




Figure B-3. Pinout Diagram, External I/O Connector (1 of 2)

DESCRIPTION	NAME	PIN
Signal indicating results of Channel 1 limit testing. User selectable TTL-high = Fail or TTL-low = Fail.	Channel 1 Limit	1
Return for the Channel 1 limit signal	Limit 1 Rtn	2
Signal indicating results of Channel 2 limit testing. User selectable TTL-high = Fail or TTL-low = Fail.	Channel 2 Limit	3
Return for the Channel 1 limit signal	Limit 2 Rtn	4
Signal indicating results of Channel 3 limit testing. User selectable TTL-high = Fail or TTL-low = Fail.	Channel 3 Limit	5
Return for the Channel 3 limit signal	Limit 3 Rtn	6
Signal indicating results of Channel 4 limit testing. User selectable TTL-high = Fail or TTL-low = Fail.	Channel 4 Limit	7
Return for the Channel 4 limit signal	Limit 4 Rtn	8
Signal indicating failure in any channel limit testing. User selectable TTL-high = Fail or TTL-low = Fail.	Limit Fail	9
Return for the Limit Fail signal	Spare	10
	Spare	11
	Limit Fail Rtn	12
	Spare	13
	Spare	14
	Ext Dig In	15
	Dig In Rtn	16
	Ext Ana Out	17
Allows an external signal to sync the 372XXA measurements; ±1V trigger.		
Return for External Dig In signal		
Provides an up-to-±10V signal for use in driving an external plotter or antenna (CW draw).		

Figure B-3. Pinout Diagram, External I/O Connector (2 of 2)

PIN	NAME	DESCRIPTION
18	Ana Out Rtm	Return for Ext Ana Out signal
19	Spare	
20	Spare	
21	Spare	
22	Spare	
23	Gnd 1	
24	Port 1 Bias	Return for Port 1 Bias.
25	Port 2 Bias	Provides for applying an external bias to the active device connected to test port 1.
	Gnd 2	Provides for applying an external bias to the active device connected to test port 2.
		Return for Port 2 Bias.

EXTERNAL I/O CONNECTOR
PINOUT DIAGRAM

REAR PANEL
CONNECTORS

REAR PANEL CONNECTORS
VGA OUT CONNECTOR PINOUT DIAGRAM




Figure B-4. Pinout Diagram, VGA IN/OUT Connector

DESCRIPTION	NAME	PIN
Red signal	Red	1
Green signal	Green	2
Blue signal	Blue	3
	Not Used	4
	Not Used	5
Red return	Red Return	6
Green return	Green Return	7
Blue return	Blue Return	8
	Not Used	9
Sync ground	Digital Ground	10
	Not Used	11
	Not Used	12
Horizontal sync	Hsync	13
Vertical sync	Vsync	14
	Not Used	15

Appendix C Performance Specifications

SYSTEM PERFORMANCE

Signal Source Characteristics Range:

37211A, 22.5 MHz to 3 GHz

37217A, 22.5 MHz to 8.6 GHz

37225A, 40 MHz to 13.5 GHz

37247A, 40 MHz to 20 GHz

37269A, 40 MHz to 40 GHz

Frequency Resolution: 1 kHz (1 Hz optional)

Power Range:

37211A, +10 to -85 dBm

37217A, +10 to -85 dBm

37225A, +10 to -85 dBm

37247A, +10 to -85 dBm

37269A, +5 to -97 dBm

Harmonics: <-35 dBc at maximum rated power

High Level Noise:

<0.4° peak-to-peak variation in a 1 kHz IF bandwidth up to 20 GHz

<0.08 dB and <0.5° peak-to-peak variation up to 40 GHz.

Test Port Characteristics:

Standard Connector Type: K (2.92 mm)

Impedance: 50 ohms

Default Port Power Level (dBm):

37211A: 0 dBm

37217A: 0 dBm

37225A: 0 dBm

37247A: 0 dBm

37269A: -15 dBm

Maximum Input Level: +20 dBm

DC Bias: 0.5 A maximum, 40 VDC maximum

Raw (Uncorrected) Source Match: 10 dB to 20 GHz

8 dB to 40 GHz

GENERAL

Front Panel Connectors and Controls:

Keyboard Input: An IBM-AT compatible keyboard can be connected to the front panel for navigating through front panel menus and disk directories, annotation of data files and display labels, printing displays and pausing instrument sweeps.

Bias Inputs: 0.5 A maximum, 40 Vdc maximum through BNC connectors.

Rear Panel Connectors and Controls:

CRT Intensity: Continuous control of CRT intensity.

CRT Degauss: Pushbutton control degausses CRT.

Printer: Centronics interface for an external printer.

VGA Out: Provides VGA output of 372XXA video display.

10 MHz Ref. In: Connects to external reference frequency standard, 10 MHz, +5 to -5 dBm, 50 ohms, BNC female.

10 MHz Ref. Out: Connects to internal reference frequency standard, 10 MHz, 0 dBm, 50Ω, BNC female.

External Analog Out: -10V to +10V with 5 mV resolution, varying in proportion to user-selected data (e.g., frequency, amplitude), BNC female.

External Trigger Control: External triggering for 372XXA measurement, ±1V trigger, 10 kΩ input impedance, BNC female.

External I/O: 25-pin DSUB connector with the following capabilities:

External Analog Out: -10V to +10V with 5 mV resolution, varying in proportion to user-selected data (e.g., frequency, amplitude), BNC female.

External Trigger Control: External triggering for 372XXA measurement, ±1V trigger, 10 kΩ input impedance, BNC female.

External Analog Input: ±50 Volt input for displaying external signals on the CRT in Diagnostics mode, BNC Female.

System Bus: Dedicated IEEE-488.2 controller interface for the plotter, external power meter, and other peripheral instruments.

GPIB: IEEE-488.2 interface

External SCSI: Provides SCSI-2 connector for external SCSI hard drive connection.

ENVIRONMENTAL CHARACTERISTICS

Temperature Range:

Operating: 0 to 50°C

Storage: -40 to 75°C

Power Requirements: 85–264V, 48–63 Hz, 400 VA maximum
Dimensions: 267H x 432W x 585D mm (10.5 x 17 x 23 in.)
Weight: 34 kg (75 lb)

MEASUREMENT CAPABILITIES

Number of Channels: Four measurement channels.
Parameters: S₁₁, S₂₁, S₂₂, S₁₂; or *non-ratioed*, complex input and output impedance; complex input or output admittance; and complex forward and reverse transmission.
Domains: Frequency Domain, CW Draw, and optional Time (Distance) Domain.
Formats: Log Magnitude, Phase, Log Magnitude and Phase, Smith Chart (Impedance), Inverse Smith Chart (Admittance), Linear Polar, Log Polar, Group Delay, Linear Magnitude, Linear Magnitude and Phase, Real, Imaginary, Real and Imaginary, SWR.
Data Points: Can be switched to a value of 1601, 801, 401, 201, 101, or 51 data (frequency) points without recalibration. In addition, the system accepts an arbitrary set of N discrete data points where: $2 < N < 1601$.
 CW mode permits selection of a single point without recalibration.
Reference Delay: Can be entered in time or in distance (when the dielectric constant is entered). Automatic reference delay feature adds the correct electrical length compensation at the push of a button. Software compensation for the electrical length difference between reference and test is always accurate and stable since measurement frequencies are all-ways synthesized. In addition, the system compensates reference phase delay for dispersive transmission media, such as waveguide and microstrip.
Number of Markers: Six independent markers can be used to read out measurement data.
Delta Markers: In delta-reference marker mode, any one marker can be selected as the reference for the other five.
Marker to Maximum/Minimum: Markers can be directed automatically to the minimum or maximum of a data trace.
Enhanced Markers: Marker search for a level or bandwidth, displaying an active marker for each channel, and discrete or continuous (interpolated) markers.
Marker Sweep: Sweeps upward in frequency between any two markers. Recalibration is not required.
Segmented Limit Lines: Two limit lines per channel, composed of flat, sloped, or single point segments, to indi-

cate test limits. Each limit line may be made from up to 10 segments.
Pass/Fail Indication: When trace exceeds a limit line segment a "PASS" or "FAIL" message is displayed on the screen. A GPIB Pass/Fail SRQ is enabled.
Limit Frequency: Identifies the ±X dB bandwidth of amplifiers, filters and other frequency sensitive devices. Interpolation algorithm determines the exact intersection frequencies of test data and limit lines.
Measurement Frequency Range: Frequency range of measurement can be narrowed within calibration range without recalibration. CW mode permits single frequency measurements, also without recalibration.
Tune Mode: Tune Mode optimizes sweep speed in tuning applications by updating forward S-parameters more frequently than reverse ones. This mode allows the user to select the ratio of forward sweeps to reverse sweeps after a full 12-term calibration. The ratio of forward sweeps to reverse sweeps can be set anywhere between 1:1 to 10,000:1.

DISPLAY CAPABILITIES

Display Channels: Four, each of which can display any S-parameter or user-defined parameter in any format with up to two traces per channel for a maximum of eight traces simultaneously. A single channel, two channels (1 and 3, or 2 and 4), or all four channels can be displayed simultaneously.
CRT: Color, 7.5-inch diagonal, VGA display.
Trace Overlay: Displays two data traces on the active channel's graticule simultaneously.
Trace Memory: A separate memory for each channel can be used to store measurement data for later display or subtraction, addition, multiplication or division with current measurement data.
Scale Resolution (minimum): 0.001 dB/div
Log Magnitude: 0.001 dB/div
Linear Magnitude: 1 pU
Phase: 0.01 degrees/div
Group Delay: 0.001 ps
Time: 0.001 ms
Distance: 0.001 mm
SWR: 1 pU
Autoscale: Automatically sets Resolution and Offset to fully display measurement data.
Reference Position: Can be set at any graticule line.
Annotation: Type of measurement, vertical and horizontal scale resolution, start and stop frequencies, and reference position.

MEASUREMENT ENHANCEMENT

Vector Error Correction: There are four methods of calibration:

- 1) OSL (standard) calibration method using short circuits, open circuits, and terminations (fixed or sliding)
- 2) Offset-Short calibration
- 3) LRL (Line-Reflect-Line) calibration
- 4) LRM Line-Reflect-Match calibration

There are five vector error correction models available:

- 1) Full 12-Term
- 2) One Path/Two Port (Forward or Reverse)
- 3) Frequency Response (Forward or Reverse or both)
- 4) Frequency Response with Isolation
- 5) Reflection Only (Port 1 or Port 2 or both)

Full 12-term can always be used, if desired, since all 372XXA series models automatically reverse the test signal. A front-panel button selects whether calibration is applied and an LED lights when error correction is applied. **Calibration Standards:** User selects SMA, GPC-3.5, GPC-7, Type N, 2.4 mm, TNC, or K Connector from the calibration menu. Use of fixed or sliding load can be selected for each connector type. Open circuit capacitance coefficients can be modified. In general, all calibration parameters may be modified manually or through the GPIB interface.

Reference Impedance: Modify the reference impedance of the measurement to other than 50 ohms (but not 0).

LRL/LRM Calibration Capability: The LRL calibration technique uses the characteristic impedance of a length of transmission line as the calibration standard. A full LRL calibration consists merely of two transmission line measurements, a high reflection measurement, and an isolation measurement. The LRM calibration technique is a variation of the LRL technique that utilizes a precision termination rather than a second length of transmission line. A third optional standard, either Line or Match, may be measured in order to extend the frequency range of the calibration. This extended calibration is achieved by mathematically concatenating either two LRL, two LRM, or one LRL and one LRM calibration(s). Using these techniques, full 12-term error correction can be performed on the 372XXA VNA.

Dispersion Compensation: Selectable as Coaxial (non-dispersive), Waveguide, or Microstrip (dispersive). **Reference Plane:** Selectable as Middle of line 1 or Ends of line 1.

Corrected Impedance: Determined by Calibration Standards.

Data Averaging: Averaging of 1 to 4096 averages can be selected. Averaging can be toggled on/off with front

SOURCE CONTROL

panel button. A front panel button turns data averaging is on/off, and a front panel LED indicates when averaging is active.

Video IF Bandwidth: Front panel button selects four levels of video IF bandwidth. MAXIMUM (10 kHz), NORMAL (1 kHz), REDUCED (100 Hz) and MINIMUM (10 Hz).

Trace Smoothing: Functions similarly to Data Averaging but computes an average over a percentage range of the data trace. The percentage of trace to be smoothed can be selected from 0 to 20% of trace. Front panel button turns smoothing on/off, and front panel LED indicates when smoothing is active.

Frequency Resolution: 1 kHz (1 Hz optional)

Test Port Power Level: The level at Port 1 may be controlled in fine increments of 0.1 dB or in 10 dB steps by using the internal 0 to 70 dB step attenuator.

Power Accuracy: ±0.5 dB at 2 GHz at default power. **Level Test Port Power:** The power, at all sweep frequencies, is leveled to within ±2 dB (±3 dB for 20–40 GHz).

Flatness Correction: Further improves the test port power flatness using an external power meter to measure and correct for level variations.

Dual Source Control: Allows a user to separately control the frequency of both the internal and an external signal source and the receiver without the need for an external controller.

Sweep Type: Linear, CW, Marker, or N-Discrete point sweep.

Frequency Accuracy, Standard Time Base: Aging: $< 1 \times 10^{-6}$ /year
Stability: $< 1 \times 10^{-6}$ over +15 to +50°C range

Frequency Accuracy, High Stability Time Base (Opt 10): Aging: $< 1 \times 10^{-9}$ /day
Stability: $< 1 \times 10^{-9}$ over 0 to +55°C range

Power Range:

Model	Rated Power (dbm)	Minimum Power (dbm)	Resolution (db)	Flatness (db)
37211A	0	-85	0.1	±1.5
37217A	0	-85	0.1	±1.5
37225A	0	-85	0.1	±1.5
37247A	0	-85	0.1	±2
37269A	-15	-97	0.1	±3

the user within 2 seconds.

Performance: After selecting the Start Print button, front panel operation and measurement capability is restored to

- Tektronix Model HC100 plotters. The plotter is connected to the dedicated system GPIB bus.
- HP Models 7440A, 7470A, 7475A, and 7550A

Compatible GPIB Plotters:

- Epson FX80
- HP LaserJet II & III Series
- HP Deskjet (b/w) (310/320, 500)
- HP QuietJet
- HP ThinkJet

Compatible Printers:

markers only.
points of tabular data can be selected as well as data at
lows portrait or landscape format. The number of data
graphical or tabular data output, and plotter type, which al-
Hardcopy Output Selection: Menu selects printer type,

HARD COPY

$$Error\ in\ \tau_g = \frac{Error\ in\ Phase}{360} + [\tau_g \times Aperture\ Freq.\ Error\ (Hz)]$$

Accuracy:

$$1.41 [(Phase\ Noise\ in\ deg^2) + (\tau_g \times Residual\ FM\ Noise\ in\ Hz^2)] \times 0.5$$

fluctuations due to phase and FM noise are:
continuous measurement of a through connection, RSS
Measurement Repeatability (sweep to sweep): For

the aperture set by the number of frequency points. A fre-
quency step size of 100 kHz corresponds to 10 ms.
Range: The maximum delay range is limited to measur-

ing no more than ±180 degrees of phase change within
the aperture width of the aperture and the percent of the fre-
quency range are displayed automatically.




20% of the frequency range without recalibration. The fre-
quency range can be changed without recalibration. The
minimum aperture is the frequency range divided by the
number of points in calibration and can be increased to

The aperture change is computed at a given frequency point.
Aperture: Defined as the frequency span over which
the phase change is computed at a given frequency point.

Group Delay is measured by computing the phase change
in degrees across a frequency step by applying the for-

GROUP DELAY CHARACTERISTICS

$$\tau_g = - \frac{1}{\omega} \frac{d\phi}{d\omega}$$



STORAGE

Internal Memory: Up to 10 front panel states can be stored and recalled from non-volatile memory locations. The current front panel setup is automatically stored in non-volatile memory at instrument power-down. When power is applied, the instrument returns to its last front panel setup (with no calibration data applied).

Internal Hard Disk Drive: A hard-disk drive is used to store and recall measurement and calibration data and front-panel setups.

External SCSI Interface: Option 4 deletes the internal hard disk drive and adds a SCSI interface connector to the rear panel for connecting a SCSI-2 formatted hard disk drive.

Internal Disk Drive: A 3.5-inch microdiskette drive with 1.44 Mbytes formatted capacity is used to load measurement programs and to store and recall measurement and calibration data and front-panel setups.

Disk Storage Format: All files are MS-DOS Compatible. User-defined file names may be 1 to 8 characters long.

Data File Size: 20.5K bytes per 401 point S-parameter trace.

Calibration: 48.8K bytes per 401 point (12-term cal+setup). Trace Memory: 3.2Kbytes per 401 point data trace.

Interface: GPIB (IEEE-488.2) Addressing: Address can be set from the front panel and can range from 0 to 30. Defaults to address 6.

Transfer Formats: ASCII, 32-bit floating point, or 64-bit floating point.

Speed: 40K bytes/s

Interface Function Codes: SH1, AH1, T6, TE0, L4, LE0, SR1, RL1, PP1, DT1, DC0, CO.

MEASUREMENT ACCURACY

The graphs shown on pages C-8 through C-14 give measurement accuracy after 12-term vector error correction. These errors include the contributions of residual directivity, load and source match, frequency response, isolation, network analyzer dynamic accuracy, and connector repeatability. In preparing the following graphs, 100 Hz IF bandwidth and averaging of 1024 points were used. Changes in the video IF bandwidth or averaging can result in variations at low levels.

DYNAMIC RANGE SUMMARY

Dynamic range (Table C-1) is given in two manners. "Receiver Dynamic Range" is defined as the ratio of the maximum signal level at Port 2 for 0.1 dB compression to the noise floor at Port 2. "System Dynamic Range" is defined

as the ratio of the power incident on Port 2 in a through line connection to the noise floor at Port 2 (forward measurements only) when both test ports are terminated in 50 Ohms. In preparing the Dynamic Range specifications, 100 Hz IF bandwidth and 1024 averages were used during calibration and measurement.

TEST PORT CHARACTERISTICS

The Test Port specifications (Table C-2) apply when the proper Model 34U or 34Y Universal Adapters are connected, with or without phase-equal insertables, to the test set ports and calibrated with the appropriate Wiltron or other designated calibration kit at $23^{\circ}\text{C} \pm 3^{\circ}\text{C}$ using the OSL calibration method with a sliding load to achieve 12-term error correction. A 90 Minute minimum warm-up time is assumed.

TIME (DISTANCE) DOMAIN MEASUREMENT CAPABILITY (OPTION 2)

Option 2, Time (Distance) Domain software allows the conversion of reflection or transmission measurements from the frequency domain to the time domain. Measured S-parameter data is converted to the time domain by application of a Fast Fourier Transform (FFT) using the Chirp Z-Transform technique. Prior to conversion any one of several selectable windowing functions may be applied. Once the data is converted to the time domain, a gating function may be applied to select the data of interest. The processed data may then be displayed in the time domain with display start and stop times selected by the user, or in the distance domain with display start and stop distance selected by the user. The data may also be converted back to the frequency domain with a time gate to view the frequency response of the gated data.

Lowpass Mode: This mode displays a response equivalent to the classic (Time Domain Reflectometer) response of the device under test. Lowpass response may be displayed in either the impulse or step mode. This type of processing requires a sweep over a harmonic series of frequencies and an extrapolated or user-entered dc value.

Bandpass Mode: This mode displays a response equivalent to the time response of the device under test to a band limited impulse. This type of processing may be used with any arbitrary frequency sweep range, limited only by the test set range or device-under-test response.

Phasor Impulse Mode: This mode displays a response similar to the Lowpass impulse response, using data taken over an arbitrary (band limited) sweep range. Detailed information, similar to that contained in the lowpass impulse response, may be used to identify the nature of impedance discontinuities in the device under test. Now, with Phasor Impulse, it is possible to characterize complex impedances on band-limited devices.

Windowing: Any one of four window functions may be applied to the initial frequency data, to counteract the effects of processing data with a finite bandwidth. These windows provide a range of tradeoffs of main-lobe width vs. sidelobe level (ringing). The general type of function used is the Blackman-Harris window, with the number of terms being varied from one to four. Typical performance is shown below:

Type of Window (Number of Terms)	First Side Lobe Relative to Peak Impulse Width ¹	Impulse Width ¹
Rectangular (1)	-13 dB	1.2W
Nominal-Hanning (2)	-43 dB	1.8W
Low Side Lobe Blackman-Harris (3)	-67 dB	2.1W
Minimum Side Lobe Blackman-Harris (4)	-67 dB	2.7W

¹ W(Bin Width)=1/2 Δt sweep width

Gating: A selective gating function may be applied to the time domain data to remove the responses of all but one desired time range. This gating function may be chosen as the convolution of any of the above window types with a rectangular gate of user-defined position and width. The gate may be specified by entering start and stop times or center and span. The gated data may be displayed in the time domain, or converted back to the frequency domain.

Time Domain Display: Data processed to time domain may be displayed as a function of time or as a function of distance, provided the dielectric constant of the transmission media is entered correctly. In the case of dispersive media such as waveguide or microstrip, the true distance to a discontinuity is displayed in the distance mode. The time display may be set to any arbitrary range by specifying either the start and stop times or the center time and span.

Frequency with Time Gate: Data that has been converted to time domain and selected by the application of gating function may be converted back to the frequency response of main. This allows the display of the frequency response of a single element contained in the device under test. Frequency response accuracy is a function of window and gate type, and gate width. For a full reflection, minimum gate and window accuracy is within 0.2 dB of the ungated response over a 40 GHz range.

OTHER OPTIONS

Option 1 & 1A-Rack & Slide Mounting Options
Option 1 provides slide mounts and associated hardware to install the 372XXA in a user-supplied rack. Option 1A provides hardware for mounting the 372XXA in a user-supplied rack where there is proper bottom support for the instrument.

Option 3 — 1 Hz Frequency Resolution
Option 3 adds 1 Hz frequency resolution to all microwave models (1 kHz is standard). (1 Hz frequency resolution is standard on Models 37211A and 37217A.)

Option 4 — External SCSI Interface
Option 4 adds a rear panel connector for connection of an external SCSI-2 Hard Disk Drive for use in applications where removable media is a requirement. In this situation, the internal hard disk drive is not installed.

Option 6 — Port 2 Test Step Attenuator
Option 6 adds a 0 to 70 dB step attenuator in the Forward Transmission signal path to allow for device output power of up to +30 dBm (1 Watt) into Port 2.

Option 7 — Test Port Connector
7A: Replaces Universal K connector with Universal GPC-7 connector
7N: Replaces Universal K connector with Universal N male connector
7NF: Replaces Universal K connector with Universal N female connector

Option 10 — Ovenized Timebase
Option 10 replaces the standard temperature compensated crystal oscillator (with a temperature stability of 1 ppm over a +15 to 55°C range) with an ovenized crystal oscillator (aging stability of $\times 10^{-9}$ /day and temperature stability $\pm \times 10^{-9}$ over 0 to 55°C range).
Option 11 — Reference Loop Extension Cables
Option 11 add extension to both Reference A and Reference B Sampler RF inputs allowing the user direct access to these channels.


MEASUREMENT SPEED SUMMARY
Measurement times will be on a per sweep basis including retrace, with a 12-term RF calibration applied, no averaging, 10 kHz IF bandwidth and two channels with one display trace each. The measurement times are as follows:
401 pts, .01-20 GHz sweep = 1.1 seconds
101 pts, .01-20 GHz sweep = .35 seconds
401 pts, 1 GHz sweep width = 1.0 seconds
101 pts, 1 GHz sweep width = .26 seconds
UNCERTAINTY CURVES (measured @23 ±3 deg C)
Uncertainty curves are provided on the following pages.

Table C-1. Dynamic Range Summary


Model	Freq (GHz)	Max Signal Into Port 2 (dbm)	Noise Floor (dbm)	Receiver Dynamic Range	Port 1 Power (dbm)	System Dynamic Range
37211A.	2	+30	-98	130	0	98
	3	+30	-98	130	0	98
37217A	2	+30	-98	130	0	98
	8.6	+30	-98	128	0	98
37225A	0.04	+30	-70	100	0	70
	2	+30	-98	128	0	98
37247A	0.04	+30	-70	100	0	70
	2	+30	-98	128	0	98
37269A	0.04	+30	-70	100	0	70
	2	+30	-98	128	0	98
	20	+30	-96	126	0	96
	40	+30	-93	123	-15	78

Table C-2. Test Port Characteristics


Connector	Frequency (GHz)	Directivity	Source Match	Load Match	Reflection Frequency Tracking	Transmission Frequency Tracking	Isolation
GPC-7	0.04	>52	>44	>52	±0.003	±0.004	>105
	1.0	>52	>44	>52	±0.003	±0.004	>115
	8.6	>52	>42	>52	±0.004	±0.012	>112
	18	>52	>42	>52	±0.012	±0.012	>112
GPC-7 LRL Calibration	2.0	>60	>60	>60	±0.001	±0.001	>115
	8.6	>60	>60	>60	±0.001	±0.001	>112
	18	>60	>60	>60	±0.001	±0.001	>112
	0.04	>44	>40	>44	±0.006	±0.006	>105
3.5 mm	1.0	>44	>40	>44	±0.006	±0.006	>115
	8.6	>44	>38	>44	±0.006	±0.050	>110
	20	>44	>38	>44	±0.015	±0.020	>110
	26.5	>44	>34	>44	±0.020	±0.030	>102
K	0.04	>42	>40	>42	±0.006	±0.006	>105
	1.0	>42	>40	>42	±0.006	±0.006	>115
	8.6	>42	>38	>42	±0.006	±0.070	>110
	20	>42	>38	>42	±0.015	±0.020	>110
	40	>38	>38	>38	±0.020	±0.030	>100




Models 37211A and 37217A (GPC-7 Connectors),
Transmission Measurements




Models 37211A and 37217A (Type N Connectors),
Transmission Measurements




Models 37211A and 37217A (GPC-7 Connectors),
Reflection Measurements




Models 37211A and 37217A (Type N Connectors),
Reflection Measurements




Models 37211A and 37217A (3.5mm Connectors), Transmission Measurements



Models 37211A and 37217A (K Connectors), Transmission Measurements





Models 37211A and 37217A (3.5mm Connectors), Reflection Measurements





Models 37211A and 37217A (K Connectors), Reflection Measurements


Model 37217A Universal Test Fixture (Model 3680K),
Microstrip LRL Calibration (Model 36804-15, 15 mil
Calibration Kit — Reflection Measurements




Model 37217A Universal Test Fixture (Model 3680K),
Microstrip LRL Calibration (Model 36804-15, 15 mil
Calibration Kit — Transmission Measurements




Model 37217A Universal Test Fixture (Model 3680K),
Microstrip LRL Calibration (Model 36804-15, 15 mil
Calibration Kit — LRLM Performance (typical)




Measurement Setup




Models 3725A and 3747A (GPC-7 Connectors),




Models 3725A and 3747A (Type N Connectors),




Models 3725A and 3747A (GPC-7 Connectors),




Models 3725A and 3747A (Type N Connectors),







Models 37225A and 37247A (K Connectors),
Transmission Measurements




Models 37225A and 37247A (GPC-7 Connectors),
Transmission Measurements




Models 37225A and 37247A (K Connectors),
Reflection Measurements




Models 37225A and 37247A (GPC-7 Connectors),
Reflection Measurements




Model 37269A (K Connectors),
Transmission Measurements





Model 37269A Universal Test Fixture (Model 3680K),
Calibration Kit — Transmission Measurements



Model 37269A (K Connectors),
Reflection Measurements



Model 37269A Universal Test Fixture (Model 3680K),
Calibration Kit — Reflection Measurements



Index

4-9	Calibration Key-Group Description
4-4, 4-9	Calibration Keys
7-14	Calibration Kit
1-4	Calibration Kits
3650	Calibration Kits
3651	Calibration Kits
3652	Calibration Kits
3653	Calibration Kits
1-6	Calibration Menus
1-7 - 1-12	Calibration Menus
4-9	Calibration Sequence
4-6	Ch 1 Key
4-6	Ch 2 Key
4-7	Ch 3 Key
4-7	Ch 4 Key
4-20	Ch1 - Ch4 Keys
4-6, 4-20	Channel Menu Key
4-6, 4-20	Channel Keys
4-20	Channel Key-Group
4-20	Calibration
4-9	Display Key-Group
4-21	Markers/Limits
4-32	Markers/Limits
4-32	Markers/Limits Key-Group
4-18, 4-20	Measurement Key-Group
4-27	Output Key-Group
4-17	Save/Recall Menu
4-29	System State
4-29	System State Key-Group
4-8	Clear/Ret Loc Key
4-39	Copying Data Files
B-2	CRT Brt
B-2	CRT Degauss
6-13	Active Channel Selection
6-12	Analog Instrument Status
6-13	Control
6-12	Frequency Range
6-12	Limits
3-9	Linear Phase
3-9	Log Magnitude
6-15	Markers

D

Data Display

6-13	Active Channel Selection
6-12	Analog Instrument Status
6-13	Control
6-12	Frequency Range
6-12	Limits
3-9	Linear Phase
3-9	Log Magnitude
6-15	Markers

B-3	10 MHz Ref IN
B-3	10 MHz Ref OUT
B-3	20dB Compressed Smith Chart Display Mode
1-4	Calibration Kits
B-1	Rear Panel Connectors
6-10	3dB Compressed Smith Chart Display Mode
A	
6-13	Active Channel Selection
8-24	Active Device Measurements
8-24	Discussion
2-5	Address, GPIB
9-17	Aliasing
6-12	Analog Instrument Status
3-5	Analyzer Module
4-4, 4-9	Apply Cal Key
4-8	Arrow Key
4-5, 4-21	Autoscale Key
4-6	Average Key
4-6	Avg/Smooth Key
4-25	Avg/Smooth Menu Key
B	
9-5	Bandpass Impulse Response
1-6	Beatty Standard
4-4, 4-9	Begin Cal Key
0-2	Bias Fuses, Port 1
0-2	Bias Fuses, Port 2
4-6	Bias Input connectors
1-26	Broadband Load
C	
2-4	Cable Length Restrictions
8-28	CAD system
7-9	Calibrating for a Measurement
	Calibration
	See measurement calibration

Dual Source Control Measurements 8-29
Discussion 8-29
Dual Trace Overlay Display Mode 6-6

E

Enhancement Keys 4-6, 4-25
Enter Key 4-8
Error Messages 5-3
Error Modeling and Flowgraphs 7-7
Error Terms
Description 3-11
Evaluating the Calibration 7-11
Ext Anlg In B-3
Ext Anlg Out B-3
External I/O B-2
External Monitor Connector 2-5
External Trigger B-3

F

Four Channel Display Mode 6-5
Fourier Transform 9-3
Frequency Range 6-12
Frequency Domain 9-3, 9-8, 9-12
Front Panel
Calibration Key-Group Description 4-9
Channels Key-Group Description 4-20
Display Key-Group Description 4-21
Key-Group Descriptions 4-3
Markers/Limits Key-Group Description 4-32
Measurement Key-Group Description 4-18
Menus, Alphabetical Listing 1-1
Output Key-Group Description 4-27
Save/Recall Key, Description 4-17
System State Key-Group Description 4-29
Front Panel Menus
Alphabetical Listing 1-1

G

Gating 9-12
General Description 3-3
GHz/10³/ms/m Key 4-8
GPFB
Indicators 4-3
Addresses 2-5
Interface to External Plotter 2-4
Setup and Interconnection 2-3
Graph Data Types 6-7

Measurement Status 6-13

Plotter Output 6-16

Polar 3-10

Reference Position Marker 6-12

S-Parameter Selection 6-14

Scale Resolution 6-12

Screen-Image Printout 6-16

Smith 3-10

Status 6-12

Sweep Marker Indicator 6-13

Tabular Printout 6-15

Update 6-14

Data Display Modes

20 dB Compressed Smith Chart 6-10

3 dB Compressed Smith Chart 6-10

Dual Channel 6-4

Dual Channel Rectilinear Graticule 6-8

Dual Trace Overlay 6-6

Four Channel 6-5

Graph Data Types 6-7

Linear Polar Graticule 6-8

Log Polar Graticule 6-9

Marker Annotation 6-11

Marker Designation 6-11

Normal Smith Chart 6-9

Single Channel 6-8

Data Display Modes and Types 6-8

Data Entry Keys 4-7

Data Plotting 4-27

Data Points Key 4-7, 4-18

Dedicated GPFB B-3

Default Parameters 8-3, 8-10

Default Program Key 4-4, 4-29

Default Settings 4-31

Device ID Key 4-18

Disk Files, Format 4-38

Disk Output 6-16

Disk Storage Interface 4-38

Diskette Drive 4-6

Display Key-Group 4-21

Display Keys 4-5, 4-21

Domain Key 4-7, 4-18

Dual Channel Display Mode 6-4

Dual Channel Rectilinear Display Mode 6-8

Dual Source Control

Bands 8-30

Control Formula 8-29

Operating Procedures 8-30

Operation 8-32

Preoperational Setup 8-31

Load Match 7-6
 Log Magnitude Display 3-9
 Log Polar Graticule Display Mode 6-9
 Low Level and Gain Measurements
 Discussion 8-12
 Receiver Dynamic Range 8-12
 Signal-to-Noise Power Ratio 8-13
 System Considerations 8-12
 Test Device (DUT) Considerations 8-17
 Low Level Measurements 8-12
 LRL/LRM Calibration Procedure
 Coaxial 7-41
 General 7-33
 Microstrip 7-34
 Waveguide 7-43
 LRL/LRM Calibration Setup Menu Flow 4-14

M

Marker
 Reference Position 6-12
 Marker Annotation Data Display 6-11
 Marker Designation 6-11
 Marker Menu Key 4-5, 4-32
 Markers
 Display of 6-15
 Markers/Limits Key-Group
 Markers/Limits Keys 4-4, 4-32
 Measurement
 Group Delay 8-20
 Measurement Calibration
 Calibration Types 7-7
 Discussion 7-3
 Error Modeling and Flowgraphs 7-7
 Evaluating the Calibration 7-11
 LRL/LRM Procedure 7-33
 Offset-Short Procedure 7-29
 Sliding Load, Procedure 7-14
 Standard (OSL) Procedure 7-20
 Understanding 7-6
 Measurement Key-Group Description 4-18
 Measurement Keys 4-7, 4-18
 Measurement Status 6-13
 Measurement Uncertainty 7-3
 Measurements
 Active Device 8-24
 Dual Source Control 8-29
 Group Delay 8-20
 High-Gain Devices 8-19
 Low Level 8-12

Graph Type Key 4-5, 4-21

Applications 8-23
 Discussion 8-20
 Equation 8-21
 Frequency Aperture 8-21
 Group Delay Measurements 8-20
 Discussion 8-20

H

Hard Copy
 Plotter Output 6-16
 Screen-Image Printout 6-16
 Tabular Printout 6-15
 Hard Copy and Disk Output 6-15
 Hard Copy Keys 4-4, 4-27
 High Level Noise Test
 Test Procedure 1B-9
 Test Setup 1B-8
 High Level Noises Test 1B-8
 Hold Key 4-7, 4-18

I

Identification Number 1-3
 IEEE 488.2 GPIB B-3
 Impulse Response 9-4
 Initial Inspection 2-3
 Initial Setup B-3
 Insertables 7-5
 Interface
 Connector 2-4
 Disk Storage 4-38
 Introduction 1B-3

K

Keyboard Connector 4-6
 Keypad 4-7
 $\text{kHz}/10^{-3}/\text{ps}/\text{mm}$ Key 4-8

L

Limit Frequency Readout Function 4-32
 Limits 6-12
 Limits Key 4-5, 4-33
 Line Fuse B-2
 Line Voltage Input B-2
 Linear Polar Graticule Display Mode 6-8

Low Level and Gain 8-12
Medium-Power Devices 8-19
Time Domain 9-3
Transmission And Reflection 8-3
Wide-Dynamic-Range Devices 8-19
Menu Flow
Calibration Key-Group Menus 4-9
Marker Menu Key 4-36
Save/Recall Key 4-17
Trace Memory Key 4-22
Menu Key 4-4, 4-27
Menu Keys 4-8
Menus
Alphabetical Listing 1-1
1-7 - 1-12
Channels Key-Group 4-20
Display Key-Group 4-21
Markers/Limits Key-Group 4-32
Measurement Key-Group 4-18
Output Key-Group 4-27
System State Key-Group 4-29
MHz/XI/ns/cm Key 4-7
Microwave Load 7-14
N
Network Analyzer 7-14
Description 1-3
Options 1-7
Network Analyzers
Basics 3-6
Error Correction 3-11
Measurements 3-9
Primer 3-5
Non-insertables 7-5
Normal Smith Chart Display Mode 6-9
O
Offset-Short Calibration Procedure 7-29
Offset-Short Calibration Setup Menu Flow 4-12
Open 8-27
Operational Checkout
High Level Noise Test 10-8
Initial Setup 10-3
Required Test Equipment 10-3
Sampler Efficiency Test 10-4
Self Test 10-3
Option 2 Time Domain
Menus 9-17
Rear Panel Connectors B-1
Readout Marker Key 4-5, 4-32
Rear Panel Connectors B-1
Connector Pinout Diagrams B-1

Option 2A Time Domain
Gating 9-12
Gating Example 9-13
Operating 9-8
Optimizing Results 9-17
Windowing 9-11
Option 5 Receiver Mode
General 9-24
Menus 9-26
Operating Procedure 9-27
Operation 9-26
Set-On Mode 9-25
Sweeper Source Lock Mode 9-24
Synthesizer Tracking Mode 9-24
4-6, 4-25
Option Menu Key 1-7
Options 9-24
5 Receiver Mode 9-24
Output Key-Group 4-27
P
Performance Specifications 1-7
Phasor-Impulse Response 9-5
Pin Depth 7-14
Pinout Diagram, External I/O Connector B-7
Pinout Diagram, GPIB & Dedicated
GPIB Connect B-4
Pinout Diagram, Printer Connector B-6
Pinout Diagram, VGA IN/OUT Connector B-9
Pinout Diagrams
Rear Panel Connectors B-1
Plotter Output 6-16
Plotting 4-27
Polar Display 3-10
Port 1 Connector 4-6
Port 1 Test Connector 4-4
Port 2 Connector 4-6
Port 2 Test Connector 4-5
Precision Component Kits 1-4
Preparation for Storage and/or Shipment 2-5
Preparation for Use 2-3
Printer Out B-3
Printing
Stop/Start 4-27
R
Readout Marker Key 4-5, 4-32
Rear Panel Connectors B-1
Connector Pinout Diagrams B-1

Recommended Test Equipment 1-7

Recovering from Disk Write/Read Errors 4-39

Ref Plane Key 4-5, 4-21

Reference Extension, RA In to RA Out B-2

Reference Extension, RB In to RB Out B-2

Reference Flat 7-16

Reference Position Marker 6-12

Rotary Knob 4-7

S

S Params Key 4-5, 4-21

S-Parameter 8-25

Description 3-9 - 3-10

Selection, Display of 6-14

S-Parameters

General 3-9

Sampler Efficiency Test 1B-4

Test Procedure 1B-5

Test Setup 1B-5

Save/Recall Menu 4-17

Save/Recall Menu Key 4-4

Save/Recall Menu Key 4-4

Save/Recall Menu Key 4-17

Scale Resolution 6-12

Scattering Parameters 3-9

Scope of Manual 1-3

Screen-Image Printout 6-16

Self Test 1B-3

Service Centers 2-7

Set Scale Key 4-5, 4-21

Setup Menu Key 4-7, 4-18

Short 8-27

Signal Power 8-13

Signal-to-Noise-Power Ratio 8-13

Single Channel Display Mode 6-3

Sliding Load 1-26

17K50, 17KF50 1-5

17S50, 17SF50 1-4

Calibration Procedure 7-14

Pin Depth 7-14

Used in Calibration 7-6

Sliding Loads 7-14

SMA 7-14

Smith Chart 8-10

20 dB Compressed 6-10

3 dB Compressed 6-10

Measurement Discussion 8-8

Normal 6-9

Smith Chart Display 3-10

Source Match 7-6

Source Module 3-4

General 1-7

Specifications, Performance 1-7

Standard Calibration Setup Menu Flow 4-10

Start Frequency 1-8

Start Print 4-27

Start Print Key 4-4, 4-27

Status Display 6-12

Stop Frequency 1-8

Stop Print Key 4-4, 4-27

Stop Printing 4-27

Sweep Marker Indicator 6-13

System Description 1-3

System GPIB Interconnection 2-4

System State Key-Group 4-29

System State Keys 4-4, 4-29

T

Tabular Printout 6-15

Test Equipment 1-7

Test Ports 7-3

Establishing, Discussion 7-3

Test Set 3-11

Reversing 3-11

Test Set Module 3-4

General 3-4

Time Delay 8-21

Linear 8-21

Time Domain Measurements 9-3

Trace Memory Key 4-5, 4-22

Trace Smooth and Average Keys 4-25

Trace Smooth Key 4-6

Tracking 7-6

Transmission And Reflection Measurements 8-3

Discussion 8-7

General 8-3

Setup and Calibration 8-3

Smith Chart 8-8

U

Utility Menu Key 4-4, 4-29

V

Verification Kit 3666

3668 1-6

Verification Kits 1-7

Used in Calibration	7-12	Z
VGA Out	B-2	
Video IF BW Key	4-6, 4-25	
W		
Windowing	9-11	
Zo Load	8-27	Z
Zo Reference	7-14	