

Getting Started

First Use of Radio

- IMPORTANT**
Long condition the battery. Refer to the Battery Charger User Guide.
- Install the Antenna
- Install the Battery
Short Condition the battery every week.
- Turn on radio, adjust speaker volume, select channel.
- Press PTT to Talk. Release to Listen.

Radio Configuration

Your Tait Orca radio has been configured for your requirements by your authorised Tait Dealer or your company administrator. Therefore, some functions will vary in operation or will not be available. The configuration information can be written onto this User Guide.

Batteries

Use Tait Orca 5000 NiCd/NiMH batteries or Tait Orca Elan/Excel/Eclipse NiCd/NiMH batteries. For more information on batteries, refer to the Battery Care Guide.

IMPORTANT
Do not put Tait Orca 5000 batteries into older battery chargers. Tait Orca 5000 NiCd/NiMH batteries are ONLY for Tait Orca battery chargers with software version 2.07+.

Parts

If any parts are damaged or missing, report this to your authorised Tait dealer immediately.

Making Calls

To make a call, select a Channel then press PTT to talk. Alternatively, use a Function Key.

When you select a Scan Group of Channels, scanning for activity will begin automatically.

3 Methods to Select a Channel or a Scan Group:

- Keypad**
Dial Number To Cancel: To Select:
SELECT CHANNEL Mode
- Scroll Keys**
Scroll to Select Short press for normal scroll. Long press for fast scroll.
SELECT CHANNEL Mode
- 16-way Selector**
Turn to select from the first 16 in the list.

Using the PTT

Press PTT to talk to all persons on the same Channel. Release PTT to listen.

You can only transmit or receive on one Channel at a time.



Standard Operation

The illustration shows the recommended method for standard operation. Use the upper microphone to speak.

Handset Operation

The illustration shows the recommended method for handset operation. Use the lower microphone to speak.

Selcall Calls

Variable Selcall
Select a Selcall Channel.

Preset/Fixed Selcall
Select a Selcall Channel.

Select the appropriate Function Key to make the call.

Press PTT to talk. Release PTT to listen.

Emergency Calls and One Touch Selcalls

You may need to Select a Selcall Channel.

Select the appropriate Function Key to make the call.

Press PTT to talk. Release PTT to listen.

Deferred Callback for Selcall If busy, the call will be sent when Channel is free: up to 15 tries (if configured).

To cancel the call: Change Channel or turn radio off. **To exit Selcall:** Long press

Receive a Selcall Call

Press PTT to talk. There is usually no need to respond to a Group Selcall.



Radio Configuration

Write your settings

Alpha Symbols	F3 Action List	Phonetic Alphabet
1	1	Alpha A
2	2	Bravo B
3	3	Charlie C
4		Delta D
5		Echo E
6		Golf F
7		Foxtrot G
8		Hotel H
9		India I
10		Juliet J
11		Kilo K
12		Lima L
13		Mike M
14		November N
15		Oscar O
16		Papa P
17		Quebec Q
18		Romeo R
19		Tango T
20		Sierra S
		Uniform U
		Victor V
		Whisky W
		X-ray X
		Yankee Y
		Zulu Z

Radio Identification

Group Information

Emergency Call Numbers

16-way Selector	1	9
	2	10
	3	11
	4	12
	5	13
	6	14
	7	15
	8	16

- Battery 100% charged
- Battery 60% charged
- Battery Low
- DTMF Mode on
- Monitor Mode on
- Scroll
- Handset Mode on
- Scanning for activity or signal
- Activity found on channels
- Transmit at normal power
- Transmit at low power Max.1W
- Channel is busy: Wait
- RSSI. Signal strength indicator. Also for contrast indication.
- Antenna
- On/Off and Volume
- LED
- Speaker
- Standard Microphone
- Menu scroll keys: Backwards Forwards
- Display
- Clear, Cancel or Back in Menu
- Menu, Select, Toggle (on/off) or Send (make call)
- Alphanumeric Keypad
- SDM
- Handset Microphone
- Function Key 1
- Function Key 2
- PTT. Press to Talk, Release to Listen.
- Function Key 3 or Action List
- Channel Select Mode
- Caller ID
- Queue: Call # of # (15 maximum)
- Repeater Talk Around

Menu

Long press to Select Menu or Exit Menu. When in Menu, short press to Select or to Toggle a function e.g. on/off

Menu scroll keys: Forwards and Backwards. Long press is fast scroll.

QUEUED CALLS
Select call (a) Return call (b) Read status or message (c) Delete call or message (not automatic)

Normal Call = "blank"
Priority Call = P
Short Data Message (SDM) = M
Status Call = S

SELECT CHANNEL
Select Channel mode. Then select a Channel or a Scan Group.

SEND SELCALL
1 SELECT STATUS → Select status label from list. LUNCH...
2 DIAL SELCALL → Dial number. Press to make call.

SEND DTMF
Dial number. If buffered, press to make call. To send A, B, C or D commands, press the PTT key whilst pressing 2, 5, 8 or 0.

DTMF Dial Tone Multi-Frequency. International standard. Tones are used to dial direct to a landline. Example: communicating with telebanking systems.

ALPHA SYMBOLS
Select from list. It can be a Channel, Selcall call, DTMF call, Status call, or combination. Short press to make the call.

SEND SDM
ENTER SDM: SDM TO... ENTER ID: >>>>0000BASE

1. Enter a Short Data Message 2. Confirm 3. Enter the Radio Identification 4. Send the SDM

Receive an SDM (Short Data Message)
Long press to display message, Scroll to read message, Delete message

SDM is always queued. Only one SDM can be queued.

Menu

USER SETTINGS
HANDSET LOW PWR KEYLOCK DTMF ECONOMY SQUELCH MONITOR SQ OVRD

- Handset mode: on/off
- Transmit at low power: on/off
- Keypad locked Long press to unlock
- DTMF dialling mode: normal/buffered
- Economy mode: on/off
- Squelch: city/country
- Monitor (signalling override): on/off
- Squelch Override: on/off

ALERT SETTINGS
TONES LEVEL KEYTONE

- Radio Tones: on/off
- Volume of Radio Tones: high/low
- Keypress Tones: on/off

DISPLAY SETTINGS
NIGHT RSSI ADJUST CONTRAST

- Night use mode: on/off
- RSSI. Signal strength indicator: on/off
- Adjust contrast of display

ADV SETTINGS
PROGRAM GROUP YN Yes/No: Member P1P2 Priority 1/2 Ch. T Default Transmit Ch.

PROGRAM FS-GROUP
S NS Selected /Not Selected P1P2 Priority 1/2 Channel

GROUP FULL CANNOT DELETE CANNOT CHANGE
16/15 Channels maximum. Remove a Channel (N/NS). 2 Channels minimum. Add a Channel (Y/S). Set other Channel to P1/P2/T then original P1/P2/T becomes Y/S.

PROGRAM SIGNAL
Select Channel then the CTCSS/DCS sub-audible signalling used on the Channel, from the list.

VERSION INFO
FW VER Firmware MAIN DB Database HW VER Hardware CAL DB Calibration

Radio Configuration

Write your settings

Note: Function keys use a toggle action e.g. on/off

	F1	F2	F3	External
Disabled				
Tones: Beeps on / off				
Economy Mode Control on / off				
One Touch Call (First Alpha Symbol)				
Channel's DTMF Preset				
Fixed Selcall Sequence				
Program Flexiscan Group				
Toggle Flexiscan on / off				
Preset Call #1 (Selcall)				
Preset Call #2 (Selcall)				
Emergency (Selcall)				
Nuisance Delete				
Repeater Talk Around on / off				
Repeater Access Tone				
Handset Mode on / off				
Low Power on / off				
Keypad Locked Long press to unlock				
Toggle Monitor on / off				
Disable Monitor				
Squelch Override on / off				
Backlighting on / off				
Night Use on / off				
Adjust Contrast of Display				
Handset Mode				
Volume				
Inactivity seconds =				

Alphanumeric Search
Type in the word you want. The radio will search and display the closest match.

WORD ABC1 ABC2...
When the word is displayed you can also scroll the list.

Conventional Features

Backlighting

When you press a key, backlighting is turned on. It turns off after 1-10 seconds of no activity. Set via a function key.

Night Use mode

If on, the keypad backlighting is turned on when there is activity on the channel or if the keypad or selector is used. Turns off after 1 to 10 seconds of no activity. Set via the Menu.

Handset mode

Speaker volume is reduced so that radio can be held near to the ear like a cellphone. Press PTT to talk, release PTT to listen.

Monitor mode

Listen to all traffic and all groups on a channel. Monitor mode automatically turns off after a preset time.

It can be reset by the despatcher or when some types of calls are made. It can be configured to override Selcall (Selcall mute) or both Selcall and CTCSS/DCS.

Squelch

Squelch allows reception of intelligible signals that are above the factory-set signal threshold, thus reducing noise. Set via the Menu to city or country.

Squelch Override

This overrides the squelch feature so that all signals are made audible. This may improve the signal reception in marginal areas, but will likely increase noise. It cannot be activated when a scan group is selected. Set via a function key.


Nuisance Delete

If a Channel in a Scan group is busy for a long time and you do not want to listen to the conversation, you can temporarily remove it from the scanning regime using Nuisance Delete.

To apply Nuisance Delete to the currently selected Channel, press the function key (if configured). This will remove the currently selected Channel from the scanning regime. Select the Scan Group again to reset and remove Nuisance Delete.


Standard Mode

Users on the same Channel can hear the message.




CTCSS/DCS Mode

Sub-audible tones enable specific calls to Channels or Groups.



Selcall Mode

Audible tones (beeps) enable selective calls to be made to Individuals or Groups.



Indicators

Slow flash = every 2 seconds
Medium flash = every 1 second
Fast flash = four per second

Flash fast Medium pitch beep, short duration, twice. Radio power-up sequence	Steady Transmit at normal power	
Flash medium Transmit at low power	Flash slow Handset mode	
Medium pitch beep, short duration. Function turned on	Low pitch beep, short duration. Function turned off	
Steady Channel is busy	Flash medium Monitor or Squelch Override	Flash slow Economy mode
Flash fast Medium pitch warble, long duration, repeating. Repeater talk around (RTA)	Steady Scan Group for activity or greatest signal strength	Flash medium Activity detected on a Scan Group
Medium pitch beep, long duration, three times. Call time is almost up, 10 seconds to go	Low pitch beep, for 1.5 seconds. Transmit timer has expired	
Low pitch beep, long duration. No transmit Channel is busy or transmit is inhibited by Selcall muting. Wait or use a free channel.	Medium pitch beep, short duration, two times. Squelch Override	

Accessory Use

Installing the Battery

Removing the Battery

Using the radio, lapel microphone and carry case

SAFETY
Do not use battery chargers in hazardous atmospheres under any circumstances.
Only use approved Intrinsically Safe (IS) accessories with IS radios.

Installing the D-clip

-
-
-
-

Removing the D-clip

-
-
-

Accessories

Contact your authorised Tait Dealer

Antennas
Belt Loop
6-Way Multi-Charger
Battery Charger
Battery
D-Clip
Accessory Connector Kits
Leather Carry Cases
Accessory Adaptors
Headphones
Earphones, Palm and Lapel Microphones
Speaker Microphones
Servicing and Programming Kits
Car Kit

Looking after your Radio

- ◆ Your radio does not require routine maintenance. However, it is a sophisticated electronic device and should be treated with care.
- ◆ Clean the radio, accessories and charger weekly using a clean dry lint-free cloth. When cleaning, do not use solvents, detergents, alcohol, aerosol sprays or petroleum-based products.
- ◆ Clean the electrical contacts on the battery and charger weekly using a fibre glass pencil, or the graphite tip of a type 4h (#4) or harder pencil.
- ◆ Do not put the radio and accessories in fluids.
- ◆ Do not drop the radio onto hard surfaces, place it down carefully.
- ◆ Do not use if the radio, antenna or accessories are damaged.
- ◆ Repairs and modifications must only be carried out by a Tait approved dealer.
- ◆ Always have the D-Clip or protective cover installed to protect the radio from dust ingress and electrostatic discharges.

Performance

To maintain the optimum performance of the radio:

- ◆ Use only the supplied antenna.
- ◆ Use only the radio and accessories for their design purpose.
- ◆ Use only accessories that are approved by Tait Electronics Ltd.
- ◆ Avoid high temperatures. If the temperature exceeds 80°C (176°F) the radio will make two short high-pitched beeps and will not work. Temperatures above 90°C (194°F) cause permanent damage to the radio.

To maintain the optimum performance of the battery:

- ◆ Charge the battery as soon as the radio gives the 'low battery' warning.
- ◆ Short condition the battery weekly.
- ◆ Long condition the battery only for the following reasons: on first use, if performance is poor, and after more than two weeks of storage.
- ◆ Do not charge a battery that has had little or no use.
- ◆ Do not leave charged batteries in the charger for more than a day.
- ◆ Turn the radio off when it is unattended for long periods.

Recycle

Recycle batteries that are of no use. Contact your authorised Tait dealer for advice.



Troubleshooting

- If the display is blank after turning on the radio and the radio turns itself off automatically after a few minutes, it is likely there is no power.
- Fast flash. Radio is incorrectly configured. Contact your authorised Tait dealer or your company administrator.
- Contact your authorised Tait dealer or your company administrator.
- Slow flash. Low pitch beep, short duration, every 5 seconds. Battery is low. Charge the battery.
- Low pitch beep for 10 seconds. Battery is too low to operate the radio. Turn off the radio. Charge the battery.
- High pitch beep, short duration, two times. Temperature is too high. Turn off the radio and allow the radio to cool down in a cool place.
- Fast flash. High pitch beeps. Radio is stunned. Contact the despatcher.

Checklist

- ◆ Is the radio turned on?
- ◆ Is the correct channel selected?
- ◆ Is the battery installed on the radio?
- ◆ Is the battery charged?
- ◆ Is the antenna damaged?
- ◆ Is the battery charger working properly?

Call Information

ACK RECEIVED STATUS32
Acknowledgement and status received from recipient of call.

NO ACKNOWLEDGE
No Acknowledge. Recipient has not acknowledged your call.

Security

KEYPAD LOCKED Keypad lock is on.
Long press to unlock

ENTER CODE Enter Security PIN code using keypad (personal identification number).

Belt Loop

- Install the Belt Loop
- Install the Radio
- Install the Carry Case

Remove by peeling apart

Note for Accessories
To use the belt loop, the accessory needs the D-clip fitting. For example: a lapel microphone.

Carry Case

Installing the Radio and Carry Case

- Install the Radio
- Install the Carry Case
- Install the clip

Removing the Radio and Carry Case

- Rotate the Carry Case by 180 degrees
- Slide the Carry Case upwards
- Unfasten the Clip and remove the Radio

Safety Precautions

- ◆ When transmitting, hold the radio microphone 25–50mm (1–2 inches) from your mouth.
- ◆ When transmitting, keep the antenna at least 25mm (1 inch) from any part of your body, especially your face and eyes.
- ◆ Turn off the radio where radio waves could interfere with electronic devices.
- ◆ Turn off the radio at fuel/gas stations.
- ◆ Turn off the radio in an area where detonators/explosives are being used.
- ◆ Turn off the radio before boarding/leaving an aircraft and whilst on board an aircraft.
- ◆ Do not use the radio whilst driving vehicles or operating machinery.
- ◆ Do not use earphones or headsets at high volume levels.
- ◆ Do not transmit in frequency bands used by distress beacons, such as 406–406.1 MHz.
- ◆ Do not put the radio, battery or accessories in liquids as they will be damaged.
- ◆ Do not allow children to play with the radio; it is not a toy.

Hazardous Atmospheres

A hazardous atmosphere has the potential for fire or explosion from dusts, gases, liquids and solids. Make sure of the following in hazardous atmospheres:

- ◆ Only use approved Intrinsically Safe (IS) radios, batteries and other accessories. Refer to the service manual for a list of approved items.
- ◆ Do not use battery chargers in hazardous atmospheres.
- ◆ Turn off and do not use non-approved radios.
- ◆ Only use IS batteries with IS radios.
- ◆ Do not use damaged or cracked radios.
- ◆ Do not modify IS radios.



Electromagnetic Interference

Turn off the radio where radio waves could interfere with electronic devices. Some facilities use equipment that is sensitive to Electromagnetic Interference such as: hospitals, medical centres, aircraft and some industrial facilities. Only use your radio in these situations if the radio is qualified for use in such areas.

Note: The warning below applies to FCC approved radios in 800 MHz and 900 MHz frequency bands:

FCC RF Exposure Limits

- This product generates radio frequency energy during transmissions. It is classified by the FCC as suitable for general population use in an uncontrolled exposure environment. The following conditions apply to the use of this radio:
- ◆ It must only be used with authorised accessories and antennas.
 - ◆ Do not exceed a duty cycle ratio of 20% transmit mode to standby or receive modes. The radio is in transmit mode when the PTT key on the radio is pressed and the TX indicator LED is lit.

