

TM8000 mobiles

TM8100 Mobile Radio
Accessories Manual



Contact Information

Tait Radio Communications

<http://www.taitworld.com>

Corporate Head Office New Zealand

Tait Electronics Ltd
P.O. Box 1645
Christchurch
New Zealand

E-mail (Sales): info@taitworld.com
E-mail (Support): support@taitworld.com
URL (Support): <http://support.taitworld.com>
URL (Corporate): <http://www.taitworld.com>

Tait North America

Regional Head Office -
United States of America
Tait North America Inc
E-mail: usa@taitworld.com

Canada
Tait North America Inc
E-mail: canada@taitworld.com

Latin America

Tait Latin America
E-mail: latinamerica@taitworld.com

Tait Europe

Regional Head Office - United Kingdom
Tait Mobile Radio Ltd
E-mail: teusales@tait.co.uk

Tait North Asia

Regional Head Office - Hong Kong
Tait Mobile Radio (Hong Kong) Ltd
E-mail: hongkong@taitworld.com

Beijing
Tait Mobile Radio (Hong Kong) Ltd
E-mail: beijing@taitworld.com

Tait South Asia

Regional Head Office - Singapore
Tait Electronics (Far East) Pte Ltd
E-mail: singapore@taitworld.com

Thailand
Tait Mobile Radio Ltd
E-mail: thailand@taitworld.com

Oceania

New Zealand
Tait Communications Ltd
E-mail: headoffice@tcl.tait.co.nz

Australia
Tait Electronics (Aust) Pty Ltd
E-mail: australia@taitworld.com

Note: For the addresses and phone numbers of the above regional offices refer to the TaitWorld website.

Tait General Software Licence Agreement

This legal document is an Agreement between you (the “Licensee”) and Tait Electronics Limited (“Tait”). By using any of the Software or Firmware items prior-installed in the related Tait product, included on this CD or downloaded from the Tait website, (hereinafter referred to as “the Software or Firmware”) you agree to be bound by the terms of this Agreement. If you do not agree to the terms of this Agreement, do not install and use any of the Software or Firmware. If you install and use any of the Software or Firmware that will be deemed to be acceptance of the terms of this licence agreement.

The terms of this agreement shall apply subject only to any express written terms of agreement to the contrary between Tait and the Licensee.

Licence

TAIT GRANTS TO YOU AS LICENSEE THE NON-EXCLUSIVE RIGHT TO USE THE SOFTWARE OR FIRMWARE ON A SINGLE MACHINE PROVIDED YOU MAY ONLY:

1. COPY THE SOFTWARE OR FIRMWARE INTO ANY MACHINE READABLE OR PRINTED FORM FOR BACKUP PURPOSES IN SUPPORT OF YOUR USE OF THE PROGRAM ON THE SINGLE MACHINE (CERTAIN PROGRAMS, HOWEVER, MAY INCLUDE MECHANISMS TO LIMIT OR INHIBIT COPYING, THEY ARE MARKED “COPY PROTECTED”), PROVIDED THE COPYRIGHT NOTICE MUST BE REPRODUCED AND INCLUDED ON ANY SUCH COPY OF THE SOFTWARE OR FIRMWARE; AND / OR
2. MERGE IT INTO ANOTHER PROGRAM FOR YOUR USE ON THE SINGLE MACHINE (ANY PORTION OF ANY SOFTWARE OR FIRMWARE MERGED INTO ANOTHER PROGRAM WILL CONTINUE TO BE SUBJECT TO THE TERMS AND CONDITIONS OF THIS AGREEMENT).

THE LICENSEE MAY NOT DUPLICATE, MODIFY, REVERSE COMPILE OR REVERSE ASSEMBLE ANY SOFTWARE OR FIRMWARE IN WHOLE OR PART.

Title to Software

THIS AGREEMENT DOES NOT CONSTITUTE A CONTRACT OF SALE IN RELATION TO THE SOFTWARE OR FIRMWARE SUPPLIED TO THE LICENSEE. NOT WITHSTANDING THE LICENSEE MAY OWN THE MAGNETIC OR OTHER PHYSICAL MEDIA ON WHICH THE SOFTWARE OR FIRMWARE WAS ORIGINALLY SUPPLIED, OR HAS SUBSEQUENTLY BEEN RECORDED OR FIXED, IT IS A FUNDAMENTAL TERM OF THIS AGREEMENT THAT AT ALL TIMES TITLE AND OWNERSHIP OF THE SOFTWARE OR FIRMWARE, WHETHER ON THE ORIGINAL MEDIA OR OTHERWISE, SHALL REMAIN VESTED IN TAIT OR THIRD PARTIES WHO HAVE GRANTED LICENCES TO TAIT.

Term and Termination

THIS LICENCE SHALL BE EFFECTIVE UNTIL TERMINATED IN ACCORDANCE WITH THE PROVISIONS OF THIS AGREEMENT. THE LICENSEE MAY TERMINATE THIS LICENCE AT ANY TIME BY DESTROYING ALL COPIES OF THE SOFTWARE OR FIRMWARE AND ASSOCIATED WRITTEN MATERIALS. THIS LICENCE WILL BE TERMINATED AUTOMATICALLY AND WITHOUT NOTICE FROM TAIT IN THE EVENT THAT THE LICENSEE FAILS TO COMPLY WITH ANY TERM OR CONDITION OF THIS AGREEMENT. THE LICENSEE AGREES TO DESTROY ALL COPIES OF THE SOFTWARE OR FIRMWARE AND ASSOCIATED WRITTEN MATERIALS IN THE EVENT OF SUCH TERMINATION.

Limited Warranty

THE SOFTWARE OR FIRMWARE IS SUPPLIED BY TAIT AND ACCEPTED BY THE LICENSEE “AS IS” WITHOUT WARRANTY OF ANY KIND EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT BEING LIMITED TO ANY IMPLIED WARRANTIES AS TO MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. THE LICENSEE ACKNOWLEDGES THAT THE SOFTWARE OR FIRMWARE IS USED BY IT IN BUSINESS AND ACCORDINGLY TO THE MAXIMUM EXTENT PERMITTED BY LAW NO TERMS OR WARRANTIES WHICH ARE IMPLIED BY LEGISLATION SHALL APPLY TO THIS AGREEMENT. TAIT DOES NOT WARRANT THAT THE FUNCTIONS CONTAINED IN THE SOFTWARE OR FIRMWARE WILL MEET THE LICENSEE’S REQUIREMENTS OR THAT THE OPERATION OF THE SOFTWARE OR FIRMWARE WILL BE UNINTERRUPTED OR ERROR FREE.

Exclusion of Liability

TAIT'S ENTIRE LIABILITY AND THE LICENSEE'S EXCLUSIVE REMEDY SHALL BE THE FOLLOWING:

1. IN NO CIRCUMSTANCES SHALL TAIT BE UNDER ANY LIABILITY TO THE LICENSEE, OR ANY OTHER PERSON WHATSOEVER, FOR ANY DIRECT OR CONSEQUENTIAL DAMAGE ARISING OUT OF OR IN CONNECTION WITH ANY USE OR INABILITY OF USING THE SOFTWARE OR FIRMWARE.
2. TAIT WARRANTS THE OPERATION OF THE SOFTWARE OR FIRMWARE ONLY WITH THE OPERATING SYSTEM FOR WHICH IT WAS DESIGNED. USE OF THE SOFTWARE OR FIRMWARE WITH AN OPERATING SYSTEM OTHER THAN THAT FOR WHICH IT WAS DESIGNED MAY NOT BE SUPPORTED BY TAIT, UNLESS OTHERWISE EXPRESSLY AGREED BY TAIT.

General

THE LICENSEE CONFIRMS THAT IT SHALL COMPLY WITH THE PROVISIONS OF LAW IN RELATION TO THE SOFTWARE OR FIRMWARE.

Law and Jurisdiction

THIS AGREEMENT SHALL BE SUBJECT TO AND CONSTRUED IN ACCORDANCE WITH NEW ZEALAND LAW AND DISPUTES BETWEEN THE PARTIES CONCERNING THE PROVISIONS HEREOF SHALL BE DETERMINED BY THE NEW ZEALAND COURTS OF LAW. PROVIDED HOWEVER TAIT MAY AT ITS ELECTION BRING PROCEEDINGS FOR BREACH OF THE TERMS HEREOF OR FOR THE ENFORCEMENT OF ANY JUDGEMENT IN RELATION TO A BREACH OF THE TERMS HEREOF IN ANY JURISDICTION TAIT CONSIDERS FIT FOR THE PURPOSE OF ENSURING COMPLIANCE WITH THE TERMS HEREOF OR OBTAINING RELIEF FOR BREACH OF THE TERMS HEREOF.

No Dealings

THE LICENSEE MAY NOT SUBLICENSE, ASSIGN OR TRANSFER THE LICENCE OR THE PROGRAM EXCEPT AS EXPRESSLY PROVIDED IN THIS AGREEMENT. ANY ATTEMPT OTHERWISE TO SUBLICENSE, ASSIGN OR TRANSFER ANY OF THE RIGHTS, DUTIES OR OBLIGATIONS HEREUNDER IS VOID.

No Other Terms

THE LICENSEE ACKNOWLEDGES THAT IT HAS READ THIS AGREEMENT, UNDERSTANDS IT AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. THE LICENSEE FURTHER AGREES THAT SUBJECT ONLY TO ANY EXPRESS WRITTEN TERMS OF AGREEMENT TO THE CONTRARY BETWEEN TAIT AND THE LICENSEE THIS IS THE COMPLETE AND EXCLUSIVE STATEMENT OF THE AGREEMENT BETWEEN IT AND TAIT IN RELATION TO THE SOFTWARE OR FIRMWARE WHICH SUPERSEDES ANY PROPOSAL OR PRIOR AGREEMENT, ORAL OR WRITTEN AND ANY OTHER COMMUNICATIONS BETWEEN THE LICENSEE AND TAIT RELATING TO THE SOFTWARE OR FIRMWARE.

Contents

| | |
|--|-----------|
| Contact Information | 2 |
| Tait General Software Licence Agreement | 3 |
| Preface | 7 |
| Scope of Manual | 7 |
| Enquiries and Comments | 7 |
| Updates of Manual and Equipment | 7 |
| Copyright | 7 |
| Disclaimer | 7 |
| Associated Documentation | 8 |
| Publication Record | 8 |
| Alert Notices | 8 |
| Abbreviations | 9 |
| | |
| 1 Safety and Servicing Information | 11 |
| 1.1 Personal Safety | 11 |
| Explosive Environments | 11 |
| Proximity to RF Transmissions | 11 |
| High Temperatures | 11 |
| 1.2 Equipment Safety | 11 |
| ESD Precautions | 11 |
| Antenna Load | 12 |
| 1.3 Identifying Screw Types | 12 |
| Torx Recess Head Screws | 12 |
| Allen UNC Screws | 13 |
| Pozidriv and Philips Screws | 13 |
| 1.4 Regulatory Information | 14 |
| 1.5 PCB Information | 14 |
| | |
| 2 TMAA01-05 Options-Extender Board | 15 |
| 2.1 Changing the Options-Extender Links | 15 |
| Power Supply Line | 16 |
| RX_BEEP_IN Line | 16 |
| 2.2 Installing the Options-Extender Board | 17 |
| Parts Required | 17 |
| Installation Procedure | 17 |
| 2.3 Interface Specification | 19 |
| 2.4 PCB Information | 21 |
| TMAA01-05 Parts List (PCB IPN 226-00129-02) | 21 |
| Options-Extender Board Layout (top side) | 23 |
| Options-Extender Board Layout (bottom side) | 24 |
| Options-Extender Board Circuit Diagram | 25 |

| | | |
|----------|---|-----------|
| 3 | TMAA02-02 DTMF Microphone | 27 |
| 3.1 | Installation | 27 |
| | Installing the Microphone. | 27 |
| | Installing the Microphone Clip | 28 |
| 3.2 | Adjustment. | 28 |
| 3.3 | Radio Programming | 28 |
| 3.4 | Interface Specification | 28 |
| 3.5 | Circuit Description | 29 |
| | | |
| 4 | TMAA10-01 Desktop Microphone | 31 |
| 4.1 | Operation. | 31 |
| 4.2 | Installation | 31 |
| 4.3 | Adjustment. | 32 |
| 4.4 | Interface Specification | 32 |
| 4.5 | Circuit Description | 33 |
| | | |
| 5 | TMAA10-04 Hands-Free Kit | 35 |
| 5.1 | Installation | 35 |
| | Installing the Microphone. | 35 |
| | Installing the Remote PTT. | 36 |
| 5.2 | Radio Programming | 36 |
| | Hands-Free PTT Form Settings | 36 |
| | Hands-Free Programmable I/O Form Settings. | 36 |
| 5.3 | Interface Specification | 37 |
| 5.4 | Circuit Description | 37 |
| 5.5 | PCB Information | 38 |
| | TMAA10-04 Parts List (PCB IPN 220-01711-01) | 38 |
| | Hands-Free Pre-Amplifier Board Layout (top side) | 39 |
| | Hands-Free Pre-Amplifier Board Layout (bottom side) | 40 |
| | Hands-Free Pre-Amplifier Board Circuit Diagram | 41 |

Preface

Scope of Manual

This manual contains information on installing, operating and servicing accessory products for TM8100 radios.

Enquiries and Comments

If you have any enquiries regarding this manual, or any comments, suggestions and notifications of errors, please contact Technical Support (refer to [“Contact Information” on page 2](#)).

Updates of Manual and Equipment

In the interests of improving the performance, reliability or servicing of the equipment, Tait Electronics Ltd reserves the right to update the equipment or this manual or both without prior notice.

Copyright

All information contained in this manual is the property of Tait Electronics Ltd. All rights are reserved. This manual may not, in whole or in part, be copied, photocopied, reproduced, translated, stored, or reduced to any electronic medium or machine-readable form, without prior written permission from Tait Electronics Ltd.

All trade names referenced are the service mark, trademark or registered trademark of the respective manufacturers.

Disclaimer

There are no warranties extended or granted by this manual. Tait Electronics Ltd accepts no responsibility for damage arising from use of the information contained in the manual or of the equipment and software it describes. It is the responsibility of the user to ensure that use of such information, equipment and software complies with the laws, rules and regulations of the applicable jurisdictions.

Associated Documentation

MM8100-00-03-804 TM8100 User's Guide

MM8100-02-00-812 TM8100 Service Manual

All available TM8100 product documentation is provided on the TM8100 Product Support CD, product code TMAA20-01. Updates may also be published on the Tait support website.

Publication Record

| Issue | Publication Date | Description |
|-------|------------------|---------------|
| 1 | September 2003 | first release |

Alert Notices

Within this manual, four types of alerts are given to the reader: warning, caution, important and note. The following paragraphs illustrate each type of alert and its associated symbol.



Warning!! This alert is used when there is a potential risk of death or serious injury.



Caution This alert is used when there is the risk of minor or moderate injury to people.



Important This alert is used to warn about the risk of equipment damage or malfunction.



Note This alert is used to highlight information that is required to ensure that procedures are performed correctly.

Abbreviations

| Abbreviation | Description |
|---------------------|--|
| AF | Audio Frequency |
| ALC | Automatic Level Control |
| CD | Compact Disk |
| CMOS | Complementary Metal Oxide Semiconductor |
| DTMF | Dual Tone Multiple Frequency |
| ESD | Electrostatic Discharge |
| IC | Integrated Circuit |
| IPN | Internal Part Number |
| LED | Light Emitting Diode |
| NB | Narrow Bandwidth (12.5kHz channel spacing) |
| PABX | Private Automatic Branch Exchange |
| PCB | Printed Circuit Board |
| PGA | Programmable-Gain Amplifier |
| PSTN | Public Switched Telephone Network |
| PTT | Press-To-Talk |
| PSTN | Public Switched Telephone Network |
| RF | Radio Frequency |
| SPI | Serial Peripheral Interface |
| WB | Wide Bandwidth (25kHz channel spacing) |

1 Safety and Servicing Information

This chapter contains general information about safety and servicing procedures when working with TM8000 radios. While many TM8100 accessories plug into external radio interfaces, some accessories are fitted inside the radio. Refer to the TM8100 Service Manual for detailed disassembly and reassembly information

1.1 Personal Safety

Explosive Environments



Warning!! Do not operate equipment near electrical blasting caps or in an explosive atmosphere. Operating the equipment in these environments is a definite safety hazard.

Proximity to RF Transmissions

Do not operate the transmitter when someone is standing within 0.9m (35 inches) of the antenna. Do not operate the transmitter unless you have checked that all RF connectors are secure.

High Temperatures

The bottom surface of the radio and heatsink fins can become hot during prolonged operation. Do not touch these parts of the radio.

1.2 Equipment Safety

ESD Precautions




Important This equipment contains devices which are susceptible to damage from static discharges. You must handle these devices carefully and according to the procedures described in the manufacturers' data books.

Purchase an antistatic bench kit from a reputable manufacturer and install and test it according to the manufacturer's instructions. Figure 1.1 shows a typical antistatic bench set-up.

You can obtain further information on antistatic precautions and the dangers of electrostatic discharge (ESD) from standards such as ESD S4.1-1997 (revised) or BS EN 100015-4 1994. The Electrostatic Discharge Association website is <http://www.esda.org/>.

Figure 1.1 Typical antistatic bench set-up



Antenna Load

The TM8100 radio has been designed to operate safely under a wide range of antenna loading conditions. However, the radio should always be operated with a suitable load to prevent damage to the transmitter output power stage.

1.3 Identifying Screw Types

Torx Recess Head Screws

Torx recess head screws are the standard type of screw used in TM8100 equipment, although Pozidriv head screws are also used in a few special applications.


The Torx recess head has the advantage of improved screwdriver tip location, reducing the chances of screw head damage caused by the driver tip rotating within the recess. In addition, using a ball-tip Torx screwdriver allows you to drive a Torx head screw with the driver on a slight angle, which can be useful in situations where access is restricted.

It is important that you use the correct Torx screwdriver tip:

- M2.5 screws - T8
- M3 screws - T10
- M4 screws - T20.

Figure 1.2 below shows a typical Torx recess head screw (the actual hardware may differ slightly from this illustration due to variations in manufacturing techniques).

Figure 1.2 Identifying Torx screws



Allen UNC Screws

Allen 4-40 UNC thread screws are used in some locations in the TM8100 radio and cannot be interchanged with M3 screws.

Pozidriv and Philips Screws

Both Pozidriv and Philips head screws are used on certain TM8100 accessories. It is important that you use the correct type and size screwdriver to avoid damaging screw heads.


It is particularly important that you do not use Philips screwdrivers on Pozidriv screw heads as the tapered driving flutes of the Philips screwdriver do not engage correctly with the parallel-sided slots in the Pozidriv screw head. This can result in considerable damage to the screw head if the screwdriver tip turns inside the recess.



Note If you find you need excessive downwards pressure to keep the screwdriver tip in the Pozidriv screw head, you are probably using the wrong type or size screwdriver.

Figure 1.3 on the following page shows the main differences between typical Pozidriv and Philips screw heads and screwdriver tips (actual hardware may differ slightly from these illustrations due to variations in manufacturing techniques).

Figure 1.3 Identifying Pozidriv and Philips screws and screwdrivers



1.4 Regulatory Information

Any modifications you make to this equipment which are not authorised by Tait Electronics Ltd may invalidate your compliance authority's approval to operate the equipment.


1.5 PCB Information

All PCBs are identified by a unique 10 digit IPN (internal part number) which is printed onto the PCB (usually on the top side), as shown in the example below:

226-00124-03

The last two digits of this number define the issue status, which starts at 01 and increments through 02,03, 04, etc. as the PCB is updated. If the PCB information contained in a section of this manual does not match the PCB number printed on your board, contact Technical Support (refer to ["Contact Information" on page 2](#)).

2 TMAA01-05 Options-Extender Board



The TMAA01-05 options-extender board provides external access to most of the signal lines provided by the radio's internal options connector.

The options-extender board fits inside the radio in the options cavity and is connected to the main PCB by the internal options connector and loom.

The internal options connector signals are then made available on the high-density 15-way D-range connector mounted on the options-extender board. This connector fits through the external options connector hole provided in the radio chassis.

2.1 Changing the Options-Extender Links

The options-extender board configuration must be completed before the board is installed in the radio, as the top side of the options-extender board is not accessible once the board is screwed to the radio lid.




Important This equipment contains devices which are susceptible to damage from static discharges. Refer to [“ESD Precautions” on page 11](#) for more information.

The options-extender board has various link options which allow the user to re-configure the outputs available on the external options connector. The outputs that can be made available by changing linking resistors are:

- the 5V supply line, and
- the RX_BEEP_IN line.

In both cases, these lines replace other lines that are available when the linking resistors are in the factory-set configuration. Note that there is no external connection available for the RX_AUD line.

Figure 2.1 Options-extender board linking resistor locations



2.1.1 Power Supply Line

The power supply output available on pin 2 of the external options connector is factory-set to 13.8V. The output on this pin can be changed to 5V if R11 (a 0Ω surface mount resistor) is moved to position R10. [Figure 2.1](#) at the top of the page shows the component locations.

2.1.2 RX_BEEP_IN Line

If the RX_BEEP_IN line is required on the external options connector, it must replace one of the following lines:

- IOP_RSSI
- AUD_TAP_IN
- AUX_MIC_AUD
- AUD_TAP_OUT.

The following table explains the resistor link changes required and [Figure 2.1](#) at the top of the page shows the component locations.

Table 2.1 RX_BEEP_IN resistor changes

| RX_BEEP_IN Line Replaces | Remove Resistor | Add Resistor |
|--------------------------|-----------------|--------------|
| IOP_RSSI | R2 | R3 |
| AUD_TAP_IN | R4 | R5 |
| AUX_MIC_AUD | R6 | R7 |
| AUD_TAP_OUT | R8 | R9 |

2.2 Installing the Options-Extender Board

2.2.1 Parts Required

The following table describes the parts required to install an options-extender board in a radio. The parts marked with an asterisk (★) are not shown in [Figure 2.2](#) and are used to connect to the radio's external options connector.

Table 2.2 Options-extender installation parts required

| Quantity | Internal Part Number | Description | Figure 2.2 Reference |
|----------|---------------------------|----------------------|----------------------|
| 1 | 362-01110-XX ^a | foam seal | ③ |
| 1 | 362-01108-XX ^a | cover seal | ⑪ |
| 2 | 347-00011-00 | 4-40x3/16 screws | ⑫ |
| 2 | 354-01043-00 | screw-lock fasteners | ⑦ |
| 4 | 349-02062-00 | M3x8 screws | ⑨ |
| ★1 | 240-00010-80 | D-range plug | — |
| ★1 | 240-06010-29 | D-range hood | — |

a. Contact Technical Support for the exact IPN.

2.2.2 Installation Procedure

1. Disassemble the radio in order to gain access to the options cavity.
For detailed disassembly instructions, refer to the disassembly procedure in the TM8100 Service Manual.

Refer to the diagram on the following page and the instructions below.

2. Remove the top cover and lid ① from the radio to access the options cavity.
3. Remove the external options connector bung ②, if it is fitted.
4. On the inside of the radio lid place the foam seal ③ over the external options connector cavity ④.
5. With the top side of the options-extender board ⑤ facing the radio lid, guide the external options connector ⑥ (the D-range connector on the options-extender board) into the external options connector cavity.
6. Screw the external options connector to the radio lid using the two screw-lock fasteners ⑦.

Tighten the fasteners to a torque of 0.9N·m (8lbf·in).




Important

The external options connector screw-lock fasteners must be tightened correctly before screwing the options-extender board onto the mounting posts ⑧.

7. Screw the options-extender board to the mounting posts on the radio lid using four M3x8 self-tapping screws ⑨.
Tighten the M3x8 screws to a torque of 1.9N·m (17lbf·in)
8. Plug the unattached end of internal options connector loom ⑩ into the internal options connector on the radio main PCB.
9. Refit the radio lid and top cover to the radio and screw the external options cover seal ⑪ over the external options connector, using the two 4-40x3/16 screws ⑫.

Figure 2.2 Options-extender board installation



2.3 Interface Specification

The following tables summarize the signals used for the options-extender board on the internal options connector (SK1 on the options-extender board) and the external options connector (SK2 on the options-extender board).




Note The TM8000 3DK Hardware Developer's Kit Application Manual (product code MMAA30-01-00-807) contains a detailed electrical specification for the signals available on the radio's internal options connector. This manual is part of the 3DK Resource CD, which can be purchased using product code TMAA30-01.

Table 2.3 Internal options connector - pins and signals

| | Pin | Connector Signal | Description |
|-----------------|------|------------------------|---|
| <p>top view</p> | 1 | 13V8_SW | switched 13V8 supply from the radio |
| | 2 | AUD_TAP_OUT | Programmable tap point out of the receive or transmit audio chain. DC-coupled |
| | 3 | AGND | analogue ground |
| | 4 | AUX_MIC_AUD | Auxiliary microphone input, with electret microphone biasing provided. Dynamic microphones are not supported. |
| | 5 | RX_BEEP_IN | receive sidetone input, AC-coupled |
| | 6 | AUD_TAP_IN | Programmable tap point into the receive or transmit audio chain. DC-coupled |
| | 7 | RX_AUD | not connected |
| | 8 | RSSI | analogue RSSI output |
| | 9-15 | IOP_GPIO1 to IOP_GPIO7 | programmable function and direction |
| | 16 | DGND | digital ground |
| | 17 | IOP_RXD | an RS-232 compliant asynchronous serial port - receive data |
| | 18 | IOP_TXD | an RS-232 compliant asynchronous serial port - transmit data |

Table 2.4 External options connector - pins and signals

| | Pin | Signal | Description |
|---|-----|--------------------------|---|
|  | 2 | 13V8_SW ^a | 13V8 supply |
| | 6 | AUD_TAP_OUT ^b | Programmable tap point out of the Rx or Tx audio chain. DC-coupled |
| | 7 | AGND | analogue ground |
| | 11 | AUX_MIC_AUD ^b | Auxiliary microphone input, with electret microphone biasing provided. Dynamic microphones are not supported. |
| | 1 | AUD_TAP_IN ^b | Programmable tap point into the Rx or Tx audio chain. DC-coupled. |
| | 3 | RSSI ^b | analogue RSSI output |
| | 15 | IOP_GPIO1 ^c | programmable function and direction |
| | 14 | IOP_GPIO2 ^c | programmable function and direction |
| | 13 | IOP_GPIO3 ^c | programmable function and direction |
| | 10 | IOP_GPIO4 ^c | programmable function and direction |
| | 9 | IOP_GPIO5 ^c | programmable function and direction |
| | 5 | IOP_GPIO6 ^c | programmable function and direction |
| | 4 | IOP_GPIO7 ^c | programmable function and direction |
| | 12 | IOP_RXD | an RS-232 compliant asynchronous serial port - receive data |
| | 8 | IOP_TXD | an RS-232 compliant asynchronous serial port - transmit data |


- a. This can be configured to be 5V. Refer to ["Power Supply Line" on page 16](#).
- b. This can be re-configured to be RX_BEEP_IN. Refer to ["RX_BEEP_IN Line" on page 16](#).
- c. 3V3 CMOS output via 1 kΩ series resistance. 5V tolerant input.

2.4 PCB Information

2.4.1 TMAA01-05 Parts List (PCB IPN 226-00129-02)


| Ref. | IPN | Description | Ref. | IPN | Description |
|------|--------------|--------------------------------|------|--------------|--------------------------------|
| C1 | 018-16100-00 | Cap 0603 100n 16vx7r+-10% | R2 | 036-10000-00 | Res M/F SMD 0805 0e 0.125w |
| C2 | 018-16100-00 | Cap 0603 100n 16vx7r+-10% | R4 | 036-10000-00 | Res M/F SMD 0805 0e 0.125w |
| C3 | 018-16100-00 | Cap 0603 100n 16vx7r+-10% | R6 | 036-10000-00 | Res M/F SMD 0805 0e 0.125w |
| C4 | 018-16100-00 | Cap 0603 100n 16vx7r+-10% | R8 | 036-10000-00 | Res M/F SMD 0805 0e 0.125w |
| C5 | 018-16100-00 | Cap 0603 100n 16vx7r+-10% | R11 | 036-10000-00 | Res M/F SMD 0805 0e 0.125w |
| C6 | 018-16100-00 | Cap 0603 100n 16vx7r+-10% | | | |
| C7 | 018-15100-00 | Cap 0603 10n 50v X7r +-10% | SK1 | 240-10000-11 | Conn SMD 18w Skt M/Match |
| C8 | 014-08100-30 | Cap Tant SMD 100u 10v Loesr D | SK2 | 240-00011-67 | Skt 15w Drng Ra Slim Dsub 7912 |
| C9 | 015-26100-08 | Cap Cer 0805 100n 10% X7r 50v | | | |
| C10 | 016-08470-01 | Cap Elec SMD 47uf 6*4 16v | | 226-00129-02 | PCB TMAA01-05 Opts Brd |
| C11 | 014-08100-30 | Cap Tant SMD 100u 10v Loesr D | | | |
| C12 | 018-16100-00 | Cap 0603 100n 16vx7r+-10% | | 240-00010-80 | Plg 15w Drng Hi-D |
| C13 | 016-08470-01 | Cap Elec SMD 47uf 6*4 16v | | 240-06010-29 | Conn 9w Hood/Cvr Lets |
| C14 | 018-15100-00 | Cap 0603 10n 50v X7r +-10% | | | |
| C15 | 018-15100-00 | Cap 0603 10n 50v X7r +-10% | | 219-00329-00 | Loom TMA Int Opt |
| C16 | 018-15100-00 | Cap 0603 10n 50v X7r +-10% | | 347-00011-00 | Scrw 4-40*3/16 Unc P/P Blk |
| C17 | 015-07220-35 | Cap Cer 1210 2u2 X5R 35v | | 349-02062-00 | Scrw M3*8 T/T P/T Conti Rmnc |
| C18 | 015-06470-01 | Cap Cer 1206 470n X7r 20% 50v | | 354-01043-00 | Fsnr Scrw Lok 1pr 4-40 |
| C19 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | 362-01108-00 | Seal Drng Cvr 9way TMA |
| C20 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | 362-01111-00 | Seal Drng 9way TMA |
| C21 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | | |
| C22 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | | |
| C23 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | | |
| C24 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | | |
| C25 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | | |
| C26 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | | |
| C27 | 018-13470-00 | Cap 0603 470p 50v X7r+-10% | | | |
| C28 | 018-15100-00 | Cap 0603 10n 50v X7r +-10% | | | |
| C29 | 015-07220-35 | Cap Cer 1210 2u2 X5R 35v | | | |
| D1 | 001-10014-03 | Diode SMD MBRS140T3 Sch | | | |
| D2 | 001-10099-01 | Diode BAV99w Dual Ss | | | |
| D3 | 001-10099-01 | Diode BAV99w Dual Ss | | | |
| D4 | 001-10099-01 | Diode BAV99w Dual Ss | | | |
| D5 | 001-10099-01 | Diode BAV99w Dual Ss | | | |
| D6 | 001-10099-01 | Diode BAV99w Dual Ss | | | |
| D7 | 001-10099-01 | Diode BAV99w Dual Ss | | | |
| D8 | 001-10099-01 | Diode BAV99w Dual Ss | | | |
| IC1 | 002-10020-20 | IC SMD ADM202 Rs-232 Con S0-16 | | | |
| IC2 | 002-10267-40 | IC LM2674 S08 Swtch Volt Regul | | | |
| L1 | 057-10100-65 | Ind SMD Pwr Cdrh6D38 100UH .65 | | | |
| L2 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L3 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L4 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L5 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L6 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L7 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L8 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L9 | 057-10010-45 | Ind SMD Pwr CDRH2D18 10UH .43A | | | |
| L10 | 057-10010-45 | Ind SMD Pwr CDRH2D18 10UH .43A | | | |
| L11 | 057-10600-05 | Ind 0603 Blm11p600s .5a F/Bead | | | |
| L12 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L13 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L14 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L15 | 057-10600-05 | Ind 0603 Blm11p600s .5a F/Bead | | | |
| L16 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L17 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |
| L18 | 057-10010-20 | Ind 0603 Blm11-B102s 0.1a | | | |

2.4.2 Options-Extender Board Layout (top side)




IPN 226-00129-02

2.4.3 Options-Extender Board Layout (bottom side)



IPN 226-00129-02

2.4.4 Options-Extender Board Circuit Diagram



3 TMAA02-02 DTMF Microphone



The TMAA02-02 DTMF microphone plugs into the microphone socket on the radio control head, and enables users to make calls to a PABX or PSTN.

To make a call, enter the required number using the DTMF keypad and the DTMF microphone generates DTMF tones as the microphone keys are pressed. Press the PTT key and speak clearly into the microphone then release the PTT key when you have finished speaking.

The microphone button operates a hookswitch, which is closed when the microphone is connected to the microphone clip and open when the microphone is removed from the microphone clip. The function of the hookswitch is determined by the radio programming.

3.1 Installation

3.1.1 Installing the Microphone




Important

The DTMF microphone grommet must be installed whenever the microphone is plugged into the microphone socket. When installed, the grommet has two functions:

- to prevent damage to the microphone socket when there is movement of the microphone cord, and
- to ensure that the control head is sealed against water, dust and other environmental hazards.

1. Plug the DTMF microphone cord into the microphone socket on the radio control head.
2. Slide the microphone grommet along the microphone cord and push two adjacent corners of the grommet into the microphone socket cavity.
3. Squeeze the grommet and push the remaining corners into position.
4. Check that the grommet is seated correctly in the cavity.

Figure 3.1 Correct DTMF microphone grommet seating



3.1.2 Installing the Microphone Clip

Install the microphone clip in the most convenient location for the radio user. It must be within easy reach of the user, but in such a position that the microphone PTT key cannot be inadvertently activated or jammed on.

Connect the microphone clip to the negative supply if hookswitch operation is required.

3.2 Adjustment

Remove the DTMF microphone back cover and set the DTMF tone level to approximately 80% deviation (± 4 kHz for wide bandwidth radios and ± 2 kHz for narrow bandwidth radios).


3.3 Radio Programming

Radio input and output lines can be configured in the Programmable I/O form of the TM8000 Programming Application. When a DTMF microphone is installed, the radio must have the CH_GPIO1 pin set to No Action. This is the default setting for this pin.

3.4 Interface Specification


The following table and diagram summarizes the signals used for the DTMF microphone on the radio's microphone connector and shows the interface between the DTMF microphone and the radio.

Table 3.1 DTMF microphone connector - pins and signals



| Pin | Signal | Colour | Description |
|-----|-----------|--------|---------------------------|
| 1 | — | — | not connected |
| 2 | 13V8_SW | red | power supply (switched) |
| 3 | — | yellow | not connected |
| 4 | MIC_PTT | black | PTT and hookswitch |
| 5 | MIC_AUD | white | audio from the microphone |
| 6 | AGND | blue | analogue ground |
| 7 | — | — | not connected |
| 8 | MIC_GPIO1 | green | mute out |

Figure 3.2 DTMF microphone to radio interface



3.5 Circuit Description

The microphone has a standard 12-key telephone keypad. When one of the keypad keys is pressed, a DTMF tone specific to that key is generated on the MIC_AUD line (pin 5). For the duration of the tone, the tone generator activates the PTT, so that the user is not required to press the PTT key to transmit each tone.

4 TMAA10-01 Desktop Microphone



The TMAA10-01 desktop microphone is an omnidirectional dynamic microphone which can be used in dispatch situations, where the microphone is positioned on a flat surface. The desktop microphone plugs into the microphone socket on the radio control head.

The desktop microphone has an internal pre-amplifier and an adjustable sensitivity control on the underside of the desktop microphone base.

4.1 Operation

Hold down the monitor key and check whether the channel is clear.

If the channel is clear, press the PTT key to transmit. Speak clearly into the microphone and release the PTT key when you have finished talking.



Note The monitor key can be locked in the 'on' position. To do this, hold the monitor key down and slide the monitor key towards you. The monitor key should now be locked on.

4.2 Installation




Important The desktop microphone grommet must be installed whenever the desktop microphone is plugged into the microphone socket. When installed, the grommet has two functions:

- to prevent damage to the microphone socket when there is movement of the microphone cord, and
- to ensure that the control head is sealed against water, dust and other environmental hazards.

1. Plug the microphone cord into the microphone socket on the radio control head.
2. Slide the grommet along the cord and push two adjacent corners of the grommet into the microphone socket cavity.

3. Squeeze the grommet and push the remaining corners into position.
4. Check that the grommet is seated correctly in the cavity.

Figure 4.1 Correct desktop microphone grommet seating



4.3 Adjustment

Adjust the output sensitivity of the desktop microphone using R5. R5 is accessible from the underside of the desktop microphone, as shown.

The microphone sensitivity is set to maximum by rotating R5 counterclockwise.




4.4 Interface Specification

The following table and diagram summarizes the signals used for the desktop microphone on the radio's microphone connector and shows the interface between the desktop microphone and the radio.

Table 4.1 Desktop microphone connector - pins and signals

| | Pin | Signal | Colour | Description |
|--|-----|---------|--------|---------------------------|
| | 1 | — | — | not connected |
| | 2 | — | — | not connected |
| | 3 | — | — | not connected |
| | 4 | MIC_PTT | yellow | PTT |
| | 5 | MIC_AUD | red | audio from the microphone |
| | 6 | AGND | bare | analogue ground |
| | 7 | — | — | not connected |
| | 8 | — | — | not connected |

Figure 4.2 Desktop microphone to radio interface



4.5 Circuit Description

The desktop microphone uses a dynamic microphone capsule and contains a pre-amplifier (Q1) to boost the microphone level to that required by the radio. Power for the pre-amplifier is provided by the electret microphone bias circuit within the radio. R5 is used to adjust the gain.

PTT and hookswitch signals are combined onto one line and fed to the control head PTT input of the radio.

5 TMAA10-04 Hands-Free Kit



The TMAA10-04 hands-free kit plugs into the radio's auxiliary connector and can be used in conjunction with the radio's rugged microphone. When hands-free operation is required, the user activates the PTT using the conveniently located remote PTT key, and the remote electret microphone replaces communication through the usual rugged microphone.

An extension lead is provided for the remote PTT and there are three mounting options for the remote microphone.

Note that the hands-free kit does not provide hookswitch operation. If this is required, the rugged microphone can provide this.



Important

The radio does not meet the IP54 protection standard once a hands-free kit has been installed.

5.1 Installation



Important

Care should be taken to avoid routing any cables near vehicle pedal controls, steering column and other moving parts.

5.1.1 Installing the Microphone

1. Choose one of the three mounting options provided for the remote microphone and determine the most appropriate location for the microphone.
The mounting position of the microphone should be no more than 50cm (20 inches) from the user's mouth.
2. Route the remote microphone cable so as not to distract the driver.
3. Mount the remote microphone in the chosen location and check that the microphone and cable are clear of all the usual movements performed by the user.

5.1.2 Installing the Remote PTT



Important The remote PTT must be operable from a normal driving position.

1. Secure the remote PTT in position using the velcro strap and plug the remote PTT cord into the remote PTT extension lead.

A common position for the remote PTT is on the gear lever of the vehicle.

2. Check that the cord and lead do not interfere with the safe operation of the vehicle.

5.2 Radio Programming

The following tables show the settings required in the PTT form and Programmable I/O form of the TM8000 Programming Application. Some of these settings are default settings and may not need to be changed. Refer to the online help of the programming application for more information.

5.2.1 Hands-Free PTT Form Settings



Note If hookswitch operation is programmed for the rugged microphone and the Inhibit PTT Transmission When Mic On Hook field is selected in the PTT tab of the PTT form, then the hands-free remote PTT cannot transmit when the rugged microphone hookswitch is closed (the microphone is on the microphone clip).

Table 5.1 Hands-free settings in the PTT form, External PTT (1) tab

| Field | | Setting |
|----------------|-----------------------|---------|
| Advanced EPTT1 | PTT Transmission Type | Voice |
| | Audio Source | AUX MIC |

5.2.2 Hands-Free Programmable I/O Form Settings



Note The Programmable I/O form setting for AUX_GPIO4 must have the default programming settings and the AUX_GPIO4 pullup resistor on the radio main PCB must be set for the factory default of 3.3V (R769 fitted).

Table 5.2 Hands-free settings in the Programmable I/O form, Digital tab

| Pin | Direction | Label | Action | Active | Debounce | Signal State | Mirrored To |
|-----------|-----------|-------|----------------|--------|----------|--------------|-------------|
| AUX_GPI1 | Input | None | External PTT 1 | Low | 25 | None | None |
| AUX_GPIO4 | None | None | No Action | None | None | None | None |

5.3 Interface Specification

The following table and diagram summarizes the signals used for the hands-free kit on the radio's auxiliary connector and shows the interface between the hands-free kit and the radio.

Table 5.3 Auxiliary connector - pins and signals



| | Pin | Signal name | Description |
|--|-----|-------------|--|
|  rear view | 8 | +13V8_SW | power to hands-free microphone pre-amplifier |
| | 10 | AUX_GPIO4 | reference voltage to pre-amplifier regulator |
| | 12 | AUX_GPI1 | PTT signal from hands-free kit |
| | 14 | AUX_MIC_AUD | microphone audio to the radio |
| | 15 | AGND | analogue ground |

Figure 5.1 Hands-free to radio interface



5.4 Circuit Description

The hands-free microphone signal is amplified by a pre-amplifier in the auxiliary connector plug. The power supply to this amplifier is provided by the +13.8V supply on the auxiliary connector. This supply is filtered and regulated down to approximately 3.3V. The reference voltage for the regulator is provided by AUX_GPIO4 line.


The hands-free microphone signal is fed via AUX_MIC_AUD and an input selector to the radio's internal microphone amplifier. The microphone input selected depends on the PTT source used to make the call. If the remote PTT is used, then AUX_MIC_AUD is selected. If the control head microphone PTT is used, then CH_MIC_AUD is selected. Test points for all other auxiliary connections are provided on the auxiliary connector plug PCB to facilitate the connection of other devices or signals e.g ignition switch signal.

5.5 PCB Information

5.5.1 TMAA10-04 Parts List (PCB IPN 220-01711-01)

| Ref. | IPN | Description | Ref. | IPN | Description |
|------|--------------|-------------------------------|------|-----|-------------|
| C2 | 015-26330-08 | Cap Cer 0805 330n 5% 10v X7r | | | |
| C3 | 018-15100-00 | Cap 0603 10n 50v X7r +-10% | | | |
| C4 | 015-26330-08 | Cap Cer 0805 330n 5% 10v X7r | | | |
| C6 | 015-26100-08 | Cap Cer 0805 100n 10% X7r 50v | | | |
| C7 | 015-26100-08 | Cap Cer 0805 100n 10% X7r 50v | | | |
| Q1 | 000-10084-71 | Xstr BC847BW NPN SOT323 | | | |
| Q2 | 000-10085-71 | Xstr SMD BC857BW PNP SOT323 | | | |
| Q3 | 000-10084-71 | Xstr BC847BW NPN SOT323 | | | |
| Q4 | 000-10084-71 | Xstr BC847BW NPN SOT323 | | | |
| R1 | 038-14220-00 | Res 0603 2k2 1/16w +-5% | | | |
| R3 | 038-14390-10 | Res 0603 3k9 1% | | | |
| R4 | 038-15470-10 | Res 0603 47k 1/16w+-1% | | | |
| R6 | 038-15330-10 | Res 0603 33k 1% | | | |
| R13 | 038-15100-10 | Res 0603 10k 1/16w +-1% | | | |
| R16 | 038-15470-10 | Res 0603 47k 1/16w+-1% | | | |
| R17 | 038-15150-00 | Res 0603 15k 1/16w +-5% | | | |
| R18 | 038-15100-10 | Res 0603 10k 1/16w +-1% | | | |
| R19 | 038-15100-10 | Res 0603 10k 1/16w +-1% | | | |
| | 219-00305-00 | cable | | | |
| | 220-01711-01 | Pcb HFree | | | |
| | 236-00001-00 | Sw Ptt W/Cbl & Strap | | | |
| | 240-00020-55 | Plg 15w Drng 105 Deg Pnl Mtg | | | |
| | 240-06010-18 | Conn 15w Hood/Cvr Drng MDJ15 | | | |
| | 252-00010-72 | Mic Electret Unidir 2.5mm Plg | | | |

5.5.2 Hands-Free Pre-Amplifier Board Layout (top side)



5.5.3 Hands-Free Pre-Amplifier Board Layout (bottom side)

