

MD0621A
V.24/V.28 (RS-232C)
Interface Unit
Operation Manual

Fourth Edition

Read this manual before using the equipment.
Keep this manual with the equipment.

JUN.
2004


ANRITSU CORPORATION


Document No.: M-W0595AE-4.0


Safety Symbols

To prevent the risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Insure that you clearly understand the meanings of the symbols BEFORE using the equipment. Some or all of the following five symbols may not be used on all Anritsu equipment. In addition, there may be other labels attached to products which are not shown in the diagrams in this manual.

Symbols used in manual

DANGER  This indicates a very dangerous procedure that could result in serious injury or death if not performed properly.

WARNING  This indicates a hazardous procedure that could result in serious injury or death if not performed properly.

CAUTION  This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction, if proper precautions are not taken.

Safety Symbols Used on Equipment and in Manual

The following safety symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions. Insure that you clearly understand the meanings of the symbols and take the necessary precautions BEFORE using the equipment.



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.



This indicates an obligatory safety precaution. The obligatory operation is indicated symbolically in or near the circle.



This indicates warning or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



These indicate that the marked part should be recycled.

MD0621A V.24/V28 (RS-232) Interface Unit
Operation Manual

November 1990 (First Edition)
March 2003 (Fourth Edition)

Copyright © 1990-2003, ANRITSU CORPORATION.

All rights reserved. No part of this manual may be reproduced without the prior written permission of the publisher.

The contents of this manual may be changed without prior notice.

Printed in Japan

For Safety

WARNING



Repair

WARNING 

1. Always refer to the operation manual when working near locations at which the alert mark shown on the left is attached. If the operation, etc., is performed without heeding the advice in the operation manual, there is a risk of personal injury. In addition, the equipment performance may be reduced.

Moreover, this alert mark is sometimes used with other marks and descriptions indicating other dangers.

2. This equipment cannot be repaired by the user. DO NOT attempt to open the cabinet or to disassemble internal parts. Only Anritsu-trained service personnel or staff from your sales representative with a knowledge of electrical fire and shock hazards should service this equipment. There are high-voltage parts in this equipment presenting a risk of severe injury or fatal electric shock to untrained personnel. In addition, there is a risk of damage to precision parts.

(Blank)

Equipment Certificate

Anritsu Corporation certifies that this equipment was tested before shipment using calibrated measuring instruments with direct traceability to public testing organizations recognized by national research laboratories including the Electrotechnical Laboratory, the National Research Laboratory and the Communication Research laboratory, and was found to meet the published specifications.

Anritsu Warranty

Anritsu Corporation will repair this equipment free-of-charge if a malfunction occurs within 1 year after shipment due to a manufacturing fault, provided that this warranty is rendered void under any or all of the following conditions.

- The fault is outside the scope of the warranty conditions described in the operation manual.
- The fault is due to misoperation, misuse, or unauthorized modification or repair of the equipment by the customer.
- The fault is due to severe usage clearly exceeding normal usage.
- The fault is due to improper or insufficient maintenance by the customer.
- The fault is due to natural disaster including fire, flooding and earthquake, etc.
- The fault is due to use of non-specified peripheral equipment, peripheral parts, consumables, etc.
- The fault is due to use of a non-specified power supply or in a non-specified installation location.

In addition, this warranty is valid only for the original equipment purchaser. It is not transferable if the equipment is resold.

Anritsu Corporation will not accept liability for equipment faults due to unforeseen and unusual circumstances, nor for faults due to mishandling by the customer.

Anritsu Corporation Contact

If this equipment develops a fault, contact the head office of Anritsu Corporation at the address in the operation manual, or your nearest sales or service office listed on the following pages.

(Blank)

TABLE OF CONTENTS

	For Safety	iii
SECTION	1 GENERAL	1-1
	1.1 Introduction	1-1
	1.2 Features	1-2
	1.3 Composition	1-3
	1.4 Specifications	1-4
	1.4.1 Operating conditions	1-4
	1.4.2 Send clock	1-4
	1.4.3 Receive clock	1-4
	1.4.4 Send pattern	1-4
	1.4.5 Error insertion	1-5
	1.4.6 START/STOP Synchronization	1-5
	1.4.7 Error measurement	1-5
	1.4.8 Pattern trace function	1-5
	1.4.9 DC voltage measurement	1-5
	1.4.10 Frequency measurement and count	1-5
	1.4.11 Time measurement	1-6
	1.4.12 Signal line monitoring	1-6
	1.4.13 Dimensions, weight and power consumption	1-6
	1.5 Ordering Information	1-7
SECTION	2 OPERATION	2-1
	2.1 Precautions before Use	2-1
	2.2 Inserting and Removing Unit	2-2
	2.3 Description of Unit Panel	2-3
	2.4 Setting the Internal Switch	2-4
	2.5 Connecting to the Device Under Test (DUT)	2-5
	2.5.1 Connecting to the DCE	2-5
	2.5.2 Connecting to the DTE	2-7
	2.6 Using an External Clock Source for the Send-Signal ..	2-10
	2.7 Outline of Measurement Operation	2-12
	2.8 INTERFACE Screen Composition	2-13
	2.9 V.24/V.28 Unit Interface Conditions	2-14
	2.10 Setting Interface Conditions	2-16

	2.11	Operation Procedure for setting V.24/V.28 Unit Send-condition	2-18
	2.12	Operation Procedure for Setting V.24/V.28 Unit Receive-Conditions	2-19
	2.13	Setting the Print Conditions for Interface Settings ...	2-20
	2.14	Monitor LED Display	2-21
	2.15	Setting the Signal-Line	2-23
	2.16	Measurement Conditions (only Items Unique to V.24/V.28 Unit)	2-24
	2.16.1	Error measurement	2-24
	2.16.2	Voltage/frequency measurement	2-26
	2.16.3	Line interval measurement	2-27
	2.16.4	Word trace	2-28
	2.17	Initial Values for Interface and Measurement Settings	2-29
SECTION	3	APPLICATION	3-1
	3.1	Introduction	3-1
	3.2	Setting the Interface-Conditions of Measurements via ST/SP (Start/Stop Sync.) mode	3-2
SECTION	4	SIMPLE OPERATION CHECKS	4-1
	4.1	Introduction	4-1
	4.2	Insertion State Check	4-2
	4.3	Confirming Error Measurement by SELF LOOP	4-3
	4.4	Confirming Frequency Measurement by SELF LOOP	4-6
	4.5	Check the Output Level	4-9
SECTION	5	REMOTE CONTROL	5-1
	5.1	Overview of Remote Control	5-1
	5.2	Control Command Table	5-1
	5.3	Response Data Table	5-1
	5.4	Control Command Table	5-2
	5.5	Response Data Table	5-7
SECTION	6	PRINCIPLES OF OPERATION	6-1
	6.1	Receiver/Driver	6-1
	6.1.1	Receiver	6-1
	6.1.2	The V.28 driver	6-1
	6.2	Connecting Circuits	6-2

6.3	Send Timing	6-5
6.3.1	The ST1 mode	6-5
6.3.2	The ST2 mode	6-5
6.3.3	The $\overline{ST2}$ mode	6-6
6.3.4	The ASYNC mode	6-6
6.3.5	The ST/SP mode	6-7
6.3.6	The RT mode	6-7
6.4	Receive Timing	6-8
6.4.1	The RT mode	6-8
6.4.2	The \overline{RT} mode	6-8
6.4.3	The ST mode	6-9
6.5	Start/Stop Synchronization	6-10
6.6	Send Control	6-11
6.7	Self Loop Mode	6-12

APPENDIX

A	MENU REFERENCE	
	V.24/V.28 INTERFACE UNIT	A-1
1	V.24/V.28 Interface Unit Menu Reference	A-2
1.1	Menu for function selection	A-3
1.2	Menu for Setting the Send Interface Unit Conditions	A-4
1.3	Menu for setting generation timing of the send signal	A-5
1.4	Menu for type of send signal clock setting	A-6
1.5	Menu for send internal clock frequency setting	A-7
1.6	Menu for setting the send internal-clock slave signal	A-8
1.7	Menu for setting the send external-clock input interface	A-8
1.8	Menu for send data length setting	A-9
1.9	Menu for setting the parity of the send short-frame pattern	A-9
1.10	Menu for setting the send data stop bit	A-10
1.11	Menu for controlling the send signal	A-10
1.12	Menu for setting the receive interface unit condition	A-11
1.13	Menu for setting generation timing of the receive signal	A-12
1.14	Menu for setting the receive internal clock frequency	A-13

1.15	Menu for setting the byte length of the receive data	A-14
1.16	Menu for setting the parity of the receive short-frame pattern	A-14
1.17	Menu for setting the signal-line	A-15
2	ERROR screen	A-16
2.1	Menu for function selection	A-17
2.2	Menu for selecting measured-results to be displayed	A-18
3	DISPLAY OF RESULTS Screen	A-19
3.1	Menu for function selection	A-20
4	VOLT/FREQUENCY Screen	A-21
4.1	Menu for function selection	A-22
4.2	Menu for selecting signal-Line for voltage measurement	A-23
4.3	Menu for selecting the signal-line for frequency measurement	A-24
5	DELAY TIME Screen	A-25
5.1	Menu for function selection	A-26
5.2	Menu for identifying the signal line to be used as the start trigger in line-transition delay measurements	A-27
5.3	Menu for identifying the signal line to be used as the stop trigger in line transition delay measurements	A-28
6	WORD TRACE Screen	A-29
6.1	Menu for function selection	A-30
6.2	Menu for setting the signal line to be used as the trace-stop trigger	A-31
APPENDIX B	COMMAND DEFERENCE EXTERNAL CONTROLLER	B-1
APPENDIX C	RESPONSE DATA REFERENCE V.24/V.28 INTERFACE UNIT	C-1

SECTION 1

GENERAL

1.1 Introduction

This manual describes handling and operation of the MD0621A V.24/V.28 (RS-232C) Interface Unit (hereinafter referred to as the V.24/V.28 Unit), an MD6420A Data Transmission Analyzer interface unit.

It covers the parts that are unique to the V.24/V.28 Unit and the various measurements that can be made by inserting it into a slot in the rear of the MD6420A. When measurements are in progress, refer to the MD6420A Data Transmission Analyzer operation manual.

This manual consists of the following Sections:

- SECTION 1 General
- SECTION 2 Operation
- SECTION 3 Application
- SECTION 4 Simple Operation Checks
- SECTION 5 Remote Control
- SECTION 6 Principles of Operation

It also contains the following appendixes:

- Appendix A EL-Display Menu Reference
- Appendix B Remote-Control Commands Reference
- Appendix C Remote-Control Response Data Reference

1.2 Features

The MD0621A V.24/V.28 Unit is an interface unit that is inserted into a slot on the rear of the MD6420A Data Transmission Analyzer.

It is used to make a variety of measurements on V.24/V.28 interfaces to ensure conformity with CCITT V.24/V.28.

(1) Measurement functions

- When inserted into the MD6420A:

Error measurements

Voltage measurements

Frequency measurements

Line interval measurements

Transmission delay time measurements

Pattern data sending and word trace

- When added with an extension unit:

Function for long-term error-measurement-data collection and analysis (error analysis unit: MD0633A)

Measurement of digital levels (ANALOG unit: MD0627A)

Measurement of distortion (Distortion unit: MD0630A)

(2) Features

- Function testing and transmission quality evaluation of V.24/V.28 (RS-232C) interface modem and terminal devices
- Measurement of transmission and reception in start-stop and asynchronous timing modes
- Detection of bit and parity errors in error-measurement

1.3 Composition

(1) Standard composition

The standard composition of the MD0621A is shown in Table 1-1.

Table 1-1 Standard Composition

No.	Item	Name	Qty.	Remarks
1	Unit	MD0621A V.24/V.28 (RS-232C) Interface Unit	1	Inserted into the MD6420A
2	Supplied accessories	Operation manual	1	

(2) Optional accessories

The optional accessories (sold separately) are listed in Table 1-2.

Table 1-2 Optional Accessories

Order No.	Name	Remarks
J0387	Double-ended 25-pin connector cable	2 m
J0388	25-pin DCE-DTE conversion connector	Used for DTE connection

1.4 Specifications

1.4.1 Operating conditions

- Operating temperature : 0° to 40°C
 - * Check to be sure that condensation has not occurred on the EL display
- Storage temperature : -25° to 70°C
- Operating humidity : 20% to 90%
- Storage humidity : 20% to 90%

1.4.2 Send clock

(1) Internal clock (Synchronous-ST1, Asynchronous-ASYNC, Start/Stop-ST/SP)

- Data signal speed : ● 50 kb/s to 20 kb/s (5 b/s step VARIABLE)
- Accuracy : ● Self oscillation : ± 5 ppm
- Slave oscillation : External input 8 bit/s, or 64 k + 8 kbit/s

(2) External clock (Synchronous-ST2, RT, External oscillator)

- Data signal speed ● 50 b/s to 20 kb/s

1.4.3 Receive clock

(1) Internal clock (Asynchronous-ASYNC, Start/Stop-ST/SP)

- Data signal speed ● 50, 75, 100, 110, 150, 200, 256, 300, 400, 500, 512, 600, 768, 800, 1000, 1200, 1600, 1800, 2000, 2560, 3000, 3600, 4800, 7200, 9600, 14400, 19200 b/s
- Accuracy ● $\leq \pm 20$ ppm

(2) External clock (Synchronous-RT)

- 50 b/s to 20 kb/s

1.4.4 Send pattern

(1) Controlling the send pattern with the CS (Clear to Send) signal

- The desired pattern can only be output when CS is ON.

(2) CONT LINE send

- ER, RS, NS can be set to ON/OFF/OPEN

The other send pattern functions conform to the specifications for the MD6420A main frame.

1.4.5 Error insertion

(1) Type of errors:

- Bit

The other error insertion functions conform to the specifications for the MD6420A main frame.

1.4.6 START/STOP Synchronization

- START/STOP bit length : START bit : 1 bit
STOP bit : 1, 1.5, 2 bit
- Data length : 5, 6, 7, 8 bit
- Parity : NONE, ODD (odd parity)
EVEN (even parity)

* Note that a parity bit of 1 may indicate either ODD or EVEN parity.

1.4.7 Error measurement

(1) Detection error

- Bit error, parity error

(2) Alarm counting and time measurement

- Measurement of number and time at which pattern sync-loss errors occur
- Clock-slip counting
- Measurement of time of power failure
- Measurement of time of pattern sync-loss (second)

The other error measurement functions conform to the specifications for the MD6420A main frame.

1.4.8 Pattern trace function

The pattern trace functions conform to the specifications for the MD6420A main frame.

1.4.9 DC voltage measurement

- Measurement signal

The DC voltage of the SD, RD, ST1, ST2, RT, ER, DR, RS, CS, CD, CI, TI, NS and can be measured.

The other DC voltage measurement functions conform to the specifications for the MD6420A main frame.

1.4.10 Frequency measurement and count

- Measurement signal

The frequency of the SD, RD, ST1, ST2, RT, ER, DR, RS, CS, CD, CI, TI, NS and external input signal can be measured.

The other frequency measurement and count functions conform to the specifications for the MD6420A main frame.

1.4.11 Time measurement

- Measurement signal

Transition times between SD, RD, ST1, ST2, RT, ER, DR, RS, CS, CD, CI, TI, NS, and external input signals can be measured.

1.4.12 Signal line monitoring

- Measurement signal

The status of SD, RD, ST1, ST2, RT, ER, DR, RS, CS, CD, CI, TI, and NS can be monitored.

Receive data can be monitored in 8 bit units

- Lighting conditions

Data 1 : Green

 0 : Off

Timing ON : Green

 OFF : Off

Control line ON : Green

 OFF : Off

- Monitor output

The voltages of the SD, RD, ST1, ST2, RT, ER, DR, RS, CS, CD, CI, TI and NS can also be monitored via the monitor terminals

1.4.13 Dimensions, weight and power consumption

Dimensions : ● 145H × 30W × 230 Dmm

Weight : ● < 0.6kg

Power consumption : ● < 12 VA

1.5 Ordering Information

Model	Name	Remarks
MD0621A J0387 J0388	V.24 (RS-232C) Interface Unit – Standard supplied accessory – MD0621A operation manual – Optional accessories – Cable with 25P connectors at both ends 2 m 25 P DCE-DTE converting connector	Used for DTE mode

SECTION 2 OPERATION

2.1 Precautions before Use

This unit has been thoroughly tested and inspected at the factory. On delivery, inspect the box for damage before opening it.

After opening the box, inspect the unit and verify the type and number of accessories.

If the unit has been damaged during shipment, please contact Anritsu.

- Operating environment


The MD0621A is used by inserting it into a slot on the rear of the MD6420A. It operates normally at an ambient temperature of 0° to 40°C. However, do not use it where:

1. Vibration is severe.
2. It is damp.
3. It is dusty.
4. There is exposure to direct sunlight.

To ensure that the unit operates normally for a long time, it should be used at ambient room temperatures in addition to the above conditions.


- This unit is designed to be used only with the MD6420A Data Transmission Analyzer. Never use it with other equipment since it may be damaged.
- Although the shape of this unit is compatible with the rear panel slots of the MD6401A Data Transmission Analyzer, it cannot be used with the MD6401A.

2.2 Inserting and Removing Unit



- ① Before inserting or removing this unit, turn the front-panel POWER switch OFF.
- ② This unit can be inserted into any position, from UNIT1 to UNIT5.
- ③ To insert the unit, align the edges of the unit PC board along the top and bottom guide rails and push it in UNIT1 it is firmly seated, then tighten the screws at the top and bottom. If the unit is not inserted and fastened properly, it may not operate correctly.
- ④ Cover empty slots with blank panels.


2.3 Description of Unit Panel



No.	Name	Explanation
①	SD, RD, ST1, ST2, RT, ER, DR, RS, CS, CD, CI, TI, NS SG	Check terminal. Send data can be monitored via the check terminals. Signal G.
②	TO DCE	25-pin connector when using the MD6420A as a dummy terminal to connect it to the DCE. When using the MD6420A as a dummy circuit to connect to a DTE device, connect the 25-pin DCE-DTE conversion connector to the MD6420A before connecting it to the DTE connector.

2.4 Setting the Internal Switch

The internal switch and the internal terminal are located as shown below:



DTE/DCE Change-Over Switch

S2 is a toggle switch for selecting either the DTE or DCE port for measurement. S2 is set to the DCE port position at shipment.


TO DCE For measurements of the DCE port

TO DTE For measurements of the DTE port (Required DTE-DCE conversion connector. Refer to table 1-2.)


2.5 Connecting to the Device Under Test (DUT)

2.5.1 Connecting to the DCE

When the MD6420A is used as a dummy terminal, the 25-pin TO DCE port on the V.24/V.28 Unit panel is connected to the DCE line.




Connect as shown below:



- As described in paragraph 2.4, set S2 to the "TO DCE" side and fasten the "TO DCE" connector to the cable connector with the top and bottom screws
- In this configuration, this unit can simultaneously send and receive.
- The send signal can be synchronized to oscillate with either the internal clock or the 8 kHz receive signal.

The table on the next page shows the signals input to and output by the 25-pin TO DCE port of this unit.



V.24 TO DCE Port 25-Pin Connections

Pin No.	Circuit No. (CCITT)	Circuit name (MD0621A)	Circuit name (RS-232C)	Direction		Explanation
				MD6420A	DCE	
1	101	FG	AA			Protective ground
2	103	SD	BA		→	Send data
3	104	RD	BB	←		Receive data
4	105	RS	CA		→	Send request
5	106	CS	CS	←		Send enabled
6	107	DR	CC	←		Data set ready
7	102	SG	AB			Signal ground
8	109	CD	CF	←		Carrier for data channel detected
9	(N)					
10	(N)					
11	126 (N)	NS			→	Send frequency selected
12	122 (N)					
13	121 (I)					
14	118 (I)					
15	114 (I)	ST2	DB	←		Send timing (DCE)
16	119 (I)					
17	115 (I)	RT	DD	←		Receive timing (DCE)
18	141 (N)					
19	120 (I)					
20	108 1/2	ER	CD		→	Data terminal ready
21	140 (N)					
22	125	CI	CE	←		Requested result
23	111 (N)					
24	113 (N)	ST1	DA		→	Send timing (DTE)
25	142	TI		←		Test display


(I) Pin used in international communications protocols

(II) Pin used in domestic (i.e. Japanese) communications protocols


Note: The equivalent of an SN75188N and SN75189N are used as the driver and receiver, respectively.

2.5.2 Connecting to the DTE

When the MD6420A is used as a dummy line (DCE), the 25-pin TO DTE port on the V.24/V.28 Unit panel is connected to a terminal.





Connect as shown below.



- As described in paragraph 2.4, set S2 to the "TO DTE" port position and fasten the "TO DCE" connector to the conversion connector with the top and bottom screws before connecting it to the cable connector.
- In this configuration, this unit can perform both sending and receiving.
- The send signal can be synchronized to oscillate with either the internal clock or the 8 kHz receive signal.

When the DCE-DTE conversion connector is connected to the TO DCE connector of the unit, the 25-pin connector is connected as follows:

- Connections for the conversion connector are shown below:




Interfacing Diagram for 25-pin DCE-DTE Conversion Connector

MD0621A DCE/DTE connection

The MD0621A DCE/DTE is connected.

The following signal conventions apply to the MD0621A send interface in the DTE send mode:

Port connection	DTE send mode	Send timing signal	Receive timing signal
TO DCE	ST1	ST1	RT
	ST2	ST2	RT
TO DTE	ST1	ST1	RT
	ST2	ST1	ST



Interfacing diagram for 37-pin DCE-DTE conversion connector

Note: In the "TO DTE" mode, the CS and DR lines can be controlled by turning the MD0621A RS and ER lines ON/OFF.





Fig. 2-1 MD0621A DCE/DTE Connection


2.6 Using an External Clock Source for the Send-Signal

An External clock can be used instead of the MD6420A internal clock source as the send clock source.

1. Slave synchronization to an external 8 kHz clock (The specified-bit-rate is generated by an internal clock source.)




- Connect the 8 kHz signal source to the rear-panel EXT1 connector via a coaxial cable.
2. Slave synchronization to an external (64 kHz + 8 kHz) clock source. (The specified-bit-rate is generated by an internal clock source.)



- Connect the 64 kHz + 8 kHz signal source to the rear-panel EXT 2 connector via a coaxial cable.

3. External clock source for send signal



2.7 Outline of Measurement Operation

Before beginning measurements, first set the send and receive interface conditions for the DUT via the INTERFACE screen. Then set the appropriate measurement conditions on the measurement screens and initiate measurement.

POWER ON
↓

-- MODE --

Anritsu

DATA TRANSMISSION ANALYZER

MD6420A

ANRITSU CORP.

SET TIME 90-06-14 23:01:40

(MORE) MO1

INTER-
FACE
PRESET
MEMORIES

- Press [F2] to display the INTERFACE screen.

[F2] key

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126

-- INTERFACE --

	S/R	ER : ↓	RS : ↓	NS : ↓						
	INTER- FACE	TIMING	CLOCK	BIT RATE	INT FREQ SOURCE	EXT INTER- FACE				P1
SEND	UNIT1 V.24/ V.28	ST/SP	INT	1200 b/s	SELF					
RECEIVE	UNIT1 V.24/ V.28	ST/SP		1200 b/s						

90-06-14 11:47:06
(MORE) MO1

ERROR
VOLT/
FREQUENCY
DELAY
TIME
WORD
TRACE
←
→

- Using the CURSOR, MODIFY, and F (soft) keys, set the send and receive interface conditions for the DUT.
- After the cursor goes off, press the appropriate F key to display the desired measurement screen.
- The V.24/V.28 Unit can be used as either the send or receive interface unit 9 or as both.

F keys Back screen key

↓ ↓

Next screen key

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126

-- ERROR --

	S/R									
ERROR COUNT	0	ERROR RATIO	0.00E-04	PATTERN 2↑6-1 NORMAL NO-SUP PSL-THR AUTO CYC-ERR 1.0E-1 CH-ERR SINGLE ERR-INS BIT ERROR BIT BLK-LNG 1.0E1 BIT MEAS MANUAL						
ES	0.00	SES	0							
CLOCK SLIP	0	ELAPSED-TIME	0:00:08	SAV RCL						
		DSPL MODE	ELAPS	BUZ OFF						


90-06-14 23:00:12
(MORE) MO1

START
MEAS
START
CYC-ERR
START
CH-ERR
PRINT
OUT

- Using the CURSOR, MODIFY, and F (soft) keys to set the send signal conditions, measurement conditions, etc.
- After the cursor goes off, select measurement start/stop, etc.
- For an operational description of the ERROR and other measurement screens, refer to the MD6420A operation manual.

2.8 INTERFACE Screen Composition

The composition of the INTERFACE screen is shown below:




NO	Label	Item	Explanation	Setting
①		Name of signal being monitored by LED	Displays names and connection circuit numbers corresponding to signal lines and alarm signals being monitored by LEDs.	×
②	S/R, SND, RCV	Signal line and alarm signal setting	Displays signal line and the alarm signal setting	○
③	SEND INTERFACE	Send interface unit setting	Displays number and name of unit selected as send interface	○
④	RECEIVE INTERFACE	Receive interface unit setting	Displays number and name of unit selected as receive interface	○
⑤		Interface setting item name	Displays send/receive interface setting item names The settings depend on the selected unit.	×
⑥		Send interface settings	The send interface setting depend on the type of send interface being used.	○
⑦		Receive interface settings	The receive interface settings depend on the type of receive interface being used	○


2.9 V.24/V.28 Unit Interface Conditions

The V.24/V.28 Unit interface conditions can be set on the INTERFACE screen as shown below:

(1) Page 1



(2) Page 2




Note: These display examples assume that both the send and receive sides of the V.24/V.28 Unit are being used. The display location of each item and the number of pages differ with the type of interface unit.




No.	Label	Name	Send	Receive	Explanation
①	INTER-FACE	Interface unit	<input type="radio"/>	<input type="radio"/>	Send/receive interface unit No. and name
②	TIMING	Send/receive signal timing	<input type="radio"/>	<input type="radio"/>	Send and receive signal timing.
③	CLOCK	Type of send clock signal	<input type="radio"/>		Send clock signal source
④	BIT RATE	Bit rate	<input type="radio"/>	<input type="radio"/>	Clock bit rate when TIMING is ASYNC, ST/SP or ST1
⑤	INT FREQ SOURCE	Type of internal-clock slave signal for send signal	<input type="radio"/>		Type of slave clock signal when CLOCK ③ is set to INT
⑥	EXT INTER-FACE	Type of external-clock input interface for send signal	<input type="radio"/>		Type of external-clock input interface when CLOCK ③ is set to EXT
⑦	DATA LENGTH	Data length	<input type="radio"/>	<input type="radio"/>	Data length (number of bits/datum) when TIMING ② is ST/SP
⑧	PARITY	Parity	<input type="radio"/>	<input type="radio"/>	Parity when TIMING ② is ST/SP
⑨	STOP BIT	Type of stop-bit	<input type="radio"/>		Type of stop-bit when TIMING ② is ST/SP
⑩	SEND CONTROL	Type of send-signal control	<input type="radio"/>		

- Subsequent items are set in accordance with the previously-set items.
- The cursor skips over the display areas of items that cannot be set.


2.10 Setting Interface Conditions

1. Basic setting procedure




- (1) When the CURSOR  key is pressed once in the cursor-off state, the cursor is displayed in the send interface setting area. Select the unit corresponding to the required send interface from the menu via the F (soft) keys.
- (2) When the CURSOR  key is pressed once while in state (1) above, the cursor is displayed in the receive interface setting area. Select the receive interface unit with the F (soft) keys, as described above.
- (3) Operate the CURSOR, MODIFY, and F (soft) keys to set or modify each interface item currently being displayed.
- (4) Press the  displayed above [F6] on the menu display. If it is not displayed, press [CURSOR OFF] followed by [F6].

2. Simple setting procedure when using the same send/receive conditions




2.11 Operation Procedure for setting V.24/V.28 Unit Send-condition



Note: From 50 to 20,000 b/s can be set in 5 bit/s steps

2.12 Operation Procedure for Setting V.24/V.28 Unit Receive-Conditions



2.13 Setting the Print Conditions for Interface Settings


The interface conditions can be printed by pressing [F6] (PRINT OUT) on page 2 of the INTERFACE screen while the cursor is disabled.

A sample print out (in which the conditions are set in accordance with paragraph 2.9) is shown below.

```
== INTERFACE ==  
90-06-18 21:33:14  
< SEND >  
UNIT1      V.24/V.28  
TIMING      ST/SP  
CLOCK      INT  
BIT RATE    1200b/s  
INT FREQ    SELF  
DATA LEN    8 BIT  
PARITY      NON  
STOP BIT    1 BIT  
SEND CTL    ALWAYS  
< RECEIVE >  
UNIT1      V.24/V.28  
TIMING      ST/SP  
BIT RATE    19200b/s  
DATA LEN    8 BIT  
PARITY      NON
```

2.14 Monitor LED Display

The statuses of the V.24/V.28 interface signal-lines can be monitored by the LEDs on any INTERFACE or measurement screen.



The monitor LEDs indicate the status of the specified signal-line.

- ① SD [CCITT Circuit No. 103/RS-232C, Circuit name BA/25P Connector pin No.2]
Transmit (Send) data: A signal output from the MD0621A that monitors the transmission of data
1: Lit, 0: Unlit
- ② RD [CCITT Circuit No. 104/RS-232C, Circuit name BB/25P Connector pin No.3]
Receive data: A signal input to the MD0621A that monitors the reception of data
1: Lit, 0: Unlit
- ③ ST1 [CCITT Circuit No. 113/RS-232C, Circuit name DA/25P Connector pin No.24]
Transmit (Send) signal element timing: Signal element timing information output to DCE.
ON: Lit, OFF: Unlit
- ④ ST2 [CCITT Circuit No. 114/RS-232C, Circuit name DB/25P Connector pin No.15]
Transmit (Send) signal element timing: Signal element timing information input from DCE.
ON: Lit, OFF: Unlit
- ⑤ RT [CCITT Circuit No. 115/RS-232C, Circuit name DD/25P Connector pin No.17]
Receive signal element timing: Signal element timing information input from DCE.
ON: Lit, OFF: Unlit
- ⑥ ER [CCITT Circuit No. 108/RS-232C, Circuit name CD/25P Connector pin No.20]
Data terminal ready: Monitors status of ER line.
ON: Lit, OFF: Unlit
- ⑦ DR [CCITT Circuit No. 107/RS-232C, Circuit name CC/25P Connector pin No.6]
Data set ready: Monitors status of DR line.
ON: Lit, OFF: Unlit

- ⑧ RS [CCITT Circuit No. 105/RS-232C, Circuit name CA/25P Connector pin No.4]
Request to send: Monitors status of RS line.
ON: Lit, OFF: Unlit
- ⑨ CS [CCITT Circuit No. 106/RS-232C, Circuit name CS/25P Connector pin No.5]
Ready for send: Monitors status of CS line.
ON: Lit, OFF: Unlit
- ⑩ CD [CCITT Circuit No. 109/RS-232C, Circuit name CF/25P Connector pin No.8]
Data channel received line signal detector: Monitors status of CD line.
ON: Lit, OFF: Unlit
- ⑪ CI [CCITT Circuit No. 125/RS-232C, Circuit name CE/25P Connector pin No.22]
Calling indicator: Monitors status of CI line.
ON: Lights, OFF: Unlit
- ⑫ TI [CCITT Circuit No. 142/RC-232C, Circuit name None/25P Connector pin No.25]
Test indicator: Monitors status of TI line.
ON: Lit, OFF: Unlit
- ⑬ NS [CCITT Circuit No. 126/RS-232C, Circuit name None/25P Connector pin No.11]
Select transmit frequency: Monitors status of NS line.
ON: Lit, OFF: Unlit

2.15 Setting the Signal-Line

The signal-lines of the V.24/V.28 Unit to be monitored can be set via any INTERFACE or measurement screen.

- Setting items

- ER : Data terminal ready
- RS : Request to send
- NS : Select transmit frequency

- Operation for setting (1)

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
103	104	113	114	115	108	107	105	106	109	125	142	126
-- ERROR --												
S/R		ER : ↓	RS : ↓	NS : ↓								
ERROR COUNT				ERROR RATIO				PATTERN 2↑6-1				
-----				-----				NORMAL NO-SUP				
ES				SES				PSL-THR AUTO				
-----				-----				CYC-ERR 1.0E-1				
CLOCK SLIP				ELAPSED-TIME				CH-ERR SINGLE				
-----				-----				ERR-INS BIT				
				DSPL MODE ELAPS				ERROR BIT				
								BLK-LNG 1.0E1 BIT				
								MEAS MANUAL				
								BUZ OFF				
											SAV RCL	
											90-06-18 14:33:17	

↑ (ON)

↓ (OFF)

(OPEN)

Move the cursor to the signal-line setting area of the screen and specify ON/OFF/OPEN.

- Operation for setting (2)

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
103	104	113	114	115	108	107	105	106	109	125	142	126
-- ERROR --												
S/R		ER : ↓	RS : ↓	NS : ↓								
ERROR COUNT				ERROR RATIO				PATTERN 2↑6-1				
-----				-----				NORMAL NO-SUP				
ES				SES				PSL-THR AUTO				
-----				-----				CYC-ERR 1.0E-1				
CLOCK SLIP				ELAPSED-TIME				CH-ERR SINGLE				
-----				-----				ERR-INS BIT				
				DSPL MODE ELAPS				ERROR BIT				
								BLK-LNG 1.0E1 BIT				
								MEAS MANUAL				
								BUZ OFF				
											SAV RCL	
											90-06-18 14:35:39	
											(MORE) MO3	

ER
ON/OFF

RS
ON/OFF

NS
ON/OFF

Switch each signal ON/OFF via the cursor off menu of page 2 (or 3) of each measurement screen. ON/OFF can also be selected when the signal line is set to OPEN (「x」).

2.16 Measurement Conditions (only Items Unique to V.24/V.28 Unit)

2.16.1 Error measurement

As regards error measurements, the following measurement conditions and items are unique to the V.24/V.28 Unit. Other items referred to as common items.

For a description of the common items and error measurement operations, refer to the MD6420A operation manual.

(1) ERROR screen

SD	RD	ST1	ST2	RT
103	104	113	114	115
-- ERROR --				
MEAS	S/R			
ERROR COUNT	2	ERROR RATIO	6.94E-06	PATTERN 2:6-1
ES	2.00	SES	0	NORMAL NO-SUP
CLOCK SLIP	0	ELAPSED-TIME	0:00:06	PSL-THR AUTO
		DSPL MODE ELAPS		CYC-ERR 1.0E-1
				CH-ERR SINGLE
				ERR-INS BIT
				ERROR BIT
				BLK-LNG 1.0E1 BIT
				MEAS MANUAL
				BUZ OFF
90-05-29 15:24:10				
(MORE) MO1				
START MEAS	START CYC-ERR	START CH-ERR	PRINT OUT	

- ① Types of errors that can be inserted
BIT: Bit error
- ② Errors that can be detected
BIT : Bit error
PARITY : Parity error (valid for start/stop-sync, parity)
- ③ Other measurable items
In addition to common items such as ordinary errors, block errors, and error performance, the following alarm items can also be selected for measurement:
PWL (sec): Power-off time
PSL (sec) : Pattern sync-loss time

(2) DISPLAY OF RESULTS screen

SD	RD	ST1	ST2	RT
103	104	113	114	115
-- DISPLAY OF RESULTS --				
	S/R			
ERROR	2	ERR RTO	2.86E-06	PWL (sec)
BLK-ERR	2	BLK RTO	1.14E-05	PSL (sec)
US	0	%US	0.00	
SES	0	%SES	0.00	
DM	1	%DM	100.00	
ES	2.00	%ES	20.00	
EFS	8.00	%EFS	80.00	
PSL-CNT	0	ELAPSED-TIME	0:00:10	
CLK-SLIP	0	DSPL MODE ELAPS		
90-05-29 15:24:31				
(MORE) MO1				
START MEAS	START CYC-ERR	START CH-ERR	PRINT OUT	

- ④ Alarm generation times
None except the common items (PWL (sec) and PSL (sec))

(3) CONDITION OF PRINT (INTERVAL) screen

```

--CONDITION OF PRINT (INTERVAL)--
INTERVAL DATA
  ERROR DATA PRINT NO THRESHOLD 0
  PRINT INTERVAL 1 sec
  CONTROL CONTINUOUS PRINT NO

ALARM DATA
PSL (sec) PRINT YES

90-05-29 15:51:38

PERIOD
    
```

⑤ Interval alarm data
Interval printing for each alarm item can be either enabled or disabled.

(4) CONDITION OF PRINT (PERIOD) screen

```

--CONDITION OF PRINT (PERIOD)--
PERIODIC / TOTAL DATA
  ERROR DATA PRINT YES BLOCK DATA PRINT YES
  US %US PRINT YES SES %SES PRINT YES
  DM %DM PRINT YES ES %ES PRINT YES
  EFS %EFS PRINT YES PSL COUNT PRINT YES
  CLK-SLIP PRINT YES

ALARM DATA
PWL (sec) PRINT YES PSL (SEC) PRINT YES

90-05-29 15:51:55

INTERVAL
    
```

⑥ Periodic alarm data
Periodic printing of each alarm can either be enabled or disabled.

(5) CONDITION OF COLLECT screen

```

--CONDITION OF COLLECT--
UNIT NO.3 AREA NO.1
  COLLECT INTERVAL 1 sec
  ERROR DATA COLLECT YES
  PERIOD DATA COLLECT YES

ALARM DATA
PSL(sec) COLLECT YES

90-05-29 15:54:24
(MORE) MO1
1 sec 10 sec 30 sec 1 min 2 min 5 min
    
```

⑦ Interval alarm data collection control
Each interval alarm data item can be selected or deselected for data collection.

2.16.2 Voltage/frequency measurement

The following voltage/frequency measurement items are unique to the V.24/V.28 Unit.

Other items are referred to as common items. For a description of the common items and the voltage/frequency measurement items, refer to the MD6420A operation manual.

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS	
103	104	113	114	115	108	107	105	106	109	125	142	126	
-- VOLT/FREQUENCY --													
S/R		ER : ↓		RS : ↓		NS : ↓							
SD (V)								PATTERN 2↑6-1					
-0.27								NORMAL NO-SUP					
				RT (KHz)		GATE TIME 100ms		INTERVAL 0.5sec					
				1.20		LINE SELECT SIGNAL							
												SAV RCL	
												90-06-15 05:15:17	
												(MORE) MO1	
START COUNT												PRINT OUT	

- ① The voltage of any signal line being monitored by an LED can be selected for measurement.
- ② The frequency of any signal line being monitored by an LED can be selected for measurement.

2.16.3 Line interval measurement

The following line interval measurement items are unique to the V.24/V.28 Unit. Other items are referred to as common items. For a description of common items and line interval measurement operations, refer to the MD6420A operation manual.

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
103	104	113	114	115	108	107	105	106	109	125	142	126
--DELAY TIME--												
	S/R	C : ↓										
<div style="display: flex; justify-content: space-between;"> <div style="text-align: center;"> <p>(ms)</p> <p>0.06</p> </div> <div style="border-left: 1px solid black; padding-left: 10px;"> <p>LINE INTERVAL</p> <p>LINE SELECT SIGNAL</p> <p>START SD OFF→ON</p> <p>STOP SD ON→OFF</p> </div> </div>										} ①		
SAV RCL 90-05-29 15:26:05 (MORE) MO1												
STOP COUNT		STOP REPEAT									PRINT OUT	

① Any signal line monitored by an LED can be selected as a START/STOP trigger.

2.16.4 Word trace

The following word-trace items are unique to the V.24/V.28 Unit.

The other items are referred to as common items. For a description of the common items and word-trace operations, refer to the MD6420A operation manual.

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
103	104	113	114	115	108	107	105	106	109	125	142	126
--WORD TRACE--												
	S/R	C : ↓										
SEND												
IDLE CODE		0000 0000		SEND DATA		PRGM						
				WORD ADDRESS		0						
SEND METHOD		MANUAL		PATTERN		0111 1111						
				LENGTH		2BYTE						
TRACE												
SYNC CODE		XXXX XXXX		TRACE STOP		LINE						
LINE SELECT		SIGNAL		STOP DELAY		SD		OFF→ON				
								OBYTE				
<div style="text-align: right;"> SAV RCL 90-05-29 15:26:54 (MORE) MO1 </div>												
STOP SEND			STOP TRACE				TRACE DISPLAY			PRINT OUT		

- ① When the trace stop condition (TRACE STOP) is LINE, any signal line being monitored by an LED can be selected as the condition signal line.

2.17 Initial Values for Interface and Measurement Settings

Initial values for interface and measurement settings unique to the V.24/V.28 Unit are shown below:

- (1) Initialization is performed from the MODE screen
- (2) The POWER is turned ON after being turned OFF when the V.24/V.28 Unit was not selected.
- (3) The measurement screen displayed at the moment the POWER was turned OFF is not redisplayed when the POWER is turned back ON.

1. Interface settings items

No.	Item		Initial value
①	INTERFACE	Send-interface unit conditions	
②	TIMING	Send-signal generation timing	ST1
③	CLOCK	Type of send-signal clock	INT
④	DATA BIT RATE	Internal-clock frequency (bit rate) of send signal	1200 b/s
⑤	INT FREQ SOURCE	Type of internal-clock slave send signal	SELF
⑥	EXTERNAL INTERFACE	Type of external-clock input interface for sending	TTL
⑦	DATA LENGTH	Send data length	8 BIT
⑧	PARITY	Send-data parity	NON
⑨	STOP BIT	Type of send-data stop bit	1 BIT
⑩	SEND CONTROL	Send control signal	ALWAYS
	INTERFACE	Receive-interface unit	
	TIMING	Receive-signal timing	RT
	DATA BIT RATE	Internal-clock frequency (bit rate) for receive signal	1200 b/s
	DATA LENGTH	Receive data length	8 BIT
	PARITY	Receive-data parity	NON

2. Signal line setting items

No.	Item		Initial value
①	ER		OFF
②	RS		OFF
③	NS		OFF

3. VOLT/FREQ/COUNT measurement

No.	Item	Initial value
①	Voltage-measurement line name	SD
②	Frequency-measurement line name/count-signal name	SD

4. DELAY measurement

No.	Item	Initial value
①	Measurement-start trigger signal	SD
②	Trigger-signal start measurement condition	0 → 1
③	Measurement-stop trigger signal	SD
④	Trigger-signal stop measurement condition	1 → 0


5. WORD TRACE measurement

No.	Item	Initial value
①	Trace-stop trigger line	SD
②	Trigger stop trace condition	0 → 1

SECTION 3 APPLICATION













3.1 Introduction


This section describes the measurement procedure for a device under test (DUT). Measurement is roughly divided into the following steps:




The following procedure is used when setting the interface parameters for ST/SP measurements.

3.2 Setting the Interface-Conditions of Measurements via ST/SP (Start/Stop Sync.) mode

Step	Procedure	Screen
1.	Set [POWER] to ON.	The MODE screen is displayed.
2.	Press [F2].	The INTERFACE screen is displayed.
3.	Move the cursor by pressing  once.	The cursor is displayed at ① in the screen below.
4.	Press [V.24/V.28].	V.24/V.28 is displayed at the receive, INTER-FACE ①.
5.	Move the cursor by pressing  once.	The cursor is displayed at ②.
6.	Press [V.24/V.28].	V.24/V.28 is displayed at SEND, INTER-FACE ②.
7.	Move the cursor by pressing  once.	The cursor is displayed at ③.
8.	Press [F5].	ST/SP is displayed at SEND, TIMING ③.
9.	Move the cursor by pressing  once.	The cursor is displayed at ④.
10.	Press [F1].	INT is displayed at SEND, CLOCK ④.
11.	Move the cursor by pressing  once.	The cursor is displayed at ⑤.
12.	Press [F1].	1200 b/s is displayed at SEND, BIT RATE ⑤.
13.	Move the cursor by pressing  once.	The cursor is displayed at ⑥.
14.	Press [F1].	SELF is displayed at SEND, INT FREQ SOURCE ⑥.
15.	Move the cursor by pressing  once.	The cursor is displayed at ⑦.
16.	Press [F6] once.	INTERFACE screen P2 is displayed.
17.	Move the cursor by pressing  once.	The cursor is displayed at ⑧.
18.	Move the cursor by pressing  once.	The cursor is displayed at ⑨.
19.	Press [F4].	The message "8 BIT" is displayed at SEND, DATA LENGTH ⑨.
20.	Move the cursor by pressing  once.	The cursor is displayed at ⑩.
21.	Press [F1].	NON is displayed at SEND, PARITY ⑩.
22.	Move the cursor by pressing  once.	The cursor is displayed at ⑪.
23.	Press [F3].	The message "2 BIT" is displayed at SEND, STOP BIT ⑪.
24.	Move the cursor by pressing  once.	The cursor is displayed at ⑫.

Step	Procedure	Screen
25.	Press [F1].	ALWAYS is displayed at SEND, SEND CONTROL Ⓚ.
26.	Move the cursor by pressing  once.	The cursor is displayed at Ⓛ.
27.	Press [MORE] once.	The next page of soft-keys is displayed.
28.	Press [F1].	The same SEND and RECEIVE conditions are set.
29.	Press [CURSOR].	The cursor is turned OFF.
30.	1. Press [F1]. 2. Press [F2]. 3. Press [F3]. 4. Press [F4].	The ERROR screen is displayed. The VOLT/FREQ screen is displayed. The DELAY/TIME screen is displayed. The WORD TRACE screen is displayed.

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126
-- INTERFACE --


		S/R	ER : ↓	RS : ↓	NS : ↓			
	INTER- FACE	TIMING	CLOCK	BIT RATE	INT FREQ SOURCE	EXT INTER- FACE		P1
SEND	UNIT4 V.24/ V.28 Ⓜ	ST/SP Ⓢ	INT Ⓣ	1200 b/s Ⓤ	SELF Ⓦ			
RECEIVE	UNIT4 V.24/ V.28 Ⓨ	ST/SP		1200 b/s				

90-06-14 11:44:26
(MORE) MO1

ERROR	VOLT/ FREQUENCY	DELAY TIME	WORD TRACE	←	→
-------	--------------------	---------------	---------------	---	---

INTERFACE screen P1

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126
-- INTERFACE --


		S/R	ER : ↓	RS : ↓	NS : ↓			
	INTER- FACE	DATA LENGTH	PARITY	STOP BIT	SEND CON- TROL			P2
SEND	UNIT4 V.24/ V.28 Ⓜ	8 BIT Ⓢ	NON Ⓣ	1 BIT Ⓤ	AL- WAYS Ⓦ			
RECEIVE	UNIT4 V.24/ V.28 Ⓨ	8 BIT Ⓢ	NON Ⓣ					

90-06-14 11:45:01
(MORE) MO1

ERROR	VOLT/ FREQUENCY	DELAY TIME	WORD TRACE	←	→
-------	--------------------	---------------	---------------	---	---

INTERFACE screen P2

The procedures for performing measurements are given in the MD6420A operation manual.



SECTION 4

SIMPLE OPERATION CHECKS

4.1 Introduction

This section describes how to make simple operation checks and verify that operation is correct when the V.24/V.28 Unit is inserted into the MD6420A.


Simple operation checks consist of:

- (1) Insertion state check
- (2) Error-measurement by SELF Loop check
- (3) Frequency-measurement by SELF Loop check













4.2 Insertion State Check

After turning the MD6420A power OFF, insert the V.24/V.28 Unit into the MD6420A rear-panel slots and tighten the screws on the top and bottom of the unit.

Turn the MD6420 power ON and verify that the V.24/V.28 Unit is inserted properly, as follows:



4.3 Confirming Error Measurement by SELF LOOP

Step	Procedure	Screen
1.	Set [POWER] to ON.	The MODE screen is displayed.
2.	Press [F2].	The INTERFACE screen is displayed.
3.	Move the cursor by pressing  once.	The cursor is displayed at ①.
4.	Press [V.24/V.28].	V.24/V.28 is displayed at RECEIVE, INTER-FACE ①.
5.	Move the cursor by pressing  once.	The cursor is displayed at ②.
6.	Press [V.24/V.28].	V.24/V.28 is displayed at SEND, INTER-FACE ②.
7.	Move the cursor by pressing  once.	The cursor is displayed at ③.
8.	Press [F5].	ST/SP is displayed at SEND, TIMING ③.
9.	Move the cursor by pressing  once.	The cursor is displayed at ④.
10.	Press [F1].	INT is displayed at SEND, CLOCK ④.
11.	Move the cursor by pressing  once.	The cursor is displayed at ⑤.
12.	Press [F1].	2400 b/s is displayed at SEND, BIT RATE ⑤.
13.	Move the cursor by pressing  once.	The cursor is displayed at ⑥.
14.	Press [F1].	SELF is displayed at SEND, INT FREQ SOURCE ⑥.
15.	Move the cursor by pressing  once.	The cursor is displayed at ①.
16.	Press [F6].	The second page of the INTERFACE screen is displayed.
17.	Move the cursor by pressing  once.	The cursor is displayed at ②.
18.	Move the cursor by pressing  once.	The cursor is displayed at ③.
19.	Press [F4].	8 BIT is displayed at SEND, DATA LENGTH ③.
20.	Move the cursor by pressing  once.	The cursor is displayed at ④.
21.	Press [F1].	NON is displayed at SEND, PARITY ④.
22.	Move the cursor by pressing  once.	The cursor is displayed at ⑤.
23.	Press [F3].	2 BIT is displayed at SEND, STOP BIT ⑤.
24.	Move the cursor by pressing  once.	The cursor is displayed at ⑥.

No.	Step Procedure Screen	Screen
25.	Press [F1].	ALWAYS is displayed at SEND, CON-TROL $\text{\textcircled{K}}$.
26.	Move the cursor by pressing $\text{\textcircled{D}}$ once.	The cursor is displayed at $\text{\textcircled{L}}$.
27.	Press [MORE] once.	The next page of the soft-key menu is displayed.
28.	Press [F2].	The same SEND and RECEIVE interface conditions are set and SELF-Loop is displayed at the RECEIVE INTER-FACE $\text{\textcircled{L}}$.
29.	Press [CURSOR OFF].	The cursor is turned OFF.
30.	Press [F1].	The ERROR screen is displayed.

Before setting SELF Loop

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126
-- INTERFACE --

S/R	ER	RS	NS				
	INTER-FACE	TIMING	CLOCK	BIT RATE	INT FREQ SOURCE	EXT INTER-FACE	P1
SEND	UNIT2 V.24/ V.28 $\text{\textcircled{K}}$	ST/SP $\text{\textcircled{L}}$	INT $\text{\textcircled{L}}$	1200 b/s $\text{\textcircled{L}}$	SELF $\text{\textcircled{L}}$		
RECEIVE	UNIT2 V.24/ V.28 $\text{\textcircled{L}}$	RT					

90-06-15 02:29:40
(MORE) MO1

ERROR	VOLT/ FREQUENCY	DELAY TIME	WORD TRACE	\leftarrow	\rightarrow
-------	--------------------	---------------	---------------	--------------	---------------

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126
-- INTERFACE --

S/R	ER	RS	NS				
	INTER-FACE	DATA LENGTH	PARITY	STOP BIT	SEND CON-TROL		P2
SEND	UNIT2 V.24/ V.28 $\text{\textcircled{L}}$	8 BIT $\text{\textcircled{L}}$	NON $\text{\textcircled{L}}$	1 BIT $\text{\textcircled{L}}$	ALL- WAYS $\text{\textcircled{K}}$		
RECEIVE	UNIT2 V.24/ V.28 $\text{\textcircled{L}}$						

90-06-15 02:30:18
(MORE) MO1

ERROR	VOLT/ FREQUENCY	DELAY TIME	WORD TRACE	\leftarrow	\rightarrow
-------	--------------------	---------------	---------------	--------------	---------------

After setting SELF Loop

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126
-- INTERFACE --

S/R	ER	RS	NS				
	INTER-FACE	TIMING	CLOCK	BIT RATE	INT FREQ SOURCE	EXT INTER-FACE	P1
SEND	UNIT2 V.24/ V.28	ST/SP	INT	1200 b/s	SELF		
RECEIVE	SELF LOOP	ST/SP		1200 b/s			

90-06-15 02:32:00
(MORE) MO1













ERROR	VOLT/ FREQUENCY	DELAY TIME	WORD TRACE	\leftarrow	\rightarrow
-------	--------------------	---------------	---------------	--------------	---------------

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126
-- INTERFACE --

S/R	ER	RS	NS				
	INTER-FACE	DATA LENGTH	PARITY	STOP BIT	SEND CON-TROL		P2
SEND	UNIT2 V.24/ V.28	8 BIT	NON	1 BIT	ALL- WAYS		
RECEIVE	SELF LOOP	8 BIT	NON				

90-06-15 02:32:39
(MORE) MO1






ERROR	VOLT/ FREQUENCY	DELAY TIME	WORD TRACE	\leftarrow	\rightarrow
-------	--------------------	---------------	---------------	--------------	---------------


Step	Procedure	Screen
31.	Move the cursor by pressing  three times.	The cursor is displayed at  .
32.	Press [F5].	2 ↑ 15-1 is displayed at PATTERN  .
33.	Move the cursor by pressing  six times.	The cursor is displayed at  .
34.	Press [F1].	BIT is displayed at ERROR  .
35.	Move the cursor by pressing  twice.	The cursor is displayed at  .
36.	Press [F1].	MANUAL is displayed at MEAS  .
37.	Press [CURSOR OFF].	The cursor is turned OFF.
38.	Press [F1].	Measurement starts. Normally, MEAS is displayed at  and errors are not counted. (0 is displayed at ERROR COUNT  .
39.	Press [F5] once.	"1" is displayed at ERROR COUNT  . (The number of errors displayed corresponds to the number of time [F5] is pressed.)

```

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126
-- ERROR --

```

	S/R	AIS : ↑							
	ERROR COUNT	ERROR RATIO	PATTERN 2↑11-1 						
	ES	SES	NORMAL NO-SUP PSL-THR AUTO CYC-ERR 1.0E-1 CH-ERR SINGLE ERR-INS BIT ERROR BIT 						
	CLOCK SLIP	ELAPSED-TIME	BLK-LNG 1.0E1 BIT MEAS MANUAL 						
		DSPL MODE ELAPS	BUZ OFF						










 SAV RCL
90-04-25 15:12:33
(MORE) MO1

START MEAS	START CYC-ERR	START CH-ERR	PRINT OUT
------------	---------------	--------------	-----------

Check method

- When measurement starts correctly as described at Step 38 and 0 is displayed at ERROR COUNT, operation is normal.
- When ERROR COUNT corresponds to the number of times [F5] (START CH-ERR) is pressed at Step 39, operation is normal.

4.4 Confirming Frequency Measurement by SELF LOOP

Step	Procedure	Screen
1.	Set [POWER] to ON.	The MODE screen is displayed.
2.	Press [F2].	The INTERFACE screen P1 is displayed.
3.	Move the cursor by pressing  once.	The cursor is displayed at ① in the screen below.
4.	Press [V.24/V.28].	V.24/V.28 is displayed at RECEIVE, INTERFACE ①.
5.	Move the cursor by pressing  once.	The cursor is displayed at ②.
6.	Press [V.24/V.28].	V.24/V.28 is displayed at SEND, INTERFACE ②.
7.	Move the cursor by pressing  once.	The cursor is displayed at ③.
8.	Press [F3].	ST1 is displayed at SEND, TIMING ③.
9.	Move the cursor by pressing  once.	The cursor is displayed at ④.
10.	Press [F1].	INT is displayed at SEND, CLOCK ④.
11.	Move the cursor by pressing  once.	The cursor is displayed at ⑤.
12.	Press [F1].	1200 b/s is displayed at SEND, BIT RATE ⑤.
13.	Move the cursor by pressing  once.	The cursor is displayed at ⑥.
14.	Press [F1].	SELF is displayed at SEND, INT FREQ SOURCE ⑥.
15.	Move the cursor by pressing  once.	The cursor is displayed at ①.
16.	Press [F6].	Interface conditions are displayed on the measurement screen P2.
17.	Move the cursor by pressing  once.	The cursor is displayed at ②.
18.	Press [F1].	ALWAYS is displayed at SEND, CONTROL ②.
19.	Move the cursor by pressing  once.	The cursor is displayed at ③.
20.	Press [MORE] once.	The next page of the soft-key menu is displayed.
21.	Press [F2].	The same send and receive interface conditions are set and SELF-LOOP is displayed at the RECEIVE, INTERFACE ③.
22.	Press [CURSOR OFF].	The cursor is turned OFF.
23.	Press [F1].	The ERROR screen is displayed.

Step	Procedure	Screen																																																																																		
	<pre> SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS 103 104 113 114 115 108 107 105 106 109 125 142 126 --INTERFACE-- </pre> <table border="1"> <thead> <tr> <th>S/R</th> <th>ER</th> <th>RS</th> <th>NS</th> <th colspan="3"></th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>INTER-FACE</td> <td>TIMING</td> <td>CLOCK</td> <td>BIT RATE</td> <td>INT FREQ SOURCE</td> <td>EXT INTER-FACE P1</td> </tr> <tr> <td>SEND</td> <td>UNIT2 V.24/V.28</td> <td>ST/SP</td> <td>INT</td> <td>1200 b/s</td> <td>SELF</td> <td></td> </tr> <tr> <td>RECEIVE</td> <td>UNIT2 V.24/V.28</td> <td>RT</td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p style="text-align: right;">90-06-15 02:29:40 (MORE) MO1</p> <table border="1"> <tr> <td>ERROR</td> <td>VOLT/FREQUENCY</td> <td>DELAY TIME</td> <td>WORD TRACE</td> <td>←</td> <td>→</td> </tr> </table>	S/R	ER	RS	NS												INTER-FACE	TIMING	CLOCK	BIT RATE	INT FREQ SOURCE	EXT INTER-FACE P1	SEND	UNIT2 V.24/V.28	ST/SP	INT	1200 b/s	SELF		RECEIVE	UNIT2 V.24/V.28	RT					ERROR	VOLT/FREQUENCY	DELAY TIME	WORD TRACE	←	→	<pre> SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS 103 104 113 114 115 108 107 105 106 109 125 142 126 --INTERFACE-- </pre> <table border="1"> <thead> <tr> <th>S/R</th> <th>ER</th> <th>RS</th> <th>NS</th> <th colspan="3"></th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>INTER-FACE</td> <td>DATA LENGTH</td> <td>PARITY</td> <td>STOP BIT</td> <td>SEND CONTROL</td> <td>P2</td> </tr> <tr> <td>SEND</td> <td>UNIT4 V.24/V.28</td> <td>8 BIT</td> <td>NON</td> <td>2 BIT</td> <td>ALL-WAYS</td> <td></td> </tr> <tr> <td>RECEIVE</td> <td>UNIT4 V.24/V.28</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p style="text-align: right;">90-06-15 02:30:18 (MORE) MO1</p> <table border="1"> <tr> <td>ERROR</td> <td>VOLT/FREQUENCY</td> <td>DELAY TIME</td> <td>WORD TRACE</td> <td>←</td> <td>→</td> </tr> </table>	S/R	ER	RS	NS												INTER-FACE	DATA LENGTH	PARITY	STOP BIT	SEND CONTROL	P2	SEND	UNIT4 V.24/V.28	8 BIT	NON	2 BIT	ALL-WAYS		RECEIVE	UNIT4 V.24/V.28						ERROR	VOLT/FREQUENCY	DELAY TIME	WORD TRACE	←	→
S/R	ER	RS	NS																																																																																	
	INTER-FACE	TIMING	CLOCK	BIT RATE	INT FREQ SOURCE	EXT INTER-FACE P1																																																																														
SEND	UNIT2 V.24/V.28	ST/SP	INT	1200 b/s	SELF																																																																															
RECEIVE	UNIT2 V.24/V.28	RT																																																																																		
ERROR	VOLT/FREQUENCY	DELAY TIME	WORD TRACE	←	→																																																																															
S/R	ER	RS	NS																																																																																	
	INTER-FACE	DATA LENGTH	PARITY	STOP BIT	SEND CONTROL	P2																																																																														
SEND	UNIT4 V.24/V.28	8 BIT	NON	2 BIT	ALL-WAYS																																																																															
RECEIVE	UNIT4 V.24/V.28																																																																																			
ERROR	VOLT/FREQUENCY	DELAY TIME	WORD TRACE	←	→																																																																															
	After setting the SELF LOOP mode																																																																																			
	<pre> D RD TI T RT ER DR R D I TI N 103 104 113 114 115 108 107 105 106 109 125 142 126 --INTERFACE-- </pre> <table border="1"> <thead> <tr> <th>S/R</th> <th>ER</th> <th>RS</th> <th>NS</th> <th colspan="3"></th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>INTER-FACE</td> <td>TIMING</td> <td>CLOCK</td> <td>BIT RATE</td> <td>INT FREQ SOURCE</td> <td>EXT INTER-FACE P1</td> </tr> <tr> <td>SEND</td> <td>UNIT2 V.24/V.28</td> <td>ST/SP</td> <td>INT</td> <td>1200 b/s</td> <td>SELF</td> <td></td> </tr> <tr> <td>RECEIVE</td> <td>SELF LOOP</td> <td>ST/SP</td> <td></td> <td>1200 b/s</td> <td></td> <td></td> </tr> </tbody> </table> <p style="text-align: right;">90-06-15 02:32:00 (MORE) MO1</p> <table border="1"> <tr> <td>ERROR</td> <td>VOLT/FREQUENCY</td> <td>DELAY TIME</td> <td>WORD TRACE</td> <td>←</td> <td>→</td> </tr> </table>	S/R	ER	RS	NS												INTER-FACE	TIMING	CLOCK	BIT RATE	INT FREQ SOURCE	EXT INTER-FACE P1	SEND	UNIT2 V.24/V.28	ST/SP	INT	1200 b/s	SELF		RECEIVE	SELF LOOP	ST/SP		1200 b/s			ERROR	VOLT/FREQUENCY	DELAY TIME	WORD TRACE	←	→	<pre> SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS 103 104 113 114 115 108 107 105 106 109 125 142 126 --INTERFACE-- </pre> <table border="1"> <thead> <tr> <th>S/R</th> <th>ER</th> <th>RS</th> <th>NS</th> <th colspan="3"></th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>INTER-FACE</td> <td>DATA LENGTH</td> <td>PARITY</td> <td>STOP BIT</td> <td>SEND CONTROL</td> <td>P2</td> </tr> <tr> <td>SEND</td> <td>UNIT2 V.24/V.28</td> <td>8 BIT</td> <td>NON</td> <td>2 BIT</td> <td>ALL-WAYS</td> <td></td> </tr> <tr> <td>RECEIVE</td> <td>SELF LOOP</td> <td>8 BIT</td> <td>NON</td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p style="text-align: right;">90-06-15 02:32:39 (MORE) MO1</p> <table border="1"> <tr> <td>ERROR</td> <td>VOLT/FREQUENCY</td> <td>DELAY TIME</td> <td>WORD TRACE</td> <td>←</td> <td>→</td> </tr> </table>	S/R	ER	RS	NS												INTER-FACE	DATA LENGTH	PARITY	STOP BIT	SEND CONTROL	P2	SEND	UNIT2 V.24/V.28	8 BIT	NON	2 BIT	ALL-WAYS		RECEIVE	SELF LOOP	8 BIT	NON				ERROR	VOLT/FREQUENCY	DELAY TIME	WORD TRACE	←	→
S/R	ER	RS	NS																																																																																	
	INTER-FACE	TIMING	CLOCK	BIT RATE	INT FREQ SOURCE	EXT INTER-FACE P1																																																																														
SEND	UNIT2 V.24/V.28	ST/SP	INT	1200 b/s	SELF																																																																															
RECEIVE	SELF LOOP	ST/SP		1200 b/s																																																																																
ERROR	VOLT/FREQUENCY	DELAY TIME	WORD TRACE	←	→																																																																															
S/R	ER	RS	NS																																																																																	
	INTER-FACE	DATA LENGTH	PARITY	STOP BIT	SEND CONTROL	P2																																																																														
SEND	UNIT2 V.24/V.28	8 BIT	NON	2 BIT	ALL-WAYS																																																																															
RECEIVE	SELF LOOP	8 BIT	NON																																																																																	
ERROR	VOLT/FREQUENCY	DELAY TIME	WORD TRACE	←	→																																																																															
24.	Move the cursor by pressing <input checked="" type="checkbox"/> three times.	The cursor is displayed at <input checked="" type="checkbox"/> .																																																																																		
25.	Press [F5].	RT is displayed at frequency measurement signal-line <input checked="" type="checkbox"/> .																																																																																		
26.	Move the cursor by pressing <input checked="" type="checkbox"/> once.	The cursor is displayed at <input checked="" type="checkbox"/> .																																																																																		
27.	Press [F1].	100 ms is displayed at GAME TIME <input checked="" type="checkbox"/> .																																																																																		
28.	Move the cursor by pressing <input checked="" type="checkbox"/> once.	The cursor is displayed at <input checked="" type="checkbox"/> .																																																																																		
29.	Press [F1].	0.5 sec is displayed at INTERVAL <input checked="" type="checkbox"/> .																																																																																		
30.	Press [CURSOR OFF].	The cursor is turned OFF.																																																																																		
31.	Press [F1].	Measurement starts (1.20 (kHz) is displayed at <input checked="" type="checkbox"/> .)																																																																																		


Step	Procedure	Screen																																														
		<div data-bbox="412 237 1105 709" style="border: 1px solid black; padding: 5px;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="font-size: small;">SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS</td> <td style="font-size: small;">103 104 113 114 115 108 107 105 106 109 125 142 126</td> </tr> <tr> <td colspan="2" style="text-align: center;">-- VOLT/FREQUENCY --</td> </tr> <tr> <td style="border: 1px solid black;">S/R</td> <td style="border: 1px solid black;">ER : ↓</td> <td style="border: 1px solid black;">RS : ↓</td> <td style="border: 1px solid black;">NS : ↓</td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> </tr> <tr> <td style="border: 1px solid black;">SD (V)</td> <td colspan="3" style="border: 1px solid black;"></td> <td colspan="4" style="border: 1px solid black;">PATTERN 2+6-1 NORMAL NO-SUP</td> </tr> <tr> <td style="border: 1px solid black;">-0.27</td> <td colspan="3" style="border: 1px solid black;">Ⓜ RT</td> <td colspan="2" style="border: 1px solid black;">(KHz)</td> <td colspan="2" style="border: 1px solid black;">GATE TIME 100ms Ⓢ</td> </tr> <tr> <td colspan="4" style="border: 1px solid black;">Ⓜ 1.20</td> <td colspan="4" style="border: 1px solid black;">INTERVAL 0.5sec Ⓢ</td> </tr> <tr> <td colspan="4" style="border: 1px solid black;"></td> <td colspan="4" style="border: 1px solid black;">LINE SELECT SIGNAL Ⓢ</td> </tr> </table> <div style="margin-top: 10px; text-align: right;"> SAV RCL 90-06-15 05:15:17 (MORE) MO1 </div> <div style="margin-top: 10px;"> <table style="width: 100%;"> <tr> <td style="border: 1px solid black; width: 50%;">START COUNT</td> <td style="border: 1px solid black; width: 50%;">PRINT OUT</td> </tr> </table> </div> </div>	SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS	103 104 113 114 115 108 107 105 106 109 125 142 126	-- VOLT/FREQUENCY --		S/R	ER : ↓	RS : ↓	NS : ↓					SD (V)				PATTERN 2+6-1 NORMAL NO-SUP				-0.27	Ⓜ RT			(KHz)		GATE TIME 100ms Ⓢ		Ⓜ 1.20				INTERVAL 0.5sec Ⓢ								LINE SELECT SIGNAL Ⓢ				START COUNT	PRINT OUT
SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS	103 104 113 114 115 108 107 105 106 109 125 142 126																																															
-- VOLT/FREQUENCY --																																																
S/R	ER : ↓	RS : ↓	NS : ↓																																													
SD (V)				PATTERN 2+6-1 NORMAL NO-SUP																																												
-0.27	Ⓜ RT			(KHz)		GATE TIME 100ms Ⓢ																																										
Ⓜ 1.20				INTERVAL 0.5sec Ⓢ																																												
				LINE SELECT SIGNAL Ⓢ																																												
START COUNT	PRINT OUT																																															

Check method

- When measurements are performed correctly and "1.20 kHz" is displayed at Step 38, operation is normal.

4.5 Check the Output Level

- Connection



Oscilloscope: frequency range > 200 MHz

A: TO DCE 25-Pin Connections Pin: No.2 (SD),
No.4 (RS), No.11 (NS), No.20 (ER), No.24 (ST1)

- Setting the interface display

SEND

```
INTERFACE      : V.24/V.28
TIMING         : ST1
CLOCK         : INT
BIT RATE      : 1200 b/s
INT FREQ SOURCE : SELF
SEND CONTROL   : ALWAYS
```

- Setting the error measurement display

PATTERN 1:1

- Setting the signal-line

ER: ON (↑), RS: ON (↑), NS: ON (↑)

- Output level

As regards the 3 to 7 kΩ unbalanced duty resistor, a voltage drop of more than 5 V but less than 15 V must occur.

SECTION 5 REMOTE CONTROL

5.1 Overview of Remote Control

The MD6420A Data Transmission Analyzer can also be used to perform measurements via a remote controller (Anritsu Packet V, IBM-PC, NEC PC-9801 (Japan), etc.) when either of the following two Remote Control Units are used.

- MD0620A GP-IB Remote Control Unit
- MD0620B RS-232C Remote Control Unit.

The MD6420A can be used to remotely control measurements made by the V.24/V.28 Unit.

This section describes items that are unique to a V.24/V.28 Unit being used for remote-control measurements.

For a description of MD6420A common commands, sample programs, etc., refer to the MD6420A operation manual.

The following are described in each paragraph of this section:

5.2 Control Command Table

- (1) INTERFACE screen
- (2) ERROR screen
- (3) VOLT/FREQUENCY screen
- (4) DELAY TIME screen
- (5) WORD TRACE screen

5.3 Response Data Table

For a detailed description of each command, see Appendix B. For a detailed description of the response data, see Appendix C.

5.4 Control Command Table

(1) INTERFACE screen-1

Item to be set	Command name	Parameter	Page
Inserted unit No. (send)	SUT	0 to 5	B - 2
Send-interface unit condition	SUN	0 to 14	B - 2
Send-signal generation timing	SMD	0, 3 to 7	B - 3
Type of send-signal clock	SCK	0, 1	B - 5
Frequency of internal send clock	SBR	50 to 20000	B - 5
Type of internal-clock slave send signal	IFS	0 to 3	B - 6
Type of external-clock input send interface	EI	0, 1	B - 6
Send-data length	SDL	5 to 8	B - 7
Send-data parity	SPR	0 to 2	B - 7
Type of send-data stop bit	SSP	0 to 2	B - 8
Send control signal	CT	0, 1	B - 8
No. of inserted unit function (receive)	RUT	0 to 5, 16	B - 9
Receive interface unit conditions	RUN	0 to 14, 255	B - 9
Receive signal generation timing	RMD	0, 3 to 6	B - 10
Frequency of internal receive clock	RBR	50 to 19200	B - 11
Receive-data length	RDL	5 to 8	B - 11
Receive-data parity	RPR	0 to 2	B - 12
Line to be monitored	MSL	0 to 4	B - 12
Signal line to be monitored	SCT	n : 5, 7, 12 m : 0 to 2	B - 13
Send signal line	SCS	n : 5, 7, 12 m : 0 to 2	B - 13
Receive signal line	SCR	n : 5, 7, 12 m : 0 to 2	B - 14

(2) ERROR screen

Setting item	Command name	Parameter	Page
Measured result display selection (Top left side)	DSA	0 to 11, 15 to 20	B - 15
Measured result display selection (Top right side)	DSB	0 to 11, 15 to 20	B - 16
Measured result display selection (Middle left side)	DSC	0 to 11, 15 to 20	B - 17
Measured result display selection (Middle right side)	DSD	0 to 11, 15 to 20	B - 18
Measured result display selection (bottom left side)	DSE	0 to 11, 15 to 20	B - 19
Alarm output data format specification	OFA	0, 1	B - 20

(3) VOLT/FREQUENCY screen

Setting item	Command name	Parameter	Page
Voltage measurement line	VM	0 to 12	B - 20
Frequency measurement line	FM	0 to 12	B - 21

(4) DELAY TIME screen

Setting item	Command name	Parameter	Page
Start line	SAL	n : 0 to 12, 13 m : 0, 1	B - 21
Stop line	SOL	n : 0 to 12, 13 m : 0, 1	B - 22


(5) WORD TRACE screen

Setting item	Command name	Parameter	Page
Trace stop line	SL	n : 0 to 12 m : 0, 1	B - 22

5.5 Response Data Table

(1) INTERFACE screen

Setting item	Command name	Parameter	Page
Contests output request	DO?	_____	C-2



SECTION 6

PRINCIPLES OF OPERATION

6.1 Receiver/Driver

6.1.1 Receiver

Figure 6-1 shows an input-circuit block diagram. The signal lines that use this type of circuit are listed below:

RD, ST2, RT, CS, DR, CD, CI, TI




Fig. 6-1 Input-Circuit Block Diagram

The input conditions conform to CCITT recommendation for V.28 interfaces. When the voltage at point A is less than -3 V , the signal is said to be in the binary "1" state. When the voltage (V_A) is greater than $+3\text{ V}$, the signal is said to be in the binary "0" state.

In the control line and timing circuits, when the voltage (V_A) is more than $+3\text{ V}$, the signal is said to be "ON". Conversely when less than -3 V , the signal is said to be "OFF".

Table 6-1

	$V_A < -3\text{ V}$	$V_A > +3\text{ V}$
Data circuit	1	0
Control and timing circuits	OFF	ON

6.1.2 The V.28 driver

Figure 6-2 is the block diagram for the output circuit. The only V.11 signal lines that can be output are SD, ST1, RS, ER and NS.




Fig. 6-2 Output-Circuit Block Diagram

The output conditions conform to CCITT recommendations for V.28 interfaces.

As regards the 3 to 7 kΩ unbalanced duty resistor, a voltage drop of more than 5 V but less than 15 V must occur.

6.2 Connecting Circuits

(1) SD [CCITT Circuit No. 103/RS-232C, Circuit name BA/25P Connector pin No.2]

Direction: Towards DCE

- (a) Used to transmit to one or more remote data stations via a data channel,
 - (b) Used to convert to DCE during maintenance testing via DTE control,
- or
- (c) Used for programming serial automatic calling routines for DCE or control,

Data signals generated by DTE are converted to DCE by this circuit.

(2) RD [CCITT Circuit No. 104/RS-232C, Circuit name BB/25P Connector pin No.3]

Direction: From DCE

Signal generated by DCE,

- (a) Used to respond to data channel tracking signals which are received from remote data stations,
- (b) Used to respond to DTE maintenance tests,

Response signal is transferred to DTE via this circuit. or

- (c) Signal generated in response to serial automatic calls to the DCE by a program from the DTE,

Response signal is transferred to DTE via this circuit.

Note: Receive conditions for maintenance test signal are specified by circuit 107.

(3) ST1 [CCITT Circuit No. 113/RS-232C, Circuit name DA/25P Connector pin No.24]

Direction: Toward DCE

The signal from this circuit provides signal element timing information to the DCE. This signal has equal ON and OFF intervals and switches from ON to OFF at the midpoint of each signal as specified for circuit 103.

(4) ST2 [CCITT Circuit No. 114/RS-232C, Circuit name DB/25P Connector pin No.15]

Direction: From DCE

The signal from this circuit provides signal element timing information to the DCE. This signal has equal ON and OFF intervals, and is generated such that OFF to ON switching of Circuit 114 occurs in synchrony with Circuit 103.

(5) RT [CCITT Circuit No. 115/RS-232C, Circuit name DD/25P Connector pin No.17]

Direction: From DCE

The signal from this circuit provides signal element timing information to the DCE. The signal has equal ON and OFF intervals and switches from ON to OFF at the midpoint of each signal element as specified for circuit 104.

(6) ER [CCITT Circuit No. 108/RS-232C, Circuit name CD/25P Connector pin No.20]

Direction: Towards DCE

This signal is used to control signal conversion and switching to a DTE line or device.

The ON state indicates that a DTE line or device is in use and that all DCE signals need to be converted appropriately. The DTE and DCE elements can only be connected after being converted externally.

The DTE ON state for circuit 108/2 is used any time data reception is expected to occur.

The OFF state is entered after all data has been transferred to circuit 103, circuit 118 or any other appropriate circuit. At that moment, DCE signal conversion is disabled.

(7) DR [CCITT Circuit No. 107/RS-232C, Circuit name CC/25P Connector pin No.6]

Direction: From DCE

This signal indicates whether or not DCE conversion is effective. When circuit 142 is OFF or not in use, signal conversion is enabled as indicated by the ON state of circuit 107. This indicates that DCE conversion in preparation for reception of the control signals from the DTE has occurred.

When circuit 142 is ON, the ON state of circuit 107 can be used during maintenance testing to verify that the receive data signal is converted from DCE to DTE. When circuit 106 is ON, the ON state of circuit 107 can be used to verify that sequential self-calling programs or data signals are executed in the DCE mode.

When circuit 106 is OFF, the OFF state of circuit 107 indicates that the:

- (a) DCE cannot convert and transfer data
- (b) DCE has detected an impasse relative to the circuit network or DCE conversions, or
- (c) The DCE has detected an unconnected display located remotely or in the circuit network.

Note: When referring to paragraphs (b) and (c) above within the DCE recommendations, consult the appropriate agencies for user rights and information regarding these functions.

(8) RS [CCITT Circuit No. 105/RS-232C, Circuit name CA/25P Connector pin No.4]

Direction: Towards DCE

This signal controls the sending of data on a DCE channel. In the ON state, data are sent on the channel by the DCE. In the OFF state, data transfers to circuit 103 are completed, after which data transmissions on the channel by the DCE are disabled.

(9) CS [CCITT Circuit No. 106/RS-232C, Circuit name CS/25P Connector pin No.5]

Direction: From DCE

This signal indicates that the DCE is ready to receive data sent on the data channel and can be used during maintenance checks of the DTE control.

The ON state indicates that the DCE is ready to receive data sent by the DTE. The OFF state indicates that the DCE is not ready to receive data sent by the DTE.

(10) CD [CCITT Circuit No. 109/RS-232C, Circuit name CF/25P Connector pin No.8]

Direction: From DCE

This signal indicates whether or not the signal received on the data receive channel is within the range specified by the related DCE recommendation.

The ON state indicates that the data signal lines between the DCE and DTE are OK and changing in accordance with the program or serial automatic calling DCE. The OFF state indicates that the receive signal is not in range.

(11) CI [CCITT Circuit No. 125/RS-232C, Circuit name CE/25P Connector pin No.22]

Direction: From DCE

This signal indicates that the DCE has received a non-calling signal.

The ON state indicates that a non-calling signal has been received and vice-versa. The OFF state may also occur during breaks in non-calling signal pulse modulation.

(12) TI [CCITT Circuit No. 142/RS-232C, Circuit name None/25P Connector pin No.25]

Direction: From DCE

This signal indicates whether or not maintenance is in progress.

The ON state indicates that a maintenance test is in progress so that neither the DCE nor the DTE can be used to send data remotely.

(13) NS [CCITT Circuit No. 136/RS-232C, Circuit name None/25P Connector pin No.11]

Direction: Towards DCE

Signals on this circuit are used to control the response times of the DCE receiver.

The ON condition of circuit 136, instructs the DCE receiver to prepare itself to detect rapidly the disappearance of the line signal (e.g., by disabling the response time circuitry associated with

circuit 109). After the received line signal falls below the threshold of the received line signal detector, the DCE will:

- 1) turn OFF circuit 109, and
- 2) prepare itself to detect rapidly the appearance of a new line signal (e.g., by resetting the receiver timing recovery circuitry).

Once turned ON, circuit 136 may be turned OFF after one unit interval and must be turned OFF after circuit 109 is turned OFF. Circuit 136 shall be OFF at all other times.

After the voltage of the receive line signal falls below the threshold value of the receive line signal detector:

- (a) Circuit 109 of the DCE is turned OFF.

Circuit 136 is turned OFF again only after 1 unit interval has elapsed (since it was turned ON) and only after circuit 109 has been turned OFF. Otherwise, circuit 136 is always OFF.

6.3 Send Timing

6.3.1 The ST1 mode

When the ST1 sync mode is selected, the ST1 signal is used as the master clock source for the MD6420A.

Figure 6-3 shows the block diagram for ST1 and SD, while Fig. 6-4 illustrates the phase relationship.




Fig. 6-3 Block-Diagram for ST1 and SD




Fig. 6-4 Phase Relationship

6.3.2 The ST2 mode

When the ST2 sync mode is selected, the ST2 clock supplied by the DCE is used as the send timing signal.

Figure 6-5 shows the block diagram for ST2 and SD, while Fig. 6-6 illustrates the phase relationship.




Fig. 6-5 Relationship Between ST2 and SD




Fig. 6-6 Phase Relationship

6.3.3 The $\overline{ST2}$ mode

When the $\overline{ST2}$ mode is set, the inverted $\overline{ST2}$ clock is used as the send timing signal.

Figure 6-5 again shows the block diagram for $\overline{ST2}$ and SD while Fig. 6-7 illustrates the phase relationship.




Fig. 6-7 Phase Relationship

6.3.4 The ASYNC mode

When the asynchronous mode is set, the MD6420A internal clock is used for both send and receive timing.

Figure 6-8 shows the block diagram for SD, RD and the master clock source.




Fig. 6-8 SD, RD and the Master Clock Source Block Diagram

6.3.5 The ST/SP mode

When the start/stop mode is set, the MD6420A internal clock is used as both the send and receive clock.

Figure 6-9 shows the block diagram for SD, RD and the master clock source.




Fig. 6-9 SD, RD and the Master Clock Source Block Diagram

6.3.6 The RT mode

When the RT synchronous mode is used, the RT (receive timing) clock supplied by the DCE is used as the send timing signal.

Figure 6-10 shows the block diagram for RT and SD while Fig. 6-11 shows the phase relationship.




Fig. 6-10




Fig. 6-11

6.4 Receive Timing

6.4.1 The RT mode

When the RT synchronous mode is selected, the RT clock supplied by the DCE is used as the receive timing signal.

Figure 6-12 shows the block diagram for RT and RD while Fig. 6-13 shows the phase relationship.




Fig. 6-12 RT and RD Block Diagram




Fig. 6-13 Phase Relationship Between RT and RD

6.4.2 The \overline{RT} mode

When the \overline{RT} synchronous mode is set, the inverted \overline{RT} clock is used as the receive timing signal.

Figure 6-12 shows the block diagram for \overline{RT} and RD while Fig. 6-14 shows the phase relationship.




Fig. 6-14

6.4.3 The ST mode

When the ST synchronous mode is set, the MD6420A internal clock is used as both the receive and send timing signal.

Figure 6-15 shows the block diagram for ST1, SD, and RD. Figure 6-16 shows the block diagram for ST2, SD, and RD. Figure 6-17 shows the phase relationship between ST, SD, and RD.




Fig. 6-15 SD and RD Block Diagram




Fig. 6-16 ST2 and SD, RD Block Diagram





Fig. 6-17 Phase Relationship Between ST, SD and RD

6.5 Start/Stop Synchronization

In the synchronous start/stop mode, synchronization is established by inserting data between the start and stop bits.

The figure below shows the format of the bit pattern.



① Start bit

A single 0 bit is inserted at the beginning of each data transmission to indicate the start of data transmission.

② Data bit

A bit length of 5 to 8 bits can be set as the length of the data code.

The codes below correspond to the data bit lengths.

- 5-bit length Baudot code
- 6-bit length EBCD code
- 7-bit length ASCII code
- 8-bit length EBCDIC code

③ Parity bit

Bit for detecting errors. It can be set to ODD or EVEN polarity or it can be disabled.

④ Stop bit

This bit is added to the end of each transmitted byte. The number of added bits can be set to 1, 1.5 or 2 bits.

6.6 Send Control

This paragraph describes the relationship between signal lines RS and CS when CS-ON is set via the SEND CONTROL interface setting.

The MD6420A RS is a signal line used to request data transfers to the modem. When the RS signal is received, the modem sends the carrier signal to the circuit to which the MD6420A is connected. After the carrier signal output by the modem has stabilized, CS is turned ON.

After CS has been turned ON, the pattern to be measured is sent by the MD6420A to the measuring instrument.




Fig. 6-18 RS and CS ON State




Fig. 6-19 RS OFF State

Note: In the CS-ON mode, the CS signal line of the send unit (V.36 in this case) can be measured. (the CS line of the send unit enters a state in which it can be monitored by an LED.)

6.7 Self Loop Mode

In this mode, output data are looped back as input so that instrument self-checking can be performed.






Fig. 6-20 Connections in the Self-Loop Mode

**APPENDIX A
MENU REFERENCE
V.24/V.28 INTERFACE UNIT**

1 V.24/V.28 Interface Unit Menu Reference

◦ If nocursor is displayed → See paragraph 1.1.



Note: When the send and receive interface units differ, the cursor position changes.

1.1 Menu for function selection

Cursor position	Cursor not displayed	Label	None
Outline	Function selection menu on INTERFACE screen		

Function key labels and explanations:

ERROR

- When pressed, the ERROR screen is fetched.
Error measurement is performed via the ERROR screen.

**VOLT/
FREQUENC**

- When pressed, the VOLT/FREQUENCY screen is fetched.
The voltage and frequency of each signal line on the receive side are measured via the VOLT/FREQUENCY screen.

**DELAY
TIME**

- When pressed, the DELAY TIME screen is fetched.
The time difference between transitions in the levels of 2 signal lines or the transmission delay time can be measured via the DELAY TIME screen.

**WORD
TRACE**

- When pressed, the WORD TRACE screen is fetched.
The send pattern is set and receive data are traced via the WORD TRACE screen.



- When pressed, the screen scrolls to the left (previous page).



- When pressed, the screen scrolls to the right (next page).

**PRINT
OUT**

- When pressed, the INTERFACE screen settings are printed.

1.2 Menu for setting the send interface unit conditions

Cursor position	Sets send interface unit conditions	Label	INTER - FACE (SEND)
-----------------	-------------------------------------	-------	------------------------

Outline Sets the send interface unit conditions

Function key labels and explanations:

UNIT 1
XXXXXXX

- When pressed, the send interface unit is set to the interface unit inserted in slot 1.

UNIT 2
XXXXXXX

- When pressed, the send interface unit is set to the interface unit inserted in slot 2.

UNIT 3
XXXXXXX

- When pressed, the send interface unit is set to the interface unit inserted in slot 3.

UNIT 4
XXXXXXX








- When pressed, the send interface unit is set to the interface unit inserted in slot 4.

UNIT 5
XXXXXXX

- When pressed, the send interface unit is set to the interface unit inserted in slot 5.



- When pressed, the screen scrolls to the right (next page).

1.3 Menu for setting generation timing of the send signal			
Cursor position	Sets send signal generation timing	Label	TIMING (SEND)
Outline	Sets send signal generation timing		
Function key labels and explanations:			
	◦ When pressed, the send signal is generated asynchronously.		
	◦ When pressed, the send signal is generated in accordance with ST/SP (Start/Stop).		
	◦ When pressed, the send signal is generated in accordance with the internal clock.		
	◦ When pressed, the send signal is generated in accordance with the ST2 signal.		
	◦ When pressed, the send signal is generated in accordance with the inverted ST2 signal.		
	◦ When pressed, the send signal is generated in accordance with the RT signal.		
	◦ When pressed, the screen scrolls to the right (next page).		

1.4 Menu for type of send signal clock setting

Cursor position	Sets send signal clock	Label	CLOCK (SEND)
Outline	Enables/disables generation of send signal by clock.		

Function key labels and explanations:

INT

- When pressed, the internal clock provides the send clock signal

EXT

- When pressed, the external input clock provides the send clock signal.
(Clock input from EXT1 connector)



- When pressed, the screen scrolls to the right (next page).

1.5 Menu for send internal clock frequency setting

Cursor position	Sets send internal clock frequency	Label	BIT RATE (SEND)
Outline	Sets send internal clock frequency		

Function key labels and explanations:

1200
b/s

- When pressed, the send internal clock frequency is set to the 1200 b/s.

2400
b/s

- When pressed, the send internal clock frequency is set to the 2400 b/s.

4800
b/s

- When pressed, the send internal clock frequency is set to the 4800 b/s.

9600
b/s

- When pressed, the send internal clock frequency is set to the 9600 b/s.

14400
b/s

- When pressed, the send internal clock frequency is set to the 14400 b/s.

19200
b/s

- When pressed, the send internal clock frequency is set to the 19200 b/s.



- When pressed, the screen scrolls to the right (next page).

© Clock frequencies of 50 to 20000 b/s can be set via the DATA MODIFIER key.

1.6 Menu for setting the send internal-clock slave signal

Cursor position	Sets send internal-clock slave signal	Label	INT FREQ SOURCE (SEND)
Outline	Sets the internal clock slave signal		

Function key level and explanations:

SELF

- When pressed, the send internal-clock slave signal is set for internal self oscillation.

EXT1 8k

- When pressed, the send internal-clock slave signal is set to the 8k clock input from EXT1 connector.

EXT2
64 k + 8

- When pressed, the send internal-clock slave signal is set to the 64k + 8k clock input from EXT2 connector.

RD 8k

- When pressed, the send internal-clock slave signal is set to received-signal.



- When pressed, the screen scrolls to the right (next page).

1.7 Menu for setting the send external-clock input interface

Cursor position	Sets send external-clock input interface	Label	EXT INTER- FACE (SEND)
Outline	Sets the signal convention for send signals input from the EXT1 connector.		

Function key label and explanations:

TTL






- When pressed, the send external-clock input interface uses a TTL signal convention.





75 Ω

- When pressed, the send external-clock input interface uses a sine wave (75 Ω) signal convention.



- When pressed, the screen scrolls to the right (next page).

1.8 Menu for send data length setting			
Cursor position	Sets send data length	Label	DATA LENGTH (SEND)
Outline	Sets send data length		
Function key labels and explanations:			
	◦ When pressed, the length of the send data byte is set to 5 bits.		
	◦ When pressed, the length of the send data byte is set to 6 bits.		
	◦ When pressed, the length of the send data byte is set to 7 bits.		
	◦ When pressed, the length of the send data byte is set to 8 bits.		
	◦ When pressed, the screen scrolls to the right (next page).		

1.9 Menu for setting the parity of the send short-frame pattern			
Cursor position	Sets send short-frame pattern parity	Label	PARITY (SEND)
Outline	Sets send short-frame pattern parity		
Function key labels and explanations:			
	◦ When pressed, the send short-frame pattern does not use a parity bit.		
	◦ When pressed, the send short-frame pattern parity is set to odd parity.		
	◦ When pressed, the send short-frame pattern parity is set to even parity.		
	◦ When pressed, the screen scrolls to the right (next page).		

1.10 Menu for setting the send data stop bit

Cursor position	Sets type of send data stop bit	Label	STOP BIT (SEND)
Outline	Sets type of send data stop bit		

Function key labels and explanations:

1 BIT

- When pressed, 1 data stop bit is used.

1.5 BIT

- When pressed, 1.5 data stop bits are used.

2 BIT

- When pressed, 2 data stop bits are used.



- When pressed, the screen scrolls to the right (next page).

1.11 Menu for controlling the send signal

Cursor position	Sets sending of the send signal	Label	SEND CONTROL (SEND)
Outline	Controls sending of the send signal		

Function key labels and explanations:

ALLWAYS

- When pressed, the send signal is continuously sent.

C-ON

- When pressed, the send signal is sent only when the C signal is ON.



- When pressed, the screen scrolls to the right (next page).

1.12 Menu for setting the receive interface unit condition

Cursor position	Sets receive interface unit	Label	INTER-FACE (RECEIVE)
Outline	Sets the receive interface unit condition		

Function key labels and explanations:

- UNIT 1
XXXXXXX

◦ When pressed, the receive interface unit is set to the interface unit inserted in slot 1.
- UNIT 2
XXXXXXX


◦ When pressed, the receive interface unit is set to the interface unit inserted in slot 2.
- UNIT 3
XXXXXXX

◦ When pressed, the receive interface unit is set to the interface unit inserted in slot 3.
- UNIT 4
XXXXXXX

◦ When pressed, the receive interface unit is set to the interface unit inserted in slot 4.
- UNIT 5
XXXXXXX

◦ When pressed, the receive interface unit is set to the interface unit inserted in slot 5.
- SAME

◦ When pressed, the same receive and send interface conditions are set.
- SELF
LOOP

◦ When pressed, the receive interface unit is set to the SELF LOOP mode.
- 

◦ When pressed, the screen scrolls to the right (next page).

1.13 Menu for setting generation timing of the receive signal

Cursor position	Sets receive signal generation timing	Label	TIMING (RECEIVE)
Outline	Sets receive signal generation timing		

Function key labels and explanations:

ASYNC

- When pressed, the receive signal is generated asynchronously.

ST/SP

- When pressed, the receive signal is generated in accordance with ST/SP (Start/Stop).

ST

- When pressed, the receive signal is generated in accordance with the internal clock.

RT

- When pressed, the receive signal is generated in accordance with the RT signal.

RT
(INV)

- When pressed, the receive signal is generated in accordance with the inverted RT signal.



- When pressed, the screen scrolls to the right (next page).

1.14 Menu for setting the receive internal clock frequency

Cursor position	Sets receive internal clock frequency	Label	BIT RATE (RECEIVE)
Outline	Sets receive internal clock frequency		

Function key labels and explanations:

1200
b/s

- When pressed, the receive internal clock frequency is set to 1200 b/s.

2400
b/s

- When pressed, the receive internal clock frequency is set to 2400 b/s.

4800
b/s

- When pressed, the receive internal clock frequency is set to 4800 b/s.

9600
b/s

- When pressed, the receive internal clock frequency is set to 9600 b/s.

14400
b/s

- When pressed, the receive internal clock frequency is set to 14400 b/s.

19200
b/s

- When pressed, the receive internal clock frequency is set to 19200 b/s.



- When pressed, the screen scrolls to the right (next page).

© Clock frequencies of 50 to 19200 b/s can be set via the DATA MODIFIER key.

1.15 Menu for setting the byte length of the receive data

Cursor position	Sets receive data length	Label	DATA LENGTH (RECEIVE)
Outline	Sets the receive data length		

Function key labels and explanations:

5 BIT

- When pressed, the length of the receive data byte is set to 5 bits.

6 BIT

- When pressed, the length of the receive data byte is set to 6 bits.

7 BIT

- When pressed, the length of the receive data byte is set to 7 bits.

8 BIT

- When pressed, the length of the receive data byte is set to 8 bits.



- When pressed, the screen scrolls to the right (next page).

1.16 Menu for setting the parity of the receive short-frame pattern

Cursor position	Sets receive short-frame pattern parity	Label	PARITY (RECEIVE)
Outline	Sets the receive short-frame pattern parity		

Function key labels and explanations:

NON

- When pressed, the receive short-frame pattern parity does not use a parity bit.

ODD

- When pressed, the receive short-frame pattern parity is set to odd parity.

EVEN

- When pressed, the receive short-frame pattern parity is set to even parity.



- When pressed, the screen scrolls to the right (next page).

1.17 Menu for setting the signal-line

Cursor position	Sets signal-line contents	Label	EACH SIGNAL LINE
Outline	Sets/resets the signal-line		

Function key labels and explanations:

↑ (ON)

- When pressed, the signal-line is set to ON.

↓
(OFF)

- When pressed, the signal-line is set to OFF.

(OPEN)

- When pressed, the signal-line is set to OPEN.

2 ERROR Screen

- If no cursor is displayed → See paragraph 2.1.

See paragraph 2.2. →

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS	
103	104	113	114	115	108	107	105	106	109	125	142	126	
-- ERROR --													
S/R		ER :↓	RS :↓	NS :↓									
ERROR COUNT		ERROR RATIO			PATTERN 2↑6-1								
-----		-----			NORMAL NO-SUP								
ES		SES			PSL-THR AUTO								
-----		-----			CYC-ERR 1.0E-6								
CLOCK SLIP		ELAPSED-TIME			CH-ERR REPEAT								
-----		-----			ERR-INS BIT								
		DSPL MODE ELAPS			ERROR BIT								
					BLK-LNG 1.0E1 BIT								
					MEAS REPEAT								
					0:01:00								
					BUZ OFF								
											SAV RCL		
											90-04-23 17:49:18		
											(MORE) MO1		
START MEAS			START COLLECT			START CYC-ERR			START CH-ERR		PRINT OUT		

2.1 Menu for function selection

Cursor position	Cursor off	Label	None
Outline	Menu for selecting ERROR screen functions		

Function key labels and explanations:

- The menu displayed on page 3 (MO3) is shown below:

SEND-ER
ON/OFF

- The send signal line (ER) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-ER
ON/OFF

- The receive signal line (AIS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

ER
ON/OFF

- The signal line (ER) ON/OFF menu is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

SEND-RS
ON/OFF

- The send signal line (RS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-RS
ON/OFF

- The receive signal line (RS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RS
ON/OFF

- The send signal line (RS) ON/OFF key is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

SEND-NS
ON/OFF

- The send signal line (NS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-NS
ON/OFF

- The receive signal line (NS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

NS
ON/OFF

- The signal line (NS) ON/OFF menu is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

2.2 Menu for selecting measured-results to be displayed

Cursor position	Sets measured-results item	Label	None
Outline	Sets the measured-results to be displayed		

Function key labels and explanations:

- The menu displayed on page 4 (MO4) is shown below:

PWL (sec)

- When pressed, the PWL (sec) measured-result is displayed.

PSL (sec)

- When pressed, the PSL (sec) measured-result is displayed.

3 DISPLAY OF RESULTS Screen

- If no cursor is displayed → See paragraph 3.1.

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
103	104	113	114	115	108	107	105	106	109	125	142	126
--DISPLAY OF RESULTS--												
	S/R	ER :↓	RS :↓	NS :↓								
ERROR		0	ERR RTO	0.00E-05	PWL(sec)							0
BLK-ERR		0	BLK RTO	0.00E-04	PSL(sec)							0
US		0	%US	0.00								
SES		0	%SES	0.00								
DM		0	%DM	0.00								
ES		0.00	%ES	0.00								
EFS		1.00	%EFS	100.00								
PSL-CNT		0	ELAPSED-TIME									
CLK-SLIP		0		0:00:01								
			DSPL MODE	ELAPS								

90-04-23 13:42:34
(MORE) MO1

START
MEAS

START
CYC-ERR

START
CH-ERR

PRINT
OUT

3.1 Menu for function selection

Cursor position	Cursor off	Label	None
Outline	Menu for selecting display items for DISPLAY OF RESULTS screen		

Function key labels and explanations:

- The menu displayed on page 2 (MO2) is shown below:

**SEND-ER
ON/OFF**

- The send signal line (ER) ON/OFF key is displayed when the send and receive interfaces are different.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**RECV-ER
ON/OFF**

- The receive signal line (ER) ON/OFF key is displayed when the send and receive interfaces are different.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**ER
ON/OFF**

- The signal line (SA) ON/OFF menu is displayed when the send and receive interfaces are the same.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**SEND-RS
ON/OFF**

- The send signal line (RS) ON/OFF key is displayed when the send and receive interfaces are different.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**RECV-RS
ON/OFF**

- The receive signal line (RS) ON/OFF key is displayed when the send and receive interfaces are different.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**RS
ON/OFF**

- The signal line (RS) ON/OFF key is displayed when the send and receive interfaces are the same.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**SEND-NS
ON/OFF**

- The send signal line (NS) ON/OFF key is displayed when the send and receive interfaces are different.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**RECV-NS
ON/OFF**

- The receive signal line (NS) ON/OFF key is displayed when the send and receive interfaces are different.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**NS
ON/OFF**

- The signal line (NS) ON/OFF key is displayed when the send and receive interfaces are the same.
This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

4 VOLT/FREQUENCY Screen

- If no Cursor is displayed → See paragraph 4.1.

SD RD ST1 ST2 RT ER DR RS CS CD CI TI NS
103 104 113 114 115 108 107 105 106 109 125 142 126
--VOLT/FREQUENCY-- REC V

	SND	ER :↓	RS :↓	NS :↓				
	RCV	ER :↓	RS :↓	NS :↓				

See paragraph 4.2. → SD (V)
0.03

See paragraph 4.3. → SD (KHz)

PATTERN 2†6-1
NORMAL NO-SUP

GATE TIME 100ms
INTERVAL 0.5sec
LINE SELECT REC V

90-04-23 20:37:35
(MORE) MO1

START COUNT

PRINT OUT

4.1 Menu for function selection

Cursor position	Cursor off	Label	None
Outline	VOLT/FREQUENCY screen functions selection menu		

Function key labels and explanations:

- The menu displayed on page 2 (MO2) is shown below:

SEND-ER
ON/OFF

- The send signal line (ER) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-ER
ON/OFF

- The receive signal line (ER) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

ER
ON/OFF

- The signal line (ER) ON/OFF key is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

SEND-RS
ON/OFF

- The send signal line (RS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-RS
ON/OFF

- The receive signal line (RS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RS
ON/OFF

- The signal line (RS) ON/OFF key is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

SEND-NS
ON/OFF

- The send signal line (NS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-NS
ON/OFF

- The receive signal line (NS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

NS
ON/OFF

- The signal line (NS) ON/OFF key is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

4.2 Menu for selecting signal-Line for voltage measurement

Cursor position	Selects voltage-measurement signal line	Label	None
Outline	Selects the voltage-measurement signal line		

Function key labels and explanations:

SD	◦ SD is selected as the voltage-measurement signal line.
RD	◦ RD is selected as the voltage-measurement signal line.
ST1	◦ ST1 is selected as the voltage-measurement signal line.
ST2	◦ ST2 is selected as the voltage-measurement signal line.
RT	◦ RT is selected as the voltage-measurement signal line.
ER	◦ ER is selected as the voltage-measurement signal line.
DR	◦ DR is selected as the voltage-measurement signal line.
RS	◦ RS is selected as the voltage-measurement signal line.
CS	◦ CS is selected as the voltage-measurement signal line.
CD	◦ CD is selected as the voltage-measurement signal line.
CI	◦ CI is selected as the voltage-measurement signal line.
TI	◦ TI is selected as the voltage-measurement signal line.
NS	◦ NS is selected as the voltage-measurement signal line.

4.3 Menu for selecting the signal-line for frequency measurement

Cursor position	Selects frequency-measurement signal line	Label	None
Outline	Selects the frequency-measurement signal line		

Function key labels and explanations:

SD

◦ SD is selected as the frequency-measurement signal line.

RD

◦ RD is selected as the frequency-measurement signal line.

ST1

◦ ST1 is selected as the frequency-measurement signal line.

ST2

◦ ST2 is selected as the frequency-measurement signal line.

RT

◦ RT is selected as the frequency-measurement signal line.

ER

◦ ER is selected as the frequency-measurement signal line.

DR

◦ DR is selected as the frequency-measurement signal line.

RS

◦ RS is selected as the frequency-measurement signal line.

CS

◦ CS is selected as the frequency-measurement signal line.

CD

◦ CD is selected as the frequency-measurement signal line.

CI

◦ CI is selected as the frequency-measurement signal line.

TI

◦ TI is selected as the frequency-measurement signal line.

NS

◦ NS is selected as the frequency-measurement signal line.

5 DELAY TIME Screen

- If no cursor is displayed → See paragraph 5.1.

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
103	104	113	114	115	108	107	105	106	109	125	142	126
--DELAY TIME--												
	S/R	ER :↓	RS :↓	NS :↓								
					(ms)	LINE INTERVAL						
					-----	LINE SELECT SIGNAL						
						START	SD	0→1				
						STOP	SD	1→0				
<div style="text-align: right;"> SAV RCL 90-04-23 13:59:57 (MORE) MO1 </div>												
START COUNT			START REPEAT			PRINT OUT						

See paragraph 5.2.

See paragraph 5.3.

5.1 Menu for function selection

Cursor position	Cursor off	Label	None
Outline	DELAY TIME screen functions selection menu		

Function key labels and explanations:

- The menu displayed on page 2 (MO2) is shown below:

SEND-ER
ON/OFF

- The send signal line (ER) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-ER
ON/OFF

- The receive signal line (ER) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

ER
ON/OFF

- The signal line (ER) ON/OFF key is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

SEND-RS
ON/OFF

- The send signal line (RS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-RS
ON/OFF

- The receive signal line (RS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RS
ON/OFF

- The signal line (RS) ON/OFF menu is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

SEND-NS
ON/OFF

- The send signal line (NS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

RECV-NS
ON/OFF

- The receive signal line (NS) ON/OFF key is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

NS
ON/OFF

- The signal line (NS) ON/OFF menu is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

5.2 Menu for identifying the signal line to be used as the start trigger in line-transition delay measurements

Cursor position	Selects the signal line to be used as the start-trigger when measuring the time difference between signal transitions.	Label	START
Outline	Selects the signal line to be used as the start-trigger when measuring the time difference between signal transitions.		

Function key labels and explanations:

SD	◦ When pressed, SD is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
RD	◦ When pressed, RD is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
ST1	◦ When pressed, ST1 is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
ST2	◦ When pressed, ST2 is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
RT	◦ When pressed, RT is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
ER	◦ When pressed, ER is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
DR	◦ When pressed, DR is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
RS	◦ When pressed, RS is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
CS	◦ When pressed, CS is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
CD	◦ When pressed, CD is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
CI	◦ When pressed, CI is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
TI	◦ When pressed, TI is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.
NS	◦ When pressed, NS is selected as the signal line to be used as the start-trigger when measuring the time difference between signal transitions.

5.3 Menu for identifying the signal line to be used as the stop trigger in line transition delay measurements

Cursor position	Selects the signal line to be used as the stop trigger in signal line transition measurements	Label	STOP
Outline	Selects the signal line to be used as the stop trigger when measuring the time difference between signal transitions.		

Function key labels and explanations:

SD

- When pressed, SD is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

RD

- When pressed, RD is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

ST1

- When pressed, ST1 is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

ST2

- When pressed, ST2 is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

RT

- When pressed, RT is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

ER

- When pressed, ER is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

DR

- When pressed, DR is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

RS

- When pressed, RS is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

CS

- When pressed, CS is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

CD

- When pressed, CD is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

CI

- When pressed, CI is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

TI

- When pressed, TI is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

NS

- When pressed, NS is selected as the signal line to be used as the stop trigger when measuring the time difference between signal transitions.

6 WORD TRACE Screen

- If no cursor is displayed → See paragraph 6.1.

SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
103	104	113	114	115	108	107	105	106	109	125	142	126
--WORD TRACE--											SEND	
	SND	ER :↓	RS :↓	NS :↓								
	RCV	ER :↓	RS :↓	NS :↓								
SEND												
IDLE CODE		0000 0000		SEND DATA		PRGM						
				WORD ADDRESS		0						
SEND METHOD		MANUAL		PATTERN		1110 0011						
				LENGTH		2BYTE						
TRACE												
SYNC CODE		XXXX XXXX		TRACE STOP		LINE						
LINE SELECT		SIGNAL		STOP DELAY		SD OFF→ON						
						0BYTE						
											SAV RCL	
											90-04-23 20:43:05	
											(MORE) MO1	
START SEND			START TRACE			TRACE DISPLAY			PRINT OUT			

See paragraph 6.2

6.1 Menu for function selection

Cursor position	Cursor off	Label	None
Outline	WORD TRACE screen functions selection menu		

Function key labels and explanations:

- The menu displayed on page 2 (MO2) is shown below:

**SEND-ER
ON/OFF**

- When pressed, the send signal line (ER) ON/OFF menu is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**RECV-ER
ON/OFF**

- When pressed, the receive signal line (ER) ON/OFF menu is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**ER
ON/OFF**

- When pressed, the signal line (ER) ON/OFF menu is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**SEND-RS
ON/OFF**

- When pressed, the send signal line (RS) ON/OFF menu is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**RECV-RS
ON/OFF**

- When pressed, the receive signal line (RS) ON/OFF menu is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**RS
ON/OFF**

- When pressed, the signal line (RS) ON/OFF menu is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**SEND-NS
ON/OFF**

- When pressed, the send signal line (NS) ON/OFF menu is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**RECV-NS
ON/OFF**

- When pressed, the receive signal line (NS) ON/OFF menu is displayed when the send and receive interfaces are different. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

**NS
ON/OFF**


- When pressed, the signal line (NS) ON/OFF menu is displayed when the send and receive interfaces are the same. This key is toggled. When it is pressed, if it is ON, it is turned OFF and if it is OFF, it is turned ON.

6.2 Menu for setting the signal line to be used as the trace-stop trigger

Cursor position	Sets TRACE STOP to LINE and moves to next item.	Label	None
Outline	Sets the trace stop trigger signal line		

Function key label and explanations:

SD	◦ When pressed, SD is set as the trace-stop trigger signal line
RD	◦ When pressed, RD is set as the trace-stop trigger signal line
ST1	◦ When pressed, ST1 is set as the trace-stop trigger signal line
ST2	◦ When pressed, ST2 is set as the trace-stop trigger signal line
RT	◦ When pressed, RT is set as the trace-stop trigger signal line
ER	◦ When pressed, ER is set as the trace-stop trigger signal line
DR	◦ When pressed, DR is set as the trace-stop trigger signal line
RS	◦ When pressed, RS is set as the trace-stop trigger signal line
CS	◦ When pressed, CS is set as the trace-stop trigger signal line
CD	◦ When pressed, CD is set as the trace-stop trigger signal line
CI	◦ When pressed, CI is set as the trace-stop trigger signal line
TI	◦ When pressed, TI is set as the trace-stop trigger signal line
NS	◦ When pressed, NS is set as the trace-stop trigger signal line



**APPENDIX B
COMMAND DEFERENCE
EXTERNAL CONTROLLER**

SUT		INTERFACE screen	
Sets insert unit No. (send)			
Format	SUT n	Parameter range	0 to 5
<p>< Details ></p> <p>Switches the send insert unit.</p> <hr/> <p>n : Unir No.</p> <hr/> <p>0 THROUGH</p> <p>1 Unit No. 1</p> <p>2 Unit No. 2</p> <p>3 Unit No. 3</p> <p>4 Unit No. 4</p> <p>5 Unit No. 5</p> <hr/>			

SUN		INTERFACE screen	
Sets send interface unit conditions			
Format	SUN n	Parameter range	0 to 14
<p>< Details ></p> <p>Specifies the send interface unit.</p> <p>When the type of interface unit is specified, the slot No. in which this interface unit is inserted will be read automatically.</p>			

SMD	INTERFACE screen	
-----	------------------	--

Sets send signal generation timing

Format	SMD n	Parameter Range	0, 3, 4, 5, 6, 7
--------	-------	-----------------	------------------

<Details>

Selects the method to be used to generate the send signal.

n : Signal generation timing method

- 0 ST1
- 3 ST2
- 4 ST2 (INV)
- 5 ASYNC
- 6 ST/SP
- 7 RT

Note: Set the send and receive timing parameters for DCE/DTE connections in the following order:

	DTE send	Send timing	Receive timing
TO DCE	ST1	ST1	RT
	ST2	ST2	RT
TO DTE	ST1	ST1	RT
	ST2	ST1	ST

SCK	INTERFACE screen								
Sets the type of send signal clock									
Format	SCK n	Parameter range	0 to 1						
<p>< Details ></p> <p>Switches the send signal clock.</p> <table border="1"> <tr> <td>n</td> <td>: Clock</td> </tr> <tr> <td>0</td> <td>INTERNAL</td> </tr> <tr> <td>1</td> <td>EXTERNAL</td> </tr> </table> <p>Note: This can be set only when the send signal is generated in the ASYNC, ST/SP on ST1 modes.</p>				n	: Clock	0	INTERNAL	1	EXTERNAL
n	: Clock								
0	INTERNAL								
1	EXTERNAL								

SBR	INTERFACE screen		
Sets the send frequency for the internal clock			
Format	SBR n	Parameter range	50 to 20000
<p>< Details ></p> <p>Sets the send frequency for the internal clock.</p> <ul style="list-style-type: none"> The frequency can be set from 50 to 20000 Hz. <p>Note: This can be used to set only the send frequency of the INTERNAL clock.</p>			

IFS	INTERFACE screen											
Sets the source to which the internal-clock send signal is to be slave-synchronized												
Format	IFS n	Parameter range 0 to 3										
<p>< Details ></p> <p>Switches the frequency source used for slave synchronization.</p> <table border="0"> <tr> <td><u>n</u></td> <td>: Frequency source</td> </tr> <tr> <td>0</td> <td>SELF</td> </tr> <tr> <td>1</td> <td>EXT1 8k</td> </tr> <tr> <td>2</td> <td>EXT2 64k + 8k</td> </tr> <tr> <td>3</td> <td>RD 8k</td> </tr> </table> <p>Note: This can be set only when an INTERNAL send signal clock is used.</p>			<u>n</u>	: Frequency source	0	SELF	1	EXT1 8k	2	EXT2 64k + 8k	3	RD 8k
<u>n</u>	: Frequency source											
0	SELF											
1	EXT1 8k											
2	EXT2 64k + 8k											
3	RD 8k											

EI	INTERFACE screen							
Sets the type of send external-clock input interface								
Format	EI n	Parameter range 0, 1						
<p>< Details ></p> <p>Switches the type of send external-clock input interface.</p> <table border="0"> <tr> <td><u>n</u></td> <td>: Type of external-clock input signal</td> </tr> <tr> <td>0</td> <td>TTL</td> </tr> <tr> <td>1</td> <td>75 Ω</td> </tr> </table> <p>Note: This can be set only when an EXTERNAL send signal clock is used.</p>			<u>n</u>	: Type of external-clock input signal	0	TTL	1	75 Ω
<u>n</u>	: Type of external-clock input signal							
0	TTL							
1	75 Ω							

SDL	INTERFACE screen	
Sets length of send data byte		
Format	SDL n	Parameter range 5 to 8
<p>< Details ></p> <p>Sets the length of the send data byte.</p> <hr/> <p>n : 5 5BIT</p> <p>6 6BIT</p> <p>7 7BIT</p> <p>8 8BIT</p> <hr/> <p>Note: This can be set only when ST/SP is used to generate the send signal.</p>		

SPR	INTERFACE screen	
Sets send short-frame pattern parity		
Format	SPR n	Parameter range 0 to 2
<p>< Details ></p> <p>Switches the send short-frame pattern parity.</p> <hr/> <p>n : Parity</p> <p>0 NON</p> <p>1 ODD</p> <p>2 EVEN</p> <hr/> <p>Note: This can be set only when the send signal is generated by the ST/SP signal.</p>		

SSP	INTERFACE screen										
Sets the number of send data stop bits											
Format	SSP n	Parameter range	0 to 2								
<p>< Details ></p> <p>Sets the number of send data stop bits.</p> <table border="1"> <tr> <td>n</td> <td>: Number of stop bits</td> </tr> <tr> <td>0</td> <td>1BIT</td> </tr> <tr> <td>1</td> <td>1.5BIT</td> </tr> <tr> <td>2</td> <td>2BIT</td> </tr> </table> <p><i>Note:</i> This can be set only when the send signal is generated by ST/SP signal.</p>				n	: Number of stop bits	0	1BIT	1	1.5BIT	2	2BIT
n	: Number of stop bits										
0	1BIT										
1	1.5BIT										
2	2BIT										

CT	INTERFACE screen								
Controls the send signal									
Format	CT n	Parameter range	0, 1						
<p>< Details ></p> <p>Selects the conditions under which the send signal is sent.</p> <table border="1"> <tr> <td>n</td> <td>: Send control mode</td> </tr> <tr> <td>0</td> <td>ALWAYS</td> </tr> <tr> <td>1</td> <td>CS-ON only</td> </tr> </table>				n	: Send control mode	0	ALWAYS	1	CS-ON only
n	: Send control mode								
0	ALWAYS								
1	CS-ON only								

RUT	INTERFACE screen	
Specifies the unit No. to be used for receiving		
Format	RUT n	Parameter range 0 to 5, 16
<p>< Details ></p> <p>Selects the unit to be used for receiving</p> <hr/> <p>n 0 : Slot number into which the unit to be used for receiving is inserted</p> <p>1 : Unit No.1</p> <p>2 : Unit No.2</p> <p>3 : Unit No.3</p> <p>4 : Unit No.4</p> <p>5 : Unit No.5</p> <p>16 : SELP LOOP</p> <hr/>		

RUN	INTERFACE screen	
Sets receive interface unit conditions		
Format	RUT n	Parameter range 0 to 14, 255
<p>< Details ></p> <p>Specifies the receive interface unit.</p> <p>When the No. of the interface unit is specified, the slot No. is read automatically.</p>		

RMD	INTERFACE screen	
-----	------------------	--

Sets generation timing for the receive signal

Format	RMD n	Parameter Range	0, 3, 4, 5, 6
--------	-------	-----------------	---------------

<Details>

Selects the method or signal to be used to generate the receive signal.

n	Signal generation timing
0	ST
3	RT
4	RT (INV)
5	ASYNC
6	ST/SP

RBR	INTERFACE screen																																																														
Sets the receive frequency of the internal clock																																																															
Format	RBR n	Parameter range	50 to 19200																																																												
<p>< Details ></p> <p>The receive frequency.</p> <ul style="list-style-type: none"> • n can be set from 50 to 20000 Hz. <p>Note:</p> <ul style="list-style-type: none"> • This can be set to set the frequency of the receive signal only when the ST/SP mode is used. • The receive frequency of the internal clock can be set to any one of the following values. <table border="1"> <thead> <tr> <th>No.</th> <th>Item</th> <th>No.</th> <th>Item</th> </tr> </thead> <tbody> <tr> <td></td> <td>50 b/s</td> <td></td> <td>1000 b/s</td> </tr> <tr> <td></td> <td>75 b/s</td> <td></td> <td>1200 b/s</td> </tr> <tr> <td></td> <td>100 b/s</td> <td></td> <td>1600 b/s</td> </tr> <tr> <td></td> <td>110 b/s</td> <td></td> <td>1800 b/s</td> </tr> <tr> <td></td> <td>150 b/s</td> <td></td> <td>2000 b/s</td> </tr> <tr> <td></td> <td>200 b/s</td> <td></td> <td>2400 b/s</td> </tr> <tr> <td></td> <td>256 b/s</td> <td></td> <td>2560 b/s</td> </tr> <tr> <td></td> <td>300 b/s</td> <td></td> <td>3000 b/s</td> </tr> <tr> <td></td> <td>400 b/s</td> <td></td> <td>3600 b/s</td> </tr> <tr> <td></td> <td>500 b/s</td> <td></td> <td>4800 b/s</td> </tr> <tr> <td></td> <td>512 b/s</td> <td></td> <td>7200 b/s</td> </tr> <tr> <td></td> <td>600 b/s</td> <td></td> <td>9600 b/s</td> </tr> <tr> <td></td> <td>768 b/s</td> <td></td> <td>14400 b/s</td> </tr> <tr> <td></td> <td>800 b/s</td> <td></td> <td>19200 b/s</td> </tr> </tbody> </table>				No.	Item	No.	Item		50 b/s		1000 b/s		75 b/s		1200 b/s		100 b/s		1600 b/s		110 b/s		1800 b/s		150 b/s		2000 b/s		200 b/s		2400 b/s		256 b/s		2560 b/s		300 b/s		3000 b/s		400 b/s		3600 b/s		500 b/s		4800 b/s		512 b/s		7200 b/s		600 b/s		9600 b/s		768 b/s		14400 b/s		800 b/s		19200 b/s
No.	Item	No.	Item																																																												
	50 b/s		1000 b/s																																																												
	75 b/s		1200 b/s																																																												
	100 b/s		1600 b/s																																																												
	110 b/s		1800 b/s																																																												
	150 b/s		2000 b/s																																																												
	200 b/s		2400 b/s																																																												
	256 b/s		2560 b/s																																																												
	300 b/s		3000 b/s																																																												
	400 b/s		3600 b/s																																																												
	500 b/s		4800 b/s																																																												
	512 b/s		7200 b/s																																																												
	600 b/s		9600 b/s																																																												
	768 b/s		14400 b/s																																																												
	800 b/s		19200 b/s																																																												

RDL	INTERFACE screen												
Sets the receive data length													
Format	RDL n	Parameter range	5 to 8										
<p>< Details ></p> <p>Sets the length of the receive data byte.</p> <table border="1"> <thead> <tr> <th>n</th> <th>Length of receive data byte</th> </tr> </thead> <tbody> <tr> <td>5</td> <td>5BIT</td> </tr> <tr> <td>6</td> <td>6BIT</td> </tr> <tr> <td>7</td> <td>7BIT</td> </tr> <tr> <td>8</td> <td>8BIT</td> </tr> </tbody> </table> <p>Note: This can only be used to set the length of the receive data byte only when the ST/SP mode is used.</p>				n	Length of receive data byte	5	5BIT	6	6BIT	7	7BIT	8	8BIT
n	Length of receive data byte												
5	5BIT												
6	6BIT												
7	7BIT												
8	8BIT												

RPR	INTERFACE screen									
Sets the parity of the receive data slave signal										
Format	RPR n	Parameter range 0 to 2								
<p>< Details ></p> <p>Sets the parity of the receive data slave signal.</p> <table border="1"> <thead> <tr> <th>n</th> <th>Parity</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>NON</td> </tr> <tr> <td>1</td> <td>ODD</td> </tr> <tr> <td>2</td> <td>EVEN</td> </tr> </tbody> </table> <p><i>Note:</i> This can only be used to set the parity of the receive signal when ST/SP mode is used.</p>			n	Parity	0	NON	1	ODD	2	EVEN
n	Parity									
0	NON									
1	ODD									
2	EVEN									

MSL	INTERFACE screen													
Selects the line to be monitored														
Format	MSL n	Parameter range 0 to 4												
<p>< Details ></p> <p>Displays the status of the signal lines.</p> <table border="1"> <thead> <tr> <th>n</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Send signal status</td> </tr> <tr> <td>1</td> <td>Receive signal status</td> </tr> <tr> <td>2</td> <td>Receive data status</td> </tr> <tr> <td>3</td> <td>Send alarm status</td> </tr> <tr> <td>4</td> <td>Receive alarm status</td> </tr> </tbody> </table>			n	Status	0	Send signal status	1	Receive signal status	2	Receive data status	3	Send alarm status	4	Receive alarm status
n	Status													
0	Send signal status													
1	Receive signal status													
2	Receive data status													
3	Send alarm status													
4	Receive alarm status													

SCT	INTERFACE screen														
Sets the signal line to be monitored															
Format	SCT n, m	Parameter range	n: 5, 7, 12 m: 0, 1, 2												
< Details >															
Switches the status of the control signal while monitoring is in progress.															
n : Signal line No.															
m : 0 OFF, 1 ON, 2 OPEN															
※ The contents of the signal line are shown below:															
<table border="1"> <tr> <td style="text-align: center;">Parameter</td> <td style="text-align: center;">5</td> <td style="text-align: center;">7</td> <td style="text-align: center;">12</td> </tr> <tr> <td style="text-align: center;">Contents</td> <td style="text-align: center;">ER</td> <td style="text-align: center;">RS</td> <td style="text-align: center;">NS</td> </tr> <tr> <td style="text-align: center;">V.24/V.28</td> <td style="text-align: center;">ER</td> <td style="text-align: center;">RS</td> <td style="text-align: center;">NS</td> </tr> </table>				Parameter	5	7	12	Contents	ER	RS	NS	V.24/V.28	ER	RS	NS
Parameter	5	7	12												
Contents	ER	RS	NS												
V.24/V.28	ER	RS	NS												
Note: When the send interface condition is THROUGH, m: 2 (THROUGH) can be set for SA and XA only.															

SCS	INTERFACE screen														
Sets the send signal line															
Format	SCS n, m	Parameter range	n: 5, 7, 12 m: 0, 1, 2												
< Details >															
Switches the status of the send control signal.															
n : Signal line No.															
m : 0 OFF, 1 ON, 2 OPEN															
※ The allowable values for the signal line are shown below:															
<table border="1"> <tr> <td style="text-align: center;">Parameter</td> <td style="text-align: center;">5</td> <td style="text-align: center;">7</td> <td style="text-align: center;">12</td> </tr> <tr> <td style="text-align: center;">Contents</td> <td style="text-align: center;">ER</td> <td style="text-align: center;">RS</td> <td style="text-align: center;">NS</td> </tr> <tr> <td style="text-align: center;">V.24/V.28</td> <td style="text-align: center;">ER</td> <td style="text-align: center;">RS</td> <td style="text-align: center;">NS</td> </tr> </table>				Parameter	5	7	12	Contents	ER	RS	NS	V.24/V.28	ER	RS	NS
Parameter	5	7	12												
Contents	ER	RS	NS												
V.24/V.28	ER	RS	NS												

SCR	INTERFACE screen										
Sets the receive signal line											
Format	SCR n, m	Parameter range	n: 5, 7, 12 m: 0, 1, 2								
<p data-bbox="267 403 430 436">< Details ></p> <p data-bbox="292 451 824 485">Switches the status of the receive control signal.</p> <p data-bbox="292 495 537 529">n : Signal line No.</p> <p data-bbox="292 539 617 573">m : 0 OFF, 1 ON, 2 OPEN</p> <p data-bbox="292 583 963 617">※ The allowable values of the signal line are shown below:</p> <table border="1" data-bbox="292 640 738 814"> <tr> <td data-bbox="292 640 560 751">Parameter Contents</td> <td data-bbox="560 640 620 751">5</td> <td data-bbox="620 640 680 751">7</td> <td data-bbox="680 640 738 751">12</td> </tr> <tr> <td data-bbox="292 751 560 814">V.24 / V.28</td> <td data-bbox="560 751 620 814">ER</td> <td data-bbox="620 751 680 814">RS</td> <td data-bbox="680 751 738 814">NS</td> </tr> </table>				Parameter Contents	5	7	12	V.24 / V.28	ER	RS	NS
Parameter Contents	5	7	12								
V.24 / V.28	ER	RS	NS								

DSA	ERROR screen	
------------	---------------------	--

Selects measured result to be displayed in the top-left corner

Format	DSA n	Parameter range	0 to 11, 15 to 24
--------	-------	-----------------	-------------------

<Details>

Specifies the area in which ERROR-screen results are displayed.

n : Specifies item for each display field

Command	DSA	DSB	DSC	DSD	DSE
Display position	Top left side	Top right side	Middle left side	Middle right side	Bottom left side

: Displayed contents

	0	1	2	3	4	5	6
Display contents	ERROR COUNT	ERROR RATIO	BLK-ERR COUNT	BLK-ERR RATIO	ES	%ES	DM

	7	8	9	10	11	12	13
Display contents	% DM	SES	% SES	US	% US		

	14	15	16	17	18	19	20
Display contents		EFS	% EFS	CLOCK SLIP	PSC COUNT	PWL (sec)	PSL (sec)

	21	22	23	24	25	26	27
Display contents							

	28	29	30	31	32	33	34
Display contents							

DSB	ERROR screen	
------------	---------------------	--

Selects result to be displayed on top right side

Format	DSB n	Parameter range	0 to 11, 15 to 20
--------	-------	-----------------	-------------------

<Details>

Specifies the results to be displayed on the ERROR-screen.

n : Specifies the item to be displayed in each field.

Command	DSA	DSB	DSC	DSD	DSE
Display position	Top left side	Top right side	Middle left side	Middle right side	Bottom left side

: Display contents

	0	1	2	3	4	5	6
Display contents	ERROR COUNT	ERROR RATIO	BLK-ERR COUNT	BLK-ERR RATIO	ES	%ES	DM

	7	8	9	10	11	12	13
Display contents	% DM	SES	% SES	US	% US		

	14	15	16	17	18	19	20
Display contents		EFS	% EFS	CLOCK SLIP	PSC COUNT	PWL (sec)	PSL (sec)

	21	22	23	24	25	26	27
Display contents							

	28	29	30	31	32	33	34
Display contents							

DSC**ERROR screen**

Selects measured result to be displayed at middle left side

Format	DSC n	Parameter range	0 to 11, 15 to 20
--------	-------	-----------------	-------------------

<Details>

Specifies the results to be displayed on the ERROR-screen.

n : Specifies item to be displayed in each field.

Command	DSA	DSB	DSC	DSD	DSE
Display position	Top left side	Top right side	Middle left side	Middle right side	Bottom left side

: Display contents

	0	1	2	3	4	5	6
Display contents	ERROR COUNT	ERROR RATIO	BLK-ERR COUNT	BLK-ERR RATIO	ES	%ES	DM

	7	8	9	10	11	12	13
Display contents	% DM	SES	% SES	US	% US		

	14	15	16	17	18	19	20
Display contents		EFS	% EFS	CLOCK SLIP	PSC COUNT	PWL (sec)	PSL (sec)

	21	22	23	24	25	26	27
Display contents							

	28	29	30	31	32	33	34
Display contents							

DSD	ERROR screen	
------------	---------------------	--

Selects the measured result to be displayed at the middle right

Format	DSD n	Parameter range	0 to 11, 15 to 20
--------	-------	-----------------	-------------------

<Details>

Specifies the results to be displayed on the ERROR screen.

n : Specifies items to be displayed in each field.

Command	DSA	DSB	DSC	DSD	DSE
Display position	Top left side	Top right side	Middle left side	Middle right side	Bottom left side

: Display contents

	0	1	2	3	4	5	6
Display contents	ERROR COUNT	ERROR RATIO	BLK-ERR COUNT	BLK-ERR RATIO	ES	%ES	DM

	7	8	9	10	11	12	13
Display contents	% DM	SES	% SES	US	% US		

	14	15	16	17	18	19	20
Display contents		EFS	% EFS	CLOCK SLIP	PSC COUNT	PWL (sec)	PSL (sec)

	21	22	23	24	25	26	27
Display contents							

	28	29	30	31	32	33	34
Display contents							

DSE	ERROR screen	
------------	---------------------	--

Selects measured result to be displayed at bottom-left.

Format	DSE n	Parameter range	0 to 11, 15 to 20
--------	-------	-----------------	-------------------

<Details>

Specifies the results to be displayed on the ERROR screen.

n : Specifies the item to be displayed in each display field.

Command	DSA	DSB	DSC	DSD	DSE
Display position	Top left side	Top right side	Middle left side	Middle right side	Bottom left side

: Display contents

	0	1	2	3	4	5	6
Display contents	ERROR COUNT	ERROR RATIO	BLK-ERR COUNT	BLK-ERR RATIO	ES	%ES	DM

	7	8	9	10	11	12	13
Display contents	% DM	SES	% SES	US	% US		

	14	15	16	17	18	19	20
Display contents		EFS	% EFS	CLOCK SLIP	PSC COUNT	PWL (sec)	PSL (sec)

	21	22	23	24	25	26	27
Display contents							

	28	29	30	31	32	33	34
Display contents							

OFA	ERROR screen							
Specifies alarm output data format								
Format	OFA n, n, n.. (Total 19)	Parameter range 0, 1						
<p>< Details ></p> <p>Specifies the format of the alarm output data (output data, data sequence).</p> <ul style="list-style-type: none"> • Up to 14 parameters can be specified. • The data items and sequence output in response to the DOA? and DRA? commands are formatted in accordance with this command, • n : Output contents <table border="1"> <tr> <td>n</td> <td>0</td> <td>1</td> </tr> <tr> <td>Alarm</td> <td>PWL</td> <td>PSL</td> </tr> </table>			n	0	1	Alarm	PWL	PSL
n	0	1						
Alarm	PWL	PSL						

VM	VOLT/FREQUENCY screen																													
Selects the line whose voltage is to be measured																														
Format	VM n	Parameter range 0 to 12																												
<p>< Details ></p> <p>Selects the line whose voltage is to be measured.</p> <p>n : Line to be measured</p> <table border="1"> <tr> <td>n</td> <td>0</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> <td>9</td> <td>10</td> <td>11</td> <td>12</td> </tr> <tr> <td>Signal</td> <td>SD</td> <td>RD</td> <td>ST1</td> <td>ST2</td> <td>RT</td> <td>ER</td> <td>DR</td> <td>RS</td> <td>CS</td> <td>CD</td> <td>CI</td> <td>TI</td> <td>NS</td> </tr> </table>			n	0	1	2	3	4	5	6	7	8	9	10	11	12	Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
n	0	1	2	3	4	5	6	7	8	9	10	11	12																	
Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS																	

FM	VOLT/FREQUENCY screen																													
Selects the line for frequency measurement																														
Format	FM n	Parameter range 0 to 12																												
<p>< Details ></p> <p>Selects the line whose frequency is to be measured.</p> <p>n : Line to be measured</p> <table border="1"> <tr> <td>n</td> <td>0</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> <td>9</td> <td>10</td> <td>11</td> <td>12</td> </tr> <tr> <td>Signal</td> <td>SD</td> <td>RD</td> <td>ST1</td> <td>ST2</td> <td>RT</td> <td>ER</td> <td>DR</td> <td>RS</td> <td>CS</td> <td>CD</td> <td>CI</td> <td>TI</td> <td>NS</td> </tr> </table>			n	0	1	2	3	4	5	6	7	8	9	10	11	12	Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
n	0	1	2	3	4	5	6	7	8	9	10	11	12																	
Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS																	

SAL	DELAY TIME screen																													
Sets start signal line and trigger condition																														
Format	SAL n, m	Parameter range n: 0 to 12, 13 m: 0, 1																												
<p>< Details ></p> <p>Sets the start signal line and trigger condition.</p> <p>The START LINE and trigger condition can only be set when the measurement mode is LINE INTERVAL.</p> <p>n : Signal line No.</p> <p>m : 0= 1→0, ON→OFF, H→L 1= 0→1, OFF→ON, L→H</p> <table border="1"> <tr> <td>n</td> <td>0</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> <td>9</td> <td>10</td> <td>11</td> <td>12</td> </tr> <tr> <td>Signal</td> <td>SD</td> <td>RD</td> <td>ST1</td> <td>ST2</td> <td>RT</td> <td>ER</td> <td>DR</td> <td>RS</td> <td>CS</td> <td>CD</td> <td>CI</td> <td>TI</td> <td>NS</td> </tr> </table>			n	0	1	2	3	4	5	6	7	8	9	10	11	12	Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
n	0	1	2	3	4	5	6	7	8	9	10	11	12																	
Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS																	

SOL	DELAY TIME screen																													
Sets the stop signal line and trigger condition																														
Format	SOL n, m	Parameter range n: 0 to 12, 13 m: 0, 1																												
<p>< Details ></p> <p>Sets the STOP LINE and trigger condition.</p> <p>The STOP LINE and trigger condition can only be set when the measurement mode is LINE INTERVAL.</p> <p>n : Signal line No.</p> <p>m : 0= 1→0, ON→OFF, H→L 1= 0→1, OFF→ON, L→H</p> <table border="1"> <tr> <td>n</td><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td> </tr> <tr> <td>Signal</td><td>SD</td><td>RD</td><td>ST1</td><td>ST2</td><td>RT</td><td>ER</td><td>DR</td><td>RS</td><td>CS</td><td>CD</td><td>CI</td><td>TI</td><td>NS</td> </tr> </table>			n	0	1	2	3	4	5	6	7	8	9	10	11	12	Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
n	0	1	2	3	4	5	6	7	8	9	10	11	12																	
Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS																	

SL	WORD TRACE screen																													
Sets the trace-stop-condition signal line																														
Format	SL n, m	Parameter range n: 0 to 12 m: 0, 1																												
<p>< Details ></p> <p>Sets the trace-stop-trigger signal line and trigger condition simultaneously.</p> <p>n : Signal line No.</p> <p>m : 0= 1→0, ON→OFF 1= 0→1, OFF→ON</p> <table border="1"> <tr> <td>n</td><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td> </tr> <tr> <td>Signal</td><td>SD</td><td>RD</td><td>ST1</td><td>ST2</td><td>RT</td><td>ER</td><td>DR</td><td>RS</td><td>CS</td><td>CD</td><td>CI</td><td>TI</td><td>NS</td> </tr> </table> <p>Note: When the signal line is SD or RD, m is 0/1. Otherwise, it is OFF/ON.</p>			n	0	1	2	3	4	5	6	7	8	9	10	11	12	Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS
n	0	1	2	3	4	5	6	7	8	9	10	11	12																	
Signal	SD	RD	ST1	ST2	RT	ER	DR	RS	CS	CD	CI	TI	NS																	

**APPENDIX C
RESPONSE DATA REFERENCE
V.24/V.28 INTERFACE UNIT**

No.	Output	Column	Number of columns	Range	Remarks
24	Receive interface	129 to 131	3	V.24/V.28 : $\Delta\Delta 1$ SELF LOOP : 255	
25	Receive timing	133	1	ST:0 RT:3 RT(INV):4 ASYNC:5 ST/SP:6	
26	Receive bit rate	135 to 139	5	50 b/s : $\Delta\Delta\Delta 50$ 19200 b/s : 19200	Invalid : 9
27	Length of receive data byte	141	1	5 bit:5 6 bit:6 7 bit:7 8 bit:8	Invalid : 9
28	Receive parity	143	1	NON:0 ODD:1 EVEN:2	Invalid : 9
29	Remaining of 100 bytes of free memory space remaining	145 to 223	78	8 bytes of free memory space remaining	



Head office address was changed

Head office address on the back cover was changed. Please substitute it as the following address.

Anritsu Corporation

1800 Onna, Atsugi-shi, Kanagawa, 243-8555, Japan

TEL: +81-46-223-1111

22 September 2003



Anritsu Service and Sales offices

America

<http://www.us.anritsu.com/>

• Argentina

MULTIRADIO S.A.

Av. Cordoba, 4860 Buenos Aires,
C1414BAT, Argentina
TEL: +55-4779-5522
FAX: +55-4779-5510

• Brazil

ANRITSU ELETRÔNICA LTDA.

Praca Amadeu Amaral, 27-1 andar
01327-010-Paraiso, Sao Paulo, Brazil
TEL: +55-11-3283-2511
FAX: +55-11-2886940

ANRITSU ELETRÔNICA LTDA.

Praia de Botafogo, 440-24 andar-Botafogo
22250-040, Rio de Janeiro, RJ, Brazil
TEL: +55-21-2527-6922
FAX: +55-11-2537-1456

• Canada

ANRITSU ELECTRONICS LTD.

(HEADQUARTERS IN OTTAWA OFFICE)

700 Silver Seven Road, Suite 120, Kanata,
Ontario K2V 1C3, Canada
Toll free: 1-800-ANRITSU (267-4878)
TEL: +1-613-591-2003
FAX: +1-613-591-1006

ANRITSU ELECTRONICS LTD.

(VANCOUVER OFFICE)

300-1055 W Hastings St., Vancouver, BC
V6E 2E9, Canada
Toll free: +1-877-267-4878
TEL: +1-604-682-5933
FAX: +1-604-682-5934

ANRITSU ELECTRONICS LTD.

(TORONTO OFFICE)

2810 Matheson Blvd. E, 2nd Fl.,
Mississauga, ON L4W 4X7, Canada
Toll free: +1-877-267-4878
TEL: +1-905-890-7799
FAX: +1-905-625-5864

• Chile

SISTEMAS DE INSTRUMENTACION LTDA.

Concha y Toro 65, Stgo Centro
Santiago, Chile 51880
TEL: +56-2-6960031
FAX: +56-2-6969665

• Colombia

RENTAMETRIC LTDA.

Calle 24 No. 32-67, Apartado: 23030
Santafe de Bogota, D.C. Colombia
TEL: +57-1-269-6555
FAX: +57-1-269-0191

• Costa Rica

SONIVISION, S.A.

P.O. Box 620-1000, San Jose, Costa Rica
TEL: +506-231-5685
FAX: +506-231-6531

• Ecuador

EQUITRONICS S.A.

Belgica N-32 Hy Av. De Los Shyris,
Edificio IVSEMON PARK, Suite 4B, Quito,
Ecuador
TEL: +593-2-255-396
FAX: +593-2-255-396

• El Salvador

EMPRESA DE COMERCIO EXTERIOR S.A. DE C.V.

Centro Comercial Feria Rosa, Alameda
Dr. Manuel Enrique Araujo, Edificio H,
Local 315 San Salvador, El Salvador
TEL: +503-243-3924
FAX: +503-243-3925

• Guatemala

IMPELSA.

4a Calle 1-15 Zong 10 Guatemala, C.A.
01010, Guatemala
TEL: +502-360-5135
FAX: +502-360-5217

• Mexico

SIHIKATRONICS mmWAVE S.A. DE C.V.

Luz Saviñon 9-701, Col. Del Valle, C.P.
03100, Mexico, D.F., Mexico
TEL: +52-5-5437313
FAX: +52-5-5437317

• Paraguay

DATALAB S.R.L.

Avda. Artigas No 1645 Edificio "DataLab"
Asuncion, Paraguay
TEL: +595-21-20-9126
FAX: +595-21-20-9127

• Peru

ELETELSE S.A.

AV Canaval Moreyra 748, San Isidro,
Lima 27, Peru
TEL: +51-1-224-2514
FAX: +51-1-224-8148

• U.S.A.

ANRITSU COMPANY

1155 East Collins Blvd., Richardson, TX
75081, U.S.A.
Toll Free: +1-800-ANRITSU (267-4878)
TEL: +1-972-644-1777
FAX: +1-972-644-3416

ANRITSU COMPANY

490 Jarvis Drive, Morgan Hill, CA 95037,
U.S.A.
Toll Free: +1-800-ANRITSU (267-4878)
TEL: +1-408-778-2000
FAX: +1-408-778-3180

ANRITSU COMPANY

10 New Maple Ave., Unit 305,

P.O. Box 836, Pine Brook, NJ 07058-0836
U.S.A.

Toll Free: +1-800-ANRITSU (267-4878)
TEL: +1-973-227-8999
FAX: +1-973-575-0092

ANRITSU COMPANY

SALES AND SERVICE, FL OFFICE

312 W. First Street, Suite 300, Sanford,
FL 32771, U.S.A.
Toll Free: 1-800-ANRITSU (267-4878)
TEL: +1-407-321-5130
FAX: +1-407-330-2018

ANRITSU COMPANY

SALES AND SERVICE, GA OFFICE

4625 Alexander Drive, Alpharetta,
GA 30022, U.S.A.
Toll Free: 1-800-ANRITSU (267-4878)
TEL: +1-678-566-0454
FAX: +1-678-566-1776

• Uruguay

CABONORTE S.A.

Colonia 1900, Esc. 603, Montevideo,
Uruguay
TEL: +598-2-430522
FAX: +598-2-418594

• Venezuela

RADI COMUNICACIONES CRUZ, C.A.

Calle La Colina Quinta. Elison, Frente al
teatro Alberto Mateo Caracas 1050,
Venezuela
TEL: +58-2-793-2322
FAX: +58-2-793-3429

Europe

<http://www.eu.anritsu.com/>

• Austria

WIEN-SCHALL GmbH

Krichbaumgasse 25, A-1120 Vienna,
Austria
TEL: +43-1-81155140
FAX: +43-1-81155180

• Belgium

ANRITSU GmbH

Grafenberger Allee 54-56, 40237
Düsseldorf, Germany
Local phone: 0800-90001 (toll free)
TEL: +49-211-96855-0
FAX: +49-211-96855-55

• Bulgaria

ELSINCO Representation OFFICE Sofia

h.e. Strelbishte, str. Kotlenski Prohod,
bl. 96/6/14, BG-1408 Sofia, Bulgaria
TEL: +359-2-958-1245
FAX: +359-2-958-1698

• **Croatia**

**ELSINCO REPRESENTATION OFFICE
ZAGREB**
Savska 66 HR-10000 Zagreb, Croatia
TEL: +385-1-6312-477
FAX: +385-1-6312-488

• **Czech Republic**

ELSINCO PRAHA SPOL S.R.O.
Novodvorská 994, CZ-142 21 Praha,
4-Braník, Czech Republic
TEL: +420-2-4149-0147
FAX: +420-2-4447-2169

**ELSINCO PRAHA SPOL S.R.O.
(BRNO BRANCH OFFICE)**

Strmá 19, CZ-616 00 Brno, Czech
Republic
TEL: +420-5-4142-7211
FAX: +420-5-4142-7219

• **Denmark**

INSTRUMENTS A/S
Lokesalle 30, DK-8700 Horsens, Denmark
TEL: + 45 75646500
FAX: + 45 75643700

• **Finland**

**ANRITSU AB
(FINLAND BRANCH OFFICE)**
Piispanportti 9, FIN-02240 Espoo, Finland
TEL: +358-9-435-522-0
FAX: +358-9-435-522-50

• **France**

ANRITSU S.A.
9 Avenue du Québec, ZA Courtabœuf 1
91951 LES ULLIS CEDEX, France
TEL: +33 1 60 92 15 50
FAX: +33 1 64 46 10 65

**ANRITSU S.A.
(TOULOUSE OFFICE)**

Bureau de Toulouse Région Centre Sud
Ouest, France
TEL: +33-5-62070484
FAX: +33-5-62070668

**ANRITSU S.A.
(TOULON OFFICE)**

Bureau de Toulon Région Centre Sud Est,
France
TEL: +33-4-94040264
FAX: +33-4-94040265

**ANRITSU S.A.
(RENNES OFFICE)**

Bureau de Rennes Région Ouest, France
TEL: +33-2-99521214
FAX: +33-2-99521224

• **Germany**

ANRITSU GmbH
Grafenberger Allee 54-56, 40237
Düsseldorf, Germany
TEL: +49-211-96855-0
FAX: +49-211-96855-55

• **Greece**

KOSTAS KARAYANNIS SA
58 Kapodistriou str, GR-142 35 Nea Ionia,
Athens, Greece
TEL: +30-1-680-0460-4
FAX: +30-1-685-3522

• **Hungary**

ELSINCO BUDAPEST KFT
Pannónia utca 8. IV/l., H-1136 Budapest,
Hungary
TEL: +36-1-339-0000
FAX: +36-1-339-4444

• **Ireland**

PEMA LTD.
Dromiskin, Dundalk, Co. Louth, Ireland
TEL: +353-42-72899
FAX: +353-42-72376

• **Italy**

ANRITSU S.P.A.
Via Elio Vittorini 129, 00144 Roma, Italy
TEL: +39-06-509-9711
FAX: +39-06-502-2425

ANRITSU S.P.A.

Via Paracelso 4, CD Colleoni, Agrate
Brianza, 20041 Milano, Italy
TEL: +39-039-657021
FAX: +39-039-6056396

• **Norway**

BLOMKVIST AS
Pb 188, 1371 ASKER, Norway
TEL: + 47 66901190
FAX: + 47 66901212

• **Poland**

ELSINCO POLSKA SP. Z.O.O
ul Gdanska 50, 01-691 Warszawa, Poland
TEL: +48-22-39-832-4042 (Sat Link)
FAX: +48-22-832-2238

• **Portugal**

OMNITECNICA S.A.
Estrada de Alfragide 23, 2720-015
Amadora, Portugal
TEL: +351-21-472-12-00
FAX: +351-21-472-12-70 (Sales)

• **Slovakia**

ELSINCO SLOVENSKO S.R.O
Kudláková 4, SK-844 15 Bratislava,
Slovakia
TEL: +421 7 6428 41 65
FAX: +421 7 6428 44 54

**ELSINCO SLOVENSKO S.R.O
(KOŠICE BRANCH OFFICE)**

Floriánska 16, SK-043 13 Kosice, Slovakia
TEL: +421 95 62 26 729
FAX: +421 95 62 26 729
CONTACT: Mr. Igor Domorak,
Branch Office Manager

• **Slovenia**

ELSINCO D.O.O.
Dalmatinova 2, SI-1000 Ljubljana,
Slovenia
TEL: +386-61-133-62-77
FAX: +386-61-317-397

• **Sweden**

ANRITSU AB
Botvid Center, Fittja Backe 1-3 S-145
84, Stockholm, Sweden
TEL: +46-8-534-70700
FAX: +46-8-534-70730

• **United Kingdom**

ANRITSU LTD.
200 Capability Green, Luton, Bedfordshire,
LU1 3LU, U.K.
TEL: (Sales) + 44 1582-433280
(Service) +44 1582-433285
FAX: +44 1582-731303

**Asia, Pacific
and Africa**

<http://www.anritsu.com.hk/>

• **Australia**

ANRITSU PTY LTD.
Unit 3/170 Forster Road, Mount. Waverley,
Vic., 3149, Australia
TEL: +61-3-9558-8177
FAX: +61-3-9558-8255

• **Bahrain**

BASMATECH
P. O. Box 5701, Manama, Bahrain
TEL: +973-273729
FAX: +973-725404

• **China**

ANRITSU COMPANY LTD.
Suite 923, 9/F., Chinachem Golden Plaza
77 Mody Road, Tsimshatsui East,
Kowloon, Hong Kong
TEL: +852-2301-4980
FAX: +852-2301-3545

**ANRITSU COMPANY LTD.
(BEIJING REPRESENTATIVE OFFICE)**

Room 1515, Beijing Fortune Building
No. 5 North Road, the East 3rd Ring Road,
Chao-Yang District, Beijing 100004
P.R. China
TEL: +86-10-6590-9230
FAX: +86-10-6590-9235

**ANRITSU COMPANY LTD.
(SHANGHAI OFFICE)**

Room 1807-1810, Tower A CITY CENTER
of Shanghai
No. 100 ZunYi Road 200051 P.R.China
TEL: +86-021-6237-0898
FAX: +86-021-6237-0899

**ANRITSU COMPANY LTD.
(GUANGZHOU REPRESENTATIVE
OFFICE)**

Room 3008-9, Dongshan Plaza, 69 Xian
Lie Zong Road Central, Guangzhou
510095, P.R. China
TEL: +86-20-8732 2231/2
FAX: +86-20-8732 2230

**ANRITSU COMPANY LTD.
(CHENGDU REPRESENTATIVE OFFICE)**

26E New Times Square, No. 42, Wenwu
Road, Xinhua Street, Chengdu 610017
P.R. China
TEL: +86-28-8651 0011/22/33
FAX: +86-28-8651 0055

**ANRITSU COMPANY LTD.
(XI'AN REPRESENTATIVE OFFICE)**

No.1102, ZhiCheng Building, No.2
Gao Xin I Road, High-Tech, Development
Zone, Xi'an 710075, P.R. China
TEL: +86-29-8377 406/9
FAX: +86-29-8377 410

**ANRITSU COMPANY LTD.
(SHENZHEN REPRESENTATIVE
OFFICE)**

Room 1505, Building A
World Trade Plaza, Fuhong Road
Shenzhen 518033, P.R. China
TEL: +86-755-8366 2847/2851/2852
FAX: +86-755-8366 2849

**ANRITSU COMPANY LTD.
(CHONG QING REPRESENTATIVE
OFFICE)**

Rm.6-2, D Building, Kejjfazan Plaza
No.210, Keyuan 1st Road, Gaoxin District
Shiqiaopu, Chongqing 400010
P.R. China
TEL: +86-23-8909-9918
FAX: +86-23-8909-9928

**ANRITSU ELECTRONICS (SHANGHAI)
CO., LTD. (SERVICE CENTER)**
2F, Room B, 52 Section Factory Building
No. 516 Fu Te North Road
Waigaoqiao Free Trade Zone
Pudong, Shanghai 200131, P.R. China
TEL: +86-21-5868-0226/7/8
FAX: +86-21-5868-0588

**ANRITSU COMPANY LTD.
(SHENYANG REPRESENTATIVE
OFFICE)**

2-185, City Plaza, No. 206, Nanjing North
Street, He Ping District, Shenyang 110001
P.R. China
TEL: +86-24-2334 1178/89
FAX: +86-24-2334 2838

**ANRITSU COMPANY LTD.
(WUHAN REPRESENTATIVE OFFICE)**

A1803, ZhongShang Plaza
No. 7, Zhongnan Road
Wuchang, Wuhan 430071, P.R. China
TEL: +86-27-8771 3355
FAX: +86-27-8732 2773

• **Cyprus**

CHRIS RADIOVISION LTD.
23 Crete Street, T.T. 1061
P. O. Box 21989, 1515Nicosia, Cyprus
TEL: +357-2-766121
FAX: +357-2-765177

• **Egypt**

GIZA SYSTEMS ENGINEERING S.A.E
17 Teeba Street Mohandeseen P.O. Box
317 Dokki-Cairo 12311, Egypt
TEL: +20-2-3368095
FAX: +20-2-3385799

• **Indonesia**

PT. SUBUR SAKTI PUTERA
Graha Astri Aniela Angun, Jl. Tanah
Abang III/15, Jakarta 10160, Indonesia
TEL: +62-21-352-4828
FAX: +62-21-352-4831

• **Israel**

TECH-CENT LTD.
P. O. Box 43259 (Mailing Address),
Tel-Aviv 61430 Israel, Street Address:
Raul Valenberg 4 Ramat Haahayal, Tel-
Aviv 69710, Israel
TEL: +972-36-478563
FAX: +972-36-478334

• **Korea**

ANRITSU CORPORATION, LTD.
8F HyunJuk Building, 832-41
Yeoksam-Dong, Kangnam-Ku, Seoul 135-
080
Korea
TEL: +82-2-553-6603
FAX: +82-2-553-6604

ANRITSU CORPORATION, LTD.

Room 1503, Dong-A Venture Tower 538-8
BongMyung-Dong, Yusong-Gu
Daejeon, 305-301
Korea
TEL: +82-42- 828-7783
FAX: +82-2-42-828-7785

• **Kuwait**

TAREQ COMPANY
P.O. Box 20506 Safat, 13066 Safat,
Kuwait
TEL: +965-431-0615
FAX: +965-431-4085

• **Malaysia**

O'CONNOR'S ENGINEERING SDN BHD
3rd Floor Bangnan O'Connor, 13 Jalan
223, 46100 Petaling Jaya,
Selangor Darul Ehsan, Malaysia
TEL: +60-3-753-8400
FAX: +60-30-757-7871

• **Morocco**

SEDEL
24, 26, Bd, Resistance, Casablanca,
Morocco

TEL: +212-2-302444
FAX: +212-2-449311

• **Nepal**

BR INTERNATIONAL PVT. LTD.
P. O. Box 60, Tamrakar Comm. Bldg.,
Bhotabahal Kathmandu, Nepal
TEL: +977-1-224-706
FAX: +977-1-227-956

• **New Zealand**

**NILSEN TECHNOLOGIES
(AUCKLAND OFFICE)**
P. O. Box 9613, New market Unit 4,
Ambury Court, 1 Porters Ave, Eden
Terrace Auckland, New Zealand
TEL: +64-9-309-2464
FAX: +64-9-309-2968

**NILSEN TECHNOLOGIES
(WELLINGTON OFFICE)**

35 Ulric Street, Plimmerton Wellington,
New Zealand
TEL: +64-4-233-9116
FAX: +64-4-233-8366

• **Oman**

**NATIONAL PROJECTS AND
TECHNOLOGY COMPANY L.L.C**
P. O. Box 97, Wadi Al Kabir, Postal Code
117, Sultanate of Oman
TEL: +968-793741
FAX: +968-796158

• **Pakistan**

AETCO
Zia Chambers, 25-Mcleod road, Lahore
54000, Pakistan
TEL: +92-42-7221716, 7311035
FAX: +92-42-7221456

**SUPERIOR ELECTRONICS
ASSOCIATED**

B-98 Block H, North Nasimabad,
Karachi-33, Pakistan
TEL: +92-21-613655

• **Philippines**

**SALRITSU INTERNATIONAL TRADING
CORPORATION**
5QB ODC International Plaza
Condominium, 219 Salcedo St., Legaspi
Village, Makati City 1229, Philippines
TEL: +632-816-2646, 893-8998
FAX: +632-815-0986

• **Puerto Rico**

CARIBBEAN DATA SYSTEM
636, San Patricio Ave. San Juan,
PR00920-4507, Puerto Rico
TEL: +1-787-774-6969
FAX: +1-787-774-6973

• Qatar

QATAR COMMUNICATIONS LTD.
P. O. Box 2481, Doha Qatar
TEL: +974-4-424347
FAX: +974-4-324777

• Saudi Arabia

A. RAJAB & A. SILSILAH & CO.
P. O. Box 203, Jeddah 21411, Saudi Arabia
TEL: +966-2-6610006
FAX: +966-2-6610558

**ELECTRONIC EQUIPMENT
MARKETING CO.**

P. O. Box 3750, Riyadh, 11481,
Saudi Arabia
TEL: +966-3-887-0218
FAX: +966-3-887-0268

• Singapore

ANRITSU PTE. LTD.
10, Hoe Chiang Road #07-01/02, Keppel
Towers, Singapore 089315
TEL: +65-6282-2400
FAX: +65-6282-2533

• South Africa

ETECSA (PTY) LTD.
12 Surrey Square Office Park, 330 Surrey
Avenue, Ferndale, 2194 Randburg,
South Africa (P. O. Box 4231 Randburg,
2125 South Africa)
TEL: +27-11-787-7200
FAX: +27-11-787-0446

• Sri Lanka

INFOTECHS LIMITED
441, Alwitigala Mawatha, Colombo,
Sri Lanka
TEL: +94-1-598237
FAX: +94-1-598112

• Taiwan

ANRITSU COMPANY, INC.
(TAIPEI OFFICE)
7F, No. 316, Sec. 1, NeiHu Rd., Taipei,
Taiwan
Phone: +886-2-8751-1816
Fax: +886-2-8751-1817

ANRITSU COMPANY, INC.
(HSINCHU OFFICE)
11F-3, 270, Sec. 1, Kuang-Fu Rd.,
Hsinchu, Taiwan
TEL: +886-3-563-6601, 6602, 6603
FAX: +886-3-564-5819

• Thailand

**JASMINE TELECOM SYSTEMS CO.,
LTD.**
200 Moo 4, 9th Floor, Chaengwatana
Road, Tambon Pakkret, Amphoe Pakkret,
Nonthaburi 11120, Thailand
TEL: +66-2-502-3240, 3000
FAX: +66-2-962-2521

• Turkey

**INTER INTRADE BILGISAYAR
ELEKTRONIK SAN. TIC. A.S.**
Egitim Mah. Poyraz Sok., Sadikoglu Is
Merkezi 1, No: 11, Kadikoy Istanbul,
Turkey
TEL: +90-216-4144758
FAX: +90-216-4144762

TEST

Sehit Adem Yavuz Sokak No. 14/15
06640, Kizilay-Ankara, Turkey
TEL: +90-312-419-3688
FAX: +90-312-419-4099

• United Arab Emirates

**UTMOST ELECTRONICS TRADING
L.L.C.**
(ABU DHABI BRANCH)
P. O. Box: 41175, Abu Dhabi,
United Arab Emirates
TEL: +971-2-6458909
FAX: +971-2-6458907

• Vietnam

**SYSTEM & TECHNOLOGIES VIETNAM
LTD.**
Unit # B236, Binh Minh Hotel 27 Ly Thai
To Str Hanoi, Vietnam
TEL: +84-48.264.728
FAX: +84-49.344.111

• Zimbabwe

MARTWELL ELECTRONICS (PVT) LTD.
P.O. Box CH 857 Chisipite Harare,
Zimbabwe
TEL: +263-4-494928
FAX: +263-4-494927



• Japan

ANRITSU CORPORATION
1800 Onna, Atsugi-shi, Kanagawa,
243-8555, Japan
TEL: +81-46-223-1111
FAX: +81-46-296-1264