

4600 AC LOAD
TRANSIENT MODE
ADDENDUM



Part No. 09-0237

REVISION G

February 18, 1999

Document History

Rev G	14857	2/18/1999	CAR
-------	-------	-----------	-----

Proprietary Rights Notice

This document and the information that it contains are the property of NH Research, Incorporated. The rights to duplicate or otherwise copy this document, the rights to disclose the document and its information to others, and the right to use the information therein may be acquired only by written permission signed by a duly authorized officer of NH Research, Incorporated.

Unauthorized duplication of software and documentation provided with the test workstations violates the copyright protection provided by law. However, backup copies of programs are permitted for archives and recovery from hardware failures.

The material in this publication is current as of the release date on the cover page and is subject to change without notice. Any questions concerning the product or any questions or comments concerning this manual should be directed to the NH Research Field Service Department during normal business hours Monday through Friday at (949) 474-3900 or FAX (946) 474-7062 or www.nhresearch.com.

POWERTEST and POWERFLEX are trademarks of NH Research, Incorporated.

TABLE OF CONTENTS

1.	INTRODUCTION	7
2.	DESCRIPTION	8
2.1	TRANSIENT OPERATION.....	8
2.2	TRANSIENT MODE SETTINGS	9
2.2.1	TRANSIENT MODE OFF	9
2.2.2	TRANSIENT MODE INITIATE	9
2.2.3	TRANSIENT MODE ARMED	9
2.2.4	TRANSIENT MODE CONTINUOUS	9
2.2.5	GENERATE EXT. TRIGGER.....	9
2.2.6	TRIG. BY EXT. TRIGGER.....	9
2.2.7	TRIG. BY VOLTAGE TRANSITION.....	9
2.2.8	TRIG. BY VOLTAGE PHASE.....	9
2.2.9	RESET TRANSIENT MODE	10
2.3	SET COMMANDS.....	10
2.4	COMMAND QUEUE	10
2.5	TRANSIENT MODE STATUS.....	10
2.5.1	TRANSIENT MODE REGISTER.....	10
2.5.2	LOAD TRIGGERED	10
2.5.3	CMD BUFFER FULL.....	10
2.5.4	TRIGGER THE PORT	10
2.5.5	READ REGISTER	10
2.6	ADVANCED SETTINGS	11
3.	EXAMPLE	12

1. INTRODUCTION

This document is an addendum to the 4600 AC load users manual. The user must understand basic operation of the AC load before attempting transient operation.

Transient operation is useful for fast or time critical changes in load operation.

With normal operation, commands are executed as soon as they are received. During transient operation commands are queued and not executed until triggered. This allows very fast changes (every cycle if needed) in current which can reveal precious information about the regulation, output voltage and current, peak capabilities etc. of the UUT in just one test. The commands can be executed as a single shot or as a loop.


2. DESCRIPTION

2.1 Transient Operation

Transient Operation button.



Transient Operation window.



2.2 Transient Mode Settings

2.2.1 Transient Mode Off

The AC Load will execute commands as soon as received. Any triggers are ignored. This is normal operation.

2.2.2 Transient Mode Initiate

This is the programming mode. In this mode “Set” commands will be queued and NOT executed. Commands are stored for execution later. After Initiate mode is set select the “Set” Commands, you wish to program.

2.2.3 Transient Mode Armed

The load is waiting for a trigger signal to execute the next command previously queued. When all queued commands have been executed, returns to Transient Mode Off. This is a one shot transient.

2.2.4 Transient Mode Continuous

This is the same as armed except when all queued commands have been executed commands restart at the beginning of queue. The transient starts over again and repeats indefinitely.

2.2.5 Generate Ext. Trigger

When this box is selected, the load will generate trigger outputs on the Trig Out port when it is triggered. This is a negative true, TTL level signal.

2.2.6 Trig. By Ext. Trigger

When this box is selected the load will accept a trigger input from the “Trigger the Port” button or the Trig In port. The Trig In port requires a negative true TTL level signal and must be 50uS minimum in length.

2.2.7 Trig. By Voltage Transition

When this box is selected, the load will generate a trigger input when:

- The input voltage starts below the Turn-Off Volts then rises and exceeds the Turn-On Volts.
- The input voltage starts above the Turn-On Volts then falls below the Turn-Off Volts.

2.2.8 Trig. By Voltage Phase

When this box is selected, the load will generate a trigger input at a programmed voltage phase angle.

2.2.9 Reset Transient Mode

Clears the command queue and allows a new transient to be programmed.

2.3 Set Commands

Here is where the user builds the sequence of commands he wishes to execute later in real time. Up to 100 commands may be queued.

Set the Current, Power, Resistance, Voltage, Crest Factor and/or Power Factor you wish the load to change to when a trigger is received. One or multiple commands may be executed with a single trigger. The Wait for Trigger command causes the load to wait for the next trigger before executing the next command or group of commands.

2.4 Command Queue

The commands, which have been queued, are displayed here.

2.5 Transient Mode Status

2.5.1 Transient Mode Register

The value of the Transient Mode Register is displayed here.

Bit	Name	Description
0 & 1	Mode	00 – No transient operation. 01 – Initiate. Set type commands will be queued, but the module output is not modified until it is armed and it receives a trigger signal. 10 – Armed. The module is waiting for a trigger signal to execute the next command(s) previously queued. When all queued commands have been executed, returns to no transient operation. 11 - Continuous. Same as armed except when all queued commands have been executed, restarts at beginning of queue.
2	Enable Output	The module will generate trigger outputs.
3	Trigger Output	0 - When enable output is 0. 1 - Latched with each trigger event, reset after read.
4	Trigger Input	Hardware trigger input enabled.
5	Voltage Input	Turn on/off voltage trigger enabled.
6	Phase Angle	Phase angle trigger enabled.
7	Queue Full	The transient command queue is full.

2.5.2 Load Triggered

This will light when the load is triggered.

2.5.3 Cmd Buffer Full

This is an error, which indicates more than 100 commands have been sent to the load.

2.5.4 Trigger the Port


Sends a trigger to the load. Ext. Trigger must be enabled.

2.5.5 Read Register


Reads the Transient Mode Register.

2.6 Advanced Settings

Advanced Settings Button.



Advanced settings window.



The Trig. By Voltage Transition may be programmed by the Turn-on and Turn-Off Voltages.

The Trig. By Voltage Phase may be programmed by selecting 0 to 359 Deg. and then enable the Trigger Synch.

3. EXAMPLE

The following is an example of turn on inrush current where the first cycle is 20A, the second cycle is 10A and the remaining cycles are 5A.

Click on the Advanced Settings Button. Set the Trigger Phase to 0 degrees and enable Trigger Synch. see section 2.6. This will cause the current to change at 0 degrees.

Click on the Transient Operation and set Transient Mode Initiate, see section 2.2.2.

Set load current to 20 Amps, see section 2.3. Observe "Set load current to 20 Amps" appear in the Command Queue window. See section 2.4.

Click on Wait for Trigger, observe "Wait for Trigger" appear in the Command Queue window.

Set load current to 10 Amps.

Click on Wait for Trigger.

Set load current to 5 Amps.

Click on Wait for Trigger.

Click on Wait for Trigger.

Click on Wait for Trigger.

Click on Trig. By Voltage Phase, see section 2.2.8.

Click on Transient Operation and set Transient Mode Continuous, see section 2.2.4.

With an oscilloscope and current probe, observe one cycle of current at 20A the next at 10A and several at 5A.

**4600 AC LOAD
USERS MANUAL**



Part No. 09-0237

REVISION G

February 18, 1999

Document History

Rev A	First printing	12/19/97	CAR
Rev B	Added calibration section	1/22/98	CAR
Rev C	Release ECO 14650	2/9/98	JW
Rev D	ECO 14684	4/16/98	CAR
Rev E	ECO 14756	6/26/98	CAR
Rev F	ECO 14803	10/8/98	VJB
Rev G	ECO 14857	021899	CAR

Proprietary Rights Notice

This document and the information that it contains are the property of NH Research, Incorporated. The rights to duplicate or otherwise copy this document, the rights to disclose the document and its information to others, and the right to use the information therein may be acquired only by written permission signed by a duly authorized officer of NH Research, Incorporated.

Unauthorized duplication of software and documentation provided with the test workstations violates the copyright protection provided by law. However, backup copies of programs are permitted for archives and recovery from hardware failures.

The material in this publication is current as of the release date on the cover page and is subject to change without notice. Any questions concerning the product or any questions or comments concerning this manual should be directed to the NH Research Field Service Department during normal business hours Monday through Friday at (949) 474-3900 or FAX (946) 474-7062 or www.nhresearch.com.

POWERTEST and **POWERFLEX** are trademarks of NH Research, Incorporated.

TABLE OF CONTENTS

1.	INTRODUCTION.....	9
1.1	BROAD OPERATING ENVELOPE	9
1.2	NON LINEAR LOADING.....	9
1.3	BROAD SPECTRUM OF EMULATION MODES.....	9
1.4	HIGH ACCURACY MEASUREMENTS.....	9
2.	SPECIFICATIONS.....	11
2.1	RATINGS.....	11
2.2	PROGRAMMABLE FEATURES	11
2.3	READBACK INSTRUMENTATION	12
2.4	PROTECTION.....	14
2.5	SUPPLEMENTAL CHARACTERISTICS	14
3.	INSTALLATION.....	15
3.1	HARDWARE INSTALLATION.....	15
3.1.1	FRONT VIEW.....	16
3.1.2	REAR VIEW	16
3.1.3	TOP VIEW.....	17
3.1.4	SIDE VIEW.....	17
3.1.5	CONNECTORS	18
3.1.5.1	CONTROL POWER INPUT	18
3.1.5.2	LOAD POWER INPUT	18
3.1.5.3	RS232 9PIN CONNECTOR	19
3.1.5.4	COMM IN/OUT.....	20
3.1.5.5	TRIG IN/OUT.....	21
3.1.5.6	HOLD IN/OUT	21
3.1.6	AIRFLOW	21
3.1.7	MASTER SLAVE INSTALLATION.....	21
3.1.7.1	LOAD POWER INPUT	22
3.1.7.2	COMPUTER CONNECTION.....	22
3.1.7.3	HOLD CONNECTION	22
3.2	SOFTWARE INSTALLATION	22
3.2.1	SOFTWARE INSTALLATION FROM CD ROM	22
3.2.2	SOFTWARE INSTALLATION FROM FLOPPIES	22
4.	USER OPERATION.....	23
4.1	HARDWARE OPERATION.....	23
4.1.1	CONTROL POWER SWITCH AND INDICATOR.....	23
4.1.2	LOAD POWER CIRCUIT BREAKER	23
4.1.3	S6R AD SWITCH	23
4.1.4	FAULT INDICATOR.....	23
4.1.5	STATUS INDICATOR	24
4.1.6	ERROR INDICATOR	24
4.1.7	TALK INDICATOR.....	24
4.1.8	LISTEN INDICATOR.....	24
4.2	SOFTWARE OPERATION.....	24
4.2.1	ACCESSING HELP.....	24
4.2.2	OFF.....	26
4.2.3	LOAD MODES	26
4.2.3.1	CONSTANT CURRENT.....	27
4.2.3.2	CONSTANT POWER	27
4.2.3.3	CONSTANT RESISTANCE	27

4.2.3.4	CONSTANT VOLTAGE.....	27
4.2.4	OTHER PROGRAMMABLE FEATURES.....	28
4.2.4.1	CREST FACTOR.....	28
4.2.4.2	POWER FACTOR.....	28
4.2.4.3	SHORT CIRCUIT.....	28
4.2.4.4	POWER FACTOR MODES.....	29
4.2.5	STATUS.....	29
4.2.6	DEVICE CAPABILITIES.....	30
4.2.7	ADVANCED SETTINGS.....	31
4.2.8	RESETTING.....	32
4.2.9	TRANSIENT.....	32
4.2.10	METERING.....	33
4.2.10.1	READ BACK CAPABILITIES.....	33
4.2.10.2	METERING MODES.....	33
4.2.10.3	WAVEFORM CAPTURE.....	34
5.	CALIBRATION.....	37
5.1	MAINTENANCE PANEL.....	37
5.2	EQUIPMENT REQUIRED.....	37
5.3	PROCEDURE.....	37
6.	THEORY OF OPERATION.....	39
6.1	ARCHITECTURE.....	39
6.2	MEMORY.....	40
6.2.1	MEMORY MAP.....	40
6.2.2	EPROM.....	41
6.2.3	ANALOG TO DIGITAL CONVERTERS.....	41
6.2.4	PERIPHERAL BUS.....	41
6.2.5	UART.....	41
6.2.6	DIGITAL INPUTS.....	41
6.2.7	DIGITAL OUTPUTS.....	41
6.2.8	FREQUENCY.....	41
6.2.9	REFERENCE DIGITAL TO ANALOG CONVERTER.....	41
6.2.10	INTERNAL RAM.....	41
6.2.11	SRAM.....	41
6.2.12	FLASH PROM.....	42
6.2.13	WAVEFORM DIGITAL TO ANALOG CONVERTER.....	42
6.3	RESET.....	42
6.4	INTERRUPTS.....	42
6.4.1	INT0.....	42
6.4.2	INT1.....	42
6.4.3	INT2.....	42
6.4.4	INT3.....	42
6.5	BLOCK DIAGRAM.....	43
6.6	SYNCHRONIZATION.....	43
6.7	FREQUENCY METERING.....	43
6.8	VOLTAGE METERING.....	43
6.9	CURRENT METERING.....	43
6.10	HARDWARE CR MODE.....	44
6.11	HARDWARE CC MODE.....	44
6.12	CREST FACTOR AND POWER FACTOR RELATIONSHIP.....	45
6.13	POWER SECTION.....	45
6.14	PROTECTION CIRCUITRY.....	46
6.14.1	CIRCUIT BREAKER.....	46
6.14.2	OVERVOLTAGE.....	46
6.14.3	OVERTEMPERATURE.....	46
6.14.4	OVERPOWER.....	46

6.14.5	NO SHARE	46
6.14.6	SECOND BREAK LIMIT	46
7.	MESSAGE FORMATS	47
7.1	COMMAND MESSAGE	47
7.1.1	COMMAND TYPES	48
7.2	RESPONSE MESSAGE	48
7.2.1	STATUS RESPONSE MESSAGE	48
7.2.2	ACKNOWLEDGE MESSAGE	48
7.2.3	COMMAND SPECIFIC RESPONSE	49
8.	COMMAND MESSAGE SET	51
8.1	GET STATUS	51
8.2	RESET	51
8.3	RESET/SELFTTEST	52
8.4	CLEAR ERRORS	52
8.5	CLEAR INTERFACE	53
8.6	SEND OWN ADDRESS (SOA)	53
8.7	SET GROUP ADDRESS	55
8.8	GET GROUP ADDRESS	55
8.9	GET REGISTER	56
8.10	SET COMMAND MODE	57
8.11	GET COMMAND MODE	57
8.12	SET LOAD MODE	58
8.13	GET LOAD MODE	58
8.14	SET MEASUREMENT MODE	59
8.15	GET MEASUREMENT MODE	59
8.16	SET TRANSIENT MODE	60
8.17	GET TRANSIENT MODE	60
8.18	READ MEMORY	61
8.19	WRITE MEMORY	62
8.20	GET VERSION NUMBER	63
8.21	FLASH DOWNLOAD MODE	64
8.22	WRITE FLASH	65
8.23	WRITE CALIBRATION FACTORS	66
8.24	RESET CALIBRATION FACTORS	66
8.25	GET DEVICE CAPS	67
8.26	CALIBRATE AC CURRENT GAIN	69
8.27	CALIBRATE AC VOLTAGE GAIN	70
8.28	QUERY MEASUREMENT	71
8.29	SET MAXIMUM FREQUENCY LIMIT	72
8.30	GET MAXIMUM FREQUENCY LIMIT	73
8.31	SET MINIMUM FREQUENCY LIMIT	74
8.32	GET MINIMUM FREQUENCY LIMIT	75
8.33	SET MAXIMUM CURRENT LIMIT	76
8.34	GET MAXIMUM CURRENT LIMIT	77
8.35	SET MAXIMUM POWER LIMIT	78
8.36	GET MAXIMUM POWER LIMIT	79
8.37	SET CURRENT	80
8.38	GET CURRENT	81
8.39	SET CREST FACTOR	82
8.40	GET CREST FACTOR	83
8.41	SET POWER FACTOR	84
8.42	GET POWER FACTOR	85
8.43	SET RESISTANCE	86
8.44	GET RESISTANCE	87
8.45	SET POWER	88

8.46	GET POWER.....	89
8.47	SET VOLTAGE.....	90
8.48	GET VOLTAGE.....	91
8.49	WAIT FOR TRIGGER.....	92
8.50	SET TURN ON VOLTAGE.....	92
8.51	GET TURN ON VOLTAGE.....	93
8.52	SET TURN OFF VOLTAGE.....	94
8.53	GET TURN OFF VOLTAGE.....	95
8.54	SET TRIGGER PHASE.....	96
8.55	GET TRIGGER PHASE.....	97
8.56	STORE WAVEFORMS.....	98
8.57	GET WAVEFORMS.....	99
8.58	WRITE CONFIGURATION DATA.....	100
8.59	READ CONFIGURATION DATA.....	101
9.	REGISTER DESCRIPTION.....	103
9.1	EVENT STATUS REGISTER.....	103
9.2	HARDWARE FAULT REGISTER.....	103
9.3	SELFTTEST ERROR REGISTER.....	104
9.4	DEVICE ERROR REGISTER.....	104
9.5	OPERATIONAL ERROR REGISTER.....	104
9.6	COMMAND MODE REGISTER.....	105
9.7	LOAD MODE REGISTER.....	105
9.8	MEASUREMENT MODE REGISTER.....	106
9.9	TRANSIENT MODE REGISTER.....	106
10.	TROUBLE SHOOTING.....	107
10.1	LOAD POWER CIRCUIT BREAKER TRIPS.....	107
10.2	FAULT LAMP LIT.....	107
10.3	STATUS LAMP NOT BLINKING.....	107
10.4	ERROR LAMP LIT.....	108
10.5	NO COMPUTER COMMUNICATION.....	108
10.6	ZERO FREQUENCY.....	108
10.7	NEGATIVE POWER DISPLAYED.....	108
10.8	UNDER VOLTAGE.....	108
	ADDENDUM	
	TRANSIENT MODE.....	109

1. INTRODUCTION

The Model 4600 family of AC Electronic Loads is designed to provide precise non-linear loading requirements for UPS and AC power supply test and evaluation applications. Manufacturers are now able to vary current, crest factor and power factor to ensure that their products are tested to worst case conditions encountered in the field. The Model 4600 offers more flexibility, enhanced reliability, less space and lower cost than an assortment of passive resistive loads.

1.1 Broad Operating Envelope

To cover the full spectrum of UPS and AC power supplies, the Model 4600 operates up to 3000W over a voltage range of 50 to 350Vac in a single-phase mode. The loading current waveform synchronizes to the voltage waveform for the set current, crest factor and power factor. Thus multiple Model 4600s can be connected in parallel for higher power loading or in single groups for multiphase systems.

1.2 Non Linear Loading

Programmable crest factor and power factor allows the Model 4600 to emulate a non-linear load such as a switching power supply. The Model 4600's capability to provide a variety of loads from sinusoidal to high crest factor allows manufacturers to characterize UUT's to worst case conditions.

1.3 Broad Spectrum of Emulation Modes

To allow UPS's and AC power supplies to be tested under a variety of loading conditions, the Model 4600 offers a broad spectrum of emulation modes. CC mode allows current to be drawn constantly, making it suitable for non-linear, linear and regulation loading. While CR mode allows the load to emulate a power resistor, CV allows it to emulate a shunt regulator. CP mode emulates a constant power load such as a switching power supply. Short circuit mode allows the load to test the UUT's short circuit protection capability. Unity power factor mode causes power factor to be as close as possible to unity, useful when the input voltage is non-sinusoidal. These capabilities makes the Model 4600 a universal load which replaces an assortment of resistive loads and short circuit relays used currently by manufacturers.

1.4 High Accuracy Measurements

The Model 4600 accomplishes high accuracy frequency, voltage, peak voltage, current, peak current, crest factor, apparent power, true power, peak power, reactive power, power factor and resistance measurements by combining high resolution measurements with precision ranging. The ability to make all measurements internally eliminates multiple external measurement instruments plus associated signal matrixing. In this manner the load provides for a more compact, less costly and considerably faster test system. Waveforms may be graphically displayed eliminating the need for an oscilloscope.

2. SPECIFICATIONS

2.1 Ratings

Power: 3000W 0 - 37° C, 2400W 38 - 50° C

Max. Peak power: 13kW (up to 20% duty cycle)

Current: 30A rms.

Max. Peak current: 90A

Voltage: 50 to 350V rms.

Max. Peak voltage: 500V

Frequency: 45 to 440Hz

2.2 Programmable Features

Constant Current Mode

Range: 0 to 30A rms.

Accuracy: 0.2% of full scale

Resolution: 0.05% of full scale

Constant Voltage Mode

Range: 50 to 350V rms.

Accuracy: 0.2% of full scale

Resolution: 0.05% of full scale

Constant Resistance Mode

Range: 2.5 to 100 Ω , 100 to 1000 Ω

Accuracy: 1% of full scale, 5% of full scale

Resolution: 0.05% of full scale

Constant Power Mode

Range: 3000W 0 - 37° C, 2400W 38 - 50° C

Accuracy: 0.5% of full scale

Resolution: 0.1% of full scale

Crest factor

Range: $\sqrt{2}$ to 3.5, limited to 90A peak

Accuracy: 1% of full scale

Resolution: 0.1% of full scale

Power factor

Range: 0 to 1 lead or lag limited by Crest factor settings

Accuracy: 1% of full scale

Resolution: 0.1% of full scale

Short circuit Mode

Max. Surge current: 300A peak, up to 50msec

Max. Continuous current: 30A rms.

Max. Voltage drop: 2.5Vr.m.s.

Maximum Set Resistance = $1 / (\text{Frequency} * 1.3e-5)$

Minimum Set Current = Voltage / Maximum Set Resistance

2.3 Readback Instrumentation

Frequency

Range: 45 to 440Hz

Accuracy: 0.1% of full scale

Resolution: 0.05% of full scale

Voltage

Range: 50 to 350V rms.

Accuracy: 0.1% of full scale

Resolution: 0.05% of full scale

Peak Voltage

Range: 50 to 500V

Accuracy: 0.5% of full scale

Resolution: 0.1% of full scale

Current

Range: 0 to 30A rms.

Accuracy: 0.2% of full scale

Resolution: 0.1% of full scale

Peak Current

Range: 0 to 90A

Accuracy: 0.5% of full scale

Resolution: 0.1% of full scale

Crest factor

Range: $\sqrt{2}$ to 3.5

Accuracy: 0.5% of full scale

Resolution: 0.1% of full scale

Apparent Power

Range: 0 to 10,500VA

Accuracy: 0.3% of full scale

Resolution: 0.1% of full scale

True Power

Range: 0 to 10,500W

Accuracy: 0.3% of full scale

Resolution: 0.1% of full scale

Peak Power

Range: 0 to 45,000W

Accuracy: 1% of full scale

Resolution: 0.1% of full scale

Reactive Power

Range: 0 to 10,500VA

Accuracy: 0.3% of full scale

Resolution: 0.1% of full scale

Power factor

Range: 0 to 1

Accuracy: 0.5% of full scale

Resolution: 0.1% of full scale

Resistance

Range: 2.5 to 100 Ω , 100 to 1000 Ω

Accuracy: 1% of full scale, 5% of full scale

Resolution: 0.05% of full scale

2.4 Protection

Over Current

Limited by input Circuit Breaker

Limited to Set Maximum Current Limit in software

Over Voltage

Output protected for voltage transients in hardware

Over Power

Power limited at maximum average and peak rated power in hardware

Limited to Set Maximum Power Limit in software

Over Temperature

Monitors heat sink temperature in hardware

2.5 Supplemental Characteristics

Size

10.5"H x 16.88"W x 25"D, 40 lbs.

Remote Sensing:

Max. 2V drop between sense and load lines

Isolation

1000V between input and chassis ground

Operating temperature:

3000W 0 - 37° C, 2400W 39 - 50° C

Control power input:

Ordered from factory as either 115VAC \pm 10%, 47 to 63Hz, 1.4A Max.

OR 230VAC \pm 10%, 47 to 63Hz, 0.7A Max.

All specifications apply for 23° C \pm 5° C

3. INSTALLATION

3.1 Hardware Installation

Unpack the load. Save the packing material if a need arises to return the load.


The load is designed to mount into a 19" rack. Optional slide rails are available.

Select a suitable location, which meets size, weight, temperature, airflow, control power input and load power input requirements.


A computer to control the load must be located nearby. The length of the (RS232 or RS485) control cable limits the distance from the load to the computer. The controlling software must be set to the same computer communication port that is connected to the load. The controlling software must be set to the same address as the S6k AD switch on the load.

The remote sense wires must be connected at the power source for more accurate metering and to compensate for voltage drop across the load wires.

3.1.3 Top View



3.1.4 Side View



3.1.5 Connectors

3.1.5.1 Control Power Input

This supplies power to the fans and control circuits.

3.1.5.2 Load Power Input

Single unit:

Pin	Signal	Description
A1	No Connection	
A2	Neutral	Load power input
A3	No Connection	
A4	Line	Load power input
1	No Connection	
2	Neutral Sense	Remote voltage sense
3-7	No Connection	
8	Line Sense	Remote voltage sense
9-17	No Connection	

The voltage sense wires are also located on this connector. The voltage sense wires must be connected to the load wires either at this connector or at the source. The load will not operate with these voltage sense wires disconnected. It will generate an undervoltage error.

Mating connector type is:

NH Part #	Description	Commercial Part #	Manufacturer
6200933	DSUB 17 - 4 CO-AX	DCM-21 WA4S	ITT CANNON
6200949	DSUB contact 40 A	DM 53744-1	ITT CANNON
6200927	DSUB shell	DCM 24660	ITT CANNON
6201309	DSUB Screw Lock	D20419-21	ITT CANNON

3.1.5.3 RS232 9pin connector

Pin	Description
2	TX
3	RX
7	RTS
5	GND

Signal levels on this connector conform to RS232C signal levels.

Mating Connector type is:

NH Part #	Description	Commercial Part #	Manufacturer
6202014	DSUB 9 Plug	DE9P	ITT CANNON
6201698	DSUB Shell	DE24657	ITT CANNON
6201309	DSUB Screw Lock	D20419-21	ITT CANNON

This connector will mate with a PC compatible nine pin RS232 port if a one to one four wire cable is used. This connection may be used for control of the load in a test system.

3.1.5.4 Comm In/Out

Pin	COMM OUT – FEMALE	Pin	COMM IN - MALE
1	TX_IN-	1	TX_IN-
2	TRIGIN+	2	TRIGIN+
3	GND	3	GND
4	TX_IN+	4	TX_IN+
5	INTLKIN+	5	INTLKIN+
6	INTLKIN-	6	INTLKIN-
7	LCLOUT0+	7	LCLIN0+
8	LCLOUT-	8	LCLIN0-
9	RX_IN-	9	RXOUT-
10	TRGOUT+	10	TRGOUT+
11	TRGOUT-	11	TRGOUT-
12	RX_IN+	12	RXOUT+
13	TRIGIN-	13	TRIGIN-
14	LCL1OUT+	14	LCLIN1+
15	LCL1OUT-	15	LCLIN1-

Signal levels on this connector are differential with levels conforming to RS422 specification.

This connector will mate with NHR S6000 type modules. This connection may be used for control of the load in a test system. If Comm In is used, remove jumpers on J9, pins 9 to 10 and pins 11 to 12.

Mating connector type is:

NH Part	Description	Commercial Part #	Manufacturer
6200844	DSUB 15 Socket (COMM IN)	DA15S	ITT CANNON
6200799	DSUB 15 Plug (COMM OUT)	DA15P	ITT CANNON
6200800	DSUB Shell	DA24658	ITT CANNON
6201309	DSUB Screw Lock	D20419-21	ITT CANNON

3.1.5.5 Trig In/Out

Connector	Description
Trigger In	Negative true TTL level signal with 1K Ohm pull up to +5V
Trigger Out	Negative true TTL level output with 39 Ohm series resistor

These are the hardware trigger input and output connectors for use with transients.

Mating Connector type is:

NH Part	Description	Commercial Part #	Manufacturer
6200262	SMB CO-AX 50 Ohm	131-1403-016	EF JOHNSON

This connector is used with RG178 type 50-ohm CO-AXIAL cable.

3.1.5.6 Hold In/Out

Connector	Description
Hold In/Out	Open collector output.

Paralleled units wait or hold until all are ready to execute new commands simultaneously. Paralleled units will work with out this connection but may not execute commands simultaneously. Connect Hold Out to Hold In from one unit to the next in a daisy chain fashion for all loads in parallel. Do not connect anything else to this connector.

Mating Connector type is:

NH Part	Description	Commercial Part #	Manufacturer
6200262	SMB CO-AX 50 Ohm	131-1403-016	EF JOHNSON

This connector is used with RG178 type 50-ohm CO-AXIAL cable.

3.1.6 Airflow

The load will dissipate over 3kW of heat.

400CFM of air must be allowed to moving through the load.

Air enters through slots on top, bottom and both sides then exits through the rear.

3.1.7 Master Slave Installation

Slave units must be located next to the master.

3.1.7.1 Load Power Input

Load power input to master slave paralleling cable:

Pin	Signal	Description
A1	Neutral	Load power input unit #1
A2	Neutral	Load power input unit #2
A3	Line	Load power input unit #1
A4	Line	Load power input unit #2
1	No Connection	
2	Neutral Sense	Remote voltage sense both units
3-7	No Connection	
8	Line Sense	Remote voltage sense both units
9-17	No Connection	

Connect the master slave paralleling cable to the master and slave load power input connectors. Connect your source to this cable. The Master-Slave paralleling cable requires (neutral connection to pins A1 and A2 in parallel) and (line connection to pins A3 and A4 in parallel).

3.1.7.2 Computer Connection

Connect the controlling computer to the RS232 port or COMM IN on the master. If COMM IN is used, remove jumpers on J9, pins 9 to 10 and pins 11 to 12. Connect COMM OUT from the master to COMM IN on the slave.

3.1.7.3 Hold Connection

Connect HOLD OUT from the master to HOLD IN on the slave.

3.2 Software Installation

3.2.1 Software Installation from CD ROM

Close all programs that are currently running in windows. Insert the CD into the drive and view the contents of the disk and double click on 'Setup' to start the installation. Follow the instructions on the screen.

3.2.2 Software Installation from Floppies

Close all programs that are currently running in windows. Insert disk #1 in the floppy drive. View the contents of the disk and double click on 'Setup' to start the installation. Follow the instructions on the screen.

4. USER OPERATION

4.1 Hardware Operation

4.1.1 Control Power Switch and Indicator

This switch/indicator is located on the front panel. When ON, this switch/indicator will light indicating fan and control power is applied.

4.1.2 Load Power Circuit Breaker

This circuit breaker is located on the front panel. When ON, this circuit breaker connects the load to the load power input terminals.

4.1.3 S6k AD Switch

The address switch on the rear of the load is used to set a unique communication address for the load on the S6000 family serial interface. Switch ADRS0 – ADRS5 are used to set a module address. Paralleled loads must have successive module addresses.

Switch GADR0 and GADR1 are used to set a group communication address. All paralleled loads must have the same group address other than 0xFF.

Example:

Load	Description	Switch ADRS 543210	Unique Address	Switch GADR 10	Group Address
1	Master in parallel with load 2	000001	0x01	00	0xFC
2	Slave in parallel with load 1	000010	0x02	00	0xFC
3	Master in parallel with load 4	000011	0x03	01	0xFD
4	Slave in parallel with load 3	000100	0x04	01	0xFD
5	Master not paralleled	000101	0x05	11	0xFF

If all eight positions of this switch are off when the load is turned on, it will boot from firmware in EPROM and not from FLASH. This is useful if the firmware in FLASH has been corrupted.

4.1.4 Fault Indicator

The fault indicator is located on the front panel. A hardware fault (overtemp, overpower, no share) caused the hardware to shutdown. This indicator is cleared by a hardware reset, clear error, reset and selftest commands only after the fault is removed.

4.1.5 Status Indicator

This indicator is located on the rear panel. It should blink at a 1Hz rate indicating the internal DSP is operating.

4.1.6 Error Indicator

This indicator located on the rear panel indicates a software error has occurred. If lit when the load is initially turned on indicates self-test failed.

4.1.7 Talk Indicator


This indicator located on the rear panel will blink on when data is going from the load to the computer.

4.1.8 Listen Indicator


This indicator located on the rear panel will blink on when commands are going from the computer to the load.

4.2 Software Operation



4.2.1 Accessing Help



Right click on the control you're interested in then highlight 'Description...' to get help for that control.




When you click on the 'Help' button you will be provided with a general description of system requirements as well as some capability information.



4.2.2 Off

The load will not draw any power when in the off state.

4.2.3 Load Modes



Use the red slider to select the mode of operation for the load.

4.2.3.1 Constant Current

The amount of rms current drawn is a constant, regardless of the input voltage. Crest Factor and Power Factor may also be programmed.

4.2.3.2 Constant Power

Varies the amount of current drawn inversely proportional with the input voltage in order to maintain a constant power. By varying the Crest Factor and the Power Factor the load emulates a very wide variety of switching power supplies.

4.2.3.3 Constant Resistance


The amount of current drawn varies in direct proportion with the voltage. In this mode the load emulates a power resistor.

4.2.3.4 Constant Voltage

Draws the necessary amount of current to maintain a constant voltage, emulates a shunt regulator.


4.2.4 Other Programmable Features

4.2.4.1 Crest Factor




Emulates different types of load characteristics (i.e. switching supplies or other nonlinear loads) in Constant Power and Constant Current mode. Not programmable when unity power factor is selected.

4.2.4.2 Power Factor



In conjunction with the crest factor it can be set from 0 to 1 (lead or lag) in Constant Power and Constant Current mode. Not programmable when unity power factor is selected. Limited by crest factor setting. See section 6.12 Crest Factor and Power Factor Relationship.

4.2.4.3 Short circuit



Internal SCR's turn on to test the UUT short circuit protection capability.

4.2.4.4 Power Factor Modes



Unity Power Factor. (Unity PF)

Forces highest power factor. Programmable Crest Factor and Power Factor do not apply. Allows Constant Current and Constant Power to be programmed correctly with non-sinusoidal input voltages.


Power Factor Priority. (PF Priority)

Changes Crest Factor to obtain desired Power Factor without phase shifting current. Programmable Crest Factor and does not apply. More closely emulates a power supply type load.

Crest Factor Priority. (CF Priority)

Crest Factor and Power Factor are Programmable. See section 6.12 Crest Factor and Power Factor Relationship.

4.2.5 Status




This status bar indicates instrument errors. The two letter descriptors stand for over power (OP), over temperature (OT), no sharing (NS), over current (OC), power factor (PF), under voltage (UV), over voltage (OV), under frequency (UF), and over frequency (OF). The status boxes will turn red if an error is detected. The status bar is separated into two regions. The left region of the status bar represents catastrophic hardware errors and the right represents operational errors.

4.2.6 Device Capabilities



The device capabilities are the permissible operational ranges of the AC Load.




A screenshot of a control panel interface. It features a table with three columns: "Setting", "Min. Cap", and "Max. Cap". Below the table is a "Return" button.


Setting	Min. Cap	Max. Cap
Frequency (Hz)	40.000	450.000
AC Voltage (V)	0.000	24.000
AC Voltage (V)	50.000	350.000
Power (W)	0.000	2400.000
Resistance (Ohms)	2.500	1000.000
Grid Factor	1.400	3.500
Power factor	-1.000	1.000
Trigger Phase	0.000	360.000

Return


4.2.7 Advanced Settings



The advanced settings allow you to customize specific operational characteristics of the AC Load as well generate a trigger based on a phase angle.



4.2.8 Resetting




Resets the load hardware to default values.


4.2.9 Transient



Queues up to 100 commands and when triggered executes them locally (internal DSP). This allows very fast changes (every cycle if needed) in current which can reveal precious information about the regulation, output voltage and current, peak capabilities etc. of the UUT in just one test. The commands can be executed as a single shot or as a loop.



4.2.10 Metering



The technique used for measurements is Synchronous Sampling. This method yields maximum speed and accuracy (one-cycle measurements).

4.2.10.1 Read back Capabilities



True RMS Current, True RMS Voltage, True Power, Peak Power, Crest Factor, Peak Current, Peak Voltage, Apparent Power, Resistance, Power Factor, Frequency and Reactive Power are all metered.


4.2.10.2 Metering Modes




By default the last several measurements made are averaged and returned. This may be up to 2 cycles old, but is returned immediately. If Next Mode is selected, a new measurement is made and returned after the command is sent.

Peak measurements are reset each cycle. If Peak mode is selected, the largest peak measurement is saved. This is useful for inrush measurement.

4.2.10.3 Waveform Capture




One cycle of current, voltage and power waveforms may be graphically displayed eliminating the need for an oscilloscope.



(Waveform Capture Cont.)

De-select the combine plots to view each individual waveform independently.



5. CALIBRATION

WARNING!!!!!! THIS SECTION IS FOR EXPERIENCED USERS WITH A DETAILED UNDERSTANDING OF THE SYSTEM HARDWARE AND SOFTWARE. POSSIBLE IRREPAIRABLE UUT DAMAGE OR CORRUPTION OF THE LOADS FLASH MEMORY MAY RESULT FROM INAPPROPRIATE SETTINGS.

5.1 Maintenance Panel

5.2 Equipment Required




Xitron Power Analyzer model 2501AH with high accuracy option or Yokogawa Power Analyzer model WT2000 or equivalent.

5.3 Procedure

From the start menu 'programs' select 'NHResearch' Click on 'L4600 Maintenance Panel'. You have to select the com. port and the instrument address to obtain access to the maintenance panel.

Click on the calibration button to obtain the calibration panel.

Click on "Calibrate All" and follow instructions.



Set calibrating current and voltage to 90% of maximum rating.

Save the calibration data by writing the calibration factors to FLASH RAM.

Write Cal Factors

Verify measured current and voltage is the same as actual \pm metering accuracy.

Calibration is now complete.

6. THEORY OF OPERATION

6.1 Architecture

The load contains a Texas Instruments TMS320C32, a 32 bit floating point digital signal processor. The DSP with a Motorola MC68681 UART uses RS232 or RS485 serial ports for the command/response interface. The DSP uses FLASH PROM for code, calibration, configuration data, hardware control registers and DMA's for output waveform generation and measurement. The DSP boot kernel is in a "read only" EPROM separate from the FLASH memory. The DSP performs all setup, control, synchronization and measurement functions for the AC waveform, control hardware initialization and setup via memory mapped control/status registers.

The load accepts commands using the S6000 command protocol. Using the set commands and/or writing control words into the appropriate registers programs operation of the load. Reading the appropriate registers provides operational feedback.

To facilitate future firmware versions, all of the DSP code, configuration and calibration data is stored in FLASH memory, which can be downloaded over the serial interface.

High accuracy is obtained by the use of 16-bit instrument grade digital to analog converters and analog to digital converters.

6.2 Memory

6.2.1 Memory Map

CPU Address	Memory	Data	Description
000000-000FFF			Internal DSP boot loader
001000-00FFFF	32	32	EPROM
010000-03FFFF	32	32	Do not access, EPROM
040000-07FFFF	32	32	Not used
080000-1FFFFFFF			Do not access
200000-23FFFF	32	32	Not used
240000-27FFFF	32	32	Analog to digital converters
280000-7FFFFFFF			Do not access
800000-807FFF			Reserved
808000-8097FF	32	32	Peripheral bus
809800-80FFFF			Reserved
810000-81000F	32	32	UART
810010-811FFF	32	32	Do not access, UART
812000-813FFF	32	32	Digital inputs
814000-815FFF	32	32	Digital outputs
816000-817FFF	32	32	Frequency register
818000-819FFF	32	32	Reference DAC
81A000-81BFFF	32	32	Not used
81C000-81DFFF	32	32	Not used
81E000-81FFFF	32	32	Not used
820000-82FFFF			Do not access
830000-87FDFF	32	32	Reserved
87FE00-87FFFF	32	32	Internal RAM
880000-887FFF	32	32	SRAM, 32k word by 32 bit
888000-89FFFF	32	32	Do not access, RAM
900000-90FFFF	32	16	SRAM, 64k word by 16 bit
910000-97FFFF	32	16	Do not access, RAM
980000-9FFFFFFF	32	16	Not used
A00000-A07FFF	16	32	Flash prom, 32k word by 32 bit
A08000-A3FFFF	16	32	Do not access, Flash prom
A40000-C7FFFF	16	32	Do not access
C00000-C0FFFF	16	16	Flash prom, 64k word by 16 bit
C10000-C3FFFF	16	16	Do not access, Flash prom
C40000-C7FFFF	16	16	Do not access
C80000-CFFFFFFF	32	16	Waveform DAC
D00000-FFFFFFF			Do not access

Memory is not fully decoded. Using a "do not access" address may access another device and cause undesired operation. CPU and external address may be different. "Memory" is memory width and "Data" is data size loaded into a STROB register.

6.2.2 EPROM

A single chip 64k by 8 bit EPROM is connected to data lines D7-0. It contains a full version of code.

6.2.3 Analog to Digital Converters

A 16-bit analog to digital converter used to measure voltage 'VADC' is connected to data lines D31-16. A 16-bit analog to digital converter used to measure current 'AADC' is connected to data lines D15-0. The DMA reads both the VADC and AADC simultaneously as one 32-bit word and writes the data into RAM.

6.2.4 Peripheral Bus

Internal to the DSP is DMA0, DMA1, timer0, timer1, serial port and external port registers.

6.2.5 UART

A Motorola MC68681 is connected to data lines D7-0. It is used for RS232 and RS485 serial communications. It is also used for triggering and fault detection.

6.2.6 Digital Inputs

A 16-bit register 'DIN' connected to data lines D31-16 is used for reading hardware status bits and the address switch.

6.2.7 Digital Outputs

A 16-bit register 'DOUT' connected to data lines D31-16 is used for writing hardware status bits.

6.2.8 Frequency

A 16-bit register 'FREQ' connected to data lines D31-16 writes to a 16-bit binary rate multiplier 'BRM'. This BRM generates the ADC_CLK and DAC_CLK. This clock is a power of 2 multiple of the load frequency.

6.2.9 Reference Digital to Analog Converter

A 16-bit digital to analog converter connected to data lines D31-16. Scales output waveform.

6.2.10 Internal RAM

The DSP contains internal RAM, which is 512-word by 32-bit. The stack starts here and may grow into external RAM.

6.2.11 SRAM

There are four 32k word by 8 bit SRAM chips. The same RAM may be accessed as a single 32-bit word or two separate 16-bit words depending upon the address. 32 bit is used for code and data. 16 bit is used for the output waveform.

6.2.12 Flash PROM

Two 64k by 8 bit Flash PROM chips are used. They are connected to data lines D15-0. They contain a full version of code and calibration factors.

6.2.13 Waveform Digital to Analog Converter

A 16-bit digital to analog converter connected to data lines D15-0 generates the output waveform. Data is copied from RAM to this DAC by a DMA.

6.3 Reset

During a reset the MCBL/MP* pin is high, this causes the DSP to enter boot loader mode. INT0 is low, INT1-3 is high, and this causes the boot loader to read code from EPROM and write it to RAM. Program execution begins in RAM. If Flash ROM checksum is correct, a newer version of code is copied from Flash ROM into RAM. By setting the address switch to 0, code will not be copied from Flash ROM to RAM.

6.4 Interrupts

6.4.1 INT0

A positive zero crossing on the load-input terminals causes an INT0 interrupt. The CPU measures phase error, uses timer0 to measure the period of input voltage waveform and synchronize the load current waveform to the input voltage waveform.

6.4.2 INT1

The BRM generates the DAC_CLK, which is connected to INT1. This interrupt causes DMA0 to read the VADC and AADC then copy the data to RAM and DMA1 to copy a new step of waveform data to the waveform DAC.


6.4.3 INT2

Not used.

6.4.4 INT3

The CPU handles communications, triggering and fault interrupts generated by the UART on INT3.

6.5 Block Diagram



6.6 Synchronization

The load power input voltage waveform is scaled down by 50 to 1 then converted to a square wave by a comparator. The output of this comparator is the sync signal.

6.7 Frequency Metering

The period of the sync signal is measured, inverted then displayed as frequency.

6.8 Voltage Metering

The voltage at the remote voltage sense terminals is scaled down 50 to 1 by a differential amplifier. This signal is then sent to the voltage 16bit analog to digital converter and sampled synchronously at a power of 2 multiple of the input frequency. The DSP then calculates AC rms voltage and other metering values.

6.9 Current Metering

The current through the shunt generates a voltage, which is scaled up 100 to 1 by a differential amplifier. This signal is then sent to the current 16bit analog to digital converter and sampled synchronously at a power of 2 multiple of the input frequency. The DSP then calculates AC rms current and other metering values.

6.10 Hardware CR Mode

The hardware emulates a resistor in this mode. The hardware is in this mode when constant resistance or voltage mode is programmed. The hardware is in this mode when constant current or constant power is programmed and unity power factor is on. The load does **not** respond to the programmed crest factor or power factor.

Voltage from the load power input is scaled down 50 to 1 and feed into the reference DAC. The reference DAC scales this signal to obtain the desired resistance.

The current error amp compares the output of the reference DAC to the metered current and generates the signal required to drive the power transistors.

6.11 Hardware CC Mode

The DSP generates a waveform with the desired crest factor and power factor in this mode. The hardware is in this mode when constant current or constant power is programmed and unity power factor is off.

The DSP generates a waveform at the output of the waveform DAC. This waveform synchronizes to the input voltage using the sync signal. The waveform is scaled by the reference DAC to obtain the desired current.

The current error amp compares the output of the reference DAC to the metered current and generates the signal required to drive the power transistors.

6.12 Crest Factor and Power Factor Relationship

This section discusses the relationship between crest factor and power factor. This only applies when the input voltage is sinusoidal, unity power factor is off and the load is in constant current or constant power mode. For non-sinusoidal input voltages select unity power factor mode.

Crest factor is peak current divided by rms current. When a crest factor of 1.414 is programmed, the DSP creates a sinusoidal current waveform. When a higher crest factor is programmed the DSP creates a modified sinusoidal current waveform with the correct crest factor. The DSP can directly create the desired crest factor.

Power factor is true power divided by apparent power. For a resistive load the power factor is 1. Assuming a constant voltage RMS and constant current RMS, as crest factor increases, power factor decreases because apparent power remains constant and true power decreases. True power decreases because current is not flowing during the entire cycle.

For a given crest factor there is only a limited range of possible power factors. The load cannot directly create the desired power factor; it can only attempt to meet the desired power factor. The programmed power factor is achieved by programming an appropriate crest factor and the DSP will phase shift the current. As crest factor increases the range of possible power factor decreases.

For example:

With a crest factor of 1.414, the only power factor allowed is 1.

With a crest factor of 2, the power factor may range from 0.6 to 0.8.

With a crest factor of 3, the power factor may range from 0.2 to 0.5.

If a higher power factor is desired, program a lower crest factor. If a lower power factor is desired, program a higher crest factor.

If the power factor programmed is positive it will be a leading power factor. If the power factor programmed is negative it will be a lagging power factor.

6.13 Power Section

The load power input is connected to a circuit breaker.

The circuit breaker is connected to the shorting SCR's and the AC side of a diode bridge.

The DC side of the Diode Bridge is connected the power transistor array.

The power transistor array consists of 4 load boards in series. Each load boards have 28 power transistors in parallel.

6.14 Protection Circuitry

The following protection is provided in hardware, and may also be redundant by the DSP.

6.14.1 Circuit Breaker

An input circuit breaker is provided. This CB will trip if input current exceeds ratings.

6.14.2 Overvoltage

Overvoltage protection is provided in two stages.

During the first stage the load will turn on and clamp voltages above rating. The load will act like a zener diode.

If the energy is greater than the load can absorb, the second stage is turning on the shorting SCR's. This is an overvoltage crowbar.

6.14.3 Overtemperature

A temperature switch is located on each of the 4 load boards. Any one will shut down the load.

6.14.4 Overpower

The DSP will not allow the load to draw more than rated power. If the remote sense wires are not properly connected the load cannot calculate the actual power dissipated.

In hardware an analog multiplier creates an average true power signal which will shut down the load if rated input power is exceeded.

6.14.5 No Share

The 4 load boards should dissipate equal energy. If they are not close enough this circuit will shut down load.

6.14.6 Second Break Limit

The power transistors have an average and peak power rating. This circuit limits peak power dissipated to the peak power rating. This will **not** shut down the load; it will just limit peak power.

7. MESSAGE FORMATS

The S6000 command/response protocol is an RS485 multidrop protocol. Each device on the bus has a unique address in the range 1 through 63. Each device listens to the bus for the command address byte. If the address byte matches the device's address or is a broadcast address (0xFF), the device will process the command. The device will respond with an acknowledge byte to all commands except status and broadcast commands. The device will only send messages to the controller when the controller requests data.

7.1 Command Message

The command message will contain the following eight bit packets:

Address

Count

Command

0 to n message specific data packets

Checksum

The address packet is the module address. The module address is set via the switch block. The module will process any message with the correct address packet or if the command is a broadcast command. The address byte is distinguished from the other byte by the setting of the parity bit.

The count packet is the number of data packets in the command message, not including the address or checksum packets. The exception is the status message. The status message count will be zero and the message will contain only address and count packets.

The command packet is the ID of the command to be processed.

The data packets are command dependent.

The checksum is the bitwise exclusive or of all the message packets with 0xFF. The checksum is used to check for message transmission errors in place of parity checking.

If any errors are detected in the command message a command error will be generated and the command will not be processed. If any errors are detected while the command is being processed an execution error will be generated and the processing of the command will be stopped. The commands listed can only be sent to the device if they are legal for the given Command mode. Various state bits in the Command Mode Register determine the Command Mode.

7.1.1 Command Types

There are three types of commands:

Broadcast

Immediate

Query

If the address packet is 0xFF the command is a broadcast command. The module will process the command but not issue an acknowledge response message. The module will respond to the CPU with an acknowledge message upon receipt of all commands except for status or broadcast commands. The module will respond to the CPU with an acknowledge message plus data upon receipt of a query command.

Commands which respond with data (i.e. fetch) should not be sent as broadcast commands. Spurious data will be generated on the interface bus.

7.2 Response Message

There are three type of response message formats; the status response message, the acknowledge message, and the command specific response. Each response message will contain a message specific number of eight bit data packets.

7.2.1 Status Response Message

The module upon receipt of a status command will issue the status response message.

The status response message has the following format:

Address

Contents of Event Status Register see section 9.1.

Checksum

The checksum is the bitwise exclusive or of all the message packets with 0xFF. The checksum is used to check for message transmission errors in place of parity checking.

7.2.2 Acknowledge Message

The acknowledge message will be issued upon receipt of all commands except the status command. The acknowledge message has the following format:

Bitwise inversion of address

7.2.3 Command Specific Response

The command specific response message will be issued upon completion of a query command. The command specific response message has the following format:

Address

Count

0 to n message specific data packets

Checksum

The count packet is the number of data packets in the command message, not including the address or checksum packets.

The data packets are command dependent.

The checksum is the bitwise exclusive or of all the message packets with 0xFF. The checksum is used to check for message transmission errors in place of parity checking.



8. COMMAND MESSAGE SET

8.1 Get Status

This message commands the module to return the contents of the Event Status Register. See section 9.1 for a description of the Event Status Register. The controller to get fast status information from the module should use it.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x00

Response:

Byte	Description	Value
1	Source address	0xnn
2	Event status reg.	0xnn
3	Checksum	0xnn

8.2 Reset

This message commands the module to return to the power-up state. All variables on the module are returned to their default values. All digital outputs and DACs are set to their power on state. This command is used to bring the module to the power-up mode. This command should be used after the controller detects a module error or as a fast way to bring the module to a fully reset state. Note that the error registers should be read before this command is sent.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x01
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.3 Reset/Selftest

The module resets and runs a selftest. See section 9.3 Selftest Error Register for a description of errors. All errors are cleared except those generated during this test.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x02
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.4 Clear Errors

This message commands the module to clear the Hardware Fault and Device Specific Error bits in the Event Status Register and all the bits in error registers. If a Hardware Fault is still true it cannot be cleared.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x03
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.5 Clear Interface

This message commands the module to clear the serial interface without resetting the module.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x04
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.6 Send Own Address (SOA)

The S6000/PC controller to perform auto configuration at power-up uses this command. This command will be used to open and close the daisy chain connection to the downstream modules, have the module respond with its logical address, and ignore all messages until it receives the command to close the daisy chain connection.

At power-up the S6000/PC controller should:

- 1) Issue a broadcast SOA type 1

This command will put all modules in SOA mode 1. The modules will open up the bus to the downstream modules.

- 2) Issue a broadcast SOA type 2

This command will put all modules in SOA mode 2. All of the modules, except those locked out, will respond with their logical address and type. Since the downstream modules are disconnected from the response bus the S6000/PC controller will only receive a response from the most upstream module.

- 3) Issue an SOA type 3 command to the module to lock it out.

- 4) Repeat steps 2 through 3 until no modules respond.

- 5) Issue a broadcast SOA type 4 command to reset bus communication.

At power up and reset the module serial bus is daisy chained from the CPU to the last module. If the module receives a RESET command while in SOA modes 1 through 4, it will reset to SOA mode 0 {normal operation} and connect the downstream modules. SOA type 1-3 sets the SOA bit of the Command Mode Register. SOA type 4 clears the SOA bit of the Command Mode Register. See section 9.6 for a description of the Command Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x07
4	Type	0xnn
5	Checksum	0xnn

Response:

Type 1:

The module will not issue any response to this command. It will open up the serial bus.

Type 2:

The module will issue configuration data.

Description	Module ID	System (Notebook) ID
2.4kW AC Load	51	2600
3.0kW AC Load Master	52	2601
3.0kW AC Load Slave	53	2602

Byte	Description	Value
1	Source address	0xnn
2	Count	0x03
3	Module Address	0xnn
4	Module Type	0x33
5	Checksum	0xnn

Type 3:

The module will issue an acknowledge message and lock itself out from responding to any commands until it receives an SOA type 4 command. It will close up the serial bus to the next module.

Byte	Description	Value
1	Acknowledge byte	0xnn

Type 4:

The module will not issue any response to this command. It will return to normal communication mode.

8.7 Set Group Address

This command will setup a secondary address to which the module will accept commands. The module will treat any command received with this address as a broadcast command, i.e. the module will not issue an acknowledge response. This command will allow the controller to setup a subgroup to communicate with of all the modules on the bus. Only commands that do not generate responses should be used with the group address. At power-up the group address parameter will be set to 0xFF, the broadcast address. The range of possible group address is from 0xF0 to 0xFF. Remember that all modules belong to group (0xFF). If the group address switch is not set to 0xFF the group address may not be changed.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x08
4	Group address	0xnn
5	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.8 Get Group Address

This command will cause the module to respond with its group address parameter.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x09
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x02
3	Group address	0xnn
4	Checksum	0xnn

8.9 Get Register

This command returns the contents of the selected register. See section 8.55 for a description of the registers.

Registers:

Index	Register description
1	Event Status
2	Hardware Fault
3	Selftest Error
4	Device Error
5	Operational Error

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x11
4	Register index	0xnn
5	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x02
3	Register data	0xnn
4	Checksum	0xnn

8.10 Set Command Mode

This command will define the command mode. A byte is written to the Command Mode Register. To use this command, read the Command Mode Register change the bits required then write it back. See section 9.6 for a description of the Command Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x12
4	Byte	0xnn
5	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.11 Get Command Mode

This command returns the contents of the Command Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x13
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x02
3	Register data	0xnn
4	Checksum	0xnn

8.12 Set Load Mode

This command will define the load mode. A byte is written to the Load Mode Register. To use this command, read the Load Mode Register change the bits required then write it back. See section 9.7 for a description of the Load Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x14
4	Byte	0xnn
5	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.13 Get Load Mode

This command returns the contents of the Load Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x15
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x02
3	Register data	0xnn
4	Checksum	0xnn

8.14 Set Measurement Mode

This command will define how measurements are made. A byte is written to the Measurement Mode Register. To use this command, read the Measurement Mode Register change the bits required then write it back. See section 9.8 for a description of the Measurement Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x16
5	Byte	0xnn
6	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.15 Get Measurement Mode

This command returns the contents of the Measurement Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x17
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x02
3	Register data	0xnn
4	Checksum	0xnn

8.16 Set Transient Mode

This command will set transient mode, input and output triggers. A byte is written to the Transient Mode Register. To use this command, get the Transient Mode Register change the bits required then write it back. See section 9.9 for a description of the Transient Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x18
4	Byte	0xnn
5	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.17 Get Transient Mode

This command returns the contents of the Transient Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x19
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x02
3	Register data	0xnn
4	Checksum	0xnn

8.18 Read Memory

This command allows the S6000/PC controller to read any address location in the module. This command should be only used for testing. No error checking on the data is performed.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x05
3	Command ID	0x1A
4	Address byte 0 LSB	0xnn
5	Address byte 1	0xnn
6	Address byte 2 MSB	0xnn
7	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Data byte 0 LSB	0xnn
4	Data byte 1	0xnn
5	Data byte 2	0xnn
6	Data byte 3 MSB	0xnn
7	Checksum	0xnn

8.19 Write Memory

This command allows the S6000/PC controller to write to any address in the module. This command should be only used for testing. No error checking on the data is performed.

This command will cause an execution error if:

The debug bit is not set in the Command Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x09
3	Command ID	0x1B
4	Address byte 0 LSB	0xnn
5	Address byte 1	0xnn
6	Address byte 2 MSB	0xnn
8	Data byte 0 LSB	0xnn
9	Data byte 1	0xnn
10	Data byte 2	0xnn
11	Data byte 3 MSB	0xnn
12	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.20 Get Version Number

This command will return the firmware version number of FLASH if executing from FLASH or EPROM if executing from EPROM.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x1C
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.21 Flash Download Mode

This command, in conjunction with the Write Flash command, is used to download new DSP firmware.

Starts Download Mode will set the download bit in the Command Mode Register, and prevent execution from FLASH at next hardware reset. End Download Mode will clear the download bit in the Command Mode Register, calculate and save firmware checksum, then allow execution from FLASH at next hardware reset.

Mode:

Mode	Description
0	Abort
1	Start Download
2	End Download

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x1D
4	Mode	0xnn
5	Packet Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.22 Write Flash

This command, in conjunction with the Flash Download Mode command, is used to download new DSP firmware. The command consists of the address and 128 bytes of data to store starting at the address.

The FLASH must be written to in 256 byte blocks, 64 32bit words, or one page at a time. Therefore this command must be issued in multiples of 2. The first packet address must be on a page boundary, a 32bit address on multiples of 0x100. The second packet address must be on ½ page boundary, the first address plus 0x80. Addresses are divided by 4 (byte to word address conversion) when loaded into SRAM. After the second packet the 256-byte block will be written to FLASH. All 256 bytes of data must be defined even if they are not used.

A hardware reset must occur for new parameters to take effect.

This command will cause an execution error if:

The download bit is not set in the Command Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x86
3	Command ID	0x1E
4	Address byte 0 LSB	0xnn
5	Address byte 1	0xnn
6	Address byte 2	0xnn
7	Address byte 3 MSB	0xnn
8	Address 1 data byte 0 LSB	0xnn
9	Address 1 data byte 1	0xnn
10	Address 1 data byte 2	0xnn
11	Address 1 data byte 3 MSB	0xnn
...	Address n data byte 0	0xnn
...	Address n data byte 1	0xnn
...	Address n data byte 2	0xnn
...	Address n data byte 3	0xnn
136	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.23 Write Calibration Factors

This command is used to write calibration factors and configuration data to flash. All calibration factors and configuration data in SRAM are written into FLASH.

This command will cause an execution error if:

The download bit is not set in the Command Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x1F
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.24 Reset Calibration Factors

This command is used to reset calibration factors in SRAM to EPROM defaults. Calibration factors are NOT written into FLASH. Defaults may be written to FLASH with the write calibration factors command after this command. This command NOT needed during normal calibration. Hardware reset is required to use FLASH calibration factors.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x20
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.25 Get Device Caps

This command will return the device maximum and minimums capacities. A set type command outside of these limits will cause an execution error. The following structure is returned.

Struct 4600CAPS

```
{  
    FLOAT32 fMinFreq;  
    FLOAT32 fMaxFreq;  
    FLOAT32 fMinACCurrent;  
    FLOAT32 fMaxACCurrent;  
    FLOAT32 fMinCrestFactor;  
    FLOAT32 fMaxCrestFactor;  
    FLOAT32 fMinPowerFactor;  
    FLOAT32 fMaxPowerFactor;  
    FLOAT32 fMinResistance;  
    FLOAT32 fMaxResistance;  
    FLOAT32 fMinPower;  
    FLOAT32 fMaxPower;  
    FLOAT32 fMinACVoltage;  
    FLOAT32 fMaxACVoltage;  
    FLOAT32 fMinTrigPhase;  
    FLOAT32 fMaxTrigPhase;  
};
```

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x21
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x42
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
...
64	Float byte 60 LSB	0xnn
65	Float byte 61	0xnn
66	Float byte 62	0xnn
67	Float byte 63 exponent	0xnn
68	Checksum	0xnn

8.26 Calibrate AC Current Gain

To use this command place the load in AC Constant Current Mode, crest factor 1.414 and power factor 1. Set load current to 90% of maximum value. Send the actual current. This command will cause the load to calculate and store its own current gain. Set Measurement Mode to last, which is the default.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x22
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.27 Calibrate AC Voltage Gain

To use this command place the load in AC mode, connect 90% of maximum AC voltage to the voltage sense terminals. Send the actual voltage. This command will cause the load to calculate and store its own voltage gain. Set Measurement Mode to last, which is the default.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x23
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.28 Query Measurement

This command will return the selected measurement. If the measurement is out of range 3.4e38 is returned.

Measurement:

Index	Measurement description
1	Frequency
2	Volts
3	Peak Volts
4	Current
5	Peak Current
6	Current Crest Factor
7	Apparent Power
8	True Power
9	Peak Power
10	Reactive Power
11	Power Factor
12	Resistance

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x03
3	Command ID	0x24
4	Measurement index	0xnn
5	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.29 Set Maximum Frequency Limit

This is the maximum operating frequency. Reset frequency is Get Device Caps fMaxFreq. Range is Minimum Frequency Limit to fMaxFreq.

This command will cause an execution error if the:
Frequency is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x25
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.30 Get Maximum Frequency Limit

This command will return the set maximum frequency limit as programmed by the Set Maximum Frequency Limit command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x26
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.31 Set Minimum Frequency Limit

This is the minimum operating frequency. Reset frequency is Get Device Caps fMinFreq. Range is Maximum Frequency Limit to fMinFreq.

This command will cause an execution error if the:
Frequency is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x27
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.32 Get Minimum Frequency Limit

This command will return the set minimum frequency limit as programmed by the Set Minimum Frequency limit command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x28
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.33 Set Maximum Current Limit

This is the maximum current in any mode. Reset current is Get Device Caps fMaxACCurrent. Range is fMinACCurrent to fMaxACCurrent.

This command will cause an execution error if the:
Current is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x29
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.34 Get Maximum Current Limit

This command will return the maximum current as programmed by the Maximum Current Limit command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x2A
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.35 Set Maximum Power Limit

This is the maximum power in any mode. Reset power is Get Device Caps fMaxPower. Range is fMinPower to fMaxPower.

This command will cause an execution error if the:
Power is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x2B
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.36 Get Maximum Power Limit

This command will return the maximum power as programmed by the Maximum Power Limit command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x2C
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.37 Set Current

This is the set current in Constant Current Mode. This command places the load in Constant Current Mode and enabled as defined by the Load Mode Register. Reset current is Get Device Caps fMinACCurrent. Range is fMinACCurrent to fMaxACCurrent.

This command will cause an execution error if the:
Current is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x2D
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.38 Get Current

This command will return the set current as programmed by the Set Current command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x2E
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.39 Set Crest Factor

This is set current waveform crest factor. This waveform is used in Constant Current and Constant Power Modes. At reset crest factor is Get Device Caps fMinCrestFactor. Crest factor range is fMinCrestFactor to fMaxCrestFactor.

This command will cause an execution error if the:
Crest factor is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x2F
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.40 Get Crest Factor

This command will return the set crest factor as programmed by the Set Crest factor command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x30
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.41 Set Power Factor

This is set load power factor. This is used in Constant Current and Constant Power Modes. Default power factor is Get Device Caps fMaxPowerFactor. Range is fMinPowerFactor to fMaxPowerFactor. Power factor range varies with crest factor and input voltage waveform. The load will attempt to meet the programmed power factor.

This command will cause an execution error if the:
Power factor is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x31
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.42 Get Power Factor

This command will return the set power factor as programmed by the Set Power factor command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x32
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.43 Set Resistance

This is the set resistance in Constant Resistance Mode. This command places the load in Constant Resistance Mode and enabled as defined by the Load Mode Register. Reset resistance is Get Device Caps fMaxResistance. Range is fMinResistance to fMaxResistance.

This command will cause an execution error if the:
Resistance is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x33
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.44 Get Resistance

This command will return the set resistance as programmed by the Set Resistance command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x34
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.45 Set Power

This is the set power in Constant Power Mode. This command places the load in Constant Power Mode and enabled as defined by the Load Mode Register. Reset power is Get Device Caps fMinPower. Range is fMinPower to fMaxPower.

This command will cause an execution error if the:
Power is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x35
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.46 Get Power

This command will return the set power as programmed by the Set Power command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x36
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.47 Set Voltage

This is the set voltage in Constant Voltage Mode. This command places the load in Constant Voltage Mode and enabled as defined by the Load Mode Register. Reset is Get Device Caps fMaxACVoltage. Range is fMinACVoltage to fMaxACVoltage. The load is put in Constant Resistance Mode and the resistance is varied to keep the voltage constant. The load operates as a shunt regulator.

This command will cause an execution error if the:
Voltage is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x37
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.48 Get Voltage

This command will return the set voltage as programmed by the Set Voltage command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x38
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.49 Wait For Trigger

This message commands the module to wait for a trigger before executing the next queued command.

This command will cause an execution error if the:

Mode is anything except initiate in the Transient Mode Register.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x39
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.50 Set Turn On Voltage

When RMS voltage exceeds this value the load is enabled. Reset is Get Device Caps fMinACVoltage plus 10 volts. Range is Set Turn Off Voltage to Get Device Caps fMaxACVoltage.

If voltage is below the turn off voltage, then a rise to exceed this turn on voltage, a trigger is generated when enabled.

This command will cause an execution error if the:

Voltage is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x3A
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.51 Get Turn On Voltage

This command will return the set turn on voltage as programmed by the Set Turn On Voltage command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x3B
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.52 Set Turn Off Voltage

When RMS voltage is below this value the load is disabled. Reset is Get Device Caps fMinACVoltage. Range is fMinACVoltage to Set Turn On Voltage.

If voltage is above the Set Turn On Voltage, then drops below this Set Turn Off Voltage, a trigger is generated when enabled.

This command will cause an execution error if the:
Voltage is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x3C
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.53 Get Turn Off Voltage

This command will return the set turn off voltage as programmed by the Set Turn Off Voltage command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x3D
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.54 Set Trigger Phase

This is the input voltage phase angle when current will change. Reset is Get Device Caps fMaxTrigPhase, current changes randomly, as soon as possible, and no trigger is generated. If less than fMaxTrigPhase current will change and a trigger is generated, if enabled, on every cycle at that phase angle. Range is fMinTrigPhase to fMaxTrigPhase.

This command will cause an execution error if the:
Phase is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x06
3	Command ID	0x3E
4	Float byte 0 LSB	0xnn
5	Float byte 1	0xnn
6	Float byte 2	0xnn
7	Float byte 3 exponent	0xnn
8	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

8.55 Get Trigger Phase

This command will return the trigger voltage phase angle as programmed by the Set Trigger Phase command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x3F
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x05
3	Float byte 0 LSB	0xnn
4	Float byte 1	0xnn
5	Float byte 2	0xnn
6	Float byte 3 exponent	0xnn
7	Checksum	0xnn

8.56 Store Waveforms

The previous cycle of current, voltage and wattage waveforms are captured and stored. The sample rate and number of samples per cycle are returned for use with the Get Waveform command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x40
5	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x0A
4	Samples rate float byte 0 LSB	0xnn
5	Samples rate float byte 1	0xnn
6	Samples rate float byte 2	0xnn
7	Samples rate float byte 3 exponent	0xnn
8	Number of samples INT32 byte 4 LSB	0xnn
9	Number of samples INT32 byte 5	0xnn
10	Number of samples INT32 byte 6	0xnn
11	Number of samples INT32 byte 7 MSB	0xnn
12	Checksum	0xnn

8.57 Get Waveforms

One cycle of current, voltage or wattage waveforms are returned which may be graphically displayed.

Waveform number 1 is current, 2 is voltage and 3 is watts.

Many packets are required to display one waveform. All packets need not be retrieved and or may be retrieved in any order or interlaced with other commands. The required number of packets is the number of samples, returned by the Store Waveform command, divided by 32 samples per packet. For example, packets number 1-4 are required to display a 128 sample waveform.

This command will cause an execution error if the:

Packet number is out of range.

Waveform number is out of range.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x04
3	Command ID	0x41
4	Waveform Number	0xnn
5	Packet Number	0xnn
6	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x81
3	Sample number 1 float byte 0 LSB	0xnn
4	Sample number 1 float byte 1	0xnn
5	Sample number 1 float byte 2	0xnn
6	Sample number 1 float byte 3 exponent	0xnn
...
127	Sample number 32 float byte 124 LSB	0xnn
128	Sample number 32 float byte 125	0xnn
129	Sample number 32 float byte 126	0xnn
130	Sample number 32 float byte 127 exponent	0xnn
131	Checksum	0xnn

8.59 Read Configuration Data

This command is used to read configuration data. The first float is the voltage gain calibration factor. The second float is the current gain calibration factor. Data bytes 0 – 127 are returned as written by the Write Configuration Data command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x02
3	Command ID	0x43
4	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn

Byte	Description	Value
1	Source address	0xnn
2	Count	0x88
3	Voltage gain float byte 0 LSB	0xnn
4	Voltage gain float byte 1	0xnn
5	Voltage gain float byte 2	0xnn
6	Voltage gain float byte 3 exponent	0xnn
7	Current gain float byte 0 LSB	0xnn
8	Current gain float byte 1	0xnn
9	Current gain float byte 2	0xnn
10	Current gain float byte 3 exponent	0xnn
11	Configuration Data byte 0	0xnn
12	Configuration Data byte 1	0xnn
13	Configuration Data byte 2	0xnn
...	Configuration Data byte n	0xnn
138	Configuration Data byte 127	0xnn
139	Checksum	0xnn

9. REGISTER DESCRIPTION

9.1 Event Status Register

Bit	Name	Description
0	Hardware Fault	A hardware fault (overtemp, overpower, no share) caused the hardware to shutdown. This bit is cleared by a hardware reset, clear error, reset and selftest commands after the fault is removed.
1	Device Specific Error	A device specific operation generated an error. Device specific errors also set bits in error registers. Hardware reset, clear error, reset and selftest clear this bit commands.
2	Command in progress	0 - all commands have totally finished execution, including any metering and transients. 1 - a command is in process. When a command is removed from the input buffer for parsing, this bit is set.
3	Operational Error	Parameters are out of range.
4	Not used	
5	Not used	
6	Not used	
7	Not used	

9.2 Hardware Fault Register

Bit	Name	Description
0	Over Temperature	A heatsink has exceeded rated temperature.
1	Over Power	Input power has exceeded rated limits.
2	No Share	Power transistors are not sharing.
3	Not used	
4	Not used	
5	Not used	
6	Not used	
7	Not used	

9.3 Selftest Error Register

Bit	Name	Description
0	EPROM	Executing firmware from ERPOM.
1	Firmware	Firmware checksum error.
2	Calibration	Calibration and configuration data checksum error.
3	RAM	RAM test failed.
4	Not used	
5	Not used	
6	Not used	
7	Not used	

9.4 Device Error Register

Bit	Name	Description
0	Checksum	Command checksum error.
1	Command	Command is not recognized.
2	Input buffer	Input buffer overrun.
3	Execution	Set parameter is out of range or can not be executed.
4	Not used	
5	Not used	
6	Not used	
7	Not used	

9.5 Operational Error Register

Bit	Name	Description
0	Under Frequency	Frequency is too low.
1	Over Frequency	Frequency is too high.
2	Under Voltage	Voltage is too low.
3	Over Voltage	Voltage is too high.
4	Power Factor	Power factor is out of range.
5	Over Current	Current is too high.
6	Not used	
7	Over Power	Power is too high.

9.6 Command Mode Register

Bit	Name	Description
0	SOA	The module is in send own address mode. This mode is used at startup by the control PC to determine the number and type of S6000 modules connected to the communication port.
1	Download	The FLASH memory is being updated.
2	Debug	Enables commands that can write directly to hardware potentially damaging unit.
3	Transient	Transient Initiate Mode. Set type commands will be queued not executed. Other commands are executed normally.
4	Not used	
5	Not used	
6	Not used	
7	Not used	

9.7 Load Mode Register

Bit	Name	Description
0	Not Used	
1	Not Used	
2, 3	Power Factor	00 – Crest Factor Priority. Crest Factor and Power Factor are Programmable. See section 6.12 Crest Factor and Power Factor Relationship. 01 – Power Factor Priority. Changes Crest Factor to obtain desired Power Factor without phase shifting current. Programmable Crest Factor and does not apply. More closely emulates a power supply type load. 10 – Unity Power Factor. Forces highest power factor. Programmable Crest Factor and Power Factor do not apply. Allows Constant Current and Constant Power to be programmed correctly with non-sinusoidal input voltages. 11 – Reserved
4, 5, 6	Mode	000 - Off 001 - Constant Current 011 - Constant Power 100 - Constant Resistance 110 - Constant Voltage
7	Short	Short with SCR.

9.8 Measurement Mode Register

Bit	Name	Description
0	Next	0 - the last several measurements made are averaged and returned. This may be up to 2 cycles old, but is returned immediately. 1 - Next, a new measurement is made and returned. This may take as long as 2 cycles.
1	Peak	0 - resets peak measurements each cycle. 1 - saves largest peak measurements.
2	Not Used	
3	Not Used	
4	Not Used	
5	Not Used	
6	Not Used	
7	Not Used	

9.9 Transient Mode Register

Bit	Name	Description
0 & 1	Mode	00 - No transient operation. 01 - Initiate. Set type commands will be queued, but the module output is not modified until it is armed and it receives a trigger signal. 10 - Armed. The module is waiting for a trigger signal to execute the next command(s) previously queued. When all queued commands have been executed, returns to no transient operation. 11 - Continuous. Same as armed except when all queued commands have been executed, restarts at beginning of queue.
2	Enable Output	The module will generate trigger outputs.
3	Trigger Output	0 - When enable output is 0. 1 - Latched with each trigger event, reset after read.
4	Trigger Input	Hardware trigger input enabled.
5	Voltage Input	Turn on/off voltage trigger enabled.
6	Phase Angle	Phase angle trigger enabled.
7	Queue Full	The transient command queue is full.

10. TROUBLE SHOOTING

10.1 Load Power Circuit Breaker Trips

This circuit breaker will trip when:

Input current is exceeded during short mode. Reduce short circuit current.

The over voltage protection crowbar turned on. Reduce input voltage.

The diode bridge or power transistor array has shorted. Return for repair.

10.2 Fault Lamp Lit

This lamp is lit when one of the following hardware faults has occurred:

Overtemperature, one of the 4 load boards has overheated. Allow more and cooler air to flow through the load. If the load is clogged with dirt, vacuum the dirt out.

Overpower, the hardware analog multiplier detected an average true power greater than rated input power. The remote sense wires may not be connected correctly and the DSP cannot calculate power correctly. The load may need to be calibrated.

No share, the load boards are not sharing power equally. A load board may be shorted or an internal wiring error. Return for repair.

When the hardware fault has been removed and clear errors command is issued, the lamp will go out.

10.3 Status Lamp Not Blinking

Verify that the control power switch/lamp is on and lit. This indicates control power is present at the control board.

If control power is present and the status lamp is not blinking at a 1 hertz rate, the DSP is not functioning properly.

Try switching all eight positions of the "S6k AD" switch to the off position. Remove and reapply control power. This will cause a reboot from EPROM. If the status lamp is still not blinking, return for repair.

8.58 Write Configuration Data

This command is used to store configuration data in SRAM. The configuration data is NOT written into FLASH. The configuration data may be written to FLASH with the Write Calibration Factors command, after this command.

Command:

Byte	Description	Value
1	Destination address	0xnn
2	Count	0x81
3	Command ID	0x42
4	Data byte 0	0xnn
5	Data byte 1	0xnn
6	Data byte 2	0xnn
...	Data byte n	0xnn
131	Data byte 127	0xnn
132	Checksum	0xnn

Response:

Byte	Description	Value
1	Acknowledge byte	0xnn


```
#####
#####
##
##          NH Research CD-ROM Installation and Setup      ##
##
#####
#####
```

This CD-ROM contains one or more of the following:

- o On-line documentation
- o NH System Software
- o NH Instrumentation Software

What is on this CD is dependent upon which System or Software you have purchased.

As with all software installations, you should backup your system and data files prior to installing any of the software on this CD.

Please refer to the appropriate sections below for installation instructions.

NOTE:

In the following instructions, "D:" refers to the CD-ROM drive. If your CD-ROM drive is NOT "D:", please substitute the appropriate letter for "D:" in all instructions below.

```
=====
General Installation Instructions
=====
```

Most of the software contained on this CD are installed as described in this section. You should, however, look through this entire document to see if there are special installation requirements for the software you are installing.

```
-----
INSTALLATION FROM WINDOWS 3.1x
-----
```

- 1) From the Program Manager, select the file menu and choose RUN. Type "D:\SETUP" and press enter.
- 2) Follow the on-screen instructions.

```
-----
INSTALLATION FROM WINDOWS 95/NT 4.x
-----
```

- 1) Select the Start button then choose RUN. Type "D:\SETUP" and press enter.
- 2) Follow the on-screen instructions.

```
=====
MAKING INSTALLATION FLOPPY DISK SETS
```

=====
Normally, the software contained on this CD is installed directly from the CD. However, if you need to, you may make floppy based installation disk sets by performing the following procedure:

- 1) At a DOS prompt type "D:" and press enter to change the current path to the CD-ROM drive.
- 2) Type "CD \SW\190xxxx" (substitute the desired part number for 190xxxx) and press enter to change the current path to the software directory.
- 3) Type "DIR" to see a list of files and directories.
- 4) Have enough blank formatted floppies available (one for each sub directory call DISKn).
- 4) Type "nDISK2A.BAT" (where n is number of disks) and follow the directions on the screen.

=====
On-line Documentation
=====

The On-line documentation is in PDF format and can be viewed with Adobe Acrobat Reader software. The Adobe software is provided on this CD and can be installed along with the On-line documentation.

The On-line documentation and reader is WINDOWS, WINDOWS 95, and WINDOWS NT compatible. It will NOT run under DOS.

=====
Notebook System Software
=====

The Notebook System Software may be installed directly from this CD, or you may create a floppy disk set and install from it.

Detailed computer setup instructions (as well as Notebook installation instructions) can be found in NHR document #09-0224a (Windows 3.1x) and #09-0224b (Windows 95).

=====
PowerFlex 5x5 System Software
=====

The PowerFlex 5x5 System Software is DOS based and MUST be installed from DOS.

You may install directly from CD or you may create a floppy disk set and install from it.

!!!!!!! WARNING !!!!!!!

Installed from Win3.XX environment, the installation process for PowerFlex will REPLACE your CONFIG.SYS and your AUTOEXEC.BAT during installation. The installation program will back up your current CONFIG.SYS and AUTOEXEC.BAT and report what name it saved them as (Usually *.NHR). If you need some of the features (device drivers, environment settings, etc.) of your current CONFIG.SYS or AUTOEXEC.BAT, you will need to manually edit the files to include what you need from both the newly installed files and the backed-up versions.

Installed from the Win95 GUI environment, if the installation program detects AUTOEXEC.DOS or CONFIG.DOS, the installation program will back up your current CONFIG.DOS and AUTOEXEC.DOS and report what name it saved them as (Usually *.NHR). If you need some of the features (device drivers, environment settings, etc.) of your current CONFIG.DOS or AUTOEXEC.DOS, you will need to manually edit the files to include what you need from both the newly installed files and the backed-up versions.

Installed from the Win95 DOS environment, (from floppies) the installation process for PowerFlex will REPLACE your CONFIG.SYS and your AUTOEXEC.BAT during installation. The installation program will back up your current CONFIG.SYS and AUTOEXEC.BAT and report what name it saved them as (Usually *.NHR). If you need some of the features (device drivers, environment settings, etc.) of your current CONFIG.SYS or AUTOEXEC.BAT, you will need to manually edit the files in the Win95 DOS environment to include what you need from both the newly installed files and the backed-up versions.

INSTALLATION DIRECTLY FROM CD-ROM

- 1) At the DOS prompt (not a DOS shell) type "D:\INSTALL D:" and press enter.
- 2) Follow the on-screen instructions.
- 3) Edit the AUTOEXEC.BAT and CONFIG.SYS files to add necessary features of the previous versions. See WARNING above.

UNINSTALLING POWERFLEX SOFTWARE

- 1) At the DOS prompt type "C:" (or whatever drive PowerFlex was installed onto) and press enter to change the current path to the PowerFlex installation drive.
- 2) Type "CD \" and press enter to change the current path to the root directory.
- 3) Type "SUBST J: /D" and press enter to remove the DOS drive substitution for "J:".

- 4) Type "SUBST L: /D" and press enter to remove the DOS drive substitution for "L:".
- 5) Type "SUBST M: /D" and press enter to remove the DOS drive substitution for "M:".
- 6) Type "DELTREE PWFLEX" and press enter to remove the PWFLEX directory and all its subdirectories.
- 7) Type "DELTREE PFLEX" and press enter to remove the PFLEX directory and all its subdirectories.
- 8) Type "DEL PWFLEX.CFG" and press enter to remove the config file.
- 9) Restore the AUTOEXEC.BAT and CONFIG.SYS files from the previously backed up files (usually named AUTOEXEC.00x and CONFIG.00x). For example:
 - Type "COPY AUTOEXEC.002 AUTOEXEC.BAT" and press enter.
 - Type "COPY CONFIG.002 CONFIG.SYS" and press enter.

=====
PowerFlex DOS System Software
=====

The PowerFlex DOS System Software may be installed directly from this CD, or you may create a floppy disk set and install from it.

INSTALLATION DIRECTLY FROM CD-ROM

If you are installing from Windows 3.1x:

- 1) From the Program Manager, select the file menu and choose RUN. Type "D:\SETUP" and press enter.

-or-

If you are installing from Windows 95:

- 1) Select the Start button then choose RUN. Type "D:\SETUP" and press enter.
- 2) Setup will run the NH Research Master Installation program. Press the button labeled "Install PowerFlex DOS" and follow the on-screen instructions.
- 3) If the Master Installation program indicates that there is a Installation Update for DOS Diagnostics on the CD, run the update program by pressing the button labeled "Install Installation Update for DOS Diagnostics". It is important that this update be installed AFTER the PowerFlex DOS installation. This program runs with no operator intervention.

TECHNICAL NOTE: 08-0383 Rev B
DATE: 08/25/99
SUBJECT: MODEL 4600 AC LOAD SETUP.

This technical note describes the setup of the SOFTWARE and HARDWARE of the MODEL 4600 AC LOAD.

SOFTWARE SETUP.

IMPORTANT:

The AC Load software can only be installed on the following operating systems:

- Windows 95 with Internet Explorer 4 or later installed.
- Windows 98
- Windows 98 SE
- Windows NT 4 with service pack 3 or later

The AC Load software CANNOT be installed on Windows 2000.

1. Close all programs that are currently running in windows. Insert the CD into the drive and view contents of disk and double click on Setup to start installation. Follow the instructions on the screen.
2. During setup, the Port Configuration Utility will be displayed. You must configure the port that your AC Load is connected to.
 - Click the "New" button and select the com port that will be used for the AC Load.
 - Verify that the I/O address and IRQ selected is correct for your port. They should be correct for Com1 and Com2, but Com3 and up are not standardized so consult with your PC documentation.
 - Select the correct protocol for your AC Load. This will be either "S6K type at 19200 bps" or "S6K type at 38400 bps" depending on the baud rate that your AC Load is set to. The default is "S6K type at 19200 bps".

HARDWARE SETUP REAR PANEL CONNECTIONS.

1. Connect Control Power Input plug this supplies power to the fans and control circuits. Check label at rear panel for your power requirements 115VAC or 230VAC.
2. Connect Load Power Input connector, the voltage sense wires are also located on this connector. The voltage sense must be connected to the load wires either at this connector or at the source. The load will not operate with these voltage sense wires disconnected. It will generate an undervoltage error.

3. Connect the RS232 cable at the rear of the load. This cable will mate with a PC compatible nine pin RS232 port if a one to one four wire cable is used.
4. For connector pin outs and any additional information please refer to user manual P/N 09-0237.