DUAL BAND REMOTE KIT / DUAL BAND DUAL CONTROL HEAD KIT

KRK-7DB/8DBH

SERVICE MANUAL

### REVISED EDITION

KENWOOD

KRK-7DB

Panel
(A62-0608-02) x 2

Angle bracket
(J29-0648-03)

Rear panel
(A82-0031-02)

Cover
(F07-1479-03) x 2

Trunk cable
(E30-3328-05)

Cap
(B09-0393-04)

Mounting hardware
(J21-4354-04) x 4

Dressed screw
(N08-0526-04) x 4

KRK-8DBH

Panel
(A62-0608-02) x 2

Angle bracket
(J29-0648-03) x 2

Rear panel
(A82-0031-02) x 2

Cap
(B09-0393-04) x 2

Cover
(F07-1479-03) x 2

Trunk cable
(E30-3328-05)

Mounting hardware
(J21-4354-04) x 4

Dressed screw
(N08-0526-04) x 4

There is a mistake in the installation section of
Service Manual KRK-7DB/8DBH (B51-8452-00).
The revised sections are on page 2, numbers 1-3
Display assembly (Fig. 3), and on page 5, number 3 Other Modification (Fig. 8).
This Service Manual (B51-8452-10) provides revised information for those sections.

KRK-7DB/8DBH

INSTALLATION

Readers are requested to make the corrections as follows.

1-3. Display assembly (Fig. 3)

The following steps apply to both the KCH-10 and the KCH-11.

1. Remove the three screws (❶) on the rear panel of the head, then remove the sub panel.
2. Connect connector W102 from the head to CN1 of the display unit (❷).
3. KCH-10 : Connect connector W103 from the head to CN3 of the display unit (❸).
   KCH-11 : Connect connector W103 from the head to CN2 and CN3 of the display unit.
4. Make a slight cut in the end of the rubber cap (❹).
5. Slide the lead wire of the connector wiring (❺) through the slit in the rubber cap (❻).
6. Insert the rubber cap into the hole in the rear panel (❼) (Follow the arrow in the diagram.)
7. Attach the connector (❽) to the ACC connector (❾) on the sub panel as shown by the arrow (❿).
8. Install the head sub panel onto the display unit sub panel (⓫).
   Note : Insert the head sub panel into the display unit sub panel.
9. Connect the sub panel to the display unit with the four screws (N32-3006-46) (⓬).
10. Install the head with the three screws that were removed in step 1.
11. Use a wire band to secure the lead wire at the end of the rubber cap (⓭).

3. Other Modification

3-1. Connection with the remote kit

When the KRK-7DB or KRK-8DBH is used, set chip resistors as shown in the table below.

	KRK-7DB	KRK-8DBH
Radio 1	Unnecessary	Unnecessary
Radio 2	1) Remove R546	1) Remove R546
	2) Remove R661	2) Remove R661
	3) Move R602 to R705	3) Move R602 to R705
		4) Remove Q515✳
		5) Jumper to Q503 and Q514✳

✳ : TK-690H unnecessary
The TK-790/790(B)/790H(B) and TK-890/890(B)/890H(B) serial numbers from 011XXXXX are unnecessary

3-2. Modification

1. Remove the upper half of the case of the TK-690H/790/890.
2. Set R546, R661, R602, and R705 on the control unit (X57 B/3) according to the table.
3. Remove Q515 and jumper to Q503 and Q514 according to the figure 8.
4. Reinstall the upper half of the case.

Fig. 3

Fig. 8

KENWOOD CORPORATION

14-6, Dogenzaka 1-chome, Shibuya-ku, Tokyo 150-8501, Japan