



Caution: L19/L39 Inner Conductors

The inner conductors of L19 and L39 are silver wire and are very fragile. Take care not to damage them when desoldering and lifting them off the pads.

When resoldering, make sure each inner conductor curves onto the pad (as shown in the drawing) to protect it from thermal stress or shorts. Do not pull the wire tight.

Figure 4.1 T858/859 Test Break Point Location

