

# Orca 5000 Trunked Menu Operation

LAYER ONE



SP

IF A PRESET CALL IS ASSIGNED TO YOUR CURRENT POSITION ON THE 16-WAY SELECTOR THIS WILL INITIATE THAT CALL



LP or



SP OR LP JUMPS BACK ONE MENU LAYER.  
E.G. IF IN SELECT SITE (LAYER THREE) ONE PRESS OF THIS KEY WILL CAUSE THE RADIO TO SWITCH TO ADVANCED SETTINGS (LAYER TWO)



USE LEFT AND RIGHT SCROLL ARROWS TO MOVE BACKWARDS AND FORWARDS WITHIN A MENU LAYER OR TO JUMP TO THE BEGINNING OR END OF THE NEXT MENU LAYER.



A LP OF THE MENU, ANYWHERE OTHER THAN "NORMAL OPERATIONAL MODE" RESULTS IN THE RADIO JUMPING BACK TO NORMAL OPERATIONAL MODE.


LP = LONG PRESS

SP = SHORT PRESS

LAYER TWO



LAYER THREE



LAYER FOUR

USE KEYS TO SELECT UP TO 30 STATUS CALLS



TOGGLES FEATURE ON & OFF



TOGGLES FEATURE ON & OFF OR HIGH & LOW

TOGGLES FEATURE ON & OFF



USE KEYS TO INCREASE OR DECREASE LCD CONTRAST

USE KEYS TO SELECT DESIRED CONTROL CHANNEL



USE KEYS TO SELECT DESIRED NETWORK

