

Part H T800 Ancillary Equipment

This part of the manual gives a brief description of the ancillary equipment and accessory kits available for use with T800 series base station equipment.

Section	Page
T318-02 Receiver/Transmitter Monitor	1
T708-91/92 Mains Power Supplies	1
T800-01-001 Programming Kit	1
T800-02 CTCSS Dencoder	1
T800-03 Auxiliary D-Range	2
T800-04 RSSI	2
T800-05 Guide Rail	2
T800-06 External Frequency Reference Kit	2
T800-07 Multichannel Kit	2
T800-10 Memory Module	2
T800-13 Extender Rail	3
T800-14 Extender Rail	3
T800-15 Speaker Panel	3
T800-16 Speaker Panel (formerly T359-01)	3
T800-19 Rack Mounting Fan	3
T800-20 Pre-wired Rack	3
T800-21 Pre-wired Rack With Interface PCB	3
T800-30 & T800-35 DFSK Modulators	4
T800-60 Slimline Repeater Mounting Kit	4
T800-80 Local Microphone	4
T800-81 Narrow Band Conversion Kit	4
T800-82 Narrow Band Conversion Kit	4
T800-83 Narrow Band Conversion Kit	4
T800-84 Narrow Band Conversion Kit	4
T801 Frequency Reference Module	5
T801-10 OCXO Module	5
T802-00 Remote Monitor	5
T802-10 RF Splitter	5
T802-20 Modem & Programming Kit	5
T802-21 Programming Kit	6

Section	Page
T802-22 Modem	6
T806 Mains Power Supply	6
T807 Mains Power Supply	6
T808 Mains Power Supply	6
T1500-50 Trunking Extra D-Range (formerly T800-50)	6
T1500-51 Trunking Transmitter Interface (formerly T800-51)	7
KS820 Spares Kit	7
KS830 Spares Kit	7
KS850 Spares Kit	7
KS880 Spares Kit	7