M820-00

Part D T828 Power Amplifier

This part of the manual is divided into five sections, as listed below. There is a detailed table of contents at the start of each section.

Section	Title
1	General Information
2	Circuit Operation
3	Initial Adjustment
4	Fault Finding
5	PCB Information

Copyright TEL 30/04/96

DII M820-00

30/04/96 Copyright TEL