



SP-200 DIFFERENT COMPONENT:

PART NO	R24	R25	R36	R38	R40	R59	R62	R64	R65	R69	R68	R70	T1	L2	C37	C38	C39	C40	C42	C43	C51	D19	D20	J1,J2	J3,J4	ZD10	ZD11	C29	ZD2	ZD9	R63
3.3V	6.8 /1/2W	22 /2W	22 /2W	470 /1/4W	430	1K	20K	1K	7K5	240	820	TF608	TR153		224 50V	103 /500V	330u /25V	1000u /16V	2200u /10V	682 100V	S30SC4M	JUMP	JUMP	JUMP	4.2V	221 /1KV	P6KE 220A	300			
5V	10 /1/2W	39 /2W	39 /2W	560 /1/4W	2K	10K	20K	1K	7K5	220	1K5	TF609	TR101		224 50V	472 /500V	330u /25V	1000u /16V	2200u /10V	472 100V	S30SC4M	JUMP	JUMP	JUMP	5.4V	221 /1KV	P6KE 220A	300			
7.5V	10 /1/2W	75 /2W	75 /2W	1K /1/4W	3K9	33K	20K	1K	3K3	220	1K5	TF610	TR177		224 50V	102 /500V	330u /25V	2200u /10V	2200u /10V	102 100V	C25P06Q	JUMP J4:X	JUMP	JUMP	8.3V	X	P6KE 200A	JUMP			
12V	12 /1/2W	180 /2W	180 /2W	2K /1/4W	10K	9K1	10K	1K	3K3	200	2K2	TF611	TR143		472 100V	102 /1KV	82u /25V	1000u /25V	2200u /10V	682 100V	D9202	JUMP J3.4:X	JUMP	JUMP	13.8V	X	P6KE 200A	JUMP			
13.5V	12 /1/2W	270 /2W	270 /2W	2K7 /1/4W	10K	43K	10K	1K	1K8	162	1K8	TF612	TR080		682 100V	471 /1KV	1000u /25V	1000u /25V	102 100V	D9202	JUMP J3.4:X	JUMP	JUMP	16.1V	X	P6KE 200A	JUMP				
15V	15 /1/2W	270 /2W	270 /2W	2K7 /1/4W	12K	100K	10K	1K	1K2	150	2K	TF613	TR062		682 100V	471 /1KV	82u /25V	1000u /25V	102 100V	D9202	JUMP J4.4:X	JUMP	JUMP	18V	X	P6KE 200A	JUMP				
24V	22 /1/2W	820 /2W	820 /2W	4K7 /1/4W	22K	100K	22K	1K	1K8	180	2K2	TF614	TR146		222 100V	471 /1KV	10u /50V	330u /35V	330u /35V	102 100V	D9202	JUMP D19:X	JUMP J2.3.4:X	JUMP	JUMP	30V 1W	X	P6KE 200A	JUMP		
27V	22 /1/2W	820 /2W	820 /2W	5K1 /1/4W	20K	100K	22K	680	1K8	162	1K8	TF615	TR146		222 100V	471 /1KV	10u /50V	330u /35V	330u /35V	222 100V	D9202	JUMP D19:X	JUMP J2.3.4:X	JUMP	JUMP	7.1V	27V 1W	P6KE 200A	JUMP		
48V	47 /1/2W	2K7 /2W	2K7 /2W	9K1 /1/4W	56K	200K	22K	560	2K	100	2K7	TF616	TR178		222 100V	221 /1KV	100u /25V	220u /63V	220u /63V	102 100V	C16P40F D19:X	JUMP J2.3.4:X	JUMP	JUMP	30V 1W	30V 1W	P6KE 200A	JUMP			