



Location of Label as limit for speaker movement.
[365-01717-01 or any equivalent sized Front Panel label]



Fit label into groove with adhesive side facing towards Keypad. Position it so that it label rests in the bottom of the groove. Use a blunt instrument such as an iceblock stick to press the adhesive onto the curved face of the outer speaker ring. The label will sit approx 1.5 to 2mm above the outer speaker ring.



Tait Electronics Ltd. 8th November 2004.

Instructions for fitting label to limit speaker movement for TM8100 Front Panel 316-06786-01.

Once the 316-06786-02 version of the Front Panel (with extra walls on the outer speaker ring) is introduced then this addition of this label is to be discontinued.

Brent Drysdale.