

# KENWOOD


## **Document Copyrights**

Copyright 2006 by Kenwood Corporation. All rights reserved.

No part of this manual may be reproduced, translated, distributed, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, for any purpose without the prior written permission of Kenwood.

## **Disclaimer**

While every precaution has been taken in the preparation of this manual, Kenwood assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein. Kenwood reserves the right to make changes to any products herein at any time for improvement purposes.

**OVERVIEW**

LMR handy transceiver speaker microphone

**FEATURE**

- Has an EXT. SP jack that mates with a 2.5mm diameter mono plug. This jack comes with a cap.
- Equipped with a 360 degree rotary clip of click type.

**SPECIFICATIONS**

## Microphone

Nominal impedance .....	1.9k $\Omega$
Nominal sensitivity .....	-57dB $\pm$ 5.5dB at 300Hz

## Speaker

Nominal impedance .....	8 $\Omega$
Specification input .....	0.6W
Maximum input .....	1.5W
Dimensions [W x H x D] ( ) : Including projections .....	56 x 78.5 (93.5) x 25.8 (39) mm
Weight (Including curl cord) .....	Approx. 0.12kg

