

Driver Installation

Download and extract the drivers to a convenient location that you can get to on your computer.

Windows XP

1. Plug the MFJ-226 USB cable in. The Plug and Play routine for installing the device should display a message that it found a new device and then open up a dialog box asking if you want to install the drivers. It is possible that the computer knows where the drivers are and installs them automatically.
2. In the first dialog box select "No not this time"
3. In the second dialog box select "Install from specific location"
4. In the third dialog box select "Search for the best driver" and also select "Include this location in the search" and click on the Browse button to browse to the location of the drivers. Then click NEXT.
5. The drivers should install and a message that the device is ready to use should appear.

Windows 7

1. Plug in the MFJ-226 to the USB port. The plug and play routine should find the device. If the drivers are available through Microsoft then it should install and come up with a message that it is ready to use.
2. If the drivers are not available, then an error message should come up saying that the device has problems. If this is the case then continue with these install instructions.
3. Open the Control Panel and in the Devices and Printers program under Unspecified section the MFJ-226 should show up with a yellow triangle and exclamation point in it should be listed.
4. Double click on the device and select the hardware tab.
5. Click on the Properties button.
6. Click on the Update Driver button.
7. In the "Search for the driver software in this location" click on the Browse button and browse to the location of the driver and select it. Then click Next.
8. The driver should install and a message that the device is ready to use.

Windows 8

1. Plug in the MFJ-226 to the USB port. The plug and play routine should find the device. If the drivers are available through Microsoft then it should install and come up with a message that it is ready to use.
2. **To manually install** the drivers swipe in from the right edge of the screen, and then tap or click Search.
3. Enter Device Manager in the search box, and tap or click Device Manager.
4. In the list of hardware categories, double-tap or double-click the category your device is in and then double-tap or double-click the device you want.
5. Tap or click the Driver tab, tap or click Update Driver, and then follow the instructions. You might be asked for an admin password or to confirm your choice.
6. The driver will install and be ready for use.