

Part F Installation

This part of the manual is divided into the sections listed below. These sections give a brief description of the basic rack mounting and wiring procedures for the T835 receiver, T836 transmitter, T837 exciter and T838/839 power amplifiers.

Section	Title	Page
1	T835 Installation	1.1
1.1	Rack Mounting	1.1
1.2	Rack Wiring	1.1
1.3	Power Supply	1.2
1.4	Reverse Polarity & Overvoltage Protection	1.2
2	T836/837 Installation	2.1
2.1	Rack Mounting	2.1
2.2	Rack Wiring	2.1
2.3	Power Supply	2.2
2.4	Reverse Polarity & Overvoltage Protection	2.2
3	T838/839 Installation	3.1
3.1	Rack Mounting	3.1
3.2	Rack Wiring	3.1
3.3	Power Supply	3.2
3.4	Reverse Polarity & Overvoltage Protection	3.2
4	N-Type Connector Assembly	4.1

Figure	Title	Page
1.1	T800-41-0002 Double Guide Kit	1.1
1.2	T835 Chassis Connectors	1.1
1.3	T835 D-Range 1 Wiring - Rear View	1.1
1.4	T835 D-Range 2 Wiring - Rear View (T800-03-0000 Kit)	1.1
2.1	T800-41-0002 Double Guide Kit	2.1
2.2	T836/837 Chassis Connectors	2.1
2.3	T836/837 D-Range 1 Wiring - Rear View	2.1
2.4	T836/837 D-Range 2 Wiring - Rear View (T800-03-0000 Kit)	2.1

Figure	Title	Page
3.1	T800-45-0001 PA Guide Kit	3.1
3.2	T838/839 Chassis Connectors	3.1
3.3	T838/839 PA In Latched Position	3.1
3.4	T838/839 D-Range Wiring - Rear View	3.1
4.1	N-Type Plug Assembly Details	4.1