

T2000 Series II Service Manual

Issue 301

March 1998

M2000-00-301



Head Office New Zealand

Tait Electronics Ltd
558 Wairakei Road
P.O. Box 1645
Christchurch
New Zealand
Phone: 64 3 358-3399
Fax: 64 3 358-3636

Australia

Tait Electronics (Aust) Pty Ltd
275 Toombul Road
Northgate 4013
P.O. Box 679
Virginia
Queensland 4014
Australia
Phone: 61 7 3865-7799
Toll Free: 1 300 304-344
Fax: 61 7 3865-7990
E-mail: helpdesk@tait.com.au

Canada

Tait Mobile Radio Inc.
Unit 5, 158 Anderson Avenue
Markham
Ontario L6E1A9
Canada
Phone: 1 905 472-1100
Fax: 1 905 472-5300
E-mail: 110252.44@compuserve.com

France

Tait France S.A.R.L.
2 avenue de la Cristallerie
92 316 Sèvres, Cedex
France
Phone: 33 1 41 14-05-50
Fax: 33 1 41 14-05-55
E-mail: 100675.651@compuserve.com

Germany

Tait Mobilfunk GmbH
Willstätterstraße 50
D-90449 Nürnberg 60
Germany
Phone: 49 911 967-460
Fax: 49 911 967-4679
E-mail: tait@t-online.de

Hong Kong

Tait Mobile Radio (Hong Kong) Ltd
Room 703A New East Ocean
Centre
9 Science Museum Road
Tsim Sha Tsui East
Hong Kong
Phone: 852 2369-3040
Fax: 852 2369-3009
E-mail: 106122.2060@compuserve.com

New Zealand

Tait Communications Ltd
Unit 4, 75 Blenheim Road
P.O. Box 1185
Christchurch
Phone: 64 3 348-3301
Fax: 64 3 343-0558
E-mail: nsc@tcl.tait.co.nz

Singapore

Tait Electronics (Far East) Pte Ltd
4 Leng Kee Road
SIS Building #05-11A
Singapore 159088
Phone: 65 471-2688
Fax: 65 479-7778
E-mail: taitffe@singnet.com.sg

Taiwan

Tait Mobile Radio (Taiwan) Ltd
1104, 142 Chung Hsiao E Rd
Sec 4
Taipei
Taiwan
Phone: 886 2 2731-1290
Fax: 886 2 2711-6351
E-mail: tait8503@ms7.hinet.net

Thailand

Tait Mobile Radio Ltd
14/1 Suwan Tower, Ground Floor
Soi Saladaeng 1
North Sathorn Rd
Bangrak
Bangkok 10500
Thailand
Phone: 662 267-6290
Fax: 662 267-6293
E-mail: taitthd@loxinfo.co.th

United Kingdom

Tait Mobile Radio Ltd
Ermine Business Park
Ermine Road
Huntingdon
Cambridgeshire PE18 6YA
United Kingdom
Phone: 44 1480-52255
Fax: 44 1480-411996
E-mail: techsupport@tait.co.uk

USA

Tait Electronics (USA) Inc.
9434 Old Katy Road
Suite 110
Houston
Texas 77055
USA
Phone: 1 713 984-8684
Toll Free: 1 800 222-1255
Fax: 1 713 468-6944
E-mail: tech@taitus.com

About This Manual

Scope This manual contains general, technical and servicing information on T2000 Series II mobile two-way radios.

Format We have published this manual in a ring binder so that “revision packages” containing additional information can be added as required.


Revision Packages Revision packages will normally be published to coincide with the release of information on a new PCB, and may also contain additions or corrections pertaining to other parts of the manual.

If you return the customer registration card at the front of this manual, you will be notified when revision packages containing new PCB information and/or text are available. You may then order as many packages as you require from your local Tait Company. Revision packages are supplied ready-punched for inclusion in your manual.

Revision Control Each page in this manual has a date of issue. This is to comply with various Quality Standards, but will also serve to identify which pages have been updated and when. Each page and its publication date is listed in the “List of Effective Pages”, and a new list containing any new/revised pages and their publication dates will be sent with each revision package.

Any portion of text that has been changed is marked by a vertical line (as shown at left) in the outer margin of the page. Where the removal of an entire paragraph means there is no text left to mark, an arrow (as shown at left) will appear in the outer margin. The number beside the arrow will indicate how many paragraphs have been deleted.

The manual issue and revision status are indicated by the last three digits of the manual product code. These digits start at 100 and will increment through 101, 102, 103, etc., as revision packages are published, e.g:



Thus, Issue 301 indicates the first revision to issue 3, and means that one package should have been added to the manual. The issue digit will only change if there is a major product revision, or if the number of revision packages to be included means that the manual becomes difficult to use, at which point a new issue manual will be published in a new ring binder.

PCB Information PCB information is provided for all current issue PCBs, as well as all previous issue PCBs manufactured in production quantities, and is grouped according to PCB. Thus, you will find the parts list, grid reference index (if necessary), PCB layouts and circuit diagram(s) for each individual PCB grouped together.

Errors

If you find an error in this manual, or have a suggestion on how it might be improved, please do not hesitate to contact the Technical Writer, Product Support Group, Tait Mobile Radio Division, Tait Electronics Ltd, P.O. Box 1645, Christchurch, New Zealand.

Technical Information

Any enquiries regarding this manual or the equipment it describes should be addressed in the first instance to your nearest approved Tait Dealer or Service Centre. Further technical assistance may be obtained from the Product Support Group, Tait Mobile Radio Division, Tait Electronics Ltd, Christchurch, New Zealand.

Updating Equipment And Manuals

In the interests of improving performance, reliability or servicing, Tait Electronics Ltd reserve the right to update their equipment and/or manuals without prior notice.

Copyright

All information contained in this manual is the property of Tait Electronics Ltd. All rights are reserved. This manual may not, in whole or part, be copied, photocopied, reproduced, translated stored or reduced to any electronic medium or machine readable form without prior written permission from Tait Electronics Ltd.

Ordering Tait Service Manuals

Service Manuals should be ordered from your nearest Tait Branch or approved Dealer. When ordering, quote the Tait product code and, where applicable, the version.

Date Of Issue

M2000-00-300 T2000 Series II Service Manual
Issue 300 published January 1997
Issue 301 published March 1998

List Of Effective Pages

The total number of pages in this Manual is 484, as listed below.

Page	Issue Date		
		2.18	31/10/96
		2.19	31/10/96
1	31/12/97	2.20	blank
2	31/12/97	3.1	31/12/97
3	31/10/96	3.2	31/10/96
4	31/10/96	3.3	31/10/96
5	31/12/97	3.4	31/10/96
6	31/12/97	3.5	31/10/96
7	31/12/97	3.6	31/12/97
8	31/12/97	3.7	31/10/96
9	31/12/97	3.8	31/10/96
10	31/10/96	3.9	31/12/97
11	31/12/97	3.10	31/12/97
12	31/12/97	3.11	31/12/97
13	31/12/97	3.12	31/10/96
14	31/12/97	3.13	31/10/96
15	31/12/97	3.14	31/10/96
16	31/12/97	3.15	31/10/96
17	31/12/97	3.16	31/10/96
18	31/12/97	3.17	31/10/96
19	31/12/97	3.18	31/10/96
20	31/12/97	4.1	31/10/96
1.1	31/10/96	4.2	31/12/97
1.2	31/10/96	4.3	31/10/96
1.3	31/10/96	4.4	31/10/96
1.4	31/10/96	4.5	31/10/96
1.5	31/12/97	4.6	31/10/96
1.6	31/12/97	4.7	31/10/96
1.7	31/10/96	4.8	31/10/96
1.8	31/10/96	4.9	31/10/96
1.9	31/12/97	4.10	31/10/96
1.10	31/10/96	4.11	31/10/96
2.1	31/10/96	4.12	blank
2.2	31/10/96	5.1	31/10/96
2.3	31/10/96	5.2	31/10/96
2.4	31/10/96	5.3	31/10/96
2.5	31/10/96	5.4	31/10/96
2.6	31/10/96	5.5	31/10/96
2.7	31/10/96	5.6	31/10/96
2.8	31/10/96	5.7	31/10/96
2.9	31/10/96	5.8	31/10/96
2.10	31/10/96	5.9	31/10/96
2.11	31/10/96	5.10	31/10/96
2.12	31/10/96	5.11	31/10/96
2.13	31/10/96	5.12	31/10/96
2.14	31/10/96	5.13	31/10/96
2.15	31/10/96	5.14	31/10/96
2.16	31/10/96	5.15	31/10/96
2.17	31/10/96	5.16	31/10/96

5.17	31/10/96		7.3.5	31/10/96	
5.18	31/10/96		7.3.6	31/10/96	
5.19	31/10/96		7.3.7	31/10/96	
5.20	31/10/96		7.3.8	31/10/96	
5.21	31/10/96		7.3.9	31/10/96	(fold-out)
5.22	31/10/96		7.3.10	31/10/96	(fold-out)
5.23	31/10/96		7.4.1	31/10/96	
5.24	31/10/96		7.4.2	31/10/96	
5.25	31/10/96		7.4.3	31/10/96	
5.26	31/10/96		7.4.4	31/10/96	
5.27	31/10/96		7.4.5	31/10/96	
5.28	31/10/96		7.4.6	31/10/96	
5.29	31/10/96		7.4.7	31/10/96	
5.30	31/10/96		7.4.8	31/10/96	
5.31	31/10/96		7.4.9	31/10/96	(fold-out)
5.32	31/10/96		7.4.10	31/10/96	(fold-out)
6.1	31/12/97		7.5.1	31/10/96	
6.2	31/10/96		7.5.2	31/10/96	
6.3	31/12/97		7.5.3	31/10/96	
6.4	31/12/97		7.5.4	31/10/96	
6.5	31/10/96		7.5.5	31/10/96	
6.6	31/10/96		7.5.6	31/10/96	
6.7	31/12/97		7.5.7	31/10/96	
6.8	31/12/97		7.5.8	31/10/96	
6.9	31/10/96		7.5.9	31/10/96	(fold-out)
6.10	31/10/96		7.5.10	31/10/96	(fold-out)
7.1	31/12/97		7.6.1	31/10/96	
7.2	31/10/96		7.6.2	31/10/96	
7.3	31/10/96		7.6.3	31/10/96	
7.4	31/10/96		7.6.4	31/10/96	
7.1.1	31/10/96		7.6.5	31/10/96	
7.1.2	31/10/96		7.6.6	31/10/96	
7.1.3	31/10/96		7.6.7	31/10/96	
7.1.4	blank		7.6.8	31/10/96	
7.1.5	31/10/96		7.6.9	31/10/96	(fold-out)
7.1.6	31/10/96		7.6.10	blank	
7.1.7	31/10/96		7.6.11	31/12/97	
7.1.8	31/10/96		7.6.12	31/12/97	
7.1.9	31/10/96	(fold-out)	7.6.13	31/12/97	
7.1.10	blank		7.6.14	31/12/97	
7.2.1	31/10/96		7.6.15	31/12/97	
7.2.2	31/10/96		7.6.16	31/12/97	
7.2.3	31/10/96		7.6.17	31/12/97	
7.2.4	31/10/96		7.6.18	31/12/97	
7.2.5	31/10/96		7.6.19	31/12/97	(fold-out)
7.2.6	31/10/96		7.6.20	blank	
7.2.7	31/10/96		7.7.1	31/12/97	
7.2.8	31/10/96		7.7.2	31/10/96	
7.2.9	31/10/96	(fold-out)	7.7.3	31/10/96	
7.2.10	31/10/96	(fold-out)	7.7.4	31/10/96	
7.3.1	31/10/96		7.7.5	31/10/96	
7.3.2	31/10/96		7.7.6	31/10/96	
7.3.3	31/10/96		7.7.7	31/10/96	
7.3.4	31/10/96		7.7.8	31/10/96	

7.7.9	31/10/96	(fold-out)	7.11.5	31/10/96	
7.7.10	blank		7.11.6	31/10/96	
7.8.1	31/10/96		7.11.7	31/10/96	(fold-out)
7.8.2	blank		7.11.8	31/10/96	(fold-out)
7.8.3	31/10/96		7.11.9	31/10/96	(fold-out)
7.8.4	31/10/96		7.11.10	blank	
7.8.5	31/10/96	(fold-out)	7.11.11	31/10/96	(fold-out)
7.8.6	blank		7.11.12	blank	
7.9.1	31/12/97		7.11.13	31/12/97	
7.9.2	blank		7.11.14	31/12/97	
7.9.3	31/10/96		7.11.15	31/12/97	
7.9.4	31/10/96		7.11.16	31/12/97	
7.9.5	31/10/96	(fold-out)	7.11.17	31/12/97	
7.9.6	blank		7.11.18	31/12/97	
7.9.7	31/12/97		7.11.19	31/12/97	(fold-out)
7.9.8	31/12/97		7.11.20	31/12/97	(fold-out)
7.9.9	31/12/97		7.11.21	31/12/97	(fold-out)
7.9.10	31/12/97		7.11.22	blank	
7.9.11	31/12/97	(fold-out)	7.11.23	31/12/97	(fold-out)
7.9.12	blank		7.11.24	blank	
7.10.1	31/10/96		7.12.1	31/12/97	
7.10.2	31/10/96		7.12.2	31/12/97	
7.10.3	31/10/96		7.12.3	31/10/96	
7.10.4	31/10/96		7.12.4	31/10/96	
7.10.5	31/10/96		7.12.5	31/10/96	(fold-out)
7.10.6	31/10/96		7.12.6	blank	
7.10.7	31/10/96	(fold-out)	7.13.1	31/12/97	
7.10.8	31/10/96	(fold-out)	7.13.2	31/12/97	
7.10.9	31/10/96	(fold-out)	7.13.3	31/10/96	
7.10.10	blank		7.13.4	31/10/96	
7.10.11	31/12/97		7.13.5	31/10/96	(fold-out)
7.10.12	31/12/97		7.13.6	blank	
7.10.13	31/12/97		7.14.1	31/12/97	
7.10.14	31/12/97		7.14.2	31/12/97	
7.10.15	31/12/97		7.14.3	31/12/97	
7.10.16	31/12/97		7.14.4	blank	
7.10.17	31/12/97	(fold-out)	7.14.5	31/10/96	
7.10.18	31/12/97	(fold-out)	7.14.6	31/10/96	
7.10.19	31/12/97	(fold-out)	7.14.7	31/10/96	(fold-out)
7.10.20	blank		7.14.8	blank	
7.10.21	31/12/97		7.15.1	31/12/97	
7.10.22	31/12/97		7.15.2	31/12/97	
7.10.23	31/12/97		7.15.3	31/10/96	
7.10.24	31/12/97		7.15.4	31/10/96	
7.10.25	31/12/97		7.15.5	31/10/96	(fold-out)
7.10.26	31/12/97		7.15.6	blank	
7.10.27	31/12/97	(fold-out)	7.16.1	31/12/97	
7.10.28	31/12/97	(fold-out)	7.16.2	blank	
7.10.29	31/12/97	(fold-out)	7.16.3	31/10/96	
7.10.30	blank		7.16.4	31/10/96	
7.11.1	31/10/96		7.16.5	31/10/96	
7.11.2	31/10/96		7.16.6	blank	
7.11.3	31/10/96		7.17.1	31/12/97	
7.11.4	31/10/96		7.17.2	blank	

7.17.3	31/10/96	8.8.5	31/10/96
7.17.4	31/10/96	8.8.6	31/10/96
7.17.5	31/10/96	8.8.7	31/10/96
7.17.6	blank	8.8.8	blank
8.1	31/12/97	8.9.1	31/10/96
8.2	31/10/96	8.9.2	blank
8.1.1	31/10/96	8.10.1	31/12/97
8.1.2	31/10/96	8.10.2	31/12/97
8.1.3	31/10/96	8.10.3	31/12/97
8.1.4	31/10/96	8.10.4	31/12/97
8.1.5	31/10/96	8.10.5	31/12/97
8.1.6	31/10/96	8.10.6	blank
8.1.7	31/10/96	8.10.7	31/12/97
8.1.8	31/10/96	8.10.8	31/12/97
8.1.9	31/10/96	8.10.9	31/12/97
8.1.10	31/10/96	8.10.10	31/12/97
8.1.11	31/10/96	8.11.1	31/10/96
8.1.12	31/10/96	8.11.2	31/10/96
8.1.13	31/10/96	8.11.3	31/10/96
8.1.14	31/10/96	8.11.4	31/10/96
8.1.15	31/10/96	8.11.5	31/10/96
8.1.16	31/10/96	8.11.6	31/10/96
8.1.17	31/12/97	8.11.7	31/10/96
8.1.18	31/10/96	8.11.8	31/10/96
8.1.19	31/10/96	8.11.9	31/10/96
8.1.20	31/10/96	8.11.10	31/10/96
8.1.21	31/10/96	8.11.11	31/10/96
8.1.22	31/10/96	8.11.12	31/10/96
8.1.23	31/10/96	8.11.13	31/10/96
8.1.24	blank	8.11.14	31/10/96
8.2.1	31/10/96	8.11.15	31/10/96 fold-out
8.2.2	31/10/96	8.11.16	blank
8.3.1	31/10/96	8.11.17	31/10/96 fold-out
8.3.2	31/10/96	8.11.18	blank
8.3.3	31/10/96	8.12.1	31/10/96
8.3.4	31/10/96	8.12.2	31/10/96
8.4.1	31/10/96	8.12.3	31/10/96
8.4.2	31/10/96	8.12.4	31/10/96
8.5.1	31/10/96	8.12.5	31/12/97
8.5.2	31/10/96	8.12.6	31/10/96
8.5.3	31/10/96	8.12.7	31/10/96
8.5.4	blank	8.12.8	31/10/96
8.6.1	31/10/96	8.12.9	31/10/96
8.6.2	31/10/96	8.12.10	31/10/96
8.6.3	31/10/96	8.12.11	31/10/96
8.6.4	31/10/96	8.12.12	31/10/96
8.7.1	31/10/96	8.12.13	31/10/96
8.7.2	31/10/96	8.12.14	blank
8.7.3	31/10/96	8.13.1	31/12/97
8.7.4	31/10/96	8.13.2	31/12/97
8.8.1	31/10/96	8.13.3	31/12/97
8.8.2	31/10/96	8.13.4	31/12/97
8.8.3	31/10/96	8.13.5	31/12/97
8.8.4	31/10/96	8.13.6	31/12/97

8.13.7	31/12/97	8.16.7	31/12/97
8.13.8	blank	8.16.8	blank
8.14.1	31/10/96	9.1	31/10/96
8.14.2	31/10/96	9.2	31/10/96
8.14.3	31/10/96	9.3	31/10/96
8.14.4	31/10/96	9.4	31/10/96
8.14.5	31/10/96	9.5	31/10/96
8.14.6	31/10/96	9.6	31/10/96
8.14.7	31/10/96	9.7	31/10/96
8.14.8	31/10/96	9.8	31/10/96
8.14.9	31/10/96		
8.14.10	31/10/96		
8.14.11	31/10/96		
8.14.12	31/10/96		
8.14.13	31/10/96		
8.14.14	31/10/96		
8.14.15	31/10/96		
8.14.16	31/10/96		
8.14.17	31/10/96		
8.14.18	31/10/96		
8.14.19	31/10/96		
8.14.20	31/10/96		
8.14.21	31/10/96		
8.14.22	31/10/96		
8.14.23	31/10/96		
8.14.24	31/10/96		
8.14.25	31/10/96		
8.14.26	31/10/96		
8.14.27	31/10/96	fold-out	
8.14.28	blank		
8.15.1	31/12/97		
8.15.2	31/12/97		
8.15.3	31/12/97		
8.15.4	31/12/97		
8.15.5	31/12/97		
8.15.6	31/12/97		
8.15.7	31/12/97		
8.15.8	31/12/97		
8.15.9	31/12/97		
8.15.10	31/12/97		
8.15.11	31/12/97		
8.15.12	31/12/97		
8.15.13	31/12/97		
8.15.14	31/12/97		
8.15.15	31/12/97		
8.15.16	31/12/97		
8.15.17	31/12/97		
8.15.18	blank		
8.16.1	31/12/97		
8.16.2	31/12/97		
8.16.3	31/12/97		
8.16.4	31/12/97		
8.16.5	31/12/97		
8.16.6	31/12/97		

Contents

1 General Information

1.1	Introduction	1.2
1.2	Specifications	1.3
1.2.1	Introduction.....	1.3
1.2.2	General.....	1.3
1.2.3	Receiver Performance	1.5
1.2.4	Transmitter Performance	1.7
1.2.5	Frequency Reference	1.8
1.2.6	Trunking	1.9
1.2.6.1	T2030, T2035, T2040 & T2050 Models	1.9
1.2.6.2	T2060 Model	1.9
1.3	Operating Instructions	1.9
1.4	Product Codes	1.10

2 Circuit Description

2.1	Design Overview	2.2
2.2	Synthesiser	2.3
2.3	Audio & Regulators.....	2.4
2.4	TCXO/TX Audio PCB.....	2.4
2.5	IF PCB	2.5
2.6	T2000-100 & -400 RF PCB	2.6
2.6.1	T2000-100 & -400 Receiver	2.6
2.6.2	T2000-100 & -400 Exciter	2.7
2.6.3	T2000-100 & -400 Power Amplifier	2.7
2.7	T2000-200 RF PCB	2.8
2.7.1	T2000-200 Receiver.....	2.8
2.7.2	T2000-200 Exciter	2.9
2.7.3	T2000-200 Power Amplifier	2.9
2.8	T2000-300 RF PCB	2.10
2.8.1	T2000-300 Receiver.....	2.10
2.8.2	T2000-300 Exciter	2.11
2.8.3	T2000-300 Power Amplifier	2.11
2.9	T2000-500, T2000-600, T2000-700, -900 & -000 RF PCB.....	2.12
2.9.1	T2000-500, -600, -700, -900 & -000 Receiver	2.12
2.9.2	T2000-500, -600, -700 -900 & -000 Exciter	2.13
2.9.3	T2000-500, -600, -700, -900 & -000 Power Amplifier.....	2.13

2.10	T2000-800 RF PCB	2.14
2.10.1	T2000-800 Receiver	2.14
2.10.2	T2000-800 Exciter	2.15
2.10.3	T2000-800 Power Amplifier	2.15
2.11	Control Module	2.16
2.11.1	T2010 & T2015 HC05 Logic PCB	2.16
2.11.2	T2020, T203X, T2040, T2050 & T2060 HC11 Logic PCB	2.19

3 Introduction To Servicing

3.1	Servicing Precautions	3.2
3.1.1	Caution: Accidental Transmit	3.2
3.1.2	Caution: Antenna Loading	3.2
3.1.3	Caution: Beryllium Oxide & Power Transistors	3.2
3.1.4	Caution: CMOS Devices	3.2
3.1.5	Caution: Screw Head Types	3.3
3.2	Disassembly Instructions	3.5
3.2.1	To Gain Access To The Logic PCB	3.5
3.2.2	To Remove The Bottom Cover And Microprocessor Shield	3.5
3.2.3	To Detach The Control Head	3.6
3.2.3.1	Locally Mounted Models	3.6
3.2.3.2	Remotely Mounted Models	3.6
3.2.4	To Disassemble The Control Head	3.7
3.2.4.1	T2010, T2015, T203X & T2060 Radios	3.7
3.2.4.2	T2020, T2040 & T2050 Radios	3.9
3.2.5	To Detach The EMC Filter PCB	3.11
3.2.6	To Remote A Locally Mounted T2020, T2040 & T2050	3.11
3.3	Power Amplifier - Special Instructions	3.12
3.3.1	To Replace PA Transistors	3.12
3.3.2	To Remove Case Mica Capacitors	3.12
3.4	Repair	3.13
3.4.1	Surface Mount Devices	3.13
3.4.1.1	Surface Mount Device (SMD) Precautions	3.13
3.4.1.2	Servicing Equipment Required	3.13
3.4.1.3	Removal & Replacement Of SMD Components	3.15
3.4.1.4	Common Causes Of SMD Failure	3.17
3.4.2	Leaded Component Removal	3.17
3.4.2.1	Desoldering Iron Method	3.17
3.4.2.2	Component Cutting Method	3.18
3.5	Programming	3.18

4 Functional Tests

4.1	Test Equipment Required	4.2
4.2	Connecting The Radio	4.3

4.3	Trunked Radios	4.4
4.3.1	Trunking System Check	4.4
4.4	Receiver Performance Tests	4.5
4.4.1	To Check The Squelch Operation.....	4.5
4.4.2	To Check The Squelch Ratio	4.5
4.4.3	To Check The Audio Output Level And Distortion	4.6
4.4.4	To Check The Sinad Sensitivity	4.6
4.4.5	To Check The Signal+Noise To Noise Ratio.....	4.7
4.4.6	To Check The Ultimate Signal To Noise Ratio.....	4.7
4.4.7	RSSI.....	4.7
4.4.8	To Check The Operation Of The Noise Blanker	4.8
4.5	Transmitter Performance Tests	4.9
4.5.1	Audio Processor	4.9
4.5.1.1	To Check The Limiter Circuit Operation	4.9
4.5.1.2	To Check The Audio ALC Operation	4.9
4.5.1.3	To Check The Gain Of The Audio Processor	4.10
4.5.2	Modulation Characteristics.....	4.10
4.5.2.1	To Check The Above Limiting Response	4.10
4.5.2.2	To Check The Below Limiting Response	4.10
4.5.3	To Check The RF Power Control Circuit	4.11
5	Fault Finding	
5.1	Servicing Warning.....	5.2
5.2	Visual Checks.....	5.2
5.3	Component Checks	5.2
5.3.1	Transistor Check.....	5.2
5.3.2	Integrated Circuit (IC) Check	5.2
5.4	DC Checks.....	5.3
5.5	Receiver RF Checks	5.4
5.5.1	VCO Frequency	5.4
5.5.2	Control Line Voltages	5.4
5.5.3	RF Sensitivity	5.5
5.6	Transmitter RF Checks	5.5
5.7	Trunked Radios: System Check.....	5.6
5.7.1	Base Station Check	5.6
5.7.1.1	T2030 Radios	5.6
5.7.1.2	T2040 Radios.....	5.6
5.7.2	Base Station Control Channel Hunt.....	5.6
5.8	Trunked Radios: Test Mode	5.7
5.8.1	Test Mode Overview	5.7
5.8.2	Manual Test Mode (MTM)	5.7
5.8.2.1	T2030 & T2035 MTM Operation.....	5.8

5.8.2.2	T2040 & T2050 MTM Operation.....	5.9
5.8.3	Computer Controlled Test Mode (CCTM).....	5.9
5.8.3.1	CCTM Selection.....	5.10
5.8.3.2	CCTM Protocol.....	5.10
5.8.4	Power-Up State.....	5.11
5.8.5	Test Facilities Available.....	5.11
5.8.5.1	Resetting The Radio.....	5.11
5.8.5.2	Test Facilities Table.....	5.12
5.8.6	Trunked Radios: Radio Mode/Status Display Codes.....	5.15
5.9	Options Interface Specifications.....	5.17
5.10	Fault Finding Charts.....	5.20
5.10.1	Radio Won't Switch On.....	5.21
5.10.2	Radio Won't Program.....	5.22
5.10.3	Synthesiser Faults.....	5.23
5.10.4	Receiver Front End Faults.....	5.24
5.10.5	Receiver IF Faults.....	5.25
5.10.6	Receiver Mute Faults.....	5.26
5.10.7	No Audio On Receive.....	5.27
5.10.8	Transmitter RF Low Power Faults.....	5.28
5.10.9	Transmitter Power Control Faults.....	5.30
5.10.10	Transmit Audio Absent.....	5.31
5.10.11	Trunked Radios: Radio Won't Acquire A Control Channel.....	5.32
6	Tuning & Adjustment	
6.1	Tuning Precautions.....	6.2
6.2	Tuning & Adjustment Points.....	6.3
6.3	Trunked Radios.....	6.5
6.4	Transmitter Adjustments.....	6.5
6.4.1	Power Output.....	6.5
6.4.2	TCXO Alignment.....	6.6
6.4.3	Dual Point Modulation Adjustment.....	6.6
6.4.4	CTCSS Modulation Adjustment.....	6.7
6.4.5	LTR Code Deviation Adjustment.....	6.7
6.4.6	Modulation Adjustment.....	6.7
6.4.7	Selcall Tone Deviation.....	6.8
6.4.8	FFSK Adjustment (Trunked Models Only).....	6.8
6.4.8.1	T203X Radios.....	6.8
6.4.8.2	T2040 Radios.....	6.8
6.5	Receiver Adjustments.....	6.9
6.5.1	RF Alignment.....	6.9
6.5.2	Internal Mute Control.....	6.10
6.5.3	RSSI.....	6.10
6.5.3.1	'L' Level Set-Up (Trunked Radios Only).....	6.10

7 PCB Information

7.1	T2000-100 RF PCB		
	Parts List	IPN 220-01331-02	7.1.1
	Mechanical & Miscellaneous Parts	"	7.1.4
	Grid Reference Index.	"	7.1.5
	PCB Layout - Top.	"	7.1.7
	PCB Layout - Bottom.	"	7.1.8
	Circuit	"	7.1.9
7.2	T2000-200 RF PCB		
	Parts List	IPN 220-01202-10	7.2.1
	Mechanical & Miscellaneous Parts	"	7.2.4
	Grid Reference Index.	"	7.2.5
	PCB Layout - Top.	"	7.2.7
	PCB Layout - Bottom.	"	7.2.8
	Circuits	"	7.2.9
7.3	T2000-300 RF PCB		
	Parts List	IPN 220-01314-01	7.3.1
	Mechanical & Miscellaneous Parts	"	7.3.4
	Grid Reference Index.	"	7.3.5
	PCB Layout - Top.	"	7.3.7
	PCB Layout - Bottom.	"	7.3.8
	Circuits	"	7.3.9
7.4	T2000-400 RF PCB		
	Parts List	IPN 220-01204-11	7.4.1
	Mechanical & Miscellaneous Parts	"	7.4.4
	Grid Reference Index.	"	7.4.5
	PCB Layout - Top.	"	7.4.7
	PCB Layout - Bottom.	"	7.4.8
	Circuits	"	7.4.9
7.5	T2000-500/-600 RF PCB		
	Parts List	IPN 220-01205-14	7.5.1
	Mechanical & Miscellaneous Parts	"	7.5.6
	Grid Reference Index.	"	7.5.7
	PCB Layout - Top.	"	7.5.9
	PCB Layout - Bottom.	"	7.5.10
	Circuits	"	7.5.11
7.6	T2000-700/-900 RF PCB		
	Parts List	IPN 220-01289-02	7.6.1
	Mechanical & Miscellaneous Parts	"	7.6.4
	Grid Reference Index.	"	7.6.5
	PCB Layout - Top.	"	7.6.7
	PCB Layout - Bottom.	"	7.6.8
	Circuit	"	7.6.9

7.7	T2000-800 RF PCB		
	Parts List	IPN 220-01305-03	7.7.1
	Mechanical & Miscellaneous Parts	"	7.7.4
	Grid Reference Index	"	7.7.5
	PCB Layout - Top	"	7.7.7
	PCB Layout - Bottom.	"	7.7.8
	Circuits	"	7.7.9
7.8	T2000 IF PCB		
	Parts List	IPN 220-01384-00	7.8.1
	PCB Layout - Top	"	7.8.3
	PCB Layout - Bottom.	"	7.8.4
	Circuits	"	7.8.5
7.9	T2000 TCXO/TX Audio PCB		
	Parts List	IPN 220-01389-00	7.9.1
	PCB Layout - Top	"	7.9.3
	PCB Layout - Bottom.	"	7.9.4
	Circuits	"	7.9.5
7.9	T2000 TCXO/TX Audio PCB		
	Parts List	IPN 220-01389-02	7.9.7
	PCB Layout - Top	"	7.9.9
	PCB Layout - Bottom.	"	7.9.10
	Circuits	"	7.9.11
7.10	T2010 & T2015 HC05 Logic PCB		
	Parts List	IPN 220-01377-01	7.10.1
	Mechanical & Miscellaneous Parts	"	7.10.4
	Grid Reference Index	"	7.10.5
	PCB Layout - Top	"	7.10.7
	PCB Layout - Bottom.	"	7.10.8
	Circuit	"	7.10.9
7.10	T2010 & T2015 HC05 Logic PCB		
	Parts List	IPN 220-01377-02	7.10.11
	Mechanical & Miscellaneous Parts	"	7.10.14
	Grid Reference Index	"	7.10.15
	PCB Layout - Top	"	7.10.17
	PCB Layout - Bottom.	"	7.10.18
	Circuit	"	7.10.19
7.10	T2010 & T2015 HC05 Logic PCB		
	Parts List	IPN 220-01377-03	7.10.21
	Mechanical & Miscellaneous Parts	"	7.10.24
	Grid Reference Index	"	7.10.25
	PCB Layout - Top	"	7.10.27
	PCB Layout - Bottom.	"	7.10.28
	Circuit	"	7.10.29

7.11	T2020, T203X, T2040, T2050 & T2060 HC11 Logic PCB		
	Parts List	IPN 220-01344-02	7.11.1
	Mechanical & Miscellaneous Parts	"	7.11.4
	Grid Reference Index	"	7.10.5
	PCB Layout - Top	"	7.11.7
	PCB Layout - Bottom	"	7.11.8
	Circuits	"	7.11.9
7.11	T2020, T203X, T2040, T2050 & T2060 HC11 Logic PCB		
	Parts List	IPN 220-01344-04	7.11.13
	Mechanical & Miscellaneous Parts	"	7.11.16
	Grid Reference Index	"	7.10.17
	PCB Layout - Top	"	7.11.19
	PCB Layout - Bottom	"	7.11.20
	Circuits	"	7.11.21
7.12	T2010 & T2030 Control Head PCB		
	Parts List	IPN 220-01331-02	7.12.1
	Mechanical & Miscellaneous Parts	"	7.12.2
	PCB Layout - Top	"	7.12.3
	PCB Layout - Bottom	"	7.12.4
	Circuits	"	7.12.5
7.13	T2015 & T2060 Control Head PCB		
	Parts List	IPN 220-01320-01	7.13.1
	Mechanical & Miscellaneous Parts	"	7.13.2
	PCB Layout - Top	"	7.13.3
	PCB Layout - Bottom	"	7.13.4
	Circuits	"	7.13.5
7.14	T2020, T2040 & T2050 Control Head PCB		
	Parts List	IPN 220-01321-04	7.14.1
	Mechanical & Miscellaneous Parts	"	7.14.3
	PCB Layout - Top	"	7.14.5
	PCB Layout - Bottom	"	7.14.6
	Circuits	"	7.14.7
7.15	T2035 Control Head PCB		
	Parts List	IPN 220-01322-03	7.15.1
	Mechanical & Miscellaneous Parts	"	7.15.2
	PCB Layout - Top	"	7.15.3
	PCB Layout - Bottom	"	7.15.4
	Circuits	"	7.15.5
7.16	T2000 EMC Filter PCB		
	Parts List	IPN 220-01383-01	7.16.1
	PCB Layout - Top	"	7.16.3
	PCB Layout - Bottom	"	7.16.4
	Circuit	"	7.16.5
7.17	T2000 Data Interface Decoupling PCB		
	Parts List	IPN 220-01388-01	7.17.1
	PCB Layout - Top	"	7.17.3
	PCB Layout - Bottom	"	7.17.4
	Circuit	"	7.17.5

8 Accessories

8.1	T2008 Power Supply	8.1.1
8.1.1	Operation	8.1.2
8.1.2	Performance Specifications	8.1.3
8.1.3	Precautions	8.1.5
8.1.4	Circuit Operation	8.1.6
8.1.5	Installation	8.1.8
8.1.6	Introduction To Servicing	8.1.10
8.1.7	Setting Up The Power Supply	8.1.12
8.1.8	Fault Finding	8.1.14
8.1.9	Repair	8.1.15
8.1.10	PCB Information	8.1.17
8.2	Connection To External Devices	8.2.1
8.2.1	Introduction	8.2.1
8.2.2	Applications	8.2.1
8.2.3	Connections	8.2.2
8.2.4	T2010 & T2015 BCD Selection	8.2.2
8.3	T2000-500 & T2000-600 1-7W Versions	8.3.1
8.3.1	Components Required	8.3.2
8.3.2	Fitting	8.3.2
8.3.3	Set-Up	8.3.4
8.3.4	Specifications	8.3.4
8.4	T2000-05 Remote Speaker Kit	8.4.1
8.4.1	Components Required	8.4.1
8.4.2	Fitting	8.4.1
8.5	T2000-06 Desktop Microphone Kit	8.5.1
8.5.1	Introduction	8.5.1
8.5.2	Fitting	8.5.1
8.5.3	T2000-06 Set-Up	8.5.1
8.5.4	Sensitivity	8.5.2
8.6	T2000-07 DTMF Microphone Kit	8.6.1
8.6.1	Fitting	8.6.1
8.6.2	Operation	8.6.1
8.6.3	T2000-07 Set-Up	8.6.1
8.7	T2000-34 Selcall Kit	8.7.1
8.7.1	Components Required	8.7.2
8.7.2	Fitting	8.7.2
8.7.3	Programming	8.7.3
8.8	T2000-36 Selcall Kit	8.8.1
8.8.1	Components Required	8.8.2
8.8.2	Fitting	8.8.2
8.8.3	PCB Information	8.8.4
8.9	T2000-40 DTMF Kit	8.9.1
8.9.1	Fitting	8.9.1
8.9.2	Programming	8.9.1

8.10	T2000-A450X CTCSS & Scrambler Kit	8.10.1
8.10.1	Components Required.....	8.10.2
8.10.2	Fitting.....	8.10.2
8.10.3	T2000-A450X Link Options.....	8.10.3
8.10.4	PCB Information.....	8.10.5
8.11	T2000-50 Handsfree Kit.....	8.11.1
8.11.1	Components Required.....	8.11.2
8.11.2	Fitting.....	8.11.2
8.11.3	Fitting The Complete Unit In The Vehicle	8.11.3
8.11.4	T2000-50 Set-Up	8.11.5
8.11.5	Signal Specifications.....	8.11.7
8.11.6	Specifications.....	8.11.8
8.11.7	Circuit Description.....	8.11.8
8.11.8	PCB Information.....	8.11.10
8.12	T2000-60 Dual Port UART Kit	8.12.1
8.12.1	Components Required.....	8.12.2
8.12.2	Fitting.....	8.12.3
8.12.3	T2000-60 Link Options.....	8.12.4
8.12.4	T2000-60 Set-Up	8.12.5
8.12.5	Signal Specifications.....	8.12.7
8.12.6	PCB Information.....	8.12.9
8.13	T2000-A66 Single Port UART Kit.....	8.13.1
8.13.1	Components Required.....	8.13.2
8.13.2	Fitting.....	8.13.2
8.13.3	Signal Specifications.....	8.13.3
8.13.4	PCB Information.....	8.13.4
8.14	T2000-80 Line Interface Kit.....	8.14.1
8.14.1	Components Required.....	8.14.2
8.14.2	Fitting.....	8.14.2
8.14.3	Line Interface Options.....	8.14.4
8.14.4	T2000-80 Set-Up	8.14.7
8.14.5	Signal Specifications.....	8.14.9
8.14.6	Applications	8.14.10
8.14.7	Specifications.....	8.14.16
8.14.8	Circuit Description.....	8.14.18
8.14.9	PCB Information.....	8.14.21
8.15	T2000-A70 Data Modem Kit.....	8.15.1
8.15.1	Components Required.....	8.15.2
8.15.2	Fitting.....	8.15.2
8.15.3	T2000-A70 Link Options	8.15.4
8.15.4	Signal Specifications.....	8.15.5
8.15.5	Programming	8.15.6
8.15.6	Circuit Description.....	8.15.12
8.15.7	PCB Information.....	8.15.13
8.16	T2000-A03/-A04/-A16 Remote Loom Kits	8.16.1
8.16.1	Components Required.....	8.16.2
8.16.2	Fitting To Locally Mounted Radios	8.16.2
8.16.3	Fitting To Remote Mounted Radios.....	8.16.6

9 Software

9.1	Identifying The Software Version Number	9.2
9.2	Software History	9.3
9.2.1	T2010 & T2015 Radios	9.3
9.2.2	T2020 Radios	9.4
9.2.3	T2030 & T3035 Radios	9.5
9.2.4	T2040 Radios	9.6
9.2.5	T2050 Radios	9.7
9.2.6	T2060 Radios	9.8

List Of Illustrations

Figure 2.1	T2000 TCXO/TX Audio PCB Block Diagram	2.4
Figure 2.2	T2000 IF PCB Block Diagram	2.5
Figure 2.3	T2000-100 & -400 RF PCB Block Diagram	2.6
Figure 2.4	T2000-200 RF PCB Block Diagram	2.8
Figure 2.5	T2000-300 RF PCB Block Diagram	2.10
Figure 2.6	T2000-500, -600, -700, -900 & -000 RF PCB Block Diagram	2.12
Figure 2.7	T2000-800 RF PCB Block Diagram	2.14
Figure 2.8	T2010 & T2030 Control Head Block Diagram	2.17
Figure 2.9	T2015 & T2060 Control Head Block Diagram	2.17
Figure 2.10	T2020, T2040 & T2050 Control Head	2.18
Figure 3.1	Anti-Static Bench Set-Up	3.2
Figure 3.2	Screwdriver Identification	3.3
Figure 3.3	T2000 Series II Radio Assembly	3.4
Figure 3.4	T2010, T2015 & T203X Control Head Assembly	3.7
Figure 3.5	T2020, T2040 & T2050 Control Head Assembly - Locally Mounted	3.9
Figure 3.6	T2020, T2040 & T2050 Control Head Assembly - Remotely Mounted	3.10
Figure 3.7	EMC Filter PCB Mounting	3.11
Figure 3.8	Identifying SMD Components	3.14
Figure 3.9	SMD Soldering Guide	3.16
Figure 4.1	Suggested Test Equipment Set-Up	4.3
Figure 5.1	RF Test Cable	5.5
Figure 6.1	RF & TXCO/Tx Audio PCBs - Tuning & Adjustment Points	6.4
Figure 6.2	Receiver Tuning Amplifier	6.9
Figure 8.1.1	T2008 Float Charging Protection Circuit	8.1.9
Figure 8.1.2	T2008 Typical Waveforms	8.1.15
Figure 8.3.1	T2000-500/600 PA - Top Side	8.3.2
Figure 8.3.2	T2000-500/600 PA - Bottom Side	8.3.3
Figure 8.3.3	T2000-500/600 PA - Bottom Side	8.3.3
Figure 8.4.1	T2000 Power Connector	8.4.2
Figure 8.7.1	T2000-34 Selcall PCB Mounting - T2010 & T2015 Logic PCB	8.7.3
Figure 8.8.1	T2000-36 Selcall PCB Mounting	8.8.2
Figure 8.10.1	T2000-A450X PCB Mounting	8.10.2
Figure 8.11.1	T2000-50 Handsfree PCB Mounting	8.11.2
Figure 8.11.2	T2000-50 Test Equipment Set-Up	8.11.5

Figure 8.11.3	T2000-50 9 Way D-Range Connector (S21)	8.11.7
Figure 8.12.1	T2000-60 UART PCB Mounting	8.12.3
Figure 8.12.2	T2000-60 Test Equipment Set-Up	8.12.5
Figure 8.12.3	T2000-60 15 Way D-Range connector (S21)	8.12.8
Figure 8.13.1	T2000-A66 Single Port UART PCB Mounting	8.13.3
Figure 8.13.2	9 Way D-Range Connector (SKT1)	8.13.3
Figure 8.14.1	T2000-80 Line Interface PCB Mounting (T2010/T2015 shown)	8.14.2
Figure 8.14.2	T2000-80 Test Equipment Set-Up	8.14.7
Figure 8.14.3	T2000-80 15 Way D-Range connector (S21)	8.14.9
Figure 8.14.4	T2000-80 Line Interface PCB Block Diagram	8.14.18
Figure 8.15.1	T2000-A70 PCB Mounting	8.15.2
Figure 8.15.2	T2000-A70 Data Modem PCB Mounting	8.15.3
Figure 8.15.3	Data Interface Decoupling PCB Mounting: Series I Chassis	8.15.3
Figure 8.15.4	Data Interface Decoupling PCB Mounting: Series II Chassis	8.15.4
Figure 8.15.5	9 Way D-Range Connector (SKT1)	8.15.5
Figure 8.16.1	Remote Control Head Assembly	8.16.3
Figure 8.16.2	Connector PCB Mounting	8.16.4
Figure 8.16.3	EMC Filter PCB Mounting	8.16.4
Figure 8.16.4	Dummy Front Panel Assembly	8.16.5

List Of Tables

Table 5.1	T2000 Test Facilities	5.13
Table 5.2	Radio Mode/Status Display	5.16
Table 5.3	Options Connectors - Audio Signal Specifications	5.17
Table 5.4	Options Connectors - Supply Voltage Specifications	5.17
Table 5.5	Options Connectors - Logic Signal Specifications	5.18
Table 5.6	BCD Channel Selection (T2010 & T2015 only)	5.19
Table 6.1	Tuning & Adjustment Point	6.3
Table 8.15.1	Message Format	8.15.7
Table 8.15.2	Messages To The Radio Unit	8.15.8
Table 8.15.3	Messages From The Radio Unit	8.15.10
Table 8.15.4	Software Test Commands	8.15.11