


NX-820(G)/820

SERVICE MANUAL

KENWOOD

JVCKENWOOD Corporation

© 2012-11 PRINTED IN JAPAN
B53-7044-00 (Y) 80



CONTENTS

| | | | |
|-------------------------------------|-----------|-----------------------------------------|-----------|
| GENERAL | 2 | TERMINAL FUNCTION | 56 |
| SYSTEM SET-UP | 4 | PC BOARD | |
| REALIGNMENT | 4 | DISPLAY UNIT (X54-3830-10) | 60 |
| INSTALLATION | 7 | TX-RX UNIT (X57-8240-1X) | 62 |
| DISASSEMBLY FOR REPAIR | 9 | INTERCONNECTION DIAGRAM | 66 |
| CIRCUIT DESCRIPTION | 11 | SCHEMATIC DIAGRAM | 67 |
| COMPONENTS DESCRIPTION | 17 | BLOCK DIAGRAM | 78 |
| PARTS LIST | 19 | LEVEL DIAGRAM | 81 |
| EXPLODED VIEW | 29 | OPTIONAL ACCESSORIES | |
| TROUBLE SHOOTING | 30 | KRA-40 | 82 |
| ADJUSTMENT | 34 | SPECIFICATIONS | 83 |

NX-820(G)/820

Document Copyrights

Copyright 2012 by JVC KENWOOD Corporation. All rights reserved.

No part of this manual may be reproduced, translated, distributed, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, for any purpose without the prior written permission of JVC KENWOOD Corporation.

Disclaimer

While every precaution has been taken in the preparation of this manual, JVC KENWOOD Corporation assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein. JVC KENWOOD Corporation reserves the right to make changes to any products herein at any time for improvement purposes.

Firmware Copyrights

The title to and ownership of copyrights for firmware embedded in KENWOOD product memories are reserved for JVC KENWOOD Corporation. Any modifying, reverse engineering, copy, reproducing or disclosing on an Internet website of the firmware is strictly prohibited without prior written consent of JVC KENWOOD Corporation. Furthermore, any reselling, assigning or transferring of the firmware is also strictly prohibited without embedding the firmware in KENWOOD product memories.

Transceivers containing AMBE+2™ Vocoder:

The AMBE+2™ voice coding technology is embedded in the firmware under the license of Digital Voice Systems, Inc.

GENERAL

INTRODUCTION

SCOPE OF THIS MANUAL

This manual is intended for use by experienced technicians familiar with similar types of commercial grade communications equipment. It contains all required service information for the equipment and is current as of the publication date. Changes which may occur after publication are covered by either Service Bulletins or Manual Revisions. These are issued as required.

ORDERING REPLACEMENT PARTS

When ordering replacement parts or equipment information, the full part identification number should be included. This applies to all parts : components, kits, or chassis. If the part number is not known, include the chassis or kit number of which it is a part, and a sufficient description of the required component for proper identification.

PERSONAL SAFETY

The following precautions are recommended for personal safety:

- DO NOT transmit if someone is within two feet (0.6 meter) of the antenna.
- DO NOT transmit until all RF connectors are secure and any open connectors are properly terminated.
- SHUT OFF this equipment when near electrical blasting caps or while in an explosive atmosphere.
- All equipment should be properly grounded before power-up for safe operation.
- This equipment should be serviced by only qualified technicians.

PRE-INSTALLATION CONSIDERATIONS

1. UNPACKING

Unpack the radio from its shipping container and check for accessory items. If any item is missing, please contact KENWOOD immediately.

2. PRE-INSTALLATION CHECKOUT

2-1. Introduction

Each radio is adjusted and tested before shipment. However, it is recommended that receiver and transmitter operation be checked for proper operation before installation.

2-2. Testing

The radio should be tested complete with all cabling and accessories as they will be connected in the final installation. Transmitter frequency, deviation, and power output should be checked, as should receiver sensitivity, squelch operation, and audio output. Signalling equipment operation should be verified.

3. PLANNING THE INSTALLATION

3-1. General

Inspect the vehicle and determine how and where the radio antenna and accessories will be mounted.

Plan cable runs for protection against pinching or crushing wiring, and radio installation to prevent overheating.

3-2. Antenna

The favored location for an antenna is in the center of a large, flat conductive area, usually at the roof center. The trunk lid is preferred, bond the trunk lid and vehicle chassis using ground straps to ensure the lid is at chassis ground.

GENERAL

3-3. Radio

The universal mount bracket allows the radio to be mounted in a variety of ways. Be sure the mounting surface is adequate to support the radio's weight. Allow sufficient space around the radio for air cooling. Position the radio close enough to the vehicle operator to permit easy access to the controls when driving.

3-4. DC Power and wiring

1. This radio may be installed in negative ground electrical systems only. Reverse polarity will cause the cable fuse to blow. Check the vehicle ground polarity before installation to prevent wasted time and effort.
2. Connect the positive power lead directly to the vehicle battery positive terminal. Connecting the Positive lead to any other positive voltage source in the vehicle is not recommended.
3. Connect the ground lead directly to the battery negative terminal.
4. The cable provided with the radio is sufficient to handle the maximum radio current demand. If the cable must be extended, be sure the additional wire is sufficient for the current to be carried and length of the added lead.

4. INSTALLATION PLANNING – CONTROL STATIONS

4-1. Antenna system

The antenna system selection depends on many factors and is beyond the scope of this manual. Your KENWOOD dealer can help you select an antenna system that will best serve your particular needs.

4-2. Radio location


Select a convenient location for your control station radio which is as close as practical to the antenna cable entry point. Secondly, use your system's power supply (which supplies the voltage and current required for your system). Make sure sufficient air can flow around the radio and power supply to allow adequate cooling.

SERVICE

This radio is designed for easy servicing. Refer to the schematic diagrams, printed circuit board views, and alignment procedures contained in this manual.


NOTE

If you do not intend to use the speaker 3.5-mm jack, the D-sub 15-pin connector and SMA connector, fit the supplied speaker-jack cap, ACC cap and SMA cap to stop dust and sand from getting in.




NX-820(G)/820

SYSTEM SET-UP



REALIGNMENT

1. Modes



| Mode | Function |
|------------------------------|---------------------------------------------------------------------------------------|
| User mode | For normal use. |
| Panel test mode | Use by the dealer to check the fundamental characteristics. |
| Panel tuning mode | Used by the dealer to tune the transceiver. |
| PC mode | Used for communication between the transceiver and PC. |
| Data programming mode | Used to read and write frequency data and other features to and from the transceiver. |
| PC test mode | Used to check the transceiver using the PC. This feature is included in the FPU. |
| PC tuning mode | Used to tune the transceiver using the PC. |
| Firmware programming mode | Used when changing the main program of the flash memory. |
| Clone mode | Used to transfer programming data from one transceiver to another. |
| Firmware version information | Used to confirm the internal firmware version. |

2. How to Enter Each Mode

| Mode | Operation |
|------------------------------|----------------------------|
| User mode | Power ON |
| Panel test mode | [A]+Power ON |
| Panel tuning mode | Panel test mode+[S] |
| PC mode | Received commands from PC |
| Firmware programming mode | [Δ]+Power ON |
| Clone mode | [<B]+Power ON (One second) |
| Firmware version information | [S]+Power ON |

3. Panel Test Mode

Setting method refer to ADJUSTMENT.

4. Panel Tuning Mode

Setting method refer to ADJUSTMENT.

5. PC Mode

5-1. Preface

The transceiver is programmed using a personal computer, a programming interface (KPG-46A/46U) and FPU (programming software).

The programming software can be used with a PC. Figure 1 shows the setup of a PC for programming.

REALIGNMENT

5-2. Connection procedure

1. Connect the transceiver to the computer using the interface cable.

Note:

- You must install the KPG-46U driver in the computer to use the USB programming interface cable (KPG-46U).
2. When the Power is switched on, user mode can be entered immediately. When the PC sends a command, the transceiver enters PC mode, and "PROGRAM" is displayed on the LCD.
When data is transmitting from the transceiver, the red LED blinks.
When data is receiving by the transceiver, the green LED blinks.

Note:

The data stored in the computer must match the "Model Name" when it is written into the flash memory.

5-3. KPG-46A description

(PC programming interface cable: Option)

The KPG-46A is required to interface the transceiver to the computer. It has a circuit in its D-sub connector (KPG-46A: 9-pin) case that converts the RS-232C logic level to the TTL level.

The KPG-46A connects the 8-pin microphone connector of the transceiver to the RS-232C serial port of the computer.

5-4. KPG-46U description

(USB programming interface cable: Option)

The KPG-46U is a cable which connects to a USB port on a computer.

When using the KPG-46U, install the supplied CD-ROM (with driver software) in the computer. The KPG-46U driver runs under Windows XP, Vista or 7.

The latest version of the USB driver is available for download from the following URL:

<http://www.kenwood.com/usb-com/>
(This URL may change without notice.)

5-5. Programming Software : KPG-141D (ver.3.00 or later) description

The FPU is the programming software for the transceiver supplied on a CD-ROM. This software runs under Windows XP, Vista or 7 on a PC.

The data can be input to or read from the transceiver and edited on the screen. The programmed or edited data can be printed out. It is also possible to tune the transceiver.





Fig. 1

6. Firmware Programming Mode

6-1. Preface

Flash memory is mounted on the transceiver. This allows the transceiver to be upgraded when new features are released in the future. (For details on how to obtain the firmware, contact Customer Service.)

6-2. Connection procedure

Connect the transceiver to the personal computer using the interface cable (KPG-46A/46U). (Connection is the same as in the PC Mode.)

6-3. Programming

1. Start up the firmware programming software (Fpro.exe(ver. 6.1 or later)). The Fpro.exe exists in the KPG-141D installed folder.
2. Set the communications speed (normally, 115200 bps) and communications port in the configuration item.
3. Set the firmware to be updated by File name item.
4. Press and hold the [Δ] key while turning the transceiver power ON. Then, the orange LED on the transceiver lights and "FIRM PRG" is displayed.
5. Check the connection between the transceiver and the personal computer, and make sure that the transceiver is in the Program mode.
6. Press "write" button in the window. When the transceiver starts to receive data, the "LOADING" display lights.
7. If writing ends successfully, the checksum is calculated and a result is displayed.
8. If you want to continue programming other transceivers, repeat steps 4 to 7.

REALIGNMENT

6-4. Function

If you press the [Δ] key while "FIRM PRG" is displayed, the checksum is calculated, and a result is displayed. If you press the [Δ] key again while the checksum is displayed, "FIRM PRG" is redisplayed.

Note:

- This mode cannot be entered if the Firmware Programming mode is set to Disable in the Programming software.
- Normally, write in the high-speed mode.

7. Clone Mode

Programming data can be transferred from one transceiver to another by connecting them via their modular microphone jacks. The operation is as follows (the transmit transceiver is the source and the receive transceiver is a target). Clone mode should be enabled.

The following data cannot be cloned.

- Tuning data
- Embedded message with password
- Model name data
- ESN (Electronic Serial Number) data

Note :

The following data can be cloned.

- Fleet (own)/ID (own) for FleetSync
- Unit ID (own) for NXDN
- ID (own) for MDC-1200
- My ID for 5-tone

1. Turn the source transceiver power ON with the [<B] key held down (1 second), "CLONE MODE" is displayed on the LCD.
2. Power on the target transceiver.
3. Connect the cloning cable (No. E30-3382-05) to the modular microphone jacks on the source and target.
4. Press the [s] key on the source transceiver.
The data of the source is sent to the target. While the source is sending data, red LED blinked. While the target is receiving the data, "PROGRAM" is displayed and green LED blinked. When cloning of data is completed, the source displays "END", and the source red LED turned off, and the target automatically operates in the User mode. The target can then be operated by the same program as the source.
5. The other target can be continuously cloned. Carry out the operation in step 2 to 4.

7-1. How to enter the data password

If the read authorization password is set in the optional feature menu, you must enter the password (Source transceiver) to activate a clone mode.

You can use 0-9 to configure the password. The maximum length of the password is 6 digits.

1. [<B]+Power ON.
2. "CLONE LOCK" is displayed on the LCD.
3. If the [↗] and [↘] keys is pressed while "CLONE LOCK" is

displayed, numbers (0 to 9) are displayed flashing. When you press the [s] key, the currently selected number is determined. If you press the [s] key after entering the password in this procedure, "CLONE MODE" is displayed if the entered password is correct. If the password is incorrect, "CLONE LOCK" is redisplayed.





Fig. 2

7-2. Flow chart (Source transceiver)



8. Firmware Version Information

Press and hold the [s] key while turning the transceiver power ON and then keep pressing and holding the [s] key, the firmware version information appears on the LCD.

INSTALLATION


1. Connection Cable (KCT-60: Option)

The KCT-60 connection cable kit is used to connect the transceiver to a Horn alert cable, KCT-18 (Ignition sense cable), KES-5 (External speaker), or through the KCT-36 extension cable.

1-1. Installing the KCT-60 (Connection cable) in the transceiver

1. Remove the ACC. cap on the rear of the transceiver.
2. Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
3. Connect the 15-pin connector of the KCT-60 to a Horn alert cable, KCT-18, KES-5, or through a KCT-36 extension cable.

Note: You must setup using the KPG-141D.



1-2. Terminal function

| D-sub 15-pin Pin No. | Name | Molex 15-pin Pin No. |
|----------------------|--------------|----------------------|
| 1 | SB | 1 |
| 2 | IGN | 2 |
| 3 | PA or EXT-SP | 12 |
| 4 | DO | 4 |
| 5 | DI | 5 |
| 6 | FNC1 | 9 |
| 7 | FNC2 | 11 |
| 8 | FNC3 | 7 |
| 9 | FNC4 | 6 |
| 10 | FNC5 | 8 |
| 11 | FNC6 | 10 |
| 12 | 5C | - |
| 13 | HR1 | 13 |
| 14 | HR2 | 14 |
| 15 | GND | 3 |

2. Horn Alert Function

The Horn alert function (max. 2A drive) is enabled by installing the KCT-60 in the transceiver.


2-1. Installation Procedure

1. Remove the ACC. cap on the rear of the transceiver.
2. Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
3. Insert the two crimp terminals of the Horn alert cable to pins 13 and 14 of the square plug.
4. Connect the square plug to the 15-pin connector of the KCT-60.
5. Connect the remaining two Horn alert cables to your car Horn alert signal control.

The internal FET switch can be controlled by turning the HA function on/off and by using a signaling decode output. The maximum current of HA is 2A. This switch is the FETswitch of P-channel type. Therefore, a DC power supply is necessary to use the HR1. The voltage range is from 5V to 16V.




Note: You must set up using the KPG-141D.



3. Ignition Sense Cable (KCT-18: Option)

The KCT-18 is an optional cable for enabling the ignition function. The ignition function lets you turn the transceiver power on and off with the car ignition key.

3-1. Installing the KCT-18 (Ignition sense cable) in the transceiver



INSTALLATION

4. External Speaker (Option)

4-1. KES-5

External speaker KES-5 can be installed for KCT-60.


■ Connection procedure

1. Remove the ACC. cap on the rear of the transceiver.
2. Connect the D-sub connector of the KCT-60 to the D-sub 15-pin terminal of the transceiver.
3. Insert the two crimp terminals of the KES-5 to pins 3 and 12 of the square plug.
4. Connect the square plug to the 15-pin connector of the KCT-60.

Note:

You must set up using the KPG-141D.

Before the external speaker can be used, you must assign one of the keys as "External Speaker", using the KPG-141D.



5. Changing Serial Port Level

5-1. Change FNC1 (TXD) and FNC2 (RXD) of D-SUB 15-pin connector from TTL level to RS-232C level


FNC1 (TXD /6pin) and FNC2 (RXD /7pin) of D-SUB 15-pin connector are configured at the TTL level as the default value. But you can change these serial port level to RS-232C level through the RS-232C level converter IC (IC516) by configuring the port.

Remove the R664, R635 and R662 chip jumpers and solder the chip jumpers to R666, R633 and R665.

5-2. Change FNC1 (TXD), FNC2 (RXD), FNC3 (RTS) and FNC4 (CTS) of D-SUB 15-pin connector from TTL level to RS-232C level

FNC1 (TXD /6pin), FNC2 (RXD /7pin), FNC3 (RTS /8pin) and FNC4 (CTS /9pin) of D-SUB 15-pin connector are configured at the TTL level as the default value. But you can change these serial port level to RS-232C level through the RS-232C level converter IC (IC516) by configuring the port.

Remove the R664, R635, R662, R659, R658 and R632 chip jumpers and solder the chip jumpers to R666, R633, R665, R663, R660 and R630.



■ In the case of 5-1.

[TTL level]

R664, R635 and R662: 0Ω chip jumper.

R666, R633 and R665: open.

[RS-232C level]

R666, R633 and R665: 0Ω chip jumper.

R664, R635 and R662: open.

■ In the case of 5-2.

[TTL level]

R664, R635, R662, R659, R658 and R632: 0Ω chip jumper.

R666, R633, R665, R663, R660 and R630: open.

[RS-232C level]

R666, R633, R665, R663, R660 and R630: 0Ω chip jumper.

R664, R635, R662, R659, R658 and R632: open.

6. Changing of Signal Type

6-1. Change signal output of D-SUB connector from DEO to AFO

The output (4pin) of D-SUB 15-pin connector is configured at the DEO as the default value.

Remove the R796 chip jumper and solder the clip jumper to R798.

6-2. Change signal input of D-SUB connector from DI to MI2

The input (5pin) of D-SUB 15-pin connector is configured at the DI as the default value.


Remove the R797 chip jumper and solder the chip jumper to R799.

NX-820(G)/820


DISASSEMBLY FOR REPAIR

1. Disassembly Procedure


1. Remove the cabinet, top packing and shielding plate of the transceiver.




2. To remove the panel assembly, first turn the transceiver upside down. Then, insert a flat-head screwdriver into the holes of the chassis and tilt it in the direction as shown by the arrow.




3. Disconnect the flat cable from connector of the panel assembly.



4. Hook the finger to hole and while pulling the speaker holder to this side, expand the panel side of ① to ③, and remove the speaker holder from the front panel.



5. When removing the TX-RX PCB, first remove the top packing. Then, remove the solder of the antenna hot pin and positive terminal of the DC cord. Remove the 16 screws from the TX-RX PCB, power module, and audio amp.




NX-820(G)/820


DISASSEMBLY FOR REPAIR

Note:

When you supply power to the TX-RX PCB after removing the TX-RX PCB from the chassis, solder the positive and ground terminals of the DC cord (Recommendation: E30-3448-25) to the + and GND terminals of the TX-RX PCB.




6. Pull it out behind the chassis by rotating the bush ③ of the DC cord 90 degrees in the direction of the arrow after the screw ① in the negative terminal is removed, and the positive terminal ② is removed from the chassis.




2. Precautions for Reassembly


1. The tab from ① to ③ is applied the front panel first. And, ④ to ⑥ tabs inside the front panel is pushed.



2. When mounting the panel assembly, pass the flat cable through the hole of the chassis as shown below then connect the flat cable to connector of the panel assembly.




3. Fit the panel assembly into the two tabs of the chassis top side first. Then, fit the panel assembly into the two tabs of the chassis bottom side by turning the panel assembly.



3. Correspondence when replacing the LED (D22 and D23)

When replacing the LED (D22 and D23), it makes it to length.



CIRCUIT DESCRIPTION

1. Overview

The NX-820 is a UHF Mobile transceiver designed to operate in the frequency range of 400 to 470MHz. The unit consists of a receiver, transmitter, phase-locked loop (PLL) frequency synthesizer, base band parts, power supply, and control circuits.

2. Frequency Configuration

The receiver is a double-conversion super-heterodyne using a first intermediate frequency (IF) of 49.95MHz and a second IF of 450kHz. Incoming signals from the antenna are mixed with the local signal from the PLL circuit to produce the first IF of 49.95MHz. This is then mixed with the 50.4MHz second local oscillator output to produce the 450kHz second IF. The transmit signal frequency is generated by the PLL VCO, and modulated by the signal from the DSP. It is then amplified and fed to the antenna.




Fig.1 Frequency configuration

3. Receiver System

3-1. RF circuit

An incoming RF signal from the antenna terminal is passed through the antenna switch (D110, 111 and 107) and then the bandpass filter (L215, 216 and 210). The bandpass filter is adjusted by a variable capacitor. The input voltage to the variable capacitor is regulated by the voltage output from the D/A converter (IC712). The signal is amplified by an RF amplifier (Q202), and passed through the bandpass filter (L207, 208, 209 and 211). The resulting signal is applied to the first mixer (Q201) where it is mixed with the first local oscillator signal output from the frequency synthesizer to produce the first IF (49.95MHz).

3-2. IF circuit

The first IF signal is passed through a four-pole monolithic crystal filter (XF1) to reject the adjacent channel signal. The filtered first IF signal is amplified by the first IF amplifier (Q305) and then applied to the IF system IC (IC303). The IF system IC provides a second mixer, AGC amplifier, and RSSI (Received Signal Strength Indicator).

The second mixer mixes the first IF signal with the 50.4MHz of the second local oscillator output and produces the second IF signal of 450kHz.

The second IF signal is passed through the ceramic filter (CF1) to reject the adjacent channel signal. The filtered second IF signal is amplified by the AGC amplifier.

The signal from the AGC amplifier is input to an AD converter in ASIC (IC507) through the ceramic filter (CF2).




Fig.2 Receiver System

NX-820(G)/820

CIRCUIT DESCRIPTION

3-3. Audio amplifier circuit

Audio processing (high-pass filter, low-pass filter, de-emphasized and so on) in FM mode and decoding in NXDN mode are processed by the DSP (IC502). Audio signals from the ASIC (IC507), IC502 goes through the amplifier (IC711). The signal then goes through the D/A converter (IC712) and an amplifier (IC714).

3-4. Squelch Circuit

This circuit amplifies the demodulated noise signal from the ASIC (IC507) after filtering through a LPF and HPF circuit. The amplified signal is then converted to a DC signal by the detection circuit. The converted signal is fed back to IC507.




Fig. 3 Squelch Circuit

4. Transmitter System

4-1. Audio Band Circuit

The signal from the microphone is amplified by IC703 (1/2) and limited by the AGC circuit composed of D703, D704, Q703 and Q704. IC703 (2/2) works as an anti-aliasing LPF filter.




Fig. 4 Transmitter System

4-2. Base Band Circuit

The audio signal output from the Audio band circuit is converted to digital data with a sampling frequency of 48 kHz. This digital data is sent to the DSP (IC502), and voice signals of 300Hz or lower and frequencies of 3kHz or higher are cut off so that an audio range 300Hz to 3kHz is extracted. The audio signal is then pre-emphasized in FM mode and synthesized with the signals, such as QT and DQT, as required, and is then output from the ASIC (IC507). In Digital mode, the audio signal is converted to the 4-Level FSK base band signal and is output from IC507. The DTMF and MSK base band signals are also generated by the DSP and output from IC507.

LPF (IC701) works as smoothing filter. The output level according to the transmit carrier is fine-adjusted according to each modulation method.

4-3. Drive and Final amplifier

The signal from the T/R switch (D17 is on) is amplified by the drive amplifier (Q102) to 16~17dBm. The output of the drive amplifier is amplified by the final amplifier module (IC102) to 25W (5.0W when the power is low). The output of the final amplifier module is then passed through the harmonic filter (LPF) and antenna switch (D110, D111 are on) and directional coupler and is applied to the antenna terminal.

4-4. APC circuit

The Automatic transmission power control (APC) circuit stabilizes the transmitter output power at a predetermined level by detecting the power module output with the directional COUPLER and diode detector (D104 and D105). The diode detector (D104 and D105) applies the detected voltage to the DC amplifier IC103 (2/2).

The APC circuit is configured to protect over-current of the power module due to fluctuations of the load at the antenna end and to stabilize transmission output at voltage and temperature variations.




Fig. 5 APC Circuit

CIRCUIT DESCRIPTION

5. PLL Frequency Synthesizer

5-1. TCXO (X1)

The TCXO (X1) generates a reference frequency of 16.8MHz for the PLL frequency synthesizer. This reference frequency is applied to pin 9 of the PLL IC (IC2) and is connected to the IF circuit as a 2nd local signal through the Tripler.

The frequency adjustment is achieved by switching the ratio of the dividing frequency. The resolution of the adjusting frequency is approximately 4Hz.

5-2. VCO

There is an RX VCO and a TX VCO.

The TX VCO (Q6) generates a transmit carrier and the RX VCO (Q5) generates the 1st local signal. For the VCO oscillation frequency, the transmit carrier is 450 to 520 MHz (K-type) or 400 to 470MHz (K2-type) and the 1st local signal is 400.05 to 470.05MHz (K-type) or 350.05 to 420.05MHz (K2-type).

The VCO oscillation frequency is determined by one system of operation switching terminal "T/R" and two systems of voltage control terminals "CV" and "ASSIST".

The operation switching terminal, "T/R", is controlled by the control line (/T_R) output from the ASIC (IC507). When the /T_R logic is low, the VCO outputs the transmit carrier and when it is high, it outputs the 1st local receive signal.

The voltage control terminals, "CV" and "ASSIST", are controlled by the PLL IC (IC2) and ASIC (IC507) and the output frequency changes continuously according to the applied voltage. For the modulation input terminal, "VCO_MOD", the output frequency changes according to the applied voltage. This is used to modulate the VCO output. "VCO_MOD" works only when "/T_R" is low.

5-3. PLL IC (IC2)

The PLL IC compares the differences in phases of the VCO oscillation frequency and the TCXO reference frequency, returns the difference to the VCO CV terminal and realizes the "Phase Locked Loop" for the return control. This allows the VCO oscillation frequency to accurately match (lock) the desired frequency.

When the frequency is controlled by the PLL, the frequency convergence time increases as the frequency difference increases when the set frequency is changed. To supplement this, the ASIC (IC507) is used before control by the PLL IC to bring the VCO oscillation frequency close to the desired frequency. As a result, the VCO CV voltage does not change and is always stable at approximately 2.5V.

The desired frequency is set for the PLL IC by the ASIC (IC507) through the 3-line "SDO1", "P_SCK1", "/PCS_RF" serial bus. Whether the PLL IC is locked or not is monitored by the ASIC through the "PLD" signal line. If the VCO is not the desired frequency (unlocked), the "PLD" logic is low.

The modulation signal of the Low-speed-Data is applied to pin 23 of the PLL IC (IC2).

The modulation signal that is digital data of a sampling frequency of 96 kHz is set for the PLL IC by the DSP (IC502) through the "PLL_MOD" line.

5-4. Local Switch (D16, D17)

The connection destination of the signal output from the buffer amplifier (Q11) is changed with the diode switch (D17) that is controlled by the transmission power supply, HSW, and the diode switch (D16) that is controlled by the reception power supply, 50R. If the HSW logic is high, it is connected to a transmit-side drive (Q102). If the HSW logic is low, it is connected to a receive-side mixer (Q202).




Fig. 6 PLL circuit

CIRCUIT DESCRIPTION

6. Control Circuit

The control circuit consists of the ASIC (IC507) and its peripheral circuits. IC507 mainly performs the following:

- 1) Switching between transmission and reception via the PTT signal input.
- 2) Reading system, zone, frequency, and program data from the memory circuit.
- 3) Sending frequency program data to the PLL.
- 4) Controlling the squelch on/off using the DC voltage from the squelch circuit.
- 5) Controlling the audio mute circuit using the decode data input.

6-1. ASIC

The ASIC (IC507) is a 32bit RISC processor, equipped with a peripheral function and ADC/DAC.

This ASIC operates at 18.432MHz clock and 3.3V /1.5V DC. It controls the flash memory, SRAM, DSP, the receive circuit, the transmitter circuit, the control circuit, and the display circuit and transfers data to or from an external device.

6-2. Memory Circuit

The memory circuit consists of the ASIC (IC507), the SRAM (IC503) and the flash memory (IC501). The flash memory has a capacity of 32Mbit which contains the transceiver control program for the ASIC and stores the data. It also stores the data for the transceiver channels and operating parameters that are written by the FPU. This program can be easily written from external devices. The SRAM has a capacity of 1Mbit which contains the work area and data area.

■ Flash memory

Note: The flash memory stores the data that is written by the FPU (KPG-141D), tuning data (Deviation, Squelch, etc.) and firmware program (User mode, Test mode, Tuning mode, etc.).

■ SRAM (static memory)

Note: The SRAM has a temporary data area and work area.

6-3. Display Unit

The display unit is composed of the LCD driver IC (IC1), the LCD & Key backlight, etc.

The LCD is controlled using the 4 serial lines (LCDDI, LCDCE, LCDCL, LCDDO) from the ASIC (IC507).

6-4. Key Detection Circuit

The keys are detected using an LCD driver IC (IC1). If a pressed key is detected by IC1, the information is passed to IC507 through the serial line.

6-5. DSP

The DSP circuit consists of a DSP (IC502) and processes the base band signal. The DSP operates on an external clock of 18.432MHz (the same as the IC507), the I/O section operates at 3.3V and the core section operates at 1.5V. The DSP carries out the following processes:

- 4 level FSK processing
- Analog FM pre-emphasis/de-emphasis
- Vocoder processing between the audio codec and modulation/demodulation
- CAI processing, such as error correction encoding
- QT/DQT encoding/decoding
- DTMF encoding/decoding
- MSK encoding/decoding
- 2-tone/5-tone encoding/decoding
- Compressor/expander processing
- Voice scrambler processing
- Transmit/receive audio filtering processing
- Microphone amplifier AGC processing
- Audio mute processing
- Modulation level processing

7. Power Supply Circuit

+B is connected to the Final amplifier and the DC/DC converter IC (IC405). IC405 regulates the +B voltage to 5.0V (50M). 50M operates whenever +B is supplied. IC401 (33M) and IC408 (15M) are enabled while the 50M is operating.

33M and 15M provide the power to the ASIC (IC507), DSP (IC502), and Flash memory. At this time the ASIC starts working. The voltage detector IC (IC402) watches the +B voltage. If the +B voltage is higher than 8.6V, IC402 (/BINT) outputs High. If the /BINT signal is high, Q403 (SB SW) is turned on by the SBC signal from the ASIC. (High : SBC=ON, Low : SBC=OFF). When the SB is turned on, IC1 (80C), IC404 (50C), Q402 (80ANT), Q404 (80T), Q415, 416 (150C), Q417 (50R) and Q408 (50CS) start working. IC409, Q409 and Q410 are controlled by the SBC signal. If the SBC signal becomes High, IC409 (33C) operates, and Q409 (33A_2) and Q410 (50MC SW) turn on.

The ASIC sets the TXC signal to High during transmission to the supply power (80T) for the transmission circuit. The ASIC sets the signals (RXC) to High during reception to the supply power (50R) for the reception circuit.

When the ASIC detects the PSW (Power switch) signal, IGN (Ignition sense) signal or /BINT signal, it sets the SBC signal to Low, and turns the transceiver power (SB) off. When D401 and Q401 detect an over-voltage condition, they turn Q403 (SB SW) off, but the ASIC continues to function.

NX-820(G)/820

CIRCUIT DESCRIPTION




Fig. 7 Power supply circuit

NX-820(G)/820

CIRCUIT DESCRIPTION

8. Signaling Circuit

8-1. Encode (QT/DQT/DTMF/2-tone/5-tone/MSK)

Each signaling data signal of the QT, DQT, DTMF, 2-tone, 5-tone and MSK is generated by the DSP circuit, superposed on a modulation signal and output from the ASIC (IC507). Each deviation of the TX QT, DQT, DTMF, 2-tone, 5-tone and MSK tones are adjusted by changing the output level of the DSP (IC502) and the resulting signal is routed to the VCO and PLL.

8-2. Decode (QT/DQT/DTMF/2-tone/5-tone/MSK)

The audio signal is removed from the FM detection signal sent to the DSP circuit and the resulting signal is decoded by the DSP.

9. Compander Circuit

The term “compander” means compressor and expander. The compander reduces noise by utilizing a compressor and an expander. The DSP (IC502) performs this operation. The Compander can be turned on or off using the FPU.

10. GPS Circuit (GPS model only)

The GPS information function can be used by setting it through the FPU. The GPS signal of 1575.42MHz received with the GPS active antenna (with a built-in LNA) is processed by the GPS module (A801) and input to the ASIC (IC507) through the UART port. The ASIC (IC507) processes the GPS data (NMEA) and sends the resulting information to the LCD.

COMPONENTS DESCRIPTION

Display unit (X54-3830-10)

| Ref. No. | Part Name | Description |
|----------|-------------|---------------------------|
| IC1 | IC | LCD driver |
| Q3 | Transistor | TX/Busy LED switch |
| Q6 | Transistor | TX/Busy LED switch |
| Q8 | Transistor | LCD backlight switch |
| Q9 | Transistor | Backlight switch |
| Q10 | Transistor | Status LED switch |
| Q11 | Transistor | Backlight switch |
| D2 | Diode | Line protection |
| D5-9 | LED | Key backlight |
| D11-21 | LED | LCD backlight |
| D22 | LED | Status LED |
| D23 | LED | TX/Busy LED |
| D24 | LED | LCD backlight |
| D25 | Varistor | Line protection |
| D26 | Diode | Key control |
| D27 | Zener diode | Over DC supply protection |

TX-RX unit (X57-8240-1X)

| Ref. No. | Part Name | Description |
|----------|-----------|----------------------------------|
| IC1 | IC | AVR (80C) |
| IC2 | IC | PLL system |
| IC3 | IC | DC AMP (CV/Assist) |
| IC102 | IC | TX power module |
| IC103 | IC | OP AMP (APC) |
| IC201 | IC | DC AMP (BPF) |
| IC301 | IC | AND gate |
| IC303 | IC | FM system |
| IC304 | IC | DC AMP (RSSI) |
| IC401 | IC | AVR (33M) |
| IC402 | IC | Voltage detector (BINT) |
| IC404 | IC | AVR (50C) |
| IC405 | IC | DC/DC converter (50M) |
| IC406 | IC | AVR (33A) |
| IC407 | IC | AVR (33GPS) |
| IC408 | IC | AVR (15M) |
| IC409 | IC | AVR (33C) |
| IC501 | IC | Flash memory |
| IC502 | IC | DSP |
| IC503 | IC | SRAM |
| IC504 | IC | Reset |
| IC506 | IC | Buffer AMP (Clock) |
| IC507 | IC | ASIC |
| IC508 | IC | AND gate |
| IC509 | IC | Dual BUS buffer (HOOK/RXD/MKEYI) |
| IC511 | IC | BUS buffer |
| IC512 | IC | Level shift |
| IC513 | IC | Dual BUS buffer (FNC3/FNC1) |
| IC514 | IC | Dual BUS buffer (FNC2/FNC4) |
| IC515 | IC | I/O expander |
| IC516 | IC | RS-232C driver |
| IC701 | IC | VCO MOD/VREF |
| IC702 | IC | LPF (APC/DMO) |
| IC703 | IC | MIC SUM AMP/LPF (DI) |
| IC705 | IC | BPF/Buffer AMP (SQ) |
| IC711 | IC | RX SUM AMP/LPF (RX AF) |
| IC712 | IC | D/A converter |
| IC713 | IC | MIC/RX selector |
| IC714 | IC | AF power AMP |
| IC716 | IC | Dual BUS buffer (TXD1/MKEO) |
| IC801 | IC | Dual BUS buffer (TXD2/RXD2) |

NX-820(G)/820

COMPONENTS DESCRIPTION

| Ref. No. | Part Name | Description |
|----------|-------------|---------------------------------------|
| Q1 | Transistor | DC switch (Assist) |
| Q2 | FET | DC switch (Assist) |
| Q4 | Transistor | Ripple filter |
| Q5 | Transistor | Buffer AMP (PLL fin) |
| Q6 | FET | RX VCO |
| Q7 | FET | TX VCO |
| Q8,9 | FET | T/R VCO switch |
| Q10,11 | Transistor | Buffer AMP |
| Q102 | Transistor | TX Drive AMP |
| Q105 | FET | DC switch (H/L power) |
| Q106 | Transistor | DC switch (50C) |
| Q201 | FET | RX 1st mixer |
| Q202 | Transistor | LNA |
| Q303 | Transistor | Tripler |
| Q305 | Transistor | 1st IF AMP |
| Q401 | Transistor | DC Switch (Over DC supply protection) |
| Q402 | Transistor | DC switch (80ANT) |
| Q403 | FET | DC switch (SB) |
| Q404 | Transistor | DC switch (80T) |
| Q405 | Transistor | DC switch (80ANT) |
| Q407 | Transistor | DC switch (50MC) |
| Q408 | Transistor | DC switch (50CS) |
| Q409 | FET | DC switch (33A_2) |
| Q410 | Transistor | DC switch (50MC) |
| Q411 | Transistor | DC switch (80T) |
| Q412 | Transistor | DC switch (80ANT) |
| Q414 | Transistor | DC switch (150C) |
| Q415,416 | Transistor | DC/DC converter |
| Q417 | Transistor | DC switch (50R) |
| Q418 | FET | DC switch (SB) |
| Q501 | FET | DC switch (System) |
| Q502 | Transistor | DC switch (Horn alert) |
| Q503 | FET | DC switch (Horn alert) |
| Q504 | Transistor | DC switch (IGN) |
| Q701 | FET | SQL noise BW switch |
| Q702 | Transistor | Noise AMP |
| Q703,704 | Transistor | MIC AGC |
| Q705 | FET | Mute (MI1) |
| Q706 | FET | Mute (MI2) |
| Q708 | Transistor | Pop noise prevention switch |
| Q709 | FET | AF mute switch |
| D2 | Zener diode | Over voltage protection |

| Ref. No. | Part Name | Description |
|----------|----------------------------|----------------------------|
| D4 | Variable capacitance diode | RX VCO frequency control |
| D5 | Variable capacitance diode | TX VCO frequency control |
| D6 | Variable capacitance diode | PLL f-in BPF tune |
| D7 | Variable capacitance diode | RX VCO assist tune |
| D8 | Variable capacitance diode | TX VCO assist tune |
| D9,10 | Variable capacitance diode | RX VCO assist tune |
| D11 | Variable capacitance diode | TX VCO assist tune |
| D13 | Variable capacitance diode | PLL f-in BPF tune |
| D14 | Diode | Speed up |
| D15 | Variable capacitance diode | FM modulation |
| D16,17 | Diode | T/R switch |
| D101 | Zener diode | Over voltage protection |
| D102 | Diode | Voltage shift |
| D103 | Diode | Reverse current prevention |
| D104,105 | Diode | TX Power detection |
| D106 | Diode | Reverse current prevention |
| D107 | Diode | Antenna switch |
| D108,109 | Diode | Over DC supply protection |
| D110,110 | Diode | Antenna switch |
| D112-114 | Diode | Over DC supply protection |
| D202-207 | Variable capacitance diode | RX BPF tune |
| D401 | Zener diode | Over DC supply protection |
| D403,404 | Diode | Reverse current prevention |
| D405 | Diode | Discharge |
| D406 | Diode | DC/DC converter |
| D407 | Diode | DC/DC converter (50M) |
| D408,409 | Diode | DC/DC converter |
| D410 | Surge absorption | Surge protection |
| D411 | Diode | Reverse current prevention |
| D502 | Diode | Reverse current prevention |
| D504 | Diode | Reverse current prevention |
| D505-510 | Diode | Line protection |
| D511-513 | Diode | Reverse current prevention |
| D601 | Diode | Line protection |
| D701 | Diode | Reverse current prevention |
| D702 | Diode | Noise detector |
| D703,704 | Diode | AF detector |
| D705,706 | Diode | Line protection |
| D801,802 | Diode | Over DC supply protection |

NX-820(G)/820

PARTS LIST

* New Parts. Δ indicates safety critical components.
 Parts without **Parts No.** are not supplied.
 Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
 Teile ohne **Parts No.** werden nicht geliefert.

L : Scandinavia K : USA P : Canada
 Y : PX (Far East, Hawaii) T : England E : Europe
 C : China X : Australia M : Other Areas

NX-820(G)/820
 DISPLAY UNIT (X54-3830-10)

| Ref. No. | Address | New parts | Parts No. | Description | Desti-nation | Ref. No. | Address | New parts | Parts No. | Description | Desti-nation |
|----------------------|---------|-----------|-------------|------------------------------|--------------|-----------------------------------|---------|-----------|---------------|---------------------------|--------------|
| NX-820(G)/820 | | | | | | DISPLAY UNIT (X54-3830-10) | | | | | |
| 1 | 1B | | A02-4073-21 | PLASTIC CABINET | | 101 | 2A | | B11-1885-03 | ILLUMINATION GUIDE | |
| 2 | 2B | | A10-4161-01 | CHASSIS | | 102 | 2A | | B38-0936-05 | LCD | |
| 3 | 3A | | A62-1200-03 | PANEL ASSY | | D5 -9 | | | B30-2337-05 | LED(YELLOW) | |
| 5 | 2B | | B09-0732-03 | CAP(D-SUB) | | D11 -21 | | | B30-2337-05 | LED(YELLOW) | |
| 6 | 2B | | B09-0754-05 | CAP(SMA) | GE | D22 | 3A | | B30-2321-05 | LED(BLUE LED) | |
| 7 | 3A | | B43-1675-04 | BADGE | | D23 | 3A | | B30-2151-05 | LED(RED/GREEN) | |
| 9 | 2B | | E04-0454-15 | RF COAXIAL RECEPTACLE(BNC) | | D24 | | | B30-2337-05 | LED(YELLOW) | |
| 10 | 2B | | E04-0492-05 | RF COAXIAL RECEPTACLE(SMA) | GE | C1 | | | CC73HCH1H101J | CHIP C 100PF | J |
| 11 | 2A | | E29-1244-14 | RELAY HARDWARE(CHASSIS) | | C2 ,3 | | | CC73HCH1H221J | CHIP C 220PF | J |
| 12 | 2B | | E30-7684-15 | DC CORD | | C4 | | | CC73HCH1H101J | CHIP C 100PF | J |
| 13 | 2A | | E37-1461-05 | FLAT CABLE(30P) | | C5 | | | CC73HCH1H221J | CHIP C 220PF | J |
| 15 | 2B | | F10-3183-03 | SHIELDING CASE(POWER MODULE) | | C6 | | | CK73HB1H471K | CHIP C 470PF | K |
| 16 | 1B | | F10-3184-03 | SHIELDING COVER(TOP) | | C7 | | | CK73HB1H102K | CHIP C 1000PF | K |
| 17 | 1B | | F10-3203-02 | SHIELDING CASE(LPF) | | C10 | | | CK73HB1H102K | CHIP C 1000PF | K |
| 19 | 1A | | G11-4353-04 | SHEET(SHIELDING/BOTTOM) | | C11 | | | CC73HCH1H221J | CHIP C 220PF | J |
| 20 | 2B | | G11-4578-04 | SHEET(FOR W/O SMA) | E | C12 | | | CC73HCH1H101J | CHIP C 100PF | J |
| 21 | 1B | | G11-4611-04 | SHEET(D-SUB) | | C13 | | | CK73HB1E103K | CHIP C 0.010UF | K |
| 22 | 1B | | G13-2102-04 | CONDUCTIVE CUSHION | | C14 ,15 | | | CK73HB1H102K | CHIP C 1000PF | K |
| 23 | 3B | | G13-2363-04 | CUSHION(PANEL HOLDER) | | C21 | | | CK73HB1E103K | CHIP C 0.010UF | K |
| 24 | 1B | | G13-2389-04 | CUSHION(SHIELDING/TOP) | | C23 | | | CK73HB1H102K | CHIP C 1000PF | K |
| 25 | 2B | | G13-2395-04 | CUSHION(X57) | | C24 ,25 | | | CK73HB1E103K | CHIP C 0.010UF | K |
| 26 | 2B | | G53-1643-04 | PACKING(DC CORD) | | C27 | | | CK73HB1A105K | CHIP C 1.0UF | K |
| 27 | 2B | | G53-1662-04 | PACKING(BNC/ANT) | | C31 | | | CK73HB1H102K | CHIP C 1000PF | K |
| 28 | 2B | | G53-1768-04 | PACKING(SMA) | GE | C32 ,33 | | | CK73HB1C473K | CHIP C 0.047UF | K |
| 31 | 1B | | G53-1819-21 | PACKING(CHASSIS) | | C34 | | | CC73HCH1H470J | CHIP C 47PF | J |
| 32 | 3A | | G53-1820-03 | PACKING(PANEL) | | C35 ,36 | | | CC73HCH1H221J | CHIP C 220PF | J |
| 33 | 3A | | G53-1858-03 | PACKING(SP) | | 103 | 2A | | E29-1231-15 | INTER CONNECTOR | |
| 35 | 3A | | J19-5542-02 | HOLDER(PANEL) | | CN1 | | | E40-6924-05 | FLAT CABLE CONNECTOR(30P) | |
| 36 | 3A | | K29-9479-01 | KEY TOP | | J1 | 3A | | E58-0535-05 | MODULAR JACK(MIC) | |
| A | 2B | | N30-2605-48 | PAN HEAD MACHINE SCREW | GE | 104 | 2A | | J21-8629-03 | MOUNTING HARDWARE(LCD) | |
| B | 2A,2B | | N67-3008-48 | PAN HEAD SEMS SCREW | | L1 | | | L92-0138-05 | CHIP FERRITE | |
| C | 2A,2B | | N87-2608-48 | BRAZIER HEAD TAPTITE SCREW | | L2 ,3 | | | L92-0140-05 | CHIP FERRITE | |
| 37 | 3A | | T07-0785-15 | SPEAKER | | CP1 | | | RK74HB1J101J | CHIP-COM 100 | J 1/16W |
| | | | | | | R1 | | | RK73HB1J101J | CHIP R 100 | J 1/16W |
| | | | | | | R2 -4 | | | RK73HB1J103J | CHIP R 10K | J 1/16W |
| | | | | | | R5 | | | RK73HB1J102J | CHIP R 1.0K | J 1/16W |
| | | | | | | R7 | | | RK73HB1J000J | CHIP R 0 | J 1/16W |
| | | | | | | R9 | | | RK73HB1J000J | CHIP R 0 | J 1/16W |
| | | | | | | R12 | | | RK73HB1J101J | CHIP R 100 | J 1/16W |
| | | | | | | R14 | | | RK73HB1J122J | CHIP R 1.2K | J 1/16W |
| | | | | | | R15 | | | RK73HB1J000J | CHIP R 0 | J 1/16W |
| | | | | | | R17 | | | RK73HB1J000J | CHIP R 0 | J 1/16W |
| | | | | | | R18 | | | RK73GB2A331J | CHIP R 330 | J 1/10W |
| | | | | | | R19 | | | RK73GB2A221J | CHIP R 220 | J 1/10W |
| | | | | | | R20 | | | RK73HB1J000J | CHIP R 0 | J 1/16W |
| | | | | | | R22 | | | RK73HB1J000J | CHIP R 0 | J 1/16W |
| | | | | | | R23 | | | RK73HB1J473J | CHIP R 47K | J 1/16W |
| | | | | | | R24 ,25 | | | RK73HB1J332J | CHIP R 3.3K | J 1/16W |
| | | | | | | R26 | | | RK73HB1J472J | CHIP R 4.7K | J 1/16W |
| | | | | | | R28 | | | RK73FB2B121J | CHIP R 120 | J 1/8W |
| | | | | | | R29 | | | RK73FB2B221J | CHIP R 220 | J 1/8W |
| | | | | | | R34 -37 | | | RK73GB2A271J | CHIP R 270 | J 1/10W |
| | | | B62-2447-00 | INSTRUCTION MANUAL | ACCESSORY | | | | | | |
| | | | E30-7523-55 | DC CORD ASSY | ACCESSORY | | | | | | |
| | | | F52-0024-05 | FUSE(15A/BLADE) | ACCESSORY | | | | | | |
| | | | J29-0726-03 | BRACKET | ACCESSORY | | | | | | |
| | | | N99-2039-05 | SCREW SET | ACCESSORY | | | | | | |
| | | | X57-8240-16 | TX-RX UNIT(FOR SERVICE) | GE | | | | | | |
| | | | X57-8240-17 | TX-RX UNIT(FOR SERVICE) | E | | | | | | |

GE: NX-820(G)
 E: NX-820

NX-820(G)/820

PARTS LIST

DISPLAY UNIT (X54-3830-10)

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|--------------------------------------------------|---------|-----------|----------------|------------------------|-------------|
| R38 -40 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R41 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R42 | | | RK73HB1J272J | CHIP R 2.7K J 1/16W | |
| R43 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R44 | | | RK73HB1J222J | CHIP R 2.2K J 1/16W | |
| R45 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| D1 | | | DZ2J062(M) | ZENER DIODE | |
| D2 | | | DA3S101F | DIODE | |
| D25 | | | MINISMDC020F | VARISTOR | |
| D26 | | | HN2S03FE | DIODE | |
| D27 | | | DZ2J062(M) | ZENER DIODE | |
| IC1 | | | LC75857W-E | MOS-IC | |
| Q3 | | | KTC4075E(Y,GR) | TRANSISTOR | |
| Q6 | | | KTC4075E(Y,GR) | TRANSISTOR | |
| Q8 | | | KTC4075E(Y,GR) | TRANSISTOR | |
| Q9 | | | QST7 | TRANSISTOR | |
| Q10 | | | LTC014EEBFS8 | TRANSISTOR | |
| Q11 | | | KTC4075E(Y,GR) | TRANSISTOR | |
| TX-RX UNIT (X57-8240-1X) -12: (G)E -13: E | | | | | |
| C1 | | | CK73HB1E103K | CHIP C 0.010UF K | |
| C2 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C3 ,4 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C5 ,6 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C7 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C8 | | | CK73HB1H471K | CHIP C 470PF K | |
| C9 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C10 ,11 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C12 | | | CC73HCH1H070B | CHIP C 7.0PF B | |
| C16 -21 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C22 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C23 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C25 ,26 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C28 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C29 | | | CS77MA1VR15M | CHIP TNL 0.15UF 35WV | |
| C30 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C31 | | | CC73HCH1H470J | CHIP C 47PF J | |
| C32 | | | CS77BA1D100M | CHIP TNL 10UF 20WV | |
| C33 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C34 | | | C93-1906-05 | CHIP FILM 0.047UF 35WV | |
| C36 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C39 | | | CC73HCH1H330J | CHIP C 33PF J | |
| C41 | | | CK73HB1H471K | CHIP C 470PF K | |
| C43 | | | CK73HB1H471K | CHIP C 470PF K | |
| C46 | | | CC73HCH1H050B | CHIP C 5.0PF B | |
| C47 | | | CC73HCH1H040B | CHIP C 4.0PF B | |
| C48 | | | CC73HCH1H050B | CHIP C 5.0PF B | |
| C49 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C50 | | | CC73HCH1H151J | CHIP C 150PF J | |
| C51 | | | CC73HCH1H271J | CHIP C 270PF J | |
| C53 | | | CC73HCH1H050B | CHIP C 5.0PF B | |
| C54 | | | CC73HCH1H080B | CHIP C 8.0PF B | |
| C55 | | | CK73HB0J105K | CHIP C 1.0UF K | |
| C56 | | | CC73HCH1H060B | CHIP C 6.0PF B | |
| C57 ,58 | | | CK73HB1H471K | CHIP C 470PF K | |
| C59 | | | CC73HCH1H240G | CHIP C 24PF G | |
| C63 | | | CC73HCH1H0R5B | CHIP C 0.5PF B | |
| C64 | | | CK73FB1A106K | CHIP C 10UF K | |
| C65 | | | CK73HB1H471K | CHIP C 470PF K | |
| C66 | | | CC73HCH1H070B | CHIP C 7.0PF B | |
| C67 | | | CC73HCH1H050B | CHIP C 5.0PF B | |
| C68 ,69 | | | CC73HCH1H060B | CHIP C 6.0PF B | |
| C70 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C71 | | | CC73HCH1H180G | CHIP C 18PF G | |
| C72 | | | CC73HCH1H040B | CHIP C 4.0PF B | |
| C73 | | | CK73HB1H471K | CHIP C 470PF K | |
| C74 | | | CC73HCH1H0R5B | CHIP C 0.5PF B | |
| C76 | | | CC73HCH1H0R5B | CHIP C 0.5PF B | |
| C78 | | | CK73HB1H471K | CHIP C 470PF K | |
| C80 | | | CK73HB1H471K | CHIP C 470PF K | |
| C81 | | | CC73HCH1H070B | CHIP C 7.0PF B | |
| C82 | | | CK73HB1H471K | CHIP C 470PF K | |
| C83 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C84 | | | CC73HCH1H030B | CHIP C 3.0PF B | |
| C85 -87 | | | CK73HB1H471K | CHIP C 470PF K | |
| C88 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C89 | | | CC73HCH1H060B | CHIP C 6.0PF B | |
| C90 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C91 | | | C93-0787-05 | CHIP C 0.1UF J | |
| C102 | | | CK73HB1H471K | CHIP C 470PF K | |
| C103 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C104 | | | CK73HB1H471K | CHIP C 470PF K | |
| C106,107 | | | CK73HB1H471K | CHIP C 470PF K | |
| C108 | | | CK73FB1E475K | CHIP C 4.7UF K | |
| C109 | | | CC73HCH1H060B | CHIP C 6.0PF B | |
| C110,111 | | | CK73HB1H471K | CHIP C 470PF K | |
| C113 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C116 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C117,118 | | | CK73HB1H471K | CHIP C 470PF K | |
| C119 | | | CC73HCH1H060B | CHIP C 6.0PF B | |
| C124 | | | CC73HCH1H070B | CHIP C 7.0PF B | |
| C125 | | | CK73HB1H471K | CHIP C 470PF K | |
| C127 | | | CC73HCH1H220J | CHIP C 22PF J | |
| C128 | | | CC73HCH1H470J | CHIP C 47PF J | |
| C129 | | | CC73HCH1H070B | CHIP C 7.0PF B | |
| C131 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C133 | | | CC73HCH1H221J | CHIP C 220PF J | |
| C134,135 | | | CK73HB1H471K | CHIP C 470PF K | |
| C136 | | | CK73FB1H471K | CHIP C 470PF K | |
| C137 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C140 | | | CS77LA1C4R7M | CHIP TNL 4.7UF 1 16WV | |
| C142 | | | CC73HCH1H220J | CHIP C 22PF J | |
| C144 | | | CC73HCH1H470J | CHIP C 47PF J | |
| C145 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C148 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C149 | | | CK73HB1H471K | CHIP C 470PF K | |
| C150 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C151 | | | C93-0553-05 | CHIP C 3.0PF C | |
| C152 | | | C92-0875-05 | ELECTRO 47UF 25WV | |
| C154 | | | CK73HB1E223K | CHIP C 0.022UF K | |
| C155 | | | CK73HB1H471K | CHIP C 470PF K | |
| C156 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C157 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C158 | | | CK73HB1H471K | CHIP C 470PF K | |
| C161 | | | CC73GCH1H040C | CHIP C 4.0PF C | |
| C165 | | | CK73HB1H471K | CHIP C 470PF K | |
| C167 | | | CC73GCH1H040C | CHIP C 4.0PF C | |
| C168 | | | CK73HB1H471K | CHIP C 470PF K | |

PARTS LIST

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Desti-nation | Ref. No. | Address | New parts | Parts No. | Description | Desti-nation |
|----------|---------|-----------|---------------|--------------------|--------------|----------|---------|-----------|---------------|--------------------|--------------|
| C169 | | | CK73HB1H102K | CHIP C 1000PF K | | C295 | | | CC73HCH1H060B | CHIP C 6.0PF B | |
| C171 | | | CC73HCH1H101J | CHIP C 100PF J | | C296 | | | CC73HCH1H180G | CHIP C 18PF G | |
| C172,173 | | | CK73HB1H471K | CHIP C 470PF K | | C297 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C175 | | | CC73FCH1H060B | CHIP C 6.0PF B | | C299 | | | CK73HB1H471K | CHIP C 470PF K | |
| C177 | | | C93-1871-05 | CHIP C 100PF 250WV | | C306 | | | CK73HB1E103K | CHIP C 0.010UF K | |
| C179 | | | C93-0554-05 | CHIP C 4.0PF C | | C307 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C180 | | | C93-0556-05 | CHIP C 6.0PF D | | C309 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C184 | | | C93-0557-05 | CHIP C 7.0PF D | | C312 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C187,188 | | | CK73HB1H102K | CHIP C 1000PF K | | C313 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C190 | | | CC73HCH1H070B | CHIP C 7.0PF B | | C315 | | | CK73HB1E103K | CHIP C 0.010UF K | |
| C191 | | | CC73GCH1H220J | CHIP C 22PF J | | C316 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C192 | | | CC73GCH1H120J | CHIP C 12PF J | | C317 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C193 | | | CC73GCH1H330J | CHIP C 33PF J | | C322 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C194 | | | CC73GCH1H100D | CHIP C 10PF D | | C323 | | | CC73HCH1H151J | CHIP C 150PF J | |
| C197 | | | C93-1857-05 | CHIP C 8PF 250WV | | C324 | | | CC73HCH1H330G | CHIP C 33PF G | |
| C201,202 | | | CK73HB1E103K | CHIP C 0.010UF K | | C325 | | | CC73HCH1H680G | CHIP C 68PF G | |
| C203 | | | CK73HB1H471K | CHIP C 470PF K | | C326 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C204 | | | CK73FB1E475K | CHIP C 4.7UF K | | C327 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C205 | | | CK73HB1H471K | CHIP C 470PF K | | C330 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C206 | | | CC73HCH1H1R5B | CHIP C 1.5PF B | | C332-335 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C207 | | | CK73HB1H471K | CHIP C 470PF K | | C336 | | | CK73FB1A106K | CHIP C 10UF K | |
| C208 | | | CC73HCH1H060B | CHIP C 6.0PF B | | C337 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C209 | | | CC73HCH1H120J | CHIP C 12PF J | | C338 | | | CK73FB1A106K | CHIP C 10UF K | |
| C210 | | | CK73HB1E103K | CHIP C 0.010UF K | | C339 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C211 | | | CC73HCH1H010B | CHIP C 1.0PF B | | C340 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C212 | | | CC73HCH1H120G | CHIP C 12PF G | | C341 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C213 | | | CC73HCH1H020B | CHIP C 2.0PF B | | C342 | | | CK73HB1A105K | CHIP C 1.0UF K | |
| C214 | | | CC73HCH1H080B | CHIP C 8.0PF B | | C343-345 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C215,216 | | | CK73HB1H471K | CHIP C 470PF K | | C346 | | | CK73HB1A105K | CHIP C 1.0UF K | |
| C217 | | | CC73HCH1H020B | CHIP C 2.0PF B | | C347 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C218 | | | CC73HCH1H050B | CHIP C 5.0PF B | | C348 | | | CC73HCH1H470J | CHIP C 47PF J | |
| C219 | | | CK73HB1H471K | CHIP C 470PF K | | C350 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C220 | | | CC73HCH1H150G | CHIP C 15PF G | | C351 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C221 | | | CC73HCH1H080B | CHIP C 8.0PF B | | C357 | | | CC73HCH1H0R5B | CHIP C 0.5PF B | |
| C222 | | | CC73HCH1H100B | CHIP C 10PF B | | C358 | | | CC73HCH1H100B | CHIP C 10PF B | |
| C223 | | | CK73HB1H471K | CHIP C 470PF K | | C359-361 | | | CK73HB1E103K | CHIP C 0.010UF K | |
| C224 | | | CC73HCH1H150G | CHIP C 15PF G | | C363 | | | CC73HCH1H220G | CHIP C 22PF G | |
| C225 | | | CC73HCH1H040B | CHIP C 4.0PF B | | C366 | | | CK73HB1E103K | CHIP C 0.010UF K | |
| C226 | | | CC73HCH1H050B | CHIP C 5.0PF B | | C367 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C227,228 | | | CK73HB1H471K | CHIP C 470PF K | | C368 | | | CK73HB1H471K | CHIP C 470PF K | |
| C230 | | | CC73HCH1H100B | CHIP C 10PF B | | C369 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C231 | | | CC73HCH1H050B | CHIP C 5.0PF B | | C371 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C232 | | | CC73HCH1H090B | CHIP C 9.0PF B | | C401 | | | C92-0968-05 | ELECTRO 470UF 25WV | |
| C233 | | | CK73HB1H471K | CHIP C 470PF K | | C403 | | | CK73HB1H471K | CHIP C 470PF K | |
| C234 | | | CC73HCH1H100B | CHIP C 10PF B | | C405 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C239 | | | CK73GB1H104K | CHIP C 0.10UF K | | C408,409 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C240 | | | CK73GB1E105K | CHIP C 1.0UF K | | C410 | | | CK73GB1C225K | CHIP C 2.2UF K | |
| C246 | | | CK73HB1H471K | CHIP C 470PF K | | C411 | | | CK73GB1H104K | CHIP C 0.10UF K | |
| C250 | | | CK73HB1H471K | CHIP C 470PF K | | C413 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C251 | | | CC73HCH1H070B | CHIP C 7.0PF B | | C416 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C252,253 | | | CK73HB1H471K | CHIP C 470PF K | | C417 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C254 | | | CC73HCH1H040B | CHIP C 4.0PF B | | C420 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C256 | | | CC73HCH1H180G | CHIP C 18PF G | | C422 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C263 | | | CC73HCH1H100B | CHIP C 10PF B | | C423,424 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C289 | | | CC73HCH1H101J | CHIP C 100PF J | | C425 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C290 | | | CC73HCH1H030B | CHIP C 3.0PF B | | C427 | | | CK73GB1H473K | CHIP C 0.047UF K | |
| C291 | | | CC73HCH1H020B | CHIP C 2.0PF B | | C428 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C292 | | | CC73HCH1H080B | CHIP C 8.0PF B | | C429 | | | CK73HB1H471K | CHIP C 470PF K | |
| C293 | | | CK73HB1H471K | CHIP C 470PF K | | C430 | | | CK73FB1E475K | CHIP C 4.7UF K | |
| C294 | | | CC73HCH1H100B | CHIP C 10PF B | | C431 | | | CC73HCH1H101J | CHIP C 100PF J | |

NX-820(G)/820

PARTS LIST

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|----------|---------|-----------|---------------|---------------------|-------------|----------|---------|-----------|---------------|------------------|-------------|
| C432 | | | CK73GB1H104K | CHIP C 0.10UF K | | C553 | | | CK73HB1A105K | CHIP C 1.0UF K | |
| C433,434 | | | CK73FB1E475K | CHIP C 4.7UF K | | C555,556 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C435 | | | CK73GB1C225K | CHIP C 2.2UF K | | C558 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C436 | | | CK73HB1H103K | CHIP C 0.010UF K | | C559 | | | CK73FB1A106K | CHIP C 10UF K | |
| C437 | | | CK73FB1E475K | CHIP C 4.7UF K | | C560 | | | CC73HCH1H030B | CHIP C 3.0PF B | |
| C438,439 | | | CK73GB1H104K | CHIP C 0.10UF K | | C563 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C440 | | | C92-0875-05 | ELECTRO 47UF 25WV | | C565-568 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C441 | | | CK73GB1C225K | CHIP C 2.2UF K | | C569 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C442 | | | CK73HB1H103K | CHIP C 0.010UF K | | C570 | | | CK73HB1A105K | CHIP C 1.0UF K | |
| C443 | | | CK73GB1E105K | CHIP C 1.0UF K | | C572-576 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C445,446 | | | CK73HB1H103K | CHIP C 0.010UF K | | C577 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C447 | | | CK73GB1E105K | CHIP C 1.0UF K | | C578 | | | CK73HB1A105K | CHIP C 1.0UF K | |
| C448 | | | CK73HB1H103K | CHIP C 0.010UF K | | C579-581 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C449 | | | CK73GB1E105K | CHIP C 1.0UF K | | C602 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C450,451 | | | CK73FB1A106K | CHIP C 10UF K | | C603 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C452 | | | CS77LA1C4R7M | CHIP TNL 4.7UF 16WV | | C604 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C453 | | | CK73HB1H103K | CHIP C 0.010UF K | | C605 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C454,455 | | | CK73GB1C225K | CHIP C 2.2UF K | | C607 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C456 | | | CK73HB1H103K | CHIP C 0.010UF K | | C609-611 | | | CC73HCH1H470J | CHIP C 47PF J | |
| C457,458 | | | CC73HCH1H101J | CHIP C 100PF J | | C612 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C460 | | | CC73HCH1H101J | CHIP C 100PF J | | C613 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C461 | | | CK73HB1A105K | CHIP C 1.0UF K | | C614-618 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C462 | | | CK73GB1E105K | CHIP C 1.0UF K | | C620 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C463 | | | CC73HCH1H101J | CHIP C 100PF J | | C621 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C464 | | | CK73HB1A105K | CHIP C 1.0UF K | | C622-624 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C465,466 | | | CK73GB1E105K | CHIP C 1.0UF K | | C625 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C468 | | | CK73HB1H103K | CHIP C 0.010UF K | | C626 | | | CK73GB1H103K | CHIP C 0.010UF K | |
| C469 | | | CK73HB1A105K | CHIP C 1.0UF K | | C627-630 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C471 | | | CC73HCH1H101J | CHIP C 100PF J | | C632 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C472 | | | CK73HB1H102K | CHIP C 1000PF K | | C633-642 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C475 | | | CK73GB1E105K | CHIP C 1.0UF K | | C643 | | | CK73HB1E223K | CHIP C 0.022UF K | |
| C476 | | | CK73HB1A104K | CHIP C 0.10UF K | | C644 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C477 | | | CK73GB1H104K | CHIP C 0.10UF K | | C645 | | | CK73GB1H103K | CHIP C 0.010UF K | |
| C501-504 | | | CK73HB1A104K | CHIP C 0.10UF K | | C646 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C505-507 | | | CK73GB0J106K | CHIP C 10UF K | | C647 | | | CK73HB1H103K | CHIP C 0.010UF K | |
| C508,509 | | | CK73HB1A105K | CHIP C 1.0UF K | | C648 | | | CK73GB1H104K | CHIP C 0.10UF K | |
| C510 | | | CK73HB1A104K | CHIP C 0.10UF K | | C649 | | | CK73GB1H103K | CHIP C 0.010UF K | |
| C512 | | | CK73HB1A104K | CHIP C 0.10UF K | | C650-652 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C514-516 | | | CK73HB1A104K | CHIP C 0.10UF K | | C660 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C518-520 | | | CK73HB1A104K | CHIP C 0.10UF K | | C661 | | | CC73HCH1H470J | CHIP C 47PF J | |
| C521 | | | CC73HCH1H101J | CHIP C 100PF J | | C680 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C522,523 | | | CK73HB1A104K | CHIP C 0.10UF K | | C701 | | | CK73HB1H682K | CHIP C 6800PF K | |
| C524 | | | CK73HB1A105K | CHIP C 1.0UF K | | C702 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C525-531 | | | CK73HB1A104K | CHIP C 0.10UF K | | C704 | | | CK73HB1A105K | CHIP C 1.0UF K | |
| C532 | | | CK73HB1H103K | CHIP C 0.010UF K | | C705 | | | CC73HCH1H470J | CHIP C 47PF J | |
| C533 | | | CK73GB0J106K | CHIP C 10UF K | | C706 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C534 | | | CK73HB1A104K | CHIP C 0.10UF K | | C707 | | | CK73HB1H681K | CHIP C 680PF K | |
| C535 | | | CK73HB1H272K | CHIP C 2700PF K | | C708 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C536 | | | CK73HB1A104K | CHIP C 0.10UF K | | C709 | | | CC73HCH1H270J | CHIP C 27PF J | |
| C537 | | | CK73HB1H102K | CHIP C 1000PF K | | C711 | | | CC73HCH1H331J | CHIP C 330PF J | |
| C541 | | | CK73HB1A104K | CHIP C 0.10UF K | | C712 | | | CC73HCH1H181J | CHIP C 180PF J | |
| C542 | | | CK73HB1H103K | CHIP C 0.010UF K | | C714 | | | CC73HCH1H680J | CHIP C 68PF J | |
| C543,544 | | | CK73HB1A104K | CHIP C 0.10UF K | | C716 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C545 | | | CK73FB1A106K | CHIP C 10UF K | | C718 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C546 | | | CK73HB1H103K | CHIP C 0.010UF K | | C719 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C547 | | | CC73HCH1H101J | CHIP C 100PF J | | C720 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C548 | | | CK73HB1H103K | CHIP C 0.010UF K | | C722 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C549 | | | CK73HB1A104K | CHIP C 0.10UF K | | C723 | | | CC73HCH1H470J | CHIP C 47PF J | |
| C551 | | | CK73HB1A104K | CHIP C 0.10UF K | | C725 | | | CC73HCH1H121J | CHIP C 120PF J | |
| C552 | | | CK73HB1H103K | CHIP C 0.010UF K | | C728 | | | CK73HB1H821K | CHIP C 820PF K | |

PARTS LIST

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Desti-nation | Ref. No. | Address | New parts | Parts No. | Description | Desti-nation |
|----------|---------|-----------|---------------|--------------------|--------------|-----------|---------|-----------|-------------|------------------------------|--------------|
| C729 | | | CK73HB1H681K | CHIP C 680PF K | | CN10-12 | | | E23-1278-05 | TERMINAL | |
| C732 | | | CK73HB1H102K | CHIP C 1000PF K | | CN14,15 | | | E23-1278-05 | TERMINAL | |
| C733 | | | CK73FB1E475K | CHIP C 4.7UF K | | CN203-206 | | | E23-1278-05 | TERMINAL | |
| C734 | | | CK73HB1H472K | CHIP C 4700PF K | | CN514 | | | E40-6847-05 | FLAT CABLE CONNECTOR(30P) | |
| C735 | | | CK73GB0J106K | CHIP C 10UF K | | CN801 | | | E04-0410-05 | PIN SOCKET(3P) | GE |
| C738 | | | CK73HB1A104K | CHIP C 0.10UF K | | J501 | 1B | | E58-0536-05 | D-SUB SOCKET(15P) | |
| C739 | | | CK73HB1A105K | CHIP C 1.0UF K | | J701 | 2B | | E11-0425-05 | 3.5D PHONE JACK(EXT-SP) | |
| C740 | | | CK73HB1H102K | CHIP C 1000PF K | | F401 | | | F53-0328-15 | FUSE(5A) | |
| C741 | | | CK73HB1A224K | CHIP C 0.22UF K | | F501 | | | F53-0324-15 | FUSE(2.5A) | |
| C743 | | | CC73HCH1H470J | CHIP C 47PF J | | F502 | | | F53-0315-15 | FUSE(250MA) | |
| C744 | | | CK73HB1A224K | CHIP C 0.22UF K | | F503 | | | F53-0316-15 | FUSE(375MA) | |
| C746 | | | CK73HB1A104K | CHIP C 0.10UF K | | F701 | | | F53-0324-15 | FUSE(2.5A) | |
| C747 | | | CC73HCH1H221J | CHIP C 220PF J | | CF1 | | | L72-1017-05 | CERAMIC FILTER(450KHZ) | |
| C749 | | | CK73HB1H102K | CHIP C 1000PF K | | CF2 | | | L72-1040-05 | CERAMIC FILTER(450KHZ) | |
| C752,753 | | | CK73HB1A104K | CHIP C 0.10UF K | | L1 | | | L92-0163-05 | BEADS CORE | |
| C758 | | | CC73HCH1H101J | CHIP C 100PF J | | L2 | | | L41-4795-39 | SMALL FIXED INDUCTOR(4.7UH) | |
| C762 | | | CK73HB1H103K | CHIP C 0.010UF K | | L3 | | | L92-0163-05 | BEADS CORE | |
| C765 | | | CC73HCH1H220J | CHIP C 22PF J | | L5 | | | L92-0163-05 | BEADS CORE | |
| C766,767 | | | CK73GB0J475K | CHIP C 4.7UF K | | L6 ,7 | | | L40-1001-86 | SMALL FIXED INDUCTOR(10UH) | |
| C769 | | | CK73HB1E103K | CHIP C 0.010UF K | | L9 | | | L40-5675-71 | SMALL FIXED INDUCTOR(56NH) | |
| C770 | | | CK73HB1A104K | CHIP C 0.10UF K | | L11 | | | L40-2285-92 | SMALL FIXED INDUCTOR(220NH) | |
| C771 | | | CK73HB1H122K | CHIP C 1200PF K | | L12 | | | L40-1885-92 | SMALL FIXED INDUCTOR(180NH) | |
| C773 | | | CK73HB1E103K | CHIP C 0.010UF K | | L13 | | | L40-2285-92 | SMALL FIXED INDUCTOR(220NH) | |
| C774 | | | CK73HB1A104K | CHIP C 0.10UF K | | L14 -16 | | | L40-1885-92 | SMALL FIXED INDUCTOR(180NH) | |
| C775 | | | CC73HCH1H101J | CHIP C 100PF J | | L17 | | | L34-4608-15 | AIR-CORE COIL(7T) | |
| C776 | | | CK73HB1A393K | CHIP C 0.039UF K | | L18 | | | L34-4609-15 | AIR-CORE COIL(8T) | |
| C777 | | | CK73HB1A104K | CHIP C 0.10UF K | | L19 | | | L92-0163-05 | BEADS CORE | |
| C778 | | | CK73HB1A105K | CHIP C 1.0UF K | | L20 | | | L40-1275-92 | SMALL FIXED INDUCTOR(12NH) | |
| C779,780 | | | CC73HCH1H101J | CHIP C 100PF J | | L21 | | | L40-2285-92 | SMALL FIXED INDUCTOR(220NH) | |
| C782 | | | CK73HB1A104K | CHIP C 0.10UF K | | L22 | | | L92-0446-05 | BEADS CORE | |
| C784 | | | CK73FB1A106K | CHIP C 10UF K | | L23 ,24 | | | L40-2285-92 | SMALL FIXED INDUCTOR(220NH) | |
| C786 | | | CK73HB1A104K | CHIP C 0.10UF K | | L25 | | | L40-2775-71 | SMALL FIXED INDUCTOR(27NH) | |
| C788 | | | CK73FB1E475K | CHIP C 4.7UF K | | L26 | | | L92-0163-05 | BEADS CORE | |
| C790,791 | | | CK73FB1A106K | CHIP C 10UF K | | L27 | | | L40-3975-92 | SMALL FIXED INDUCTOR(39NH) | |
| C796 | | | CK73GB1E105K | CHIP C 1.0UF K | | L29 | | | L40-2285-92 | SMALL FIXED INDUCTOR(220NH) | |
| C797,798 | | | CK73GB1C224K | CHIP C 0.22UF K | | L40 ,41 | | | L92-0163-05 | BEADS CORE | |
| C801 | | | C92-0875-05 | ELECTRO 47UF 25WV | | L101 | | | L40-2275-92 | SMALL FIXED INDUCTOR(22NH) | |
| C802 | | | CK73HB1H102K | CHIP C 1000PF K | | L102 | | | L40-1875-92 | SMALL FIXED INDUCTOR(18NH) | |
| C803,804 | | | C92-0906-05 | ELECTRO 330UF 16WV | | L103 | | | L92-0140-05 | CHIP FERRITE | |
| C805 | | | CK73HB1H102K | CHIP C 1000PF K | | L105 | | | L92-0163-05 | BEADS CORE | |
| C806 | | | CK73GB1E105K | CHIP C 1.0UF K | | L106 | | | L40-1875-92 | SMALL FIXED INDUCTOR(18NH) | |
| C807 | | | CK73HB1A473K | CHIP C 0.047UF K | | L107 | | | L92-0140-05 | CHIP FERRITE | |
| C808 | | | CK73HB1A683K | CHIP C 0.068UF K | | L108-110 | | | L92-0179-05 | CHIP FERRITE | |
| C809 | | | CK73HB1H102K | CHIP C 1000PF K | GE | L111 | | | L92-0163-05 | BEADS CORE | |
| C810 | | | CK73FB1E475K | CHIP C 4.7UF K | | L112 | | | L34-4667-05 | AIR-CORE COIL(9.5T) | |
| C811 | | | CK73HB1H102K | CHIP C 1000PF K | | L113 | | | L34-4694-05 | AIR-CORE COIL(1.5T) | |
| C812 | | | CK73FB1A106K | CHIP C 10UF K | | L114 | | | L34-4667-05 | AIR-CORE COIL(9.5T) | |
| C813 | | | CK73GB0J106K | CHIP C 10UF K | E | L115 | | | L34-4912-05 | AIR-CORE COIL(1T) | |
| C813,814 | | | CK73GB0J106K | CHIP C 10UF K | GE | L116,117 | | | L34-4669-05 | AIR-CORE COIL(2.5T) | |
| C815 | | | CK73HB1A104K | CHIP C 0.10UF K | GE | L118 | | | L40-2275-92 | SMALL FIXED INDUCTOR(22NH) | |
| C816 | | | CK73HB1H102K | CHIP C 1000PF K | GE | L121 | | | L40-1575-71 | SMALL FIXED INDUCTOR(15NH) | |
| C820 | | | CK73HB1A104K | CHIP C 0.10UF K | GE | L201 | | | L92-0138-05 | CHIP FERRITE | |
| C821,822 | | | CC73HCH1H180J | CHIP C 18PF J | GE | L202 | | | L41-5685-39 | SMALL FIXED INDUCTOR(0.56UH) | |
| C823 | | | CK73HB1H102K | CHIP C 1000PF K | GE | L203 | | | L41-2785-39 | SMALL FIXED INDUCTOR(0.27UH) | |
| C824,825 | | | CC73HCH1H180J | CHIP C 18PF J | GE | L204,205 | | | L40-1875-71 | SMALL FIXED INDUCTOR(18NH) | |
| C826 | | | CK73HB1A104K | CHIP C 0.10UF K | GE | L206 | | | L40-4775-71 | SMALL FIXED INDUCTOR(47NH) | |
| C829 | | | CK73GB0J106K | CHIP C 10UF K | | L207-209 | | | L41-3378-14 | SMALL FIXED INDUCTOR(33NH) | |
| C830,831 | | | CK73HB1A104K | CHIP C 0.10UF K | | L210 | | | L41-8278-14 | SMALL FIXED INDUCTOR(82NH) | |
| C832,833 | | | CK73HB1H102K | CHIP C 1000PF K | | L211 | | | L41-3378-14 | SMALL FIXED INDUCTOR(33NH) | |

NX-820(G)/820

PARTS LIST

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|-----------|---------|-----------|--------------|------------------------------|-------------|----------|---------|-----------|--------------|---------------------|-------------|
| L212 | | | L92-0138-05 | CHIP FERRITE | | R29 | | | RK73HB1J470J | CHIP R 47 J 1/16W | |
| L213,214 | | | L41-2278-14 | SMALL FIXED INDUCTOR(22NH) | | R30 | | | RK73HB1J184J | CHIP R 180K J 1/16W | |
| L215,216 | | | L41-3378-14 | SMALL FIXED INDUCTOR(33NH) | | R31 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| L228 | | | L40-2763-92 | SMALL FIXED INDUCTOR(2.7NH) | | R33 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| L302 | | | L40-5681-86 | SMALL FIXED INDUCTOR(0.56UH) | | R34 -36 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| L304 | | | L40-5675-92 | SMALL FIXED INDUCTOR(56NH) | | R40 ,41 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| L307 | | | L40-2291-86 | SMALL FIXED INDUCTOR(2.2UH) | | R46 | | | RK73HB1J330J | CHIP R 33 J 1/16W | |
| L309 | | | L40-1085-57 | SMALL FIXED INDUCTOR(100NH) | | R48 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| L310 | | | L92-0138-05 | CHIP FERRITE | | R49 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| L312 | | | L41-1585-14 | SMALL FIXED INDUCTOR(150NH) | | R50 | | | RN73HH1J100D | CHIP R 10 D 1/16W | |
| L315 | | | L41-3985-39 | SMALL FIXED INDUCTOR(0.39UH) | | R52 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| L316 | | | L41-1885-39 | SMALL FIXED INDUCTOR(0.18UH) | | R53 ,54 | | | RK73HB1J333J | CHIP R 33K J 1/16W | |
| L404 | | | L92-0639-05 | CHIP FERRITE | | R55 | | | RN73HH1J181D | CHIP R 180 D 1/16W | |
| L405 | | | L33-1496-05 | SMALL FIXED INDUCTOR(22UH) | | R56 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| L501 | | | L92-0138-05 | CHIP FERRITE | | R57 | | | RN73HH1J181D | CHIP R 180 D 1/16W | |
| L503 | | | L92-0138-05 | CHIP FERRITE | | R58 | | | RN73HH1J100D | CHIP R 10 D 1/16W | |
| L504-506 | | | L92-0162-05 | BEADS CORE | | R59 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| L508 | | | L92-0138-05 | CHIP FERRITE | | R60 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| L510 | | | L92-0138-05 | CHIP FERRITE | | R61 | | | RK73HB1J154J | CHIP R 150K J 1/16W | |
| L801 | | | L79-1958-05 | FILTER | GE | R62 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| L802 | | | L40-2775-57 | SMALL FIXED INDUCTOR(27.0NH) | GE | R63 | | | RK73HB1J682J | CHIP R 6.8K J 1/16W | |
| L805,806 | | | L92-0138-05 | CHIP FERRITE | GE | R64 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| X1 | | | L77-3073-05 | TCXO (16.8MHZ) | | R65 | | | RK73HB1J221J | CHIP R 220 J 1/16W | |
| X501 | | | L77-3015-05 | TCXO(18.432MHZ) | | R66 | | | RK73HB1J391J | CHIP R 390 J 1/16W | |
| XF1 | | | L71-0678-05 | MCF (49.95MHZ) | | R67 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| CP1 | | | RK74HB1J100J | CHIP-COM 10 J 1/16W | | R69 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| CP501 | | | RK74HB1J104J | CHIP-COM 100K J 1/16W | | R70 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| CP502 | | | RK74HA1J104J | CHIP-COM 100K J 1/16W | | R71 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| CP503 | | | RK74HB1J104J | CHIP-COM 100K J 1/16W | | R72 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| CP504 | | | RK74HA1J101J | CHIP-COM 100 J 1/16W | | R73 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |
| CP505 | | | RK74HA1J104J | CHIP-COM 100K J 1/16W | | R75 | | | RK73HB1J100J | CHIP R 10 J 1/16W | |
| CP506-508 | | | RK74HB1J104J | CHIP-COM 100K J 1/16W | | R76 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| CP510 | | | RK74HA1J104J | CHIP-COM 100K J 1/16W | | R80 ,81 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |
| CP511 | | | RK74HA1J101J | CHIP-COM 100 J 1/16W | | R83 ,84 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |
| CP512 | | | RK74HA1J104J | CHIP-COM 100K J 1/16W | | R87 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| CP513 | | | RK74HB1J104J | CHIP-COM 100K J 1/16W | | R101 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | |
| CP514 | | | RK74HA1J104J | CHIP-COM 100K J 1/16W | | R102 | | | RK73HB1J221J | CHIP R 220 J 1/16W | |
| CP515 | | | RK74HA1J101J | CHIP-COM 100 J 1/16W | | R103 | | | RK73HB1J220J | CHIP R 22 J 1/16W | |
| CP516 | | | RK74HB1J101J | CHIP-COM 100 J 1/16W | | R104 | | | RK73HB1J221J | CHIP R 220 J 1/16W | |
| CP701 | | | RK74HB1J101J | CHIP-COM 100 J 1/16W | | R108 | | | RK73GB2A680J | CHIP R 68 J 1/10W | |
| CP703,704 | | | RK74HB1J104J | CHIP-COM 100K J 1/16W | | R109 | | | RK73HB1J221J | CHIP R 220 J 1/16W | |
| CP705,706 | | | RK74HA1J104J | CHIP-COM 100K J 1/16W | | R110 | | | RK73GB2A220J | CHIP R 22 J 1/10W | |
| CP707 | | | RK74HB1J102J | CHIP-COM 1.0K J 1/16W | | R111 | | | RK73HB1J272J | CHIP R 2.7K J 1/16W | |
| R2 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R112 | | | RK73HB1J681J | CHIP R 680 J 1/16W | |
| R10 | | | RK73HB1J100J | CHIP R 10 J 1/16W | | R113 | | | RK73GB2A150J | CHIP R 15 J 1/10W | |
| R12 | | | RK73HB1J683J | CHIP R 68K J 1/16W | | R114 | | | RK73HB1J471J | CHIP R 470 J 1/16W | |
| R13 ,14 | | | RK73HB1J473J | CHIP R 47K J 1/16W | | R120 | | | RK73HB1J153J | CHIP R 15K J 1/16W | |
| R15 | | | RK73HB1J100J | CHIP R 10 J 1/16W | | R121 | | | RK73FB2B821J | CHIP R 820 J 1/8W | |
| R16 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R122,123 | | | RK73FB2B120J | CHIP R 12 J 1/8W | |
| R17 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R125 | | | RK73FB2B821J | CHIP R 820 J 1/8W | |
| R18 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R128 | | | RK73HB1J221J | CHIP R 220 J 1/16W | |
| R19 ,20 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R130 | | | RK73HB1J153J | CHIP R 15K J 1/16W | |
| R21 | | | RK73HB1J470J | CHIP R 47 J 1/16W | | R131 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R22 | | | RK73HB1J181J | CHIP R 180 J 1/16W | | R133 | | | RK73HB1J123J | CHIP R 12K J 1/16W | |
| R23 | | | RK73HB1J100J | CHIP R 10 J 1/16W | | R134 | | | RK73GB2A121J | CHIP R 120 J 1/10W | |
| R24 | | | RK73HH1J391D | CHIP R 390 D 1/16W | | R135 | | | RK73HB1J823J | CHIP R 82K J 1/16W | |
| R25 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R136 | | | RK73GB2A151J | CHIP R 150 J 1/10W | |
| R26 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R137 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R27 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R138 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R28 | | | RK73HB1J106J | CHIP R 10M J 1/16W | | R139,140 | | | RK73GB2A151J | CHIP R 150 J 1/10W | |

PARTS LIST

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Desti-nation | Ref. No. | Address | New parts | Parts No. | Description | Desti-nation |
|----------|---------|-----------|--------------|---------------------|--------------|----------|---------|-----------|--------------|---------------------|--------------|
| R141 | | | RK73HB1J333J | CHIP R 33K J 1/16W | | R328 | | | RK73HB1J183J | CHIP R 18K J 1/16W | |
| R142 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R329 | | | RK73HB1J100J | CHIP R 10 J 1/16W | |
| R143 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R332 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R145 | | | RK73GB2A100J | CHIP R 10 J 1/10W | | R336,337 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R146 | | | RK73HB1J393J | CHIP R 39K J 1/16W | | R338 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R147 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R339 | | | RK73HB1J153J | CHIP R 15K J 1/16W | |
| R148 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R340 | | | RK73HB1J274J | CHIP R 270K J 1/16W | |
| R149 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R341 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R150 | | | RK73HB1J124J | CHIP R 120K J 1/16W | | R342 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R152 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R343 | | | RK73HB1J223J | CHIP R 22K J 1/16W | |
| R154 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R344 | | | RK73HB1J272J | CHIP R 2.7K J 1/16W | |
| R155 | | | RK73HB1J233J | CHIP R 22K J 1/16W | | R345 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R157,158 | | | RK73HB1J333J | CHIP R 33K J 1/16W | | R350 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R159,160 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R351 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R161 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R355 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R167 | | | RK73HB1J153J | CHIP R 15K J 1/16W | | R357 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R168,169 | | | RK73EB2E241J | CHIP R 240 J 1/4W | | R358 | | | RK73HB1J333J | CHIP R 33K J 1/16W | |
| R170 | | | RK73GB2A000J | CHIP R 0 J 1/10W | | R368 | | | RK73HB1J221J | CHIP R 220 J 1/16W | |
| R171 | 2B | | R92-1061-05 | JUMPER REST 0 OHM | | R378 | | | RK73HB1J394J | CHIP R 390K J 1/16W | |
| R176 | | | RK73GB2A221J | CHIP R 220 J 1/10W | | R379 | | | RK73HB1J222J | CHIP R 2.2K J 1/16W | |
| R177,178 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R381 | | | RK73HB1J221J | CHIP R 220 J 1/16W | |
| R179,180 | | | RK73HB1J333J | CHIP R 33K J 1/16W | | R390 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R181 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R394 | | | RK73HB1J181J | CHIP R 180 J 1/16W | |
| R183 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R401 | | | RK73HB1J471J | CHIP R 470 J 1/16W | |
| R184,185 | | | RK73HB1J471J | CHIP R 470 J 1/16W | | R402 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R187 | | | RK73HB1J473J | CHIP R 47K J 1/16W | | R403 | | | RK73HH1J274D | CHIP R 270K D 1/16W | |
| R188 | | | RK73GB2A120J | CHIP R 12 J 1/10W | | R404 | | | RK73HH1J104D | CHIP R 100K D 1/16W | |
| R201 | | | RK73HB1J470J | CHIP R 47 J 1/16W | | R405,406 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R203 | | | RK73HB1J681J | CHIP R 680 J 1/16W | | R407 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R204 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | | R408 | | | RK73HB1J684J | CHIP R 680K J 1/16W | |
| R205 | | | RK73HB1J151J | CHIP R 150 J 1/16W | | R409 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R207 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R410 | | | RK73GB2A4R7J | CHIP R 4.7 J 1/10W | |
| R208 | | | RK73HB1J184J | CHIP R 180K J 1/16W | | R411 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R209 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R412,413 | | | RK73GB2A100J | CHIP R 10 J 1/10W | |
| R210 | | | RK73HB1J224J | CHIP R 220K J 1/16W | | R414,415 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R213-217 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R417 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R218 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R418 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R223 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R419 | | | RK73HB1J272J | CHIP R 2.7K J 1/16W | |
| R230 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R421 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R233 | | | RK73HB1J274J | CHIP R 270K J 1/16W | | R422 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R234 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R423 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R235 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R424 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R241 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R425 | | | RK73HH1J124D | CHIP R 120K D 1/16W | |
| R242 | | | RK73HB1J274J | CHIP R 270K J 1/16W | | R426 | | | RK73HH1J183D | CHIP R 18K D 1/16W | |
| R243 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R427 | | | RK73HH1J223D | CHIP R 22K D 1/16W | |
| R245 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R428 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R247 | | | RK73HB1J470J | CHIP R 47 J 1/16W | | R429 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R249,250 | | | RK73HB1J183J | CHIP R 18K J 1/16W | | R430 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R255-257 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R431 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R259 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R432 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R290 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R433 | | | RK73HB1J274J | CHIP R 270K J 1/16W | |
| R303-305 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R434 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R306 | | | RK73HB1J334J | CHIP R 330K J 1/16W | | R435 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R307 | | | RK73HB1J561J | CHIP R 560 J 1/16W | | R438 | | | RK73GB2A100J | CHIP R 10 J 1/10W | |
| R308 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R439 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R315 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R440 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R316 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | | R441 | | | RK73HB1J272J | CHIP R 2.7K J 1/16W | |
| R323 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R501 | | | RK73HB1J220J | CHIP R 22 J 1/16W | |
| R324 | | | RK73HB1J183J | CHIP R 18K J 1/16W | | R503,504 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R326 | | | RK73GB2A331J | CHIP R 330 J 1/10W | | R505,506 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |

NX-820(G)/820

PARTS LIST

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|----------|---------|-----------|--------------|---------------------|-------------|----------|---------|-----------|--------------|---------------------|-------------|
| R508-511 | | | RK73HB1J101J | CHIP R 100 J 1/16W | GE | R657 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R512 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R658,659 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |
| R513 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R661 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R515-517 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R662 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |
| R518 | | | RK73HB1J101J | CHIP R 100 J 1/16W | | R664 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |
| R519 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R667 | | | RK73GB2A101J | CHIP R 100 J 1/10W | |
| R521,522 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R668 | | | RK73HB1J471J | CHIP R 470 J 1/16W | |
| R524 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R669-671 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R525 | | | RK73HB1J474J | CHIP R 470K J 1/16W | | R672 | | | RK73GB2A471J | CHIP R 470 J 1/10W | |
| R526 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R673 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R531 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R674 | | | RK73HB1J105J | CHIP R 1.0M J 1/16W | |
| R532 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R677-680 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |
| R533,534 | | | RK73HB1J473J | CHIP R 47K J 1/16W | | R681 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R536 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R682,683 | | | RK73GB2A000J | CHIP R 0 J 1/10W | |
| R541 | | | RK73HB1J101J | CHIP R 100 J 1/16W | | R684 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R546 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R685 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R549 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R686 | | | RK73HB1J223J | CHIP R 22K J 1/16W | |
| R550 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R687 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R552,553 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | | R688 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R554 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | | R690 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R555 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R701 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R556 | | | RK73HB1J220J | CHIP R 22 J 1/16W | | R702 | | | RK73HB1J222J | CHIP R 2.2K J 1/16W | |
| R557 | | | RK73HB1J153J | CHIP R 15K J 1/16W | | R703 | | | RK73HB1J563J | CHIP R 56K J 1/16W | |
| R558 | | | RK73HB1J220J | CHIP R 22 J 1/16W | | R704 | | | RK73HB1J153J | CHIP R 15K J 1/16W | |
| R559 | | | RK73HB1J392J | CHIP R 3.9K J 1/16W | | R705 | | | RK73HB1J683J | CHIP R 68K J 1/16W | |
| R560 | | | RK73HB1J474J | CHIP R 470K J 1/16W | | R706 | | | RK73HB1J823J | CHIP R 82K J 1/16W | |
| R561 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R707 | | | RK73HB1J182J | CHIP R 1.8K J 1/16W | |
| R566 | | | RK73HB1J474J | CHIP R 470K J 1/16W | | R708 | | | RK73HB1J333J | CHIP R 33K J 1/16W | |
| R567 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R709 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R568,569 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R710 | | | RK73HB1J563J | CHIP R 56K J 1/16W | |
| R571,572 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R711 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R580 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | | R712 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R581 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R713 | | | RK73HB1J223J | CHIP R 22K J 1/16W | |
| R583 | | | RK73HB1J104D | CHIP R 100K D 1/16W | | R716 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R584 | | | RK73HB1J473J | CHIP R 47K J 1/16W | | R720 | | | RK73HB1J334J | CHIP R 330K J 1/16W | |
| R599 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R722 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R603 | | | RK73HB1J474J | CHIP R 470K J 1/16W | | R724 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R606 | | | RK73HB1J105J | CHIP R 1.0M J 1/16W | | R728 | | | RK73HB1J393J | CHIP R 39K J 1/16W | |
| R610 | | | RK73HB1J474J | CHIP R 470K J 1/16W | | R730 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R611 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R738 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R612 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | R739 | | | RK73HB1J334J | CHIP R 330K J 1/16W | |
| R613 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R741 | | | RK73HB1J470J | CHIP R 47 J 1/16W | |
| R614 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R742 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | |
| R615 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | | R743 | | | RK73HB1J471J | CHIP R 470 J 1/16W | |
| R616 | | | RK73HB1J474J | CHIP R 470K J 1/16W | | R745 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R617 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | R746 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R620 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | R748,749 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R621-624 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R750 | | | RK73HB1J393J | CHIP R 39K J 1/16W | |
| R626 | | | RK73HB1J101J | CHIP R 100 J 1/16W | | R751 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R627,628 | | | RK73HB1J682J | CHIP R 6.8K J 1/16W | | R752 | | | RK73HB1J394J | CHIP R 390K J 1/16W | |
| R629 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R754 | | | RK73HB1J563J | CHIP R 56K J 1/16W | |
| R631 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | R755 | | | RK73HB1J224J | CHIP R 220K J 1/16W | |
| R632 | | | RK73GB2A000J | CHIP R 0 J 1/10W | | R756 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R634 | | | RK73HB1J101J | CHIP R 100 J 1/16W | | R769 | | | RK73HB1J684J | CHIP R 680K J 1/16W | |
| R635 | | | RK73GB2A000J | CHIP R 0 J 1/10W | | R770,771 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R636 | | | RK73HB1J474J | CHIP R 470K J 1/16W | | R772 | | | RK73HB1J153J | CHIP R 15K J 1/16W | |
| R637,638 | | | RK73FB2B102J | CHIP R 1.0K J 1/8W | | R773 | | | RK73HB1J000J | CHIP R 0 J 1/16W | |
| R639 | | | RK73HB1J471J | CHIP R 470 J 1/16W | | R775 | | | RK73HB1J562J | CHIP R 5.6K J 1/16W | |
| R641 | | | RK73GB2A000J | CHIP R 0 J 1/10W | | R776,777 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R643 | | | RK73GB2A000J | CHIP R 0 J 1/10W | | R778 | | | RK73HB1J273J | CHIP R 27K J 1/16W | |

PARTS LIST

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Desti- nation | Ref. No. | Address | New parts | Parts No. | Description | Desti- nation |
|----------|---------|-----------|--------------|----------------------------|------------------|----------|---------|-----------|----------------|------------------|------------------|
| R779 | | | RK73HB1J223J | CHIP R 22K J 1/16W | | D502 | | | DB2S310 | DIODE | |
| R783 | | | RK73HB1J154J | CHIP R 150K J 1/16W | | D504 | | | DB2S310 | DIODE | |
| R785 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | D505-510 | | | MC2850 | DIODE | |
| R786 | | | RK73HB1J563J | CHIP R 56K J 1/16W | | D511-513 | | | DB2S310 | DIODE | |
| R787 | | | RK73HB1J123J | CHIP R 12K J 1/16W | | D601 | | | DB2S310 | DIODE | |
| R796,797 | | | RK73GB2A000J | CHIP R 0 J 1/10W | | D701 | | | DA2S101 | DIODE | |
| R800 | | | RK73HB1J104J | CHIP R 100K J 1/16W | | D702 | | | 1SS422 | DIODE | |
| R801 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | E | D703,704 | | | DA3S101F | DIODE | |
| R801,802 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | GE | D705,706 | | | EMZ6.8N | ZENER DIODE | |
| R803,804 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | | D801,802 | | | RN142S | DIODE | GE |
| R805,806 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | IC1 | | | TA7808F-NQ | ANALOGUE IC | |
| R810 | | | RK73HB1J123J | CHIP R 12K J 1/16W | | IC2 | | | SKY72310-362 | MOS-IC | |
| R811 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | IC3 | | | BD7542FVM | MOS-IC | |
| R813 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | IC102 | 2B | | RA60H40471101 | IC(POWER MODULE) | |
| R814 | | | RK73HB1J391J | CHIP R 390 J 1/16W | | IC103 | | | NJM12904RB1 | MOS-IC | |
| R816 | | | RK73HB1J123J | CHIP R 12K J 1/16W | | IC201 | | | BD7542FVM | MOS-IC | |
| R818 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | | IC301 | | | TC7SH08FU-F | MOS-IC | |
| R819,820 | | | RK73HB1J222J | CHIP R 2.2K J 1/16W | | IC303 | | | TK10931VTL-G | ANALOGUE IC | |
| R821,822 | | | RK73GB2A000J | CHIP R 0 J 1/10W | | IC304 | | | BU7445HFV | MOS-IC | |
| R823 | | | RK73HB1J123J | CHIP R 12K J 1/16W | | IC401 | | | XC6209B332M-G | MOS-IC | |
| R824 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | | IC402 | | | XC6118C23CMR | MOS-IC | |
| R825 | | | RK73HB1J000J | CHIP R 0 J 1/16W | | IC404 | | | XC6209B502P-G | MOS-IC | |
| R826 | | | RK73HB1J103J | CHIP R 10K J 1/16W | | IC405 | | | LT1616ES6-PBF | ANALOGUE IC | |
| R827 | | | RK73HB1J823J | CHIP R 82K J 1/16W | | IC406 | | | XC6209B332M-G | MOS-IC | |
| R831,832 | | | RK73HB1J683J | CHIP R 68K J 1/16W | | IC407 | | | NJM2878F4-33 | BI-POLAR IC | |
| R833 | | | RK73HB1J101J | CHIP R 100 J 1/16W | | IC408 | | | XC6205B152P-G | MOS-IC | |
| R834 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | | IC409 | | | NJM2878F4-33 | BI-POLAR IC | |
| R835 | | | RK73HB1J100J | CHIP R 10 J 1/16W | GE | IC501 | | | Note1(BGA) | ROM IC | |
| R837 | | | RK73HB1J562J | CHIP R 5.6K J 1/16W | | IC502 | | | Note1(BGA) | ASIC | |
| R838 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | | IC503 | | | Note1(BGA) | SRAM IC | |
| R839 | | | RK73EB2E100J | CHIP R 10 J 1/4W | GE | IC504 | | | BD5329FVE | MOS-IC | |
| R842-844 | | | RK73HB1J000J | CHIP R 0 J 1/16W | GE | IC506 | | | SM5023CNDH-G | MOS-IC | |
| R845 | | | RK73HB1J101J | CHIP R 100 J 1/16W | | IC507 | | | Note1(BGA) | MOS-IC | |
| R846,847 | | | RK73HB1J223J | CHIP R 22K J 1/16W | | IC508 | | | TC7SH08FU-F | MOS-IC | |
| | | | | | | IC509 | | | TC7WH126FU-F | MOS-IC | |
| D2 | | | DZ2J091(M) | ZENER DIODE | | IC511 | | | TC74VHCT244AFK | MOS-IC | |
| D3 ,4 | | | 1SV323F | VARIABLE CAPACITANCE DIODE | | IC512 | | | TC7WBD125AFK | MOS-IC | |
| D7 -12 | | | 1SV282-F | VARIABLE CAPACITANCE DIODE | | IC513 | | | TC7WT126FU-F | MOS-IC | |
| D13 | | | 1SV278F | VARIABLE CAPACITANCE DIODE | | IC514 | | | TC7WH126FU-F | MOS-IC | |
| D14 | | | DA2S101 | DIODE | | IC515 | | | PCA9535BS | MOS-IC | |
| D16 ,17 | | | RKS151KJ | DIODE | | IC516 | | | ADM202EARNZ | MOS-IC | |
| D101 | | | DZ2J056(M) | ZENER DIODE | | IC701 | | | BU7462NUX | MOS-IC | |
| D102 | | | DA3S101F | DIODE | | IC702 | | | BU7242NUX | MOS-IC | |
| D103 | | | RKS151KJ | DIODE | | IC703 | | | BU7462NUX | MOS-IC | |
| D104,105 | | | HSB88AS-E | DIODE | | IC705 | | | BU7242NUX | MOS-IC | |
| D106 | | | DZ2J056(M) | ZENER DIODE | | IC711 | | | BU7462NUX | MOS-IC | |
| D107 | | | RKP351KW-1P2 | DIODE | | IC712 | | | R2A20178NP | DAC IC | |
| D108,109 | | | RB520SM-30 | DIODE | | IC713 | | | TC7W53FK(F) | MOS-IC | |
| D110,111 | | | L407CDB | DIODE | | IC714 | 2A | | LA4600 | BI-POLAR IC | |
| D112-114 | | | RN142S | DIODE | | IC716 | | | TC7WT126FU-F | MOS-IC | |
| D201-206 | | | 1SV278F | VARIABLE CAPACITANCE DIODE | | IC801 | | | TC7WH126FU-F | MOS-IC | GE |
| D401 | | | DZ2J180(M) | ZENER DIODE | | Q1 | | | LTC014EEBFS8 | TRANSISTOR | |
| D403 | | | RB520SM-30 | DIODE | | Q2 | | | 2SJ648-A | FET | |
| D404 | | | DA2S101 | DIODE | | Q4 | | | 2SC5383-T111 | TRANSISTOR | |
| D405 | | | DB2S310 | DIODE | | Q5 ,6 | | | MCH3914(8)-H | FET | |
| D406 | | | DB22306 | DIODE | | Q8 | | | EM6M1 | FET | |
| D407 | | | RB520SM-30 | DIODE | | Q9 | | | SSM3J15FS | FET | |
| D408,409 | | | DB2S310 | DIODE | | Q10 ,11 | | | 2SC5108(Y)F | TRANSISTOR | |
| D410 | | | 22ZR-10D | SURGE ABSORBER | | Q101 | | | 2SC3356-A(R24) | TRANSISTOR | |
| D411 | | | DSA3A1 | DIODE | | Q102 | | | 2SC3357-A | TRANSISTOR | |

GE: NX-820(G)
E: NX-820

**If a part reference number is listed in a shaded box, that part does not come with the PCB.
Note 1: This part cannot be replaced. Therefore, this part is not supplied as a service part.**

NX-820(G)/820


PARTS LIST

TX-RX UNIT (X57-8240-1X)

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|----------|---------|-----------|----------------|-------------|-------------|----------|---------|-----------|-----------|-------------|-------------|
| Q105 | | | FK330301 | FET | | | | | | | |
| Q106 | | | EMD5 | TRANSISTOR | | | | | | | |
| Q201 | | | 3SK318 | FET | | | | | | | |
| Q202 | | | NESG240034 | TRANSISTOR | | | | | | | |
| Q303 | | | 2SC5108(Y)F | TRANSISTOR | | | | | | | |
| Q305 | | | 2SC4215-F(Y) | TRANSISTOR | | | | | | | |
| Q401 | | | LTC014EEBFS8 | TRANSISTOR | | | | | | | |
| Q402 | | | 2SA1955A-F | TRANSISTOR | | | | | | | |
| Q403 | | | MTM981400BF | FET | | | | | | | |
| Q404 | | | 2SA1955A-F | TRANSISTOR | | | | | | | |
| Q405 | | | LTC014EEBFS8 | TRANSISTOR | | | | | | | |
| Q407 | | | FK330301 | FET | | | | | | | |
| Q408 | | | EMD5 | TRANSISTOR | | | | | | | |
| Q409 | | | EM6M1 | FET | | | | | | | |
| Q410 | | | 2SA1955A-F | TRANSISTOR | | | | | | | |
| Q411,412 | | | LTC014EEBFS8 | TRANSISTOR | | | | | | | |
| Q414 | | | EMD9 | TRANSISTOR | | | | | | | |
| Q415 | | | 2SC4738(GR)F | TRANSISTOR | | | | | | | |
| Q416 | | | 2SA1832(GR)F | TRANSISTOR | | | | | | | |
| Q417 | | | EMD5 | TRANSISTOR | | | | | | | |
| Q418 | | | LTC014EEBFS8 | TRANSISTOR | | | | | | | |
| Q501 | | | FK330301 | FET | | | | | | | |
| Q502 | | | LTC014TEBFS8 | TRANSISTOR | | | | | | | |
| Q503 | | | MTM981400BF | FET | | | | | | | |
| Q504 | | | LTC014TEBFS8 | TRANSISTOR | | | | | | | |
| Q701 | | | FK330301 | FET | | | | | | | |
| Q702 | | | KTC4075E(Y,GR) | TRANSISTOR | | | | | | | |
| Q703 | | | 2SA1832(GR)F | TRANSISTOR | | | | | | | |
| Q704 | | | 2SC4738(GR)F | TRANSISTOR | | | | | | | |
| Q705,706 | | | SSM3J15FS | FET | | | | | | | |
| Q708 | | | LTC014EEBFS8 | TRANSISTOR | | | | | | | |
| Q709 | | | SSM6N37FE | FET | | | | | | | |
| TH1 | | | ERTJ0EV104H | THERMISTOR | | | | | | | |
| TH101 | | | ERTJ0EV104H | THERMISTOR | | | | | | | |
| TH103 | | | ERTJ0EV104H | THERMISTOR | | | | | | | |
| TH701 | | | ERTJ0EV104H | THERMISTOR | | | | | | | |
| A801 | | | W02-3768-05 | GPS MODULE | GE | | | | | | |

NX-820(G)/820

EXPLODED VIEW



Parts with the exploded numbers larger than 700 are not supplied.
If a part reference number is listed in a box on the exploded view of the PCB, that part does not come with the PCB.
These parts must be ordered separately.

TROUBLE SHOOTING

Fault Diagnosis of the BGA (Ball Grid Array) IC

■ Overview

A flowchart for determining whether or not the transceiver can be powered on (the LCD does not function even if the power switch is turned on) due to broken BGA parts.

■ BGA parts

ASIC (IC507), DSP (IC502), FLASH (IC501), SRAM (IC503)

When the BGA IC is problematic, please bring the printed circuit board (X57-8240-14 /-15 /-16 /-17) in for service. Various ESN/default adjustment values are written on the printed circuit board for service.

Additionally various ESN stickers are included.

After the printed circuit board has been readjusted, please attach any ESN stickers to the chassis. When "ESN Validation" is used with Trunking, you must modify the ESN register.

● Checking power supply voltage

| Checking voltage | |
|------------------------------------------------------------|----------------|
| Points to be checked | Normal voltage |
| 33M IC401 (5 pin) | 3.3V |
| 15M IC408 (5 pin) | 1.5V |
| 33A IC406 (5 pin) | 3.3V |
| Power supply of each device is connected through the coil. | |
| [ASIC] | |
| 33M: L508, 15M: L510, 33A: R571 | |
| [DSP] | |
| 33M: L503, 15M: R505 | |
| [FLASH] | |
| 33M: L501 | |
| [SRAM] | |
| 33M: L504 | |

When an abnormal value is confirmed.

| Checking for an abnormal point | |
|--------------------------------------------------------------------------------------------------|--|
| 33M has an abnormal voltage. | |
| [ASIC] | |
| Remove L508 to check the voltage of the 33M. If the voltage becomes normal, the ASIC is broken. | |
| [DSP] | |
| Remove L503 to check the voltage of the 33M. If the voltage becomes normal, the DSP is broken. | |
| [FLASH] | |
| Remove L501 to check the voltage of the 33M. If the voltage becomes normal, the FLASH is broken. | |
| [SRAM] | |
| Remove L504 to check the voltage of the 33M. If the voltage becomes normal, the SRAM is broken. | |
| 15M has an abnormal voltage. | |
| [ASIC] | |
| Remove L510 to check the voltage of the 15M. If the voltage becomes normal, the ASIC is broken. | |
| [DSP] | |
| Remove R505 to check the voltage of the 15M. If the voltage becomes normal, the DSP is broken. | |
| 33A has an abnormal voltage. | |
| [ASIC] | |
| Remove R571 to check the voltage of the 33A. If the voltage becomes normal, the ASIC is broken. | |
| If the voltage is not corrected, there is a problem other than the BGA parts. | |

● Checking the clock

| Checking the clock | |
|-------------------------|-----------------------|
| Points to be checked | Normal voltage (3.3V) |
| 18.432MHz IC506 (4 pin) | 18.432MHz |

When a normal value is confirmed.

When an abnormal value is confirmed.

● Checking the Reset/Control signal

| Checking the control signal input to the ASIC | |
|-----------------------------------------------|----------------|
| Points to be checked | Normal voltage |
| RST (RESET) IC504 (1 pin) | 3.3V |
| /BINT IC402 (1 pin) | 3.3V |
| /OVRB D403 (Cathode side) | 3.3V |

When a normal value is confirmed.

When an abnormal value is confirmed.

| Checking the ASIC input switch signal | |
|---------------------------------------|-------------------|
| The POWER key is pressed and held. | |
| Points to be checked | Confirmed voltage |
| POWER R690 | ON: 0V |
| The ignition key is kept ON. | OFF: 3.3V |
| Points to be checked | Confirmed voltage |
| /IGN C633 (Q504-Collector Side) | ON: 0V |
| | OFF: 3.3V |

When a normal value is confirmed.

When an abnormal value is confirmed.

● Checking the output signal from the ASIC


| Checking the output signal from the ASIC | |
|------------------------------------------|----------------|
| Points to be checked | Normal voltage |
| /FRST R516 | 3.3V |

When a normal value is confirmed.


When an abnormal value is confirmed.

| |
|----------------------------------------------------------------------------------------|
| If the /FRST is always 0V, the ASIC is broken. |
| If the /FRST repeats 3.3V and 0V at intervals, the ASIC, FLASH and SRAM may be broken. |

TROUBLE SHOOTING



● When an error display appears on the LCD.



NX-820(G)/820

TROUBLE SHOOTING

Failure diagnosis of the GPS section. (Built-in GPS model only)


Overview: When the GPS function does not operate, use this flowchart to determine the problem.

Note:

The transceiver supplies the voltage to the GPS antenna and the voltage is checked when the transceiver is turned "ON". When the voltage is lower than the specified value, "G ANT FAIL" is displayed for 2 seconds before entering user mode. (At this time, the expected defect of the GPS antenna is a short. This error message does not appear when the expected defect is an open .)

Major parts for a GPS circuit

- GPS module (A801) : W02-3768-05
- Buffer IC (IC801) : TC7WH126FUF
- Filter (L801) : L79-1958-05
- GPS active antenna : KRA-40 (option)



Replacing TX-RX Unit

■ TX-RX unit Information

| Model Name | Frequency Range [MHz] | Original TX-RX unit Number | For Service TX-RX unit Number |
|--------------------------|-----------------------|----------------------------|-------------------------------|
| NX-820(G) (GPS model): E | 400 - 470 | X57-8240-12 | X57-8240-16 |
| NX-820: E | 400 - 470 | X57-8240-13 | X57-8240-17 |

TROUBLE SHOOTING

Method of confirming “Original TX-RX unit” and “Service TX-RX unit”

SUPPLIED ACCESSORIES

| | |
|-----------------|---|
| ESN Label | 1 |
| • KENWOOD ESN | |
| • NXDN ESN | |
| • MPT ESN | |
| Addendum | 1 |

PRINTED CIRCUIT BOARD DATA

The following data is written on the printed circuit board:

| Data Type | Description |
|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Firmware | NX-720/820 K type firmware |
| FPU Data (PC programming mode) | X57-823: NX-720 Kx type data |
| | X57-824: NX-820 Kx type data |
| Voice Language | English |
| Various Adjustment Data (PC Test mode) | General adjustment values for the X57-823 (NX-720), and X57-824 (NX-820). |
| KENWOOD ESN | Model Name: • 136~174MHz NX-720HGS: X57-8230-12 (for GPS model) NX-720HS: X57-8230-13 • 400~470MHz NX-820HGS: X57-8240-16 (for GPS model) NX-820HS: X57-8240-17 Type : Kx The same number as the KENWOOD ESN label is written. |
| | |
| NXDN ESN/MPT ESN | The same number as the NXDN ESN/ MPT ESN label is written. |


AFTER CHANGING THE PCB

- 1 After changing the printed circuit board, write the up-to-date Firmware following the instructions in the service manual.
 - Write the Firmware in accordance to the Market. If you write different Market Firmware, there are times communication with the FPU is not possible.
- 2 Using the KPG-141D, select your desired item (Model Name and Frequency) from the Model > Product Information menu, then use Program > Write Data to the Transceiver to write the FPU data (PC Programming mode). When writing to the transceiver, a Warning Message, corresponding to the item selected, appears. Click [OK] to continue writing the data.
- 3 Enter Program > Test Mode, then adjust the various adjustment data (PC Test mode) as described in the service manual.
- 4 Attach the new labels corresponding to the new printed circuit board. (Refer to the images below for label placement.)
- 5 If necessary, write the FPU data used by the customer with the KPG-141D.

Note:

- When using the ESN Validation function of Trunking, the ESN number changes when the circuit board is changed (the number is written on the circuit board); the Trunking system cannot be accessed. Maintain the ESN data of the Trunking System following the new ESN.
- When a new printed circuit board is used, the KENWOOD ESN changes, as does the Transceiver Information display of the KPG-141D, but this does not have any effect on the operation of the transceiver.
- If changing to the original ESN, please contact our service center.


ATTACHING THE ESN LABEL




NX-820(G)/820

ADJUSTMENT

Controls



KMC-36 (OPTION)



■ Preparations for checking/tuning the transceiver

Before attempting to check/tune the transceiver, connect the unit to a suitable power supply.

Whenever the transmitter is turned on, the unit must be connected to a suitable dummy load (i.e. power meter).

The speaker output connector must be terminated with a 4Ω dummy load and connected to an AC voltmeter and an audio distortion meter or a SINAD measurement meter at all times during checking/tuning.

Panel Test Mode

■ Test mode operation features

This transceiver has a test mode. To enter test mode, press and hold the [A] key while turning the transceiver power ON. Before the transceiver enters test mode, the frequency version information appears on the LCD momentarily. Test mode can be inhibited by programming. To exit test mode, turn the transceiver power OFF. The following functions are available in test mode.

■ Key operation

| Key | “—” not appears on the LCD display | |
|-------------------------------|------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|
| | Function | Display |
| [^]/[v] | Test channel up/down | Channel No. |
| [Δ] | Push: Squelch level up Hold: Squelch off | Squelch level Squelch off: icon appears |
| | Wide 5k/Wide 4k/Narrow/ Very narrow | Wide 5k: “W” Wide 4k: “S” Narrow: “N” Very narrow: “V” |
| [S] | Shift to panel tuning mode | - |
| [A] | Function on | “—” appears on the LCD display |
| [<B] | MSK 1200bps and 2400bps | 2400bps: icon appears |
| [C>] | Push: Test signaling up Hold: Test signaling up continuously | Signaling No. |
| [^]/[v] | Volume level up/down | |
| [PTT] (MIC) | Transmit | - |
| [0] to [9] and [#], [*] (MIC) | Use as the DTMF keypad. If a key is pressed during transmission, the DTMF corresponding to the key that was presses is sent. | - |


| Key | “—” appears on the LCD display | |
|-------------------------------|--------------------------------|---------------------------------------------------|
| | Function | Display |
| [^] | Function off | - |
| [v] | Analog /NXDN | Analog: “A”, NXDN: “N” |
| [Δ] | Function off | - |
| | LCD all lights | LCD all point appears |
| [S] | High /Low power | High: icon not appears Low: “— —” icon appears |
| [A] | Function off | - |
| [<B] | Compander on/off | On: icon appears |
| [C>] | Beat shift on/off | On: icon appears |
| [^]/[v] | Volume level up/down | |
| [PTT] (MIC) | Transmit | - |
| [0] to [9] and [#], [*] (MIC) | Function off | - |

ADJUSTMENT

• LED indicator

- Red LED Lights during transmission.
- Green LED Lights when there is carrier.

• LCD display in panel test mode



■ Frequency and Signaling

The transceiver has been adjusted for the frequencies shown in the following table. When required, readjust them following the adjustment procedure to obtain the frequencies you want in actual operation.

• Test frequency

| CH | RX (MHz) | TX (MHz) |
|------|-----------|-----------|
| 1 | 435.05000 | 435.10000 |
| 2 | 400.05000 | 400.10000 |
| 3 | 469.95000 | 469.90000 |
| 4 | 435.00000 | 435.00000 |
| 5 | 435.20000 | 435.20000 |
| 6 | 435.40000 | 435.40000 |
| 7~16 | - | - |

• Analog mode signaling

| No. | RX | TX |
|-----|-----------------------------------------------------------|-----------------------------------------------------------|
| 1 | None | None |
| 2 | None | 100Hz Square Wave |
| 3 | LTR Data: AREA=0, GOTO=12 HOME=12 ID=47, FREE=25 | LTR Data: AREA=0, GOTO=12 HOME=12 ID=47, FREE=25 |
| 4 | QT: 67.0Hz | QT: 67.0Hz |
| 5 | QT: 151.4Hz | QT: 151.4Hz |
| 6 | QT: 210.7Hz | QT: 210.7Hz |
| 7 | QT: 254.1Hz | QT: 254.1Hz |
| 8 | DQT: D023N | DQT: D023N |
| 9 | DQT: D754I | DQT: D754I |
| 10 | DTMF: 159D | DTMF: 159D |
| 11 | None | DTMF Code 9 |
| 12 | 2-tone: A: 304.7Hz, B: 3106.0Hz | 2-tone: A: 304.7Hz, B: 3106.0Hz |
| 13 | Single Tone: 979.9Hz | Single Tone: 979.9Hz |
| 14 | None | Single Tone: 1000Hz |
| 15 | None | MSK PN9 |
| 16 | MSK | MSK |

ADJUSTMENT

• NXDN mode signaling

| No. | RX | TX |
|-----|---------------------------------------------------|-----------------------------|
| 1 | RAN1 | RAN1 |
| 2 | None | PN9 |
| 3 | RAN1 | Maximum Deviation Pattern |
| 7 | None | FSW+PN9 (PC test mode only) |
| 9 | Tone Pattern (1031Hz) (Simple BER Measurement) | Tone Pattern (1031Hz) |

RAN: Radio Access Number

PN9: Pseudo-Random Pattern (for production only)

No.9 Item: PC test mode only


Panel Tuning Mode

■ Transceiver tuning (To enter tuning mode)

To enter tuning mode, press the [S] key while the transceiver is in test mode. Use the [<B] key to write tuning data through tuning modes, and the [↔]/[↔] to adjust tuning requirements (1 to 4096 appears on the LCD).

Use the [C>] key to select the adjustment item through tuning modes. Use the [A] key to adjust 5 reference level adjustments, and use the [■] key to switch between Wide/Narrow/Very narrow.

• LCD display in panel tuning mode



■ Key operation

| Key | Function | |
|-------------------------|-------------------------------------------------------|------------------------------|
| | Push | Hold (1 second) |
| [↔]/[↔] | Adjustment value up/down | |
| [Δ] | 20Hz/2kHz (During transmission in balance adjustment) | - |
| [■] | Wide/Narrow/Very narrow | - |
| [S] | Shift to panel test mode | - |
| [A] | To enter 5 reference level adjustments | - |
| [<B] | Writes the adjustment value | - |
| [C>] | Go to next adjustment item | Back to last adjustment item |
| [^]/[v] | Volume level up/down | |
| [PTT] | Transmit | |
| [0] to [9] and [#], [*] | - | |

■ 5 reference level adjustments frequency

| Tuning point | RX (MHz) | TX (MHz) |
|--------------|-----------|-----------|
| Low | 400.05000 | 400.10000 |
| Low' | 417.55000 | 417.60000 |
| Center | 435.05000 | 435.10000 |
| High' | 452.55000 | 452.60000 |
| High | 469.95000 | 469.90000 |

■ 9 reference level adjustments frequency

| Tuning point | RX (MHz) | TX (MHz) |
|--------------|-----------|-----------|
| Low1 | 400.05000 | 400.10000 |
| Low2 | 408.80000 | 408.85000 |
| Low3 | 417.55000 | 417.60000 |
| Center1 | 426.30000 | 426.35000 |
| Center2 | 435.05000 | 435.10000 |
| Center3 | 443.80000 | 443.85000 |
| High1 | 452.55000 | 452.60000 |
| High2 | 461.30000 | 461.35000 |
| High3 | 469.95000 | 469.90000 |

ADJUSTMENT

■ Adjustment item supplement

| Adjustment Item | Description |
|------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Receive Assist | The lock voltage of VCO (Receive) is adjusted. This item must be adjusted before all adjustment items for receiver section are adjusted. This item can be adjusted only in PC Test Mode. |
| Transmit Assist | The lock voltage of VCO (Transmit) is adjusted. This item must be adjusted before all adjustment items for transmitter section are adjusted. This item can be adjusted only in PC Test Mode. |
| Frequency | Frequency stability is adjusted under receiving condition with SSG. The SSG needs 0.001ppm accuracy so please use a standard oscillator if necessary. This item can be adjusted only in PC Test Mode so that the adjustment value is not changed easily. |
| High Transmit Power Limit | High Transmit Power Limit is adjusted. |
| Low Transmit Power Limit | Low Transmit Power Limit is adjusted. |
| High Transmit Power | High Transmit Power is adjusted. |
| Low Transmit Power | Low Transmit Power is adjusted. |
| Balance | The transmit audio frequency response is adjusted. This item is adjusted so that the deviation of 2kHz becomes the same deviation of 20Hz. This item must be adjusted before all adjustment items for deviations are adjusted. |
| Maximum Deviation (NXDN Narrow/Very Narrow) | Maximum Deviation of NXDN (Narrow/Very Narrow) is adjusted. |
| Maximum Deviation (Analog Wide 5k/Wide 4k/Narrow) | Maximum Deviation of Analog (Wide 5k/Wide 4k/Narrow) is adjusted. This item must be adjusted before all adjustment items for tone deviations are adjusted. Note: "Maximum Deviation (Analog Wide 5k/Wide 4k/Narrow)" must be adjusted before "CW ID Deviation (NXDN Very Narrow)" is adjusted. |
| QT Deviation | QT tone deviation is adjusted. |
| DQT Deviation | DQT tone deviation is adjusted. |
| LTR Deviation | LTR tone deviation is adjusted. |
| DTMF Deviation | DTMF tone deviation is adjusted. |
| Single Tone Deviation | The deviation of Single Tone used in "2-tone/5-tone" is adjusted. |
| MSK Deviation | MSK tone deviation is adjusted. |
| CW ID Deviation | CW ID tone deviation is adjusted. CW ID is used to inform the others who is transmitting on a 6.25 kHz spacing channel. (In FCC rule, Analog mode or CW ID is required for each channel-spacing.) |
| Sensitivity 1 | Band-Pass Filter is adjusted. The performance of Receive Sensitivity and unwanted signal rejection are improved. This item can be adjusted only in PC Test Mode. |
| Sensitivity 2 | Band-Pass Filter is adjusted. The performance of Receive Sensitivity and unwanted signal rejection are improved. This item can be adjusted only in PC Test Mode. |
| RSSI Reference | The minimum RSSI level for scan stop is adjusted. |
| Open Squelch | The squelch level at level "5" is adjusted. |
| Low RSSI | RSSI display level "V" is adjusted. |
| High RSSI | Both "Low RSSI" and "High RSSI" must be adjusted. (The curve data of RSSI level is applied.) |
| Tight Squelch | The squelch level at level "9" is adjusted. |

ADJUSTMENT

■ Adjustment item and Adjustment range

| Order | Adjustment item | Panel tuning | PC test | AW (Analog Wide 5k) | AS (Analog Wide 4k) | AN (Analog Narrow) | NN (NXDN Narrow) | NV (NXDN Very Narrow) | Adjust item Number |
|-------|-------------------------------|--------------|---------|---------------------------|---------------------------|--------------------------|------------------------|--------------------------|---------------------------|
| | | | | Adjustment range | | | | | |
| 1 | Receive Assist | | ✓ | 9 point ADJ | | | | | Common Section 2 |
| | | | | 1~4096 | | | | | |
| 2 | Transmit Assist | | ✓ | 9 point ADJ | | | | | Common Section 3 |
| | | | | 1~4096 | | | | | |
| 3 | Frequency | | ✓ | 1 point ADJ | | | | | Common Section 4 |
| | | | | 1~4096 | | | | | |
| 4 | High Transmit Power Limit | ✓ | ✓ | - | - | 5 | - | - | Transmitter Section 1 |
| | | | | 1~256 | | | | | |
| 5 | Low Transmit Power Limit | ✓ | ✓ | - | - | 5 | - | - | Transmitter Section 1 |
| | | | | 1~256 | | | | | |
| 6 | High Transmit Power | ✓ | ✓ | - | - | 5 | - | - | Transmitter Section 2 |
| | | | | 1~1024 | | | | | |
| 7 | Low Transmit Power | ✓ | ✓ | - | - | 5 | - | - | Transmitter Section 2 |
| | | | | 1~1024 | | | | | |
| 8 | Balance | ✓ | ✓ | - | - | 5 | - | - | Transmitter Section 2 |
| | | | | 1~1024 | | | | | |
| 9 | Maximum Deviation (NXDN) | ✓ | ✓ | - | - | - | 5 | 5 | Transmitter Section 4 |
| | | | | 1~1024 | | | | | |
| 10 | Maximum Deviation (Analog) | ✓ | ✓ | 5 | 5 | 5 | - | - | Transmitter Section 5 |
| | | | | 1~1024 | | | | | |
| 11 | QT Deviation | ✓ | ✓ | 1 | 1 | 1 | - | - | Transmitter Section 6 |
| | | | | 1~1024 | | | | | |
| 12 | DQT Deviation | ✓ | ✓ | 1 | 1 | 1 | - | - | Transmitter Section 7 |
| | | | | 1~1024 | | | | | |
| 13 | LTR Deviation | ✓ | ✓ | 1 | - | 1 | - | - | Transmitter Section 8 |
| | | | | 1~1024 | | | | | |
| 14 | DTMF Deviation | ✓ | ✓ | 1 | 1 | 1 | - | - | Transmitter Section 9 |
| | | | | 1~1024 | | | | | |
| 15 | Single Tone Deviation | ✓ | ✓ | 1 | 1 | 1 | - | - | Transmitter Section 10 |
| | | | | 1~1024 | | | | | |
| 16 | MSK Deviation | ✓ | ✓ | 1 | 1 | 1 | - | - | Transmitter Section 11 |
| | | | | 1~1024 | | | | | |
| 17 | CW ID Deviation | ✓ | ✓ | - | - | - | - | 1 | Transmitter Section 12 |
| | | | | 1~1024 | | | | | |
| 18 | Sensitivity 1 | | ✓ | - | - | 5 | - | - | Receiver Section 2 |
| | | | | 1~256 | | | | | |
| 19 | Sensitivity 2 | | ✓ | - | - | 5 | - | - | Receiver Section 3 |
| | | | | 1~256 | | | | | |


ADJUSTMENT

| Order | Adjustment item | Panel tuning | PC test | AW (Analog Wide 5k) | AS (Analog Wide 4k) | AN (Analog Narrow) | NN (NXDN Narrow) | NV (NXDN Very Narrow) | Adjust item Number |
|-------|-----------------|--------------|---------|---------------------|---------------------|--------------------|------------------|-----------------------|--------------------|
| | | | | Adjustment range | | | | | |
| 20 | RSSI Reference | ✓ | ✓ | 5 | 5 | 5 | - *1 | 5 | Receiver Section 4 |
| | | | | 1~256 | | | | | |
| 21 | Open Squelch | ✓ | ✓ | 5 | 5 | 5 | - *1 | 5 | Receiver Section 5 |
| | | | | 1~256 | | | | | |
| 22 | Low RSSI | ✓ | ✓ | 5 | 5 | 5 | - *1 | 5 | Receiver Section 6 |
| | | | | 1~256 | | | | | |
| 23 | High RSSI | ✓ | ✓ | 5 | 5 | 5 | - *1 | 5 | Receiver Section 7 |
| | | | | 1~256 | | | | | |
| 24 | Tight Squelch | ✓ | ✓ | 5 | 5 | 5 | - | - | Receiver Section 8 |
| | | | | 1~256 | | | | | |


*1: Because NXDN Narrow is adjusted by adjusting Analog Narrow, it is not necessary to adjust NXDN Narrow.

■ Panel tuning mode flow chart

Note: In this Panel tuning mode flow chart, the Adjustment item name is modified.



ADJUSTMENT




ADJUSTMENT

Test Equipment Required for Alignment


| Test Equipment | Major Specifications | |
|---------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| 1. Standard Signal Generator (SSG) | Frequency Range Modulation Output When performing the Frequency adjustment, the following accuracy is necessary. • 0.001ppm Use a standard oscillator for adjustments, if necessary. | 100 to 520MHz Frequency modulation and external modulation -127dBm/0.1μV to greater than -20dBm/22.4mV |
| 2. Power Meter | Input Impedance Operation Frequency Measurement Capability | 50Ω 100 to 520MHz Vicinity of 100W |
| 3. Deviation Meter | Frequency Range | 100 to 520MHz |
| 4. Digital Volt Meter (DVM) | Measuring Range Input Impedance | 10mV to 20V DC High input impedance for minimum circuit loading |
| 5. Oscilloscope | | DC through 30MHz |
| 6. High Sensitivity Frequency Counter | Frequency Range Frequency Stability | 10Hz to 1000MHz 0.01ppm or less |
| 7. Ammeter | | 20A or more |
| 8. AF Volt Meter (AF VM) | Frequency Range Voltage Range | 50Hz to 10kHz 1mV to 10V |
| 9. Audio Generator (AG) | Frequency Range Output | 50Hz to 5kHz or more 0 to 1V |
| 10. Distortion Meter | Capability Input Level | 3% or less at 1kHz 50mV to 10Vrms |
| 11. 4Ω Dummy Load | | Approx. 4Ω, 10W |
| 12. Regulated Power Supply | | 13.2V, approx.20A (adjustable from 9V to 17V) Useful if ammeter equipped |
| 13. Spectrum Analyzer | Frequency Range Input Level Input Sensitivity Resolution Bandwidth Video Bandwidth | 40MHz to 520MHz Up to +20dBm -100dBm 100Hz 100Hz |
| 14. Tracking Generator | Frequency Range Output Level | 40MHz to 520MHz -30dBm to 0dBm |

*The test equipment which is not used for adjustment is contained in this table.

■ Test cable for microphone input (E30-3360-28)



■ MIC connector (Front panel view)




- 1 : MBL
- 2 : +B
- 3 : GND
- 4 : PTT/TXD (PC serial data from radio)
- 5 : MICE
- 6 : MIC
- 7 : HOOK/RXD (PC serial data to radio)
- 8 : DM

■ Tuning cable (E30-3383-05 or E30-7754-05)

Adapter cable (E30-3383-05 or E30-7754-05) is required for injecting an audio if PC tuning is used.
See "PC Mode" section for the connection.

Illust is E30-3383-05.



NX-820(G)/820

ADJUSTMENT

Radio check Section

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|--------------------------|---------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|------|----------|------------|-------|-----------------------------------------------------------|-------------------------------------|
| | Panel test mode | PC test mode | Test- equipment | Unit | Terminal | Unit | Parts | Method | |
| 1. Frequency check | 1) CH-Sig : 1-1 PTT : ON | 1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button. | f. counter | | ANT | | | Check an internal temperature of radio from 20°C to 26°C. | +/-0.25ppm +/-108Hz @435.1MHz |
| 2. High power check | 1) CH-Sig : 1-1 PTT : ON | 1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button. | Power meter Ammeter | | | | | Check | 23W~29W 10A or less |
| | 2) CH-Sig : 2-1 PTT : ON | 2) Test Channel Channel: 2 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button. | | | | | | | |
| | 3) CH-Sig : 3-1 PTT : ON | 3) Test Channel Channel: 3 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button. | | | | | | | |
| 3. Low power check | 1) CH-Sig : 1-1 PTT : ON | 1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button. | | | | | | | 3.5W~6.5W 7A or less |
| | 2) CH-Sig : 2-1 PTT : ON | 2) Test Channel Channel: 2 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button. | | | | | | | |
| | 3) CH-Sig : 3-1 PTT : ON | 3) Test Channel Channel: 3 Test Signaling Mode: Analog Signaling: 1 PTT: Press [Transmit] button. | | | | | | | |
| 4. MIC sensitivity check | 1) CH-Sig: 1-1 AG: 1kHz PTT: ON | 1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 AG: 1kHz PTT: Press [Transmit] button. | Deviation meter Oscillo- scope AG AF VM | | | | | Adjust AG input to get a standard MOD. | Dev 1.5kHz at 5mV±1.0mV |

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------|------|---------------------------------|------------|-------|--------|----------------------------|
| | Panel test mode | PC test mode | Test- equipment | Unit | Terminal | Unit | Parts | Method | |
| 5. Sensitivity check | 1) CH-Sig: 1-1 SSG output Wide 5k: -117dBm (0.32μV) (MOD: 1kHz/±3kHz) Narrow: -117dBm (0.32μV) (MOD: 1kHz/±1.5kHz) | 1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 SSG output Wide 5k: -116dBm (0.35μV) (MOD: 1kHz/±3kHz) Narrow: -115dBm (0.40μV) (MOD:1kHz/±1.5kHz) | SSG AF VM Oscillo- scope Distortion meter 4Ω Dummy load | | ANT Ext.SP con- nector | | | Check | 12dB SINAD or more |



Common Section

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|------|----------|------------|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test- equipment | Unit | Terminal | Unit | Parts | Method | |
| 1. Setting | 1) DC voltage: 13.2V 2) SSG standard modulation [Wide 5k] MOD: 1kHz,DEV: 3kHz [Wide 4k] MOD: 1kHz,DEV: 2.4kHz [Narrow] MOD: 1kHz,DEV: 1.5kHz | | | | | | | | |
| 2. Receive Assist | * This adjustment can be performed only PC test mode. | 1) Adj item: [Receive Assist] 2) Adj item: [Low1], [Low2], [Low3], [Center1], [Center2], [Center3], [High1], [High2], [High3] Press [Apply All] button to store the adjustment value. | | | | | [PC test mode] [◀], [▶] | [PC test mode] [Automatic Adjustment] Press [Tune Assist Voltage] button. Press [Apply All] button to store the adjustment value after the automatic adjustment has finished. [Manual Adjustment] [V] indicator on the PC window shows VCO lock voltage. Change the adjustment value to get VCO lock voltage within the limit of the specified voltage. | 2.5V±0.1V [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. Check! The assist adjustment value must be between from 340 to 3550. |
| 3. Transmit Assist | * This adjustment can be performed only PC test mode. | 1) Adj item: [Transmit Assist] 2) Adj item: [Low1], [Low2], [Low3], [Center1], [Center2], [Center3], [High1], [High2], [High3] PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value. | | | | | | Note: Confirm the VCO lock voltage approximately 3 seconds after the adjustment value is changed. | |







ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|--------------|-------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|------|----------|------------|-------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| 4. Frequency | * The Frequency adjustment can be performed only in PC test mode. | 1) Adj item: [Frequency] SSG output : -20dBm (22.4mV) (CW (without modulation)) Caution: Perform the frequency adjustment under the following conditions. <ul style="list-style-type: none"> Temperature range of +20°C to +26°C. (The temperature is displayed on the Frequency adjustment screen of the KPG-141D and the LCD of the transceiver.) Use an accuracy of 0.001ppm for the SSG. (Use a standard oscillator if necessary.) | SSG | | ANT | | | [PC test mode] Press [Start] button of "Auto Tuning". Press [Apply] button to store the adjustment value after the automatic adjustment was finished. | [PC test mode] The value of "IF20" will become around "0" (Target: ±12digit) after the adjustment was finished. Remark: "Frequency" is adjusted under receiving condition with SSG. |




Transmitter Section

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|------------------------|------|----------|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|---------------------------------------------------------------------------------------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| 1. High Transmit power Limit | 1) Adj item: [HLMT] Adjust: [****] 2) Adj item: [H.LMT_]→ [H.L.MT_]→ [H.L.M.T_]→ [H.L.M.T.]→ [H.L.M.T._]→ PTT: ON Press [<B] key to store the adjustment value | 1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit Press [Apply All] button to store the adjustment value. | Power meter Ammeter | | ANT | | [Panel tuning mode]  [PC test mode]  | 28W | ±2.0W [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |
| Low Transmit power Limit | 1) Adj item: [LLMT] Adjust: [****] 2) Adj item: [L.LMT_]→ [L.L.MT_]→ [L.L.M.T_]→ [L.L.M.T.]→ [L.L.M.T._]→ PTT: ON Press [<B] key to store the adjustment value | 1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit Press [Apply All] button to store the adjustment value. | | | | | 10W | | |





ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|------|----------|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| 2. High Transmit Power | 1) Adj item: [HPWR] Adjust: [****] 2) Adj item: [H.PWR_]→ [H.P.WR_]→ [H.P.W.R_]→ [H.P.W.R._]→ [H.P.W.R._.] PTT: ON Press [B] key to store the adjustment value | 1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit Press [Apply All] button to store the adjustment value. | Power meter Ammeter | | ANT | | [Panel tuning mode]  [PC test mode]  | 25.0W | ±1.0W 10.0A or less [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |
| Low Transmit power | 1) Adj item: [LPWR] Adjust: [****] 2) Adj item: [L.PWR_]→ [L.P.WR_]→ [L.P.W.R_]→ [L.P.W.R._]→ [L.P.W.R._.] PTT: ON Press [B] key to store the adjustment value | 1) TEST CH: Low, Low', Center, High', High (5 point) 2) Transmit Press [Apply All] button to store the adjustment value. | | | | | | 5.0W | ±0.2W 7.0A or less [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |
| 3. Balance *2 | 1) Adj item: [BAL] Adjust: [***] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [B.AL_]→ [B.A.L_]→ [B.A.L._]→ [B.A.L._.] Adjust: [***] PTT: ON Press [B] key to store the adjustment value. | 1) Adj item: [Balance] Deviation meter LPF: 3kHz HPF: OFF 2) Adj item: [Low], [Low'], [Center], [High'], [High] PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value. [2kHz Sine Wave Check box]: Check while transmitting change to 2kHz. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode]  | The Deviation of 20Hz frequency is fixed. Change the 2kHz adjustment value to become the same deviation of 20Hz within the specified range. | 2kHz Tone deviation is within ±1.0% of 20Hz tone deviation. [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |
| *2: Refer to the "Necessary Deviation adjustment item for each signaling and mode" table on page 50. Balance adjustment is common with the adjustment of all signaling deviations. | | | | | | | | | |
| 4. Maximum Deviation (NXDN) *3 [Narrow] | 1) Adj item: [NDEV] Adjust: [****.] Deviation meter LPF: 3kHz HPF: OFF PTT: ON Press [B] key to store the adjustment value. | 1) Adj item: [Maximum Deviation (NXDN Narrow)] Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode]  | Write Reference value "513" for each adjustment point. Transmit at each adjustment point and check that the Analog deviation is between 2995Hz and 3117Hz. | 2995~3117Hz [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|------|----------|------------|-----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| 4. Maximum Deviation (NXDN) *3 [Very Narrow] | 1) Adj item: [NDEV] Adjust: [****] PTT: ON Press [B] key to store the adjustment value. | 1) Adj item: [Maximum Deviation (NXDN Very Narrow)] PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode] [◀], [▶] | Write Reference value "513" for each adjustment point. Transmit at each adjustment point and check that the Analog deviation is between 1311Hz and 1363Hz. | 1311~1363Hz [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |
| 5. Maximum Deviation (Analog) *3 [Narrow] | 1) Adj item: [ADEV] Adjust: [****.] Deviation meter LPF: 15kHz HPF: OFF PTT: ON Press [B] key to store the adjustment value. | 1) Adj item: [Maximum Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode] [◀], [▶] | Write Reference value "513" for each adjustment point. Transmit at each adjustment point and check that the Analog deviation is between 2050Hz and 2150Hz. | 2050~2150Hz [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |
| [Wide 4k] | 1) Adj item: [ADEV] Adjust: [***.*] PTT: ON Press [B] key to store the adjustment value. | 1) Adj item: [Maximum Deviation (Analog Wide 4k)] PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value. | | | | | | Write Reference value "513" for each adjustment point. Transmit at each adjustment point and check that the Analog deviation is between 3310Hz and 3410Hz. | 3310~3410Hz [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |
| [Wide 5k] | 1) Adj item: [ADEV] Adjust: [**.*.*] PTT: ON Press [B] key to store the adjustment value. | 1) Adj item: [Maximum Deviation (Analog Wide 5k)] PTT: Press [Transmit] button. Press [Apply All] button to store the adjustment value. | | | | | | Write Reference value "513" for each adjustment point. Transmit at each adjustment point and check that the Analog deviation is between 4150Hz and 4250Hz. | 4150~4250Hz [PC test mode] Press [Apply All] button to store the adjustment value after all adjustment point was adjusted. |
| *3: Refer to the "Necessary Deviation adjustment item for each signaling and mode" table on page 50. Regarding Maximum Deviation (Analog), it is common with the adjustment of all analog signalings. | | | | | | | | | |
| 6. QT Deviation *4 [Narrow] | 1) Adj item: [QT] Adjust: [****.] Deviation meter LPF: 3kHz HPF: OFF PTT : ON Press [B] key to store the adjustment value. | 1) Adj item: [QT Deviation (Analog Narrow)] Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode] [◀], [▶] | Write the value 513 (Reference value) | 0.35kHz±0.05kHz |







ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks | |
|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|------|----------|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|---------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | | |
| 6. QT Deviation *4 [Wide 4k] | 1) Adj item: [QT] Adjust: [***.*.] PTT: ON Press [B] key to store the adjustment value. | 1) Adj item: [QT] Deviation (Analog Wide 4k) Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode]  | Write the value 513 (Reference value) | 0.60kHz±0.05kHz | |
| | [Wide 5k] | 1) Adj item: [QT] Adjust: [**.*.*.] PTT: ON Press [B] key to store the adjustment value. | | | | | | 1) Adj item: [QT] Deviation (Analog Wide 5k) Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 513 (Reference value) |
| 7. DQT Deviation *4 [Narrow] | 1) Adj item: [DQT] Adjust: [****.*.] Deviation meter LPF: 3kHz HPF: OFF PTT: ON Press [B] key to store the adjustment value. | 1) Adj item: [DQT] Deviation (Analog Narrow) Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode]  | Write the value 430 (Reference value) | 0.35kHz±0.05kHz | |
| | [Wide 4k] | 1) Adj item: [DQT] Adjust: [***.*.] PTT: ON Press [B] key to store the adjustment value. | | | | | | 1) Adj item: [DQT] Deviation (Analog Wide 4k) PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 430 (Reference value) |
| | [Wide 5k] | 1) Adj item: [DQT] Adjust: [**.*.*.] PTT: ON Press [B] key to store the adjustment value. | | | | | | 1) Adj item: [DQT] Deviation (Analog Wide 5k) PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 430 (Reference value) |

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks | | |
|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|------|----------|------------|-------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|---------------------------------------|-----------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | | | |
| 8. LTR Deviation *4 [Narrow] | 1) Adj item: [LTR] Adjust: [****.] Deviation meter LPF: 3kHz HPF: OFF PTT: ON Press [<B] key to store the adjustment value. | 1) Adj item: [LTR] Deviation (Analog Narrow) Deviation meter LPF: 3kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode] [↕], [↔] [PC test mode] [◀], [▶] | Write the value 465 (Reference value) | 0.75kHz±0.05kHz | | |
| | [Wide] | 1) Adj item: [LTR] Adjust: [**.*.*] PTT: ON Press [<B] key to store the adjustment value. | | | | | | 1) Adj item: [LTR] Deviation (Analog Wide) PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 465 (Reference value) | 1.00kHz±0.05kHz |
| 9. DTMF Deviation *4 [Narrow] | 1) Adj item: [DTMF] Adjust: [****.] Deviation meter LPF : 15kHz HPF : OFF PTT : ON Press [<B] key to store the adjustment value. | 1) Adj item: [DTMF] Deviation (Analog Narrow) Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode] [↕], [↔] [PC test mode] [◀], [▶] | Write the value 648 (Reference value) | 1.5kHz±0.05kHz | | |
| | [Wide 4k] | 1) Adj item: [DTMF] Adjust: [***.*.] PTT : ON Press [<B] key to store the adjustment value. | | | | | | 1) Adj item: [DTMF] Deviation (Analog Wide 4k) PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 648 (Reference value) | 2.0kHz±0.05kHz |
| | [Wide 5k] | 1) Adj item: [DTMF] Adjust: [**.*.*] PTT : ON Press [<B] key to store the adjustment value. | | | | | | 1) Adj item: [DTMF] Deviation (Analog Wide 5k) PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 648 (Reference value) | 3.0kHz±0.05kHz |
| 10. Single Tone Deviation *4 [Narrow] | 1) Adj item: [TONE] Adjust: [****.] Deviation meter LPF: 15kHz HPF: OFF PTT: ON Press [<B] key to store the adjustment value. | 1) Adj item: [Single Tone Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode] [↕], [↔] [PC test mode] [◀], [▶] | Write the value 513 (Reference value) | 1.50kHz±0.05kHz | | |

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks | |
|-----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|------|----------|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|---------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | | |
| 10. Single Tone Deviation *4 [Wide 4k] | 1) Adj item: [TONE] Adjust: [***.]. PTT: ON Press [<B] key to store the adjustment value. | 1) Adj item: [Single Tone Deviation (Analog Wide 4k)] PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode]  | Write the value 513 (Reference value) | 2.40kHz±0.05kHz | |
| | [Wide 5k] | 1) Adj item: [TONE] Adjust: [***.]. PTT: ON Press [<B] key to store the adjustment value. | | | | | | 1) Adj item: [Single Tone Deviation (Analog Wide 5k)] PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 513 (Reference value) |
| 11. MSK Deviation *4 [Narrow] | 1) Adj item: [MSK] Adjust: [****.]. Deviation meter LPF: 15kHz HPF: OFF PTT: ON Press [<B] key to store the adjustment value. | 1) Adj item: [MSK Deviation (Analog Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode]  | Write the value 513 (Reference value) | 1.50kHz±0.05kHz | |
| | [Wide 4k] | 1) Adj item: [MSK] Adjust: [***.]. PTT: ON Press [<B] key to store the adjustment value. | | | | | | 1) Adj item: [MSK Deviation (Analog Wide 4k)] PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 513 (Reference value) |
| | [Wide 5k] | 1) Adj item: [MSK] Adjust: [***.]. PTT: ON Press [<B] key to store the adjustment value. | | | | | | 1) Adj item: [MSK Deviation (Analog Wide 5k)] PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | | Write the value 513 (Reference value) |
| 12. CWID Deviation *4 [Very Narrow] | 1) Adj item: [CWID] Adjust: [****] Deviation meter LPF: 15kHz HPF: OFF PTT: ON Press [<B] key to store the adjustment value. | 1) Adj item: [CW ID Deviation (NXDN Very Narrow)] Deviation meter LPF: 15kHz HPF: OFF PTT: Press [Transmit] button. Press [Apply] button to store the adjustment value. | Deviation meter Oscilloscope | | ANT | | [Panel tuning mode]  [PC test mode]  | Write the value 376 (Reference value) | 1.00kHz±0.10kHz | |

*4: Refer to the "Necessary Deviation adjustment item for each signaling and mode" table on page 50.

NX-820(G)/820

ADJUSTMENT

■ Necessary Deviation adjustment item for each signaling and mode

The following shows the necessary adjustment items for each signaling deviation. Please read the following table like the following example. In the case of the signaling "QT (Wide 5k/Wide 4k)", this signaling is composed of three elements [Balance, Maximum Deviation (Analog Wide 5k/Wide 4k) and QT Deviation (Wide 5k/Wide 4k)]. Please adjust Balance and Maximum Deviation (Analog Wide 5k/Wide 4k) before adjusting QT Deviation (Wide 5k/Wide 4k).

| Mode | Signaling | Necessary adjustment and order | | |
|--------|--------------------|-------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| | | Wide 5k/Wide 4k | Narrow | Very Narrow |
| Analog | Audio | 1. Balance adjust 2. Maximum Deviation (Analog Wide 5k/Wide 4k) | 1. Balance adjust 2. Maximum Deviation (Analog Narrow) | - |
| | QT | 1. Balance adjust 2. Maximum Deviation (Analog Wide 5k/Wide 4k) 3. QT Deviation (Wide 5k/Wide 4k) | 1. Balance adjust 2. Maximum Deviation (Analog Narrow) 3. QT Deviation (Narrow) | - |
| | DQT | 1. Balance adjust 2. Maximum Deviation (Analog Wide 5k/Wide 4k) 3. DQT Deviation (Wide 5k/Wide 4k) | 1. Balance adjust 2. Maximum Deviation (Analog Narrow) 3. DQT Deviation (Narrow) | - |
| | LTR | 1. Balance adjust 2. Maximum Deviation (Analog Wide 5k) 3. LTR Deviation (Wide 5k) | 1. Balance adjust 2. Maximum Deviation (Analog Narrow) 3. LTR Deviation (Narrow) | - |
| | DTMF | 1. Balance adjust 2. Maximum Deviation (Analog Wide 5k/Wide 4k) 3. DTMF Deviation (Wide 5k/Wide 4k) | 1. Balance adjust 2. Maximum Deviation (Analog Narrow) 3. DTMF Deviation (Narrow) | - |
| | 2TONE/ 5TONE | 1. Balance adjust 2. Maximum Deviation (Analog Wide 5k/Wide 4k) 3. Single TONE Deviation (Analog Wide 5k/Wide 4k) | 1. Balance adjust 2. Maximum Deviation (Analog Narrow) 3. Single TONE Deviation (Analog Narrow) | - |
| | MSK (FleetSync) | 1. Balance adjust 2. Maximum Deviation (Analog Wide 5k/Wide 4k) 3. MSK Deviation (Analog Wide 5k/Wide 4k) | 1. Balance adjust 2. Maximum Deviation (Analog Narrow) 3. MSK Deviation (Analog Narrow) | - |
| NXDN | Audio | - | 1. Balance adjust 2. Maximum Deviation (NXDN Narrow) | 1. Balance adjust 2. Maximum Deviation (NXDN Very Narrow) |
| | CWID | - | - | 1. Balance adjust 2. Maximum Deviation (Analog Narrow) 3. CWID Deviation (NXDN Very Narrow) |

Receiver Section

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------|------|-------------------------|------------|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------|------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| 1.AF level setting | [Panel test mode] 1) CH-Sig: 1-1 SSG output: -47dBm (1mV) (MOD: 1kHz/±1.5kHz) Wide 5k/Narrow: Narrow Beat Shift: Uncheck Compander: Uncheck | 1) Test Channel Channel: 1 Test Signaling Mode: Analog Signaling: 1 Wide 5k/Narrow: Narrow Beat Shift: Uncheck Compander: Uncheck SSG output: -47dBm (1mV) (MOD: 1kHz/±1.5kHz) | SSG DVM AF VM 4Ω Dummy load Oscilloscope | | ANT Ext.SP connector | | [Panel tuning mode] [∧], [∨] [PC test mode] [◀], [▶] | Volume Up/Down Key to obtain 2.83V AF output. (2.0W @ 4Ω load) | 2.83V±0.3V (Volume Button in PC test mode screen) |

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks | | | | | | | | | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|------|----------------------------|------------|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|--|--------|--------|-------|----|----|--------|----|-----|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | | | | | | | | | | |
| 2. Sensitivity 1 | * This adjustment can be performed only PC test mode. | 1) Adj item: [Sensitivity 1] 2) Adj item: [Low], [Low'], [Center], [High'], [High] Press [Apply All] button to store the adjustment value. | SSG AF VM 4Ω Dummy load Distortion meter Oscilloscope | | ANT Ext.SP connector | | [PC test mode] [◀], [▶] | Write the value as follows, [Low]:34 (Preset) [Low']:75 (Preset) [Center]: 117 (Fixed) [High']: 155 (Fixed) [High]: 192 (Fixed) | | | | | | | | | | |
| 3. Sensitivity 2 | * This adjustment can be performed only PC test mode. | 1) Adj item: [Sensitivity 2] 2) Adj item: [Low], [Low'], [Center], [High'], [High] Press [Apply All] button to store the adjustment value. | SSG AF VM 4Ω Dummy load Distortion meter Oscilloscope | | ANT Ext.SP connector | | [PC test mode] [◀], [▶] | Write the value as follows, [Low]: 59 (Preset) [Low']: 98 (Preset) [Center]: 137 (Preset) [High']: 179 (Preset) [High]: 209 (Preset) | *Note | | | | | | | | | |
| <p>*Note: 12dB SINAD or more at -118.5dBm (Mod: 1kHz/±1.5kHz) with preset digit value at each adjustment point. If less than 12dB SINAD, execute the "Readjustment method 1" procedure at the failed adjustment point.</p> <p>[Readjustment method 1] Decrease the digit value to get 12dB SINAD at -118.5dBm (Mod: 1kHz/±1.5kHz). If it is still NG, execute the "Readjustment method 2" procedure.</p> <p>[Readjustment method 2] If the sensitivity is still NG for [Low] or [Low'] point by using method1, conduct the following procedure.</p> <p>1. Change the data of the failed adjustment point. ([Low] or [Low']) to the following, and store it.</p> <table style="margin-left: 40px;"> <tr> <td></td> <td>Sens 1</td> <td>Sens 2</td> </tr> <tr> <td>[Low]</td> <td>54</td> <td>69</td> </tr> <tr> <td>[Low']</td> <td>95</td> <td>108</td> </tr> </table> <p>2. Open Sensitivity 1, and select the failed adjustment point. 3. Set SSG to the following. SSG Output: -118.5dBm (0.266uV) MOD: 1kHz/±1.5kHz 4. Decrease the data until the sensitivity becomes 12dB SINAD. 5. Press [Apply All] button</p> | | | | | | | | | | | Sens 1 | Sens 2 | [Low] | 54 | 69 | [Low'] | 95 | 108 |
| | Sens 1 | Sens 2 | | | | | | | | | | | | | | | | |
| [Low] | 54 | 69 | | | | | | | | | | | | | | | | |
| [Low'] | 95 | 108 | | | | | | | | | | | | | | | | |
| 4. RSSI reference *5 [Analog Narrow] | 1) Adj item: [RRSS] Adjust: [***.] 2) Adj item: [R.RSS]→ [R.R.SS]→ [R.R.S.S]→ [R.R.S.S.]→ [R.R.S.S._] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz) | 1) Adj item: [RSSI Reference (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±1.5kHz) | SSG AF VM 4Ω Dummy load Distortion meter Oscilloscope | | ANT Ext.SP connector | | | [Panel tuning mode] After input signal from SSG, press [] key to store the adjustment value. [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value. | | | | | | | | | | |
| [Analog Wide 4k] | 1) Adj item: [RRSS] Adjust: [***.] 2) Adj item: [R.RSS]→ [R.R.SS]→ [R.R.S.S]→ [R.R.S.S.]→ [R.R.S.S._] SSG output: 12dB SINAD level for Analog Narrow -3dB (MOD:1kHz/±2.4kHz) | 1) Adj item: [RSSI Reference (Analog Wide 4k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: 12dB SINAD level for Analog Narrow -3dB (MOD: 1kHz/±2.4kHz) | | | | | | | | | | | | | | | | |

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------|------|---------------------------------|------------|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| 4. RSSI reference *5 [Analog Wide 5k] | 1) Adj item: [RRSS] Adjust: [***] 2) Adj item: [R.RSS]→ [R.R.SS]→ [R.R.S.S]→ [R.R.S.S.]→ [R.R.S.S._] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±3kHz) | 1) Adj item: [RSSI Reference (Analog Wide 5k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: 12dB SINAD level -3dB (MOD: 1kHz/±3kHz) | SSG AF VM 4Ω Dummy load Distortion meter Oscillo- scope | | ANT Ext.SP con- nector | | | [Panel tuning mode] After input signal from SSG, press [<B] key to store the adjustment value. [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value. | Adjust with the analog signal. |
| [NXDN Very Narrow] | 1) Adj item: [RRSS] Adjust: [***] 2) Adj item: [R.RSS]→ [R.R.SS]→ [R.R.S.S]→ [R.R.S.S.]→ [R.R.S.S._] SSG output: 12dB SINAD level for Analog Narrow -3dB (MOD: 1kHz/±1.5kHz) | 1) Adj item: [RSSI Reference (NXDN Very Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: 12dB SINAD level for Analog Narrow -3dB (MOD: 1kHz/±1.5kHz) | | | | | | | |
| *5: Because RSSI Reference (NXDN Narrow) is adjusted by adjusting RSSI Reference (Analog Narrow), it is not necessary to adjust RSSI Reference (NXDN Narrow). | | | | | | | | | |
| 5. Open Squelch *6 (Squelch level 5 adjust) [Analog Narrow] | 1) Adj item: [SQL] Adjust: [***] 2) Adj item: [S.Q.L]→ [S.Q.L.]→ [S.Q.L.]→ [S.Q.L._.]→ [S.Q.L._. _.] SSG output: 12dB SINAD level (MOD: 1kHz/±1.5kHz) | 1) Adj item: [Open Squelch (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: 12dB SINAD level (MOD: 1kHz/±1.5kHz) | SSG AF VM 4Ω Dummy load Distortion meter Oscillo- scope | | ANT Ext.SP con- nector | | | [Panel tuning mode] After input signal from SSG, press [<B] key to store the adjustment value. [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value. | “Open Squelch” will not be adjusted correctly if MOD and Deviation are wrong. Remark: During production, a fixed value is written. 138 (Fixed) |
| [Analog Wide 4k] | 1) Adj item: [SQL] Adjust: [***] 2) Adj item: [S.Q.L]→ [S.Q.L.]→ [S.Q.L.]→ [S.Q.L._.]→ [S.Q.L._. _.] SSG output: 12dB SINAD level (MOD: 1kHz/±2.4kHz) | 1) Adj item: [Open Squelch (Analog Wide 4k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: 12dB SINAD level (MOD: 1kHz/±2.4kHz) | | | | | | | |
| [Analog Wide 5k] | 1) Adj item: [SQL] Adjust: [***] 2) Adj item: [S.Q.L]→ [S.Q.L.]→ [S.Q.L.]→ [S.Q.L._.]→ [S.Q.L._. _.] SSG output: 12dB SINAD level (MOD: 1kHz/±3kHz) | 1) Adj item: [Open Squelch (Analog Wide 5k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: 12dB SINAD level (MOD: 1kHz/±3kHz) | | | | | | | |

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|------|----------------------------|------------|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| 5. Open Squelch *6 (Squelch level 5 adjust) [NXDN Very Narrow] | 1) Adj item: [SQL] Adjust: [***] 2) Adj item: [S.QL]→ [S.Q.L]→ [S.Q.L.]→ [S.Q.L._.]→ [S.Q.L._._] SSG output: 12dB SINAD level for Analog Narrow -4dB (MOD: 400Hz/±1.1kHz) | 1) Adj item: [Open Squelch (NXDN Very Narrow)] 2) Adj item: [Low],[Low'], [Center], [High'], [High] SSG output: 12dB SINAD level for Analog Narrow -4dB (MOD: 400Hz/±1.1kHz) | SSG AF VM 4Ω Dummy load Distortion meter Oscilloscope | | ANT Ext.SP connector | | | [Panel tuning mode] After input signal from SSG, press [<B] key to store the adjustment value. [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value. | Adjust with the analog signal. This item is adjusted under the condition that MOD is "400Hz" and Deviation is "±1.1kHz" due to the circuit configuration. Remark: During production, a fixed value is written. 171 (Fixed) |
| *6: Because Open squelch (NXDN Narrow) is adjusted by adjusting Open squelch (Analog Narrow), it is not necessary to adjust Open squelch (NXDN Narrow). | | | | | | | | | |
| 6. Low RSSI at -118dBm *7 [Analog Narrow] | 1) Adj item: [LRSS] Adjust: [***.] 2) Adj item: [L.RSS]→ [L.R.SS]→ [L.R.S.S]→ [L.R.S.S.]→ [L.R.S.S._.] SSG output: -118dBm (0.28uV) (MOD: 1kHz/±1.5kHz) | 1) Adj item: [Low RSSI (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -118dBm (0.28uV) (MOD: 1kHz/±1.5kHz) | SSG | | ANT Ext.SP connector | | | [Panel tuning mode] After input signal from SSG, press [<B] key to store the adjustment value. [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value. | |
| [Analog Wide 4k] | 1) Adj item: [LRSS] Adjust: [**.*.] 2) Adj item: [L.RSS]→ [L.R.SS]→ [L.R.S.S]→ [L.R.S.S.]→ [L.R.S.S._.] SSG output: -118dBm (0.28uV) (MOD: 1kHz/±2.4kHz) | 1) Adj item: [Low RSSI (Analog Wide 4k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -118dBm (0.28uV) (MOD: 1kHz/±2.4kHz) | | | | | | | |
| [Analog Wide 5k] | 1) Adj item: [LRSS] Adjust: [*.*.*.] 2) Adj item: [L.RSS]→ [L.R.SS]→ [L.R.S.S]→ [L.R.S.S.]→ [L.R.S.S._.] SSG output: -118dBm (0.28uV) (MOD: 1kHz/±3kHz) | 1) Adj item: [Low RSSI (Analog Wide 5k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -118dBm (0.28uV) (MOD: 1kHz/±3kHz) | | | | | | | |
| [NXDN Very Narrow] | 1) Adj item: [LRSS] Adjust: [***] 2) Adj item: [L.RSS]→ [L.R.SS]→ [L.R.S.S]→ [L.R.S.S.]→ [L.R.S.S._.] SSG output: -118dBm (0.28uV) (MOD: 1kHz/±1.5kHz) | 1) Adj item: [Low RSSI (NXDN Very Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -118dBm (0.28uV) (MOD: 1kHz/±1.5kHz) | | | | | | | Adjust with the analog signal. |

NX-820(G)/820

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|------|----------------------|------------|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| *7: Because Low RSSI at -118dBm (NXDN Narrow) is adjusted by adjusting Low RSSI at -118dBm (Analog Narrow), it is not necessary to adjust Low RSSI at -118dBm (NXDN Narrow). | | | | | | | | | |
| 7. High RSSI at -80dBm *8 [Analog Narrow] | 1) Adj item: [HRSS] Adjust: [***.] 2) Adj item: [H.RSS]→ [H.R.SS]→ [H.R.S.S]→ [H.R.S.S.]→ [H.R.S.S._.] SSG output: -80dBm (22.4uV) (MOD: 1kHz/±1.5kHz) | 1) Adj item: [High RSSI (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -80dBm (22.4μV) (MOD: 1kHz/±1.5kHz) | SSG | | ANT Ext.SP connector | | | [Panel tuning mode] After input signal from SSG, press [<B] key to store the adjustment value. [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value. | |
| [Analog Wide 4k] | 1) Adj item: [HRSS] Adjust: [**,*.] 2) Adj item: [H.RSS]→ [H.R.SS]→ [H.R.S.S]→ [H.R.S.S.]→ [H.R.S.S._.] SSG output : -80dBm (22.4uV) (MOD: 1kHz/±2.4kHz) | 1) Adj item: [High RSSI (Analog Wide 4k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -80dBm (22.4μV) (MOD: 1kHz/±2.4kHz) | | | | | | | |
| [Analog Wide 5k] | 1) Adj item: [HRSS] Adjust: [*,*.*] 2) Adj item: [H.RSS]→ [H.R.SS]→ [H.R.S.S]→ [H.R.S.S.]→ [H.R.S.S._.] SSG output : -80dBm (22.4uV) (MOD: 1kHz/±3kHz) | 1) Adj item: [High RSSI (Analog Wide 5k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -80dBm (22.4μV) (MOD: 1kHz/±3kHz) | | | | | | | |
| [NXDN Very Narrow] | 1) Adj item: [HRSS] Adjust: [***] 2) Adj item: [H.RSS]→ [H.R.SS]→ [H.R.S.S]→ [H.R.S.S.]→ [H.R.S.S._.] SSG output : -80dBm (22.4uV) (MOD: 1kHz/±1.5kHz) | 1) Adj item: [High RSSI (NXDN Very Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] SSG output: -80dBm (22.4μV) (MOD: 1kHz/±1.5kHz) | | | | | | | Adjust with the analog signal. |
| *8: Because "RSSI at -80dBm adjust" of NXDN Narrow is adjusted by adjusting "RSSI at -80dBm adjust [Analog Narrow]", it is not necessary to adjust "RSSI at -80dBm adjust" of NXDN Narrow. | | | | | | | | | |

ADJUSTMENT

| Item | Condition | | Measurement | | | Adjustment | | | Specifications/ Remarks |
|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|------|-------------------------|------------|-------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Panel tuning mode | PC test mode | Test-equipment | Unit | Terminal | Unit | Parts | Method | |
| 8. Squelch (Tight) [Analog Narrow] | 1) Adj item: [SQLT] Adjust: [***.] 2) Adj item: [S.QLT]→ [S.Q.LT]→ [S.Q.L.T.]→ [S.Q.L.T.]→ [S.Q.L.T._.] SSG output: 12dB SINAD level + 4dB (MOD: 1kHz/±1.5kHz) | 1) Adj item: [Tight Squelch (Analog Narrow)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] Press [Apply All] button to store the adjustment value. | SSG AF VM 4Ω Dummy load Distortion meter Oscilloscope | | ANT Ext.SP connector | | | [Panel tuning mode] After input signal from SSG, press [] key to store the adjustment value. [PC test mode] After input signal from SSG, press [Apply] button to store the adjustment value. | “Squelch (Tight)” will not be adjusted correctly if MOD or Deviation is wrong. Remark: During production, a fixed value is written. -Analog Narrow [S.QLT]→ 248 [S.Q.LT]→ 248 [S.Q.L.T.]→ 248 [S.Q.L.T._.]→ 248 -Analog Wide 4k [S.QLT]→ 252 [S.Q.LT]→ 252 [S.Q.L.T.]→ 252 [S.Q.L.T._.]→ 252 -Analog Wide 5k [S.QLT]→ 255 [S.Q.LT]→ 255 [S.Q.L.T.]→ 255 [S.Q.L.T._.]→ 255 |
| [Analog Wide 4k] | 1) Adj item: [SQLT] Adjust: [***.] 2) Adj item: [S.QLT]→ [S.Q.LT]→ [S.Q.L.T.]→ [S.Q.L.T.]→ [S.Q.L.T._.] SSG output: 12dB SINAD level + 4dB (MOD: 1kHz/±2.4kHz) | 1) Adj item: [Tight Squelch (Analog Wide 4k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] Press [Apply All] button to store the adjustment value. | | | | | | | |
| [Analog Wide 5k] | 1) Adj item: [SQLT] Adjust: [***.] 2) Adj item: [S.QLT]→ [S.Q.LT]→ [S.Q.L.T.]→ [S.Q.L.T.]→ [S.Q.L.T._.] SSG output: 12dB SINAD level + 4dB (MOD: 1kHz/±3kHz) | 1) Adj item: [Tight Squelch (Analog Wide 5k)] 2) Adj item: [Low], [Low'], [Center], [High'], [High] Press [Apply All] button to store the adjustment value. | | | | | | | |

NX-820(G)/820

TERMINAL FUNCTION

Display unit (X54-3830-10)

| Pin No. | Name | I/O | Function |
|----------------------------------|----------|-----|------------------------------------|
| CN1 (to TX-RX unit CN514) | | | |
| 1 | SB | I | Battery voltage DC supply |
| 2 | SB | I | Battery voltage DC supply |
| 3 | SP- | I | Speaker input - |
| 4 | SP- | I | Speaker input - |
| 5 | SP+ | I | Speaker input + |
| 6 | SP+ | I | Speaker input + |
| 7 | BLC | I | LCD backlight control signal input |
| 8 | MBL | I | MIC backlight control signal input |
| 9 | RLED | I | Red LED control signal input |
| 10 | GLED | I | Green LED control signal input |
| 11 | BLED | I | Blue LED control signal input |
| 12 | GND | - | Ground |
| 13 | GND | - | Ground |
| 14 | GND | - | Ground |
| 15 | EMG | O | Emergency key detection |
| 16 | GND | - | Ground |
| 17 | NC | - | No connection |
| 18 | 50C | I | 5V DC power supply |
| 19 | LCDDI | I | LCD data input |
| 20 | LCDCE | I | LCD enable input |
| 21 | LCDCL | I | LCD clock input |
| 22 | LCDDO | O | LCD data output |
| 23 | GND | - | Ground |
| 24 | GND | - | Ground |
| 25 | MIC | O | MIC signal output |
| 26 | ME | - | MIC ground |
| 27 | HOOK/RXD | O | HOOK/PC serial data |
| 28 | PTT/TXD | I/O | PTT/PC serial data |
| 29 | MKEY | I/O | MIC data detection |
| 30 | POWER | O | Detection output of power switch |
| J1 (MIC jack) | | | |
| 1 | MBL | O | MIC backlight control |
| 2 | SB | O | Battery voltage DC supply |
| 3 | GND | - | Ground |
| 4 | PTT | I/O | PTT/ PC serial data from radio |
| 5 | ME | - | MIC ground |
| 6 | MIC | I | MIC signal input |
| 7 | HOOK | I | HOOK/ PC serial data to radio |
| 8 | DM | I/O | MIC data detection |

TX-RX unit (X57-8240-1X)

| Pin No. | Name | I/O | Function |
|------------------------------------|--------------|-----|-------------------------------------|
| CN514 (to Display unit CN1) | | | |
| 1 | SB | O | Battery voltage DC supply |
| 2 | SB | O | Battery voltage DC supply |
| 3 | SP- | O | Speaker output - |
| 4 | SP- | O | Speaker output - |
| 5 | SP+ | O | Speaker output + |
| 6 | SP+ | O | Speaker output + |
| 7 | BLC | O | LCD backlight control signal output |
| 8 | MBL | O | MIC backlight control signal output |
| 9 | RLED | O | Red LED control signal output |
| 10 | GLED | O | Green LED control signal output |
| 11 | BLED | O | Blue LED control signal output |
| 12 | GND | - | Ground |
| 13 | GND | - | Ground |
| 14 | GND | - | Ground |
| 15 | EMG | I | Emergency key detection |
| 16 | GND | - | Ground |
| 17 | NC | - | No connection |
| 18 | 50C | O | 5V DC power supply |
| 19 | LCDDI | O | LCD data output |
| 20 | LCDCE | O | LCD enable output |
| 21 | LCDCL | O | LCD clock output |
| 22 | LCDDO | I | LCD data input |
| 23 | GND | - | Ground |
| 24 | GND | - | Ground |
| 25 | MIC | I | MIC signal input |
| 26 | ME | - | MIC ground |
| 27 | HOOK/ RXD | I | HOOK/PC serial data |
| 28 | PTT/TXD | I/O | PTT/PC serial data |
| 29 | MKEY | I/O | MIC data detection |
| 30 | POWER | I | Detection input of power switch |

TERMINAL FUNCTION

8pin Modular Connector Specification

| Pin No. | Pin Name | I/O | Signal Type | Description/port type | Item and Condition | Min | Typ | Max | Unit | Note |
|---------|--------------|-----|-------------|----------------------------------------------------|-------------------------------------------|--------------------------------------------|-----|--------|-------|------|
| 1 | MBL | O | Digital | CMOS output | VOH | 4.2 | | 5.2 | V | |
| | | | | | VOL | - | | 0.8 | V | |
| 2 | SB | O | Power | Switched B output | Output Voltage | This parameter depends on Battery voltage. | | | | |
| | | | | | Output Current | | | 200 | mA | |
| 3 | GND | - | GND | Ground | Allowable current value | | | 200 | mA | |
| 4 | PTT | I | Digital | CMOS input (Pull Up: 5.0V/10kΩ) | VIH | 4.2 | | 5.0 | V | |
| | | | | | VIL | 0 | | 0.8 | V | |
| | TXD | O | Digital | CMOS 3-State Buffer output (Pull Up: 5.0V/10kΩ) | VOH | 4.2 | | 5.2 | V | |
| | | | | | VOL | - | | 0.8 | V | |
| | | | | | Baud rate | - | | 19200 | bps | |
| 5 | ME | - | GND | MIC Ground | MIC Ground | This is ground port for Microphone. | | | | |
| 6 | MIC | I | Analog | Audio input | Output Amplitude (1kHz, 60% deviation) | - | 5 | - | mVrms | |
| | | | | | Coupling Capacitor | - | 10 | - | uF | |
| | | | | | Input impedance | - | 600 | - | Ω | |
| | | | | | Allowable Frequency | 300 | | 3000 | Hz | |
| 7 | HOOK/ RXD | I | Digital | DTC144EE input (Pull Up: 5.0V/4.7kΩ) | VIH | 4.2 | | 5.0 | V | |
| | | | | | VIL | 0 | | 0.8 | V | |
| | | | | | Baud rate | - | | 115200 | bps | |
| 8 | DM | I | Digital | CMOS input/output (Pull Up: 5.0V/47kΩ) | VIH | 4.2 | | 5.0 | V | |
| | | | | | VIL | 0 | | 0.8 | V | |
| | | O | Digital | | VOL | - | | 0.8 | V | |

15pin D-sub Connector Specification

| Pin No. | Pin Name | I/O | Signal Type | Description | Item and Condition | Min | Typ | Max | Unit | Note |
|---------|----------|-----|-------------|----------------------|---------------------|--------------------------------------------|-----|------|------|-----------------------|
| 1 | SB | - | Power | Switched B output | Voltage | This parameter depends on Battery voltage. | | | | |
| | | | | | Supply Current | - | - | 2.0 | A | |
| | | | | | (with KCT-60) | - | - | 0.5 | A | |
| 2 | IGN | I | Digital | Ignition sense input | Input Voltage | 10.8 | - | 16 | V | |
| 3 | SP2/PA | O | Analog | Speaker output | Audio output | 3 | 4 | - | W | at 4Ω, 10% Distortion |
| | | | | | Coupling Capacitor | - | 330 | - | uF | |
| | | | | | RL | 4 | - | - | Ω | |
| | | | | | Allowable Frequency | 300 | - | 3000 | Hz | |

NX-820(G)/820

TERMINAL FUNCTION


| Pin No. | Pin Name | I/O | Signal Type | Description | Item and Condition | Min | Typ | Max | Unit | Note |
|-----------|------------------|-----|-------------|---------------------------|---------------------|------|------|-------|-------|--------------------|
| 4 | DETO | O | Analog | FM detector output | Output Level | - | 0.28 | - | Vp-p | |
| | | | | | Coupling Capacitor | - | 4.7 | - | uF | |
| | | | | | Allowable Load | 600 | - | - | Ω | |
| | AFO | O | Analog | RX Audio output | Output Level | - | 0.24 | - | Vp-p | |
| | | | | | Coupling Capacitor | - | 4.7 | - | uF | |
| | | | | | Allowable Load | 600 | - | - | Ω | |
| 5 | DATAI | I | Analog | External Modulation input | Input Voltage Range | - | 0.5 | 1.98 | Vp-p | Standard deviation |
| | | | | | Input Impedance | - | 100 | - | kΩ | |
| | MI2 | I | Analog | External MIC AF Input | Input Voltage Range | - | 5 | - | mVrms | |
| | | | | | Allowable Frequency | 300 | - | 3000 | Hz | |
| | | | | | Input Impedance | - | 600 | - | Ω | |
| 6 | FNC1/ TXD | I/O | Digital | Programmable I/O | VIH | 4.0 | - | 5.2 | V | |
| | | | | | VIL | -0.5 | - | 1.0 | V | |
| | | | | | VOH (Io=-1.5mA) | 4.0 | - | 5.2 | V | |
| | | | | | VOL (Io=1.5mA) | - | - | 1.1 | V | |
| | TXD (RS-232C) | O | Digital | RS-232C Serial port (TXD) | Voltage Swing | ±5 | ±9 | - | V | 3kΩ Load |
| | | | | | Baud Rate | 1200 | - | 19200 | bps | |
| | | | | | CL | | 100 | | pF | |
| 7 | FNC2/ RXD | I/O | Digital | Programmable I/O | VIH | 4.0 | - | 5.2 | V | |
| | | | | | VIL | -0.5 | - | 1.0 | V | |
| | | | | | VOH (Io=-1.5mA) | 4.0 | - | 5.2 | V | |
| | | | | | VOL (Io=1.5mA) | - | - | 1.1 | V | |
| | RXD (RS-232C) | I | Digital | RS-232C Serial port (RXD) | Input Voltage Range | -30 | - | 30 | V | |
| | | | | | Threshold Low | 0.5 | 1.3 | - | V | |
| | | | | | Threshold High | - | 1.75 | 2.6 | V | |
| Baud Rate | 1200 | - | 19200 | bps | | | | | | |
| 8 | FNC3 | I/O | Digital | Programmable I/O | VIH | 4.0 | - | 5.2 | V | |
| | | | | | VIL | -0.5 | - | 1.0 | V | |
| | | | | | VOH (Io=-1.5mA) | 4.0 | - | 5.2 | V | |
| | | | | | VOL (Io=1.5mA) | - | - | 1.1 | V | |
| | RTS (RS-232C) | O | Digital | RS-232C Serial port (RTS) | Voltage Swing | ±5 | ±9 | - | V | 3kΩ Load |
| 9 | FNC4 | I/O | Digital | Programmable I/O | VIH | 4.0 | - | 5.2 | V | |
| | | | | | VOH | -0.5 | - | 1.0 | V | |
| | | | | | VOH (Io=-1.5mA) | 4.0 | - | 5.2 | V | |
| | | | | | VOL (Io=1.5mA) | - | - | 1.1 | V | |
| | CTS (RS-232C) | I | Digital | RS-232C Serial port (CTS) | Input Voltage Range | -30 | - | 30 | V | |
| | | | | | Threshold Low | 0.5 | 1.3 | - | V | |
| | | | | | Threshold High | - | 1.75 | 2.6 | V | |
| 10 | FNC5 | I/O | Digital | Programmable I/O | VIH | 4.0 | - | 5.2 | V | |
| | | | | | VOH | -0.5 | - | 1.0 | V | |
| | | | | | VOH (Io=-1.5mA) | 4.0 | - | 5.2 | V | |
| | | | | | VOL (Io=1.5mA) | - | - | 1.1 | V | |

TERMINAL FUNCTION


| Pin No. | Pin Name | I/O | Signal Type | Description | Item and Condition | Min | Typ | Max | Unit | Note |
|---------|----------|-----|-------------|--------------------------|--------------------|------|-----|------|------|------|
| 11 | FNC6 | I/O | Digital | Programmable I/O | VIH | 4.0 | - | 5.2 | V | |
| | | | | | VIL | -0.5 | - | 1.0 | V | |
| | | | | | VOH (Io=-1.5mA) | 4.0 | - | 5.2 | V | |
| | | | | | VOL (Io=1.5mA) | - | - | 1.1 | V | |
| 12 | 50MC | O | Power | 5V DC Power supply | Output Voltage | 4.5 | 5.0 | 5.25 | V | |
| | | | | | Output Current | - | - | 100 | mA | |
| 13 | HR1 | I | Analog | Horn alert signal input | Input Voltage | 5 | - | 16 | V | |
| | | | | | Input Current | - | - | 2.0 | A | |
| | | | | | Rds (ON) | - | 55 | 108 | mΩ | |
| 14 | HR2 | O | Analog | Horn alert signal output | Output Voltage | - | - | 16 | V | |
| | | | | | Output Current | - | - | 2.0 | A | |
| 15 | GND | - | GND | Ground | | | | | - | |

NX-820(G)/820 PC BOARD

DISPLAY UNIT (X54-3830-10) Component side view (J79-0345-09)




DISPLAY UNIT (X54-3830-10) Foil side view (J79-0345-09)




PC BOARD NX-820(G)/820


DISPLAY UNIT (X54-3830-10) Component side view (J79-0345-09)




| Ref. No. | Address |
|----------|---------|
| D5 | 4D |
| D7 | 7K |
| D8 | 7G |
| D9 | 7O |
| D11 | 3G |
| D12 | 3N |
| D13 | 4N |
| D14 | 4G |
| D15 | 3H |
| D17 | 4M |
| D16 | 3M |
| D18 | 4H |
| D19 | 3J |
| D21 | 4K |
| D20 | 3K |
| D22 | 4C |
| D23 | 4B |



DISPLAY UNIT (X54-3830-10) Foil side view (J79-0345-09)




| Ref. No. | Address |
|----------|---------|
| IC1 | 12K |
| Q3 | 11B |
| Q6 | 12B |
| Q8 | 11F |
| Q9 | 11E |
| Q10 | 12B |
| Q11 | 11F |
| D1 | 10B |
| D2 | 9C |
| D25 | 10B |
| D26 | 12M |
| D27 | 11E |




NX-820(G)/820 PC BOARD

TX-RX UNIT (X57-8240-1X) Component side view (J79-0344-09)




PC BOARD NX-820(G)/820

TX-RX UNIT (X57-8240-1X) Component side view (J79-0344-09)



| Ref. No. | Address | Ref. No. | Address |
|----------|---------|----------|---------|
| IC2 | 9K | Q703 | 9F |
| IC3 | 10L | Q704 | 9F |
| IC103 | 7K | Q705 | 8E |
| IC201 | 11P | Q706 | 8F |
| IC303 | 12L | Q708 | 9D |
| IC402 | 8D | Q709 | 8D |
| IC404 | 7E | D2 | 10L |
| IC409 | 8J | D101 | 7I |
| IC509 | 11E | D102 | 7J |
| IC511 | 11D | D111 | 7K |
| IC512 | 9D | D201 | 10N |
| IC515 | 9E | D202 | 10O |
| IC701 | 11H | D203 | 10O |
| IC702 | 9G | D205 | 10O |
| IC703 | 9G | D404 | 7C |
| IC705 | 9H | D410 | 6C |
| IC711 | 10H | D411 | 6D |
| IC712 | 8H | D502 | 11E |
| IC713 | 9I | D505 | 7H |
| IC716 | 11D | D506 | 7H |
| IC801 | 5C | D507 | 7H |
| Q1 | 10L | D508 | 7G |
| Q2 | 9L | D509 | 7G |
| Q105 | 8K | D510 | 7G |
| Q402 | 7E | D511 | 11D |
| Q404 | 8E | D512 | 5E |
| Q405 | 8E | D513 | 5E |
| Q408 | 7F | D601 | 5E |
| Q411 | 8F | D701 | 9I |
| Q412 | 8E | D702 | 9I |
| Q417 | 7F | D703 | 9G |
| Q504 | 6D | D704 | 9G |
| Q701 | 10H | D801 | 7C |
| Q702 | 10H | D802 | 7C |




J79-0344-09


NX-820(G)/820 PC BOARD

TX-RX UNIT (X57-8240-1X) Foil side view (J79-0344-09)

| Ref. No. | Address | Ref. No. | Address |
|----------|---------|----------|---------|
| IC1 | 7Q | Q418 | 5Q |
| IC301 | 11M | Q501 | 12M |
| IC304 | 12H | Q502 | 3O |
| IC401 | 9M | Q503 | 3N |
| IC405 | 7O | D3 | 10H |
| IC406 | 9M | D4 | 11I |
| IC407 | 8P | D7 | 10H |
| IC408 | 8N | D8 | 10J |
| IC501 | 11P | D9 | 10H |
| IC502 | 9P | D10 | 10H |
| IC503 | 11Q | D11 | 10J |
| IC504 | 12Q | D12 | 10J |
| IC506 | 9N | D13 | 10I |
| IC507 | 11N | D14 | 9I |
| IC508 | 12M | D16 | 8H |
| IC513 | 8L | D17 | 8H |
| IC514 | 8K | D103 | 6E |
| IC516 | 7L | D104 | 5C |
| Q4 | 9I | D105 | 6E |
| Q5 | 10H | D106 | 6E |
| Q6 | 10I | D107 | 8E |
| Q8 | 9I | D108 | 10L |
| Q9 | 9I | D109 | 10L |
| Q10 | 9H | D110 | 8F |
| Q11 | 9H | D112 | 8F |
| Q101 | 7I | D113 | 8F |
| Q102 | 7J | D114 | 8F |
| Q106 | 7I | D204 | 9D |
| Q201 | 10G | D206 | 9D |
| Q202 | 9C | D401 | 6Q |
| Q303 | 10K | D403 | 6P |
| Q305 | 11F | D405 | 9M |
| Q401 | 6P | D406 | 7N |
| Q403 | 6R | D407 | 7O |
| Q407 | 8O | D408 | 11K |
| Q409 | 9L | D409 | 11K |
| Q410 | 8O | D504 | 9K |
| Q414 | 11L | D705 | 5N |
| Q415 | 11L | D706 | 5N |
| Q416 | 11L | | |




Component side



Foil side

PC BOARD NX-820(G)/820


TX-RX UNIT (X57-8240-1X) Foil side view (J79-0344-09)




J79-0344-09

NX-820(G)/820

INTERCONNECTION DIAGRAM




SCHEMATIC DIAGRAM NX-820(G)/820




NX-820(G)/820 SCHEMATIC DIAGRAM

TX-RX UNIT (X57-8240-1X)




SCHEMATIC DIAGRAM NX-820(G)/820

TX-RX UNIT (X57-8240-1X)




NX-820(G)/820 SCHEMATIC DIAGRAM

TX-RX UNIT (X57-8240-1X)



SCHEMATIC DIAGRAM NX-820(G)/820


TX-RX UNIT (X57-8240-1X)



NX-820(G)/820 SCHEMATIC DIAGRAM


| *1 | X57-824X-XX | A801 | CN801 | C809 | C814 | C815 | C816 | C820 | C821 | C822 | C823 | C824 | C825 | C826 | D801 | D802 | L801 | L802 | L805 | L806 | R561 | R802 | R835 | R839 | R842 | R843 | R844 | IC801 | |
|------|-------------|------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|-------|-----|
| 0-12 | NX-820(G) | E | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES |
| 0-13 | NX-820 | F | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO | NO |

TX-RX UNIT (X57-8240-1X)



SCHEMATIC DIAGRAM NX-820(G)/820

TX-RX UNIT (X57-8240-1X)





NX-820(G)/820 SCHEMATIC DIAGRAM

TX-RX UNIT (X57-8240-1X)


THP1

THP1



SCHEMATIC DIAGRAM NX-820(G)/820


TX-RX UNIT (X57-8240-1X)



AT AU AV AW AX


NX-820(G)/820 SCHEMATIC DIAGRAM

TX-RX UNIT (X57-8240-1X)




SCHEMATIC DIAGRAM NX-820(G)/820

DISPLAY UNIT (X54-3830-10)




NX-820(G)/820

BLOCK DIAGRAM




NX-820(G)/820

BLOCK DIAGRAM




NX-820(G)/820

BLOCK DIAGRAM




LEVEL DIAGRAM

Receiver Section



To make measurements in the AF section, connect the AC level meter. (ANT input: -53dBm, 1kHz FM, 3kHz DEV (Wide))
 In the RF section, use a 1000pF coupling capacitor.
 (The display shows the SSG input value required to obtain 12dB SINAD without local level.)

Transmitter Section



MIC input : 3kHz DEV.(Wide), 1.5kHz DEV.(Narrow) at 1kHz MOD.
 Transmitting frequency : Center frequency

NX-820(G)/820

OPTIONAL ACCESSORIES

KRA-40 (GPS ACTIVE ANTENNA)

■ Specifications

| | |
|--------------------------------------|-------------------|
| Operating Temperature | -30°C ~ +85°C |
| Water Performance..... | IP*7 |
| Center Frequency | 1575.42MHz |
| Output Impedance | 50Ω |
| Dimensions (Cable not included)..... | 33 x 36 x 12.8 mm |
| Cable length | Approx. 5 m |

■ External View



SPECIFICATIONS

GENERAL

| | |
|-----------------------------------|--------------------------------------------------|
| Frequency Range | 400~470MHz |
| Number of Channels..... | 260 |
| Zones..... | 128 |
| Max. Channels per Zone | 250 |
| Channel Spacing | Analog: 12.5/20/25 kHz Digital: 6.25/12.5 kHz |
| Operating Voltage | 13.2V DC (10.8~15.6V DC) |
| Operating Temperature Range | -30°C~+60°C |
| Frequency Stability | ±1.0ppm |
| Antenna Impedance | 50Ω |
| Dimensions (W x H x D) | 160 x 43 x 136 mm |
| (Projections not included) | |
| Weight | 1.3 kg |

RECEIVER

| | |
|------------------------------------|-----------------------------------------------------------------------|
| Sensitivity | Digital @6.25kHz (1% BER): 0.28μV Digital @12.5kHz (1% BER): 0.4μV |
| | Analog EIA 12dB SINAD: 0.25μV |
| | Analog EN 20dB SINAD: -3dBμV |
| Adjacent Channel Selectivity | Analog @25kHz: 78dB Analog @20kHz: 76dB Analog @12.5kHz: 68dB |
| Intermodulation Distortion | Analog: 65dB |
| Spurious Response | Analog: 80dB |
| Audio Distortion | Less than 3% |
| Audio Output | 4W/4Ω |

TRANSMITTER

| | |
|-------------------------|------------------------------------------------------------------------------------------------------------------------|
| RF Power Output | 5~25W |
| Spurious Response | -36dBm ≤ 1GHz, -30dBm > 1GHz |
| FM Noise (EIA) | Analog @25kHz: 50dB Analog @20kHz: 50dB Analog @12.5kHz: 45dB |
| Modulation | 16K0F3E, 14K0F2D, 14K0F3E, 12K0F2D, 8K50F3E, 7K50F2D, 8K30F1E, 8K30F1D, 8K30F7W, 4K00F1E, 4K00F1D, 4K00F7W, 4K00F2D |

Analog measurements made per EN standards or TIA/EIA 603 and specifications shown are typical.

JVC KENWOOD Corporation reserves the right to change specifications without prior notice or obligation.

NX-820(G)/820

JVCKENWOOD Corporation

3-12, Moriyacho, Kanagawa-ku, Yokohama-shi,
Kanagawa, 221-0022 Japan

Kenwood U.S.A. Corporation

P.O. BOX 22745, 2201 East Dominguez Street, Long Beach,
CA 90801-5745, U.S.A.

Kenwood Electronics Canada Inc.

6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

Kenwood Electronics Deutschland GmbH

Rembrücker Str. 15, 63150 Heusenstamm, Germany

Kenwood Electronics Belgium N.V.

Leuvensesteenweg 248 J, 1800 Vilvoorde, Belgium

Kenwood Electronics France S.A.

L'Etoile Paris Nord 2, 50 Allée des Impressionnistes,
Bp 58416 Villepinte, 95944 Roissy Ch De Gaulle Cedex

Kenwood Electronics UK Limited

Kenwood House, Dwight Road, Watford, Herts.,
WD18 9EB United Kingdom

Kenwood Electronics Europe B.V.

Amsterdamseweg 37, 1422 AC Uithoorn, The Netherlands

Kenwood Electronics Italia S.p.A.

Via G. Sirtori, 7/9 20129 Milano, Italy

Kenwood Ibérica, S.A.

Carretera de Rubi, 88 Planta 1 A 08174 Sant Cugat del Vallès
Barcelona, Spain

JVCKENWOOD Australia Pty. Ltd.

Talavera Business Park Building A, 4 Talavera Road,
North Ryde NSW 2113 Australia

Kenwood Electronics (Hong Kong) Ltd.

Suite 2504, 25/F, Tower 2, Nina Tower, No. 8 Yeung Uk Road,
Tsuen Wan, New Territories, Hong Kong

Kenwood Electronics Singapore Pte Ltd


1 Ang Mo Kio Street 63, Singapore 569110

NX-820(G)/820 PC BOARD


PC BOARD NX-820(G)/820

DISPLAY UNIT (X54-3830-10) Component side view (J79-0345-09)

DISPLAY UNIT (X54-3830-10) Component side view (J79-0345-09)




| Ref. No. | Address |
|----------|---------|
| D5 | 4D |
| D7 | 7K |
| D8 | 7G |
| D9 | 7O |
| D11 | 3G |
| D12 | 3N |
| D13 | 4N |
| D14 | 4G |
| D15 | 3H |
| D17 | 4M |
| D16 | 3M |
| D18 | 4H |
| D19 | 3J |
| D21 | 4K |
| D20 | 3K |
| D22 | 4C |
| D23 | 4B |




DISPLAY UNIT (X54-3830-10) Foil side view (J79-0345-09)

DISPLAY UNIT (X54-3830-10) Foil side view (J79-0345-09)



| Ref. No. | Address |
|----------|---------|
| IC1 | 12K |
| Q3 | 11B |
| Q6 | 12B |
| Q8 | 11F |
| Q9 | 11E |
| Q10 | 12B |
| Q11 | 11F |
| D1 | 10B |
| D2 | 9C |
| D25 | 10B |
| D26 | 12M |
| D27 | 11E |




NX-820(G)/820 PC BOARD


PC BOARD NX-820(G)/820

TX-RX UNIT (X57-8240-1X) Component side view (J79-0344-09)

TX-RX UNIT (X57-8240-1X) Component side view (J79-0344-09)



| Ref. No. | Address | Ref. No. | Address |
|----------|---------|----------|---------|
| IC2 | 9K | Q703 | 9F |
| IC3 | 10L | Q704 | 9F |
| IC103 | 7K | Q705 | 8E |
| IC201 | 11P | Q706 | 8F |
| IC303 | 12L | Q708 | 9D |
| IC402 | 8D | Q709 | 8D |
| IC404 | 7E | D2 | 10L |
| IC409 | 8J | D101 | 7I |
| IC509 | 11E | D102 | 7J |
| IC511 | 11D | D111 | 7K |
| IC512 | 9D | D201 | 10N |
| IC701 | 11H | D203 | 10O |
| IC702 | 9G | D205 | 10O |
| IC703 | 9G | D404 | 7C |
| IC705 | 9H | D410 | 6C |
| IC711 | 10H | D411 | 6D |
| IC712 | 8H | D502 | 11E |
| IC713 | 9I | D505 | 7H |
| IC716 | 11D | D506 | 7H |
| IC801 | 5C | D507 | 7H |
| Q1 | 10L | D508 | 7G |
| Q2 | 9L | D509 | 7G |
| Q105 | 8K | D510 | 7G |
| Q402 | 7E | D511 | 11D |
| Q404 | 8E | D512 | 5E |
| Q405 | 8E | D513 | 5E |
| Q408 | 7F | D601 | 5E |
| Q411 | 8F | D701 | 9I |
| Q412 | 8E | D702 | 9I |
| Q417 | 7F | D703 | 9G |
| Q504 | 6D | D704 | 9G |
| Q701 | 10H | D801 | 7C |
| Q702 | 10H | D802 | 7C |




NX-820(G)/820 PC BOARD

PC BOARD NX-820(G)/820

TX-RX UNIT (X57-8240-1X) Foil side view (J79-0344-09)

TX-RX UNIT (X57-8240-1X) Foil side view (J79-0344-09)



| Ref. No. | Address | Ref. No. | Address |
|----------|---------|----------|---------|
| IC1 | 7Q | Q418 | 5Q |
| IC301 | 11M | Q501 | 12M |
| IC304 | 12H | Q502 | 3O |
| IC401 | 9M | Q503 | 3N |
| IC405 | 7O | D3 | 10H |
| IC406 | 9M | D4 | 11I |
| IC407 | 8P | D7 | 10H |
| IC408 | 8N | D8 | 10J |
| IC501 | 11P | D9 | 10H |
| IC502 | 9P | D10 | 10H |
| IC503 | 11Q | D11 | 10J |
| IC504 | 12Q | D12 | 10J |
| IC506 | 9N | D13 | 10I |
| IC507 | 11N | D14 | 9I |
| IC508 | 12M | D16 | 8H |
| IC513 | 8L | D17 | 8H |
| IC514 | 8K | D103 | 6E |
| IC516 | 7L | D104 | 5C |
| Q4 | 9I | D105 | 6E |
| Q5 | 10H | D106 | 6E |
| Q6 | 10I | D107 | 8E |
| Q8 | 9I | D108 | 10L |
| Q9 | 9I | D109 | 10L |
| Q10 | 9H | D110 | 8F |
| Q11 | 9H | D112 | 8F |
| Q101 | 7I | D113 | 8F |
| Q102 | 7J | D114 | 8F |
| Q106 | 7I | D204 | 9D |
| Q201 | 10G | D206 | 9D |
| Q202 | 9C | D401 | 6Q |
| Q303 | 10K | D403 | 6P |
| Q305 | 11F | D405 | 9M |
| Q401 | 6P | D406 | 7N |
| Q403 | 6R | D407 | 7O |
| Q407 | 8O | D408 | 11K |
| Q409 | 9L | D409 | 11K |
| Q410 | 8O | D504 | 9K |
| Q414 | 11L | D705 | 5N |
| Q415 | 11L | D706 | 5N |
| Q416 | 11L | | |



Component side



J79-0344-09



TX-RX UNIT(X57-8240-1X)

