



MOTOROLA

MTP700

Digital Portable Radio

380 - 430 MHz

806 - 870 MHz

Detailed Service Manual

Part Number: 6866534D39-E



November 2006

COPYRIGHT

Computer Software Copyrights

The Motorola products described in this manual may include copyrighted Motorola computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form, the copyrighted computer program. Accordingly, any copyrighted Motorola computer programs contained in the Motorola products described in this manual may not be copied or reproduced in any manner without the express written permission of Motorola. Furthermore, the purchase of Motorola products shall not be deemed to grant, either directly or by implication, estoppel or otherwise, any license under the copyrights, patents or patent applications of Motorola, except for the normal non-exclusive royalty-free license to use that arises by operation of law in the sale of a product.

Trademarks

Motorola is the trademark of Motorola, Inc.

All other copyrights mentioned in this manual are trademarks of their respective companies.

DOCUMENT HISTORY

The following major changes have been implemented in this manual since the previous edition:

| Edition | Description | Date |
|--------------|---|-----------|
| 6866534D39-O | Initial edition | Nov. 2001 |
| 6866534D39-A | Updated Safety Information to latest version. | Aug. 2002 |
| | Chapter 4.1 and 4.2: Updated Theory of Operation, block diagrams and troubleshooting charts. Changed board diagrams, schematics and parts lists for UHF and 800MHz bands. | |
| | Chapter 5. Programming: Updated icons for LCD display and edited LCD Display test. | |
| | Chapter 8. Flex Layout, Schematics & Parts Lists Updated Bottom Flex diagram and parts list. | |
| 6866534D39-B | Document History added. | Apr. 2003 |
| | Safety Information updated to new TETRA Standard. | |
| | Chapter 4.1. Transceiver 400 MHz Updated board diagram to 8466547A08. Changed some part values for UHF Main VCO schematic diagram and changed parts list. | |
| | Chapter 6. Maintenance: Updated mechanical parts list. | |
| 6866534D39-C | Chapter 1: Scope and Warranty Information Updated Asia Pacific Radio Support Centers information with deletion of toll-free and non-toll-free contact nos. | July 2003 |
| | Chapter 2: Model Information & Accessories Updated 400MHz and 800MHz Model Charts. Updated MTP700 Accessories-To-Model Chart table. | |
| | Chapter 4.1 & 4.2: Transceiver 400 MHz and Transceiver 800MHz Added memory components update information to Digital and Audio Section of theory of operation, block diagrams, schematics and parts list. | |
| | Chapter 6: Maintenance Changed Frequency Knob part no. and added Keypad English/Chinese and Keypad English/ Korean part nos. to Exploded View Components List. | |
| | Appendix A: Replacement Parts & Kits Updated table on Service Boards and Front Cover Kits. | |

| Edition | Description | Date |
|----------------|--|-------------|
| 6866534D40-D | Chapter 6: Maintenance Deleted front housing kit assembly and disassembly instructions. Changed exploded view diagram and mechanical parts list. | Oct. 2003 |
| 6866534D40-E | Chapter 2 & Appendix A: Cyrillic tanapa has been added for 380-430MHz | Oct. 2006 |

SAFETY

Product Safety and RF Exposure for Portable Two-Way Radios



Caution

BEFORE USING THIS RADIO, READ THIS BOOKLET WHICH CONTAINS IMPORTANT OPERATING INSTRUCTIONS FOR SAFE USAGE AND RF ENERGY AWARENESS AND CONTROL INFORMATION FOR COMPLIANCE WITH RF ENERGY EXPOSURE LIMITS IN APPLICABLE NATIONAL AND INTERNATIONAL STANDARDS.

The information provided in this document supersedes the general information contained in user guides published prior to February 2002.

For radios that have been approved as intrinsically safe, read the instructions and information on intrinsic safety.

Compliance with RF Energy Exposure Standards

NOTICE: This radio is intended for use in occupational/controlled applications where users have been made aware of the potential for exposure and can exercise control over their exposure. This radio device is **NOT** authorized for general population, consumer or similar use.

Federal Communication Commission (FCC) Regulations

The FCC has established limits for safe exposure to radio frequency (RF) emissions from portable two-way radios. The FCC requires manufacturers to demonstrate compliance with RF exposure limits before portable two-way radios can be marketed in the U.S. When two-way radios are approved for occupational/controlled environment exposure limits, the FCC requires users to be fully aware of, and exercise control over, their exposure. Awareness and control of RF exposure can be accomplished by the use of labels, or by education or training through appropriate means, such as information and instructions in user manuals or safety booklets.

Your Motorola two-way radio has an RF exposure information label in the battery compartment. This user safety booklet includes useful information about RF exposure and helpful instructions on how to control your RF exposure.

Your Motorola two-way radio is designed and tested to comply with a number of national and international standards and guidelines (listed below) regarding human exposure to radio frequency electromagnetic energy. **This radio complies with the IEEE (FCC) and ICNIRP exposure limits for occupational/controlled RF exposure environments at usage factors of up to 50% talk–50% listen.** In terms of measuring RF energy for compliance with FCC exposure guidelines, **your radio radiates measurable RF energy only while it is transmitting (during talking), not when it is receiving (listening) or in standby mode.**


NOTE: The approved batteries, supplied with the portable radio, are rated for a 5-5-90 duty cycle (5% talk–5% listen–90% standby), even though this radio complies with FCC occupational exposure limits at usage factors of up to 50% talk.

Your Motorola two-way radio complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission, Code of Federal Regulations; 47 CFR part 2 sub-part J
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation - Human Exposure) Standard, 2001
- ANATEL, Brasil Regulatory Authority, Resolution 256 (April 11, 2001) "additional requirements for SMR, cellular and PCS product certification."

Compliance and Control Guidelines and Operating Instructions for Portable Two-Way Radios

To control your exposure and ensure compliance with the occupational/ controlled environment exposure limits, always adhere to the following procedures:

- Transmit no more than 50% of the time. To transmit (talk), push the Push-To-Talk (PTT) button. To receive calls, release the PTT button. Transmitting 50% of the time or less is important since the radio generates measurable RF energy exposure only when transmitting (in terms of measuring standards compliance).
- **Hold the radio in a vertical position in front of the face with the microphone (and other parts of the radio including the antenna) at least one to two inches (2.5 to 5 centimeters) away from the lips. Keeping the radio at a proper distance is important since RF exposures decrease with distance from the antenna.** 
- For body-worn operation, always place the radio in a Motorola-approved clip, holder, holster, case, or body harness for this product. Using non-Motorola-approved accessories may result in exposure levels which exceed the FCC's occupational/controlled environment RF exposure limits.
- If you are not using a body-worn accessory and are not using the radio in the intended use position in front of the face, ensure the antenna and the radio are kept one inch (2.5 centimeters) from the body when transmitting. Keeping the radio at a proper distance is important since RF exposures decrease with distance from the antenna.
- **Use only Motorola-approved supplied or replacement antennas, batteries, and accessories.** Use of non-Motorola-approved antennas, batteries and accessories may exceed FCC RF exposure guidelines. **For a list of Motorola-approved antennas, batteries, and other accessories, visit the following web site which lists approved accessories:**
<http://ap.cgiss.motorola.com/AAD/index.html>

For additional information on exposure requirements or other training information, visit <http://www.motorola.com/rfhealth>.

Electromagnetic Interference/Compatibility

NOTE:Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

Facilities

To avoid electromagnetic interference and/or compatibility conflicts, turn off your radio in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your radio when on board an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Pacemakers

The Advanced Medical Technology Association (AdvaMed) recommends that a minimum separation of 6 inches (15 centimeters) be maintained between a handheld wireless radio and a pacemaker. These recommendations are consistent with those of the U.S. Food and Drug Administration.

Persons with pacemakers should:

- ALWAYS keep the radio more than 6 inches (15 centimeters) from their pacemaker when the radio is turned ON.
- not carry the radio in the breast pocket.
- use the ear opposite the pacemaker to minimize the potential for interference.
- turn the radio OFF immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless radios may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Driver Safety

Check the laws and regulations on the use of radios in the area where you drive. Always obey them.

When using your radio while driving, please:

- Give full attention to driving and to the road.
- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Operational Warnings



WARNING

For Vehicles With An Air Bag

Do not place a portable radio in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable radio is placed in the air bag deployment area and the air bag inflates, the radio may be propelled with great force and cause serious injury to occupants of the vehicle.

Potentially Explosive Atmospheres

Turn off your radio prior to entering any area with a potentially explosive atmosphere, unless it is a portable radio type especially qualified for use in such areas as “Intrinsically Safe” (for example, Factory Mutual, CSA, UL, or CENELEC). Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles such as grain, dust or metal powders. Areas with potentially explosive atmospheres are often but not always, posted.

Blasting Caps And Blasting Areas

To avoid possible interference with blasting operations, turn off your radio when you are near electrical blasting caps, in a blasting area, or in areas posted: “Turn off two-way radio.” Obey all signs and instructions.

Operational Cautions



Caution

Antennas

Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.

Batteries

All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.

Intrinsically Safe Radio Information

FMRC Approved Equipment

Anyone intending to use a radio in a location where hazardous concentrations of flammable materials exist (hazardous atmosphere) is advised to become familiar with the subject of intrinsic safety and with the National Electric Code NFPA 70 (National Fire Protection Association) Article 500 (hazardous [classified] locations).

An Approval Guide, issued by Factory Mutual Research Corporation (FMRC), lists manufacturers and the products approved by FMRC for use in such locations. FMRC has also issued a voluntary approval standard for repair service (“Class Number 3605”).

FMRC Approval labels are attached to the radio to identify the unit as being FMRC Approved for specified hazardous atmospheres. This label specifies the hazardous Class/Division/Group along with the part number of the battery that must be used. Depending on the design of the portable unit, this FM label can be found on the back or the bottom of the radio housing. The FM Approval Mark is shown here.





- Do not operate radio communications equipment in hazardous atmospheres unless it is a type specifically qualified (e.g., FM Approved) for such use. An explosion or fire may result.
- Do not operate the FMRC Approved Product in a hazardous atmosphere if it has been physically damaged (e.g., cracked housing). An explosion or fire may result.
- Do not replace or charge batteries in a hazardous atmosphere. Contact sparking may occur while installing or removing batteries, and cause an explosion or fire.
- Do not replace or change accessories in a hazardous atmosphere. Contact sparking may occur while installing or removing accessories, and cause an explosion or fire.
- Turn the radio off before removing or installing a battery or accessory.
- Do not disassemble an FMRC Approved Product in any way that exposes the internal circuits of the unit.

Radios must ship from the Motorola manufacturing facility with the hazardous atmosphere capability and FM Approval labeling. Radios will not be “upgraded” to this capability and labeled in the field. A modification changes the unit’s hardware from its original design configuration. Modifications can only be made by the original product manufacturer at one of its FMRC-audited manufacturing facilities.



- Failure to use an FMRC Approved Product with an FMRC Approved battery or FMRC Approved accessories specifically approved for that product may result in the dangerously unsafe condition of an unapproved radio combination being used in a hazardous location.
- Unauthorized or incorrect modification of an FMRC Approved Product will negate the Approval rating of the product

Repair of FMRC Approved Products

REPAIRS FOR MOTOROLA PRODUCTS WITH FMRC APPROVAL ARE THE RESPONSIBILITY OF THE USER.

You should not repair or relabel any Motorola-manufactured communication equipment bearing the FMRC Approval label (“FMRC Approved Product”) unless you are familiar with the current FMRC Approval standard for repairs and service (“Class Number 3605”).

You may want to consider using a repair facility that operates under 3605 repair service approval.



- Incorrect repair or relabeling of any FMRC Approved Product could adversely affect the Approval rating of the unit.
- Use of a radio that is not intrinsically safe in a hazardous atmosphere could result in serious injury or death.

The FMRC’s Approval Standard Class Number 3605 is subject to change at any time without notice to you. You may want to obtain a current copy of 3605 from the FMRC. Per the December 1994 publication of 3605, some key definitions and service requirements are as follows:

Repair

A repair constitutes something done internally to the unit that would bring it back to its original condition—Approved by FMRC. A repair should be done in an FMRC Approved repair facility.

Items not considered as repairs are those in which an action is performed on a unit which does not require the outer casing of the unit to be opened in a manner which exposes the internal electrical circuits of the unit. You do not have to be an FMRC Approved repair facility to perform these actions.

Relabeling

The repair facility shall have a method by which the replacement of FMRC Approval labels are controlled to ensure that any relabeling is limited to units that were originally shipped from the manufacturer with an FM Approval label in place. FMRC Approval labels shall not be stocked by the repair facility. An FMRC Approval label shall be ordered from the original manufacturer, as needed, to repair a specific unit. Replacement labels may be obtained and applied by the repair facility, provided there is satisfactory evidence that the unit being relabeled was originally an FMRC Approved unit. Verification may include, but is not limited to a unit with a damaged Approval label, a unit with a defective housing displaying an Approval label, or a customer invoice indicating the serial number of the unit and purchase of an FMRC Approved model.

Do Not Substitute Options or Accessories

The Motorola communications equipment certified by Factory Mutual is tested as a system and consists of the FM Approved portable, FM Approved battery, and FM Approved accessories or options, or both. This FM Approved portable and battery combination must be strictly observed. There must be no substitution of items, even if the substitute has been previously Approved with a different Motorola communications equipment unit. Approved configurations are listed in the FM Product Listing Manual that was included with your radio.

European Union Directives Conformance Statement

This product is in conformance with the TETRA (TErrestrial Trunked RAdio) standard.
This product is in conformance with the requirements of the applicable EU Council Directives.
Declarations of Conformance with the requirements are located at:

Motorola a/s
Sydvestvej 15
DK-2600 Glostrup

Denmark

CONTENTS

| | |
|--------------------|--|
| COPYRIGHT | Computer Software Copyrights ii |
| | Trademarks ii |
| HISTORY | DOCUMENT HISTORY iii |
| SAFETY | Product Safety and RF Exposure for Portable Two-Way Radios v |
| CHAPTER 1 | SCOPE & WARRANTY INFORMATION 1-1 |
| | Scope Of This Manual 1-1 |
| | Manual Revisions 1-1 |
| | Related Publications 1-2 |
| | Warranty and Service Support 1-3 |
| | European Radio Support Centers (ERSC) 1-4 |
| | Asia Pacific Radio Support Centers 1-5 |
| | Latin America Radio Support Centers 1-6 |
| CHAPTER 2 | MODEL INFORMATION & ACCESSORIES 2-1 |
| | MTP700 Portable Radio Model Charts 2-1 |
| | MTP700 Portable Radio Model Information 2-5 |
| | MTP700 Portable Radio Model Specification 2-6 |
| | MTP700 Accessories-To-Model Chart 2-7 |
| CHAPTER 3 | OVERVIEW 3-1 |
| | General 3-1 |
| | Digital Modulation Technology 3-1 |
| CHAPTER 4 | RADIO INFORMATION 4-1 |
| | Section Introduction 4-1 |
| CHAPTER 4.1 | TRANSCEIVER 400 MHz 4.1-1 |
| | General 4.1-1 |
| | Block Diagram Overview 4.1-1 |
| | Receiver Section 4.1-3 |
| | Transmitter Section 4.1-3 |
| | Frequency Generating Section (Synthesizer) 4.1-4 |
| | Digital & Audio Section 4.1-4 |
| | Block Diagrams Descriptions 4.1-5 |
| | Receiver Path 4.1-5 |
| | Transmitter Path 4.1-6 |
| | Frequency Generating Section 4.1-7 |
| | Digital & Audio Section 4.1-9 |
| | Detailed Circuit Description 4.1-10 |

| | |
|--|--------|
| Receiver Path, Detailed Circuit Description | 4.1-10 |
| Transmitter Path, Detailed Circuit Description | 4.1-13 |
| Frequency Generating Section, Detailed Circuit Description | 4.1-16 |
| Digital & Audio Section, Detailed Circuit Description | 4.1-18 |
| Display and Keypad, Detailed Description | 4.1-26 |
| 380-430 MHz Board Layout, Schematics & Parts Lists | 4.1-31 |
| 380-430 MHz Main Board Top Side PCB No. 8466547A08 | 4.1-31 |
| 380-430 MHz Main Board Bottom Side PCB No. 8466547A08 | 4.1-32 |
| Digital and RF Block Diagram | 4.1-33 |
| DSP, Controller & Memory Schematic Diagram (RedCap2) | 4.1-34 |
| DSP, Controller & Memory Schematic Diagram (Memory) | 4.1-35 |
| GCAP (Audio & DC) Schematic Diagram - GCAP3 | 4.1-36 |
| GCAP (Audio & DC) Schematic Diagram - Periphery | 4.1-37 |
| IO Interface & Connectors | |
| Schematic Diagram - 40 Pin Connector | 4.1-38 |
| IO Interface & Connectors | |
| Schematic Diagram - 16 Pin Connector | 4.1-39 |
| Switches & Associated Components | |
| Schematic Diagram - Switch | 4.1-40 |
| Switches & Associated Components | |
| Schematic Diagram - 24 Pin Connector | 4.1-41 |
| RF Section Block Diagram | 4.1-42 |
| RXU Schematic Diagram | 4.1-43 |
| RF Core Unit Schematic Diagram - WPIC | 4.1-44 |
| RF Core Unit Schematic Diagram - 2nd LO | 4.1-45 |
| Main VCO Schematic Diagram | 4.1-46 |
| TXU Block Diagram | 4.1-47 |
| TXU-LNODCT Schematic Diagram | 4.1-48 |
| TXU-TX Power Amplifier Schematic Diagram | 4.1-49 |
| TXU-TX Front End Schematic Diagram | 4.1-50 |
| TXU-ESCORT/TX VCO Schematic Diagram | 4.1-51 |
| 380-430 MHz Radio Parts List | 4.1-52 |
| Troubleshooting (400 MHz) | 4.1-59 |
| General | 4.1-59 |
| Test Procedures | 4.1-59 |
| Troubleshooting Flowcharts | 4.1-59 |

| | | |
|---|----------------------------|--------------|
| CHAPTER 4.2 | TRANSCEIVER 800 MHz | 4.2-1 |
| General | | 4.2-1 |
| Block Diagram Overview | | 4.2-1 |
| Receiver Section | | 4.2-3 |
| Transmitter Section | | 4.2-3 |
| Frequency Generating Section | | 4.2-4 |
| Digital & Audio Section | | 4.2-5 |
| Block Diagrams Description | | 4.2-6 |
| Receiver Path | | 4.2-6 |
| Transmitter Path | | 4.2-7 |
| Frequency Generating Section | | 4.2-8 |
| Digital & Audio Section | | 4.2-10 |
| Detailed Circuit Description | | 4.2-11 |
| Receiver Path, Detailed Circuit Description | | 4.2-11 |
| Transmitter Path, Detailed Circuit Description | | 4.2-14 |
| Frequency Generating Section, Detailed Circuit Description | | 4.2-17 |
| Digital & Audio Section, Detailed Circuit Description | | 4.2-19 |
| Display and Keypad, Detailed Description | | 4.2-27 |
| 806-870 MHz Board Layout, Schematics & Parts Lists | | 4.2-33 |
| 806-870 MHz Main Board Top Side PCB No. 8485951Z04 | | 4.2-33 |
| 806-870 MHz Main Board Bottom Side PCB No. 8485951Z04 | | 4.2-34 |
| Controller Memory Schematic Diagram (Redcap 2) sheet 1 of 2 | | 4.2-35 |
| Controller Memory Schematic Diagram (Redcap 2) sheet 2 of 2 | | 4.2-36 |
| DC Supply & Audio Schematic Diagram (GCAP 3) sheet 1 of 2 | | 4.2-37 |
| DC Supply & Audio Schematic Diagram (GCAP 3) sheet 2 of 2 | | 4.2-38 |
| I/O Interface Schematic Diagram sheet 1 of 2 | | 4.2-39 |
| I/O Interface Schematic Diagram (sheet 2 of 2) | | 4.2-40 |
| Switches And Associated Components | | |
| Schematic Diagram (sheet 1 of 2) | | 4.2-41 |
| Switches And Associated Components | | |
| Schematic Diagram (sheet 2 of 2) | | 4.2-42 |
| Receiver Front End Schematic Diagram | | 4.2-43 |
| Receiver Back End Schematic Diagram | | 4.2-44 |
| Transmitter Schematic Diagram (sheet 1 of 2) | | 4.2-45 |
| Transmitter Schematic Diagram (sheet 2 of 2) | | 4.2-46 |
| Frequency Generation Unit Schematic Diagram | | 4.2-47 |
| ESCORT Schematic Diagram | | 4.2-48 |
| 806-870 MHz Radio Parts List | | 4.2-49 |
| Troubleshooting (800 MHz) | | 4.2-55 |
| General | | 4.2-55 |
| Test Procedures | | 4.2-55 |
| Troubleshooting Flowcharts | | 4.2-55 |

| | | |
|------------------|---|------------|
| CHAPTER 5 | PROGRAMMING THE RADIO | 5-1 |
| | Before Using the Customer Programming Software (CPS) | 5-1 |
| | Reading Codeplug | 5-2 |
| | Programming Codeplug | 5-2 |
| | Programming Frequency | 5-3 |
| | Restoring Factory Frequencies of the Radio | 5-4 |
| | Programming Firmware | 5-4 |
| | Manual Mode Testing | 5-5 |
| | Preparation for Testing | 5-5 |
| | Tests | 5-5 |
| | LCD Display Test | 5-5 |
| | | |
| CHAPTER 6 | MAINTENANCE | 6-1 |
| | Introduction | 6-1 |
| | Preventive Maintenance | 6-1 |
| | Safe Handling of CMOS and LDMOS Devices | 6-3 |
| | Repair Procedures and Techniques — General | 6-4 |
| | Parts Replacement and Substitution | 6-4 |
| | Disassembling and Reassembling the Radio - General | 6-4 |
| | Radio Disassembly - Detailed | 6-5 |
| | Front Cover from Chassis Disassembly | 6-5 |
| | Chassis Assembly Disassembly | 6-8 |
| | Radio Reassembly - Detailed | 6-9 |
| | Chassis Assembly Reassembly | 6-9 |
| | Chassis and Front Cover Reassembly | 6-9 |
| | Service Aids | 6-11 |
| | MTP700 Unit - Exploded View | 6-12 |
| | | |
| CHAPTER 7 | KEYPAD BOARD LAYOUT, SCHEMATICS & PARTS LIST | 7-1 |
| | Keypad Board Top Side PCB No. 8466556A01 | 7-1 |
| | Keypad Board Bottom Side PCB No. 8466556A01 | 7-2 |
| | Keypad Board Schematic Diagram | 7-3 |
| | Keypad Board Parts List | 7-4 |

| | | |
|-------------------|---|------------|
| CHAPTER 8 | FLEX LAYOUT, SCHEMATICS & PARTS LISTS. | 8-1 |
| | Interconnect Flex | 8-1 |
| | Schematic for Interconnect Flex | 8-2 |
| | Parts List for Interconnect Flex | 8-2 |
| | Universal Connector Flex | 8-3 |
| | Schematic for Universal Connector Flex | 8-4 |
| | Parts List for Universal Connector Flex | 8-4 |
| | Display Flex | 8-5 |
| | Schematic for Display Flex | 8-6 |
| | Parts List for Display Flex | 8-6 |
| | Bottom Flex | 8-7 |
| | Schematic for Bottom Flex | 8-8 |
| | Parts List for Bottom Flex | 8-8 |
| | | |
| APPENDIX A | REPLACEMENT PARTS AND KITS | A-1 |
| | Servicing MTP700 Portable Units | A-1 |
| | Replacement Parts | A-1 |
| | Service Kits | A-2 |
| | | |
| APPENDIX B | CONNECTOR PIN FUNCTIONS | B-1 |
| | General | B-1 |
| | Side Accessory Connector Pin Assignment | B-1 |
| | Bottom Accessory Connector Pin Assignment | B-3 |
| | | |
| APPENDIX C | TEST EQUIPMENT. | C-1 |
| | Test Equipment | C-1 |
| | | |
| APPENDIX D | SELF CHECK (ERROR & FAIL CODES). | D-1 |
| | General | D-1 |
| | Self Check Error Codes. | D-1 |

THIS PAGE INTENTIONALLY LEFT BLANK

CHAPTER 1

SCOPE & WARRANTY INFORMATION

Scope Of This Manual

This manual contains information necessary to identify and troubleshoot the MTP700 Dimetra Portable Radio at the component level. It also contains information on radio assembling, disassembling, and maintenance. Depending on the radio application, these radios are designed to work with Motorola's Dimetra system or other TETRA compliant systems.

Accordingly, information in this manual is divided into the following chapters and appendixes:

- SAFETY Product Safety and RF Exposure for Portable Two-Way Radios
- CHAPTER 1 Scope & Warranty Information
- CHAPTER 2 Model Information & Accessories
- CHAPTER 3 Overview
- CHAPTER 4 Radio Information
- CHAPTER 4.1 Transceiver 400 MHz
- CHAPTER 4.2 Transceiver 800 MHz
- CHAPTER 5 Programming the Radio
- CHAPTER 6 Maintenance
- CHAPTER 7 Keypad Board Layout, Schematics and Parts List
- CHAPTER 8 Flex Layout, Schematics and Parts Lists
- APPENDIX A Replacement Parts and Kits
- APPENDIX B Connector Pin Functions
- APPENDIX C Test Equipment
- APPENDIX D Self Check (Error/Fail Codes)

Manual Revisions

Changes which occur after this manual is printed are described in Manual Revisions. These Manual Revisions provide complete information on changes including pertinent parts listing data.

Related Publications

| | |
|------------|---|
| 6866534D27 | MTP700 User's Guide incl. Quick Reference Card (English) |
| 6866534D28 | MTP700 User's Guide incl. Quick Reference Card (German) |
| 6866534D29 | MTP700 User's Guide incl. Quick Reference Card (French) |
| 6866534D30 | MTP700 User's Guide incl. Quick Reference Card (Dutch) |
| 6866534D31 | MTP700 User's Guide incl. Quick Reference Card (Spanish) |
| 6866534D32 | MTP700 User's Guide incl. Quick Reference Card (Portuguese) |
| 6804112J75 | MTP700 User's Guide incl. Quick Reference Card (Mandarin) |
| 6866534D40 | MTP700 Basic Service Manual (English) |
| 6802956C20 | MTP700 Customer Programming Software (CPS) Start-up manual |
| 6864117B25 | Safety Leaflet (European Languages) |
| 6804110J47 | Safety Leaflet (English/Mandarin) |
| 6802300U57 | EME Warnings, Pocket Size |
| 6866534D69 | R&TTE Leaflet (for EMEA region only) |
| 6866534D94 | Factory Mutual Supplement |

Warranty and Service Support

Motorola offers long term support for its products. This support includes full exchange and/or repair of the product during the warranty period, and service/repair or spare parts support out of warranty. Any "return for exchange" or "return for repair" by an authorised Motorola Dealer must be accompanied by a Warranty Claim Form. Warranty Claim Forms are obtained by contacting an Authorised Motorola Dealer.

Warranty Period and Return Instructions

The terms and conditions of warranty are defined fully in the Motorola Dealer or Distributor or Reseller contract. These conditions may change from time to time and the following notes are for guidance purposes only.

In instances where the product is covered under a "return for replacement" or "return for repair" warranty, a check of the product should be performed prior to shipping the unit back to Motorola. This is to ensure that the product has been correctly programmed or has not been subjected to damage outside the terms of the warranty.

Prior to shipping any radio back to the appropriate Motorola warranty depot, please contact Customer Resources. All returns must be accompanied by a Warranty Claim Form, available from your Customer Services representative. Products should be shipped back in the original packaging, or correctly packaged to ensure no damage occurs in transit.

After Warranty Period

After the Warranty period, Motorola continues to support its products in two ways.

1. Motorola's Regional Radio Support Centers offer repair services to both end users and dealers at competitive prices.
2. AAD supplies individual parts and modules that can be purchased by dealers who are technically capable of performing fault analysis and repair.

European Radio Support Centers (ERSC)

The ERSC Customer Information Desk is available through the following service numbers:

| | | | |
|----------|--------------------|--------------|----------------|
| Austria: | 06 60 75 41 | Italy: | 16 78 77 387 |
| Belgium: | 08 00 72 471 | Luxemburg: | 08 00 23 27 |
| Denmark: | 80 01 55 72 | Netherlands: | 60 22 45 13 |
| Finland: | 08 00 11 49 10 | Norway: | 80 01 11 15 |
| France: | 05 90 30 90 | Portugal: | 05 05 49 35 70 |
| Germany: | 08 00 18 75 240 | Spain: | 90 09 84 902 |
| Greece: | 00 80 04 91 29 020 | Sweden: | 02 07 94 307 |
| UK : | 08 00 96 90 95 | Switzerland: | 1 55 30 82 |
| Ireland: | 18 00 55 50 21 | Iceland: | 80 08 147 |

Or dial Customer Care Center:

Tel: +49 6128 70 2164

Please use these numbers for repair enquiries only.

Piece Parts

Some replacement parts, spare parts, and/or product information can be ordered directly. If a complete Motorola part number is assigned to the part, it is available from Motorola Radio Aftermarket and Accessory Division (AAD). If no part number is assigned, the part is not normally available from Motorola. If a parts list is not included, this generally means that no user-serviceable parts are available for that kit or assembly.

Note on this digital TETRA Radio: **The CPS has no capability to tune the radio. Tuning the radio can only be performed at the factory or at the appropriate Motorola Repair Center. Component replacement can affect the radio tuning and must only be performed by the appropriate Motorola Repair Center.**

Parts Identification and Ordering

Request for help in identification of non-referenced spare parts should be directed to the Customer Care Organisation of Motorola's local area representation. Orders for replacement parts, kits and assemblies should be placed directly on Motorola's local distribution organisation or via Motorola Online (Extranet).

EMEA Test Equipment Support

Information related to support and service of Motorola Test Equipment is available via Motorola Online (Extranet), through the Customer Care Organisation of Motorola's local area representation or by calling the Motorola switchboard in Germany using phone number +49 6128 700.

Asia Pacific Radio Support Centers

Piece Parts

Some replacement parts, spare parts, and/or product information can be ordered directly. If a complete Motorola part number is assigned to the part, it is available from Motorola Radio Aftermarket and Accessory Division (AAD). If no part number is assigned, the part is not normally available from Motorola. If a parts list is not included, this generally means that no user-serviceable parts are available for that kit or assembly.

Note on this digital TETRA Radio: **The CPS has no capability to tune the radio. Tuning the radio can only be performed at the factory or at the appropriate Motorola Repair Center. Component replacement can affect the radio tuning and must only be performed by the appropriate Motorola Repair Center.**

All orders for parts/information should include the complete Motorola identification number. All part orders should be directed to your local AAD office. Please refer to your latest price pages.

Technical Support

Technical support is available to assist the dealer/distributor in resolving any malfunction which may be encountered. Initial contact should be by telephone wherever possible. When contacting Motorola Technical Support, be prepared to provide the product **model number** and the unit's **serial number**.

Further Assistance From Motorola

You can also call the CGISS Indirect Business Customer Help Desk number, (604)-6302525 or send an email to customer care.asia@motorola.com.

Latin America Radio Support Centers

The Customer Support is available through the following service numbers:

Warranty and Repairs:

Motorola De Colombia Service Center
Diagonal 127A no. 17-64
Santa Fe de Bogotá
Colombia
(571) 520-0510 or (571) 657-5759

Motorola De Mexico Service Center

Bosques de Alisos #125
Col. Bosques de las Lomas
CP 05120 Mexico DF
5252576700

Piece Parts:

To order parts in Latin America and the Carribean:
7:00 A.M. to 7:00 P.M. (Central Standard Time)
Monday through Friday (Chicago, USA)
1-847-538-8023

Technical Support:

lataech1@email.mot.com <mailto:lataech1@email.mot.com>

Motorola Parts (Accessories and Aftermarket Division AAD):

Attention: Order Processing
1313 E. Algonquin Road
Schaumburg. IL. 60196

Parts Identification:

1-847-538-0021 (Voice)
1-847-538-8194 (Fax)

Piece Parts

Some replacement parts, spare parts, and/or product information can be ordered directly. If a complete Motorola Part number is assigned to the part, it is available from Motorola Radio Aftermarket and Accessory Division (AAD). If no part number is assigned, the part is not normally available from Motorola. If a parts list is not included, this generally means that no user-serviceable parts are available for that kit or assembly.

Note on this digital TETRA Radio: **The CPS has no capability to tune the radio. Tuning the radio can only be performed at the factory or at the appropriate Motorola Repair Center. Component replacement can affect the radio tuning and must only be performed by the appropriate Motorola Repair Center.**

CHAPTER 2

MODEL INFORMATION & ACCESSORIES

MTP700 Portable Radio Model Charts

| MTP700, 380-430 MHz | | | | | |
|----------------------------|---------------|---|--------------------|--|--|
| Model | | | Description | | |
| | H47QCM6TZ6AN | | | MTP700 380-430 MHz 1W 25K CR PT911E | |
| | *H47QCM6TZ6AB | | | MTP700 380-430 MHz 1W 25K CR PT911E | |
| | H47QCM6TZ5AN | | | MTP700 380-430 MHz 1W 25K ES PT911E | |
| | *H47QCM6TZ5AB | | | MTP700 380-430 MHz 1W 25K ES PT911E | |
| | | | Item | Description | |
| x | | | **PMUE1852_ | ***MTP700 Super Tanapa 380-430 MHz 1W 25K CR-TEA1 | |
| | | x | **PMUE1853_ | ***MTP700 Super Tanapa 380-430 MHz 1W 25K ES-TEA1 | |
| x | | | **PMUE1856_ | ***MTP700 Super Tanapa 380-430 MHz 1W 25K CR-TEA2 | |
| | | x | **PMUE1857_ | ***MTP700 Super Tanapa 380-430 MHz 1W 25K ES-TEA2 | |
| x | x | | **PMUE1825_ | ***MTP700 Super Tanapa 380-430 MHz 1W 25K CR | |
| | | x | x | **PMUE1826_ | ***MTP700 Super Tanapa 380-430 MHz 1W 25K ES |
| x | | | **PMUE2052_ | MTP700 Super Tanapa 380-430 MHz 1W 25K CR (Chinese) | |
| | | x | **PMUE2053_ | MTP700 Super Tanapa 380-430 MHz 1W 25K ES (Chinese) | |
| x | | | **PMUE2054_ | MTP700 Super Tanapa 380-430 MHz 1W 25K CR (Korean) | |
| | | x | **PMUE2055_ | MTP700 Super Tanapa 380-430 MHz 1W 25K ES (Korean) | |
| x | | | **PMUE2056_ | MTP700 Super Tanapa 380-430 MHz 1W 25K CR-TEA1 (Chinese) | |
| | | x | **PMUE2057_ | MTP700 Super Tanapa 380-430 MHz 1W 25K ES-TEA1 (Chinese) | |
| x | | | **PMUE2058_ | MTP700 Super Tanapa 380-430 MHz 1W 25K CR-TEA1 (Korean) | |
| | | x | **PMUE2059_ | MTP700 Super Tanapa 380-430 MHz 1W 25K ES-TEA1 (Korean) | |
| x | x | | **PMUE1865_ | ***MTP700 Tanapa 380-430 MHz 1W 25K CR | |
| | | x | x | **PMUE1827_ | ***MTP700 Tanapa 380-430 MHz 1W 25K ES |
| x | x | | **PMUE2877_ | ***MTP700 Tanapa 380-430 MHz 1W 25K CR (Cyrillic) | |
| | | x | **PMUE2086_ | MTP700 Tanapa 380-430 MHz 1W 25K ES (Chinese) | |
| x | | | **PMUE2087_ | MTP700 Tanapa 380-430 MHz 1W 25K CR (Chinese) | |
| | | x | **PMUE2088_ | MTP700 Tanapa 380-430 MHz 1W 25K ES (Korean) | |
| x | | | **PMUE2089_ | MTP700 Tanapa 380-430 MHz 1W 25K CR (Korean) | |
| | | x | PMHE4012_ | Back Chassis Kit 380-430 MHz 1W 25K ES | |
| x | | | PMHE4013_ | Back Chassis Kit 380-430 MHz 1W 25K CR | |
| x | | | PMHN4048_ | MTP700 Front Housing Kit CR (English/Chinese) | |
| x | | | PMHN4049_ | MTP700 Front Housing Kit CR (English/Korean) | |
| x | x | | PMHN4038_ | MTP700 Front Housing Kit CR | |
| | | x | x | PMHN4039_ | MTP700 Front Housing Kit ES |

| MTP700, 380-430 MHz (Continued) | | | | | |
|--|---|---|-----------|---|---------------------------------|
| Model | | | | Description | |
| H47QCM6TZ6AN | | | | MTP700 380-430 MHz 1W 25K CR PT911E | |
| *H47QCM6TZ6AB | | | | MTP700 380-430 MHz 1W 25K CR PT911E | |
| H47QCM6TZ5AN | | | | MTP700 380-430 MHz 1W 25K ES PT911E | |
| *H47QCM6TZ5AB | | | | MTP700 380-430 MHz 1W 25K ES PT911E | |
| Item | | | | Description | |
| | x | x | PMHN4039_ | MTP700 Front Housing Kit ES | |
| | x | | PMHN4050_ | MTP700 Front Housing Kit ES (English/Chinese) | |
| | x | | PMHN4051_ | MTP700 Front Housing Kit ES (English/Korean) | |
| x | x | x | x | FAE6000_ | Narrow Band Antenna 380-400 MHz |
| x | x | x | x | FAE6001_ | Narrow Band Antenna 410-430 MHz |
| x | x | x | x | FAE5520_ | Whip Antenna 380-400 MHz |
| x | x | x | x | FAE6002_ | Whip Antenna 410-430 MHz |
| x | x | x | x | 6866534D27 | MTP700 User Guide (English) |
| x | x | x | x | 6866534D28 | MTP700 User Guide (German) |
| x | x | x | x | 6866534D29 | MTP700 User Guide (French) |
| x | x | x | x | 6866534D30 | MTP700 User Guide (Dutch) |
| x | x | x | x | 6866534D31 | MTP700 User Guide (Spanish) |
| x | x | x | x | 6866534D32 | MTP700 User Guide (Portuguese) |
| x | x | x | x | 6804112J75 | MTP700 User Guide (Mandarin) |

Note:

- x Indicates one of each is required.
- * For Asia, please use H415EK Option for Bulk Package.
- ** For replacement kits, see Appendix A Replacement Parts and Kits.
- *** Not Field Replaceable for Latin America

| MTP700, 806-870 MHz | | | | | |
|----------------------------|---|---|---|---|--|
| Model | | | | Description | |
| H47XCM6TZ5AK | | | | MTP700 806-870 MHz 1W 25K ES PT711E (Korea) | |
| H47XCM6TZ6AN | | | | MTP700 806-870 MHz 1W 25K CR PT711E | |
| *H47XCM6TZ6AB | | | | MTP700 806-870 MHz 1W 25K CR PT711E | |
| H47XCM6TZ5AN | | | | MTP700 806-870 MHz 1W 25K ES PT711E | |
| *H47XCM6TZ5AB | | | | MTP700 806-870 MHz 1W 25K ES PT711E | |
| Item | | | | Description | |
| x | | | | **PMUF1092_ | ***MTP700 Super Tanapa 806-870 MHz 1W 25K CR-TEA1 |
| | | x | | **PMUF1093_ | ***MTP700 Super Tanapa 806-870 MHz 1W 25K ES-TEA1 |
| x | | | | **PMUF1096_ | ***MTP700 Super Tanapa 806-870 MHz 1W 25K CR-TEA2 |
| | | x | | **PMUF1097_ | ***MTP700 Super Tanapa 806-870 MHz 1W 25K ES-TEA2 |
| x | x | | | **PMUF1077_ | ***MTP700 Super Tanapa 806-870 MHz 1W 25K CR |
| | | x | x | **PMUF1078_ | ***MTP700 Super Tanapa 806-870 MHz 1W 25K ES |
| x | | | | **PMUF1115_ | MTP700 Super Tanapa 806-870 MHz 1W 25K ES |
| x | | | | **PMUF1157_ | MTP700 Super Tanapa 806-870 MHz 1W 25K CR (Chinese) |
| | | x | | **PMUF1158_ | MTP700 Super Tanapa 806-870 MHz 1W 25K ES (Chinese) |
| x | | | | **PMUF1159_ | MTP700 Super Tanapa 806-870 MHz 1W 25K CR (Korean) |
| | | x | | **PMUF1160_ | MTP700 Super Tanapa 806-870 MHz 1W 25K ES (Korean) |
| x | | | | **PMUF1161_ | MTP700 Super Tanapa 806-870 MHz 1W 25K CR-TEA1 (Chinese) |
| | | x | | **PMUF1162_ | MTP700 Super Tanapa 806-870 MHz 1W 25K ES-TEA1 (Chinese) |
| x | | | | **PMUF1163_ | MTP700 Super Tanapa 806-870 MHz 1W 25K CR-TEA1 (Korean) |
| | | x | | **PMUF1164_ | MTP700 Super Tanapa 806-870 MHz 1W 25K ES-TEA1 (Korean) |
| x | x | | | **PMUF1102_ | ***MTP700 Tanapa 806-870 MHz 1W 25K CR |
| | | x | x | **PMUF1079_ | ***MTP700 Tanapa 806-870 MHz 1W 25K ES |
| x | | | | **PMUF1116_ | MTP700 Tanapa 806-870 MHz 1W 25K ES |
| | | x | | **PMUF1165_ | MTP700 Tanapa 806-870 MHz 1W 25K ES (Chinese) |
| x | | | | **PMUF1166_ | MTP700 Tanapa 806-870 MHz 1W 25K CR (Chinese) |
| | | x | | **PMUF1167_ | MTP700 Tanapa 806-870 MHz 1W 25K ES (Korean) |
| x | | | | **PMUF1168_ | MTP700 Tanapa 806-870 MHz 1W 25K CR (Korean) |
| | | x | | PMHF4000_ | Back Chassis Kit 806-870 Mhz 1W 25W ES |
| x | | | | PMHF4001_ | Back Chassis Kit 806-870 Mhz 1W 25W CR |
| x | | | | PMHN4048_ | MTP700 Front Housing Kit CR (English/Chinese) |
| x | | | | PMHN4049_ | MTP700 Front Housing Kit CR (English/Korean) |
| x | x | | | PMHN4038_ | MTP700 Front Housing Kit CR |
| | | x | x | PMHN4039_ | MTP700 Front Housing Kit ES |
| x | | | | PMHN4040_ | MTP700 Front Housing Kit ES |

| MTP700, 806-870 MHz (Continued) | | | | | |
|--|---|---|---|------------|---|
| Model | | | | | Description |
| H47XCM6TZ5AK | | | | | MTP700 806-870 MHz 1W 25K ES PT711E (Korea) |
| H47XCM6TZ6AN | | | | | MTP700 806-870 MHz 1W 25K CR PT711E |
| *H47XCM6TZ6AB | | | | | MTP700 806-870 MHz 1W 25K CR PT711E |
| H47XCM6TZ5AN | | | | | MTP700 806-870 MHz 1W 25K ES PT711E |
| *H47XCM6TZ5AB | | | | | MTP700 806-870 MHz 1W 25K ES PT711E |
| Item | | | | | Description |
| | | | x | PMHN4050_ | MTP700 Front Housing Kit ES (English/Chinese) |
| | | | x | PMHN4051_ | MTP700 Front Housing Kit ES (English/Korean) |
| | x | x | x | NAF5037_ | 1/2 Wave Whip Antenna 806-870 MHz |
| x | x | x | x | NAF5042_R | 1/4 Wave Stubby Antenna 806-870 MHz |
| x | x | x | x | 6866534D27 | MTP700 User Guide (English) |
| | x | x | x | 6866534D28 | MTP700 User Guide (German) |
| | x | x | x | 6866534D29 | MTP700 User Guide (French) |
| | x | x | x | 6866534D30 | MTP700 User Guide (Dutch) |
| | x | x | x | 6866534D31 | MTP700 User Guide (Spanish) |
| | x | x | x | 6866534D32 | MTP700 User Guide (Portuguese) |
| | x | x | x | 6804112J75 | MTP700 User Guide (Mandarin) |

Note:

x Indicates one of each is required.

* For Asia, please use H415EK Option for Bulk Package.


** For replacement kits, see Appendix A Replacement Parts and Kits.

*** Not Field Replaceable for Latin America

MTP700 Portable Radio Model Information

| Model | Model Description |
|-------|--|
| P1 | MTP700, 380-430 MHz , 1 W, 25 kHz, with Continuous Rotary knob for group selection (CR) |
| P2 | MTP700, 380-430 MHz , 1 W, 25 kHz, with End Stop knob for group selection (ES) |
| P3 | MTP700, 806-870 MHz , 1 W, 25 kHz, with Continuous Rotary knob for group selection (CR) |
| P4 | MTP700, 806-870 MHz , 1 W, 25 kHz, with End Stop knob for group selection (ES) |
| P5 | MTP700, 806-870 MHz , 1 W, 25 kHz, with End Stop knob for group selection (ES), Korean model |

Sales Model Nomenclature



* For Asia, please use H415EK Option for Bulk Package.

MTP700 Portable Radio Model Specification

| GENERAL | | RECEIVER | | TRANSMITTER | |
|---|---|---|-----------------------|--|---|
| ETSI: | ETS 300 394-1 | Receiver Type: | Class B | Modulation Type: | $\pi/4$ DQPSK |
| Type Number | | Frequency Range: | | Nomin. Output Power: | |
| - 380-430 MHz: | PT911E | - TMO: | 380-430 MHz | - TMO | 30 dBm |
| - 806-870 MHz: | PT711E | | 851-870 MHz | - DMO | 30 dBm |
| | | - DMO: | 380-430 MHz | Frequency Range: | |
| | | | 851-870 MHz | - TMO: | 380-430 MHz |
| | | | | - DMO: | 806-825 MHz |
| | | | | | 380-430 MHz |
| | | | | | 851-870 MHz |
| Temperature: | | Channel Spacing: | 25 kHz | Channel Spacing: | 25 kHz |
| - Operating Temp.: | -30... +60°C (except Lilon battery & LCD display: -20°C) | Sensitivity (4%) BER: | -112 dBm (minimum) | | |
| - Storage Temp.: | -40... +85°C | | | | |
| Battery chemistries: | Lilon or NiMh | Intermodulation: | -47 dBm | Spurious Emission: | -36 dBm |
| Battery capacity: | | Blocking: | | Adjacent Channel Power (at ± 25 kHz) | -55 dBc (UHF) |
| - with standard Lilon: | 1200 mAh | - at 1, 2, 5 & 10 MHz | -25 dBm | | |
| - with NiMh: | 1200 mAh | - Adjacent channel selectivity @ 25 kHz | -60 dBm | | |
| Battery autonomy 5/5/90 (TX/RX/Stdby): | | | | Spurious Rejection: | -45 dBm |
| - with standard Lilon or NiMh | 24 hours* | | | Frequency Stability: | |
| | | | | - TMO | ± 100 Hz relative to downlink carrier frequency |
| | | | | - DMO | ± 1 kHz |
| Battery autonomy 5/35/60 (TX/RX/Stdby): | | Audio Rated: | 500 mWatt | | |
| - with standard Lilon or NiMh | 15 hours* | Distortion: | < 5 % | | |
| Dimensions (HxWxD) mm: | 138x55x39 | | | | |
| Weight: | | | | | |
| - with standard Lilon battery | 361 g | | | | |
| - with standard NiMh battery | 434 g | | | | |

* at medium audio power level

Table 2-1 Model Specification

MTP700 Accessories-To-Model Chart

| MTP700 PORTABLE RADIO ACCESSORIES | Kit Number | 380-430 MHz | | 806-870 MHz | | |
|--|-------------------|-------------|-----------|-------------|-----------|-----------|
| | | P1 | P2 | P3 | P4 | P5 |
| Batteries - Smart | Kit Number | P1 | P2 | P3 | P4 | P5 |
| Battery, Lilon, Std, 1200 mAh | PMNN4047_ | x | x | x | x | x |
| Battery, NiMH, 1200 mAh | PMNN4048_ | x | x | x | x | |
| Battery, NiMH, FM, 1150 mAh | PMNN4049_ | x | x | x | x | |
| Antennae | Kit Number | P1 | P2 | P3 | P4 | P5 |
| 806-870 MHz, Whip | NAF5037_ | | | x | x | |
| 806-870 MHz, Stubby | NAF5042_R | | | x | x | x |
| 380-400 MHz, Narrow band | FAE6000_ | x | x | | | |
| 410-430 MHz, Narrow band | FAE6001_ | x | x | | | |
| 380-400 MHz, Whip | FAE5520_ | X | X | | | |
| 410-430 MHz, Whip | FAE6002_ | x | x | | | |
| Chargers | Kit Number | P1 | P2 | P3 | P4 | P5 |
| IMPRES Multi Unit Charger (MUC) with 230V Euro Plug | WPLN4109_ | x | x | x | x | |
| IMPRES Multi Unit Charger (MUC) with 230V UK Plug | WPLN4110_ | x | x | x | x | |
| IMPRES Multi Unit Charger (MUC) with 120V USA Plug | WPLN4120_ | x | x | x | x | |
| Battery Insert (all MUCs need this battery adapter) | RLN5212_ | x | x | x | x | |
| 110V Single Unit Charger (SUC) Smart Charger | WPLN4111_R | x | x | x | x | |
| IMPRES Single Unit Charger (SUC) with Euro Plug | WPLN4112_ | x | x | x | x | |
| IMPRES Single Unit Charger (SUC) with UK Plug | WPLN4113_ | x | x | x | x | |
| IMPRES Single Unit Charger (SUC) with AUST/ NZ Plug | WPLN4115_ | x | x | x | x | |
| IMPRES Single Unit Charger (SUC) with Argentina Plug | WPLN4116_ | x | x | x | x | |
| Single Unit Adaptive Charger (SUC) with US/NA Plug | WPLN4117_R | x | x | x | x | |
| Battery Insert (all SUCs need this battery adapter) | RLN5211_ | x | x | x | x | |
| Rapid Charger, Non-Smart, US Plug 2-Pin* | PMTN4063_ | x | x | x | x | |
| Rapid Charger, Non-Smart, Euro Plug 2-Pin* | PMTN4064_ | x | x | x | x | |
| Rapid Charger, Non-Smart, UK Plug 3-Pin* | PMTN4065_ | x | x | x | x | |
| Charger Base only - Non-Smart* | PMLN4522_ | x | x | x | x | x |

Table 2-2 Accessories

| MTP700 PORTABLE RADIO ACCESSORIES | Kit Number | 380-430 MHz | | 806-870 MHz | | |
|--|---|-------------|-----------|-------------|-----------|-----------|
| | | P1 | P2 | P3 | P4 | P5 |
| Carrying Case Accessories | Kit Number | P1 | P2 | P3 | P4 | P5 |
| Hard leather case with Swivel | PMLN4474_ | x | x | x | x | x |
| Carrying strap for above | NTN5243_ | x | x | x | x | x |
| 2.5 inch belt clip | HLN9714_ | x | x | x | x | x |
| Light leather case ("GSM" style) | PMLN4475_ | x | x | x | x | |
| Wrist strap | HLN9767_ | x | x | x | x | x |
| Nylon Case | RLN4851_ | x | x | x | x | |
| Large Shoulder Harness Kit | GMLN4093_ | x | x | x | x | |
| Small Shoulder Harness Kit | GMLN1051_ | x | x | x | x | |
| AUDIO - REMOTE SPEAKER / MICROPHONE (RSM) | Kit Number | P1 | P2 | P3 | P4 | P5 |
| Enhanced Remote Speaker/Microphone (ERSM), terminates with side connector, emergency button, programmable button, manual volume control, earpiece jack, vibrator alert | RMN5011_ (Short - 35 cm) RMN5012_ (Long - 70 cm) | x | x | x | x | x |
| Short Coil Cord (35 cm) | RLN5258_ | x | x | x | x | |
| Long Coil Cord (70 cm) | RLN5259_ | x | x | x | x | |
| Remote Speaker/Microphone (RSM), with 3.5 mm threaded jack | RMN5013_ | x | x | x | x | |
| Receive only earbud, black coiled cord (plugs into 3.5 mm jack on RSM) | RLN4885_ | x | x | x | x | |
| Programming Equipment | Kit Number | P1 | P2 | P3 | P4 | P5 |
| Data Cable | PMLN4504_ | x | x | x | x | x |
| Programming/Data Cable | FLN9636_ | x | x | x | x | x |
| Programming Stand | PMLN4510_ | x | x | x | x | x |
| MTP700 Customer Programming Software (CPS) | FVN5051_ | x | x | x | x | x |
| Audio Surveillance | Kit Number | P1 | P2 | P3 | P4 | P5 |
| Rx Only Earpiece - Black | RMN4028_ | x | x | x | x | |
| Rx Only Earpiece - Beige | RMN4021_ | x | x | x | x | |
| Rx Only Earpiece -with transparent tube for RSM | RLN4941_ | x | x | x | x | |
| Earpiece with mic and PTT combined, beige, 2 wire | RMN4022_ | x | x | x | x | x |
| Earpiece with mic and PTT combined, black, 2 wire | RMN4029_ | x | x | x | x | |
| Earpiece with separate mic and PTT, beige, 3 wire | ENMN4017_ | x | x | x | x | x |
| Earpiece with separate mic and PTT, black, 3 wire | ENMN4014_ | x | x | x | x | |
| Earplugs Foam w/Acoustic Tube | NTN8370_ | x | x | x | x | |
| Rubber Eartips w/Acoustic Tube | NTN8371_ | x | x | x | x | |
| Noise Attenuating Plugs | 5080384F72 | x | x | x | x | |
| Large Earshell (offered in EMEA) | WADN4223_ | x | x | x | x | |
| Small Earshell (offered in EMEA) | WADN4224_ | x | x | x | x | |
| Audio - Headsets | Kit Number | P1 | P2 | P3 | P4 | P5 |
| Lightweight Headset with Swivel Boom Microphone & PTT | RMN5014_ | x | x | x | x | |
| Breeze Headset, PTT | ENMN4012_ | x | x | x | x | |

Table 2-2 Accessories

* For Asia only.

CHAPTER 3 OVERVIEW

General

The MTP700 is Motorola's latest and most advanced digital portable TETRA radio. This radio generation is based on a new digital platform technology. It covers Trunk Mode Operation (TMO) as well as Direct Mode Operation (DMO) and among other new features it is supplied with extended code and operation memory capacity to support all new market requirements. The MTP700 TETRA radio ensures a high audio quality.

To achieve a high spectrum efficiency, the MTP700 units use digital modulation technology and sophisticated voice-compression algorithm. The voice of the person speaking into the microphone is converted into a digital bit stream consisting of zeros (0) and ones (1). This stream is then modulated into a radio-frequency (RF) signal, which is transmitted over the air to another unit. This process is called digital modulation.

Digital Modulation Technology

The MTP700 are 380-430 MHz or 806-870 MHz portable radios that can operate in dispatch mode. They use two digital technologies: $\Pi/4$ DQPSK and Time Division Multiple Access (TDMA).

$\Pi/4$ DQPSK is a modulation technique that transmits information by altering the phase of the radio frequency (RF) signal. Data is converted into complex symbols, which alter the RF signal and transmit the information. When the signal is received, the change in phase is converted back into symbols and then into the original data.

The TETRA system can accommodate 4-voice channels in the standard 25 kHz channel as used in the two-way radio.

Time Division Multiple Access (TDMA) is used to allocate portions of the RF signal by dividing time into four slots, one for each unit.

Time allocation enables each unit to transmit its voice information without interference from other transmitting units. Transmission from a unit or base station is accommodated in time-slot lengths of 14 milliseconds and frame lengths of 57 milliseconds. The TDMA technique requires sophisticated algorithms and voice compressions/decompressions (perform by digital-signal processor, DSP) and RF modulation/demodulation.

Voice Compression Technology

Voice is converted into a digital bit stream by sampling the voice at a high rate and converting the samples into numbers, which are represented by bits.

Voice compression reduces the number of bits per second while maintaining the voice at an acceptable quality level. The TETRA system uses a coding technique called ACELP (Algebraic Code Excited Linear Prediction). The compressed voice-data bits modulate the RF signal.

THIS PAGE INTENTIONALLY LEFT BLANK

CHAPTER 4

RADIO INFORMATION

Section Introduction

This section provides a block diagram overview of the main Digital/RF Board supplemented by the detailed block diagram and detailed circuit description followed by board and schematic diagrams and parts lists and troubleshooting charts.

This chapter contains the following sections:

- 4.1 Transceiver 380-430 MHz
- 4.2 Transceiver 806-870 MHz

THIS PAGE INTENTIONALLY LEFT BLANK

CHAPTER 4.1

TRANSCEIVER 400 MHz

General

This section provides a block diagram overview of the main Digital/RF Board. This is supplemented by the detailed block diagram and detailed circuit description.

Block Diagram Overview

The main Digital/RF Block contains the following four sections (see Figure 4.1-1). An overview of these four sections is provided in the following paragraphs:

- Receiver Section
- Transmitter Section
- Frequency Generating Section (Synthesizer)
- Digital & Audio Section




Figure 4.1-1 General Block Diagram

Receiver Section

The receiver section includes the following main components:

- Antenna Switch
- Limiter
- Pre-selection Filter
- Low Noise Amplifier (LNA)
- Post-selection Filter
- Mixer
- IF Filter
- Balun
- WPIC

The Receiver Path implements an Automatic Gain Control (AGC). It is required to maintain good receiver linearity over a wide range of incoming signals and to prevent clipping of high level signals.

The First Intermediate frequency (IF) circuit consists of the Mixer, IF Filter, and WPIC. The First IF is down converted to baseband using an analog mixer (high-side injection) located in the WPIC. An external second LO synthesizer IC is used to generate the required 219.3 MHz signal, which is further divided by two to 109.65 MHz before being applied to the mixer.

The WPIC performs the following functions:

- Carries out amplification and quadrature down conversion of the signal into baseband.
- Performs IF AGC.
- Converts the baseband analog signal into digital I & Q formats.
- Synthesizes the receive and transmit data (i.e. Sigma-Delta) clock.
- Transmits the received data to the DSP.

Transmitter Section

The transmitter circuitry includes a linear class AB Power Amplifier (PA) for the linear modulation of the MTP700. Also included is a cartesian feedback loop to enhance the transmitter linearity and hence reducing splattering in the adjacent channels.

The transmitter path consists of forward and feedback paths. The forward path includes the WPIC for digital-to-analog conversion of the transmit baseband signal, the LNODCT (Low Noise Offset Direct Conversion Transmitter) IC, Balun, Attenuator and Power Amplifier. The feedback path includes the directional coupler, attenuator and LNODCT (Low Noise Offset Direct Conversion Transmitter) IC.

The linearized power from the PA goes through the isolator which provides the isolation between the antenna and the PA. The signal then passes through the antenna switch and a lowpass Harmonic Filter to provide additional filtering to remove far out unwanted signals.

Frequency Generating Section (Synthesizer)

The frequency generating section contains the following components:

- TCXO Reference Oscillator.
- Main Synthesizer - consists of the WPIC's PLL and the Main Voltage Controlled Oscillator (VCO).
- 2nd Local Oscillator (LO) VCO together with the LMX Dual Synthesizer IC.
- Transmit PLL - consists of TX VCO together with ESCORT Synthesizer IC.

Digital & Audio Section

The digital section includes the RedCap2 host micro-processor which is the controller of the Digital/RF Board. It controls the operation of the audio and transmitter, receiver, and synthesizer integrated circuits located in the RF section. It has the serial communication interface to communicate with the keypad, display and other internal peripherals.

For audio, the RedCap2 contains a Digital Signal Processor (DSP) which performs modulation and de-modulation functions for the radio. It also performs ACELP speech coding and Forward Error Correction.

Major components of the digital section are:

- RedCap2 (microprocessor with DSP embedded)
- GCAP3 (DC power supply and audio amplifier circuits)
- Serial peripheral interface (SPI)
- External host memories (Flash and SRAM)
- Keypad block & circuits
- LCD (liquid-crystal display) circuits
- Bottom connector & side connector interface circuits

Block Diagrams Descriptions

The block diagrams descriptions cover Receiver Path, Transmitter Path, Frequency Generation Section and Digital Section.

Receiver Path

The received signal (see Figure 4.1-2) from the antenna is directed by the Antenna Switch to the Pre-selection Filter.




Figure 4.1-2 Receive Path - Block Diagram

The Pre-selection Filter blocks the half IF and image frequencies and reduces the RF oscillator leakage to the antenna. The mid-frequency of this front filter is tuneable in five steps to achieve the required selectivity for the entire receive frequency range 380-430MHz. Additional selectivity is provided by a fixed-tuned Post-selection Filter. The filtered signal is mixed (at high side) with the signal of the Main Synthesizer to create the first IF at 109.65 MHz. The IF signal is filtered by the crystal filter and sent to the WPIC.

The WPIC performs down conversion to the baseband frequency (0 Hz). The baseband analog signals are converted to digital In-phase (I) and Quadrature (Q) formats. This data is sent for further processing to the Digital Signal Processor (DSP) (part of RedCap2) over the Synchronous Serial Interface (SSI) data links.

The DSP performs: the demodulation, Forward Error Correction (FEC) and other correction algorithms for overcoming channel errors, and decoder procedure for digital speech data decompression.

Transmitter Path

When the radio is transmitting (see Figure 4.1-3), the microphone audio is sent to the GCAP3 (CODEC). The CODEC performs 13-bit analog-to-digital conversion and the digital signal is routed to the DSP (part of RedCap2). The DSP performs coding, Error Correction and modulation. From the DSP, the digital base band signal is sent to the WPIC.




Figure 4.1-3 Transmit Path - Block Diagram

In the WPIC, the digital baseband I & Q signals are converted into corresponding analog signals. These signals are also filtered. From the WPIC, I & Q signals are injected to the LNODCT. In the LNODCT, the data is mixed with RF signal.

From the differential output of the LNODCT, the modulated RF signal is injected to the Balun wideband transformer that transforms the differential input into single output, and then it is routed to the antenna via TX PA, Isolator, Antenna Switch and Harmonic Filter.

The feedback signal is used for power control.

Frequency Generating Section

The frequency generating section contains the following components (see Figure 4.1-4):

- TCXO Reference Oscillator.
- Main Synthesizer - consists of the WPIC's PLL and the Main Voltage Controlled Oscillator (VCO).
- 2nd Local Oscillator (LO) VCO together with the LMX Dual Synthesizer IC.
- Transmit PLL - consists of TX VCO together with ESCORT Synthesizer IC.




Figure 4.1-4 Frequency Generation - Block Diagram

TCXO Reference Oscillator

All frequencies originate from the Reference oscillator - TCXO. This is a digital temperature compensated crystal oscillator producing an accurate and stable 16.8 MHz reference frequency. The 16.8 MHz reference frequency is divided in the WPIC and in the Dual Synthesizer IC to produce required reference frequency for the other synthesizers.

Main Synthesizer

The Main Synthesizer consists of the WPIC internal PLL modules and an external, discrete Voltage Controlled Oscillator (VCO). The output provides the LO signal to down-convert the received RF signal to the first IF of 109.65 MHz. The output is also routed as the transmit injection frequency for the ESCORT IC.

RX Second Local Oscillator (LO)

The second LO synthesizer supplies the second IF local oscillator signal to the receiver. The signal of the frequency of 219.3 MHz will be used in the WPIC to generate the quadrature signals for downconverting the received IF signal to the baseband (zero IF).

Transmit PLL

The TX PLL consists of a discrete TX Voltage Controlled Oscillator (TX VCO) and the ESCORT Synthesizer IC. The ESCORT IC receives its reference signal (TETRA_TX_LO) from the main synthesizer/VCO to synthesize the TX VCO signal within the frequency range of 380-430 MHz, which is subsequently routed to the transmitter path (LNODCT).

Digital & Audio Section

The digital section (see Figure 4.1-5) contains the radio's RedCap2 RISC processor, DSP (embedded within), external memories and GCAP3. The DSP has its own processing memory. GCAP3 contains switching and linear regulators, audio preamplifiers, 13-bit CODEC, A/D and D/A Converters, and interfaces with an external Audio Amplifier for receive audio.

RedCap2 controls the receive/transmit frequencies, power levels, display, keypad, accessories, MMI, and other radio functions. This microprocessor can be operated through the RS232 interface by a personal computer to program the Flash memory with firmware and codeplug.

The DSP performs the functions of audio filtering, ACELP speech coding, Forward Error Correction and digital modulation. The GCAP3's CODEC handles the analog-to-digital and digital-to-analog conversions on audio signals.

The power distribution is supported by the Global Control Audio Power (GCAP3) IC. This IC supplies power to the radio using step-down PWM regulator supplying 1.875 VDC to the RedCap2 core, supplying V3 linear regulator 2.775VDC to the external memories, display and RedCap2 peripheral modules, supplying V2 to GCAP3 internal logic, internal audio amplifier and A/D converter. The regulator's power-down mode is controlled by the RedCap2, which senses the ON or OFF condition.




Figure 4.1-5 Digital Section - Block Diagram

Detailed Circuit Description

Receiver Path, Detailed Circuit Description

See Figure 4.1-6.




Figure 4.1-6 Receive Path Circuit Diagram

Antenna Switch

The signal from the antenna is routed to the receiver input via the transmitter harmonic filter (C5016, L5008, C5015 and C5011), an equivalent quarter wave line (L5007 with C5011 and C5020) and the low pass (C5020, L5011, C5022 and C5021) for spurious response improvement. Isolation to transmitter frequencies at this point is better than 35dB; attenuation of the wanted Rx signal is typically 0.7dB.

Limiter

Diode D2100 limits the level of incoming high power signals (> 5dBm) to prevent damage to the receiver front end.

Pre-selector

The signal arriving at the receiver input is routed through the integrated, tuneable Pre-selector Filter FL2100 into the Low Noise Amplifier (LNA) U2200 via a matching network C2200, L2200, R2200 and C2201.

The pre-selector attenuates unwanted incoming RF signals, especially the image frequency (25dB). Typically, the insertion loss is 2dB.

Low Noise Amplifier (LNA)

The LNA U2200 amplifies the RF signal. The overall gain of the LNA including the output matching circuit, L2201, R2202, C2209, C2210 and L2202 typically is 18dB. Because the LNA is the first amplifier in the RX line, it is important that it provides high gain and has a low noise figure.

The LNA has an "enable" pin (pin 3) which is called VPD. When this pin receives a signal of 2.7V from DC switch Q2200 the amplifier is enabled (via signal GP05_DCLICP from WPIC). In the transmit slot, Q2200 is switched off. The LNA current is controlled by R2201. Resistor R2202 ensures the amplifier is stable throughout its operating range. From the LNA, the signal passes to the fixed-tuned post-selector.

Post-selector

The Post-selector, consisting of discrete components C2300-C2306, L2300-L2302, attenuates the non-linear products of the LNA and also the image product. Typically, its insertion loss is 2dB. From the output of the post-selection filter, the received signal is routed to the mixer RF input via attenuator R2404-R2406 and band pass L2402, C2402.

Mixer

The mixer U2400 down-converts (at high side) the incoming RF signal to an IF signal (109.65 MHz). The mixer IC consists of a mixer and an LO buffer amplifier.

The RF signal enters the mixer at pin 1, and the IF is produced at pin 6. The LO signal from the main synthesizer passes via the attenuator R2400-R2402 and the wide band matching network L2400, C2400, R2403, C2401 into the IC at pin 3. The LO power is boosted internally before being applied to the mixer. The LO signal power at the LO mixer input is -4dBm. The 2.7V DC is supplied by switch Q2400, that is enabled during receive mode (via signal GP06_DCLICIN from WPIC).

The mixer conversion gain is -6 dB.

An impedance matching network is placed between the mixer and the IF filter FL2500. It consists of C2405, L2403, C2500, L2500 and C2501.

IF Filter

The IF signal is routed via the IF filter (FL2500), which has an insertion loss of 2 dB and attenuates unwanted mixing products of the mixer. It is connected via a matching network, consisting of C2502, L2501 and C2503, to the balun network.

Balun

The balun network (L2502, C2505, C2504 and L2503) transforms the single-ended input RF signal to a differential double-ended output.

The differential signal is routed to the WPIC, pins A4 and B4, via C1018 and C1019.

WPIC (Receiver Back End Section)

The differential IF signal is amplified and converted down to zero IF inside the WPIC (World Phone IC) by the 2nd LO signal. The 2nd LO signal is routed to the WPIC at pin D1 and divided by two into the quadrature generator block of the WPIC. The baseband signal from this 2nd mixer passes to an amplifier baseband filter array. The amplified and filtered signal is passed to the WPIC A/D converter. This A/D converter digitises the analog differential signal into its I and Q components. The I and Q components appear in sequence on the WPIC_SRD line whenever the RX_ACQ line is high. The WPIC_SRD data is clocked into the DSP using a clock signal (WPIC_TXCLK) from WPIC. The WPIC is controlled via SPIA_MOSI, SPIA_CLK and SPIA_CSO_WPIC from RedCap2.

An internal AGC that is controlled by a control unit, establishes an appropriate attenuation for unwanted signals as well as an appropriate gain for wanted signals. The voltage at external capacitor C1008 indicates the AGC attenuation level for the different input signal levels. The voltage at the capacitor varies from 1.4V to 2.7V as a function of the power of the received signal.

Transmitter Path, Detailed Circuit Description

See Figure 4.1-7.




Figure 4.1-7 Transmit Path - Circuit Diagram

Forward Path

WPIC

The WPIC (World Phone IC) U1001 receives serial data that is transmitted by the RedCap2 at 48 kbps (kilobits/second) to the SSI port (pin K10, WPIC_STD). Data is transmitted as a 16-bit 'I' word followed by a 16-bit 'Q' word. The WPIC provides a serial clock of 4.8MHz to the RedCap2 (pin K11, WPIC_TXCLK) and sends a frame sync signal (pin L11, WPIC_FSYNC) at the beginning of every 'I' word transmission to instruct the RedCap2 to send data. In the WPIC, the received serial I & Q words from the RedCap2 are converted into parallel I & Q words, and transferred to an interpolating filter. The interpolating filter increases the sampling rate to reduce in-band quantization noise, as well as to reduce image at multiples of the input data. The interpolated samples are rounded to 8 bits, and run through the 8-bit D/A converters. The D/A converters take the digital I & Q words and convert them into analog signals, which are then filtered and amplified. The output is comprised of two separate low-level differential signals, I & Q (pins A8, OUTQ; C8, OUTQB; D8, OUTI; A9, OUTIB). A differential output is used to minimize the noise pick-up, due to its inherent common mode rejection.

The output signals are routed to the LNODCT IC. The WPIC sends a 2.4MHz low-level differential reference clock signal (pins B11, TCLK; C10, TCLKB) to the LNODCT. It also sends a differential signal (pins A11, TSLOT; A10, TSLOTB) that marks the beginning and the end of each transmission time slot (whenever pin 8, WPIC_TXE signal is received from RedCap2). After receiving the TSLOT signal, the LNODCT toggles the ASW line (pin J5) which signals the WPIC to set VCNT0 signal LOW (pin J6) which enables the Antenna Switch during transmit time.

TX LO Line-Up

The TX frequency signal TX_SOURCE is generated in the TX PLL of the Frequency Generating Section. This signal passes an attenuator R6001-R6003, the LO driver Q6001 and a band pass filter (C6006-C6012, L6003, L6004) to attenuate unwanted spurious frequencies. The signal level is about +7dBm. This is then split by a simple, resistive 6dB power splitter consisting of R6008, R6009 and R6010.

One output of the power splitter drives phase splitter U6001 that converts the single input signal into two quadrature (90 degrees phase shift) 'I' and 'Q' signals and then routes them to the LO input (LOI, LOIB, LOQ, LOQB) of the LNODCT.

The second output of the power splitter U6001 is applied to the LNODCT LO feedback input (MVCO).

LNODCT

The LNODCT IC (Low Noise Offset Direct Conversion Transmit IC) U6002 is the heart of the transmitter.

The differential baseband signals from WPIC are applied to the LNODCT on pins 58 – 61 (BINQB, BINQ, BINIB and BINI). They pass through a variable attenuator and then they are summed with the down converted I & Q feedback. The baseband signal is then amplified and sent to the up-mixer.

The up-mixer consists of two mixers, one for the I channel and the other for the Q channel. The split I & Q LO signal is mixed with the baseband I & Q signals to produce I & Q modulated signals at RF frequency. The signals then are output differentially on pins 51 and 52 (RFOUTB, RFOUT).

Balun

The differential RF signal is converted to a single-ended (unbalanced) signal by passing the Balun (**balanced-unbalanced**) wide band transformer T6001. The Balun has a 200 Ohm balanced input and 50 Ohm single-ended output, set by C6032 and C6053 respectively. This Balun configuration matches the LNODCT differential output for optimum performance in the 380-430MHz frequency range. The insertion loss of the Balun is about 1dB.

Resistors R6024–R6026 form an attenuator to compensate for changes in gain in the forward path RF PA stages.

RF Power Amplifier

The signal is routed through coupling capacitor C6034 to the RF power amplifier (PA). The PA consists of 2 devices, namely U4001 driver and Q4001 final PA. U4001 is a 2-stage IC that is capable of amplifying the signal to about 18dBm. The capacitors and inductors between U4001 output and Q4001 input form a high pass - low pass matching network. Q4001 output is then matched to the 50 ohms input of the isolator by a low pass pi matching stage using microstrip-lines and discrete components.

Wideband RF stability of the PA is optimised by insertion of RF losses (R4008, R4006, R4004) in the gate circuit of Q4001.

The U4001 amplifier gain is set in the factory using the VBLIN signal (from WPIC). VBLIN is amplified by DC amplifier U4002. The voltage output from U4002 sets the quiescent current and hence the gain of the LDMOS driver IC U4001.

The gain of Q4001 is set in factory through serial SPI commands (from RedCap2) to the E-pot IC U4102. The output voltage of the E-pot is dependent on the internal resistance divider ratio and amplified by DC amplifier U4100. During transmission, the 2.775V supply to the E-pot is enabled using the signal PA_BIAS (from RedCap2). When this line signal is 2.775V (HIGH), the voltage to bias the final stage device is enabled.

Coupler and Feedback Path

The output signal from the RF PA passes through directional coupler U5001 to the Isolator FL5001. The sampled signal from the coupler provides feedback for linearization and power control. The sampled signal is routed via attenuator R5001, R5002, R5003 to the LNODCT (pins 37, RFIN; 36, RFINB). The feedback signal is routed back to LNODCT and mixed down to baseband in a quadrature mixer, amplified and summed with the baseband input signal.

Isolator

The signal in the forward path is fed to pin 4 of the isolator FL5001. The isolator is placed at the PA output to decrease the influence of antenna impedance variation on the PA performance. The reflected power from the antenna is absorbed in a 50-Ohm resistor inside the isolator. The isolator also protects the Cartesian loop from sudden VSWR variations that could lead to loop instability.

Antenna Switch

PIN diodes D5001, D5002 and D5003 are used as antenna switches. These PIN diodes are turned on during the transmission time slot. The RF signal from the Isolator is applied to the PIN diodes D5001 and D5002. The RF signal is then routed through the harmonic filter (C5011, L5008, C5015 and C5016) to the antenna. D5003 provides the needed RX isolation during Transmission mode.

In the Receiving mode the PIN diodes are turned off, the input RF signal is directed to the receiver path via $\lambda/4$ quarterwave equivalent LC-circuit (C5011, L5007 and C5020) and a further low pass filter (C5020, L5011, C5022 and C5021).

The condition of the PIN diodes is controlled by the voltage switch Q5001 by applying the ANT_EN signal (from RedCap2) to the switch. The VCNT0 signal (from WPIC) applied to the voltage switch Q5001 is set LOW during the Receiving and Transmission modes. The resistors R5006 and R5008 determine the DC current through the PIN diodes.

The RF output signal is disabled during the CLCH (Training) mode by setting the VCNT0 signal HIGH thus providing low output power to the antenna during the training slot.

Harmonic Filter

From the antenna switch the signal is routed to a single-section LC filter, consisting of L5008, C5011, C5015 and C5016. The filter attenuates the harmonics of the transmitter signal and reduces leakage of the Rx LO signal.

Resistor R5014 provides a discharge path for any build-up of static electricity at the antenna.

Frequency Generating Section, Detailed Circuit Description

See Figure 4.1-8

This section describes the circuits that generate all the required frequencies for the required transmitter and receiver functions. These circuits are described as follows:

- TCXO REF. Oscillator.
- Main VCO and Main Synthesizer.
- Second LO VCO and Dual Synthesizer RF section.
- Transmit PLL - TX VCO with the ESCORT Synthesizer IC.




Figure 4.1-8 Frequency Generation Section - Block Diagram

TCXO Reference Oscillator

The TCXO oscillator Y1301 is the reference frequency source for all the radio synthesizers. The output of the oscillator is a 16.8 MHz stable temperature-compensated reference clock. This oscillator's centre frequency is adjustable by means of a PWM DAC (256 steps) to warp the radio frequency in order to lock to the base station. This 16.8 MHz signal from pin 3 of the TCXO is routed into the following devices:

1. To WPIC's K6 XTALBASE pin via C1301. The signal is divided by 4 to produce the 4.2 MHz reference signal, which is used for the Main Synthesizer PLL.
2. To LMX Dual Synthesizer's OSCIN pin via C1505. The signal is divided to produce the 300 kHz reference signal for the second LO PLL.

The reference signal is also routed from WPIC's pin F10 (16.8_MHz_CLK) to GCAP3 (and subsequently to RedCap2) to clock the digital circuits.

Main VCO and Main Synthesizer

The main synthesizer components are WPIC, Loop Filter, VCO and buffer. It produces the LO signal.

The synthesizer functions are as follows:

- To serve as the local oscillator for the mixer of the receiver. It is used to down-mix the RF frequency to the IF frequency 109.65 MHz
- To provide the reference signal for the ESCORT PLL IC of the Tx synthesizer.
- To provide as the WPIC feedback signal for locking the main synthesizer.

The WPIC is programmed by the DSP through the SPI bus.

The VCO (Q3002 and associated circuitry) generates the LO signal which is fed back to the synthesizer (inside the WPIC) through the PRSCIN. The TCXO provides the 16.8 MHz reference frequency.

The synthesizer then generates the VCTRL tuning voltage through WPIC's CPGITR pin to control the VCO frequency. The loop filter (LPF) consists of C1810, R1805, R1802 and C1816 which filters noise in the tuning voltage. A pre-setting of the VCO frequency is provided by additional tuning via the DC signals from the "Coarse Tune DAC" in the WPIC.

The Q3003 and Q3004 buffers prevent loading and interference to the next stage - i.e. the RX Mixer and ESCORT.

LMX - Dual Synthesizer

The U1501 (LMX233XL) is an integrated dual frequency synthesizer IC that includes prescalers. It is used with the second LO VCO at the RFCU section.

The LMX uses the 16.8 MHz from the TCXO for the second LO synthesizers and divides the TCXO frequency into 300 kHz reference frequency for the second LO.

Second LO VCO

The Second LO VCO is a discrete VCO (Q1521) that is controlled by the Dual Synthesizer IC (U1501). The VCO produces a frequency of 219.3 MHz that routes into LOIN pin of WPIC.

The output signal of the VCO is also routed via C1544 to the phase detector of Dual Synthesizer (pin 18, FINIFPOS). The internal phase detector is of the charge pump type.

The output signal of the phase detector is present at Dual Synthesizer (pin 20, DOIF) and then routed via the loop filter R1511, C1511 and C1512 to tuning diode D1521 of the tank circuit.

Transmit PLL

The TX VCO is a discrete VCO that is controlled by the ESCORT IC U7001. The VCO produces the TX frequency signals in the frequency band 380-430MHz. A discrete coil L7501 is used in the tank circuit of the VCO. Four tuning diodes (D7501-D7504) and the variable feedback by D7505 ensure excellent performance in noise behaviour and signal level stability throughout the whole band. A cascode amplifier is used as buffer to minimize the impact of load pull on the VCO frequency.

The synthesizer IC is the ESCORT IC U7001 employing NUD (near-unity-divider) technique to provide fast lock-in to TX frequency using a high reference frequency. The Main synthesizer is used as reference frequency source. The signal frequency of the Main VCO is divided by 41/32 and compared with the TX VCO frequency in the fast phase comparator of the ESCORT. The comparator output signals IUP and IDOWN then control the current mirrors Q7021 and Q7022 to supply the tuning voltage to low pass filter C7011, C7012, R7011 and voltage range extension transistors Q7023 and Q7024 to the tuning diodes. The ESCORT is controlled by the RedCap2 via SPIA_CLK; SPIA_MOSI and SPIA_CS1_ESCORT.

Digital & Audio Section, Detailed Circuit Description

See Figure 4.1-9.




Figure 4.1-9 Digital Section - Detailed Circuit Diagram

RedCap2 (Microprocessor & DSP)




Figure 4.1-10 RedCap2 - Block Diagram

Figure 4.1-10 is a block diagram of the RedCap2 and its interfaces.

The RedCap2 RISC processor controls the operation of the transmitter, receiver, synthesizer and audio (GCAP3) integrated circuits. It uses the Flash memory and SRAM, both located externally.

RedCap2 employs SPI protocol (Serial Peripheral Interface) to communicate with the RF ICs, display, keypad and other internal peripherals. The processor can be operated through the RS232 interface by a personal computer to program the Flash memory with firmware and codeplug.

Within the RedCap2 is the Digital Signal Processor (DSP) which performs modulation and de-modulation functions for the radio. It also performs ACELP speech coding and Forward Error Correction.

External Host Memories

The RedCap2 Address bus is a 22-bit wide (0:21) and RedCap2 Data Bus is a 16-bit wide (0:15).

RedCap2 uses two types of memories:

Flash Memory

The Flash memory is dedicated to the application software. This memory has a 16-bit wide data bus. The Flash memory is 4 Meg x 16-bit (ie 64 MBits density). When addressing the Flash memory location, the processor reads into its 16-bit wide data bus.

Apart from storing radio firmware, the Flash also stores the Radio CodePlug (Customer related information) such as telephone numbers, addresses, etc.

SRAM Memory

This 512k x 16-bit Static RAM is used for Data storage.

Serial Peripheral Interface (SPI)

The RedCap2 uses the SPI protocol (Serial Peripheral Interface) to communicate with RF IC's (WPIC, LNODCT, ESCORT), GCAP3 IC and the display driver.

The protocol is built upon 4 lines [MOSI(Tx), MISO(Rx), CS, CLK].

The RF IC's are connected to SPIA module, while GCAP3 and the display are connected via SPIB module.

The Display Module, based on the display driver (i.e. Samsung KS0741) uses a serial interface.

GCAP3

The Global Control Audio Power (GCAP3) IC handles DC power distribution and audio processing (ie audio amplification and analog-to-digital/digital-to-analog conversions). It contains switching and linear regulators, audio preamplifiers, 13-bit CODEC, 14-channel 10-bit A/D Converter, 8-bit D/A Converter and interfaces with an external Audio Amplifier for receive audio.

DC Power Distribution

See Figure 4.1-11




Figure 4.1-11 MTP700 DC Distribution

Several sections of the radio are connected directly to the battery, which supplies RAW_B+ and FUSED_B+. The radio operates at a low voltage of 5.8Vdc, nominal-level voltage of 7.2Vdc, and high-level voltage of 12Vdc. The battery is connected to J001 pins 3 (+) and J001 pin 1 (-). These pins supply the RAW_B+ to the RF TX power amplifier and the SWB+ current limit regulator. RAW_B+ is routed via F200 (Fuse) becoming FUSED_B+, which is used by the Audio PA, the 3.3V Switching Regulator and the SWB+ switch for the TX Driver bias circuit.

3.3V Switching Regulator

An external 3.3V switching regulator is used to convert the battery voltage (7.2V) down to 3.3V to be used by GCAP3. This regulator can be set to fixed frequency 600KHz (during Tx & Rx) or variable switching frequency (when idle) depending on the load.

PWM #1 (Pulse Width Modulation)

PWM #1 is a selectable step down switching regulator. It is selectable using the RedCap2 SPIB bus from 1.2V to 2.45V in 6 steps, Pass Through and Power down modes. The switcher is active during Power Reset (POR) in 1.875V mode. It is set to 1.875V. Switching regulator is PWM#1_1.875V, which is the supply for the internal core, emulation port and clock output drivers of the RedCap2. The switcher is supplied from FILT_3.3V and it is active whenever the radio is turned ON.

V1 Linear Regulator

V1 is a programmable linear regulator. It is programmed using the RedCap2 SPIB bus from 0.975V to 3.0V in 8 steps. This regulator is active during POR and its initial value is 1.55V. For this radio, V1 is programmed to 3.0V, supplying ESCORT section by filtered V1_3V. This regulator is active whenever the radio is turned ON.

V2 Linear Regulator

V2 is a selectable linear regulator. It is selectable using the GCAP3 UV_SEL pin (internal logic) between either 2.5V and 2.775V. This regulator is active during POR and its initial output value is set by GCAP3 UV_SEL pin. Connecting UV_SEL pin to FILT_3.3V sets V2 output value to 2.775V, connecting UV_SEL pin to Ground sets V2 output value to 2.5V. For this radio, V2 is selected to 2.775V. This regulator is supplied by FILT_3.3V and it is active whenever the radio is turned ON. V2 is the supply for internal audio circuits, CLK_IN input driver and TS interface.

V3 Linear Regulator

V3 is a selectable linear regulator. It is selectable using the RedCap2 SPIB bus from 1.875V to 2.775V in 4 steps. This regulator is active during POR and its initial output value is 2.775V. For this radio, V3 is selected to 2.775V. The regulator is supplied by FILT_3.3V and it is active whenever the radio is turned ON. V3 is directly used as V3_2.775V_DIG, which is the supply for the RedCap2, Flash, SRAM, GCAP3, Display, logic lines pull-up and 40-pin connector. V3_2.775V is the filtered V3 supply voltage for the Serial VCC of U1001/WPIC+.

V4 Linear Regulator

V4 is a selectable linear regulator with external pass transistor. It is selectable using the RedCap2 SPIB bus from 1.875V to 2.775V in 4 steps. It is set to 2.775V. V4 is always powered from FILT_3.3V and it is active whenever the radio is turned ON. This regulator is active during POR. V4 supplies via the filtered V4_2.775V the RF sections RFCU, RXU, TXPA and TXFE whilst the LNODCT section has an extra filtered supply voltage V4_LNODCT.

VREF1 Linear Regulator

VREF1 is a programmable linear regulator. It is programmed using the RedCap2 SPIB bus from 0.95V to 2.775V. This regulator is active during POR and its initial value is 2.775V. For this radio, VREF1 is programmed to 2.775V and is supplied by FILT_3.3V. VREF1 is VREF1_2.775V, which is the supply for the AND Gate on TCXO_WARP line.

VREF2 Linear Regulator

VREF2 is a programmable linear regulator. It is programmed using RedCap2 SPIB bus from 0.95V to 2.775V. For this radio, it is programmed to 2.775V which supplies directly (VREF2_2.775_DIG) the backlights and filtered (VREF2_2.775V) the SSC section (Tx/Rx-LED).

TS_REF Linear Regulator

TS_REF is a fixed output linear regulator. It is supplied internally from the V2 linear regulator. It is set to 2.3V. The radio uses TS_REF for the AD voltage dividers. It is not active at POR.

5.5V Linear Regulator

This is an external linear regulator fed by SWB+. It is used to supply GCAP3 DSC regulator and the Battery Interface Circuitry.

DSC Linear Regulator

DSC is a fixed output linear regulator. This regulator is active during POR in the 5V mode. DSC is supplied from an external 5.5V linear regulator. The output voltage is filtered (5V_RF) to supply the WPIC+, 2nd LO PLL-IC and ESCORT-IC charge pump circuits, the PA bias OP and LNODCT_RFOUT circuit.

Current Limit

The SWB+ current limit regulator provides power from the phone battery to clip-on accessories. It is enabled only when the phone is powered up and an accessory which requires power from the phone is connected.

Radio Audio System

See Figure 4.1-12

The audio system consists of the GCAP3 IC (U200) and the DSP (U301), both are located on the main board.

The GCAP3 performs the analog task and part of the digital task of the audio system.

Tx Path

Audio speech is fed either to the internal microphone or the external microphone. The signals reach the GCAP3 IC. In the GCAP3 IC, a fix gain amplifier (A3 or A5) provides the signal amplification, the multiplexer (MUX) selects the active input and the Programmable Gain Amplifier (TxPGA) adjust the path gain according to the radio mode of operation. Finally, the A/D converts the analog signal into digital format and transfers it to the DSP. The DSP performs the functions of audio filtering, ACELP speech compression, forward error correction (FEC), digital modulation, and transfers the data to the RF section. When the radio is operating in the telephone interconnect mode, the DSP performs the required tasks such as echo and noise reduction.

Rx Path

The digital output signal from the receiver is fed to the DSP which performs the functions of digital de-modulation, FEC, ACELP speech de-compression, and audio filtering. It transfers the data to the GCAP3 IC. In this IC, the D/A converts the digital audio format to an analog signal, the Programmable Gain Amplifier (RxPGA) adjusts the path gain according to the setting of the volume control, and the multiplexer routes the audio to the active receive path. The audio is fed to A4, single-ended audio power amplifier. It is then fed to the Audio PA, where most of the amplification is performed and can be selected either to go through the internal speaker or external speaker. Alternatively, the audio from GCAP3 can also be sent through A1 to the internal Earpiece.




Figure 4.1-12 Audio Path - Block Diagram

RS232, SB9600, JTAG

The RedCap2 processor (RCE) uses the three serial protocols: RS232/UART, SB9600, and JTAG to communicate with external devices via the bottom connector of the unit. There is no external hardware for switching from one protocol to another because the RedCap2 handles the switching and line multiplexing functions internally.

Battery ID

The battery is equipped with a Dallas 2502 EPROM. A one-wire serial bus allows the radio or the battery charger to communicate with the battery and identify whether or not the battery is compatible. If the battery is determined to be incompatible, the unit automatically shuts off, and the charger does not enter charging mode.

Besides compatibility data, the EPROM also stores the following information: battery type, capacity, fuel-gauging parameters, and voltage threshold.

Display and Keypad, Detailed Description

Display

The LCD (Liquid Crystal Display) Module is a Graphic Display based upon the KS0741TB-01 display driver.

It consist of LCD Holographic Glass, LED backlight and a 22 pin flex cable connected to the Keypad board.

The Communication to the RedCap2 IC is performed using a SPI protocol (Serial Peripheral Interface). The Operation of the LCD is determined upon the RS line configuration (Data/Command).

The Display is 128X100 (Columns X Rows respectively).

Keypad

The RedCap2 processor (RCE) is responsible for decoding key presses and displaying them properly on the LCD. The keys are arranged into a matrix of five rows and five columns, which includes the Volume and PTT keys.

The PWR key is not decoded by the RCE; it directly drives the GCAP3, which sends a signal to RCE through INT1. The five row lines are pulled high via five internal 22 Kohm resistors. The five row lines and five column lines are fed to RedCap2 I/O pins. Pressing any key also generates the keypad internal interrupt. The RedCap2 debounces the keys by reading them 25 milliseconds later.

The keypad-decoding scheme works as follows:

1. RedCap2 sets rows to inputs; all columns are set as outputs and driven logic low.
2. Rows are pulled logic high. When a key is pressed, one row goes low, which indicates a key press and sends an internal interrupt.
3. RedCap2 reads rows. A low on that row indicates a key press. All others are high.
4. RedCap2 sets all columns to output logic high.
5. One column at a time is set to output logic low. RedCap2 reads the columns to see which one is now at a logic low level.
6. The low row level (in step 3) and low column level (in step 5) indicate the correct column and row.

All keypad circuitry is located on the keypad board. Refer to the keypad board schematics.

Backlight and LEDs

Backlight

The keypad backlight consists of 8 green LEDs. There are 2 more LEDs in the LCD module that are connected in parallel to the keypad LEDs.

Top LEDs

There is a tri-color (Green, Red and Amber when both turns on) LED located on the main board. These LED colors are used as indicators to the radio operation.

Radio Programming

The radio is entered into programming mode by setting the MOD pin high level, and applying a preamble sequence to the radio via the RS232 lines. A 12Vdc can be applied to pin 15 on the 16-pin connector to set the radio into flashing mode.

The MOD pin assertion is encountered at least 4 CKIH cycles before the negation of the Reset pin.

Accessory Connector

The radio provides two connectors for access to personal computers, data devices and audio accessories.

Bottom Connector



The 14-pin bottom connector is intended to support connection to personal computers, and test systems. The bus has seven standard modes of operation: Normal (Nothing Connected), USB Mode, Emergency, PTT, RS232 Mode 4-wire, RS232 8-wire/SSI Mode and SB9600 mode. There are also three additional non-standard modes, KEYLOAD, FLASH, and JTAG, which are used only for secure keyloading, development, factory programming and debugging.

These modes are selected by applying appropriate logic levels to the Option Select pins, named OPTION1 and OPTION2. Some of the modes listed above are selected by the additional application of a level on the USB POWER and CE_ON_OFF pins as well.

Mode Select (OPTION1 and OPTION2)

Logic levels applied to the OPTION1, OPTION2, USB POWER, and ON_OFF/JTAG/FLASH lines are used to select the different modes. The modes will be set as follows:

Table 4.1-1 Bottom Connector Mode Table

| | MODE | ON_OFF/ JTAG/ FLASH | BOTTOM OPTION1 | BOTTOM OPTION2 | USB PWR |
|-------------------|--------------------------|------------------------|--|-------------------|------------|
| Standard Modes | Normal (No Accessory) | 0 | 1 | 1 | 0 |
| | USB Accessory / Computer | 0 | 1 | 1 | >4.0V |
| | Emergency | 0 | 1 | 0 | X |
| | RS-232 (4 wire) / SSI | 0 | *  | | X |
| | PTT (Push To Talk) | 0 | 0 | 0 | X |
| | RS-232 (8 wire) | 0 | 0 | 1 | X |
| | SB9600 | 0 | *  | | X |
| Non | KEYLOAD | 0 | ----- | | X |
| Standard Modes | FLASH | 11.4-12.6 V | X | X | X |
| | JTAG | 7.6-8.4 V | X | X | X |

Note: * Schottky Diode with forward voltage less than 0.4V.

Logic Levels

1 : 2.0V to 2.85V, typical 2.775V

0 : 0V to 0.8V

X : Do Not Care Condition

| Pin No. | Signal Name (Short_Form) | Power/ Default States | USB | RS232/ SSI | RS232 (8 wire) | SB9600 | JTAG |
|---------|---|-----------------------------|-----------------|-----------------|-------------------|-----------------|-----------------|
| 1 | Power Ground (GND) | GND | GND | GND | GND | GND | GND |
| 2 | USB+/TXD (D+)/TDO | | D+ | TXD | TXD | TXD | TDO |
| 3 | USB-/RXD (D-)/TDI | | D- | RXD | RXD | RXD | TDI |
| 4 | USB Power/RTS/Reset_In | | USB_ PWR | RTS | RTS | BUSY IN | RESET_IN |
| 5 | SWB+ | SWB+ | SWB+ | SWB+ | SWB+ | SWB+ | SWB+ |
| 6 | CTS/MCU_DE | | | CTS | CTS | BUSY OUT | MCU_DE |
| 7 | FS/DCD/DSP_DE | | | FS | DCD | | DSP_DE |
| 8 | SCK/RI/TCK | | | SCK | RI | | TCK |
| 9 | SRDA/DTR/TMS | | | SRDA | DTR | | TMS |
| 10 | STDA/DSR/TRST | | | STDA | DSR | | TRST |
| 11 | Bottom_Option_1 (BOT_OPT1) | BOT_ OPT1 | BOT_ OPT1 | BOT_ OPT1 | BOT_ OPT1 | BOT_ OPT1 | BOT_ OPT1 |
| 12 | Bottom_Option_2 (BOT_OPT2) | BOT_ OPT2 | BOT_ OPT2 | BOT_ OPT2 | BOT_ OPT2 | BOT_ OPT2 | BOT_ OPT2 |
| 13 | On_Off/JTAG/FLASH Mode (On_Off/JTAG) | On_Off /JTAG | On_Off /JTAG | On_Off /JTAG | On_Off /JTAG | On_Off /JTAG | On_Off /JTAG |
| 14 | Headset Indication/Key_Fail | Key | Key | HS/Key | Key | Key | |

Table 4.1-2 Bottom Connector Pin Out Table

Side Connector

The side connector is intended to support connection to accessories such as PSM, RSM, Headset, 2 or 4-wire data terminals and SB9600 based devices.

The side connector has 16 modes of operation as shown in Table 4.1-3.

In order to be compatible with previous generation radios, the modes of operation are selected by applying the appropriate logic levels to the Side Option Select Pins named SIDE_OPTION1, SIDE_OPTION2. In addition, SIDE_OPTION3 will be used to select the other modes as per Table 4.1-3. Voltage level for SIDE_OPTION3 is per Table 4.1-4.

Table 4.1-3 Side Connector Mode Table

| | Mode | SIDE OPTION1 | SIDE OPTION2 | SIDE OPTION3 |
|----|---------------------|---------------------|---------------------|---------------------|
| 1 | Ext PTT | 0 | 0 | V4 |
| 2 | Emergency | 0 | 0 | V3 |
| 3 | Volume Up | 0 | 0 | V2 |
| 4 | Volume Down | 0 | 0 | V1 |
| 5 | Man Down | 0 | 0 | V0 |
| 6 | MAP27 | 1 | 0 | V4 |
| 7 | Spare | 1 | 0 | V3 |
| 8 | SB9600/SBEP | 1 | 0 | V2 |
| 9 | 4-Wire Data (RS232) | 1 | 0 | V1 |
| 10 | 2-Wire Data (RS232) | 1 | 0 | V0 |
| 11 | Ext Spkr | 0 | 1 | V4 |
| 12 | RSM with earbud | 0 | 1 | V3 |
| 13 | RSM/PSM | 0 | 1 | V2 |
| 14 | User Programmable 2 | 0 | 1 | V1 |
| 15 | User Programmable1 | 0 | 1 | V0 |
| 16 | Idle | 1 | 1 | V4 |


| Symbol | Min Level/V | Typical/V | Max Level/V |
|---------------|--------------------|------------------|--------------------|
| V0 | 0 | 0.3 | 0.58 |
| V1 | 0.62 | 0.8 | 0.98 |
| V2 | 1.02 | 1.2 | 1.38 |
| V3 | 1.42 | 1.6 | 1.78 |
| V4 | 1.82 | 2.1 | 2.30 |

Table 4.1-4 Voltage Levels for Side Option3


| Pin No. | Signal Name |
|----------------|--------------------|
| 1 | Ext_Speaker+ |
| 2 | Ext_Speaker- |
| 3 | OPT B+ |
| 4 | Ext_Mic |
| 5 | SIDE_OPT2 |
| 6 | SIDE_OPT1 |
| 7 | GND |
| 8 | Rx_Data |
| 9 | Tx_Data |
| 10 | CTS / BUSY_OUT |
| 11 | RTS / BUSY_IN |
| 12 | SIDE_OPT3 |
| 13 | VIBRATOR |

Table 4.1-5 Side Connector Pin Out Table


380-430 MHz Board Layout, Schematics & Parts Lists




380-430 MHz Main Board Top Side PCB No. 8466547A08






380-430 MHz Main Board Bottom Side PCB No. 8466547A08



Digital and RF Block Diagram





DSP, Controller & Memory Schematic Diagram (RedCap2)




| Type of SRAM (U302) | A6 | E3 |
|---------------------|-----|-----|
| 256K x 16 CYPRESS | DNP | DNP |
| 256K x 16 SAMSUNG | X | DNP |
| 512K x 16 CYPRESS | X | DNP |
| 512K x 16 SAMSUNG | X | X |


Bypass Caps for REDCAP



DSP, Controller & Memory Schematic Diagram (Memory)




GCAP (Audio & DC) Schematic Diagram - GCAP3




GCAP (Audio & DC) Schematic Diagram - Periphery


40-PIN CONNECTOR




IO Interface & Connectors
Schematic Diagram - 40 Pin Connector




**IO Interface & Connectors
Schematic Diagram - 16 Pin Connector**




**Switches & Associated Components
Schematic Diagram - Switch**




Switches & Associated Components Schematic Diagram - 24 Pin Connector




RF Section Block Diagram




RXU Schematic Diagram




RF Core Unit Schematic Diagram - WPIC




RF Core Unit Schematic Diagram - 2nd LO




Main VCO Schematic Diagram




TXU Block Diagram



TXU-TX Power Amplifier Schematic Diagram



TXU-TX Front End Schematic Diagram



TXU-ESCORT/TX VCO Schematic Diagram

380-430 MHz Radio Parts List

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---------------------------------------|
| C1001 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1002 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1003 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1004 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1005 | 2113743L29 | Cap Cer Chip 3300pF 10% 16V X7R 0402 |
| C1006 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1007 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1008 | 2113741A49 | Cap Cer Chip 15000pF 5% 50V X7R 0805 |
| C1009 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C1010 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C1011 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1012 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1013 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1014 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1015 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1016 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C1017 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C1018 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C1019 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C1020 | 2113743L01 | Cap Cer Chip 220pF 10% 16V X7R 0402 |
| C1021 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C1022 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C1301 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1302 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1501 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---|
| C1502 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C1504 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C1505 | 2113743N34 | Cap Cer Chip 22.0pF 5% 16V COG 0402 |
| C1506 | 2113743L05 | Cap Cer Chip 330pF 10% 16V X7R 0402 |
| C1511 | 2113743L50 | Cap Cer Chip 33000pF 10% 16V X7R 0402 |
| C1512 | 2113743L33 | Cap Cer Chip 4700pF 10% 16V X7R 0402 |
| C1521 | 2113743N21 | Cap Cer Chip 6.2pF +/-0.5pF 16V COG 0402 |
| C1522 | 2113743N16 | Cap Cer Chip 3.9pF +/-0.25pF 16V COG 0402 |
| C1523 | 2113743N24 | Cap Cer Chip 8.2pF +/-0.5pF 16V COG 0402 |
| C1524 | 2113743N26 | Cap Cer Chip 10.0pF 5% 16V COG 0402 |
| C1525 | 2113743N26 | Cap Cer Chip 10.0pF 5% 16V COG 0402 |
| C1526 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1527 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1541 | 2113743L05 | Cap Cer Chip 330pF 10% 16V X7R 0402 |
| C1542 | 2113743N28 | Cap Cer Chip 12.0pF 5% 16V COG 0402 |
| C1543 | 2113743N30 | Cap Cer Chip 15.0pF 5% 16V COG 0402 |
| C1544 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C1801 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1802 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C1803 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1804 | 2113743N38 | Cap Cer Chip 33.0pF 5% 16V COG 0402 |
| C1805 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C1806 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1807 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C1808 | Not Placed | GCAM Dummy Part Number |
| C1809 | 2113743L29 | Cap Cer Chip 3300pF 10% 16V X7R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---------------------------------------|
| C1810 | 2113743L48 | Cap Cer Chip 22000pF 10% 16V X7R 0402 |
| C1811 | 0885126C07 | Cap 0.1uF Poly |
| C1812 | Not Placed | GCAM Dummy Part Number |
| C1815 | 2113743L29 | Cap Cer Chip 3300pF 10% 16V X7R 0402 |
| C1816 | 2113743N50 | Cap Cer Chip 100pF 5% 16V COG 0402 |
| C1817 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C1820 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| D1521 | 4809877C13 | Diode Varactor ISV305 ESC |
| L1001 | 2462587V38 | Ind Chip 220nH 5% 0805 |
| L1002 | 2462587V38 | Ind Chip 220nH 5% 0805 |
| L1521 | 2413926G15 | Ind Cer Chip 47.0nH 5% 0603 |
| L1522 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| L1541 | 2413926G15 | Ind Cer Chip 47.0nH 5% 0603 |
| Q1521 | 4805793Y01 | Trans Mini Sot NPN NE68519 |
| Q1531 | 4805723X03 | Trans Dual NPN-PNP UMD3N |
| R1001 | 0662057U85 | Res Chip 2.2k 1% 0.063W 0402 |
| R1002 | 0662057U39 | Res Chip 33 1% 0.063W 0402 |
| R1003 | 0662057N23 | Res Chip 100k 5% 0.063W 0402 |
| R1004 | 0662057N23 | Res Chip 100k 5% 0.063W 0402 |
| R1005 | 0662057N23 | Res Chip 100k 5% 0.063W 0402 |
| R1301 | 0662057M78 | Res Chip 1500 5% 0.063W 0402 |
| R1511 | 0662057M90 | Res Chip 4700 5% 0.063W 0402 |
| R1512 | 0662057U85 | Res Chip 2.2k 1% 0.063W 0402 |
| R1521 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R1522 | 0662057M60 | Res Chip 270 5% 0.063W 0402 |
| R1523 | 0662057M90 | Res Chip 4700 5% 0.063W 0402 |
| R1524 | 0662057M50 | Res Chip 100 5% 0.063W 0402 |
| R1802 | 0662057M54 | Res Chip 150 5% 0.063W 0402 |
| R1803 | 0662057M58 | Res Chip 220 5% 0.063W 0402 |
| R1804 | 0662057U39 | Res Chip 33 1% 0.063W 0402 |
| R1805 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R1807 | 0662057M90 | Res Chip 4700 5% 0.063W 0402 |
| R1810 | 0662057U39 | Res Chip 33 1% 0.063W 0402 |
| SH1000 | 2666510A02 | Shield, RFCU - WPI |
| SH1500 | 2686118Z01 | Primary Shield, 2ND LO |
| U1001 | 5185368C21 | WPIC Plus |
| U1501 | 5186226J12 | LMX2332 |
| Y1301 | 5102463J73 | KT19 16.8MHz TCXO 1ppm |
| C2001 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C2002 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C2100 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C2101 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---|
| C2200 | 2113743N28 | Cap Cer Chip 12.0pF 5% 16V COG 0402 |
| C2201 | 2113743N30 | Cap Cer Chip 15.0pF 5% 16V COG 0402 |
| C2202 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C2203 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C2204 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C2205 | 2113743N38 | Cap Cer Chip 33.0pF 5% 16V COG 0402 |
| C2206 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C2207 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C2208 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C2209 | 2113740F09 | Cap Cer Chip 1.8pF +/-0.1pF NPO 50V 0603 |
| C2210 | 2113740L02 | Cap Cer Chip 2.2pF +/-0.1pF NPO 50V 0603 |
| C2300 | 2113740L11 | Cap Cer Chip 5.1pF +/-0.1pF NPO 50V 0603 |
| C2301 | 2113740F02 | Cap Cer Chip 0.75pF +/-0.1pF NPO 50V 0603 |
| C2302 | 2113740L17 | Cap Cer Chip 9.1pF +/-0.1pF NPO 50V 0603 |
| C2303 | 2113740L09 | Cap Cer Chip 4.3pF +/-0.1pF NPO 50V 0603 |
| C2304 | 2113740L17 | Cap Cer Chip 9.1pF +/-0.1pF NPO 50V 0603 |
| C2305 | 2113740L05 | Cap Cer Chip 3.0pF +/-0.1pF NPO 50V 0603 |
| C2306 | 2113740L11 | Cap Cer Chip 5.1pF +/-0.1pF NPO 50V 0603 |
| C2400 | 2113740L40 | Cap Cer Chip 82.0pF 2% NPO 50V 0603 |
| C2401 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C2402 | 2113740L20 | Cap Cer Chip 12.0pF 2% NPO 50V 0603 |
| C2403 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C2404 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C2405 | 2113740L20 | Cap Cer Chip 12.0pF 2% NPO 50V 0603 |
| C2406 | 2113741F41 | Cap Cer Chip 4700pF 5% 50V X7R 0603 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C2407 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C2408 | 2113743N38 | Cap Cer Chip 33.0pF 5% 16V COG 0402 |
| C2500 | 2113740L02 | Cap Cer Chip 2.2pF +/-0.1pF NPO 50V 0603 |
| C2501 | 2113740L02 | Cap Cer Chip 2.2pF +/-0.1pF NPO 50V 0603 |
| C2502 | 2113740L02 | Cap Cer Chip 2.2pF +/-0.1pF NPO 50V 0603 |
| C2503 | 2113740L12 | Cap Cer Chip 5.6pF +/-0.1pF NPO 50V 0603 |
| C2504 | 2113740L18 | Cap Cer Chip 10.0pF +/-0.25pF NPO 50V 0603 |
| C2505 | 2113740L18 | Cap Cer Chip 10.0pF +/-0.25pF NPO 50V 0603 |
| C2506 | 2113740L34 | Cap Cer Chip 47.0pF 2% NPO 50V 0603 |
| D2100 | 4813825A19 | Diode Schottky Barrier Series |
| E2100 | 2480640Z01 | C/IND BK1005HM471 Bead |
| E2200 | 2480640Z01 | C/IND BK1005HM471 Bead |
| E2400 | 2480640Z01 | C/IND BK1005HM471 Bead |
| FL2100 | 9166508A01 | Tuneable Chip Multilayer LC Filter |
| FL2500 | 9186323Z01 | FLTR 3 POL SURF MT XTAL 109.65MHz TOYOCOM |
| L2001 | 2409377M36 | Ind Chip WW 220nH 5% 0603 |
| L2200 | 2409377M06 | Ind Chip WW 15nH 5% 0603 |
| L2201 | 2462587V30 | Ind Chip 47nH 5% 0805 |
| L2202 | 2462587V28 | Ind Chip 33nH 5% 0805 |
| L2300 | 2413923B15 | Ind Chip 22nH 2% 805CS |
| L2301 | 2413923B24 | Ind Chip 15nH 2% 805CS |
| L2302 | 2413923B24 | Ind Chip 15nH 2% 805CS |
| L2400 | 2462587V30 | Ind Chip 47nH 5% 0805 |
| L2401 | 2462587V30 | Ind Chip 47nH 5% 0805 |
| L2402 | 2462587V23 | Ind Chip 12nH 5% 0805 |
| L2403 | 2462587V23 | Ind Chip 12nH 5% 0805 |
| L2500 | 2413926K31 | Ind Cer Chip 470nH 5% 0805 |
| L2501 | 2413926K31 | Ind Cer Chip 470nH 5% 0805 |
| L2502 | 2409377M36 | Ind Chip WW 220nH 5% 0603 |
| L2503 | 2409377M36 | Ind Chip WW 220nH 5% 0603 |
| Q2200 | 4805723X03 | Trans Dual NPN-PNP UMD3N |
| Q2400 | 4809939C06 | Tstr Dual PNP/NPN UMZ2N |
| R2200 | 0662057M26 | Res Chip 10 5% 0.063W 0402 |
| R2201 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R2202 | 0662057M72 | Res Chip 820 5% 0.063W 0402 |
| R2400 | 0662057M62 | Res Chip 330 5% 0.063W 0402 |
| R2401 | 0662057U31 | Res Chip 15 1% 0.063W 0402 |
| R2402 | 0662057M62 | Res Chip 330 5% 0.063W 0402 |
| R2403 | 0662057M68 | Res Chip 560 5% 0.063W 0402 |
| R2404 | 0662057M62 | Res Chip 330 5% 0.063W 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---|
| R2405 | 0662057U31 | Res Chip 15 1% 0.063W 0402 |
| R2406 | 0662057M62 | Res Chip 330 5% 0.063W 0402 |
| R2407 | 0662057M80 | Res Chip 1800 5% 0.063W 0402 |
| R2408 | 0662057U89 | Res Chip 3.3k 1% 0.063W 0402 |
| R2409 | 0662057U89 | Res Chip 3.3k 1% 0.063W 0402 |
| R2410 | 0662057M80 | Res Chip 1800 5% 0.063W 0402 |
| SH2001 | 2666513A02 | Shield, RXU - IF |
| SH2002 | 2666512A02 | Shield, RXU - RF |
| U2200 | 5185368C01 | IC 3V Low Noise AMP RC2361 |
| U2400 | 5108428S91 | Linear Mixer CMY211 |
| C3001 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C3002 | 2113740F51 | Cap Cer Chip 100pF 5% NPO 50V 0603 |
| C3003 | 2113743N53 | Cap Cer Chip 130pF 5% 16V COG 0402 |
| C3005 | 2104801Z32 | Cap Cer Chip 15.0pF 2% HF16V 0402 |
| C3006 | 2104801Z10 | Cap Cer Chip 1.5pF +/-0.1pF HF16V 0402 |
| C3007 | 2104801Z32 | Cap Cer Chip 15.0pF 2% HF16V 0402 |
| C3008 | 2104801Z27 | Cap Cer Chip 7.5pF +/-0.25pF HF16V 0402 |
| C3009 | 2104801Z31 | Cap Cer Chip 12.0pF +/-0.25pF HF16V 0402 |
| C3011 | 2104801Z28 | Cap Cer Chip 8.2pF +/-0.25pF HF16V 0402 |
| C3012 | 2104801Z26 | Cap Cer Chip 6.8pF +/-0.25pF HF16V 0402 |
| C3013 | 2113740F51 | Cap Cer Chip 100pF 5% NPO 50V 0603 |
| C3014 | 2113743N53 | Cap Cer Chip 130pF 5% 16V COG 0402 |
| C3015 | 2104801Z30 | Cap Cer Chip 0.75pF +/-0.1pF HF16V 0402 |
| C3016 | 2113743N53 | Cap Cer Chip 130pF 5% 16V COG 0402 |
| C3017 | 2113743N53 | Cap Cer Chip 130pF 5% 16V COG 0402 |
| C3018 | 2113743N10 | Cap Cer Chip 2.2pF +/-0.25pF 16V COG 0402 |
| C3019 | 2104801Z32 | Cap Cer Chip 15.0pF 2% HF16V 0402 |
| C3020 | 2104801Z32 | Cap Cer Chip 15.0pF 2% HF16V 0402 |
| C3021 | 2113743N53 | Cap Cer Chip 130pF 5% 16V COG 0402 |
| C3022 | 2113743N14 | Cap Cer Chip 3.3pF +/-0.25pF 16V COG 0402 |
| C3023 | Not Placed | GCAM Dummy Part Number |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---------------------------------------|
| C3024 | 2104801Z32 | Cap Cer Chip 15.0pF 2% HF16V 0402 |
| C3025 | 2104801Z32 | Cap Cer Chip 15.0pF 2% HF16V 0402 |
| C3026 | 2311049A59 | Cap Tant Chip 10uF 10% 6V A |
| C3028 | 2113743L48 | Cap Cer Chip 22000pF 10% 16V X7R 0402 |
| C3029 | 2113743L48 | Cap Cer Chip 22000pF 10% 16V X7R 0402 |
| D3001 | 4809877C13 | Diode Varactor ISV305 ESC |
| D3002 | 4809877C13 | Diode Varactor ISV305 ESC |
| D3003 | 4809877C13 | Diode Varactor ISV305 ESC |
| E3001 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| L3001 | 2462587V41 | Ind Chip 390nH 10% 0805 |
| L3002 | 2462587V41 | Ind Chip 390nH 10% 0805 |
| L3003 | 2462587V41 | Ind Chip 390nH 10% 0805 |
| L3004 | 2462587V41 | Ind Chip 390nH 10% 0805 |
| L3005 | 2462587V22 | Ind Chip 8.2nH 5% 0805 |
| L3006 | 2462587V22 | Ind Chip 8.2nH 5% 0805 |
| Q3001 | 4809939C06 | Tstr Dual PNP/NPN UMZ2N |
| Q3002 | 4805793Y01 | Trans Mini SOT NPN NE68519 |
| Q3003 | 4805793Y01 | Trans Mini SOT NPN NE68519 |
| Q3004 | 4805793Y01 | Trans Mini SOT NPN NE68519 |
| R3001 | 0662057N33 | Res Chip 270k 5% 0.063W 0402 |
| R3002 | 0662057N23 | Res Chip 100k 5% 0.063W 0402 |
| R3003 | Not Placed | GCAM Dummy Part Number |
| R3004 | 0662057U85 | Res Chip 2.2k 1% 0.063W 0402 |
| R3005 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R3006 | 0662057M18 | Res Chip 4.7 5% 0.063W 0402 |
| R3007 | 0662057U87 | Res Chip 2.7k 1% 0.063W 0402 |
| R3008 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R3009 | 0662057M01 | Res Chip 0 5% 0.063W 0402 |
| R3010 | 0662057M62 | Res Chip 330 5% 0.063W 0402 |
| R3013 | 0662057M41 | Res Chip 43 5% 0.063W 0402 |
| R3014 | 0662057N07 | Res Chip 22k 5% 0.063W 0402 |
| R3015 | 0662057M41 | Res Chip 43 5% 0.063W 0402 |
| R3016 | 0662057N07 | Res Chip 22k 5% 0.063W 0402 |
| R3017 | 0662057M34 | Res Chip 22 5% 0.063W 0402 |
| R3018 | 0662057M34 | Res Chip 22 5% 0.063W 0402 |
| SH3001 | 2666514A02 | Shield, Main VCO |
| Y3001 | 4805911Z14 | Ind Coaxial Ceramic 1100 MHz |
| C4001 | 2113743L48 | Cap Cer Chip 22000pF 10% 16V X7R 0402 |
| C4003 | 2113743P01 | Cap Cer Chip 180pF 5% 16V COH 0402 |
| C4005 | 2113743L05 | Cap Cer Chip 330pF 10% 16V X7R 0402 |
| C4006 | 2113743L48 | Cap Cer Chip 22000pF 10% 16V X7R 0402 |
| C4007 | 2113743L48 | Cap Cer Chip 22000pF 10% 16V X7R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C4008 | 2113743L05 | Cap Cer Chip 330pF 10% 16V X7R 0402 |
| C4009 | 2113743N30 | Cap Cer Chip 15.0pF 5% 16V COG 0402 |
| C4011 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 |
| C4012 | 2113743L48 | Cap Cer Chip 22000pF 10% 16V X7R 0402 |
| C4013 | 2113743L05 | Cap Cer Chip 330pF 10% 16V X7R 0402 |
| C4014 | 2113743L05 | Cap Cer Chip 330pF 10% 16V X7R 0402 |
| C4015 | 2113740L20 | Cap Cer Chip 12.0pF 2% NPO 50V 0603 |
| C4018 | 2113743P01 | Cap Cer Chip 180pF 5% 16V COH 0402 |
| C4019 | 2113740F61 | Cap Cer Chip 270pF 5% NPO 50V 0603 |
| C4020 | 2113743P01 | Cap Cer Chip 180pF 5% 16V COH 0402 |
| C4021 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C4022 | 2113743P01 | Cap Cer Chip 180pF 5% 16V COH 0402 |
| C4024 | 2113740L28 | Cap Cer Chip 27.0pF 2% NPO 50V 0603 |
| C4026 | 2113743P01 | Cap Cer Chip 180pF 5% 16V COH 0402 |
| C4028 | 2113740L34 | Cap Cer Chip 47.0pF 2% NPO 50V 0603 |
| C4030 | 2113743F16 | Cap Cer Chip 1.0uF +80/-20% 16V Y5V 0805 |
| C4031 | Not Placed | GCAM Dummy Part Number |
| C4033 | 2113740L18 | Cap Cer Chip 10.0pF +/-0.25pF NPO 50V 0603 |
| C4035 | 2311049C49 | Cap Tant Chip 100uF 10% 16V D |
| C4036 | 2311049C49 | Cap Tant Chip 100uF 10% 16V D |
| C4037 | 2311049C49 | Cap Tant Chip 100uF 10% 16V D |
| C4042 | 2113740L28 | Cap Cer Chip 27.0pF 2% NPO 50V 0603 |
| C4043 | 2113740L28 | Cap Cer Chip 27.0pF 2% NPO 50V 0603 |
| C4050 | 2113743P01 | Cap Cer Chip 180pF 5% 16V COH 0402 |
| C4051 | Not Placed | GCAM Dummy Part Number |
| C4052 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C4100 | 2113743P01 | Cap Cer Chip 180pF 5% 16V COH 0402 |
| C4101 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| E4002 | 7608671Y02 | Ferrite Bead 500 OHM SMD Pkg |
| L4003 | 2413926N29 | Ind Cer Chip 270nH 5% 0603 |
| L4005 | 2413926N29 | Ind Cer Chip 270nH 5% 0603 |
| L4006 | 2409377M14 | Ind Chip WW 68nH 5% 0603 |
| L4007 | 2409377M05 | Ind Chip WW 12nH 5% 0603 |
| L4008 | 2462587V64 | Ind Chip 5.6nH 5% 0805 |
| L4009 | 2409414M37 | Ind Chip WW 18nH 10% 0805 |
| L4010 | 2462587V64 | Ind Chip 5.6nH 5% 0805 |
| L4011 | 2409377M17 | Ind Chip WW 100nH 5% 0603 |
| L4100 | 2413926N29 | Ind Cer Chip 270nH 5% 0603 |
| M4001 | 2680499Z01 | Heat Spreader |
| Q4001 | 4813828A09 | Tstr 8W 450MHZ 7.5V MRF1517 |
| Q4100 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 |
| R4001 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R4002 | 0662057M57 | Res Chip 200 5% 0.063W 0402 |
| R4003 | 0662057N07 | Res Chip 22k 5% 0.063W 0402 |
| R4004 | 0662057A13 | Res Chip 33 5% 0.1W 0603 |
| R4005 | 0662057A13 | Res Chip 33 5% 0.1W 0603 |
| R4006 | 0662057M57 | Res Chip 200 5% 0.063W 0402 |
| R4007 | 0662057M50 | Res Chip 100 5% 0.063W 0402 |
| R4008 | 0662057B55 | Res Chip 2.0 5% 0.1W 0603 |
| R4009 | 0662057M26 | Res Chip 10 5% 0.063W 0402 |
| R4010 | 0662057A13 | Res Chip 33 5% 0.1W 0603 |
| R4012 | 0662057N07 | Res Chip 22k 5% 0.063W 0402 |
| R4016 | 0662057M57 | Res Chip 200 5% 0.063W 0402 |
| R4018 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R4100 | Not Placed | GCAM Dummy Part Number |
| R4101 | 0662057M01 | Res Chip 0 5% 0.063W 0402 |
| R4102 | Not Placed | GCAM Dummy Part Number |
| RT4001 | 0686931J01 | Thermistor 47k |
| SH4001 | 2666515A02 | Shield, TXPA - Driver |
| SH4002 | 2666516A03 | Shield, TXPA - PA |
| U4001 | 5185130C65 | IC VHF/UHF/800 MHZ LDMOS Driver 30C65 |
| U4002 | 5162852A09 | Low Pwr OP AMP LMC7101BI |
| U4100 | 5162852A09 | Low Pwr OP AMP LMC7101BI |
| U4102 | 5102463J79 | MAX5401 Low-Drift Digital Potentiometer |
| C5001 | 2113743L05 | Cap Cer Chip 330pF 10% 16V X7R 0402 |
| C5002 | 2113743N30 | Cap Cer Chip 15.0pF 5% 16V COG 0402 |
| C5003 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C5005 | 2113740F63 | Cap Cer Chip 330pF 5% NPO 50V 0603 |
| C5006 | 2113740L14 | Cap Cer Chip 6.8pF +/-0.1pF NPO 50V 0603 |
| C5007 | 2113743P01 | Cap Cer Chip 180pF 5% 16V COH 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C5008 | 2113740L12 | Cap Cer Chip 5.6pF +/-0.1pF NPO 50V 0603 |
| C5009 | 2113740F63 | Cap Cer Chip 330pF 5% NPO 50V 0603 |
| C5010 | 2113740F63 | Cap Cer Chip 330pF 5% NPO 50V 0603 |
| C5011 | 2113740L14 | Cap Cer Chip 6.8pF +/-0.1pF NPO 50V 0603 |
| C5012 | 2113740F57 | Cap Cer Chip 180pF 5% NPO 50V 0603 |
| C5013 | 2113740F57 | Cap Cer Chip 180pF 5% NPO 50V 0603 |
| C5014 | 2113740F63 | Cap Cer Chip 330pF 5% NPO 50V 0603 |
| C5015 | 2113740F03 | Cap Cer Chip 1.0pF +/-0.1pF NPO 50V 0603 |
| C5016 | 2113740L10 | Cap Cer Chip 4.7pF +/-0.1pF NPO 50V 0603 |
| C5018 | 2113740F63 | Cap Cer Chip 330pF 5% NPO 50V 0603 |
| C5019 | 2113740F01 | Cap Cer Chip 0.5pF +/-0.1pF NPO 50V 0603 |
| C5020 | 2113740L14 | Cap Cer Chip 6.8pF +/-0.1pF NPO 50V 0603 |
| C5021 | 2113740F03 | Cap Cer Chip 1.0pF +/-0.1pF NPO 50V 0603 |
| C5022 | 2113740F03 | Cap Cer Chip 1.0pF +/-0.1pF NPO 50V 0603 |
| D5001 | 4809948D12 | Diode RF Switch BAR63-02W |
| D5002 | 4809948D12 | Diode RF Switch BAR63-02W |
| D5003 | 4809948D13 | Diode RF Switch BA892 ESC |
| FL5001 | 5804901K14 | 380-430 MHZ ISOLATOR |
| J5001 | 2880658Z03 | Connector (SMA) |
| L5003 | 2462587V38 | IND CHIP 220nH 5% 0805 |
| L5004 | 2462587V26 | IND CHIP 22nH 5% 0805 |
| L5005 | 7686949J02 | Ferrite Bead Chip-0402 SIZE |
| L5006 | 2409414M31 | IND CHIP WW 150nH 2% 0805 |
| L5007 | 2462587V27 | IND CHIP 27nH 5% 0805 |
| L5008 | 2462587V24 | IND CHIP 15nH 5% 0805 |
| L5010 | 2462587V38 | IND CHIP 220nH 5% 0805 |
| L5011 | 2462587V25 | IND CHIP 18nH 5% 0805 |
| Q5001 | 4809939C06 | Tstr Dual PNP/NPN UMZ2N |
| R5001 | 0662057M54 | Res Chip 150 5% 0.063W 0402 |
| R5002 | 0662057M46 | Res Chip 68 5% 0.063W 0402 |
| R5003 | 0662057M54 | Res Chip 150 5% 0.063W 0402 |
| R5004 | 0662057A18 | Res Chip 51 5% 0.1W 0603 |
| R5005 | 0662057N47 | Res Chip 1M 5% 0.063W 0402 |
| R5006 | 0662057U43 | Res Chip 47 1% 0.063W 0402 |
| R5007 | 0662057N23 | Res Chip 100k 5% 0.063W 0402 |
| R5008 | 0662057M52 | Res Chip 120 5% 0.063W 0402 |
| R5010 | 0662057U89 | Res Chip 3.3k 1% 0.063W 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---|
| R5011 | 0662057M80 | Res Chip 1800 5% 0.063W 0402 |
| R5012 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R5013 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R5014 | 0662057A79 | Res Chip 18k 5% 0.1W 0603 |
| SH5001 | 2666517A02 | Shield, TXFE - ANT Switch |
| U5001 | 5866504A01 | 400/500MHZ Band Chip Direct Coupler |
| C6001 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6002 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6003 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6004 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6005 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6006 | 2113740L24 | Cap Cer Chip 18.0pF 2% NPO 50V 0603 |
| C6007 | 2113740L22 | Cap Cer Chip 15.0pF 2% NPO 50V 0603 |
| C6008 | 2113740L12 | Cap Cer Chip 5.6pF +/-0.1pF NPO 50V 0603 |
| C6009 | 2113740L04 | Cap Cer Chip 2.7pF +/-0.1pF NPO 50V 0603 |
| C6010 | 2113740L12 | Cap Cer Chip 5.6pF +/-0.1pF NPO 50V 0603 |
| C6011 | 2113740L22 | Cap Cer Chip 15.0pF 2% NPO 50V 0603 |
| C6012 | 2113740L24 | Cap Cer Chip 18.0pF 2% NPO 50V 0603 |
| C6013 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6014 | 2113743N11 | Cap Cer Chip 2.4pF +/-0.25pF 16V COG 0402 |
| C6015 | 2113743N11 | Cap Cer Chip 2.4pF +/-0.25pF 16V COG 0402 |
| C6016 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6017 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6018 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6019 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6020 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6021 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6022 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---|
| C6023 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6024 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6025 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6026 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C6027 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6029 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6030 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6031 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6032 | 2113743N07 | Cap Cer Chip 1.5pF +/-0.25pF 16V COG 0402 |
| C6033 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6034 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6035 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6036 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6037 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6038 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6039 | 2113743E07 | Cap Cer Chip .022uF 10% 16V X7R 0603 |
| C6040 | 2113741F45 | Cap Cer Chip 6800pF 5% 50V X7R 0603 |
| C6041 | 2113743E03 | Cap Cer Chip .015uF 10% 16V X7R 0603 |
| C6042 | 2113743E03 | Cap Cer Chip .015uF 10% 16V X7R 0603 |
| C6043 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6044 | 2113743E05 | Cap Cer Chip .018uF 10% 16V X7R 0603 |
| C6045 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6046 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6047 | 2113743E05 | Cap Cer Chip .018uF 10% 16V X7R 0603 |
| C6048 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---|
| C6049 | 2113741F41 | Cap Cer Chip 4700pF 5% 50V X7R 0603 |
| C6050 | 2113741F41 | Cap Cer Chip 4700pF 5% 50V X7R 0603 |
| C6051 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C6052 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6053 | 2113740L22 | Cap Cer Chip 15.0pF 2% NPO 50V 0603 |
| C6055 | 2113743N17 | Cap Cer Chip 4.3pF +/-0.25pF 16V COG 0402 |
| C6056 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C6057 | 2113743N12 | Cap Cer Chip 2.7pF +/-0.25pF 16V COG 0402 |
| E6001 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E6002 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| L6002 | 2409377M17 | Ind Chip WW 100nH 5% 0603 |
| L6003 | 2413923B23 | Ind Chip 12nH 2% 805CS |
| L6004 | 2413923B23 | Ind Chip 12nH 2% 805CS |
| L6005 | 2409377M17 | Ind Chip WW 100nH 5% 0603 |
| L6006 | 2409377M17 | Ind Chip WW 100nH 5% 0603 |
| L6008 | Not Placed | GCAM Dummy Part Number |
| L6009 | 2409154M20 | Ind Cer Chip 39nH 5% 0402 |
| Q6001 | 4802197J95 | TSTR NPN PBR941 |
| Q6002 | 4809939C06 | TSTR Dual PNP/NPN UMZ2N |
| R6001 | 0662057M40 | Res Chip 39 5% 0.063W 0402 |
| R6002 | 0662057M54 | Res Chip 150 5% 0.063W 0402 |
| R6003 | 0662057M54 | Res Chip 150 5% 0.063W 0402 |
| R6004 | 0662057M46 | Res Chip 68 5% 0.063W 0402 |
| R6005 | 0662057M62 | Res Chip 330 5% 0.063W 0402 |
| R6006 | 0662057M66 | Res Chip 470 5% 0.063W 0402 |
| R6008 | 0662057U31 | Res Chip 15 1% 0.063W 0402 |
| R6009 | 0662057U31 | Res Chip 15 1% 0.063W 0402 |
| R6010 | 0662057U31 | Res Chip 15 1% 0.063W 0402 |
| R6011 | 0662057M44 | Res Chip 56 5% 0.063W 0402 |
| R6012 | 0662057M44 | Res Chip 56 5% 0.063W 0402 |
| R6013 | 0662057M44 | Res Chip 56 5% 0.063W 0402 |
| R6014 | 0662057M58 | Res Chip 220 5% 0.063W 0402 |
| R6015 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R6016 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R6017 | 0662057M66 | Res Chip 470 5% 0.063W 0402 |
| R6018 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R6019 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R6020 | 0662057U39 | Res Chip 33 1% 0.063W 0402 |
| R6021 | 0662057U39 | Res Chip 33 1% 0.063W 0402 |
| R6022 | 0662057U39 | Res Chip 33 1% 0.063W 0402 |
| R6023 | 0662057U39 | Res Chip 33 1% 0.063W 0402 |
| R6024 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R6025 | 0662057M18 | Res Chip 4.7 5% 0.063W 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| R6026 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R6029 | Not Placed | GCAM Dummy Part Number |
| SH6001 | 2666518A02 | Shield, TXU - LNODECT2 |
| SH6002 | 2666519A02 | Shield, TXU - LNODECT |
| T6001 | 2580443L04 | Transformer BALUN |
| U6001 | 5880334L02 | 450MHZ 90 Deg Splitter |
| U6002 | 5108428S43 | Low Noise ODC T |
| C7001 | 2311049A59 | CAP TANT CHIP 10uF 10% 6V A |
| C7002 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C7003 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C7011 | 2113743E03 | Cap Cer Chip .015uF 10% 16V X7R 0603 |
| C7012 | 2113743L21 | Cap Cer Chip 1500pF 10% 16V X7R 0402 |
| C7021 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C7022 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C7031 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C7501 | Not Placed | GCAM Dummy Part Number |
| C7502 | 2113740L20 | Cap Cer Chip 12.0pF 2% NPO 50V 0603 |
| C7503 | 2113740L09 | Cap Cer Chip 4.3pF +/-0.1pF NPO 50V 0603 |
| C7504 | 2113740L14 | Cap Cer Chip 6.8pF +/-0.1pF NPO 50V 0603 |
| C7505 | 2113740L13 | Cap Cer Chip 6.2pF +/-0.1pF NPO 50V 0603 |
| C7506 | 2113740F01 | Cap Cer Chip 0.5pF +/-0.1pF NPO 50V 0603 |
| C7507 | 2113743N48 | Cap Cer Chip 82.0pF 5% 16V COG 0402 |
| C7508 | Not Placed | GCAM Dummy Part Number |
| C7509 | 2113743N42 | Cap Cer Chip 47.0pF 5% 16V COG 0402 |
| C7510 | 2113740L12 | Cap Cer Chip 5.6pF +/-0.1pF NPO 50V 0603 |
| C7511 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C7512 | 2311049C18 | CAP TANT CHIP 4.7uF 10% 6V LP(A) |
| C7513 | 2113743E12 | Cap Cer Chip .047uF 10% 16V X7R 0603 |
| C7514 | 2113740L02 | Cap Cer Chip 2.2pF +/-0.1pF NPO 50V 0603 |
| D7501 | 4809877C13 | Diode Varactor ISV305 ESC |
| D7502 | 4809877C13 | Diode Varactor ISV305 ESC |
| D7503 | 4862824C01 | Diode Varactor 1SV229 USC |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---------------------------------|
| D7504 | 4862824C01 | Diode Varactor 1SV229 USC |
| D7505 | 4809877C13 | Diode Varactor ISV305 ESC |
| L7501 | 2462587W03 | Ind Chip 17nH 5% 1206 |
| L7502 | 2462587V18 | Ind Chip 180nH 10% 0805 |
| L7503 | 2462587V18 | Ind Chip 180nH 10% 0805 |
| L7504 | 2462587V18 | Ind Chip 180nH 10% 0805 |
| L7505 | 2462587V18 | Ind Chip 180nH 10% 0805 |
| L7506 | 2462587V34 | Ind Chip 100nH 5% 0805 |
| L7507 | 2462587V29 | Ind Chip 39nH 5% 0805 |
| L7508 | 2462587V44 | Ind Chip 680nH 10% 0805 |
| Q7021 | 4805723X02 | Trans Dual PNP UMT1N |
| Q7022 | 4805723X02 | Trans Dual PNP UMT1N |
| Q7023 | 4805793Y01 | Trans Mini SOT NPN NE68519 |
| Q7024 | 4805793Y01 | Trans Mini SOT NPN NE68519 |
| Q7501 | 4805793Y01 | Trans Mini SOT NPN NE68519 |
| Q7502 | 4805793Y01 | Trans Mini SOT NPN NE68519 |
| Q7503 | 4805793Y01 | Trans Mini SOT NPN NE68519 |
| Q7504 | 4809939C06 | Tstr Dual PNP/NPN UMZ2N |
| R7001 | 0662057M56 | Res Chip 180 5% 0.063W 0402 |
| R7002 | 0662057U39 | Res Chip 33 1% 0.063W 0402 |
| R7003 | 0662057M40 | Res Chip 39 5% 0.063W 0402 |
| R7004 | 0662057N23 | Res Chip 100k 5% 0.063W 0402 |
| R7005 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R7011 | 0662057M48 | Res Chip 82 5% 0.063W 0402 |
| R7021 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R7022 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R7023 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R7024 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R7031 | 0662057M44 | Res Chip 56 5% 0.063W 0402 |
| R7501 | 0662057U91 | Res Chip 3.9k 1% 0.063W 0402 |
| R7502 | 0662057U85 | Res Chip 2.2k 1% 0.063W 0402 |
| R7503 | 0662057U43 | Res Chip 47 1% 0.063W 0402 |
| R7504 | 0662057M18 | Res Chip 4.7 5% 0.063W 0402 |
| R7505 | 0662057U89 | Res Chip 3.3k 1% 0.063W 0402 |
| R7506 | 0662057U43 | Res Chip 47 1% 0.063W 0402 |
| R7507 | 0662057U31 | Res Chip 15 1% 0.063W 0402 |
| R7508 | 0662057U85 | Res Chip 2.2k 1% 0.063W 0402 |
| R7509 | 0662057U31 | Res Chip 15 1% 0.063W 0402 |
| R7510 | 0662057U87 | Res Chip 2.7k 1% 0.063W 0402 |
| R7511 | 0662057U31 | Res Chip 15 1% 0.063W 0402 |
| R7512 | 0662057M44 | Res Chip 56 5% 0.063W 0402 |
| R7513 | 0662057M26 | Res Chip 10 5% 0.063W 0402 |
| R7514 | 0662057M40 | Res Chip 39 5% 0.063W 0402 |
| R7515 | 0662057M32 | Res Chip 18 5% 0.063W 0402 |
| R7516 | 0662057N23 | Res Chip 100k 5% 0.063W 0402 |
| R7517 | 0662057U85 | Res Chip 2.2k 1% 0.063W 0402 |
| R7518 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| SH7000 | 2666520A02 | Shield, ESCORT/TXVCO |
| U7001 | 5185368C18 | ESCORT IC IN 16 PIN QFN Package |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C001 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C002 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C003 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C004 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C005 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C006 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C007 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C009 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C010 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C011 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C012 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C013 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C016 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C017 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C018 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C019 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C024 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C025 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C026 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C027 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C030 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C031 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C032 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C033 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C034 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 |

| Circuit Ref | Motorola Part No. | Description | Circuit Ref | Motorola Part No. | Description | Circuit Ref | Motorola Part No. | Description | Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|-------------|-------------------|---|-------------|-------------------|-------------------------------------|-------------|-------------------|---------------------------------------|
| C035 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | C105 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 | C138 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | R130 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| C036 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | C112 | 2113743N38 | Cap Cer Chip 33.0pF 5% 16V COG 0402 | C139 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | R131 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| C037 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | C113 | 2113743N38 | Cap Cer Chip 33.0pF 5% 16V COG 0402 | D100 | 4802245J47 | Diode Schottky Barrier RB471E | R132 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| C038 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | C114 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 | D101 | 4802245J47 | Diode Schottky Barrier RB471E | RV101 | 0686407Z01 | TRANSORB Diode V5.5MLA 0603 |
| D001 | 4809118D03 | Led Red/Grn 2X3MM SMD LNJ123W8P0MT | C115 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | E101 | 2480675U01 | 0805 Chip-3Amp | S100 | 4070354A01 | Light Touch Switch-SMD |
| E001 | 2486132Z01 | BK20104M601 Ferrite Bead Array | C116 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | E102 | 2480675U01 | 0805 Chip-3Amp | U100 | 9185759B01 | Fltr RC Network |
| E002 | 2486132Z01 | BK20104M601 Ferrite Bead Array | C117 | 2113743K16 | Cap Cer Chip .022uF +80/-20% 16V Y5V 0603 | E103 | 2409134J04 | Ind Chip Fer Fltr 600 0603 | U101 | 9185759B01 | Fltr RC Network |
| J001 | 0986237A02 | Connector (Contact Battery) | C118 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | E104 | 2409134J04 | Ind Chip Fer Fltr 600 0603 | U102 | 9185759B01 | Fltr RC Network |
| J002 | 0986017Z01 | Connector, 24 Pin Socket | C119 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | E105 | 2409134J04 | Ind Chip Fer Fltr 600 0603 | U106 | 5109522E22 | IC Sngl And Gate TC7S08FU |
| R001 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | C120 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 | E106 | 2480675U01 | 0805 Chip-3Amp | U107 | 5105625U75 | IC CMOS Inverter TC7WU04FU |
| R002 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | C121 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 | E107 | 2480675U01 | 0805 Chip-3Amp | U108 | 5180508F01 | IC NOR Gate Unbuffered TC7W02FU |
| R003 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C122 | 2186133Z01 | Capacitor Array 33pF +/-10% 0805 | E108 | 2480675U01 | 0805 Chip-3Amp | U111 | 5162852A62 | IC MAX4373T, Low Cost Mircpwr |
| R004 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C123 | 2186133Z01 | Capacitor Array 33pF +/-10% 0805 | J100 | 0905505Y04 | Conn ZIF Horizontal | VR100 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| R005 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C124 | 2186133Z01 | Capacitor Array 33pF +/-10% 0805 | J110 | 0980472U01 | Connector 16 Pos Right Angle | VR101 | 4805656W08 | Diode 5.6V Zener Quad MMQA5V6T1 |
| R006 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C125 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 | Q100 | 5102463J80 | FDC6330L Integrated Load Switch | VR102 | 4805656W08 | Diode 5.6V Zener Quad MMQA5V6T1 |
| R007 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C126 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 | Q101 | 5102463J80 | FDC6330L Integrated Load Switch | VR103 | 4805656W08 | Diode 5.6V Zener Quad MMQA5V6T1 |
| R008 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C127 | 2113743N38 | Cap Cer Chip 33.0pF 5% 16V COG 0402 | Q102 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 | VR104 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| R009 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C130 | 2113743N38 | Cap Cer Chip 33.0pF 5% 16V COG 0402 | Q103 | 4802245J54 | UMG5N Digital Transistor | VR105 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| R010 | Not Placed | GCAM Dummy Part Number | C131 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | R100 | Not Placed | GCAM Dummy Part Number | C200 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| S001 | 4080710Z07 | Frequency Switch (Endless Rotation) | C132 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | R101 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C201 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| S002 | 4070354A01 | Light Touch Switch-SMD | C133 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | R102 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C202 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| S003 | 4070354A01 | Light Touch Switch-SMD | C134 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | R103 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C203 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| S004 | 4070354A01 | Light Touch Switch-SMD | C135 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | R106 | 0662057M40 | Res Chip 39 5% 0.063W 0402 | C204 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| S005 | 4070354A01 | Light Touch Switch-SMD | C136 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | R107 | 0662057M40 | Res Chip 39 5% 0.063W 0402 | C205 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| U001 | 5102463J90 | NL27WZ16-Dual Buffer | C137 | 2113743L09 | Cap Cer Chip 470pF 10% 16V X7R 0402 | R108 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C206 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| U002 | 5102463J90 | NL27WZ16-Dual Buffer | | | | R109 | 0686135Z01 | Current Sensor Resistor (0.1ohm) | C207 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| U005 | 9185759B01 | FLTR RC Network | | | | R110 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 | C208 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| VR001 | 4805656W08 | Diode 5.6V Zener Quad MMQA5V6T1 | | | | R111 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 | C209 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| VR002 | 4805656W08 | Diode 5.6V Zener Quad MMQA5V6T1 | | | | R112 | 0662057N01 | Res Chip 12k 5% 0.063W 0402 | C210 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| VR004 | 4805656W08 | Diode 5.6V Zener Quad MMQA5V6T1 | | | | R113 | 0662057M95 | Res Chip 7500 5% 0.063W 0402 | C211 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| VR009 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 | | | | R114 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C212 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C100 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | | | | R115 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | C213 | Not Placed | GCAM Dummy Part Number |
| C101 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 | | | | R116 | 0662057M82 | Res Chip 2200 5% 0.063W 0402 | | | |
| C102 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 | | | | R117 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 | | | |
| C104 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 | | | | R118 | 0662057N17 | Res Chip 56k 5% 0.063W 0402 | | | |
| | | | | | | R119 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |
| | | | | | | R120 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |
| | | | | | | R121 | 0662057M40 | Res Chip 39 5% 0.063W 0402 | | | |
| | | | | | | R122 | 0662057M50 | Res Chip 100 5% 0.063W 0402 | | | |
| | | | | | | R123 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |
| | | | | | | R124 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |
| | | | | | | R125 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |
| | | | | | | R126 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |
| | | | | | | R127 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |
| | | | | | | R128 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |
| | | | | | | R129 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 | | | |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C214 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C215 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C216 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C217 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C218 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C219 | 2113743A27 | Cap Cer Chip .470uF 10% 16V X7R 0805 |
| C220 | 2113743A27 | Cap Cer Chip .470uF 10% 16V X7R 0805 |
| C221 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C222 | 2113743T19 | Cap Cer Chip 10.0uF 10% 16V X5R 3225 |
| C223 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C224 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C225 | 2311049A97 | Cap Tant Chip 33uF 20% 16V C |
| C226 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C227 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C228 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 |
| C229 | 2113928A01 | Cap Cer Chip 1.0uF +80/-20% 10V Y5V 0603 |
| C230 | 2113928A01 | Cap Cer Chip 1.0uF +80/-20% 10V Y5V 0603 |
| C231 | 2113928A01 | Cap Cer Chip 1.0uF +80/-20% 10V Y5V 0603 |
| C232 | 2113928A01 | Cap Cer Chip 1.0uF +80/-20% 10V Y5V 0603 |
| C233 | 2113928A01 | Cap Cer Chip 1.0uF +80/-20% 10V Y5V 0603 |
| C234 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 |
| C235 | 2113928A01 | Cap Cer Chip 1.0uF +80/-20% 10V Y5V 0603 |
| C236 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C237 | 2113743N30 | Cap Cer Chip 15.0pF 5% 16V COG 0402 |
| C238 | 2113743N30 | Cap Cer Chip 15.0pF 5% 16V COG 0402 |
| C239 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C240 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C241 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C242 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C243 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C244 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C245 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C246 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C247 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C248 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C249 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C250 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 |
| C251 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C252 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C253 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C254 | 2113928A01 | Cap Cer Chip 1.0uF +80/-20% 10V Y5V 0603 |
| C255 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C256 | Not Placed | GCAM Dummy Part Number |
| C257 | Not Placed | GCAM Dummy Part Number |
| C258 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C259 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C260 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C261 | 2113928C04 | Cap Cer Chip 4.7uF 10% 6.3V X5R 0805 |
| C262 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C263 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C264 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C265 | Not Placed | GCAM Dummy Part Number |
| C266 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C267 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C268 | 2113743T19 | Cap Cer Chip 10.0uF 10% 16V X5R 3225 |
| C269 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C270 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C271 | 2113928D08 | Cap Cer Chip 10.0uF 10% 10V Y5V 1206 |
| C272 | Not Placed | GCAM Dummy Part Number |
| C273 | 2113743T19 | Cap Cer Chip 10.0uF 10% 16V X5R 3225 |
| C274 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C275 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C276 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C277 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C278 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C279 | 2113743N41 | Cap Cer Chip 43.0pF 5% 16V COG 0402 |
| C280 | 2113743T19 | Cap Cer Chip 10.0uF 10% 16V X5R 3225 |
| C281 | 2113743T19 | Cap Cer Chip 10.0uF 10% 16V X5R 3225 |
| C282 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C283 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C284 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C285 | 2113928A01 | Cap Cer Chip 1.0uF +80/-20% 10V Y5V 0603 |
| C286 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C287 | 2113743L17 | Cap Cer Chip 1000pF 10% 16V X7R 0402 |
| C288 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C289 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C290 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C291 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C292 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C293 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C294 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C295 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C296 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 |
| C297 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C298 | 2113741F47 | Cap Cer Chip 8200pF 5% 50V X7R 0603 |
| C299 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C401 | Not Placed | GCAM Dummy Part Number |
| C402 | 2113743M24 | Cap Cer Chip 0.1uF +80/-20% 16V Y5V 0402 |
| D202 | 4813833A19 | Diode Schottky 1A 20V PWR-MITE |
| D203 | 4813833A19 | Diode Schottky 1A 20V PWR-MITE |
| D204 | 4813825A19 | Diode Schottky Barrier Series 0805 CHIP-3AMP |
| E200 | 2480675U01 | Ind Chip Fer Fltr 600 0603 |
| E201 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E202 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E203 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E204 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E205 | 2480675U01 | 0805 CHIP-3Amp |
| E206 | 2480675U01 | 0805 CHIP-3Amp |
| E207 | 2480675U01 | 0805 CHIP-3Amp |
| E208 | 2480675U01 | 0805 CHIP-3Amp |
| E209 | 2480675U01 | 0805 CHIP-3Amp |
| E210 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E211 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E212 | 2480675U01 | 0805 Chip-3Amp |
| E213 | 2480675U01 | 0805 Chip-3Amp |
| E214 | 2480675U01 | 0805 Chip-3Amp |
| E215 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| F200 | 6586221J04 | Fuse 2.5A 16V SMD |
| L200 | 2408603Y01 | Idctr 4.7uH |
| L201 | 2486085A02 | Idctr 15uH |
| L202 | 2404927K02 | Idctr 47uH +/-20% |
| Q201 | 5102463J80 | FDC6330L Integrated Load Switch |
| Q202 | 4805128M27 | Sot Trans BSR33 |
| Q204 | 4802245J54 | UMG5N Digital Transistor |
| R202 | 0662057N15 | Res Chip 47k 5% 0.063W 0402 |
| R203 | 0662057N15 | Res Chip 47k 5% 0.063W 0402 |
| R204 | 0662057N15 | Res Chip 47k 5% 0.063W 0402 |
| R205 | 0662057N17 | Res Chip 56k 5% 0.063W 0402 |
| R206 | 0662057M96 | Res Chip 8200 5% 0.063W 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|-------------------------------------|
| R207 | 0662057M96 | Res Chip 8200 5% 0.063W 0402 |
| R208 | 0662057B20 | Res Chip 820k 5% 0.1W 0603 |
| R209 | 0662057M82 | Res Chip 2200 5% 0.063W 0402 |
| R210 | 0662057N11 | Res Chip 33k 5% 0.063W 0402 |
| R211 | 0662057M93 | Res Chip 6200 5% 0.063W 0402 |
| R212 | 0662057N11 | Res Chip 33k 5% 0.063W 0402 |
| R213 | 0662057M82 | Res Chip 2200 5% 0.063W 0402 |
| R214 | 0662057M82 | Res Chip 2200 5% 0.063W 0402 |
| R215 | 0662057N30 | Res Chip 200k 5% 0.063W 0402 |
| R217 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R218 | Not Placed | GCAM Dummy Part Number |
| R220 | 0662057B05 | Res Chip 200k 5% 0.1W 0603 |
| R221 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R225 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R229 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R230 | 0662057M96 | Res Chip 8200 5% 0.063W 0402 |
| R232 | 0662057M50 | Res Chip 100 5% 0.063W 0402 |
| R235 | Not Placed | GCAM Dummy Part Number |
| R240 | 0662057N11 | Res Chip 33k 5% 0.063W 0402 |
| R241 | 0662057N05 | Res Chip 18k 5% 0.063W 0402 |
| R242 | 0662057M94 | Res Chip 6800 5% 0.063W 0402 |
| R243 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R244 | 0662057M74 | Res Chip 1000 5% 0.063W 0402 |
| R245 | 0662057M90 | Res Chip 4700 5% 0.063W 0402 |
| R252 | 0662057N06 | Res Chip 20k 5% 0.063W 0402 |
| R254 | 0662057V30 | Res Chip 130k 5% 0.063W 0402 |
| R255 | 0662057M26 | Res Chip 10 5% 0.063W 0402 |
| R256 | 0662057N06 | Res Chip 20k 5% 0.063W 0402 |
| R271 | 0662057M78 | Res Chip 1500 5% 0.063W 0402 |
| R272 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R274 | 0662057N16 | Res Chip 51k 5% 0.063W 0402 |
| R275 | 0662057N14 | Res Chip 43k 5% 0.063W 0402 |
| R277 | Not Placed | GCAM Dummy Part Number |
| R278 | 0662057N06 | Res Chip 20k 5% 0.063W 0402 |
| R279 | 0662057V30 | Res Chip 130k 5% 0.063W 0402 |
| R280 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R281 | 0662057M98 | Res Chip 10k 5% 0.063W 0402 |
| R284 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R285 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R287 | 0662057N23 | Res Chip 100k 5% 0.063W 0402 |
| R296 | 0662057A18 | Res Chip 51 5% 0.1W 0603 |
| RT200 | 0686931J01 | Thermistor 47k |
| SH200 | 2686114Z01 | Primary Shield, GCAP3 |
| SH201 | 2686120Z01 | Primary Shield, Switching Regulator |
| U200 | 5109879E83 | IC BICMOS GCAP3 V2.2 179BGA |
| U201 | 5102463J75 | MAX1685 Step Down Regulator |
| U202 | 5102463J44 | Audio Amplifier TDA8547TS |
| U205 | 5102463J82 | ADP3331 Linear Voltage Regulator |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---------------------------------------|
| VR201 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| Y200 | 4809995L05 | Xtal Quartz 32.768kHz CC4V-T1 |
| C300 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C301 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C302 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C303 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C304 | 2113741F45 | Cap Cer Chip 6800pF 5% 50V X7R 0603 |
| C305 | 2113741F49 | Cap Cer Chip 10000pF 5% 50V X7R 0603 |
| C306 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C307 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C308 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C309 | 2113928P04 | Cap Cer Chip 1.0uF 20% 6.3V X5R 0603 |
| C310 | 2113743N54 | Cap Cer Chip 150pF 5% 16V COG 0402 |
| C311 | 2113928P04 | Cap Cer Chip 1.0uF 20% 6.3V X5R 0603 |
| C312 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C313 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C314 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C315 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C316 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C317 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C318 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C319 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C320 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C321 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C322 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C323 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---------------------------------------|
| C324 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C325 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C326 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C327 | 2113743L41 | Cap Cer Chip 10000pF 10% 16V X7R 0402 |
| C328 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| C329 | 2113928K09 | Cap Cer Chip 10.0uF 10% 6.3V X5R 1206 |
| C330 | 2113743N38 | Cap Cer Chip 33.0pF 5% 16V COG 0402 |
| C331 | Not Placed | GCAM Dummy Part Number |
| C340 | 2113743L03 | Cap Cer Chip 270pF 10% 16V X7R 0402 |
| C341 | 2113928N01 | Cap Cer Chip 0.1uF 10% 6.3V X5R 0402 |
| E302 | 2480067M02 | CHK RF Chip Bead Inductor |
| L301 | 2409377M36 | IND CHIP WW 220nH 5% 0603 |
| R307 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R308 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| R309 | 0662057M01 | Res Chip 0 5% 0.063W 0402 |
| R310 | Not Placed | GCAM Dummy Part Number |
| R312 | 0662057A18 | Res Chip 51 5% 0.1W 0603 |
| R313 | Not Placed | GCAM Dummy Part Number |
| R314 | 0662057N07 | Res Chip 22k 5% 0.063W 0402 |
| R315 | 0662057M94 | Res Chip 6800 5% 0.063W 0402 |
| R316 | Not Placed | GCAM Dummy Part Number |
| R318 | 0662057M01 | Res Chip 0 5% 0.063W 0402 |
| R319 | 0662057M01 | Res Chip 0 5% 0.063W 0402 |
| R324 | 0662057N13 | Res Chip 39k 5% 0.063W 0402 |
| SH300 | 2686110Z01 | Primary Shield, Controller |
| SH301 | 2686119Z01 | Primary Shield, Memories |
| U301 | 5185368C99 | IC 17X17 256 MAPBGA |
| U302 | 5109509A43 | IC 512k x 16, 1MB SRAM |
| U303 | 5102476J01 | Intel 64MBIT Flash GE28F640C3 |
| U304 | 5109522E22 | IC Sngl And Gate TC7S08FU |
| U305 | 5102463J77 | MC74HC1G04 NOT GATE |
| U307 | 5109522E22 | IC Sngl And Gate TC7S08FU |
| U308 | 9185759B01 | Filtr RC Network |

Troubleshooting (400 MHz)

General

Troubleshooting faults in the radio require proper understanding of the different circuitry contained in the radio. Since the radio contains a highly integrated system, the software and hardware functions can not be separated easily. Thus, it is also necessary to understand the functioning of different ICs and the role of the software in the operation of the radio.

This service manual includes schematic diagrams, circuit board layouts, block diagrams, and troubleshooting procedures, which help a technician to troubleshoot a malfunctioning circuit and detect a defective component.

NOTE The CPS has no capability to tune the radio. Tuning the radio can only be performed at the factory or at the appropriate Motorola Repair Centre. Components replacement can affect the radio tuning and must only be performed by the appropriate Motorola Repair Centre.

The radio is tuned and tested at the factory. The results of the tuning procedures are stored in a special EEPROM. This information includes tuning and other system parameters. The area of the memory in the radio where the tuning information stored is called the "codeplug". A radio codeplug can be read using the CPS programme.

Test Procedures

This section explains the procedures required to troubleshoot a MTP700 radio.


The digital tests should be performed using the GoNoGo PATS test and TETRACom SW. To use the TETRACom you must go to test mode by using the command <Test Enter>.


Troubleshooting Flowcharts

Use the following flowcharts to troubleshoot the radio. These flowcharts contain procedures using TETRACom SW application, GoNoGo PATS test and factory test modes for troubleshooting radios having digital, receiver, transmitter, or frequency generation test failures.


Digital Analysis Test

Use this test for troubleshooting the main board





Digital Analysis Test (Cont.)



DC Distribution (V3_2.775V) Test


Use this test on a unit with the following symptoms: no power, no V3_2.775V, V1_3V, V2_2.775V, VREF1_2.775V, VREF2_2.775V.

Note: The following are the DC power distribution voltages with their correct values and appropriate location to check the voltages:


- FUSED B+ (7.2Vdc) @ F200, C268, VR201, @ C222, C228, C250, C280, C281.
- FILT_3.3V (3.3Vdc) @ C282, C255, C260, C284, @ C240, C241, @ C201, C242.
- V1_3V (3Vdc) @ C211, @ C264, C266..
- V2_2.775V (2.775Vdc) @ C210, C213, C257.
- V3_2.775V_DIG (2.775Vdc) @ C209, C258, C259.
- V3_2.775V (2.775Vdc) @ C294, C295
- VREF1_2.775V (2.775Vdc) @ C285.
- VREF2_2.775V_DIG (2.775Vdc) @ C212, C260, C261.
- VREF2_2.775V (2.775Vdc) @ C262, C263.
- V4_2.775V_GCAP3 (2.775Vdc) @ C225, C244, C247.
- V4_2.775V (2.775Vdc) @ C90, C291.
- V4_2.775V_LNODCT (2.775Vdc) @ C340, C341.
- 5V_RF (5Vdc) @ C292, C293, @ C251, C223.
- PWM1_1.8V (1.8Vdc) @ C224, C226, C243, C248.
- 5.5V_RF (5.5Vdc) @ C299, C220.

DC Distribution (V3_2.775V) Test


Use this test on a unit with the following symptoms: no V3_2.775V.



DC Distribution (V3_2.775V) Test (Cont.)




DC Distribution (V3_2.775V) Test (Cont.)




DC Distribution (V3_2.775V/PWM1_1.8V) Test

Use this test on a unit with the following symptoms: no V3_2.775V, no PWM1_1.8V.




DC Distribution (BOT_SWB+) Test

Use this test on a unit with the following symptoms: no BOT_SWB+ .




DC Distribution (SWB+ 7.2V) Test

Use this test on a unit with the following symptoms: no 7.2Vdc SWB+.




DC Distribution (5.5V_RF) Test

Use this test on a unit with the following symptoms: no 5.5V_RF.




DC Distribution (5V_RF) Test

Use this test on a unit with the following symptoms: no 5V_RF.




DC Distribution (V1_3V) Test

Use this test on a unit with the following symptoms: no V1_3V.




DC Distribution (V4_2.775V) Test

Use this test on a unit with the following symptoms: no V4_2.775V.




DC Distribution (VREF1_2.775V) Test

Use this test on a unit with the following symptoms: no VREF1_2.775V.




DC Distribution (VREF2_2.775V) Test

Use this test on a unit with the following symptoms: no VREF2_2.775V




Standby Current Troubleshooting


This test should be carried out only after the successful completion of the previous tests.




Receiver Troubleshooting



Escort Troubleshooting




Escort Troubleshooting (Cont.)




Closed Loop Power Test

This test should be carried out only after the successful completion of the previous tests.




Open Loop Power Test


This test should be carried out only after the successful completion of the previous tests.



Open Loop Power Test (Cont.)




Open Loop Power Test (Cont.)




Transmitter Current Consumption Test

This test should be carried out only after the successful completion of the previous tests.




2nd LO Troubleshooting




Synthesizer & VCO Troubleshooting

Use this test on a unit with the following symptom: no Tx or Rx.



Synthesizer & VCO Troubleshooting (Cont.)



THIS PAGE INTENTIONALLY LEFT BLANK

CHAPTER 4.2

TRANSCEIVER 800 MHz

General

This section provides a block diagram overview of the main Digital/RF Board. This is supplemented by the detailed block diagram and detailed circuit description.

Block Diagram Overview

The main Digital/RF Block contains the following four sections (see Figure 4.2-1). An overview of these four sections is provided in the following paragraphs:

- Receiver Section
- Transmitter Section
- Frequency Generating Section (Synthesizer)
- Digital & Audio Section




Figure 4.2-1 General Block Diagram

Receiver Section

The receiver section includes the following main components:

- Antenna Switch
- Limiter
- Front Filter (First Pre-selector)
- Low Noise Amplifier (LNA)
- Second Pre-selector
- Mixer
- IF Filter
- Balun
- WPIC

The Receiver Path implements an Automatic Gain Control (AGC). It is required to maintain good receiver linearity over a wide range of incoming signals and prevents clipping of high level signals.

The First Intermediate frequency (IF) circuit consists of the Mixer, IF Filter, and WPIC. The First IF is down converted to baseband using an analog mixer (high-side injection) located in the WPIC. An external second LO synthesizer IC is used to generate the required 219.3 MHz signal, which is further divided by two to 109.65 MHz before being applied to the mixer.

The WPIC performs the following functions:

- Carries out amplification and quadrature down conversion of the signal into baseband.
- Synthesizes the second VCO frequency.
- Performs IF AGC.
- Converts the baseband analog signal into digital I & Q formats.
- Synthesizes the receive and transmit data (ie Sigma-Delta) clock.
- Transmits the received data to the DSP.

Transmitter Section

The transmitter circuitry includes a linear class AB Power Amplifier (PA) for the linear modulation of the MTP700. It also includes a cartesian feedback loop to enhance its transmitter linearity and reduced splattering power into adjacent channels.

The transmitter path consists of a forward path and a cartesian feedback loop. The forward path includes the LNODCT (Low Noise Offset Direct Conversion Transmitter) ASIC, Balun, Attenuator, and Power Amplifier. The loop feedback path includes the directional coupler, attenuator and LNODCT.

The linearized power from the PA goes through the isolator which provides the isolation between the antenna and the PA. The signal then passes through the antenna switch and a lowpass Harmonic Filter to provide additional filtering to remove far out unwanted signals.

Frequency Generating Section

The frequency generating section contains the following components:

- TCXO REF. Oscillator.
- Main Synthesizer - consists of the WPIC's PLL and the Main Voltage Controlled Oscillator (VCO).
- 2nd Local Oscillator (LO) VCO together with the LMX Dual Synthesizer.
- Transmit PLL - consists of TX VCO together with ESCORT Synthesizer IC.

TCXO Reference Oscillator

All frequencies originate from the REF. oscillator -TCXO. This is a digital temperature compensated crystal oscillator producing an accurate and stable 16.8 MHz reference frequency. The 16.8 MHz reference frequency is divided in the WPIC and in the Dual Synthesizer to produce required reference frequency for the other synthesizers. The 16.8 MHz reference is also routed to GCAP3 to clock the digital circuits.

Main Synthesizer

The Main Synthesizer consists of the WPIC internal PLL modules, and Main VCO on board. It produces the LO signal to down-convert the receive signal to the first IF 109.65 MHz frequency and provides the transmit injection frequency for the ESCORT IC.

RX Second Local Oscillator (LO)

The second LO synthesizer supplies the second IF local oscillator frequency to the receiver. It produces 219.3 MHz that is divided by two in the WPIC in order to down-convert the received signal to the baseband.

Transmit PLL

The transmit PLL consists of the ESCORT IC and transmit VCO. The ESCORT IC receives the reference signal from the main synthesizer. The ESCORT IC which is another PLL together with the transmit VCO does the synthesis of the required transmitter signal.

Digital & Audio Section

The digital section includes the RedCap2 host micro-processor which is the controller of the Digital/RF Board. It controls the operation of the audio and transmitter, receiver, and synthesizer integrated circuits located in the RF section. It has the serial communication interface to communicate with the keypad, display and other internal peripherals.

For audio, the RedCap2 contains a Digital Signal Processor (DSP) which performs modulation and de-modulation functions for the radio. It also performs ACELP speech coding and Forward Error Correction.

Major components of the digital section are:

- RedCap2 (microprocessor with DSP embedded)
- GCAP3 (DC power supply and audio amplifier circuits)
- Serial peripheral interface (SPI)
- External host memories (Flash and SRAM)
- Keypad block & circuits
- LCD (liquid-crystal display) circuits.
- Bottom connector & side connector interface circuits

Block Diagrams Description

The block diagrams description cover Receiver Path, Transmitter Path, Frequency Generation Section and Digital Section.

Receiver Path

The received signal (see Figure 4.2-2) from the antenna is directed by the Antenna Switch to the Front End Filter




Figure 4.2-2 Receive Path - Block Diagram

The Front End Filter, which defines the receive frequency range, blocks the half IF and image frequency entry, and reduces the RF oscillator leakage. The signal is mixed with the local oscillator (high-side) to create the first IF at 109.65 MHz. The signal is filtered by the crystal filter and sent to the WPIC ASIC.

The WPIC performs down conversion to baseband frequency (0 Hz) and converts the baseband analog signals into digital-in-phase (I) and quadrature (Q) formats. This data is sent for further processing to the Digital Signal Processor (DSP) (part of RedCap2) over the Synchronous Serial Interface (SSI) data links.

The DSP performs: the demodulation, Forward Error Correction (FEC) and other correction algorithms for overcoming channel errors, and decoder procedure for digital speech data decompression.

Transmitter Path

When the radio is transmitting (see Figure 4.2-3), the microphone audio is sent to the GCAP3 (CODEC). The CODEC performs 13-bit analog-to-digital conversion and the digital signal is routed to the DSP (part of RedCap2). The DSP performs coding, Error Correction and modulation. From the DSP, the signal is sent to the WPIC.




Figure 4.2-3 Transmit Path - Block Diagram

In the WPIC, the digital baseband I & Q signals are converted into corresponding analog signals. These signals are also filtered. From the WPIC, I & Q signals are injected to the LNODCT. In the LNODCT the data is mixed with RF signal.

From the differential output of the LNODCT the modulated RF signal is injected to the Balun-Filter, that transforms the differential input into single output, and then it is routed to the antenna via the Antenna Switch.

The feedback signal is used for power control.

Frequency Generating Section

The frequency generating section contains the following components (see Figure 4.2-4):

- TCXO REF. Oscillator.
- Main Synthesizer - consists of the WPIC's PLL and the Main Voltage Controlled Oscillator (VCO).
- 2nd Local Oscillator (LO) VCO together with the LMX Dual Synthesizer IC.
- Transmit PLL - consists of TX VCO together with ESCORT Synthesizer IC.




Figure 4.2-4 Frequency Generation - Block Diagram

TCXO Reference Oscillator

All frequencies originate from the REF. oscillator - TCXO. This is a digital temperature compensated crystal oscillator producing an accurate and stable 16.8 MHz reference frequency. The 16.8 MHz reference frequency is divided in the WPIC and in the Dual Synthesizer to produce required reference frequency for the other synthesizers. The 16.8 MHz reference is also routed to GCAP3 to clock the digital circuits.

Main Synthesizer

The Main Synthesizer consists of the WPIC internal PLL modules and an external, discrete Main VCO on board. It produces the LO signal to down-convert the receive signal to the first IF 109.65 MHz frequency and provides the transmit injection frequency for the ESCORT IC.

RX Second Local Oscillator (LO)

The second LO synthesizer supplies the second IF local oscillator frequency to the receiver. It produces 219.3 MHz that is divided by two in the WPIC in order to down-convert the received signal to the baseband.

Transmit PLL

The transmit PLL consists of the ESCORT IC and transmit VCO. The ESCORT IC receives the reference signal from the main synthesizer. The ESCORT IC which is another PLL together with the transmit VCO does the synthesis of the required transmitter signal.

Digital & Audio Section

The digital section (see Figure 4.2-5) contains the radio's RedCap2 RISC processor, DSP (embedded within), external memories and GCAP3. The DSP has its own processing memory. GCAP3 contains switching and linear regulators, audio preamplifiers, 13-bit CODEC, A/D and D/A Converters, and interfaces with an external Audio Amplifier for receive audio.

RedCap2 controls the receive/transmit frequencies, power levels, display, keypad, accessories, MMI, and other radio functions. This microprocessor can be operated through the RS232 interface by a personal computer to program the Flash memory with firmware and codeplug.

The DSP performs the functions of audio filtering, ACELP speech coding, Forward Error Correction and digital modulation. The GCAP3's CODEC handles the analog-to-digital and digital-to-analog conversions on audio signals.

The power distribution is supported by the Global Control Audio Power (GCAP3) IC. This IC supplies power to the radio using step-down PWM regulator supplying 1.875 VDC to the RedCap2 core, supplying V3 linear regulator 2.775VDC to the external memories, display and RedCap2 peripheral modules, supplying V2 to GCAP3 internal logic, internal audio amplifier and A/D converter. The regulator's power-down mode is controlled by the RedCap2, which senses the ON or OFF condition.




Figure 4.2-5 Digital Section - Block Diagram

Detailed Circuit Description

Receiver Path, Detailed Circuit Description

See Figure 4.2-6




Figure 4.2-6 Receive Path Circuit Diagram

Antenna Switch

The signal coming from the antenna is routed to the receiver section via the harmonic filter, which is comprised of C943, L912 and C944. The signal continues to flow through L915 and C940, to the Rx section, toward limiter diode D500. The attenuation of wanted signal is typically 0.7dB.

Limiter

The limiter (D500) function is to limit the signal levels of signal with power higher than 5dBm, which may damage the receiver front-end. L500 resonates out the diode stray capacitance.

Front Filter (First Pre-selector)

The signal arriving from the limiter is routed through the front SAW filter (FL500) into the Low Noise Amplifier (LNA) (U500) via a matching network C500, L501 and C501.

The front filter is also called the 1st pre-selector and is used to attenuate the incoming parasitic RF frequencies, especially the image frequency. The Insertion Loss (IL) is typically 2dB.

Low Noise Amplifier (LNA)

The LNA (U500) amplifies the RF signal. The LNA gain including output matching circuit, L502, R502 and C514, is typically 15dB. Because the LNA is the first amplifier in the line, it is important that it will maintain large gain and small Noise Figure.

The LNA has an "enable" pin (pin 3) which is called VPD. When this pin receives a supply of 2.7 V from DC switch (Q500), the amplifier is enabled (controlled by GP05_DCLICP from WPIC). The LNA current is controlled by R500. Resistor R502 ensures the amplifier is stable through out its operating range. From the LNA the signal passes to second pre-selector, SAW filter (FL501).

Second Pre-selector

The 2nd Pre-selector (FL501) is another SAW filter which attenuates the non-linear products of the LNA and also the image product. Its IL is typically 2dB. From the output of the 2nd SAW filter the received signal is routed to the Mixer RF input via a LC match.

Mixer

The Mixer (U502) function is to down convert the incoming RF signal into IF signal (109.65 MHz). The mixer IC consists of a mixer and LO injection buffer.

The RF signal enters the Mixer at pin 4, and the IF is produced at pin 6. The LO (from the main VCO) signal passes via low pass filter FL503 and R514 into the IC at pin 3. The LO power is boosted internally by the mixer IC's injection amplifier before being applied to the mixer. The LO buffer output choke, L513, is used to resonate out the chip internal capacitance, allowing a high injection signal into the mixer. The mixer IF current is partly controlled by R511 and R510. R511 controls the mixer gain while C528 provides RF bypass. The LO power at the LO mixer input is -2dBm to -4dBm. The 2.7V DC is supplied by switch Q501 (controlled by GP06_DCLICIN from WPIC).

The mixer conversion gain is about 3dB.

An impedance matching net is placed between the mixer and the IF filter (FL502). It consists of L514, C534, C535, C537, L509, R516 and C538.

IF Filter

The IF signal is routed via the IF filter (FL502), which has IL of 2.5dB and attenuates parasitic products of the mixer. It is connected via an impedance matching network that consists of C539, C540 and L510 to the Balun.

Balun

The Balun transforms the single ended input RF signal to a differential double-ended output. It consists of L507, C523, C522 and L508.

The differential signal is routed to the WPIC (World Phone IC) at pins A4 and B4 (PREINI and PREINIB) via C651 and C652.

WPIC (Receiver Back End Section)

The differential IF signal is amplified and converted down to baseband signal inside the WPIC (World Phone IC) by the 2nd LO signal. The 2nd LO signal is routed to the WPIC at pin D1 and divided by two into the quadrature generator block of the WPIC. The baseband signal from the mixer passes to an amplifier baseband filter array. The amplified and filtered signal is passed to the WPIC A/D converter. This A/D converter digitises the analog differential signal as I and Q components. The I and Q components appears as serial data on the WPIC_SRD line whenever the RX_ACQ line is high. The WPIC_SRD data is clocked into the DSP baseband port using a clock signal (WPIC_TXCLK) from WPIC. The DSP performs the functions of digital de-modulation. The WPIC is controlled via SPIA_MOSI, SPIA_CLK and SPIA_CS0_WPIC from RedCap2.

An internal AGC that is controlled by a control unit, establishes an appropriate attenuation for unwanted signals as well as an appropriate gain for wanted signals. The voltage at external capacitor C612 indicates the AGC attenuation level for the different input signal levels. The voltage at the capacitor varies from 1.3V to 2V as a function of the power of the received signal.

Transmitter Path, Detailed Circuit Description

See Figure 4.2-7




Figure 4.2-7 Transmit Path - Circuit Diagram

Forward Path

WPIC

The WPIC (World Phone IC) U601 receives serial data that is transmitted by the RedCap2 at a 48 kbps (kilosamples/second) rate to the SSI port (pin K10, WPIC_STD). Data is transmitted as a 16-bit 'I' word followed by a 16-bit 'Q' word. The WPIC provides a serial clock of 4.8MHz to the RedCap2 (pin K11, WPIC_TXCLK) and sends a frame sync signal (pin L11, WPIC_FSYNC) at the beginning of every 'I' word transmission to instruct the RedCap2 to send data. In the WPIC, the received serial I & Q words from the RedCap2 are converted into parallel I & Q words, and transferred to an interpolating filter. The interpolating filter increases the sampling rate to reduce in-band quantization noise, as well as to reduce image at multiples of the input data. The interpolated samples are rounded to 8 bits, and run through the 8-bit D/A converters. The D/A converters take the digital I & Q words and convert them into analog signals, which are then filtered and amplified. The output is comprised of two separate low-level differential signals, I & Q (pins A8, OUTQ; C8, OUTQB; D8, OUTI; A9, OUTIB). A differential output is used to minimize the noise pick-up, due to its inherent common mode rejection. The output signals are routed to the LNODCT IC where the transmitting loop is closed.

The WPIC sends a 2.4MHz low-level differential reference clock signal (pins B11, TCLK; C10, TCLKB) to the LNODCT. It also sends a differential signal (pins A11, TSLOT; A10, TSLOTB) that marks the beginning and the end of each transmission time slot (whenever pin 8, WPIC_TXE signal is received from the RedCap2). After receiving the TSLOT signal, the LNODCT toggles the ASW line (pin J5) which signals the WPIC to set VCNT0 signal LOW (pin J6) which enables the Antenna Switch during transmit time.

TX LO Line-Up

The TX LO line-up includes the ESCORT IC which generates a signal of frequency equal to the transmit frequency. The signal level is about +7dBm. This is then split thru a 3dB power splitter consisting of R457, R458 and R459.

One output of the power splitter U801 (MVCO signal) goes into the LO input of the LNODCT downconverter. This signal downconverts the RF feedback input signal to baseband.

The other output of the power splitter (MVCO_PS signal) goes into the phase splitter which generates I and Q signals for the upconverter in the LNODCT. These signals upconvert the baseband signal into RF frequency.

LNODCT

The LNODCT (Low Noise Offset Direct Conversion Transmitter) U803 is the heart of the transmitter.

The differential baseband signals from the WPIC are inputted into the LNODCT on pins 58 – 61 (BINQB, BINQ, BINIB and BINI). They pass through a variable attenuator and then they are summed with the down converted I & Q feedback. The baseband signal is then amplified and sent to the up-mixer.

The up-mixer consists of two mixers, one for the I channel and the other for the Q channel. The split I & Q LO signal is mixed with the baseband I & Q signals to produce an I and Q modulated signals at RF frequency. The signal is then output differentially on pins 51 and 52 (RFOUTB, RFOUT).

Balun - Filter

The differential RF signal is converted to a single-ended (unbalanced) signal by passing the Balun-Filter T800 (balanced-unbalanced filter). The Balun-Filter has a 200 Ohm input and 50 Ohm single-ended output. The Balun-Filter output voltage amplitude is two times higher than the differential voltages amplitudes. Thus the LNODCT output signal is increased by 6dB when compared to each of the differential signals. The insertion loss of the Balun-Filter is 3dB.

Resistors R921 - R923 form an attenuator to compensate for changes in the forward path RF PA gain stages.

RF Power Amplifier

The signal is routed through DC coupling capacitor C901 to the RF power amplifier (PA). The PA consists of 2 devices, namely U800 driver and Q800 final PA. U800 is a 2-stage IC that is capable of amplifying the signal to about 24dBm level. The capacitors and inductors between U800 output and Q800 input form a high pass - low pass matching network. Q800 output is then matched to the 50 ohms input of the isolator thru a low pass pi matching stage using microstrips.

The U800 amplifier gain is set in the factory using the VBLIN signal (from WPIC). The VBLIN voltage is amplified via a DC amplifier U907. Output voltage from U907 sets the quiescent current, and hence the gain of the LDMOS driver IC.

The gain of the final stage PA is set in the factory through serial SPI commands (from RedCap2) to the E-pot. The output of the E-pot is dependent on the resistance divider ratio internal to it. During transmission, the 2.775V supply to the E-pot is enabled using PA Bias line signal (from RedCap2). When this line signal goes to 2.775V (HIGH), the voltage to bias the final stage device is enable.

Coupler and Feedback Path

A coupler U806 exists at the RF PA output, it is used to pass the signal to Isolator FL801 and sample the signal thus providing the necessary feedback for the linearization and feedback correction. The sampled signal is routed via attenuator R913, R914, R915 to the LNODCT (pin 37, RFIN). The feedback signal is then mixed down to baseband in a quadrature down mixer, amplified and summed with the baseband input signal. The loop is closed.

Isolator

The signal in the forward path is fed to pin 1 of the isolator (FL801). The isolator is placed at the PA output to decrease the influence of the antenna impedance variation on the PA performance. The reflected power returned from the antenna, is absorbed in a 50 Ohms resistor inside the isolator. The isolator also protects the Cartesian loop from sudden VSWR variations that could lead to loop instability.

Antenna Switch

The RF signal from the Isolator is applied to PIN diodes D901 and D903. The PIN diodes are turned on during the transmission time slot, and the DC current flows through the Isolator to the ground. The RF signal is routed thru the harmonic filter (C943, L912 and C944) to the antenna.

In the Receiving mode the PIN diodes are turned off, the input RF signal is directed to the receiver path via $\lambda/4$ LC equivalent circuit (C943, L915 and C938).

The condition of the PIN diodes is controlled by the voltage switch Q806 by applying the ANT_EN signal (from RedCap2) to the switch. The resistor R911 determines the DC current through PIN diodes. Pin diodes D802 and D803 provide the additional capacitance so as to improve isolation to receiver path during transmission mode. Capacitors C939 and C931 compensate the parasitic inductance of D802 and D803 respectively. The VCNT0 signal applied to the voltage switch Q806 is set LOW during the Receiving and Transmission modes.

The RF output signal is disabled during the CLCH (Training) mode by setting the VCNT0 signal HIGH thus providing the low output power during the training slot.

Harmonic Filter

From the antenna switch the signal is routed to a one section of LC filter, consisting of the coil L912 and capacitors C943 and C944. The filter is required to attenuate the harmonics of the amplifying stages at the transmission path, and the Local Oscillator leakage at the receiver path.

Resistor R809 is added to provide a discharge path for any static electricity buildup at the antenna.

Frequency Generating Section, Detailed Circuit Description

See Figure 4.2-8

This section describes the generating circuits that supply all the required frequencies for the required transmitter and receiver functions. These circuits are described as follows:

- TCXO REF. Oscillator.
- Main VCO and Main Synthesizer.
- Second LO VCO and Dual Synthesizer RF section.
- Transmit PLL - TX VCO with the ESCORT Synthesizer IC.




Figure 4.2-8 Frequency Generation Section - Block Diagram

TCXO Reference Oscillator

The TCXO is the reference frequency source for all the radio synthesizers. The output of the oscillator is a 16.8 MHz stable temperature compensated reference clock. This oscillator's centre frequency is adjustable by means of a PWM DAC (256 steps) to warp the radio frequency in order to lock to the base station. This 16.8 MHz signal is present at pin 3 of the TCXO, and is routed into the following devices:

1. To WPIC's K6 XTALBASE pin. The signal is divided by 2 to produce the 8.4 MHz reference signal, which is used for the Main PLL synthesizer.
2. To LMX Dual Synthesizer's OSC_IN pin via C731. The signal is divided to produce the 300 KHz reference signal for the second LO.

The reference signal is also routed from WPIC's pin F10 (16.8_MHz_CLK) to GCAP3 (and subsequently to RedCap2) to clock the digital circuits.

Main VCO and Main Synthesizer

The main synthesizer components are WPIC, Loop Filter, VCO and buffer. It produces the LO signal.

The main synthesizer functions are as follows:

- To serve as the local oscillator for the mixer of the receiver. It is used to down-mix the RF frequency to 1st IF (109.65 MHz).
- To provide reference for the transmit frequency PLL
- To serve as the WPIC feedback signal for locking the main synthesizer.

The WPIC is programmed by the DSP through the SPI bus.

The VCO (Q700 and associated circuitry) generates the LO signal which is feedback to the synthesizer (inside the WPIC) through the PRSCIN. The TCXO provides the 16.8MHz reference frequency.

The synthesizer then generates the VCTRL tuning voltage through WPIC's CPGITR pin to control the VCO frequency. The Loop Filter (LPF) consists of C641, R624, R623, which filters noise in the tuning voltage.

The Q702 and Q459 buffers prevent loading and interference to the next stage - ie RX Mixer and ESCORT respectively.

LMX - Dual Synthesizer

The U730 (LMX233XL) is an integrated dual frequency synthesizer that includes prescalers. It is used with the second LO VCO at the RF section.

The LMX uses the 16.8 MHz from the TCXO for the synthesizers and divides the TCXO frequency into 300 kHz reference frequency for the 2nd LO.

Second LO VCO

The Second LO VCO is a discrete VCO (Q730) that is controlled by the LMX Dual Synthesizer IC (U730).

The VCO produces a frequency of 219.3 MHz, that routes into WPIC's pin D1 (LOIN). This signal is further divided by two before being applied to the second mixer in the WPIC.

The output signal of the VCO is also routed via the phase detector of Dual Synthesizer, pin 18 (FINIF2). The internal phase detector is of the charged pump type.

The output of the phase detector is present at Dual Synthesizer pin 20 (DOIF). This signal is directed to loop filter R733, C738 and C739 and to tuning diode D730 of the tank circuit.

Transmit PLL

The TX VCO (Q463) is a discrete VCO that is controlled by the ESCORT IC U460. The VCO produces the TX frequency signals in the frequency band 806-870MHz. A discrete coil (resonator) Y460 and shunt capacitors are used as a tank circuit for VCO. The Colpitts Oscillator was adopted to ensure excellent performance in noise behavior and signal level stability throughout the whole band. Cascade amplifier is used as buffer to minimize the impact of load pull on the VCO frequency.

The synthesizer IC is the ESCORT IC employing NUD (near-unity-divider) technique to provide fast lock-in to TX frequency using a high reference frequency. The Main synthesizer is used as reference frequency source. The signal frequency of the Main VCO is divided by 36/32 (NUD) and compared with the TX VCO frequency in the fast phase comparator of the ESCORT. The comparator output signals IUP and IDOWN are then controlling the current mirror Q460 to supply the right tuning voltage to tuning diode D460 via loop filter R464, C472 and C473. ESCORT IC is controlled by RedCap2 via SPIA_CLK, SPIA_MOSI and SPIA_CS1_ESCORT.

Digital & Audio Section, Detailed Circuit Description

See Figure 4.2-9




Figure 4.2-9 Digital Section - Detailed Circuit Diagram

RedCap2 (Microprocessor & DSP)




Figure 4.2-10 RedCap2 Block Diagram

Figure 4.2-10 is a block diagram of the RedCap2 and its interfaces.

The RedCap2 RISC processor controls the operation of the transmitter, receiver, synthesizer and audio (GCAP3) integrated circuits. It uses the Flash memory and SRAM, both located externally.

RedCap2 employs SPI protocol (Serial Peripheral Interface) to communicate with the RF ICs, display, keypad and other internal peripherals. The processor can be operated through the RS232 interface by a personal computer to program the Flash memory with firmware and codeplug.

Within the RedCap2 is the Digital Signal Processor (DSP) which performs modulation and de-modulation functions for the radio. It also performs ACELP speech coding and Forward Error Correction.

External Host Memories

The RedCap2 Address bus is a 22-bit wide (0:21) and RedCap2 Data Bus is a 16-bit wide (0:15).

RedCap2 uses two types of memories:

Flash Memory

The Flash memory is dedicated to the application software. This memory has a 16-bit wide data bus. The Flash memory is 4 Mega x 16-bit (ie 64 Mbits density). When addressing the Flash memory location, the processor reads into its 16-bit wide data bus.

Apart from storing radio firmware, the Flash also stores the Radio CodePlug (Customer related information) such as telephone numbers, addresses, etc.

SRAM Memory

This 512k x 16-bit Static RAM is used for Data storage.

Serial Peripheral Interface (SPI)

The RedCap2 uses the SPI protocol (Serial Peripheral Interface) to communicate with RF IC's (WPIC, ODCT, ESCORT), GCAP3 IC and the display driver.

The protocol is built upon 4 lines [MOSI(Tx), MISO(Rx), CS, CLK)].

The RF IC's are connected to SPIA module, while GCAP3 and the display are connected via SPIB module.

The Display Module, based on the display driver (i.e. Samsung KS0741) uses a serial interface.

GCAP3

The Global Control Audio Power (GCAP3) IC handles DC power distribution and audio processing (ie audio amplification and analog-to-digital/digital-to-analog conversions). It contains switching and linear regulators, audio preamplifiers, 13-bit CODEC, 14-channel 10-bit A/D Converter, 8-bit D/A Converter and interfaces with an external Audio Amplifier for receive audio.

DC Power Distribution

See Figure 4.2-11




Figure 4.2-11 MTP700 DC Distribution

Several sections of the radio are connected directly to the battery, which supplies Raw_B+ and Fused_B+. The radio operates at a low voltage of 5.8Vdc, nominal-level voltage of 7.2Vdc, and high-level voltage of 12Vdc. The battery is connected to J001 pins 3 (+) and J001 pin 1 (-). These pins supply the Raw_B+ to the RF TX power amplifier. Raw_B+ is routed via F200 (Fuse) becoming Fused_B+, which is used by the Audio PA.

3.3V Switching Regulator

An external 3.3V switching regulator is used to convert the battery voltage (7.2V) down to 3.3V to be used by GCAP3. This regulator can be set to fixed freq 600KHz (during Tx & Rx) or variable switching frequency (when idle) depending on the load.

PWM #1 (Pulse Width Modulation)

PWM #1 is a selectable step down switching regulator. It is selectable using the RedCap2 SPIB bus from 1.2V to 2.45V in 6 steps, Pass Through and Power down modes. The switcher is active during Power Reset (POR) in 1.875V mode. It is set to 1.875V. Switching regulator is PWM #1_1.875V, which is the supply for the internal core, emulation port and clock output drivers of the RedCap2. The switcher is supplied from B+ and it is active whenever the radio is turned ON.

V1 Linear Regulator

V1 is a programmable linear regulator. It is programmed using the RedCap2 SPIB bus from 0.975V to 3.0V in 8 steps. This regulator is active during POR and its initial value is 1.55V. For this radio, V1 is programmed to 3.0V, supplying ESCORT section. This regulator is active whenever the radio is turned ON.

V2 Linear Regulator

V2 is a selectable linear regulator. It is selectable using the GCAP3 UV_SEL pin (internal logic) between either 2.5V and 2.775V. This regulator is active during POR and its initial output value is set by GCAP3 UV_SEL pin. Connecting UV_SEL pin to B+ sets V2 output value to 2.775V, connecting UV_SEL pin to Ground sets V2 output value to 2.5V. For this radio, V2 is selected to 2.775V. This regulator is supplied by B+ and it is active whenever the radio is turned ON. V2 is the supply for internal and external audio circuits, CLK_IN input driver and TS interface.

V3 Linear Regulator

V3 is a selectable linear regulator. It is selectable using the RedCap2 SPIB bus from 1.875V to 2.775V in 4 steps. This regulator is active during POR and its initial output value is 2.775V. For this radio, V3 is selected to 2.775V. The regulator is supplied by B+ and it is active whenever the radio is turned ON. V3 is V3_2.775V, which is the supply for the RedCap2, Flash, SRAM, GCAP3, Display, logic lines pull-up and 16-pin connector.

V4 Linear Regulator

V4 is a selectable linear regulator with external pass transistor. It is selectable using the RedCap2 SPIB bus from 1.875V to 2.775V in 4 steps. It is set to 2.775V. V4 is always powered from B+ and it is active whenever the radio is turned ON. This regulator is active during POR. V4 supplies all the RF sections.

VREF1 Linear Regulator

VREF1 is a programmable linear regulator. It is programmed using the RedCap2 SPIB bus from 0.95V to 2.775V. This regulator is active during POR and its initial value is 2.775V. For this radio, VREF1 is programmed to 2.775V and is battery supplied. VREF1 is VREF1_2.775V, which is the supply for the AND Gate on TCXO_WARP line.

VREF2 Linear Regulator

VREF2 is a programmable linear regulator. It is programmed using RedCap2 SPIB bus from 0.95V to 2.775V. For this radio, it is programmed to 2.775V which supplies the Tx/Rx LED, backlights and display.

TS_REF Linear Regulator

TS_REF is a fixed output linear regulator. It is supplied internally from the V2 linear regulator. It is set to 2.3V. The radio uses TS_REF for the AD voltage dividers. It is not active at POR.

5.5V Linear Regulator

This is an external linear regulator used to supply GCAP3 DSC regulator, and a 4.5V linear regulator in ESCORT section. Its supplies comes from SWB+.

DSC Linear Regulator

DSC is a fixed output linear regulator. This regulator is active during POR in the 5V mode. DSC is supplied from an external 5.5V linear regulator. DSC 5V is used to supply the WPIC and ODCT charge pump circuits. It is also used by ESCORT and Main VCO sections.

Current Limit

The SWB+ current limit regulator provides power from the phone battery to clip-on accessories. It is enabled only when the phone is powered up and an accessory which requires power from the phone is connected.

Radio Audio System

See Figure 4.2-12

The audio system consists of the GCAP3 IC (U200) and the DSP (U301), both are located on the main board.

The GCAP3 perform the analog task and part of the digital task of the audio system.

Tx Path

Audio speech is fed either to the internal microphone or the external microphone. The signals reach the GCAP3 IC. In the GCAP3 IC, a fix gain amplifier (A3 or A5) provides the signal amplification, the multiplexer (MUX) selects the active input and the Programmable Gain Amplifier (TxPGA) adjust the path gain according to the radio mode of operation. Finally, the A/D converts the analog signal into digital format and transfers it to the DSP. The DSP performs the functions of audio filtering, ACELP speech compression, forward error correction (FEC), digital modulation, and transfers the data to the RF section. When the radio is operating in the telephone interconnect mode, the DSP performs the required tasks such as echo and noise reduction.

Rx Path

The digital output signal from the receiver is fed to the DSP which performs the functions of digital de-modulation, FEC, ACELP speech de-compression, and audio filtering. It transfers the data to the GCAP3 IC. In this IC, the D/A converts the digital audio format to an analog signal, the Programmable Gain Amplifier (RxPGA) adjusts the path gain according to the setting of the volume control, and the multiplexer routes the audio to the active receive path. The audio is fed to A4, single-ended audio power amplifier. It is then fed to the Audio PA, where most of the amplification is performed and can be selected either to go through the internal speaker or external speaker. Alternatively, the audio from GCAP3 can also be sent through A1 to the internal Earpiece.




Figure 4.2-12 Audio Path - Block Diagram

RS232, SB9600, JTAG

The RedCap2 processor (RCE) uses the three serial protocols: RS232/UART, SB9600, and JTAG to communicate with external devices via the bottom connector of the unit. There is no external hardware for switching from one protocol to another because the RedCap2 handles the switching and line multiplexing functions internally.

Battery ID

The battery is equipped with a Dallas 2502 EPROM. A one-wire serial bus allows the radio or the battery charger to communicate with the battery and identify whether or not the battery is compatible. If the battery is determined to be incompatible, the unit automatically shuts off, and the charger does not enter charging mode.

Besides compatibility data, the EPROM also stores the following information: battery type, capacity, fuel-gauging parameters, and voltage threshold.

Display and Keypad, Detailed Description

Display

The LCD (Liquid Crystal Display) Module is a Graphic Display based upon the KS0741TB-01 display driver.

It consist of LCD Holographic Glass, LED backlight and a 22 pin flex cable connected to the Keypad board.

The Communication to the RedCap2 IC is performed using a SPI protocol (Serial Peripheral Interface). The Operation of the LCD is determined upon the RS line configuration (Data/Command).

The Display is 128 X 100 (Columns X Rows respectively).

Keypad

The RedCap2 processor (RCE) is responsible for decoding key presses and displaying them properly on the LCD. The keys are arranged into a matrix of five rows and five columns, which includes the Volume and PTT keys.

The PWR key is not decoded by the RCE; it directly drives the GCAP3, which sends a signal to RCE through INT1. The five row lines are pulled high via five internal 22 Kohm resistors. The five row lines and five column lines are fed to RedCap2 I/O pins. Pressing any key also generates the keypad internal interrupt. The RedCap2 debounces the keys by reading them 25 milliseconds later.

The keypad-decoding scheme works as follows:

1. RedCap2 sets rows to inputs; all columns are set as outputs and driven logic low.
2. Rows are pulled logic high. When a key is pressed, one row goes low, which indicates a key press and sends an internal interrupt.
3. RedCap2 reads rows. A low on that row indicates a key press. All others are high.
4. RedCap2 sets all columns to output logic high.
5. One column at a time is set to output logic low. RedCap2 reads the columns to see which one is now at a logic low level.
6. The low row level (in step 3) and low column level (in step 5) indicate the correct column and row.

All keypad circuitry is located on the keypad board. Refer to the keypad board schematics.

Backlight and LEDs

Backlight

The keypad backlight consists of 8 green LEDs. There are 2 more LEDs in the LCD module that are connected in parallel to the keypad LEDs.

Top LEDs

There is a tri-color (Green, Red and Amber when both turns on) LED located on the main board. These LED colors are used as indicators to the radio operation.

Radio Programming

The radio is entered into programming mode by setting the MOD pin high level, and applying a preamble sequence to the radio via the RS232 lines. A 12Vdc can be applied to pin 15 on the 16-pin connector to set the radio into flashing mode.

The MOD pin assertion is encountered at least 4 CKIH cycles before the negation of the Reset pin.

Accessory Connector

The radio provides two connectors for access to personal computers, data devices and audio accessories.

Bottom Connector



The 14-pin bottom connector is intended to support connection to personal computers, and test systems. The bus has seven standard modes of operation: Normal (Nothing Connected), USB Mode, Emergency, PTT, RS232 Mode 4-wire, RS232 8-wire/SSI Mode and SB9600 mode. There are also three additional non-standard modes, KEYLOAD, FLASH, and JTAG, which are used only for secure keyloading, development, factory programming and debugging.

These modes are selected by applying appropriate logic levels to the Option Select pins, named OPTION1 and OPTION2. Some of the modes listed above are selected by the additional application of a level on the USB POWER and CE_ON_OFF pins as well.

Mode Select (OPTION1 and OPTION2)

Logic levels applied to the OPTION1, OPTION2, USB POWER, and ON_OFF/JTAG/FLASH lines are used to select the different modes. The modes will be set as follows:

Table 4.2-1 Bottom Connector Mode Table

| | MODE | ON_OFF/ JTAG/ FLASH | BOTTOM OPTION1 | BOTTOM OPTION2 | USB PWR |
|--------------------------|--------------------------|------------------------|---|-------------------|------------|
| Standard Modes | Normal (No Accessory) | 0 | 1 | 1 | 0 |
| | USB Accessory / Computer | 0 | 1 | 1 | >4.0V |
| | Emergency | 0 | 1 | 0 | X |
| | RS-232 (4 wire) / SSI | 0 | *  | | X |
| | PTT (Push To Talk) | 0 | 0 | 0 | X |
| | RS-232 (8 wire) | 0 | 0 | 1 | X |
| | SB9600 | 0 | *  | | X |
| Non Standard Modes | KEYLOAD | 0 | ---- | | X |
| | FLASH | 11.4-12.6 V | X | X | X |
| | JTAG | 7.6-8.4 V | X | X | X |

Note: * Schottky Diode with forward voltage less than 0.4V.

Logic Levels

1 : 2.0V to 2.85V, typical 2.775V

0 : 0V to 0.8V

X : Do Not Care Condition

| Pin No. | Signal Name (Short_Form) | Power/ Default States | USB | RS232/ SSI | RS232 (8 wire) | SB9600 | JTAG |
|---------|--------------------------------------|--------------------------|--------------|---------------|-------------------|--------------|--------------|
| 1 | Power Ground (GND) | GND | GND | GND | GND | GND | GND |
| 2 | USB+/TXD (D+)/TDO | | D+ | TXD | TXD | TXD | TDO |
| 3 | USB-/RXD (D-)/TDI | | D- | RXD | RXD | RXD | TDI |
| 4 | USB Power/RTS/Reset_In | | USB_PWR | RTS | RTS | BUSY IN | RESET_IN |
| 5 | SWB+ | SWB+ | SWB+ | SWB+ | SWB+ | SWB+ | SWB+ |
| 6 | CTS/MCU_DE | | | CTS | CTS | BUSY OUT | MCU_DE |
| 7 | FS/DCD/DSP_DE | | | FS | DCD | | DSP_DE |
| 8 | SCK/RI/TCK | | | SCK | RI | | TCK |
| 9 | SRDA/DTR/TMS | | | SRDA | DTR | | TMS |
| 10 | STDA/DSR/TRST | | | STDA | DSR | | TRST |
| 11 | Bottom_Option_1 (BOT_OPT1) | BOT_OPT1 | BOT_OPT1 | BOT_OPT1 | BOT_OPT1 | BOT_OPT1 | BOT_OPT1 |
| 12 | Bottom_Option_2 (BOT_OPT2) | BOT_OPT2 | BOT_OPT2 | BOT_OPT2 | BOT_OPT2 | BOT_OPT2 | BOT_OPT2 |
| 13 | On_Off/JTAG/FLASH Mode (On_Off/JTAG) | On_Off /JTAG | On_Off /JTAG | On_Off /JTAG | On_Off /JTAG | On_Off /JTAG | On_Off /JTAG |
| 14 | Headset Indication/Key_Fail | Key | Key | HS/Key | Key | Key | |

Table 4.2-2 Bottom Connector Pin Out Table

Side Connector

The side connector is intended to support connection to accessories such as PSM, RSM, Headset, 2 or 4-wire data terminals and SB9600 based devices.

The side connector has 16 modes of operation as shown in Table 4.2-3.

In order to be compatible with previous generation radios, the modes of operation are selected by applying the appropriate logic levels to the Side Option Select Pins named SIDE_OPTION1, SIDE_OPTION2. In addition, SIDE_OPTION3 will be used to select the other modes as per Table 4.2-3. Voltage level for SIDE_OPTION3 is per Table 4.2-4.

Table 4.2-3 Side Connector Mode Table

| | Mode | SIDE OPTION1 | SIDE OPTION2 | SIDE OPTION3 |
|----|---------------------|--------------|--------------|--------------|
| 1 | Ext PTT | 0 | 0 | V4 |
| 2 | Emergency | 0 | 0 | V3 |
| 3 | Volume Up | 0 | 0 | V2 |
| 4 | Volume Down | 0 | 0 | V1 |
| 5 | Man Down | 0 | 0 | V0 |
| 6 | MAP27 | 1 | 0 | V4 |
| 7 | Spare | 1 | 0 | V3 |
| 8 | SB9600/SBEP | 1 | 0 | V2 |
| 9 | 4-Wire Data (RS232) | 1 | 0 | V1 |
| 10 | 2-Wire Data (RS232) | 1 | 0 | V0 |
| 11 | Ext Spkr | 0 | 1 | V4 |
| 12 | RSM with earbud | 0 | 1 | V3 |
| 13 | RSM/PSM | 0 | 1 | V2 |
| 14 | User Programmable 2 | 0 | 1 | V1 |
| 15 | User Programmable1 | 0 | 1 | V0 |
| 16 | Idle | 1 | 1 | V4 |

| Symbol | Min Level/V | Typical/V | Max Level/V |
|--------|-------------|-----------|-------------|
| V0 | 0 | 0.3 | 0.58 |
| V1 | 0.62 | 0.8 | 0.98 |
| V2 | 1.02 | 1.2 | 1.38 |
| V3 | 1.42 | 1.6 | 1.78 |
| V4 | 1.82 | 2.1 | 2.30 |


Table 4.2-4 Voltage Levels for Side Option3

| Pin No. | Signal Name |
|----------------|--------------------|
| 1 | Ext_Speaker+ |
| 2 | Ext_Speaker- |
| 3 | OPT B+ |
| 4 | Ext_Mic |
| 5 | SIDE_OPT2 |
| 6 | SIDE_OPT1 |
| 7 | GND |
| 8 | Rx_Data |
| 9 | Tx_Data |
| 10 | CTS / BUSY_OUT |
| 11 | RTS / BUSY_IN |
| 12 | SIDE_OPT3 |
| 13 | VIBRATOR |


Table 4.2-5 Side Connector Pin Out Table


THIS PAGE INTENTIONALLY LEFT BLANK

806-870 MHz Board Layout, Schematics & Parts Lists



ZMY0130995-A






| DNP (Do Not Place) List | | LARGEST REF DES. NUMBERS | |
|-------------------------|--|--------------------------|-------|
| R310 | | C328 | E302 |
| R317 | | R325 | D300 |
| | | U306 | TP321 |


| VCC TRUTH TABLE | |
|-----------------|--|
| V3_2.775V | = 2.775V (from GCAP3 V3) |
| PWM2_1.8V | = 1.875V (Redcap Core, ADDR/Data Bus, Flash, SRAM) |
| VSIM1 | = 3V for the SIM and QVCC |

ZMY0131007-0




ZMY0130997-0

DC Supply & Audio Schematic Diagram (GCAP 3) sheet 1 of 2




ZMY013010998-O


DC Supply & Audio Schematic Diagram (GCAP 3) sheet 2 of 2



ZMY0131008-O




ZMY013101009-O




ZMY0131014-O

**Switches And Associated Components
Schematic Diagram (sheet 1 of 2)**




ZMY0131015-O

Switches And Associated Components
Schematic Diagram (sheet 2 of 2)




ZMY0131011-A

Receiver Back End Schematic Diagram





Transmitter Schematic Diagram (sheet 1 of 2)




ZMY01301000-A

Transmitter Schematic Diagram (sheet 2 of 2)



ZMY0131012-O

Frequency Generation Unit Schematic Diagram



ZMY0131013-A

ESCORT Schematic Diagram

806-870 MHz Radio Parts List

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|----------------------------------|
| C006 | 2186133Z01 | Capacitor Array 33PF +/-10% 0805 |
| C007 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C008 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C009 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C010 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C014 | 2186133Z01 | Capacitor Array 33PF +/-10% 0805 |
| C015 | 2186133Z01 | Capacitor Array 33PF +/-10% 0805 |
| C100 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C101 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C102 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C104 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C105 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C112 | 2113743N33 | Cap Chip 20.0 PF 5% COG |
| C113 | 2113743N33 | Cap Chip 20.0 PF 5% COG |
| C114 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C115 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C116 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C117 | 2113743K16 | Cap Chip .220 UF +80-20% 16V |
| C118 | 2113743N44 | Cap Chip 56.0 PF 5% COG |
| C119 | 2113743N44 | Cap Chip 56.0 PF 5% COG |
| C200 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C201 | 2113928K09 | Cap Cer Chip 10.0 UF 6.3V 10% |
| C202 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C203 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C204 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C205 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C206 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C207 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C208 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C209 | 2113928C04 | Cap Cer Chip 4.7UF 6.3V10%0805 |
| C210 | 2185802B01 | Cap 10V 4.7UF |
| C211 | 2311049A72 | Cap Tant Chip 10.0UF 10% 10V |
| C212 | Not Placed | GCAM Dummy Part Number |
| C213 | Not Placed | GCAM Dummy Part Number |
| C214 | 2113928C04 | Cap Cer Chip 4.7UF 6.3V10%0805 |
| C215 | 2113928C04 | Cap Cer Chip 4.7UF 6.3V10%0805 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------|
| C216 | 2311049A72 | Cap Tant Chip 10.0UF 10% 10V |
| C217 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C218 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C219 | 2113743A27 | Cap Chip .470 UF 10% 16V |
| C220 | 2113743A27 | Cap Chip .470 UF 10% 16V |
| C221 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C222 | Not Placed | GCAM Dummy Part Number |
| C223 | 2113928K09 | Cap Cer Chip 10.0 UF 6.3V 10% |
| C224 | 2311049C15 | Cap Tant Chip 33.0 UF 10V 10% |
| C225 | 2311049A97 | Cap Tant Chip 33 UF 16V 20% |
| C227 | 2113928C04 | Cap Cer Chip 4.7UF 6.3V10%0805 |
| C229 | 2113928A01 | Cap Cer Chip 1.0 UF1 0V |
| C230 | 2113928A01 | Cap Cer Chip 1.0 UF1 0V |
| C231 | 2113928A01 | Cap Cer Chip 1.0 UF1 0V |
| C232 | 2113928A01 | Cap Cer Chip 1.0 UF1 0V |
| C233 | 2113928A01 | Cap Cer Chip 1.0 UF1 0V |
| C234 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C235 | 2113928A01 | Cap Cer Chip 1.0 UF1 0V |
| C236 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C237 | 2113743N30 | Cap Chip 15.0 PF 5% COG |
| C238 | 2113743N30 | Cap Chip 15.0 PF 5% COG |
| C239 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C240 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C241 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C242 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C243 | Not Placed | GCAM Dummy Part Number |
| C244 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C245 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C246 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C247 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C248 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C249 | 2113928C04 | Cap Cer Chip 4.7UF 6.3V10%0805 |
| C250 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C251 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C252 | 2113928K09 | Cap Cer Chip 10.0 UF 6.3V 10% |
| C253 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C254 | 2113928A01 | Cap Cer Chip 1.0 UF1 0V |
| C256 | Not Placed | GCAM Dummy Part Number |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------|
| C257 | Not Placed | GCAM Dummy Part Number |
| C258 | 2113928C04 | Cap Cer Chip 4.7UF 6.3V10%0805 |
| C259 | 2113928C04 | Cap Cer Chip 4.7UF 6.3V10%0805 |
| C260 | Not Placed | GCAM Dummy Part Number |
| C261 | 2113928C04 | Cap Cer Chip 4.7UF 6.3V10%0805 |
| C265 | Not Placed | GCAM Dummy Part Number |
| C267 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C269 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C270 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C271 | 2113928D08 | Cap Ceramic Chip 10.0UF |
| C272 | Not Placed | GCAM Dummy Part Number |
| C273 | 2113743H14 | Cap Chip 10.0 UF 16V +80-20% |
| C274 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C275 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C276 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C277 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C278 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C279 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C280 | 2113743T19 | Cap 10UF 16V Cer 3225 X5R |
| C282 | 2311049A97 | Cap Tant Chip 33 UF 16V 20% |
| C283 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C285 | 2113928A01 | Cap Cer Chip 1.0 UF1 0V |
| C286 | 2113743L03 | Cap Metal/poly Film 0.1 |
| C287 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C290 | 2113743L03 | Cap Metal/poly Film 0.1 |
| C291 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C292 | 2113743L03 | Cap Metal/poly Film 0.1 |
| C293 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C294 | 2113743L03 | Cap Metal/poly Film 0.1 |
| C295 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C296 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C297 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C298 | 2113741F47 | Cap Chip CL2 X7R Reel 8200 |
| C299 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C300 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C301 | 2113743M24 | CAP CHIP 100000 PF +80-20% Y5V |
| C302 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C303 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C304 | 2113741F45 | Cap Chip CL2 X7R Reel 6800 |
| C305 | 2113741F49 | Cap Chip CL2 X7R Reel 10000 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------|
| C306 | 2311049A59 | Cap Tant Chip A/P 10UF 10% 6V |
| C307 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C308 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C309 | 2113928P04 | Cap Cer Chip 1.0UF 20% 6.3V |
| C310 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C311 | 2113928P04 | Cap Cer Chip 1.0UF 20% 6.3V |
| C312 | 2311049A59 | Cap Tant Chip A/P 10UF 10% 6V |
| C313 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C314 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C315 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C316 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C317 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C318 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C319 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C320 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C321 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C322 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C323 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C324 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C325 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C326 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C327 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C450 | 2113928K09 | Cap Cer Chip 10.0 UF 6.3V 10% |
| C451 | 2113928K09 | Cap Cer Chip 10.0 UF 6.3V 10% |
| C455 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C456 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C457 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C458 | 2113743N03 | Cap Chip 1.0 PF +- .25PF COG |
| C459 | 2113743N08 | Cap Chip 1.6 PF +- .25PF COG |
| C460 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C461 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C462 | 2113743N41 | Cap Chip 43.0 PF 5% COG |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------|
| C466 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C467 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C469 | 2113743K16 | Cap Chip .220 UF +80-20% 16V |
| C470 | Not Placed | GCAM Dummy Part Number |
| C471 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C472 | 2113743L37 | Cap Chip 6800 PF 10% X7R |
| C473 | 2113743L10 | Cap Chip 510 PF 10% X7R |
| C475 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C476 | 2113743N19 | Cap Chip 5.1 PF +/-5PF COG |
| C477 | 2113743N19 | Cap Chip 5.1 PF +/-5PF COG |
| C478 | 2113743N03 | Cap Chip 1.0 PF +/-25PF COG |
| C479 | 2113743N19 | Cap Chip 5.1 PF +/-5PF COG |
| C480 | 2113743N11 | Cap Chip 2.4 PF +/-25PF COG |
| C481 | 2113743N11 | Cap Chip 2.4 PF +/-25PF COG |
| C482 | 2113743N19 | Cap Chip 5.1 PF +/-5PF COG |
| C483 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C484 | 2113743N12 | Cap Chip 2.7 PF +/-25PF COG |
| C485 | 2113743N20 | Cap Chip 5.6 PF +/-5PF COG |
| C486 | Not Placed | GCAM Dummy Part Number |
| C487 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C488 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C489 | 2113743N03 | Cap Chip 1.0 PF +/-25PF COG |
| C490 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C491 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C493 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C494 | 2170282A03 | High Cap MLCC,4.7UF |
| C495 | 2170282A03 | High Cap MLCC,4.7UF |
| C500 | 2113743N22 | Cap Chip 6.8 PF +/-5PF COG |
| C501 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C508 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C510 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C511 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C512 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C514 | 2113743N15 | Cap Chip 3.6 PF +/-25PF COG |
| C516 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C517 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C519 | Not Placed | GCAM Dummy Part Number |
| C522 | 2113743N26 | Cap Chip 10.0 PF 5% COG |
| C523 | 2113743N26 | Cap Chip 10.0 PF 5% COG |
| C524 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C527 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------|
| C528 | 2113743N54 | Cap Chip 150 PF 5% COG |
| C529 | Not Placed | GCAM Dummy Part Number |
| C530 | 2113743N18 | Cap Chip 4.7 PF +/-25PF COG |
| C531 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C533 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C534 | 2113743N34 | Cap Chip 22.0 PF 5% COG |
| C535 | 2113743N39 | Cap Chip 36.0 PF 5% COG |
| C536 | 2170282A03 | High Cap MLCC,4.7UF |
| C537 | 2113743N23 | Cap Chip 7.5 PF +/-5PF COG |
| C538 | 2113740L02 | Cap Cer Chip 2.2 PF+-0.1PF |
| C539 | 2113740F13 | Cap Chip Reel CL1 +/-30 2.7 |
| C540 | 2113743N23 | Cap Chip 7.5 PF +/-5PF COG |
| C601 | 2113743L05 | Cap Chip 330 PF 10% X7R |
| C602 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C605 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C606 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C607 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C608 | 2113743E12 | Cap Chip .047UF 10% X7R |
| C609 | 2113743L29 | Cap Chip 3300PF 10% X7R |
| C610 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C611 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C612 | 2113743E03 | Cer Chip Cap .015UF |
| C614 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C615 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C616 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C617 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C618 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C619 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C620 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C626 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C629 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C635 | 2113743L03 | Cap Metal/poly Film 0.1 |
| C636 | 2113743L03 | Cap Metal/poly Film 0.1 |
| C640 | 2113743L21 | Cap Chip 1500 PF 10% X7R |
| C641 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C643 | 0885126C07 | Cap 0.1 UF Poly |
| C644 | 0885126C07 | Cap 0.1 UF Poly |
| C645 | 0885126C07 | Cap 0.1 UF Poly |
| C646 | 0885126C07 | Cap 0.1 UF Poly |
| C647 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C651 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C652 | 2113743L41 | Cap Chip 10000 PF 10% X7R |
| C653 | Not Placed | GCAM Dummy Part Number |
| C700 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C701 | 2113743N12 | Cap Chip 2.7 PF +/-25PF COG |
| C702 | 2113743N12 | Cap Chip 2.7 PF +/-25PF COG |
| C703 | 2113743N09 | Cap Chip 2.0PF +/-25PF COG |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------|
| C704 | 2113743N11 | Cap Chip 2.4 PF +/-25PF COG |
| C705 | 2113743N08 | Cap Chip 1.6 PF +/-25PF COG |
| C706 | 2113743N11 | Cap Chip 2.4 PF +/-25PF COG |
| C709 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C710 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C711 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C712 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C713 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C718 | 2113743N03 | Cap Chip 1.0 PF +/-25PF COG |
| C720 | Not Placed | GCAM Dummy Part Number |
| C724 | 2113743N12 | Cap Chip 2.7 PF +/-25PF COG |
| C725 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C726 | 2113743N03 | Cap Chip 1.0 PF +/-25PF COG |
| C727 | Not Placed | GCAM Dummy Part Number |
| C728 | 2113743N38 | Cap Chip 33.0 PF 5% COG |
| C731 | 2113743N34 | Cap Chip 22.0 PF 5% COG |
| C732 | 2113743L05 | Cap Chip 330 PF 10% X7R |
| C734 | 2113743L03 | Cap Metal/poly Film 0.1 |
| C735 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C737 | 2113743L17 | Cap Chip 1000 PF 10% X7R |
| C738 | 2113743M08 | Cap Chip 22000PF +80-20% Y5V |
| C739 | 2113743L21 | Cap Chip 1500 PF 10% X7R |
| C740 | 2113743N21 | Cap Chip 6.2 PF +/-5PF COG |
| C741 | 2113743N16 | Cap Chip 3.9 PF +/-25PF COG |
| C742 | 2113743N24 | Cap Chip 8.2 PF +/-5PF COG |
| C743 | 2113743N26 | Cap Chip 10.0 PF 5% COG |
| C744 | 2113743N26 | Cap Chip 10.0 PF 5% COG |
| C745 | 2113743M24 | Cap Chip 100000 PF +80-20% Y5V |
| C746 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C748 | 2113743N44 | Cap Chip 56.0 PF 5% COG |
| C750 | 2113743N50 | Cap Chip 100 PF 5% COG |
| C751 | 2113743N54 | Cap Chip 150 PF 5% COG |
| C800 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C801 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C802 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C803 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C804 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C805 | 2311049J11 | Capacitor Tant 10% 4.7UF |
| C806 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C807 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C808 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C809 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|------------------------------|
| C810 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C811 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C812 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C813 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C814 | 2113743M08 | Cap Chip 22000PF +80-20% Y5V |
| C815 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C816 | 2113741F45 | Cap Chip CL2 X7R Reel 6800 |
| C817 | 2113743E07 | Cer Chip Cap .022UF |
| C818 | 2113743E07 | Cer Chip Cap .022UF |
| C819 | 2113741F41 | Cap Chip CL2 X7R Reel 4700 |
| C820 | 2113741F41 | Cap Chip CL2 X7R Reel 4700 |
| C821 | 2113743E07 | Cer Chip Cap .022UF |
| C822 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C823 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C824 | 2113743E07 | Cer Chip Cap .022UF |
| C825 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C826 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C827 | Not Placed | GCAM Dummy Part Number |
| C828 | 2113743N12 | Cap Chip 2.7 PF +/-25PF COG |
| C829 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C830 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C831 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C832 | 2113743M08 | Cap Chip 22000PF +80-20% Y5V |
| C833 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C835 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C836 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C844 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C845 | Not Placed | GCAM Dummy Part Number |
| C846 | Not Placed | GCAM Dummy Part Number |
| C848 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C849 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C850 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C851 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C852 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C853 | Not Placed | GCAM Dummy Part Number |
| C901 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C902 | 2311049C49 | Cap Tant Chip 100 UF 10% 16V |
| C903 | 2311049C49 | Cap Tant Chip 100 UF 10% 16V |
| C904 | 2311049C49 | Cap Tant Chip 100 UF 10% 16V |
| C907 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C908 | 2113743M08 | Cap Chip 22000PF +80-20% Y5V |
| C909 | 2113743M08 | Cap Chip 22000PF +80-20% Y5V |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------|
| C910 | 2113743M08 | Cap Chip 22000PF +80-20% Y5V |
| C912 | 2113743N12 | Cap Chip 2.7 PF +/- .25PF COG |
| C913 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C914 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C915 | 2113743N23 | Cap Chip 7.5 PF +/- .5PF COG |
| C916 | Not Placed | GCAM Dummy Part Number |
| C918 | 2113743N32 | Cap Chip 18.0 PF 5% COG |
| C920 | Not Placed | GCAM Dummy Part Number |
| C921 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C922 | Not Placed | GCAM Dummy Part Number |
| C924 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C926 | 2113743M08 | Cap Chip 22000PF +80-20% Y5V |
| C927 | 2113740L18 | Cap Cer Chip 10.0 PF +/- .25PF |
| C928 | Not Placed | GCAM Dummy Part Number |
| C931 | 2113743N21 | Cap Chip 6.2 PF +/- .5PF COG |
| C932 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C933 | 2113740F42 | Cap Chip Reel CL1 +/-30 43 |
| C934 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C935 | 2113740F42 | Cap Chip Reel CL1 +/-30 43 |
| C936 | 2113740L03 | Cap Cer Chip 2.4PF +/-0.1PF |
| C937 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C938 | 2113743N03 | Cap Chip 1.0 PF +/- .25PF COG |
| C939 | 2113743N20 | Cap Chip 5.6 PF +/- .5PF COG |
| C940 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C941 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C942 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C943 | 2113740L05 | Cap Cer Chip 3.0 PF +/-0.1PF |
| C944 | 2113740F03 | Cap Chip Reel CL1 +/-30 1.0 |
| C948 | 2113740F07 | Cap Chip Reel CL1 +/-30 1.5 |
| C949 | 2113740F42 | Cap Chip Reel CL1 +/-30 43 |
| C950 | 2113743M08 | Cap Chip 22000PF +80-20% Y5V |
| C951 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C955 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C956 | Not Placed | GCAM Dummy Part Number |
| C957 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C958 | Not Placed | GCAM Dummy Part Number |
| C961 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C962 | 2113743N41 | Cap Chip 43.0 PF 5% COG |
| C963 | Not Placed | GCAM Dummy Part Number |
| C964 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C965 | 2113740L10 | Cap Cer Chip 4.7 PF +/-0.1PF |
| C966 | 2113740L13 | Cap Cer Chip 6.2PF +/-0.1PF |
| C967 | Not Placed | GCAM Dummy Part Number |
| C968 | 2113928N01 | Cap Cer Chip 0.1UF 10% 6.3 |
| C969 | 2113743E05 | Cer Chip Cap .018UF |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------|
| D001 | 4809118D03 | Led Red/Grn RT ANGL 2X3MM SMD |
| D100 | 4802245J47 | Diode Schottky Barrier(RB471E) |
| D101 | 4802245J47 | Diode Schottky Barrier(RB471E) |
| D202 | 4813833A19 | Diode Schottky 1A 20V PWR-MITE |
| D203 | 4813833A19 | Diode Schottky 1A 20V PWR-MITE |
| D460 | 4809877C13 | Diode Varactor ISV305 SMD |
| D500 | 4813825A19 | Diode Schottky Barrier Series |
| D700 | 4809877C13 | Diode Varactor Isv305 Smd |
| D701 | 4809877C13 | Diode Varactor Isv305 Smd |
| D730 | 4809877C13 | Diode Varactor Isv305 Smd |
| D802 | 4885908A02 | Diode RF Pin |
| D803 | 4885908A02 | Diode RF Pin |
| D901 | 4809948D13 | Diode RF Switch BA892 ESC |
| D903 | 4809948D13 | Diode RF Switch BA892 ESC |
| E001 | 2486132Z01 | BK20104M601 Ferrite Bead Array |
| E002 | 2486132Z01 | BK20104M601 Ferrite Bead Array |
| E003 | 2486132Z01 | BK20104M601 Ferrite Bead Array |
| E004 | 2480640Z01 | C/IND BK1005HM471 Bead |
| E005 | 2480640Z01 | C/IND BK1005HM471 Bead |
| E100 | 2480640Z01 | C/IND BK1005HM471 Bead |
| E200 | 2480675U01 | 0805 CHIP-3AMP |
| E201 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E202 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E203 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E204 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E205 | 2480675U01 | 0805 Chip-3Amp |
| E206 | 2480675U01 | 0805 Chip-3Amp |
| E207 | 2480675U01 | 0805 Chip-3Amp |
| E208 | 2480675U01 | 0805 Chip-3Amp |
| E210 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E211 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E212 | 2480675U01 | 0805 Chip-3Amp |
| E215 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E300 | 2480067M02 | CHK RF Chip Bead Inductor |
| E301 | 2480067M02 | CHK RF Chip Bead Inductor |
| E302 | 2480067M02 | CHK RF Chip Bead Inductor |
| E500 | 2480640Z01 | C/IND BK1005HM471 Bead |
| E501 | 2480640Z01 | C/IND BK1005HM471 Bead |
| E806 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E807 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| E808 | 7608671Y02 | Ferrite Bead 500 Ohm SMD PKG |
| E810 | 7686949J02 | Ferrite Bead Chip-0402 Size |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---------------------------------|
| E811 | 7686949J02 | Ferrite Bead Chip-0402 Size |
| F200 | 6586221J04 | Fuse 2.5A 16V SMD |
| FL500 | 9186121Z01 | 850-870 MHz Bandpass SAW Filter |
| FL501 | 9186121Z01 | 850-870 MHz Bandpass SAW Filter |
| FL502 | 9186323Z01 | Filtr 3 POL SURF MT Xtal 109.65 |
| FL503 | 9164626E02 | Thin-FI L P FIT LP085A0967AWTR |
| FL801 | 5885915B01 | Isolator (Wideband) |
| H800 | 2680499Z01 | Heat Spreader |
| J001 | 0986237A02 | Connector (Contact Battery) |
| J002 | 0986017Z01 | Connector, 24 Pin Socket |
| J100 | 0905505Y04 | Conn Zif Horizontal |
| J110 | 0980472U01 | Connector 16Pos Right Angle |
| J800 | 2880658Z03 | Connector (SMA) |
| L200 | 2408603Y01 | Inductor 4.7UH |
| L201 | 2486085A02 | SMT Power Inductor 15UH +/-20% |
| L202 | 2404927K02 | Inductor Power 47UH +/-20% |
| L458 | 2485930A19 | IND 100NH 5% |
| L459 | 2413926G10 | IND 18.0 NH 5% |
| L461 | 2462587V35 | Chip Ind 120 NH 5% 0805 |
| L462 | 2485930A19 | IND 100NH 5% |
| L463 | 2485930A19 | IND 100NH 5% |
| L464 | 2485930A19 | IND 100NH 5% |
| L465 | 2413926G04 | IND 5.6 NH +/- 0.3 NH |
| L466 | 2413926G04 | IND 5.6 NH +/- 0.3 NH |
| L500 | 2487319K17 | Ind Cer WW 19NH 5% 1005 SMD |
| L501 | 2409377M03 | Ind Chip WW 6.8 NH 5% 1608 |
| L502 | 2487319K15 | Ind Cer WW 12NH 5% 1005 SMD |
| L503 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L505 | 2487319K12 | IND Cer WW 9NH 5% 1005 SMD |
| L507 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L508 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L509 | 2462587V41 | Ind Chip 390 NH 10% |
| L510 | 2462587V41 | Ind Chip 390 NH 10% |
| L513 | 2409377M05 | Ind Chip WW 12 NH 5% 1608 |
| L514 | 2409377M19 | Ind Chip WW 22 NH 5% 1608 |
| L520 | 2487319K10 | Ind Cer WW 7.5NH 5% 1005 SMD |
| L603 | 2487319K20 | Ind Cer WW 36NH 5% 1005 SMD |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--------------------------------------|
| L700 | 2409377M17 | Ind Chip WW 100 NH 5% 1608 |
| L701 | 2409377M17 | Ind Chip WW 100 NH 5% 1608 |
| L702 | 2409377M17 | Ind Chip WW 100 NH 5% 1608 |
| L703 | 2409377M17 | Ind Chip WW 100 NH 5% 1608 |
| L704 | 2487319K13 | Ind Cer WW 10NH 5% 1005 SMD |
| L705 | 2409377M17 | Ind Chip WW 100 NH 5% 1608 |
| L706 | 2487319K16 | Ind Cer WW 15NH 5% 1005 SMD |
| L730 | 2413926G15 | IND 47.0 NH 5% |
| L731 | 2409134J04 | Ind Chip Fer Fltr 600 0603 |
| L732 | 2487319K15 | Ind Cer WW 12NH 5% 1005 SMD |
| L800 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L801 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L807 | 2409377M04 | Ind Chip WW 10 NH 5% 1608 |
| L808 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L900 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L901 | 2409377M03 | Ind Chip WW 6.8 NH 5% 1608 |
| L902 | 2409377M02 | Ind Chip WW 3.9 NH 5% 1608 |
| L904 | 2113740F05 | Cap Chip Reel CL1 +/-30 1.2 |
| L905 | 0662057B47 | Chip Res 0 Ohms +/- .050 Ohms |
| L906 | 2485973Z01 | Toko's XS-3P wire-wound chip |
| L908 | 2485973Z10 | TTOKO'S XS-3P Wire-wound Inductor |
| L909 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L910 | 2413926G12 | IND 27.0 NH 5% |
| L911 | 2485973Z07 | Toko's XS-3P wire-wound inductor |
| L912 | 2485973Z06 | TOKO'S XS-3P Wire-wound Inductor (9) |
| L914 | 2409377M36 | Ind Chip WW 220 NH 5% 1608 |
| L915 | 2485973Z07 | Toko's XS-3P wire-wound inductor |
| L918 | Not Placed | GCAM Dummy Part Number |
| Q100 | 5102463J80 | FDC6330L Integrated load switch |
| Q101 | 5102463J80 | FDC6330L Integrated load switch |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| Q102 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 |
| Q103 | 4802245J54 | UMG5N Digital Transistor |
| Q201 | 5102463J80 | FDC6330L Integrated load switch |
| Q202 | 4805128M27 | SOT Trans |
| Q204 | 4802245J54 | UMG5N Digital Transistor |
| Q459 | 4805793Y01 | Trans Mini SOT NPN Low Noise |
| Q460 | 4805723X02 | Trans Dual PNP UMT1N ROHM |
| Q463 | 4805793Y01 | Trans Mini SOT NPN Low Noise |
| Q464 | 4805793Y01 | Trans Mini SOT NPN Low Noise |
| Q465 | 4802245J88 | Isolated Dual (NPN-PNP) Transistor |
| Q466 | 4805793Y01 | Trans Mini SOT NPN Low Noise |
| Q467 | 4802245J88 | Isolated Dual (NPN-PNP) Transistor |
| Q500 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 |
| Q501 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 |
| Q700 | 4805793Y01 | Trans Mini SOT NPN Low Noise |
| Q702 | 4805793Y01 | Trans Mini SOT NPN Low Noise |
| Q703 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 |
| Q730 | 4805793Y01 | Trans Mini SOT NPN Low Noise |
| Q731 | 4805723X03 | Trans Dual NPN-PNP UMD3N ROHM |
| Q800 | 4813828A09 | Tstr 8W 450MHZ 7.5V |
| Q801 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 |
| Q805 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 |
| Q806 | 4809939C05 | Tstr Dual NPN/PNP UMH 5 |
| R001 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R002 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R003 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R004 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R005 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R006 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R007 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R008 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R009 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R010 | Not Placed | GCAM Dummy Part Number |
| R100 | Not Placed | GCAM Dummy Part Number |
| R101 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R102 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R103 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R106 | 2486261Z01 | BLM18BA470SN1-EMIFIL Chip Ferrite Bead |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| R107 | 2486261Z01 | BLM18BA470SN1-EMIFIL Chip Ferrite Bead |
| R108 | 0662057A85 | Chip Res 33K Ohm 5% |
| R109 | 0686135Z01 | Current Sensor Resistor (0.1ohm) |
| R110 | 0662057A73 | Chip Res 10K OHMS 5% |
| R111 | 0662057A73 | Chip Res 10K OHMS 5% |
| R112 | 0662057N01 | Res. Chip 12K 5% 20X40 |
| R113 | 0662057M95 | Res. Chip 7500 5% 20X40 |
| R114 | 0662057A85 | Chip Res 33K OHM 5% |
| R115 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R116 | 0662057M82 | Res. Chip 2200 5% 20X40 |
| R117 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R118 | 0662057N17 | Res. Chip 56K 5% 20X40 |
| R119 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R120 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R121 | 2486261Z01 | BLM18BA470SN1-EMIFIL Chip Ferrite Bead |
| R122 | 2486261Z01 | BLM18BA470SN1-EMIFIL Chip Ferrite Bead |
| R202 | 0662057N15 | Res. Chip 47K 5% 20X40 |
| R203 | 0662057N15 | Res. Chip 47K 5% 20X40 |
| R204 | 0662057N15 | Res. Chip 47K 5% 20X40 |
| R205 | 0662057N17 | Res. Chip 56K 5% 20X40 |
| R206 | 0662057M96 | Res. Chip 8200 5% 20X40 |
| R207 | 0662057M96 | Res. Chip 8200 5% 20X40 |
| R208 | 0662057B20 | Chip Res 820K OHMS 5% |
| R209 | 0662057M82 | Res. Chip 2200 5% 20X40 |
| R210 | 0662057N11 | Res. Chip 33K 5% 20X40 |
| R211 | 0662057M93 | Res. Chip 6200 5% 20X40 |
| R212 | 0662057N11 | Res. Chip 33K 5% 20X40 |
| R213 | 0662057M82 | Res. Chip 2200 5% 20X40 |
| R214 | 0662057M82 | Res. Chip 2200 5% 20X40 |
| R215 | 0662057N30 | Res. Chip 200K 5% 20X40 |
| R216 | Not Placed | GCAM Dummy Part Number |
| R217 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R218 | Not Placed | GCAM Dummy Part Number |
| R220 | 0662057B05 | Chip Res 200K Ohms 5% |
| R221 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R222 | Not Placed | GCAM Dummy Part Number |
| R223 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R225 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R229 | 0662057A85 | Chip Res 33K OHM 5% |
| R230 | 0662057M96 | Res. Chip 8200 5% 20X40 |
| R232 | 0662057M50 | Res. Chip 100 5% 20X40 |
| R234 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R235 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R240 | 0662057N11 | Res. Chip 33K 5% 20X40 |
| R241 | 0662057N11 | Res. Chip 33K 5% 20X40 |
| R242 | 0662057M94 | Res. Chip 6800 5% 20X40 |
| R243 | 0662057M74 | Res. Chip 1000 5% 20X40 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|------------------------------|
| R244 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R245 | 0662057M90 | Res. Chip 4700 5% 20X40 |
| R252 | 0662057N06 | Res. Chip 20K 5% 20X40 |
| R254 | 0662057V30 | Res. Chip 130K 1% 1/16W |
| R255 | 0662057M26 | Res. Chip 10 5% 20X40 |
| R256 | 0662057N06 | Res. Chip 20K 5% 20X40 |
| R271 | 0662057M78 | Res. Chip 1500 5% 20X40 |
| R272 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R274 | 0662057N16 | Res. Chip 51K 5% 20X40 |
| R275 | 0662057N14 | Res. Chip 43K 5% 20X40 |
| R277 | 0662057B10 | Chip Res 330K OHMS 5% |
| R278 | 0662057N06 | Res. Chip 20K 5% 20X40 |
| R279 | 0662057V30 | Res. Chip 130K 1% 1/16W |
| R280 | 0662057M98 | Res. Chip 10K 5% 20X40 |
| R281 | 0662057M98 | Res. Chip 10K 5% 20X40 |
| R284 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R285 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R286 | Not Placed | GCAM Dummy Part Number |
| R287 | 0662057N23 | Res. Chip 100K 5% 20X40 |
| R290 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R294 | Not Placed | GCAM Dummy Part Number |
| R295 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R296 | 0662057A41 | Chip Res 470 OHMS 5% |
| R297 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R298 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R300 | 0662057B47 | Chip Res 0 Ohms +- .050 Ohms |
| R301 | 0662057B47 | Chip Res 0 Ohms +- .050 Ohms |
| R302 | 0662057B47 | Chip Res 0 Ohms +- .050 OHMS |
| R303 | 0662057B47 | Chip Res 0 Ohms +- .050 Ohms |
| R304 | 0662057B47 | CHIP RES 0 Ohms +- .050 Ohms |
| R305 | 0662057B47 | Chip Res 0 Ohms +- .050 Ohms |
| R306 | 0662057B47 | Chip Res 0 Ohms +- .050 Ohms |
| R307 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R308 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R309 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R310 | Not Placed | GCAM Dummy Part Number |
| R312 | 0662057A17 | Res. Chip 47 Ohms 5% |
| R313 | Not Placed | GCAM Dummy Part Number |
| R314 | 0662057N07 | Res. Chip 22K 5% 20X40 |
| R315 | 0662057M94 | Res. Chip 6800 5% 20X40 |
| R316 | Not Placed | GCAM Dummy Part Number |
| R318 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R319 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R320 | 0662057M01 | Res. Chip 0 5% 20X40 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|-------------------------|
| R321 | Not Placed | GCAM Dummy Part Number |
| R322 | Not Placed | GCAM Dummy Part Number |
| R323 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R324 | 0662057N13 | Res. Chip 39K 5% 20X40 |
| R325 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R452 | 0662057M43 | Res. Chip 51 5% 20X40 |
| R453 | 0662057M50 | Res. Chip 100 5% 20X40 |
| R454 | 0662057M84 | Res. Chip 2700 5% 20X40 |
| R456 | 0662057M87 | Res. Chip 3600 5% 20X40 |
| R457 | 0662057M30 | Res. Chip 15 5% 20X40 |
| R458 | 0662057M30 | Res. Chip 15 5% 20X40 |
| R459 | 0662057M30 | Res. Chip 15 5% 20X40 |
| R460 | 0662057M98 | Res. Chip 10K 5% 20X40 |
| R461 | 0662057N23 | RES CHIP 100K 5% 20X40 |
| R462 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R463 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R464 | 0662057M58 | Res. Chip 220 5% 20X40 |
| R465 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R466 | 0662057N06 | Res. Chip 20K 5% 20X40 |
| R467 | 0662057M98 | RES CHIP 10K 5% 20X40 |
| R468 | 0662057M44 | RES, CHIP 56 5% 20X40 |
| R470 | 0662057M26 | Res. Chip 10 5% 20X40 |
| R471 | 0662057M50 | Res. Chip 100 5% 20X40 |
| R472 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R473 | 0662057M66 | Res. Chip 470 5% 20X40 |
| R474 | 0662057M26 | Res. Chip 10 5% 20X40 |
| R476 | 0662057M52 | Res. Chip 120 5% 20X40 |
| R477 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R478 | 0662057M70 | Res. Chip 680 5% 20X40 |
| R479 | 0662057M26 | Res. Chip 10 5% 20X40 |
| R480 | Not Placed | GCAM Dummy Part Number |
| R481 | Not Placed | GCAM Dummy Part Number |
| R482 | 0662057M66 | Res. Chip 470 5% 20X40 |
| R483 | 0662057M52 | Res. Chip 120 5% 20X40 |
| R498 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R499 | 0662057M52 | Res. Chip 120 5% 20X40 |
| R500 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R502 | 0662057M58 | Res. Chip 220 5% 20X40 |
| R506 | Not Placed | GCAM Dummy Part Number |
| R509 | 0662057M32 | Res. Chip 18 5% 20X40 |
| R510 | 0662057M50 | Res. Chip 100 5% 20X40 |
| R511 | 0662057M40 | Res. Chip 39 5% 20X40 |
| R516 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R528 | 0662057M60 | Res. Chip 270 5% 20X40 |
| R529 | 0662057M60 | Res. Chip 270 5% 20X40 |
| R602 | Not Placed | GCAM Dummy Part Number |
| R603 | 0662057M82 | Res. Chip 2200 5% 20X40 |
| R604 | 0662057M38 | Res. Chip 33 5% 20X40 |
| R608 | Not Placed | GCAM Dummy Part Number |
| R610 | Not Placed | GCAM Dummy Part Number |
| R611 | Not Placed | GCAM Dummy Part Number |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|-------------------------------|
| R612 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R621 | 0662057M92 | Res. Chip 5600 5% 20X40 |
| R623 | 0662057M46 | Res. Chip 68 5% 20X40 |
| R624 | 0662057M57 | Res. Chip 200 5% 20X40 |
| R627 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R700 | 0662057M26 | Res. Chip 10 5% 20X40 |
| R701 | 0662057M57 | Res. Chip 200 5% 20X40 |
| R704 | 0662057M90 | Res. Chip 4700 5% 20X40 |
| R705 | 0662057M96 | Res. Chip 8200 5% 20X40 |
| R706 | 0662057M44 | Res. Chip 56 5% 20X40 |
| R707 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R708 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R709 | 0662057M87 | Res. Chip 3600 5% 20X40 |
| R710 | 0662057M87 | Res. Chip 3600 5% 20X40 |
| R711 | 0662057M60 | Res. Chip 270 5% 20X40 |
| R713 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R733 | 0662057M89 | Res. Chip 4300 5% 20X40 |
| R734 | 0662057M82 | Res. Chip 2200 5% 20X40 |
| R735 | 0662057M98 | RES CHIP 10K 5% 20X40 |
| R736 | 0662057M60 | Res. Chip 270 5% 20X40 |
| R737 | 0662057N05 | Res. Chip 18K 5% 20X40 |
| R738 | 0662057M50 | Res. Chip 100 5% 20X40 |
| R800 | 0662057M50 | Res. Chip 100 5% 20X40 |
| R801 | 0662057M67 | Res. Chip 510 5% 20X40 |
| R802 | 0662057M43 | Res. Chip 51 5% 20X40 |
| R803 | 0662057M43 | Res. Chip 51 5% 20X40 |
| R804 | 0662057M43 | Res. Chip 51 5% 20X40 |
| R806 | 0662057B47 | Chip Res 0 OhmS +/- .050 Ohms |
| R807 | 0662057A93 | Chip Res 68K OHMS 5% |
| R808 | 0662057M43 | Res. Chip 39 5% 20X40 |
| R809 | 0662057M92 | Res. Chip 5600 5% 20X40 |
| R810 | 0662057M43 | Res. Chip 39 5% 20X40 |
| R901 | Not Placed | GCAM Dummy Part Number |
| R902 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R908 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R909 | 0662057M43 | Res. Chip 51 5% 20X40 |
| R910 | Not Placed | GCAM Dummy Part Number |
| R911 | 0662057M32 | Res. Chip 18 5% 20X40 |
| R912 | 0662057M61 | Res. Chip 300 5% 20X40 |
| R913 | 0662057M56 | Res. Chip 180 5% 20X40 |
| R914 | 0662057M37 | Res. Chip 30 5% 20X40 |
| R915 | 0662057M56 | Res. Chip 180 5% 20X40 |
| R916 | 0662057M61 | Res. Chip 300 5% 20X40 |
| R919 | 0662057N07 | Res. Chip 22K 5% 20X40 |
| R920 | Not Placed | GCAM Dummy Part Number |
| R921 | 0662057M01 | Res. Chip 0 5% 20X40 |
| R922 | Not Placed | GCAM Dummy Part Number |
| R923 | Not Placed | GCAM Dummy Part Number |
| R924 | 0662057N11 | Res. Chip 33K 5% 20X40 |
| R929 | 0662057N07 | Res. Chip 22K 5% 20X40 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|-------------------------------------|
| R930 | 0662057M74 | Res. Chip 1000 5% 20X40 |
| R931 | 0662057A32 | Chip Res 200 OHMS 5% |
| RT200 | 0686931J01 | Termistor 47K |
| RT800 | 0686931J01 | Termistor 47K |
| S001 | 4080710Z06 | Frequency Switch (reflow 250oC) |
| S002 | 4070354A01 | Light Touch Switch-SMD |
| S003 | 4070354A01 | Light Touch Switch-SMD |
| S004 | 4070354A01 | Light Touch Switch-SMD |
| S005 | 4070354A01 | Light Touch Switch-SMD |
| S100 | 4070354A01 | Light Touch Switch-SMD |
| SH200 | 2686114Z01 | Primary Shield, GCAP3 |
| SH201 | 2686120Z01 | Primary Shield, Switching Regulator |
| SH300 | 2686110Z01 | Primary Shield, Controller |
| SH301 | 2686119Z01 | Primary Shield, Memories |
| SH400 | 2686106Z01 | Primary Shield, ESCORT |
| SH500 | 2686115Z01 | Primary Shield, RxFE1 |
| SH501 | 2686116Z01 | Primary Shield, RxFE2 |
| SH600 | 2686117Z01 | Primary Shield, WPIC |
| SH700 | 2686105Z01 | Primary Shield, Main VCO |
| SH730 | 2686118Z01 | Primary Shield, 2ND LO |
| SH800 | 2686109Z01 | Primary Shield, ODCT1 |
| SH801 | 2686113Z01 | Primary Shield, ODCT2 |
| SH900 | 2686107Z01 | Primary Shield, Antenna SW & HF1 |
| SH901 | 2686111Z01 | Primary Shield, Antenna SW & HF2 |
| SH902 | 2686108Z01 | Primary Shield, PA1 |
| SH903 | 2686112Z01 | Primary Shield, PA2 |
| T800 | 2585959A01 | Transformer BALUN Ceramic |
| U001 | 5102463J90 | NL27WZ16-Dual Buffer |
| U002 | 5102463J90 | NL27WZ16-Dual Buffer |
| U005 | 9185759B01 | Filtr RC Network |
| U100 | 9185759B01 | Filtr RC Network |
| U101 | 9185759B01 | Filtr RC Network |
| U102 | 9185759B01 | Filtr RC Network |
| U103 | 9185759B01 | Filtr RC Network |
| U104 | 9185759B01 | Filtr RC Network |
| U105 | 9185759B01 | Filtr RC Network |
| U111 | 5162852A62 | IC MAX4373T, Low Cost MIRCPOWER |
| U200 | 5109879E83 | IC BICMOS GCAP3 V 2.6 179 BGA |
| U201 | 5102463J75 | MAX1685 Step Down Regulator |
| U202 | 5102463J44 | Audio Amplifier TDA8547TS |
| U205 | 5102463J82 | ADP3331 Linear Voltage Regulator |
| U301 | 5185368C99 | IC REDCAP 2 256 PIN BGA ROM3 |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|---|
| U302 | 5109509A43 | IC 512K X 16 1MB SRAM |
| U303 | 5102476J01 | Intel 64MBIT Flash GE28F640C3 |
| U304 | 5109522E22 | IC Sngl And Gate TC7S08FU |
| U305 | 5102463J77 | MC74HC1G04 NOT GATE |
| U307 | 5109522E22 | IC Sngl And Gate TC7S08FU |
| U460 | 5185368C18 | ESCORT IC IN 16 PIN QFN Package |
| U461 | 5102463J74 | Bipolar Linear Regulator 4.5V |
| U500 | 5185368C01 | IC 3V Low Noise AMP |
| U502 | 5102463J96 | MMIC Mixer With IF Buffer |
| U601 | 5185368C21 | WPIC 3.1 |
| U730 | 5186226J12 | PLL Dual Freq Synt. LMX2332 |
| U800 | 5185130C65 | IC VHF/UHF/800 MHz LDMOS Driver |
| U801 | 5886201Z01 | CHIP Multilayer3DB/90Deg Splitter |
| U802 | 5102463J79 | MAX5401 Low-Drift Digital Potentiometer |
| U803 | 5108428S43 | Low Noise ODCT |
| U806 | 5102463J86 | Coupler Without Internal Low Pass Filter(H) |
| U907 | 5162852A09 | Low Pwr OP AMP W/Rail To Rail |
| VR001 | 4805656W08 | Diode Zener Quad |
| VR002 | 4805656W08 | Diode Zener Quad |
| VR006 | 4813830C11 | Diode 3.9V 'D3' MMSZ5228BT1 |
| VR007 | 4805656W08 | Diode Zener Quad |
| VR008 | 4813830C11 | Diode 3.9V 'D3' MMSZ5228BT1 |
| VR009 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| VR100 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| VR101 | 4805656W08 | Diode Zener Quad |
| VR102 | 4805656W08 | Diode Zener Quad |
| VR103 | 4805656W08 | Diode Zener Quad |
| VR104 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| VR105 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| VR106 | 4813830C11 | Diode 3.9V 'D3' MMSZ5228BT1 |
| VR201 | 4813830C26 | Diode 13V 'H3' MMSZ5243BT1 |
| Y200 | 4809995L05 | Xtal Quartz 32.768KHZ CC4V-T1 |
| Y460 | 4805911Z02 | Resonator Ceramic |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|------------------------------------|
| Y601 | 5102463J73 | Ref Oscillator 16.8MHz, 1ppm, SMD, |
| Y700 | 4805911Z02 | Resonator Ceramic |

THIS PAGE INTENTIONALLY LEFT BLANK

Troubleshooting (800 MHz)

General

Troubleshooting faults in the radio require proper understanding of the different circuitry contained in the radio. Since the radio contains a highly integrated system, the software and hardware functions can not be separated easily. Thus, it is also necessary to understand the functioning of different ICs and the role of the software in the operation of the radio.

This service manual includes schematic diagrams, circuit board layouts, block diagrams, and troubleshooting procedures, which help a technician to troubleshoot a malfunctioning circuit and detect a defective component.

NOTE The CPS has no capability to tune the radio. Tuning the radio can only be performed at the factory or at the appropriate Motorola Repair Centre. Components replacement can affect the radio tuning and must only be performed by the appropriate Motorola Repair Centre.

The radio is tuned and tested at the factory. The results of the tuning procedures are stored in a special EEPROM. This information includes tuning and other system parameters. The area of the memory in the radio where the tuning information stored is called the "codeplug". A radio codeplug can be read using the CPS programme.

Test Procedures

This section explains the procedures required to troubleshoot a MTP700 radio.


The digital tests should be performed using the GoNoGo PATS test and TETRACom SW. To use the TETRACom you must go to test mode by using the command <Test Enter>.

Troubleshooting Flowcharts


Use the following flowcharts to troubleshoot the radio. These flowcharts contain procedures using TETRACom SW application, GoNoGo PATS test and factory test modes for troubleshooting radios having digital, receiver, transmitter, or frequency generation test failures.

Digital Analysis Test


Use this test for troubleshooting the main board.



Digital Analysis Test (Cont.)



Digital Analysis Test (Cont.)



DC Distribution (V2_2.775V) Test


Use this test on a unit with the following symptoms: no power, no V2_2.775V, V1_2.775V, V3_2.775V, VREF1_2.775V, VREF2_2.775V.

Note: The following are the DC power distribution voltages with their correct values and appropriate location to check the voltages:

- Fused B+ (7.2Vdc) @ F200.
- Filt_3.3V (3.3Vdc) @ C282.
- V1_3V (3Vdc) @ C211.
- V2_2.775V (2.775Vdc) @ C210.
- V3_2.775V (2.775Vdc) @ C209, C258, C259.
- VREF1_2.775V (2.775Vdc) @ C285.
- VREF2_2.775V (2.775Vdc) @ C212.
- V4_2.775V (2.775Vdc) @ C225, C244, C247.
- 5V_RF (5Vdc) @ C251, C223.
- PWM1_1.8V (1.8Vdc) @ C224, C248.
- 5.5V_RF (5.5Vdc) @ C299


DC Distribution (5.5V_RF) Test

Use this test on a unit with the following symptoms: no 5.5V_RF.




DC Distribution (5V_RF) Test

Use this test on a unit with the following symptoms: no 5V_RF.




DC Distribution (BOT_SWB+) Test

Use this test on a unit with the following symptoms: no BOT_SWB+




DC Distribution (SWB+ 7.2V) Test

Use this test on a unit with the following symptoms: no 7.2Vdc SWB+.




DC Distribution (V1_3V) Test


Use this test on a unit with the following symptoms: no V1_3V.




DC Distribution (V2_2.775V) Test



DC Distribution (V2_2.775V) Test (Cont.)




DC Distribution (V2_2.775V) Test (Cont.)




DC Distribution (V3_2.775V/PWM1_1.8V) Test

Use this test on a unit with the following symptoms: no V3_2.775V, no PWM1_1.8V.




DC Distribution (V4_2.775V) Test

Use this test on a unit with the following symptoms: no V4_2.775V.




DC Distribution (VREF1_2.775V) Test

Use this test on a unit with the following symptoms: no VREF1_2.775V.




DC Distribution (VREF2_2.775V) Test

Use this test on a unit with the following symptoms: no VREF2_2.775V.




Standby Current Troubleshooting


This test should be carried out only after the successful completion of the previous tests.




Receiver Troubleshooting



Escort Troubleshooting




Escort Troubleshooting (cont.)




Closed Loop Power Test

This test should be carried out only after the successful completion of the previous tests.




Open Loop Power Test


This test should be carried out only after the successful completion of the previous tests.



Open Loop Power Test (Cont.)




Open Loop Power Test (Cont.)




Transmitter Current Consumption Test

This test should be carried out only after the successful completion of the previous tests.




2nd LO Troubleshooting




Synthesizer & VCO Troubleshooting

Use this test on a unit with the following symptom: no Tx or Rx.



Synthesizer & VCO Troubleshooting (Cont.)



THIS PAGE INTENTIONALLY LEFT BLANK

CHAPTER 5

PROGRAMMING THE RADIO

Before Using the Customer Programming Software (CPS)

Before you begin programming, ensure the following:

1. Install the Customer Programming Software (CPS), FVN5051A, in your computer.
2. Use a fully charged radio battery.
3. With the radio initially turned off, properly place radio into Programming Stand, PMLN4510.
4. Connect the Programming/Data cable, FLN9636, according to Setup for Radio Programming Figure 5-1. This cable has a switch with two positions "Data" and "Flash". Set the switch to "Flash" to enable programming.
5. Turn radio on by rotating the On/Off knob clockwise. Verify that no display appears on the radio LCD screen.





Figure 5-1 Setup for Radio Programming.

Reading Codeplug

1. Run the Customer Programming Software (CPS) on your computer.
2. Click the Toolbar “Read Phone” icon. *Refer to the CPS Application Window Screen in the CPS User Guide, Publication No. 68P02956C20.* The setup enters an initialization process that takes about 20 seconds. After that, a reading process starts.

Note: While reading is in progress, the radio screen displays the following data:



A progress bar appears on the computer screen. After the reading process is finished, the radio Codeplug screen appears.

Programming Codeplug

1. On the menu bar, click “File”, “Open”.
2. Browse for the required Codeplug file and open the file (.dbf extension).
3. The Codeplug window appears on the screen.
4. Click the Toolbar “Write Phone” icon.

Note: The Codeplug is now being written into the radio. A progress bar is displayed on the computer screen showing the writing status.
After a successful writing, the message “The Operation Was Successful” appears on the computer screen.

5. Press the “OK” button.

Programming Frequency

Carry out the following steps if you need to add or change the radio frequencies.

Note: Save your radio factory frequencies before you start programming by using “File”, “Save As”. Give the file a proper name, eg “default.dbf”.

1. In the “Codeplug Tree” select “System Parameters”.
 - Click on “Frequency List”.
 - Click on “List2”.
 - At the top of list, enter the three frequencies which you have selected (the following frequencies are for example only):

Rx 420.0125MHz (IFR 800)

Rx 425.0125MHz (IFR 1000)

Rx 429.9875MHz (IFR 1199)

2. Click the Toolbar “Write Phone” icon.
3. Disconnect the radio from the programming kit.

Note: The new programmed frequencies of the radio are now available to be tested with the IFR or for any other use.

“List2” frequencies are saved on the codeplug and may only be accessed in Test Page mode. To go into Test Page (feature must be turned on in CPS i.e. “User Personal Data\Ergonomic Parameters\Feature Flags\Test Page” checked on), perform steps 4 thru 7 by pressing the radio keys sequentially (less then a second between every consecutive press):

4. *Press the “Side Button 2” key.*
5. *Press the “1” key, and “Menu” key.*
6. *Press the “2” key, and “Menu” key.*
7. *Press the “3” key.*

Hereafter, there is no need for quick sequence of pressing the radio keys.

8. Scroll through the list and select “Cell Lists”.
9. Press the “OK” key.
10. Scroll through the list. Select “List2”.
11. Press the “OK” key.
12. View the frequencies using the arrow navigation keys.

Restoring Factory Frequencies of the Radio

To restore the factory frequencies of the radio, perform the following steps:

1. After testing your radio on the IFR, connect the setup as shown in Figure 5-1.
2. Run the CPS software on your PC.
3. In the menu bar click "Tools", "Copy Wizard".
 - Click on "Read from a file".
 - Click on "Browse".
 - Open the file which contains the default factory frequencies (ie "default.dbf" file which you saved in "Programming Factory" section earlier).
 - Click on "Next".
 - Click on "Select All".
 - Click on "Next".
 - Click on "Write".
 - Click on "Done".

Note: Click on toolbar "Read Phone" to check whether the same factory frequencies were entered into the radio before programming.

Programming Firmware

Note: Login as "Administrator" to perform this task.

1. On the menu bar click "Tools", "Write Software".

Note: The CPS reads data from the radio. A progress bar is displayed on the computer screen showing the reading status.
After a successful reading, the "Write Software To Phone" window appears on the computer screen.

2. Press the "Write" button.

Note: The application is now being written into the radio. A progress bar is displayed on the computer screen showing the writing status.
After a successful writing, the message "The Operation Was Successful" appears on the computer screen.

3. Press the "OK" button.
4. Click the Toolbar "R" (Reset) icon to put radio into normal operating mode.

Manual Mode Testing

Preparation for Testing

1. Verify that the radio is turned off.
2. Press the “1”, “2” and “3” keys together and turn the On/Off knob clockwise to turn the radio on.
3. The display shows “LCD Test Press Any Key To Proceed”.

Tests

Note: Any key that will be pressed will cause the test to advance from one step to the next.

LCD Display Test

1. Press any key consecutively. The display shows horizontal lines that becomes thicker with every key press, until it becomes fully dark.
2. Press any key again, the following appears at the top of the display:



3. Press any key consecutively. The display shows vertical lines that becomes thicker with every key press, until it becomes fully dark.
4. Press any key again. The display shows the Motorola logo.
5. Press any key again. The display shows “Vibrator On”. You will need to have an external Smart RSM (RMN5011_ or RMN5012_) to verify that the radio is vibrating.
6. Press any key again. The display shows “Red Led On” and the Red LED at the top of the radio is constantly lit.
7. Press any key again. The display shows “Green Led On” and the Green LED at the top of the radio is constantly lit.
8. Press any key again. The display shows “Both Leds On” and the amber LED at the top of the radio is flashing.
9. Press any key again. The display shows “Backlight On” and the display and keypad backlight are both on.
10. Press any key again. The display shows “Speaker Tone Test”, a tone is heard via the speaker.

11. Press any key again. The display shows "Earpiece Tone Test", a tone is heard via the earpiece.
12. Press any key again. The display shows "Audio Loopback Test", speak into the microphone, you should hear your voice via the earpiece.
13. Press any key again. The display shows "Chopper-Noise Test 1", a low hum must not be heard via the earpiece.
14. Press any key again. The display shows "Chopper-Noise Test 2", a low hum must not be heard via the earpiece.
15. Press any key again. The display shows the "Rotary Knob Test" map.
16. Rotate the talkgroup knob from location "1" until "16" and make sure at each location the corresponding number disappears from the display.
17. The display proceeds to show all the radio keys, knobs and buttons.
18. Press every radio item one by one. Each item you press causes its respective display to disappear.
19. The display then shows "Press any key to Continue".
20. Pressing any key will cause display to show a series of "*", "<" and ">" characters.
21. Press the Top Navigation key until all top four "*" characters disappear.
22. Press the Bottom Navigation key until all bottom four "*" characters disappear.
23. Press the Left Navigation key until all left four "<" characters disappear.
24. Press the Right Navigation key until all right four ">" characters disappear.
25. After pressing all keys, the display is clear.
26. Turn the radio Off.

CHAPTER 6

MAINTENANCE

Introduction

This chapter provides details about the following:

- Preventive Maintenance (inspection and cleaning)
- Safe Handling of CMOS and LDMOS Devices
- Repair Procedures and Techniques
- Disassembly and Reassembly of the Radio

Preventive Maintenance

The portable radio does not require a scheduled preventive maintenance program. However, periodic visual inspection is recommended.

Inspection

Check that the external surfaces of the radio are clean, and that all external controls and switches are functional. It is not recommended to inspect the interior electronic circuitry.

Cleaning Procedures

The following procedures describe the recommended cleaning agents and methods to be used when cleaning the external and internal surfaces of the radio. External surfaces should be cleaned whenever a periodic visual inspection reveals the presence of smudges, compound, or grime. Internal surfaces (circuit boards and components) should only be cleaned when the radio is disassembled for servicing or repair.

NOTE Internal surfaces should be cleaned only when the radio is disassembled for service or repair.

The only recommended agent for cleaning external radio surfaces is a 0.5% solution (one teaspoon of detergent per gallon of water) of mild dishwashing detergent in water. The internal surfaces should only be cleaned with isopropyl alcohol (70% by volume).



CAUTION: The effects of certain chemicals and their vapors can have harmful results on certain plastics. Avoid using aerosol sprays, tuner cleaners and other chemicals.

Cleaning External Plastic Surfaces

Apply the 0.5% detergent-water solution sparingly with a stiff, non-metallic, short-bristled brush to work all loose dirt away from the radio. Use a soft, absorbent, lintless cloth or tissue to remove the solution and dry the radio. Make sure that no water remains entrapped near the connectors, cracks, or crevices.

Cleaning Internal Circuit Boards and Components

Isopropyl alcohol (70%) may be applied with a stiff, non-metallic, short-bristled brush to dislodge embedded or caked materials located in hard-to-reach areas. The brush stroke should direct the dislodged material out and away from the inside of the radio. Make sure that controls or tunable components are not soaked with alcohol. Do not use high-pressure air to hasten the drying process since this could cause the liquid to collect in unwanted places. After completing of the cleaning process, use a soft, absorbent, lintless cloth to dry the area. Do not brush or apply any isopropyl alcohol to the frame, front cover, or back cover.

NOTE Always use a fresh supply of alcohol and a clean container to prevent contamination by dissolved material (from previous usage).

Safe Handling of CMOS and LDMOS Devices

Complementary metal-oxide semiconductor (CMOS) devices are used in this family of radios, and are susceptible to damage by electrostatic or high voltage charges. Damage can be latent, resulting in failures occurring weeks or months later. Therefore, special precautions must be taken to prevent device damage during disassembly, troubleshooting, and repair.

Handling precautions are mandatory for CMOS circuits and are especially important in low humidity conditions. DO NOT attempt to disassemble the radio without first referring to the following CAUTION statement.



CAUTION: This radio contains static-sensitive devices. Do not open the radio unless you are properly grounded. Take the following precautions when working on this unit:

- Store and transport all CMOS devices in conductive material so that all exposed leads are shorted together. Do not insert CMOS devices into conventional plastic "snow" trays used for storage and transportation of other semiconductor devices.
- Ground the working surface of the service bench to protect the CMOS device. We recommend using the Motorola Static Protection Assembly (part number 0180386A82), which includes a wrist strap, two ground cords, a table mat, and a floor mat.
- Wear a conductive wrist strap in series with a 100k resistor to ground. (Replacement wrist straps that connect to the bench top covering are Motorola part number RSX-4015.)
- Do not wear nylon clothing while handling CMOS devices.
- Do not insert or remove CMOS devices with power applied. Check all power supplies used for testing CMOS devices to be certain that there are no voltage transients present.
- When straightening CMOS pins, provide ground straps for the apparatus used.
- When soldering, use a grounded soldering iron.
- If at all possible, handle CMOS devices by the package and not by the leads. Prior to touching the unit, touch an electrical ground to remove any static charge that you may have accumulated. The package and substrate may be electrically common. If so, the reaction of a discharge to the case would cause the same damage as touching the leads.

Repair Procedures and Techniques — General

Parts Replacement and Substitution

When damaged parts are replaced, identical parts should be used. If the identical replacement part is not locally available, check the parts list for the proper Motorola part number and order the part from the nearest Motorola Radio Support Center. For details, please refer to relevant Support Depots on page 1-4 to 1-6.

Disassembling and Reassembling the Radio - General

Since these radios may be disassembled and reassembled with the use of only five (board to casting) screws, it is important to pay particular attention to the snaps and tabs and how parts align with each other.

The following tools are required for disassembling the radio:

- chassis opener (6686263Z02)
- flat-head, penknife-size screwdriver
- TORX™ T6 screwdriver (0180320B16)

If a unit requires more complete testing or service than is customarily performed at the basic level, send this unit to a Motorola Authorized Service Center.

Chassis Assembly Disassembly should be performed only if necessary.

Radio Disassembly - Detailed

Front Cover from Chassis Disassembly

1. Turn off the radio.
2. Remove the battery:
 - a. Pull down on the two battery-release buttons.
 - b. With the buttons pulled down, the top of the battery will fall from the radio.
 - c. Remove the battery from the radio.




Figure 6-1 Battery Removal

3. Remove the antenna

- 4. Remove the Talkgroup knob off its shaft.




Figure 6-2 Talkgroup Knob Removal

NOTE The knob slides on and off. However, it is supposed to fit very tightly on its shaft.

- 5. Separate the chassis from the internal electronics front cover assembly as follows:
 - a. Insert the chassis opener, or similar instrument, in between the thin retaining wall and the chassis at the bottom of the radio. Do not mar the O-ring sealing underneath the radio housing.
 - b. Slowly pry the bottom of the chassis from the cover by pushing the chassis opener down, and prying the handle of the tool over and behind the base of the radio. This prying action forces the thin inner plastic wall toward the base of the radio, releasing the two chassis base tabs.




Figure 6-3 Chassis Removal



CAUTION: Marring the front cover O-ring sealing area will prevent the radio from sealing properly.

NOTE Flexible ribbon circuits (flexes) connecting the front cover assembly and the chassis prevent you from completely separating the two units. Display radios and radios with option boards have three flexes.

6. Push the Talkgroup switch shaft back into radio housing to slide chassis away.
7. Gently remove flex from the socket connector.
8. Lay the chassis down. Rotate the front cover backward and slightly away from the chassis.
9. Lift the latches on the main circuit board to release the flexes from their connectors.




Figure 6-4 Unlatch Flex Connectors

Chassis Assembly Disassembly

1. Use a TORX™ screwdriver with a T6 head to remove the five screws holding the secondary shield and main board to the chassis.




Figure 6-5 Remove Main Board from Chassis

2. Lift the secondary shield and main board from the chassis (See Figure 6-5).



CAUTION: Refer to the CMOS CAUTION paragraph on page 3 before removing the main board. Be sure to use ESD protection when handling circuit boards.

3. Remove the eight small O-ring retainers from their slots in the chassis. Note the alignment of the retainers for reassembly.
4. Remove the O-ring.

Radio Reassembly - Detailed

Chassis Assembly Reassembly

1. Reassemble the O-ring. The tabs on the O-ring should reach around the chassis and point down.
2. Place the eight small O-ring retainers into their slots in the chassis.

NOTE When properly assembled, the retainers on the O-ring should align with the slots on the chassis. If this is not the case, remove and replace the O-ring until it is aligned with the chassis and completely seated in place around the perimeter.

3. Make sure the battery contact module is properly sealed on the RF board.
4. Place the main board and secondary shield straight down on top of the chassis.
5. Use the TORX™ screwdriver with a T6 head to fasten the 5 screws holding the secondary shield and main board to the chassis. Torque the screws to 0.3Nm (3lbf.in).

Chassis and Front Cover Reassembly

1. Align the chassis assembly end-to-end with the front cover assembly.
2. Insert the tails of the flex circuits into their respective connectors at the bottom of the front cover.
3. Push down the latches on the connectors to hold the flex circuits to the main board.
4. Attach the UC flex circuit tail to the socket connector.
5. Slide the Talkgroup switch shaft into position in the front cover.
6. Push the chassis assembly completely into the top of the front cover until it settles in place.
7. Be sure the O-ring is properly seated.
8. Snap the bottom of the chassis into the front cover.
9. Reassemble the Talkgroup knob, antenna and battery.

10. Turn on the Volume knob and make sure radio powers up normally.




Figure 6-6 Fastening the Chassis

Service Aids

The following table lists the service aids recommended for working on the radio. While all of these items are available from Motorola, most are standard workshop equipment items and any equivalent item capable of the same performance may be substituted for the item listed.

| Motorola Part No. | Description | Application |
|--|--|---|
| PMLN4510_ | Programming Stand | Pocket for connecting to radio/Programming/Flashing with CPS. |
| FLN9636_ | Programming Cable | Cable to connect PC to programming stand. |
| PMLN4504_ | Data Cable | Cable for data transfer. |
| RLN4510_ | Battery Eliminator Regulator, 7.5V | Regulator to power radio via battery eliminator cable. |
| 0180305J49 | Battery Eliminator Cable | Interconnects radio to power supply. |
| 5880384G68 | Antenna Adapter | SMA-BNC |
| 6686263Z02 | Chassis Opener | Tool to separate chassis from front cover housing. |
| 0180320B16 6680321B81 6680321B56 | Torx Screw Driver Kit (T6,8,10,15,25) Torx Bit Insert Bit extra long | Tool to remove torx screws in radio. |
| - | Phillips Screw Driver | Tool to remove speaker retainer. |
| - | Flat-head, Penknife-size Screw Driver | Tool to remove display retainer. |

MTP700 Unit - Exploded View




Figure 6-7 MTP700 - Exploded view

MTP700 components are listed in the table below. The first column marked with a # sign provides you with the call out numbers of the components as marked in MTP700 - Exploded view.

Parts contained in this manual are the only ones that will be available for replacement.

MTP700 Components List


| # | Description | Part # |
|-----|-------------------------------|------------------------|
| 1a | Antenna, 380 - 400 MHz | 8505644V11 |
| 1b | Antenna, 410 - 430 MHz | 8505644V04 |
| 1c | Antenna, 806-870 MHz, stubby | 8505241U06 |
| 1d | Antenna, 806-870 MHz, whip | 8505241U03 |
| 2 | Knob, Volume | 3686050Z01 |
| 3 | Frequency Knob | 3686485Z01 |
| 4a | Front Cover Kit (ES) | PMHN4039A |
| 4b | Front Cover Kit (CR) | PMHN4038A |
| 4c | Front Cover Kit (Kor Mod) | PMHN4040A |
| 5 | Screw, Torx™ T6, Machine | 0386104Z01 |
| 6 | **Secondary Shield | 2686046Z01 |
| 7 | Escutcheon, ZIF | 1386262Z01 |
| 8 | *Main Board | Refer to Appendix A |
| 9 | Seal, Battery Contact Module | 3280534Z01 |
| 10 | Thermal Pad | 7580556Z01 |
| 11 | Gasket, O-Ring | 3286006Z01 |
| 12 | Chassis | 2786007Z01 |
| 13a | Battery, Lilon, Std, 1200 mAh | PMNN4047A |
| 13b | Battery, Lilon, Lite, 850 mAh | PMNN4050A |
| 13c | Battery, NiMH, 1200 mAh | PMNN4048A |
| 13d | Battery, NiMH, FM, 1150 mAh | PMNN4049A |
| 14 | Beltclip | HLN9844 |

Note: * Reference Only
Replacement or repair of all internal boards is not authorized in Latin America.


** The secondary shield is not placed for
PMUF1115A Super Tanapa.

THIS PAGE INTENTIONALLY LEFT BLANK


CHAPTER 7 KEYPAD BOARD LAYOUT, SCHEMATICS & PARTS LIST



Keypad Board Top Side PCB No. 8466556A01



Keypad Board Bottom Side PCB No. 8466556A01



Keypad Board Schematic Diagram

Keypad Board Parts List


| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|--|
| C1 | 2113928N01 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C2 | 2113928N01 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C3 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C4 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C5 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C6 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C7 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C8 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C9 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C10 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C11 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C12 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C13 | 2113743N54 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C14 | 2113928N01 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C15 | 2113928N01 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C16 | 2113928A01 | CAP CER CHIP 1.0uF +80/-20% 10V Y5V 0603 |
| C17 | 2113741F49 | CAP CER CHIP 10000pF 5% 50V X7R 0603 |
| C18 | 2113743N38 | CAP CER CHIP 33.0pF 5% 16V COG 0402 |
| C23 | 2113928N01 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C24 | 2113928N01 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C25 | 2113928N01 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| C26 | 2113928N01 | CAP CER CHIP 0.1uF 10% 6.3V X5R 0402 |
| D1 | 4809496B11 | LED CHIP YEL-GRN 1608 CL191YG |
| D2 | 4809496B11 | LED CHIP YEL-GRN 1608 CL191YG |
| D3 | 4809496B11 | LED CHIP YEL-GRN 1608 CL191YG |

| Circuit Ref | Motorola Part No. | Description |
|-------------|-------------------|-------------------------------|
| D4 | 4809496B11 | LED CHIP YEL-GRN 1608 CL191YG |
| D5 | 4809496B11 | LED CHIP YEL-GRN 1608 CL191YG |
| D6 | 4809496B11 | LED CHIP YEL-GRN 1608 CL191YG |
| D7 | 4809496B11 | LED CHIP YEL-GRN 1608 CL191YG |
| D8 | 4809496B11 | LED CHIP YEL-GRN 1608 CL191YG |
| J1 | 0980521Z01 | CONN, ZIF VERTICAL,40 PIN |
| J2 | 0986016Z01 | CONNECTOR, 10 PIN FPC |
| P1 | NOTPLACED | GCAM DUMMY PART NUMBER |
| P2 | NOTPLACED | GCAM DUMMY PART NUMBER |
| R1 | 0662057M42 | RES CHIP 47 5% 0.063W 0402 |
| R2 | 0662057M42 | RES CHIP 47 5% 0.063W 0402 |
| R3 | 0662057M42 | RES CHIP 47 5% 0.063W 0402 |
| R4 | 0662057M42 | RES CHIP 47 5% 0.063W 0402 |
| R5 | 0662057M42 | RES CHIP 47 5% 0.063W 0402 |
| R6 | 0662057M42 | RES CHIP 47 5% 0.063W 0402 |
| R7 | 0662057M42 | RES CHIP 47 5% 0.063W 0402 |
| R8 | 0662057M42 | RES CHIP 47 5% 0.063W 0402 |
| R10 | NOTPLACED | GCAM DUMMY PART NUMBER |
| | 8466556A01 | KEYPAD BOARD |


CHAPTER 8

FLEX LAYOUT, SCHEMATICS & PARTS LISTS

Interconnect Flex




Front Metal
View From Top Side



Back Metal
View From Top Side


Schematic for Interconnect Flex



Parts List for Interconnect Flex

| Reference Symbol | Motorola Part No. | Description |
|------------------|-------------------|------------------------------------|
| J100 | 0980521Z01 | Connector, ZIF, Vertical 40 pin |
| J200 | 0905505Y04 | Connector, ZIF, Horizontal, 40 pin |


Universal Connector Flex



Front Metal
View From Top Side

Back Metal
View From Top Side



Schematic for Universal Connector Flex




Parts List for Universal Connector Flex

| Reference Symbol | Motorola Part No. | Description |
|------------------|-------------------|---------------------------|
| Ear Piece | 5004154G01 | Earpiece |
| J002 | 0986226Z01 | Connector, 24 pin, header |
| Speaker | 5085738Z05 | Speaker |
| Volume | 1886009Z01 | Volume Potentiometer |

Display Flex




Schematic for Display Flex




Parts List for Display Flex

| Reference Symbol | Motorola Part No. | Description |
|------------------|-------------------|------------------------|
| J2 | 0986016Z01 | Connector, ZIF, 10 pin |
| J11 | 0987817K02 | Connector, 16 pin |

Bottom Flex




Front Metal
View From Top Side



Back Metal
View From Top Side

Schematic for Bottom Flex



Parts List for Bottom Flex

| Reference Symbol | Motorola Part No. | Description |
|------------------|-------------------|------------------------|
| C1 | 2113740F42 | Capacitor, 43pF |
| R1 | 0662057B47 | 0 ohm Resistor |
| R2 | 0662057B47 | 0 ohm Resistor |
| INT MIC | 5085600J01 | Speaker |
| J1 | 0980472U02 | Connector, ZIF, 16 Pin |

APPENDIX A

REPLACEMENT PARTS AND KITS

Servicing MTP700 Portable Units

Service for the portable units is based on the substitution method; a faulty part is replaced by a working one, providing quicker service to the customer. For example, if the transceiver board is faulty, it is replaced. If the portable requires more complete testing or servicing than that is available at field level, it is sent to your nearest Radio Service Center; where it is serviced.

The MTP700 portables are programmed at the factory. They cannot be tuned at the field service level.

Level 1 and Level 2 Maintenance

This manual covers Level 1 and Level 2 Maintenance: at Level 1 Maintenance you replace the transceiver and/or accessories and send the faulty transceiver and/or accessories to a higher level of maintenance; at Level 2 Maintenance a faulty kit is replaced.

For Latin America Level 1 and Level 2 Maintenance contact your local Motorola CGISS office for information. For details, please refer to relevant Support Depots on page 1-4 to 1-6.

Level 3 Maintenance

All Radio Support Depots outside of Latin America are level 3 service partners. The depots are capable of performing repairs down to component level where retuning is required. Contact your local CGISS office for information. For details, please refer to relevant Support Depots on page 1-4 to 1-6.

Replacement Parts

Damaged parts should be replaced with identical replacement parts. For complete information on ordering required parts and kits, contact your local customer service representative.

Service Kits

| Model | Model Description |
|-------|--|
| P1 | MTP700, 380-430 MHz , 1 W, 25 kHz, with Continuous Rotary knob for group selection (CR) |
| P2 | MTP700, 380-430 MHz , 1 W, 25 kHz, with End Stop knob for group selection (ES) |
| P3 | MTP700, 806-870 MHz , 1 W, 25 kHz, with Continuous Rotary knob for group selection (CR) |
| P4 | MTP700, 806-870 MHz , 1 W, 25 kHz, with End Stop knob for group selection (ES) |
| P5 | MTP700, 806-870 MHz , 1 W, 25 kHz, with End Stop knob for group selection (ES), Korean model |

| Description | Kit Number | 380-430 MHz | | 806-870 MHz | | |
|---|------------|-------------|----|-------------|----|----|
| | | P1 | P2 | P3 | P4 | P5 |
| * Service Boards | | | | | | |
| ***Transceiver FRU 380-430M 1W 25K CR | PMUE1825BS | x | | | | |
| ***Transceiver FRU 380-430M 1W 25K ES | PMUE1826BS | | x | | | |
| ***Transceiver FRU 806-870M 1W 25K CR | PMUF1077BS | | | x | | |
| ***Transceiver FRU 806-870M 1W 25K ES | PMUF1078BS | | | | x | |
| ***Transceiver FRU 380-430M 1W 25K CR-TEA1 | PMUE1852BS | x | | | | |
| ***Transceiver FRU 380-430M 1W 25K ES-TEA1 | PMUE1853BS | | x | | | |
| ***Transceiver FRU 806-870M 1W 25K CR-TEA1 | PMUF1092BS | | | x | | |
| ***Transceiver FRU 806-870M 1W 25K ES-TEA1 | PMUF1093BS | | | | x | |
| ***Transceiver FRU 380-430M 1W 25K CR-TEA2 | PMUE1856BS | x | | | | |
| ***Transceiver FRU 380-430M 1W 25K ES-TEA2 | PMUE1857BS | | x | | | |
| ***Transceiver FRU 806-870M 1W 25K CR-TEA2 | PMUF1096BS | | | x | | |
| ***Transceiver FRU 806-870M 1W 25K ES-TEA2 | PMUF1097BS | | | | x | |
| Transceiver 806-870M 1W 25K ES (Eriko) | PMUF1115AS | | | | | x |
| Transceiver FRU 380-430M 1W 25K CR (Chinese) | PMUE2052AS | x | | | | |
| Transceiver FRU 380-430M 1W 25K CR (Cyrillic) | PMUE2877AS | x | | | | |
| Transceiver FRU 380-430M 1W 25K ES (Chinese) | PMUE2053AS | | x | | | |
| Transceiver FRU 806-870M 1W 25K CR (Chinese) | PMUF1157AS | | | x | | |
| Transceiver FRU 806-870M 1W 25K ES (Chinese) | PMUF1158AS | | | | x | |
| Transceiver FRU 380-430M 1W 25K CR (Korean) | PMUE2054AS | x | | | | |

| Description | | 380-430 MHz | | 806-870 MHz | | |
|---|------------|-------------|----|-------------|----|----|
| | | | | | | |
| Transceiver FRU 806-870M 1W 25K CR (Korean) | PMUF1159AS | | | x | | |
| Transceiver FRU 806-870M 1W 25K ES (Korean) | PMUF1160AS | | | | x | |
| Transceiver FRU 380-430M 1W 25K CR-TEA1 (Chinese) | PMUE2056AS | x | | | | |
| Transceiver FRU 380-430M 1W 25K ES-TEA1 (Chinese) | PMUE2057AS | | x | | | |
| Transceiver FRU 806-870M 1W 25K CR-TEA1 (Chinese) | PMUF1161AS | | | x | | |
| Transceiver FRU 806-870M 1W 25K ES-TEA1 (Chinese) | PMUF1162AS | | | | x | |
| Transceiver FRU 380-430M 1W 25K CR-TEA1 (Korean) | PMUE2058AS | x | | | | |
| Transceiver FRU 380-430M 1W 25K ES-TEA1 (Korean) | PMUE2059AS | | x | | | |
| Transceiver FRU 806-870M 1W 25K CR-TEA1 (Korean) | PMUF1163AS | | | x | | |
| Transceiver FRU 806-870M 1W 25K ES-TEA1 (Korean) | PMUF1164AS | | | | x | |
| Front Cover | Kit Number | P1 | P2 | P3 | P4 | P5 |
| Front Housing Kit (CR) | PMHN4038A | x | | x | | |
| Front Housing Kit (ES) | PMHN4039A | | x | | x | |
| Front Housing Kit (ES) (Eriko) | PMHN4040A | | | | | x |
| Front Housing Kit CR (English/Chinese) | PMHN4048A | x | | x | | |
| Front Housing Kit CR (English/Korean) | PMHN4049A | x | | x | | |
| Front Housing Kit ES (English/Chinese) | PMHN4050A | | x | | x | |
| Front Housing Kit ES (English/Korean) | PMHN4051A | | x | | x | |

Note: * These boards include the main board and chassis.

*** Not Field Replaceable for Latin America.

THIS PAGE INTENTIONALLY LEFT BLANK

APPENDIX B

CONNECTOR PIN FUNCTIONS

General

This appendix describes the connector pin functions for the Radio. The description gives information on the type of signals, voltages and current conditions. Pins which are marked with no function, should not be connected

Side Accessory Connector Pin Assignment




Figure B-1 Side Accessory Connector Pin Assignment

| Pin | Name | Function | Description |
|-----|--------------|----------|---|
| 1 | EXT_SPEAKER+ | OUT | Speaker + (pin 1) and Speaker - (pin 2) are used for the external speaker. Typical output power is 0.5W for a 20 ohm load. |
| 2 | EXT_SPEAKER- | OUT | Speaker + (pin 1) and Speaker - (pin 2) are used for the external speaker. Typical output power is 0.5W for a 20 ohm load. |
| 3 | OPT_B+ | OUT | With a side accessory attached, this pin provides a typical voltage of 7.5V. It is current limited at 800mA against short circuit protection. |
| 4 | EXT_MIC | IN | This is the external microphone input. Input impedance is 2 kohm with a biasing voltage of 2.775V and a typical input level of 8 mVrms. |
| 5 | SIDE_OPT2 | IN | SIDE_OPT1, 2 and 3 selects the various radio operation modes with different accessories. |
| 6. | SIDE_OPT1 | IN | SIDE_OPT1, 2 and 3 selects the various radio operation modes with different accessories. |
| 7. | GND | IN/OUT | Used as ground. |
| 8 | RX_DATA | IN | RS-232 input data. |
| 9 | TX_DATA | OUT | RS-232 output data. |
| 10 | CTS/BUSY_OUT | OUT | Used as Clear-To-Send in RS-232 communication. BUSY_OUT is used as handshake output for SB9600 communication. |
| 11. | RTS/BUSY_IN | IN | Used as Request-To-Send in RS-232 communication. BUSY_IN is used as handshake input for SB9600 communication. |
| 12. | SIDE_OPT3 | IN | SIDE_OPT1, 2 and 3 selects the various radio operation modes with different accessories. |
| 13. | VIBRATOR | OUT | This is a logic output to enable the vibrator motor in some accessories. |

Table B-1 Side Accessory Connector Pin Functions

Bottom Accessory Connector Pin Assignment




Figure B-2 Bottom Accessory Connector Pin Assignment

| Pin | Name | Function | Description |
|-----|--------------------------------|----------|---|
| 1 | POWER GROUND | IN/OUT | Used as ground. |
| 2 | USB+/TXD (D+)/TDO | IN/OUT | +ve signal for the USB bus/transmit data in RS-232 mode/serial output in JTAG Mode. |
| 3 | USB-/RXD (D-)/TDI | IN/OUT | -ve signal for the USB bus/receive data in RS-232 mode/serial input in JTAG Mode. |
| 4 | USB_POWER/RTS/ RESET_IN | IN | 5V power from USB Host/Used as Request-T0-Send in RS-232/Reset input in JTAG Mode. |
| 5 | SWB+ | OUT | With a bottom accessory attached, this pin provides a typical voltage of 7.5V. It is current limited at 800mA against short circuit protection. |
| 6. | CTS/MCU_DE | OUT/IN | Used as Clear-To-Send in RS-232 mode/MCU Debug Event function in JTAG Mode. |
| 7. | FS/DCD/DSP_DE | IN/OUT | This pin is used as Frame Sync in SSI mode/Used as Data Carrier Detect in RS-232 mode/DSP Debug Event function in JTAG Mode. |
| 8 | SCK/RI/TCK | IN/OUT | This pin is used as Serial Clock in SSI mode/Used as RingIndicator in RS-232 mode/Test Clock in JTAG Mode. |
| 9 | SRDA/DTR/TMS | IN | This pin receives serial data in SSI mode/Used as Data Terminal Ready in RS-232 Mode/Test. |
| 10 | STDA/DSR/TRST | OUT | This pin transmit serial data in SSI mode/Used as Data Set Ready in RS-232 Mode/Test Reset in JTAG Mode. |
| 11. | BOTTOM_OPTION_1 | IN | BOTTOM_OPTION1 and 2 selects the varioius radio operation modes with different accessories. |
| 12. | BOTTOM_OPTION_2 | IN | BOTTOM_OPTION1 and 2 selects the various radio operation modes with different accessories. |
| 13. | ON_OFF/JTAG/FLASH MODE | IN | Turns on the radio in SB9600 Mode/Puts the radio into JTAG Mode/Puts the radio into FLASH Mode. |
| 14. | HEADSET INDICATION/KEY_FAIL | IN | Indicates a headset accessory is being used/Used to load the secure key for encryption. |

Table B-2 Bottom Accessory Connector Pin Functions

APPENDIX C

TEST EQUIPMENT



WARNING

Any level 3 repairs can deeply affect the performance of the MTP700 radio and may cause a new tuning procedure.

This tuning procedure can only be applied by certain authorised Motorola depots where the appropriate TEST & TUNE EQUIPMENT is available.

The appropriate TEST & TUNE EQUIPMENT is a special automated test equipment which is only available at some Motorola factories and Motorola repair centers.

Test Equipment

The table below lists the special test equipment required for servicing TETRA Portable Radios.

| Motorola Part No. | Description |
|-------------------|---|
| WADN4161A* | TETRA SERVICE MONITOR, MOBILES ONLY |
| WADN4163A | TETRA SERVICE MONITOR, MOBILES AND DIRECT MODE |
| WADN4164A | TETRA SERVICE MONITOR, MOBILES AND BASE STATIONS |
| WADN4173A | TETRA SERVICE MONITOR, MOBILES, DIRECT MODE AND BASE STATIONS |
| WADN4233A | TETRA SERVICE MONITOR, MOBILES, DIRECT MODE AND MPT1327/1343 |

NOTE:* WADN4161A is the minimum required for testing TETRA Radios

THIS PAGE INTENTIONALLY LEFT BLANK

APPENDIX D

SELF CHECK (ERROR & FAIL CODES)

General

This appendix describes the possible self check error codes for the MTP700 Portable Radios.

Self Check Error Codes

Table D-1 is the possible self check error (non fatal) codes for the MTP700 Portable Radios. No corrective action is required.

| Message | Cause |
|------------|---|
| Error00001 | A non-fatal error was logged during operation |
| Error00002 | CodePlug error log validity error |

Table D-1 Self Check Error (Non-Fatal) Codes

Table D-2 is the possible self check fail (fatal) codes for the MTP700 Portable Radios. The radio is inoperable, the user should return the radio to Depot.

| Message | Cause |
|-----------|------------------------------|
| Fail00100 | Old CodePlug Version failure |
| Fail00200 | New CodePlug Version failure |
| Fail00400 | CodePlug Model failure |
| Fail00800 | CodePlug validity error |
| Fail00801 | CP - Unknown block |
| Fail00802 | CP - Unknown Field |
| Fail00803 | CP - Unknown Flag |
| Fail00804 | CP - Unknown format |
| Fail00805 | CP - Invalid pointer |
| Fail00806 | CP - Invalid path |

Table D-2 Self Check Fail (Fatal) Codes

| Message | Cause |
|----------------|---|
| Fail00807 | CP - Invalid handler |
| Fail00808 | CP - Invalid length |
| Fail00809 | CP - Invalid index |
| Fail0080A | CP - Invalid offset |
| Fail0080B | CP - Invalid header pointer |
| Fail0080C | CP - Invalid block header |
| Fail0080D | CP - Initialization failed |
| Fail0080E | CP - Recovery failed |
| Fail0080F | CP - Write failure |
| Fail00810 | CP - Corrupted block |
| Fail00811 | CP - Corrupted codeplug |
| Fail00812 | CP - Radio Operation System error |
| Fail00813 | CP - Lower layer error |
| Fail00814 | CP - Too many arguments |
| Fail00815 | CP - Log Overflow |
| Fail00816 | CP - Invalid Checksum |
| Fail00817 | CP - Not initialized |
| Fail00818 | CP - Ambiguous code |
| Fail00819 | CP - Invalid start entry |
| Fail0081A | CP - Duplicate data |
| Fail0081B | CP - Invalid version number |
| Fail01000 | Flash checksum error |
| Fail02000 | A fatal error was logged during operation |
| Fail10000 | Handset communication error |
| FailF4000 | Ergo pre-selftest codeplug error |
| FailF8000 | Ergo pre-selftest invalid device error |

Table D-2 Self Check Fail (Fatal) Codes