

WAVETEK
WAVETEK SAN DIEGO, INC.
9045 Balboa Ave., San Diego, CA 92123
P. O. Box 85265, San Diego, CA 92138
Tel 619/279-2200 TWX 910/335-2007

Manual Revision 11/83
Instrument Release A

THIS DOCUMENT CONTAINS INFORMATION PRO-
PRIETARY TO WAVETEK AND IS SOLELY FOR IN-
STRUMENT OPERATION AND MAINTENANCE. THE
INFORMATION IN THIS DOCUMENT MAY NOT BE
DUPLICATED IN ANY MANNER WITHOUT THE PRIOR
APPROVAL IN WRITING OF WAVETEK.

© 1983 Wavetek

**INSTRUCTION MANUAL
MODEL 278
12 MHZ PROGRAMMABLE
SYNTHESIZED
FUNCTION GENERATOR**

WARRANTY

WaveTek warrants that all products of its own manufacture conform to WaveTek specifications and are free from defects in material and workmanship when used under normal operating conditions and within the service conditions for which they were furnished.

The obligation of WaveTek hereunder shall expire one (1) year after delivery and is limited to repairing, or at its option, replacing without charge, any such product which in WaveTek's sole opinion proves to be defective within the scope of this Warranty. In the event WaveTek is not able to repair or replace defective products or components within a reasonable time after receipt thereof, Buyer shall be credited for their value at the original purchase price.

WaveTek must be notified in writing of the defect or nonconformity within the warranty period and the affected product returned to WaveTek's factory or to an authorized service center within thirty (30) days after discovery of such defect or nonconformity. Shipment shall not be made without prior authorization by WaveTek.



This is WaveTek's sole warranty with respect to the products delivered hereunder. No statement, representation, agreement or understanding, oral or written, made by an agent, distributor, representative or employee of WaveTek, which is not contained in this warranty, will be binding upon WaveTek, unless made in writing and executed by an authorized WaveTek employee. WaveTek makes no other warranty of any kind whatsoever, expressed or implied, and all implied warranties of merchantability and fitness for a particular use which exceed the aforesaid obligation are hereby disclaimed by WaveTek and excluded from this agreement. Under no circumstances shall WaveTek be liable to Buyer, in contract or in tort, for any special, indirect, incidental or consequential damages, expenses, losses or delays however caused.

SAFETY

This instrument is wired for earth grounding via the facility power wiring. Do not bypass earth grounding with two wire extension cords, plug adapters, etc.

BEFORE PLUGGING IN the instrument, comply with installation instructions.

MAINTENANCE may require power on with the instrument covers removed. This should be done only by qualified personnel aware of the electrical hazards.


The instrument power receptacle is connected to the instrument safety earth terminal with a green/yellow wire. Do not alter this connection. (Reference:  or  stamped inside the rear panel near the safety earth terminal.)

This instrument contains a BR-1/2A, 3V lithium battery, that contains 0.3 grams of lithium. To prevent the battery from releasing a potentially harmful substance, DO NOT RECHARGE, SHORT CIRCUIT, DISASSEMBLE, OR APPLY HEAT TO THE BATTERY. In addition, observe correct polarity when replacing the battery.

WARNING notes call attention to possible injury or death hazards in subsequent operations.

CAUTION notes call attention to possible equipment damage in subsequent operations.

Model 278, 12 MHz Programmable Synthesized Function Generator



GENERAL DESCRIPTION

SECTION

lithium battery, that contains less than 0.3 grams of lithium. To prevent the release of a potentially harmful substance, DO NOT RECHARGE, SHORT CIRCUIT, DISASSEMBLE, OR APPLY HEAT TO THE BATTERY. In addition, observe correct polarity when replacing.

Instruments manufactured prior to serial number 7230039 may be limited to 40 sets of stored settings without battery back-up. But if an option (previously identified as Option 001) was installed, there will be a total of 100 sets of stored settings with non-rechargeable battery back-up as described in this manual.

1.2 ACCESSORIES

Rack mounts for a single instrument, rack mounts for two series 270 instruments side-by-side and instrument slides are available accessories. Refer to paragraph 1.3.16 for details.

1.3 SPECIFICATIONS

1.3.1 Waveforms (Functions)

Programmable sine \sim , triangle ∇ , square \square , pulse \square , pulse complement \square , external width, and dc.

Sine Distortion (THD at 5 Vp-p)

>0.5%, 10 MHz — 99.9 KHz
No harmonics above
-40 dBc, 100 KHz — 999 KHz
-30 dBc, 1 MHz — 12 MHz

Time Symmetry

$\pm 1\% \pm 8$ ns.

Square Transition Time

< 15 ns.

Square Overshoot

< 4% at full amplitude

Triangle Linearity

99% to 100 KHz.

1.1 MODEL 278

The Model 278, a 0.01 Hz to 12 MHz Programmable Synthesized Function Generator, can operate in continuous, triggered, gated, burst, synthesized, external reference, or external phase lock modes with output levels to 20 volts peak-to-peak.

The synthesized mode has 5 digits of frequency resolution with 0.0005% accuracy, or it can be locked to an external 10 MHz (zero-crossing or TTL) frequency reference for greater accuracy and stability. In addition, the separate synthesizer circuit acts as a highly accurate internal trigger source.

The generator can produce sine, triangle, square, square complement, and pulse waveforms as well as dc and external width.

Data entry is from the front panel or GPIB (IEEE-488, 1978). Numeric input is entered in free format: fixed, floating, or exponential notation. Parameters may be entered in any order. Internally, all entries are interactively checked for errors and displayed on the front panel, or they may be accessed through the GPIB.

Output level is specified from 10 mV to 10 Vp-p into a 50 Ω termination and 20 mV to 10 Vp-p into an open circuit with 3 digits of resolution. Offset can be programmed to vary the waveform base line up to ± 10 V, or in the dc function, to vary the dc output.

All inputs and outputs are protected against short circuits and excessive voltages between ± 15 V. The function output is further protected against voltage inputs up to 140 Vac or ± 200 Vdc. Activation of the protection circuits will cause a front panel error message and may cause a GPIB service request.

Up to 100 sets of complete front panel settings can be stored in memory. The memory has a non-rechargeable lithium battery back up for up to 6 months (typically 1 to 2 years). A "low battery" warning will be indicated on the display when the battery voltage drops to 80% of its normal voltage.

WARNING

This equipment uses a BR-1/2A, 3V

1.3.2 Operational Modes

Continuous

Output continuous at programmed frequency.

Triggered

Output quiescent until triggered by external signal, GPIB trigger, internal trigger, or manual trigger, then generates one cycle at programmed frequency. Trigger sources include 1 Hz to 24 MHz internal trigger generator in nonsynthesized modes.

Gated

As Triggered mode except output is continuous for the duration of the gate signal. The last cycle started is completed. Internal gate signal produces 50% duty cycle gate at trigger rates below 12 MHz.

Burst

As Triggered mode for programmed number of cycles.

Count Range: 1 to 1,048,200.

Burst Rate: 12 MHz maximum

Synthesized

Same as Continuous except 5 digit frequency resolution and 0.0005% accuracy (5 ppm).

TTL Reference

Same as Synthesized except synthesizer externally referenced to a 10 MHz TTL source at REF IN BNC.

Zero Reference

Same as TTL Reference except external source is a zero-crossing 10 MHz signal.

TTL Lock

Main generator phase locked to external TTL signal at REF IN BNC. Capture and lock range > 5% of programmed frequency.

Zero Lock

As TTL lock mode with external zero-crossing signal at REF IN BNC.

1.3.3 Frequency

Range

10 MHz to 12 MHz except 10 Hz minimum in synthesized modes.

Resolution

5 digits in synthesized modes. 3 digits in all other modes.

Accuracy

5 ppm \pm 1 mHz in Synthesized mode. Accuracy of external signal \pm 1 mHz in reference modes. \pm 2% in all other modes.

Noise Floor

< -50 dbc.

Spurious

Typically < -45 dbc.

Repeatability (24 hr)

0.0003% in synthesized mode. \pm 1% in all other modes.

Jitter

$\leq 0.1\% \pm 100$ ps.

Control

Frequency may be controlled 3 ways: Value, VCG, or External Lock.

Value: Frequency value is keyboard or GPIB programmable with automatic range selection.

VCG (Voltage Controlled Generator): AC or DC input controls frequency. 0.01 to 12 V into 10 k Ω for up to 1200:1 frequency change in each of 9 frequency ranges (ranges must be programmed).

Slew rate is limited to 0.1 V/ μ s.

External Lock: Frequency is determined by an externally applied signal at the REF IN BNC.

1.3.4 Amplitude

Range

0.01 to 10 Vp-p into 50 Ω (0.02 to 20 Vp-p into ≥ 50 k Ω) from main output. Absolute peak amplitude plus offset may not exceed 5V into 50 Ω (10V into ≥ 50 k Ω).

Resolution

3 digits or 10 mV when absolute peak amplitude plus offset > 0.5V; 3 digits or 1 mV when absolute peak amplitude plus offset ≤ 0.5 V.

Accuracy

$\pm 2\%$ of programmed value and: ± 5 mV for 0.1 to 1V (peak amplitude + offset > 0.5V), ± 20 mV for 1.01 to 10V, ± 50 mV for all other.

Repeatability (24 hr)

$\pm 1\% \pm 10$ mV.

Flatness

For output at 5 Vp-p: 0.1 dB to 100 kHz, 1.5 dB to 12 MHz.

1.3.5 Offset

Range

DC or offset programmable from -5V to +5V into 50 Ω (-10V to +10V into ≥ 50 k Ω). Absolute peak amplitude plus offset may not exceed 5V into 50 Ω (10V into ≥ 50 k Ω).

Resolution

3 digits or 10 mV when absolute peak amplitude plus

offset > 0.5 V, 3 digits or 1 mV when absolute peak
 amplitude plus offset $\leq 0.5V$.
Accuracy
 ± 40 mV in dc function.
Repeatability (24 hr)
 $\pm 1\% < 20$ mV.

1.3.6 Internal Trigger
 Range: 1 Hz to 24 MHz.
 Resolution: 5 digits.
 Accuracy: 0.0005%.

1.3.7 Pulse Period
 Range: 90 ns to 1 sec.
 Resolution: 3 digits.
 Accuracy: 0.0005%.

1.3.8 Pulse Width
 Range: 45 ns to 0.5 sec.
 Resolution: 2 digits.
 Accuracy: 3% + 5 ns.

1.3.9 Upper/Lower Level
 Upper level must be greater than lower level.
 Range: $\pm 5V$.
 Resolution: 20 mV.
 Accuracy: See amplitude and offset specifications.

1.3.10 Outputs
Function Output
 Source of primary waveforms. Programmable to be On (source impedance 50 Ω), Off High Z (> 500 k Ω), or Off Low Z ($\sim 50\Omega$).
Source Impedance: 50 Ω .
Protection: Output protected to 140 Vac or 200 Vdc without replacement of internal fuse.
Sync Output
 Sync signal is at programmed frequency and TTL level.
 Level: $\leq 0.4V$ to $\geq 2.4V$ into 50 Ω , $\leq 0.8V$ to $\geq 4.8V$ into ≥ 50 k Ω .
Source Impedance: 50 Ω .
Timing: Concurrent with function output in square; lags sine and triangle by 90°.
Over/Undershoot: $< 10\%$ into 50 Ω .
Protection: Output protected from short circuit to any voltage between ± 15 Vdc.
Reference Output
 1.5 Vp-p into 50 Ω , TTL level into open circuit, 10 MHz

internal reference when in synthesized mode.
 internal trigger frequency when internally in Trig-
 gered, Gated or Burst Modes.
Protection: Output protected from short circuit to any
 voltage between ± 15 Vdc.

1.3.11 Inputs
 Trigger of input circuit is programmable for a + or -
 signal slope and required threshold level.
 Level: -10 to +10V.
 Resolution: 20 mV.
 Accuracy: ± 500 mV.
 Input Impedance: 10 k Ω .
Maximum Trigger Rate: 12 MHz (24 MHz for Exter-
 nal Width).
Minimum Trigger Width: 20 ns.
Minimum Amplitude: 500 mVp-p to 1 MHz, 1 Vp-p to
 24 MHz.

Protection
 Inputs protected to $\pm 50V$.
VCG In
 Voltage control of generator frequency. See Frequency.
 Range: 0.01 to 12V.
 Impedance: 10 k Ω .

Reference Input
 Used to externally reference or phase lock the main
 generator.
Programmable Input Selection: TTL or 1 Vp-p
 minimum zero-crossing.
 Input: 10 MHz for external reference, 10 Hz to 12
 MHz for phase lock.
Protection: Input protected to ± 50 Vdc.

1.3.12 GPIB Programming
 IEEE 488-1978 compatible. Non-isolated. Double
 buffered.
Address
 0-30, keyboard or internal switch selectable. Internal
 switch can lock out keyboard selection. Power-up
 address is internal setting.

Subsets
 SH1, AH1, T6, TE0, L4, SR1, RL1, PP0, DC1, CO, E2.
Interface Timing
 11 ms Frequency
 14 ms Amplitude
 14 ms Offset
 4 ms Mode
 5 ms Waveform
 8 ms Execute
 4 ms Other

1.3.13 Stored Settings

Nonvolatile memory for 100 stored settings.

1.3.14 General

Environmental

Temperature Range: 25°C ± 10°C for spec operation, operates 0°C to 50°C, - 50°C to + 75°C for storage.

Warm-up Time: 20 minutes for specified operation.

Altitude: Up to 10,000 ft for operation. Up to 40,000 ft for storage.

Relative Humidity: 95% at 25°C and at sea level (non-condensing).

Dimensions
21.7 cm (8.54 in.) wide (half-rack), 13.3 cm (5.25 in.) high, 39.4 cm (15.5 in.) deep.

Weight
6.8 (15 lb) net, 7.2 kg (16 lb) shipping.

Power

90 to 105, 108 to 126, 198 to 231, or 216 to 252 volts rms; 48 to 66 Hz; 1 phase; < 50 watts.

1.3.15 Options

002: Rear Panel Connectors

Front panel BNC's relocated to rear panel.

1.3.16 Accessories

Style 12: Single Rack Adapter Kit

Allows right or left mounting in a standard 19 inch rack. 5 1/4 inches high.

Style 13: Dual Rack Adapter Kit

Allows any 270 series instrument to be mounted side-by-side in a standard 19 inch rack. 5 1/4 inches high.

Rack Slides

SECTION 2 INSTALLATION AND INTERFACE

Conversion to other input voltages requires a change in rear panel fuse holder voltage card position and fuse (figure 2-1) according to the following procedure.




Figure 2-1. Voltage Selector and Fuse

1. Disconnect the power cord at the instrument, open fuse holder cover door and rotate fuse-pull to left to remove the fuse.

2. Remove the small printed circuit board and select operating voltage by orienting the printed circuit board to position the desired voltage to the top left side. Push the board firmly into its module slot.

Card Position	Input Vac	Fuse
100	90 to 105	½ amp
120	108 to 126	½ amp
220	198 to 231	½ amp
240	216 to 252	½ amp

3. Rotate the fuse-pull back into the normal position and insert the correct fuse into the fuse holder. Close the cover door.
4. Connect the ac line cord to the mating connector at the rear of the unit and the power source.

2.1 MECHANICAL INSTALLATION

After unpacking the instrument, visually inspect all external parts for possible damage to connectors, surface areas, etc. If damage is discovered, file a claim with the carrier who transported the unit. The shipping container and packing material should be saved in case reshipment is required.

The generator can be used as a bench instrument or rack mounted. The 278 can be converted to rack mounts in the field by using the following kits:

Rack Mount Kit	Part Number	Reference Drawing
Single Instrument (left and right mounting)	1101-00-1043	0102-00-1043
Dual Instrument Rack Slides	1101-00-1041	0102-00-1041
	1101-00-1042	0102-00-1042

NOTE

The rack slides can only be used with dual rack mounted instruments.

Whether used on a bench or in a rack, ensure that there is no impedance to air flow at any surface of the instrument. Before rack mounting, it may be desirable to perform the initial checkout (paragraph 2.2.5) to verify operation of all functions.

2.2 ELECTRICAL INSTALLATION


2.2.1 Power Connection

NOTE

Unless otherwise specified at the time of purchase, this instrument was shipped from the factory with the power transformer connected for operation on a 120 Vac line supply and with a ½ amp fuse.

Figure 2-2. GPIB Address Selector Switch

NOTE: GPIB address selected is decimal 4; switch 1 Off, 2 Off, 3 On, 4 Off, 5 Off. (Table 2-2: 00100).



2.2.4 GPIB Address

For instruments on the General Purpose Interface Bus (GPIB), ensure that the instrument GPIB address is correct. The GPIB address can be changed by the internal switch (for access, remove the bottom cover, see figure 2-2) or the front panel GPIB ADPS key (e.g., ADPS 4 EXEC). The switch sections are labeled from 1 through 5 and their OFF position noted (OFF = Binary "0" in table 2-2). To verify the address, press ADR on the front panel. The device number (decimal) will be displayed. Upon power-up, the address is always that of the internal switch.

2.2.3 GPIB Connections

The GPIB I/O rear panel pin connections and signal names are given in table 2-1. The panel connector is an Amphenol 57-10240 or equivalent and connects to a GPIB bus cable connector (available from Wavetek in 1 and 2 meter lengths).

Instrument BNC connectors are:
 TRIG IN. Acceptable trigger level and slope are programmable; -10 to +10V, 10 kΩ impedance.
 SYNC OUT. TTL level square wave; 50Ω impedance
 FUNC OUT. Up to 10 Vp-p into 50Ω impedance; up to 20 Vp-p into > 50 kΩ impedance.
 VCG IN. 0.01 to 12V; 10 kΩ impedance.
 REF IN. Acceptable reference input signal is dependent upon the selected mode (ref: paragraph 3.8.5). 10 kΩ impedance.
 REF OUT. TTL level pulse. Output is dependent upon the selected mode (ref: paragraph 3.8.5). 50Ω impedance.
 Signal ground may be floated up to ±42 volts with respect to chassis ground. Be aware that all signal grounds are common; thus, if one signal ground requires floating, all grounds must be floated together.

Use RGS8U or equivalent 50Ω coaxial cables equipped with BNC connectors to distribute signals.

NOTE

2.2.2 Signal Connections

Signal	Pin	
True When Low	DIO1	1
	DIO2	2
	DIO3	3
	DIO4	4
	EOL	5
	DAV	6
	NRFD	7
	NDAC	8
	IFC	9
	SRO	10
True When High	ATN	11
	Chassis Ground	12
	DIO5	13
	DIO6	14
	DIO7	15
	DIO8	16
	REN	17
	Signal Gnd	18
	Signal Gnd	19
	Signal Gnd	20
True When Low	DIO9	21
	DIO10	22
	DIO11	23
	DIO12	24

Table 2-1. GPIB Data In/Out



Table 2-2. GPIB Address Codes

Device	ASCII		Switch Position	Hexa-decimal
	Listen	Talk		
0	(space)	@	0 0 0 0	20
1	!	A	1 0 0 0	21
2	..	B	0 1 0 0	22
3	#	C	1 1 0 0	23
4	\$	D	0 0 1 0	24
5	%	E	1 0 1 0	25
6	&	F	0 1 1 0	26
7	.	G	1 1 0 0	27
8	(H	0 0 0 1	28
9)	I	1 0 0 1	29
10	*	J	0 1 0 1	2A
11	+	K	1 1 0 1	2B
12	.	L	0 0 1 1	2C
13	-	M	1 0 1 1	2D
14	•	N	0 1 1 1	2E
15	/	O	1 1 1 1	2F
16	0	P	0 0 0 1	30
17	1	Q	1 0 0 1	31
18	2	R	0 1 0 1	32
19	3	S	1 1 0 1	33
20	4	T	0 0 1 1	34
21	5	U	1 0 1 1	35
22	6	V	0 1 1 1	36
23	7	W	1 1 1 1	37
24	8	X	0 0 0 1	38
25	9	Y	1 0 0 1	39
26	:	Z	0 1 0 1	3A
27	:	[1 1 0 1	3B
28	<	\	0 0 1 1	3C
29	=]	1 0 1 1	3D
30	>	V	0 1 1 1	3E

NOTE

Address 31 is not allowed.

2.2.5 Initial Checkout and Operation Verification

Make the equipment setup as shown in figure 2-3 and perform the steps in table 2-3 to verify Model 278 operation. If further explanations are required, refer to figure 3-1 and table 3-1.




Figure 2-3. Setup

Table 2-3. Initial Checkout

Step	Test	Tester & Setup	Program	Desired Results
1	Wake-up State			<p>Display: All segments, decimal points and commas light up for 1 sec ($\frac{1}{2}$), typical of 20 then displays WAVETEK MODEL 278.</p> <p>Power ON</p>
2	Wake-up Status			<p>Press STAT key</p> <p>Display (changes automatically): FREQ 1 KHz AMPLITUDE 5V OFFSET 0V MODE CONTINUOUS (0) FUNC SINE (0) BURST COUNT 2 PERIOD 1 ms WIDTH 45 ns UPPER LEVEL 2.5V LOWER LEVEL - 2.5V OUTPUT OFF (0) EXTERNAL TRIGGER (0) TRIG RATE 200 Hz TRIG SLOPE POS (0) TRIG LEVEL 1.5V</p>
3	Status Search			<p>STAT</p> <p>Status display sequence stops.</p> <p>Status progresses forward.</p> <p>Status progresses backward.</p> <p>STAT</p> <p>Status display automatic sequence continues.</p> <p>DISP TEST</p> <p>All segments, decimal points and commas light up. Back to last display when key released.</p> <p>Press FREQ key a few times</p> <p>Beeper sounds everytime key is pressed.</p> <p>Press \uparrow, then FREQ key a few times</p> <p>Beeper is silent.</p> <p>Beeper enabled.</p>
4				
5				
6				
7	Display Test			
8	Beeper Test			
9				
10				
11	Command Recall			
12				
13	GPB Address And Status			

<p>Power ON</p> <p>Display: All segments, decimal points and commas light up for 1 sec ($\frac{1}{2}$), typical of 20 then displays WAVETEK MODEL 278.</p>	<p>Press STAT key</p> <p>Display (changes automatically): FREQ 1 KHz AMPLITUDE 5V OFFSET 0V MODE CONTINUOUS (0) FUNC SINE (0) BURST COUNT 2 PERIOD 1 ms WIDTH 45 ns UPPER LEVEL 2.5V LOWER LEVEL - 2.5V OUTPUT OFF (0) EXTERNAL TRIGGER (0) TRIG RATE 200 Hz TRIG SLOPE POS (0) TRIG LEVEL 1.5V</p>	<p>STAT</p> <p>Status display sequence stops.</p> <p>Status progresses forward.</p> <p>Status progresses backward.</p> <p>STAT</p> <p>Status display automatic sequence continues.</p> <p>DISP TEST</p> <p>All segments, decimal points and commas light up. Back to last display when key released.</p> <p>Press FREQ key a few times</p> <p>Beeper sounds everytime key is pressed.</p> <p>Press \uparrow, then FREQ key a few times</p> <p>Beeper is silent.</p> <p>Beeper enabled.</p>	<p>Press each of the 6 keys in the MAIN generator section 4 times</p> <p>Strings of characters shown on display. Characters are the ones shown on lower left of RCL</p> <p>Press -- then --</p> <p>Moves characters right then left 4 at a time.</p> <p>Display: GPB ADRS 1 then GPB ADRS 30</p>
---	--	---	--

Table 2-3. Initial Checkout (Continued)

Step	Test	Tester & Setup	Program	Desired Results
14	Quality Assurance Procedure	Connect Model 278 and oscilloscope as shown in figure 2-3. Scope setting: CH1 2 V/div, horizontal 0.2 ms/div; CH2 2 V/div; trigger on CH2.	Press: RCL 2000 EXEC	Display: (0) BEGIN QA PROC Scope: CH1 5 Vp-p 1 kHz sine wave CH2 2.5 Vp-p 1 kHz square wave
15	Frequency: Exercises Each Frequency Bit and the Sine Wave Function.		Press: CURSOR 1 once.	Display: (1) FREQUENCY Scope: CH1 5 Vp-p sine wave continuously sweeping from 1 kHz to 10 kHz. CH2 2.5 Vp-p square wave synchronous with CH1.
16	Amplitude: Exercises Each Amplitude Bit and the Triangle Wave Function.		Press: CURSOR 1 once.	Display: (2) AMPLITUDE Scope: CH1 1 kHz triangle wave, amplitude continuously increases from 1V to 10 Vp-p. CH2 2.5 Vp-p square wave synchronous with CH1.
17	Offset: Exercises Each DC Offset Bit and Square Function.		Press: CURSOR 1 once.	Display: (3) OFFSET Scope: CH1 1 Vp-p square wave. DC offset continuously increases from -4V to +4V. CH2 2.5 Vp-p square wave synchronous with CH1.
18	Trigger Circuit	Trigger Scope on CH1.	Press CURSOR 1 once.	Display: (4) TRIGGER Scope: CH1 single 5 kHz 5Vp-p sine wave. CH2 2.5 Vp-p 100 μs pulse, delayed 50 μs relative to positive edge CH1.
19	Gate Circuit		Press: CURSOR 1 once.	Display: (5) GATE Scope: CH1 Burst of 6 cycles of 5 kHz sine waves CH2 2.5 Vp-p Pulse burst: six 50 μs pulses.
20	Burst Circuit		Press: CURSOR 1 once.	Display: (6) BURST Scope: CH1 5 Vp-p sine wave continuously stepping from 9 to 2. CH2 2.5 Vp-p 100 μs pulse continuously stepping from 9 to 2.
21	Quiescent State of Outputs		Press: CURSOR 1 once.	Display: (7) END QA PROC Scope: CH1 Burst of 2 cycles of 5 Vp-p 5 kHz sine waves CH2 Burst of 2 cycles of 2.5 Vp-p 50 μs pulses.

SECTION 3 OPERATION

3.3 BASIC COMMAND STRUCTURE

The Model 278 is programmed by sending ASCII coded characters (ref: table 3-1 and Appendix A) to the microprocessor via one of the two possible input ports (keyboard or GPIB) shown in figure 3-2. If input characters are present on more than one input port, they are read first from the GPIB and then from the keyboard. Thus, if the GPIB port is continuously supplied with characters, then no characters will ever be read from the keyboard and the keyboard will appear inoperative to the user.



3.3.1 Characters

Characters used to program the 278 are divided into classes:

1. **Alphabetic Characters**—The characters A through Z (except E) select actions or commands. The X character used in front of another alphabetic character selects an alternate set of actions or commands. The X must directly precede the alphabetic character without intervening characters of any kind. For example, F selects frequency and XF selects percent frequency, but X F selects frequency not percent frequency because a space character, not X, was placed immediately before the F. Alphabetic characters are generated from the keyboard by pressing the labeled action and parameter keys. The characters generated by such keys are printed in a corner of the key.
2. **Numeric Characters**—The characters 0 through 9, E, —, and decimal point (.)
3. **Special Character**—Quote (") instructs the microprocessor to send to the display what is in quotes.
4. **Terminator Character**—Initially the ASCII line feed character (LF). This can be changed by programming (refer to paragraph 3.16.6).
5. **Nonprogramming Characters**—Any character not in one of the previously described classes.

3.1 DATA ENTRY

Using the Model 278 is quite straight forward and is easily understood by trial and error. The micro-processor "converses" with you during operation, informing you what was programmed, what is possible to program, and when an error is made. Perform the procedures of table 2-3 to familiarize yourself with Model 278 operation. The keyboard is shown in figure 3-1 and cross referenced to table 3-1, which, in turn, references the applicable text. Readout that occurs when the keys are pressed are listed in Appendix C. When the operator starts keying in the parameter argument, no unit of measure is displayed until the parameter is terminated by a key other than a numeric entry key. Coded parameters, such as function, mode and output show their programmed argument in parentheses.

An audible tone indicates when a key is pressed. Pressing  will prevent or restore the key tone. If there is no tone when keys are pressed, pressing  restores the tone and vice versa. Information exclusive to the GPIB is given in paragraph 3.16. Additional reference information appears in the appendices:


- Appendix A - ASCII and IEEE (GPIB) Code Chart
- Appendix B - Programming Command Summary
- Appendix C - Displays
- Appendix D - Output and Timing for Basic Modes and Functions.
- Appendix E - Glossary of Mnemonics
- Appendix F - Waveform Measurements

3.2 POWER

Power is turned on and off with a front panel push-button. When the power is turned on, the entire display lights up for a display element test. Then after about 1 second, "WAVTEK MODEL 278" is displayed. When the power comes on, the output is automatically disabled.

Figure 3-1. Controls and Connectors

NOTE: Features are keyed to Table 3-1



Location in Figure 3-1	ASCII Character	Function	Action (A) or Parameter (P)	Paragraph
1		VCG Input		3.8.1.3
2		Power		3.2
3		Cursor	A	3.6
4		Display		3.16.9
5	B	Mode	P	3.8.5
6	F	Frequency	P	3.8.1.1
7	A	Amplitude	P	3.8.2
8	D	Offset	P	3.8.3
9	R	Burst	P	3.8.6
10	C	Function	P	3.8.4
11	0 thru 9, •, ±	Number Characters	P	3.3.1
12		Function Output		3.11.1
13		Sync Out		3.10.4
14	Z	Reset	A	3.13
15		Display Test	A	3.14
16		Status	A	3.15
17		Service Request	A/P	3.16.5.2
18		•(Tone On/Off)	A	3.1
19	I	Execute	A	3.5
20		Clear	A	3.12
21	E	Exponent	P	3.3.3
22	P	Output On	P	3.11.2
23	Y	Recall Settings	P	3.10.2
24	M	Store Settings	P	3.10.1
25	J	Manual Trigger Pressed	A	3.7
25	H	Manual Trigger Released	A	3.7
26	O	Trigger Slope	P	3.7
27	XL	Trigger Level	P	3.7
28		Local Control Enable	A	3.16.8
29		Command Recall	A	3.16.10
30		GPB Address	A	3.16.2.1
31		Trigger Input		3.7
A	N	Width	P	3.9.2
C	V	Lower Level	P	3.9.4
D	U	Upper Level	P	3.9.3
E	S	Period	P	3.9.1
AA		Reference Input		3.8.1.1
BB		Reference Output		3.11.5
CC	G	External Trigger	P	3.7
DD	T	Trigger Rate	P	3.7
	XU	Recall Next Lesser Numbered Program	A	3.10.2
	XW	Recall Next Greater Numbered Program	A	3.10.2
	XG	GET Mode	A	3.10.2
	XQ	SRQ Mode	P	3.16.5.1
	XT	Talk Message	P	3.16.4
	XV	Terminator Select	P	3.16.6
	XF	Percent Frequency	P	3.8.1.2

Table 3-1. Function Cross Reference

To examine the current value of a parameter, simply program the proper alphabetic character from either the front panel or GPIB port. The current value is then displayed on the front panel. Display occurs whether or not the instrument is enabled. If the character programmed does not correspond to a legal parameter in the instrument, nothing happens.

(ref: REN, paragraph 3.16.1).
 when that character is read by the microprocessor the instrument is in the enable state at the moment GPIB port. The action will then take place, but only if alphabetic character from either the front panel or GPIB port. The action will then take place, but only if some aspect of the instrument's operation.

To program an action, simply program the proper alphabetic character from either the front panel or GPIB port. The action will then take place, but only if some aspect of the instrument's operation. most have keys) plus a numeric value which controls programming parameter has one or two letters (and is pressed. There is no need for a numerical suffix. A sequence of events which happens when the letter that selects it is programmed or the key that selects it actions or parameters (ref: table 3-1). An action is a The alphabetic characters are used to select either

3.3.2 Action Vs Parameter

They have no effect on programming and may be interspersed freely among programming characters, except after X (refer to item 1).


To change a parameter value, first program the alphabetic character which selects the desired parameter (F = frequency, etc.). Next, program the new value using numeric characters. Any sequence of characters which gives the new value is acceptable. For example, all of the sequences in table 3-2 cause the value 100 to be programmed.

The numbers to the left of the E are the mantissa; the digits to the right (only two are allowed) are the exponent. The result value is the mantissa times 10 to the

- Fixed Point — Decimal remains at far right.
- Floating Point — You program the decimal point. It floats to the left in its designated position as you enter more numerals.
- Exponential Notation — A value, then E followed by the exponent of a times ten multiplier. When the value (mantissa) is limited to one digit exponential notation is called scientific notation.

3.3.3 Programming Parameter Values
 The numeric characters (0 through 9, E, -) are used to program new parameter values. Data entry is free format, i.e., fixed point, floating point and exponential notation, or scientific notation.

Figure 3-2. Memory Structure



Class 1 errors are caused by programming values outside the legal limits of the parameter being programmed. For example, programming an amplitude of 500 volts will cause a parameter error when the next alpha character is programmed. At this time, the 278 disregards the new values and retains the previously programmed values in scratch pad memory (see figure 3-2).

3.4.1 Class 1 Errors

When an illegal value is programmed or interdependent parameter errors are detected, an error signal is indicated on the front panel or GPIB. Keyboard class 1, 2 and 3 errors are indicated on the front panel display and by a double "beep" of the key tone. For errors made via the GPIB (but not the keyboard), the service request line (SRQ) is asserted, providing a service request mode (XQ) has been selected (ref: paragraph 3.16.5). The controller can then serial poll its instruments to verify that the 278 sent the SRQ and can then inquire as to the nature of the 278 error. The method of reporting errors on the GPIB is given in paragraph 3.16.4.

3.4 ERRORS

Round Off	Parameter	Round Off
Up to 3 digits, 10 mHz minimum.	Synthesized, External Reference, and Phase Lock	Up to 5 digits, 1 mHz minimum
Up to 3 digits, 10 mV	Amplitude and Offset	Up to 3 digits, 10 mV minimum
Up to 3 digits, 1 mV	Absolute peak amplitude plus Offset > 0.5V	Up to 3 digits, 1 mV minimum
Up to 3 digits, 20 mV	Trigger level	Up to 3 digits, 20 mV minimum
Up to 3 digits, 0.1 ns	Period	Up to 3 digits, 0.1 ns minimum
Up to 5 digits, 0.1 mHz minimum	Internal Trigger Rate	Up to 5 digits, 0.1 mHz minimum
Up to 2 digits, 10 ns	Width	Up to 2 digits, 10 ns minimum
Up to 3 digits, 20 mV	Upper and Lower Level	Up to 3 digits, 20 mV minimum
To nearest integer	All Other Parameters	To nearest integer

Table 3-3. Round Offs

Since the number input format is so general, the microprocessor must be told when the last numeric character has been entered so it can evaluate the number. This is done by programming either an alphabetic, special or terminator character. When this is done, the new value is rounded off (ref: table 3-3) and tested to see if it is a legal value for the setting being changed (ref: paragraph 3.4). If it is legal, the new value is entered into the instrument's scratch pad memory; however, it is not yet sent to the waveform circuits. That is usually done by programming the I action (EXEC key on the front panel). Other methods of execution are GET and cursor, which are described later. An asterisk (*) on the display indicates that the new parameter value programmed has not been executed and resides in scratch pad memory only (ref: figure 3-2). All parameter values may be erased before execution by using the CLR key, the value stored in scratch pad is erased and the original value is displayed.

Several parameters required codes for specific selections; for example, function codes 0 through 3 select sine wave, triangle wave, square wave and complement square wave. Refer to Appendix B for codes.

Standard Notation	Keyboard	ASCII
100	100	100
100 (leading zeroes are ignored)	0100	0100
1 EXP 2	1 EXP 2	1E2
1×10^2	.01 EXP 4	.01E4
$.01 \times 10^4$.01 EXP 304	.01E304
1000 EXP ± 1	1000 EXP ± 1	1000E-1
1 = 10^2 (two minus signs cancel)	1 EXP $\pm 2 \mp$	1E-2
1×10^2 (decimal points in exponent are ignored)	1 EXP .2	1E.2

Table 3-2. Examples of Value Programming

exponent power; for example $9.99 E2 = 9.99 \times 10^2 = 999$

3.4.2 Class 2 Errors

Class 2 errors are interparameter inconsistencies, such as the dc offset and peak amplitude greater than 5V into 50Ω. Tests are made every time an execute (I) is given, a setup is stored (M) or a cursor key is pressed. Resulting errors are displayed, and transfers of values are made to waveform circuits or storage regardless of the error indicated. Notice that upon receiving a Group Execute Trigger (ref: paragraph 3.16.7), the 278 programming is executed without error checking.

3.4.3 Class 3 Error

Class 3 error occurs if an empty stored setting is retrieved. The error is displayed and the state of the 278 remains unchanged from the previously executed program.

3.5 EXECUTING THE PROGRAM

A program or setting can be executed, i.e., transferred to the waveform circuits by execute commands, GET (Group Execute Trigger) command, and the action keys: CURSOR 1 and CURSOR 1.

GP1B I and the front panel EXEC key are execute commands that cause parameter value and interparameter tests to be made and transfer the programmed values to the waveform generation circuits. GET is a GP1B only command (no front panel key) that causes the 278 to execute and trigger, but without time consuming microprocessor error checks (ref: paragraph 3.16.7).

CURSOR 1 and CURSOR 1 are exclusively front panel functions which perform an execute with error checks after each digit increment or decrement. GP1B Z and the front panel RESET are commands which reset the 278 to the original power up conditions (as described in table 2-3, step 2) and perform an automatic execute. An asterisk (*) on the display indicates that the new parameter value programmed has not been executed and resides in scratch pad memory only (ref: figure 3-2).

3.6 CURSOR

The four cursor keys can modify a parameter value or code.

NOTE

The modified value is automatically executed.

3.7 TRIGGER

The triggered and gated modes of the generator are initiated by a trigger signal. Triggers are: an external signal at the front panel TRIG IN BNC, an internal trigger source within the 278, a manual trigger using the front panel MAN TRIG key, or J (and H) commands via the GP1B.

G (or pressing EXT) followed by its code selects either external or internal triggering.

G0 Selects external trigger.

G1 Selects internal trigger. When using internal trigger, use REF OUT BNC for a synchronization trigger output.

T (or pressing RATE) followed by its value selects the internal trigger rate. The rate can be programmed between 1 Hz and 24 MHz with up to 5 digits of resolution and 5 ppm accuracy.

J (or pressing MAN TRIG) is the start trigger for the main generator. In gated mode, the main generator is gated on.

H (or releasing MAN TRIG), in gated mode, terminates the output of the main generator. The last cycle started is always completed.

NOTE

Pressing manual trigger has no effect when internal trigger is selected.

Q followed by its code selects triggering either on the rising edge of the trigger signal or the falling edge of the rising edge (F) of the trigger signal. When internal trigger is selected, the generator always triggers on the rising edge.

Q0

Selects triggering on the rising edge (F) of the trigger signal. When internal trigger is selected, the generator always triggers on the rising edge.

Each time a frequency is programmed the 278 microprocessor determines the best one of nine internal frequency ranges for operation. Each frequency range and its limits are shown in table 3-5. Firmware automatically changes frequency ranges as necessary. These are ranges associated with ASCII **F** programming, as opposed to ASCII **XF** (ref: paragraph 3.8.1.2) programming or VCG (ref: paragraph 3.8.1.3) operation.

3.8.1.2 Percent Frequency (XF)
XF, a GPIB exclusive parameter, followed by a value (0 to 100) programs frequency in percent of frequency range (0 to 100% in 0.1% increments). Internal to the 278, there are nine decade ranges as shown in table 3-5. Maximum frequency is limited to 100% of a range; for example: the 10⁰ range is limited to 10 MHz. The minimum frequency can be programmed to 0% with derated frequency accuracy. At 0% the actual output frequency may be 0 Hz.

In synthesized modes, percent frequency can only be used between 10% and 100% of the selected frequency range.

3.8.1.3 VCG Frequency
 A signal, either dc or ac, applied to the VCG IN BNC can be used to externally control the frequency of the FUNC OUT signal. A positive voltage applied to the VCG IN connector will increase the generator frequency within a range, and a negative voltage will decrease the frequency within a range.

Frequency, using the VCG IN, can only be changed within a frequency range. Table 3-5 shows the nine frequency ranges, internal to the 278, and the limits for each range.

Figure 3-3 illustrates the VCG voltage required to change the programmed frequency to a desired output frequency. Frequency range must be selected before applying the VCG signal. For example, if 500 Hz is programmed, the 278 selects the 10² range (ref: table 3-5). As shown in the example of figure 3-3, the "Frequency Mantissa of Program" is 5 and a 5V "VCG IN" changes the "Frequency Mantissa of Output" to 10. Since operation is in the 10² range, output frequency is 1.2 kHz (max). Another example is a 1200:1 frequency sweep from 1 kHz to 1.2 MHz using 0.01 to 12.0 volt VCG signal. Table 3-5 shows that the frequency range is 10³. To get in that range, program a value in the 10⁵ "F" range. Next, program **F0**, from which, the 0.01 VCG voltage will cause the output to be 1 kHz, and a 0.01 to 12 volt VCG input will cause a 1 kHz to 1.2 MHz frequency sweep.

Mode (Code)	Frequency Accuracy	Resolution
Continuous (0) Triggered (1) Gated (2) Burst (3)	± 2%	Up to 3 digits
Synthesized (4)	± 0.0005%	Up to 5 digits
Synthesized with TTL (5) or Zero Crossing Reference Input	Accuracy determined by the reference source	Up to 5 digits
Phase Lock with TTL (7) or Zero Crossing (8) Input	Limited to accuracy of the external ref input	Frequency of external ref input

Table 3-4. Mode Affect on Frequency Accuracy and Resolution

Frequency resolution, accuracy and ranges depend on the selected operating mode, refer to table 3-4. For synthesizer modes with reference input (5 and 6) and phase lock modes (7 and 8), an external reference signal is required (ref: paragraph 3.8.5).

Selecting **F** followed by a value programs, in hertz, the generator frequency.

3.8.1.1 Frequency (F)

Direct frequency programming (nonsynthesized, synthesized, or phase locked), percentage frequency programming and voltage controlled frequency (VCG) are discussed in these sections.

3.8.1 Frequency


The following sections describe the primary parameters related to generator operation. The block of keys involved is labeled MAIN on the front panel.

3.8 GENERATOR

Q1 Selects triggering on the falling edge (⌋) of the trigger signal.

XL followed by its value selects the signal trigger level. The value can be in the -10 to +10 Vdc range with 3 digit resolution. In internal trigger, selecting the trigger level does not affect generator triggering.

C5 Selects external width. In external width, the output pulse period and width is fixed by the trigger signal (internal or external), while output level is adjustable by normal programming (ref: figure 3-4).



External width requires no mode selection but, in external trigger, requires trigger slope and level selection (ref: paragraph 3.7).

Pulse width is between the manual trigger push and release, ASCII **J** and **H** via the GPIB, or TRIG IN signal crossing and recrossing the trigger level value.

External width, when internal trigger is selected, requires selection of a triggered mode. Trigger rate programs the external width pulse period (ref: paragraph 3.7).

C6 Selects a single pulse in phase with SYNC OUT.
C7 Selects a single pulse 180° out of phase with SYNC OUT.

3.8.5 Modes

B followed by its code (0 through 8) selects the operating mode. The selected mode is indicated on the front panel readout when the MODE key is pressed. Three modes depend on a trigger, and four modes require an external reference signal. Refer to paragraph 3.7 for trigger slope and level selection.

B0 Selects continuous operation of the main generator.

B1 Selects triggered mode. The generator is triggered by external signal, internal trigger, manual trigger, or GPIB commands. When triggered, one cycle is generated.

B2 Selects gated mode. The onset of the trigger, regardless of its source (ref: mode **B1**), enables the generator for the duration of the trigger

signal plus the time required for the completion of the last cycle started.

B3 Selects burst mode. Burst is the output of a preprogrammed number of cycles each time the generator is triggered (ref: paragraph 3.8.6).

B4 Selects the synthesizer mode that uses the instrument's internal reference. In synthesized mode, the instrument operates the same as continuous, but with increased frequency accuracy (0.0005%) and resolution (5 digits).

B5 Selects a synthesized mode that requires an external 10 MHz TTL reference signal at the REF IN BNC.
B6 Selects a synthesized mode the same as TTL reference (B5), except a 10 MHz zero-crossing signal is required at the REF IN BNC.

B7 Selects a phase lock mode that requires an external TTL signal at the REF IN BNC. The display reads LOOP LOCKED when the correct reference signal is present and LOOP NOT LOCKED when the signal is incorrect. The external reference frequency must be within 5% of the instrument's programmed frequency.

B8 Selects a phase lock mode the same as a TTL lock (B7), except a zero-crossing signal is required at the REF IN BNC.

3.8.6 BURST

R followed by a value (1 to 1,048,200) denotes the number of cycles in a burst. Duration of a burst is dependent upon the programmed frequency. Burst can be internally or externally triggered.

3.9 PULSE

The following sections describe pulse parameter control for pulse operation. The block of keys involved is labeled PULSE on the front panel. Pulse parameters are defined in Appendix D.

3.9.1 Period

S followed by a value programs, in seconds, the pulse period. Periods are programmable from 90 ns to 1 sec with up to 3 digits of resolution.

3.9.2 Width

N followed by a value, in seconds, denotes the pulse width. Programmed pulse widths are 45 ns to 500 ms with up to 2 digits of resolution.

Pulse width is measured from the 50% point of the leading edge to the 50% point of the trailing edge.

The identifying numbers of programs in RAM range from 1 through 100. If the number of a program which does not exist or an illegal identifying number is programmed, an error will result.

A special location, RCL 0, contains the last executed settings. When power is turned off, RCL 0 contains the last executed settings prior to power off. Pressing the cursor 1 key or programming XW causes the program next in sequence after the last program accessed to be recalled. This provides an automatic way to recall a sequence of programs. However, the programs need not be numbered consecutively. If there is no program following the last program accessed, an error occurs. Pressing the cursor 1 key or programming XU is similar to the cursor 1 or XW action previously described, except that programs are recalled in descending numeric order.

3.10.3 High Speed Recall of Stored Programs

The Group Execute Trigger (GET) allows a rapid GPIB recall of stored programs. In the GET mode of operation, the program is recalled and executed, and the waveform circuits are triggered, all within 2.5 ms of receiving the GET command. There are three possible modes of GET operation (ref: paragraph 3.16.7). There is no error checking in GET mode.

3.10.4 Deleting Programs

To delete a program, program the letter M followed by a minus sign and a number (except 0) of the program to be removed. When the number is terminated (by the next alpha character), the program is removed from storage; there is no other effect.

3.11 OUTPUTS

3.11.1 Function Output

At power-up and reset the FUNC OUT signal is turned off.

3.11.2 Output On/Off

P followed by a code switches the output on or off. P0 Internally disconnects the signal from the FUNC OUT BNC (as described in paragraph 3.11.1) making the signal unavailable at the connector. In P0, the function output presents a high source impedance at the BNC. P1 Internally connects the signal to FUNC OUT BNC.

3.9.3 Upper Level

U followed by its value, in volts, programs the upper peak of all functions except dc. The upper level has a voltage range of -4.98 to +5V with up to 3 digits of resolution. The upper level must always be more positive than the lower level.

3.9.4 Lower Level

V followed by its value, in volts, programs the lower peak of all function except dc. The lower level has a voltage range of -5 to +4.98V with up to 3 digits of resolution. The lower level must always be more negative than the upper level.

3.10 STORED SETTINGS

Up to 100 different sets of front panel settings can be stored in and recalled from Random Access Memory (RAM). Nonvolatile memory is battery backed for 6 month (minimum) retention of settings.

3.10.1 Storing Program Sets

Program sets may be stored by keyboard or GPIB command. To store the program set that is in scratch pad memory (ref: figure 3-2), enter M followed by the storage location (1 through 100). The next alpha programmed is the terminator, which allows the storage to occur. If a program was previously stored in that location, it will be erased and replaced by the new set. When a program is stored, the settings are tested for errors in the same manner as with an execute command (ref: paragraph 3.5). The program is always stored, whether or not errors were detected. Programs can be stored without interrupting the output of the 278 if a terminator other than EXEC (I) is used; this is possible because it is the scratch pad memory that is stored rather than the actual settings of the waveform circuits (ref: figure 3-2). Notice that during 278 operation, scratch pad memory can be changed and stored without affecting 278 output.

3.10.2 Recalling Stored Programs

The information stored in a program may be recovered either from the front panel or by a command over the GPIB. To recall, program a Y followed by the number of desired program. When the next alpha entry is made, the settings stored in the selected program are transferred to display memory and the scratch pad memory (ref: figure 3-2). Then data is available to be sent to the waveform circuitry of the instrument, or, if desired, it may be examined and altered by use of the front panel keys.

P2 Internally disconnects the signal from FUNC OUT making the signal unavailable. The function output source impedance is approximately 50Ω.

3.11.3 Output Protection

The function output is protected from short circuits and external overvoltages over 200 Vdc or 140 Vac without damage to internal circuits.

Overvoltages are handled by using two methods: an overvoltage protection circuit and an output protection fuse.

The overvoltage protection circuit will detect external voltages (greater than ±15 Vdc but less than ±200 Vdc or 140 Vac) at the function output BNC and disconnect the output amplifier from the function output. The disconnection time is approximately 2 ms, but time can vary depending upon the level of the external voltage.

The output protection fuse will blow when an external voltage exceeds 200 Vdc or 140 Vac. When the fuse is blown, the display shows OUTPUT FUSE BLOWN, providing the function out is terminated with 50Ω, during one of the following cycles: after selecting Reset, at power up, after output on/off, or during the internal protection check. If the fuse is blown, remove the top cover, pull out the fuse (located at the rear of the main board), turn the fuse over and insert it. If the display continues to read OUTPUT FUSE BLOWN, replace with a new fuse block (Wavetek part number 1208-00-0977).

3.11.4 Sync Outputs

The SYNC OUT is a 0V to approximately 5V (TTL) signal from a 50Ω source. SYNC OUT is coincident with FUNC OUT. Timing relationships are shown in Appendix D.

3.11.5 Reference Output

The reference output is a 10 MHz TTL level pulse in the synthesized mode (B4). When internal trigger is selected in either the triggered (B1), gated (B2) or burst (B3) modes, the REF OUT will be a TTL level signal at the same frequency as the internal trigger ratio (ref: paragraph 3.7).

3.12 CLEAR ENTRY

The CLR key erases a parameter value which is being entered. The key removes the numeric digits entered

after the last parameter letter entry but prior to execution. A clearable entry can be identified by either of two methods: an asterisk preceding the parameter or a cursor line (—) following the last number. The display is replaced by the previous value (scratch-pad value) of the parameter being programmed.

3.13 RESET

The RST key returns the 278 waveform parameters to their power-on condition. The readout becomes "RESET". Significant parameters values and conditions are given in table 2-3, step 2.

3.14 DISPLAY TEST

The DISP TEST key lights all 20 sets of character segments and semicolon as shown in table 2-3 step 1.

3.15 STATUS

Pressing STAT automatically displays the current waveform generator status one parameter and value at a time (ref: Appendix C). When STAT is pressed a second time the cycling immediately stops. The parameters can then be manually searched by using the CURSOR (↑ or ↓) keys (ref: table 2-3, steps 3 through 6).

3.16 GPIB

Almost all of the information in Section 3 is applicable to the General Purpose Bus (GPIB) programming of the 278, but the information in this paragraph is *exclusive* to the GPIB.

The GPIB interface is an implementation of IEEE Standard 488-1978. It supports the following interface functions: SH1-Complete source handshake, AH1-Complete acceptor handshake, T6-Basic talker, TE0-No extended talker, L4-Basic listener, SR1-Complete service request (software select), RL1-Remote/local and local lockout, PP0-No parallel poll capability, DC1-Complete device clear/selective device clear, DT1-Complete device trigger capability, E2-Tri-state drivers. The talk capability allows a device to send data (such as error message readings) out over the bus. The listen capability allows a device to receive data (such as device programming information) from the bus.

3.16.1 Bus Lines Defined

The GPIB consists of 16 negative true signal lines:

DIO1 - DIO8 Data In/Out Lines
ATN Attention

Listen addresses are used to command a device to read any data bytes transmitted over lines DIO1-DIO8. There are 31 different available addresses (hexadecimal codes 20 through 3E, ASCII codes SP through >). A 32nd address, called unlisten (hexadecimal 3F, ASCII ?), is used to command all devices to not read data bytes. The 278 listen address is selected by internal switches (figure 2-2) or by front panel keyboard; e.g., ADRS 1 EXEC for address number one. Either method of selection specifies the lower 5 bits of the address (ref: table 2-2). Pressing the front panel ADRS key displays the GPIB address as a decimal device number. At power-on the address is always that set by internal switches. Another internal switch (figure 2-2) can lock out address selection by front panel keyboard if desired. Each time ADRS is pressed, **XA** will appear in the CMD RCL string. The address can not be reprogrammed from the GPIB.

3.16.2.1 Listen Addresses

These commands and command groups are shown with their binary codes in Appendix A and further explanation follows.

- 1. Listen Addresses
 - 2. Talk Addresses
 - 3. Secondary Addresses
 - 4. Universal Commands
 - 5. Addressed Commands
- DCL—Device Clear
 SPE—Serial Poll Enable
 SPD—Serial Poll Disable
 LLO—Local Lockout
 GTL—Go To Local
 SDC—Selective Device Clear
 GET—Group Execute Trigger

Commands are sent over lines DIO1-DIO8 with ATN true. They are divided into five classes.

3.16.2 Commands

- 6. **SRO**—This line (Service Request) is used by the 278 and other devices on the bus to signal the controller that they request attention. (Ref: paragraph 3.16.5). Since the SRO line is common to all devices, additional tests must be made to determine which devices are signaling. The controller performs a Serial Poll to accomplish this.
- 7. **IFC**—This line (Interface Clear) is used by the controller to reset the interface logic in all devices connected to the bus to a known initial state.

- 4. **DAV, NRFD, NDAC**—These are the "handshake" lines (Data Valid, Not Ready For Data and Not Data Accepted) which regulate the transmission of information over the lines DIO1-DIO8. For each command or data byte transferred, a complete handshake cycle occurs. This handshake is designed to hold up the bus until the slowest device has accepted the information.
- 5. **EOI**—When ATN is false, EOI (End Or Identify) indicates that the data on lines DIO1-DIO8 is the last byte of a data message. When the 278 receives a data byte with EOI true, the 278 automatically supplies a terminator character (ref: paragraph 3.16.6) following the data byte. When the 278 transmits the last byte of a message (which is always a terminator character), it also sets EOI true.

- 3. **REN**—This line (Remote Enable) controls whether devices on the GPIB are in local or remote modes. In local mode, devices respond to front panel commands and do not respond to GPIB originated commands. In remote mode, the situation is reversed: GPIB originated commands are obeyed, while front panel commands are ignored. The 278 enters the remote state when it receives its listen address (ref: paragraph 3.16.2.1) and REN is enabled. The 278 then stays in the remote mode until the REN line is put in the local state, a Go To Local (GTL) command is received or the LCL front panel key is pressed (ref: paragraph 3.16.2.4, item 4).
- 2. **ATN**—This line (Attention) is operated only by the controller. It specifies whether the information on lines DIO1 - DIO8 is data (ATN false) or a command (ATN true). Whenever ATN is set true, no activity is allowed on the bus except for controller-originated messages; additionally, every device connected to the bus is required to receive and process every command sent by the controller.
- 1. **DIO1-DIO8**—These eight lines (Data IN/OUT) are used to send commands from the controller and transfer data back and forth between instruments and the controller.

- REN Remote Enable
- DAV Data Available
- NRFD Not Ready For Data
- NDAC Not Data Accepted
- EOI End Or Identify
- SRO Service Request
- IFC Interface Clear

control, the GPIB controller must place the REN

line in the local state.

3.16.2.5 Addressed Commands

Addressed commands are used to command a device to perform designated actions. Addressed commands are recognized only when the instrument is addressed as a *listener*. Addressed commands performed by the 278 are:

1. **Go To Local (GTL)**—Commands are 278 to go to the local mode (ref: to paragraph 3.16.1 for explanation of the REN line).

2. **Selective Device Clear (SDC)**—Resets the 278 to initial power on conditions. Refer to paragraph 3.13 for power on conditions. SDC affects only the selected unit.

3. **Group Execute Trigger (GET)**—Causes the actions specified by the GET mode (XG) code (ref: paragraph 3.16.7). If the 278 microprocessor is idle (i.e., not processing a previously sent programming string), a GET command will be completed) within 2.5 ms of receipt. Otherwise, it will not be done until current programming is processed.

3.16.3 Data Transfer

In addition to accepting programming characters, the 278 will transmit status information over the bus. To program the instrument, first send the listen address (with ATN on), followed by the programming data (in ASCII, with ATN off). The instrument microprocessor accepts the data as fast as possible, until either 64 characters are received or there is a pause during the transfer of data. At that time, the entire string of received characters is scanned by the microprocessor, which carries out the scan and accepts the next 64 character string. Whenever the microprocessor is finished scanning a string, the display will show the last parameter of the string. If the EOI line is asserted while sending a character to the 278, the currently programmed terminator character will be put into the input string following the character with the EOI.

3.16.4 Talk Mode

To read a message from the 278, send the talk address (with ATN on) over the bus. The instrument will then send the message currently selected by the Talk Mode (XT) setting. The last character of the 278's message will be the currently programmed terminator character with the EOI line asserted.

3.16.2.2 Talk Address

Talk addresses are used to command a device to transmit data over lines DIO1-DIO8 whenever ATN is false. There are 31 different available addresses (hexadecimal codes 40 through 5E, ASCII codes @ through v). A 32nd address, called *untalk* (hexadecimal 5F, ASCII —) is used to command all devices to cease talking. The lower 5 bits of the 278 talk address are selected by the same switches used to select the listen address. Thus, if the 278 listen address is hexadecimal 21 (ASCII i), the talk address is hexadecimal 41 (ASCII A). Pressing the front ADPS key displays the GPIB address as a decimal device number.

3.16.2.3 Secondary Address

Secondary addresses are used following a talk or listen address to provide the ability to address more than the 31 devices provided for by simple talk or listen addresses. Secondary addresses are ignored by the 278.

3.16.2.4 Universal Commands

Universal commands are used to command a device to perform designated actions. Universal commands are recognized at all times. Universal commands performed by the 278 are:

1. **Device Clear (DCL)**—Resets the 278 to the initial power on settings. Refer to table 2-3, step 2 for power on conditions. DCL affects all devices on the bus. This information is also set into the waveform generating circuitry.

2. **Serial Poll Enable (SPE)**—Causes the instrument to engage in a serial poll by responding with the serial poll status byte when addressed as a talker. Data line DIO7 will be on, if service is being requested on the SRC line. When the status byte is read, it is reset to an ASCII blank, and the SRC line is released (of course, it may still be held down by other devices). The status byte is also available by reading the 278 talk message number 1. When this message is read, the status byte is reset and SRC released as for the serial poll.

3. **Serial Poll Disable (SPD)**—Discontinues serial poll. Returns instruments to normal talk modes.

4. **Local Lockout (LLO)**—Causes the 278 to enter a state where the front panel LCL key is inoperative. In this state, the keyboard is disabled and the instrument will only accept parameter changes through the GPIB. To enable keyboard

XT followed by a code (0 through 8) selects the kind of message the 278 will send when it is addressed as a talker on the GPIB.

XT0 Programming Error List (only errors from GPIB input). A typical error string is E 1F 2AD 3Y.

Some error string characteristics are:

a. All error strings begin with E.

b. Most recent error is at the end of string.

c. Errors are separated by spaces.

d. Class 1 Error: A 1 followed by programming character that caused the error.

e. Class 2 Error: A 2 followed by the two consecutive program characters.

f. Class 3 Error: A 3 followed by M (Store) or Y (Recall).

g. Error strings can be up to 80 characters including E and blanks.

h. After transfer, the instrument clears the error string.

XT0 is the power-up talk mode.

XT1 Poll Byte Response: The byte sent if a serial poll was performed. The controller, by reading this byte, causes the instrument to clear the poll byte and reset the SRQ line if asserted. The poll byte sent is described in table 3-5.

XT2 The most recently selected parameter and its value. Example: FREQ 1E3. If no parameter is selected; e.g., power-on state or reset, then returns: NO PARAMETER SELECTED.

XT3 The entire instrument setup after last execute. Example: F1E3A5D0B0C0R2S1E-3N45E-9U2;5V-2;5G0T200P0Q0XL1.5 (the instrument setup immediately after a reset or on power up). The instrument setup when execute is received; same format as **XT3**.

XT5 Instrument Identification: WAVETEK MODEL 278 V(X,Y). X,Y identifies the software version number.

XT6 The time since the instrument was powered on. Example Time: 1.3. Unit of measure is hours with 0.1 hour resolution (6 minutes).

XT7 The accumulated operating time. Example: TOTAL TIME: 306.2.

NOTE:

Toggle switch 7 (figure 2-2) clears the instrument-operating-time clock. With SW7

The terminator character has two uses. During output, it is appended to the end of every response to a

3.16.6 End of String or Terminator Specification
XV followed by its argument designates a new End Of String (EOS) or terminator character. The argument is the decimal value of the ASCII character that is to be the new terminator: an EOS character recognized by the 278. Any ASCII character except NUL is accepted.

3.16.5.2 SRQ Key
The SRQ key is located on the front panel of the 278. To use the SRQ key, the 278 must be in the local mode and the SRQ mode bit weight 128 must be selected (ref: table 3-6). Under these conditions, pressing the SRQ key asserts the SRQ line of the GPIB.

XQ1 is the SRQ power up mode.

3.16.5.1 SRQ Mode
XQ followed by a value (0 through 255) selects the conditions under which the 278 asserts the SRQ line and rsv bit. The equivalent binary value is a "mask" for the serial poll response byte (ref: table 3-6). The binary mask selects certain conditions that will be recognized as conditions that assert the SRQ line and rsv bit. All other conditions are ignored (masked). Table 3-6 shows the serial poll response byte. Each of the 8 bits represent a condition that, if selected by the SRQ mode, will assert the GPIB's SRQ line and the serial poll byte's rsv bit. Each bit may be selected individually or in various combinations. The rsv bit (bit decimal position 64) and the undefined bit (bit decimal position 32) will have no affect if selected.

For example **XQ1** dictates that the SRQ line and the serial poll byte's rsv bit are asserted when there is a program error, such as, frequency beyond the 278's limits. The serial poll response byte will be 0100001. In another example, **XQ131** dictates that the SRQ line and the rsv bit are asserted when a program error has occurred, the output protection is enabled, or the SRQ key is pressed. The serial poll response byte will be 11000011.

3.16.5 SRQ (Service Request)

XT8 The number of stored settings installed. For the 278: STORED SETTINGS 100.

on, the clock runs during power on. With SW7 off, the clock clears to zero.

The front panel LCL key switches the GPIB interface

3.16.8 Local

Upon receipt of GET, the stored setting next in sequence after the last stored setting accessed is recalled, if it exists. Then the actions described for code 0 are performed. This is the same sequence of events that would occur if a next setting, an execute and a trigger action (XWIL) were programmed, except that no error checking is done.

Upon receipt of GET, the stored setting previous in sequence before the last stored setting accessed is recalled if it exists. Then the actions described for code 0 are performed. This is the same sequence of events that would occur if a next setting, an execute and a trigger action (XWIL) were programmed, except that no error checking is done.

Upon receipt of GET, the stored setting next in sequence after the last stored setting accessed is recalled, if it exists. Then the actions described for code 0 are performed. This is the same sequence of events that would occur if a next setting, an execute and a trigger action (XWIL) were programmed, except that no error checking is done. GET mode 0 is the power up condition.

1 -

Upon receipt of GET, the programmed waveform values are transferred to the waveform generator circuits, and then the microprocessor

XG followed by its code selects what actions occur when a Group Execute Trigger (GET) command is sent to the 278. The code may be 0, 1 or - 1.

3.16.7 GET Mode

At power on time, the EOS character is the line feed control character, ASCII character LF (10₁₀). When the 278 issues a talk message, the EOS character is the last byte sent. In addition, the End Or Identify (EOI) line is pulsed low (END message) during the EOS character transmission. If the GPIB controller does not look for the END message (EOI line low), and it does not recognize the Line Feed (LF) as a string terminator, a new EOS character will be needed. For example, to change the EOS character from an LF to a Carriage Return (CR), program XV13.

talk request on the GPIB. During input, it signals, the end of a group of programming characters. Since it is always recognized, even in a quoted string, it can be used to insure that the instrument is in a known state, so that following programming characters will be interpreted correctly.

* Binary Code: 1 = Selected
0 = Not Selected

Bit	Decimal Position	Binary Position*	Bit Name	Bit Description
128	(MSB)	1000 0000	SRO Key	A front panel key (ref: paragraph 3.15.5.2).
64		0100 0000	rsv	Request for service.
32		0010 0000	Undefined	Undefined bit.
16		0001 0000	Reference	Indicates the generator is not locked to the external reference signal.
8		0000 1000	Low Battery	Indicates a low battery level for memory back-up battery (ref: paragraph 3.10).
4		0000 0100	Fuse Blown	Indicates output amplifier fuse is blown (ref: paragraph 3.11).
2		0000 0010	Output Protection	Indicates output protection is tripped (ref: paragraph 3.11)
1	(LSB)	0000 0001	Program Error	Indicates a program error; it can be either class 1, 2 or 3 error (ref: paragraph 3.4).

Table 3-6. Serial Poll Response Byte

to the local mode if it is not locked out (ref: paragraph 3.16.2.4, item 4).

3.16.9 Display

The single quote character (') is used to program a string of characters to be displayed on the front panel display. Program a single quote, the characters to be displayed, followed either by another single quote or by the terminator character. When the second quote or the terminator is programmed, the first 20 characters programmed after the first quote are displayed on the front panel. If fewer than 20 characters are programmed, then blanks are added to fill the display.

Examples (\ indicates a blank character)

Three Programmed Inputs

1. 20^CHARACTER^LIMIT

- 2. THIS^STRING^IS^TOO^LONG^TO^DISPLAY^ENTIRELY
- 3. ^ (no characters in string)

The Resulting Displays

1. 20^CHARACTER^LIMIT^

2. THIS^STRING^IS^TOO^

3. (blank display)

3.16.10 Command Recall

Pressing **CMD RCL** displays the last 40 parameters, values and actions (all in ASCII Code) sent to the 278 from the keyboard and the GPIB. The display shows only 20 characters at a time, and the CURSOR — and — must be used to see the entire 40 character program string.

