

5 December 2003

POCSAG Paging via the TM8100

Introduction

The TM8100 is able to support POCSAG modulation via the use of an external Encoding device. The modulation from the device is tapped into the radios audio processing chain and conveyed over the air when the appropriate External Press To Talk (EPTT) is activated.

The following is an example of the use of this feature, this particular application involves using the radios inbuilt selcall and external alert facilities.

An example of where this application could be used would be any situation where vehicle operators (e.g. taxi/courier drivers) typically respond to selcall calls. When away from their vehicles they would carry a POCSAG pager and therefore not miss critical calls.

POCSAG Paging



Please note that the use of POCSAG modulation requires regulatory approval in some countries.

In the example above, the pager used is a LASER NUMERIC POCSAG pager. Details of this unit can be found at <http://www.atiwireless.net/>


The POCSAG encoder board used was the MIDIAN ANI-MP. Details of this unit are available from the Midian Product catalogue. <http://www.midians.com/index.asp>. Look under PRODUCTS/PAGING and DIALING/POCSAG for the specification sheet and manual.

We have also sourced pagers from Selective Communications in Auckland, and used the APOLLO model AL-901 Numeric Pager in our TM8100 Product Roadshow. This can be seen at <http://www.selective.co.nz/pagers.html>, some of these pagers are synthesised and are available in different frequency bands.

Operational Description

In the diagram above RADIO B has been configured to internally alert to a selcall call for a set period of time, and then if the call remains unanswered to activate an **EXTERNAL ALERT**.

This external alert line is connected to one of the inputs of the POCSAG Encoder. On receipt of the output trigger from the radio, the Encoder is programmed to Externally PTT the radio and send the POCSAG paging string to its Transmitter. The radio is also programmed to "TAP" the incoming pocsag modulation into the appropriate point in the TX audio processing chain. (As POCSAG modulation extends from close to DC, it is necessary to bypass some of the usual "voice" filtering.)




Connection details

The diagram below shows an example of how the Midian Encoder could be connected to the TM8100 via the Auxiliary connector.

Details of the required programming for the Encoder board are after the radio programming information.

The PCB is small enough to mount in the housing of a D RANGE plug, The plug is then connected to the back of the radio.

Alternatively, the encoder PCB could be mounted in the options area within the radio and connected to the INTERNAL OPTIONS CONNECTOR. In this instance the signals would need to be programmed to interface with this connector and not the Auxiliary one. We have only shown the D-Range connections in this document.




HARDWARE CONNECTION DETAILS

Radio Programming Details


The TM8100 needs to be configured so that its Auxiliary connector is interfaced with the POC SAG Encoder. A default datafile can be supplied on request. Some connections on the auxiliary connector are fixed (12V supply, GND, AUDIO TAP IN), but a programmable I/O line must be assigned for External Alert and EPTT1.

The radio first needs to be configured and set up using the customers existing SELCALL set up information or new selcall set up created if not currently using Selcall.


1. Under the ALERTS / GENERAL tab, the internal alert duration needs to be set to the required length and External alert needs to be enabled



- Under the ALERTS / EXTERNAL ALERTS tab, set the behaviour of the selected external alert. Delay before it is sent, the duration of the alert and the signal pattern to STEADY.




- In order to ensure that the EPTT1 takes priority, it can be set for the HIGHEST in the PTT / EXTERNAL PTT(1) tab. Additionally the audio source for this PTT is set for AUDIO TAP IN.




- In the PROGRAMMABLE I/O DIGITAL tab, GPIO4 has been configured as an output, which will be the External alert to the Pocsag pager module. GPIO6 has been set to an input, and is the EPTT line from the POCSAG module.

- Both are set for active low, and the PTT line has been given a debounce value of 10 mS.




Alternatively, if you wished to initiate the POCESAG page on a different channel from the one the SELCALL call was made on: Configure another input in the programmable I/O form, and set the action for PRESET CHANNEL.




- Make the DEBOUNCE for the EPTT input longer (60 ms in this case) and set the DEBOUNCE for the Preset channel for a shorter time (10ms in this case).

7. In this case the PRESET CHANNEL has been defined as CH2 in the bottom right corner of the PROG I/O page.
8. The PTT line from the Pager board is fed to BOTH the inputs on the connector of the radio (i.e. GPIO 6 & 7: Aux pins 9 & 1 in this example) This is shown in the connection diagram below.



9. When the PTT line from the ANI module goes LOW, after the debounce time of 10ms the radio initiates a channel change then after a further 50ms the radio initiates a PTT.
10. In the PROGRAMMABLE I/O AUDIO tab, the AUDIO TAP IN point has been configured to insert the pocsag modulation at the appropriate point in the TX audio processing chain. As POCSAG modulation requires a response close to DC, it is important that the traditional subaudible filtering and pre-emphasis are bypassed.
11. The Tap type is set for BYPASS (The TAP IN audio replaces any other audio source – like the microphone audio).

12. The TAP IN is set to occur ON EPTT1. (We have already identified that this will be EPTT1 on the previous PTT programming tab).



The method of activation of the POCESAG encoder via an External alert line is not the only way the radio could be configured.

E.g. The radio could be programmed to activate a digital control line on receipt of its selcall identity with the correct control status digit.


ANI Module Programming

The MIDIAN ANI module is available with an operation manual and programming software (KL-3) as well as a programming lead.

Please refer to this for connection to the module for programming.

To Program the module:

- Ensure you have the right **COM** port (**FILE/PREFERENCES/COM 1-4**)
- **READ** the current settings



- The programmer is divided into global settings at the top and 3 independent configurable settings for each of the available inputs (1-3)
- Below is a description of the programming features.

GLOBAL SETTINGS

KEYUP DELAY: This sets the delay that can be set after the PTT signal is sent out, before the actual POCSAG modulation is sent to the radio.

REPEAT INTERVAL: If the module has been programmed to send more than one transmission of the POCSAG modulation, this is the time interval between each transmission.

TRANSMIT COUNT: The module can be configured to send the POCSAG modulation from 1 – 99 times once its input has been triggered.

INVERT: The POCSAG modulation polarity can be inverted if required. This is necessary for transmission to some POCSAG paging units.

UPDATE: With this selected, the programmer will be given a visual indication (Via the Memory Use indicator to the left of the tick box) of the amount of memory buffer used.

DETAILS OF TRANSMITTED DATA FOR EACH INPUT

All 3 inputs have the same fields for data input.

PAGER ADDRESS : This number is used to address the required pager. Up to 7 digits can be used.

DEBOUNCE: A debounce can be programmed on the input trigger, which must go low or high for the programmed period of time before the encoder will initiate a paging call.

BAUD RATE: The Pocsag data rate can be configured for either 512, 1200 or 2400.

LOW INPUT : If the Input trigger is expected to be low, (Otherwise select **D** and use the HIGH INPUT below).

- A page of **1-4 rings** to be heard by a tone only pager.
- **N** for a numeric pager followed by the string of digits you want displayed by the pager.
- **A** for an alphanumeric pager followed by the characters you want displayed by the pager.

HIGH INPUT : If the Input trigger is expected to be high, (Otherwise select **D** and use the LOW INPUT above).

- A ring page of 1-4 to be heard by a tone only pager.
- N for a numeric pager followed by the string of digits you want displayed by the pager.
- A for an alphanumeric pager followed by the characters you want displayed by the pager.
- To save any changed settings, **PROGRAM** the module

Midian Electronics KL3 - Universal Board Programmer - [ANI-MP: animp.dft]

File ReadUnit! ProgramUnit! Window Help

0.5 Keypad delay (front porch) [0.00-300.00 seconds] Update

10 Repeat interval [0.00-300.00 seconds] 2 Transmit count [1-99 times] Invert

Transmitted Data for Each Input

Input 1

1595640 Pager Address 0.5 Debounce (0.01-300.00 seconds)

Baud Rate: Low Input - Select Disabled, # of rings or Numeric/Alphanumeric Message

512 D 1 2 3 4 N A 1234567

1200

High Input - Select Disabled, # of rings or Numeric/Alphanumeric Message

2400 D 1 2 3 4 N A

Input 2

1595640 Pager Address 0.2 Debounce (0.00-300.00 seconds)

Baud Rate: Low Input - Select Disabled, # of rings or Numeric/Alphanumeric Message

512 D 1 2 3 4 N A

1200

High Input - Select Disabled, # of rings or Numeric/Alphanumeric Message

2400 D 1 2 3 4 N A

Input 3

1595640 Pager Address 0.3 Debounce (0.00-300.00 seconds)

Baud Rate: Low Input - Select Disabled, # of rings or Numeric/Alphanumeric Message

512 D 1 2 3 4 N A

1200

High Input - Select Disabled, # of rings or Numeric/Alphanumeric Message

2400 D 1 2 3 4 N A

ANI ENCODER MODULATION LEVEL

The POCSAG modulation level must not exceed 1.5KHz for Narrowband channels and 3KHz for Wideband. There is a modulation adjustment on the POCSAG encoder PCB (R12) that can be used to set this if necessary.

Pager Setup

Depending on the pager you are using you will either have to order the pager on a certain frequency or you can get a synthesised pager and program it to match the frequency the TM8100 is transmitting on with your POCSAG signal.

Instructions for programming this are usually supplied with the pager units, and are different depending on the manufacturer.

They are available in different frequency bands but it must be in the same band as the radios channel used for the sending the POCSAG modulation.



If you require any clarification or further information please contact the National Support Centre on 0800 MOBILE (0800 662453).

**TaitNet Support Services
Tait Communications Ltd**

540 Wairakei Road, PO Box 1185,
Christchurch, New Zealand.
Phone: 03 3572 750

Fax: 03 3582 029

email: helpdesk@tcl.tait.co.nz

Website: www.support.taitworld.com

Issued by:

Barry Deuart
Senior Customer Service
Technician

Distribute to:

All Sales and Technical Staff

