

*inform*

**T610 Mobile Data Terminal  
Service Manual**

**Issue 1.00**

**June 1995**

**M610-100-100**



### **Head Office New Zealand**

Tait Electronics Ltd  
558 Wairakei Road  
P.O. Box 1645  
Christchurch  
New Zealand  
Phone: 64 3 358-3399  
Fax: 64 3 358-3636

### **Australia**

Tait Electronics (Aust) Pty Ltd  
275 Toombul Road  
Northgate 4013  
P.O. Box 679  
Virginia  
Queensland 4014  
Australia  
Phone: 61 7 260-7799  
Toll Free: 1800 077-112  
Fax: 61 7 260-7990

### **Canada**

Tait Mobile Radio Inc.  
Unit 5, 158 Anderson Avenue  
Markham  
Ontario L6E1A9  
Canada  
Phone: 1 905 472-1100  
Toll Free: 1 800 890-8248  
Fax: 1 905 472-5300

### **France**

Tait France Sarl  
2 Avenue de la Cristallerie  
92 316 Sèvres, Cedex  
France  
Phone: 33 1 41 14-05-50  
Fax: 33 1 41 14-05-55

### **Germany**

Tait Mobilfunk GmbH  
Willstätterstraße 50  
D-90449 Nürnberg 60  
Germany  
Phone: 49 911 96 746-0  
Fax: 49 911 96 746-79

### **New Zealand**

Tait Communications Ltd  
Unit 4, 75 Blenheim Road  
P.O. Box 1185  
Christchurch  
Phone: 64 3 348-3301  
Fax: 64 3 343-0558

### **Singapore**

Tait Electronics (Far East) Pte Ltd  
4 Leng Kee Road  
SIS Building #05-11A  
Singapore 0315  
Phone: 65 471-2688  
Fax: 65 479-7778

### **United Kingdom**

Tait Mobile Radio Ltd  
Ermine Business Park  
Ermine Road  
Huntingdon  
Cambridgeshire PE18 6YA  
United Kingdom  
Phone: 44 1480-52255  
Fax: 44 1480-411996

### **USA**

Tait Electronics (USA) Inc.  
9434 Old Katy Road  
Suite 110  
Houston  
Texas 77055  
USA  
Phone: 1 713 984-8684  
Toll Free: 1 800 222-1255  
Fax: 1 713 468-6944

# Contents

## Preliminary Pages

Scope of Manual .....	vii
Technical Information .....	vii
Updating Equipment And Manuals .....	vii
Copyright .....	vii
Trademarks .....	vii
Ordering Tait Service Manuals .....	vii
Date Of Issue .....	vii
Amendment Procedure .....	viii
List of Effective Pages .....	ix

## 1 Introduction

1.1 Introduction to this Service Manual .....	1-1
1.2 Introduction to the T610 MDT .....	1-2
1.3 Specifications .....	1-3
1.3.1 Mechanical Specifications .....	1-3
1.3.2 Electrical Specifications .....	1-4
1.3.3 Miscellaneous Specifications .....	1-4

## 2 Health and Safety Information

2.1 Hazards During Use of the MDT .....	2-2
2.2 Hazards During Service of the MDT .....	2-3
2.2.1 Caution: CMOS Devices .....	2-3
2.2.2 Lithium Batteries .....	2-3
2.2.2.1 Battery Handling .....	2-4
2.2.2.2 Contact with Antistatic Conductive Materials .....	2-5

### 3 Circuit Operation

3.1	General	3-1
3.1.1	Protection Circuitry	3-1
3.1.2	Power Supplies	3-3
3.1.3	LCD Backlighting	3-3
3.1.4	Piezo and Driver	3-3
3.1.5	Serial Interface	3-4
3.1.6	Keypad	3-4
3.1.7	LCD Module	3-4
3.1.8	Microprocessor and Memory Circuits	3-4

### 4 Servicing

4.1	Introduction to Servicing	4-2
4.1.1	Pozidriv Recess Head Screws	4-2
4.1.2	Screw Torques	4-2
4.1.3	Conventions	4-3
4.1.4	Tools required	4-2
4.1.5	Caution: CMOS Devices	4-3
4.2	Disassembly	4-4
4.2.1	Removing the MDT from its Working Installation	4-5
4.2.1.1	Disconnecting the Data Cable	4-5
4.2.1.2	Removing the MDT from the Mounting Bracket	4-5
4.2.2	Removing the Sunshield	4-6
4.2.3	Disassembling the MDT	4-6
4.2.3.1	Separating the Front Panel and Rear Panel Assemblies	4-7
4.2.3.2	Separating the Main PCB from the Rear Panel	4-8
4.2.3.3	Removing the PCB Shield	4-9
4.2.3.4	Separating the LCD from the Front Panel	4-10
4.3	Servicing	4-11
4.3.1	Component Replacement	4-11
4.3.1.1	Leaded Components	4-11
4.3.2	Surface Mount Devices	4-12
4.3.3	Fitting a New Battery to the Main PCB	4-12
4.4	Assembly	4-14
4.4.1	Fitting the LCD to the Front Panel	4-14
4.4.2	Fitting the Main PCB and Shield to the Rear Panel	4-15
4.4.2.1	Fitting the Shield to the Main PCB	4-15
4.4.2.2	Completing the Rear Panel Assembly	4-16
4.4.3	Completing the Assembly	4-17

## 5 Functional Tests

5.1	Preparation for Testing	5-2
5.1.1	Serial Port Loop Back Test Connector	5-2
5.1.2	Test Equipment	5-3
5.2	Testing the MDT	5-4
5.2.1	Starting Up the MDT in Test Mode	5-4
5.2.2	Power Up Self-Test	5-5
5.2.2.1	Self-Test Failure	5-5
5.2.3	Supervising Test Mode	5-6

## 6 Fault Finding

6.1	MDT Won't Power Up	6-2
6.2	Start-up Self Test Failure	6-4
6.2.1	LCD Module Test Failure	6-4
6.2.2	RAM Operation Test Failure	6-4
6.2.2.1	Address Decoding	6-5
6.2.3	RAM Integrity Test Failure	6-6
6.3	Test Mode Failures	6-7
6.3.1	Port 1 and/or Port 2 Test Failure	6-7
6.3.1.1	Port 1 and Port 2 Tests Fail	6-8
6.3.1.2	Port 1 Test Fails	6-9
6.3.1.3	Port 2 Test Fails	6-10
6.3.2	Serial # Test Failure	6-11
6.3.3	Flash ROM Test Failure	6-12
6.3.4	Piezo Test Failure	6-12
6.3.5	Backlight Test Failure	6-14
6.3.6	Contrast Test Failure	6-15
6.3.7	Key Test Failure	6-16

## 7 PCB Information

7.1	Using the PCB Information	7-1
7.1.1	Circuit Diagram and PCB layouts	7-2
7.1.2	Grid Reference Index	7-2
7.1.3	Parts List	7-3
7.2	Main PCB (IPN 220-01310-01)	7-4
	Parts List	7-4
	Mechanical and Miscellaneous Parts	7-6
	Grid Reference Index	7-7
	PCB Layout	7-8
	Circuit Diagram	7-11

## List Of Illustrations

Figure 2.1	Typical Antistatic Bench Setup .....	2-3
Figure 3.1	T610-100 Block Diagram .....	3-2
Figure 4.1	Typical Antistatic Bench Setup .....	4-3
Figure 4.2	Removing the MDT from its Working Installation .....	4-5
Figure 4.3	Disassembling the MDT - Rear View .....	4-7
Figure 4.4	Separating the Main PCB from the Rear Panel - Internal View .....	4-8
Figure 4.5	Disconnecting the LCD to Main PCB Ribbon Cable .....	4-9
Figure 4.6	Separating the LCD from the Front Panel - Internal View of Front Assembly .....	4-10
Figure 4.7	Fitting the LCD to the Front Panel - Internal View of Front Assembly .....	4-14
Figure 4.8	Fitting the Main PCB and Shield to the Rear Panel - Internal View ..	4-15
Figure 4.9	Connecting the LCD to Main PCB Ribbon Cable .....	4-16
Figure 4.10	Assembling the MDT - Rear View .....	4-17
Figure 5.1	Wiring Arrangement for Serial Port Loop Back Test Connector .....	5-2
Figure 5.2	MDT Test Mode Display .....	5-4
Figure 5.3	MDT System Start-up Message .....	5-5
Figure 5.4	MDT Test Mode Display - Tests Complete .....	5-7
Figure 6.1	SN1 Pin Configuration .....	6-11
	T610 Main PCB - Top Side .....	7-8
	T610 Main PCB - Bottom Side .....	7-9

## List Of Tables

Table 4.1	Screw Torques .....	4-2
Table 4.2	MDT Disassembly - Primary Units and Sub-units .....	4-6
Table 5.1	Self-Test Fail Notification .....	5-5
Table 5.2	Test Routines and Outcomes .....	5-6
Table 6.1	Serial Communications .....	6-5

## Scope of Manual

This Manual contains technical and servicing information in support of the *inform* T610 Mobile Data Terminal (MDT).

## Technical Information

Any enquiries regarding this manual or the equipment it describes should be addressed in the first instance to your nearest approved Tait representative. Further technical assistance may be obtained from Tait Mobile Data, Tait Electronics Ltd, Christchurch, New Zealand.

## Updating Equipment And Manuals

In the interests of improving performance, reliability or servicing, Tait Electronics Ltd. reserve the right to update their equipment and/or manuals without prior notice.

## Copyright

All information contained in this manual is the property of Tait Electronics Ltd. All rights are reserved. This manual may not, in whole or part, be copied, photocopied, reproduced, translated stored or reduced to any electronic medium or machine readable form without prior written permission from Tait Electronics Ltd.

## Trademarks

*inform*<sup>TM</sup> is a trademark of Tait Electronics Limited.

## Ordering Tait Service Manuals

Service Manuals should be ordered from your nearest approved Tait representative. When ordering, quote the Tait Internal Part Number (IPN) and, where applicable, the version.

## Date Of Issue

IPN: M610-100

*inform* T610 MDT Service Manual  
Issue 1.00 published 15th June 1995

## Amendment Procedure

This manual is subject to an amendment procedure which allows it to be updated to include details of any modifications that may be made to the *inform* MDT. The salient details of the amendment procedure are as follows:

- The manual is provided as loose-leafed pages assembled in a ring binder to allow obsolete pages to be removed and exchanged for current information.
- All amendments are issued in the form of revision packages. Revision packages comprise copies of all updated pages and specific instructions for the incorporation of each amended page into the manual.
- Each time a revision package is released, all registered copyholders of the manual are notified. Copies of the revision package can be ordered from Tait Electronics as required. Revision packages are provided ready-punched for inclusion in your manual.
- Each page in this manual is printed with an issue status to allow you to identify which pages have been updated. Whenever an amended page is issued by Tait Electronics, the issue status of the page shall be updated also.
- A list of effective pages is included among the preliminary pages of this manual. The list shows the issue status of each page. Whenever an amended page is issued, an updated list of effective pages shall be issued also.
- It is the responsibility of the copyholder to ensure that all amendments are incorporated into the manual.



## List Of Effective Pages

This manual comprises a total of 76 pages, as listed below.

**Note:** Any portion of text that has been changed is indicated by a vertical line in the outer margin of the page.

Page	Issue Date	4-16	15/6/95	
i	15/6/95	5-1	15/6/95	
ii	15/6/95	5-2	15/6/95	
iii	15/6/95	5-3	15/6/95	
iv	15/6/95	5-4	15/6/95	
v	15/6/95	5-5	15/6/95	
vi	15/6/95	5-6	15/6/95	
vii	15/6/95	5-7	15/6/95	
viii	15/6/95	5-8	15/6/95	
ix	15/6/95			
x	15/6/95	6-1	15/6/95	
		6-2	15/6/95	
1-1	15/6/95	6-3	15/6/95	(fold-out)
1-2	15/6/95	6-4	15/6/95	(fold-out)
1-3	15/6/95	6-5	15/6/95	(fold-out)
1-4	15/6/95	6-6	15/6/95	(fold-out)
		6-7	15/6/95	(fold-out)
2-1	15/6/95	6-8	15/6/95	(fold-out)
2-2	15/6/95	6-9	15/6/95	(fold-out)
2-3	15/6/95	6-10	15/6/95	(fold-out)
2-4	15/6/95	6-11	15/6/95	
2-5	15/6/95	6-12	15/6/95	
2-6	15/6/95	6-13	15/6/95	(fold-out)
		6-14	15/6/95	(fold-out)
3-1	15/6/95	6-15	15/6/95	(fold-out)
3-2	15/6/95	6-16	15/6/95	(fold-out)
3-3	15/6/95			
3-4	15/6/95	7-1	15/6/95	
		7-2	15/6/95	
4-1	15/6/95	7-3	15/6/95	
4-2	15/6/95	7-4	15/6/95	
4-3	15/6/95	7-5	15/6/95	
4-4	15/6/95	7-6	15/6/95	
4-5	15/6/95	7-7	15/6/95	
4-6	15/6/95	7-8	15/6/95	
4-7	15/6/95	7-9	15/6/95	
4-8	15/6/95	7-10	15/6/95	
4-9	15/6/95	7-11	15/6/95	(fold-out)
4-10	15/6/95	7-12	15/6/95	(fold-out)
4-11	15/6/95			
4-12	15/6/95			
4-13	15/6/95			
4-14	15/6/95			
4-15	15/6/95			

END OF PRELIMINARY PAGES