

---

# Contents

---

## Part A: Introduction

<b>Servicing Tait Orca 5000 portable radios .....</b>	<b>A-3</b>
WWW technical support .....	A-3
What does this manual contain? .....	A-3
Calibration service kit .....	A-3
Programming kit .....	A-4
<b>The Tait Orca 5000 series of portable radios .....</b>	<b>A-5</b>
The Tait Orca product code .....	A-5
Operating instructions .....	A-5
Accessories .....	A-5
<b>Important information .....</b>	<b>A-9</b>
Basic servicing precautions .....	A-9
Programming .....	A-9
Calibrating .....	A-10
Test facilities .....	A-10
Basic maintenance .....	A-10
<b>Servicing Intrinsically Safe radios .....</b>	<b>A-11</b>
Intrinsically Safe radios .....	A-11
IS PCB servicing requirements .....	A-11
FM approval .....	A-11
FM approved products .....	A-11
FM approved accessories .....	A-11

## Part B: Radio specifications and circuit descriptions

<b>Radio specifications .....</b>	<b>B-3</b>
General specifications.....	B-3
Receiver performance .....	B-3
Transmitter performance .....	B-4
TOP-Axxxx 66-88MHz radio specifications.....	B-5
TOP-Bxxxx 136-174MHz radio specifications .....	B-6
TOP-Cxxxx 174-225MHz radio specifications .....	B-7
TOP-Gxxxx 336-400MHz radio specifications.....	B-8
TOP-Hxxxx 400-470MHz radio specifications.....	B-9
TOP-Ixxxx 450-530MHz radio specifications .....	B-10

TOP-Jxxxx 806-870MHz radio specifications.....	B-11
TOP-Kxxxx 896-941MHz radio specifications .....	B-12
<b>Circuit descriptions .....</b>	<b>B-13</b>
Transmitter .....	B-13
Transmit (Tx) audio .....	B-13
Receiver .....	B-13
Receive (Rx) audio .....	B-13
DSP .....	B-14
Synthesiser and VCO .....	B-14
Power supplies .....	B-14
Accessory connector interface .....	B-15
Universal band versus wideband IF filtering .....	B-15

## Part C: Diagnostics and fault finding

<b>Test facilities .....</b>	<b>C-3</b>
Error codes .....	C-3
Test commands.....	C-5
Calculating the parameters required for test command 101.....	C-7
<b>Fault finding charts .....</b>	<b>C-8</b>
Radio cannot be switched on .....	C-9
Cannot change channel .....	C-10
No serial communication .....	C-11
Receive faults .....	C-12
Cannot transmit .....	C-13
No transmit audio .....	C-14

## Part D: Servicing the radio

<b>Servicing the radio .....</b>	<b>D-3</b>
Screw head types .....	D-3
<b>Disassembling the radio .....</b>	<b>D-4</b>
Removing the front panel from the chassis .....	D-4
Removing the shield sub-assembly from the chassis .....	D-5
Removing the PCB from the chassis .....	D-6
Removing the rear panel .....	D-7
<b>Replacing key mechanical and ancillary devices .....</b>	<b>D-8</b>
Replacing the lens (Orca 5015/2x/35/40) .....	D-8
Replacing the PTT keypad .....	D-8
Replacing the speaker .....	D-9

Replacing the LCD display (Orca 5015/2x/35/40) .....	D-9
Replacing the shield, user interface PCB and polyester dome (Orca 5015/2x/35/40) .....	D-12
Replacing the antenna connector, channel selector switch and volume control switch .....	D-12
Replacing the microphone .....	D-12
Replacing the battery and speaker contacts .....	D-12
Replacing the tact switch .....	D-12
Replacing the chassis .....	D-13
<b>Reassembling the radio .....</b>	<b>D-14</b>
Rear panel reassembly and replacing the auxiliary flexible PCB .....	D-14
Fitting the PCB to the chassis and replacing the RF out assembly .....	D-15
Fitting the shield to the chassis .....	D-15
Fitting the front panel to the chassis .....	D-16
<b>Spares kits .....</b>	<b>D-17</b>
Information contained in the tables .....	D-17
PCB Product Codes .....	D-17
Orca 5010/11/30 spares kit (TOPA-SP-401G) .....	D-18
Orca 5035 spares kit (TOPA-SP-402G).....	D-19
Orca 5015/2x/40 spares kit (TOPA-SP-403G).....	D-20
Orca 5010/11/30 re-skinning kit (TOPA-SP-404) .....	D-21
Orca 5035 Re-skinning kit (TOPA-SP-405).....	D-21
Orca 5020/40 Re-skinning kit (TOPA-SP-406).....	D-21
Orca 5015/2x/35/40 User Interface PCB and Shield (TOPA-SP-407) .....	D-22
Orca 5015/21 Re-skinning kit (TOPA-SP-408).....	D-22

## Part E: Battery packs and chargers

<b>Battery packs .....</b>	<b>E-3</b>
Battery shift life .....	E-3
Disposing of used nickel-cadmium batteries .....	E-4
<b>Battery chargers .....</b>	<b>E-5</b>
<b>Desktop fast charger .....</b>	<b>E-6</b>
Fast charger operation .....	E-6
Using the fast charger .....	E-9
Repairing the fast charger .....	E-10
<b>Desktop trickle charger .....</b>	<b>E-12</b>
Trickle charger operation .....	E-12
Using the trickle charger .....	E-13
Repairing the trickle charger .....	E-13

Troubleshooting .....	E-14
<b>Multi-charger .....</b>	<b>E-15</b>
Multi-charger operation .....	E-15
Repairing the multi-charger .....	E-15
Fuse replacement .....	E-16

## Part F: Accessories

<b>Tait Orca 5000 accessory connector .....</b>	<b>F-3</b>
Screw head types .....	F-3
Connecting an accessory .....	F-3
Connecting a headset .....	F-5
Accessory connector signal descriptions .....	F-6
<b>7.5 mm Accessory adaptor .....</b>	<b>F-8</b>
<b>Tait Orca vehicle kit .....</b>	<b>F-10</b>
Product codes .....	F-10
Update to the vehicle kit .....	F-10
Installing a vehicle kit .....	F-10
Vehicle kit operation .....	F-10
Vehicle kit specifications .....	F-12
Servicing the vehicle kit .....	F-13
Spares kits .....	F-14
Vehicle kit spares kit (TOPA-SP-301).....	F-15
Vehicle kit reskinning kit (TOPA-SP-302).....	F-16
Custom modifications .....	F-17
Vehicle kit circuit descriptions .....	F-19

## Part G: Additional information

<b>Glossary .....</b>	<b>G-3</b>
<b>Accessory connector compatibility .....</b>	<b>G-8</b>