



**Tait Orca 5000 Handportable Radios
Service Manual**

**Issue 03
September 2001**

IPN: M5000-00-102

Preface

Enquiries and Comments

If you have any enquiries regarding this manual, or any comments, suggestions and notifications of errors, please contact Customer Support, Tait Electronics Ltd, Christchurch, New Zealand. Refer to <http://www.taitworld.com/> for more information.

Disclaimer

There are no warranties extended or granted by this manual. Tait Electronics Ltd accepts no responsibility for damage arising from use of the information contained in the manual or of the equipment and software it describes. It is the responsibility of the user to ensure that use of such information, equipment and software complies with the laws, rules and regulations of the applicable jurisdictions.

Updating Equipment And Manuals

In the interests of improving performance, reliability or servicing, Tait Electronics Ltd reserve the right to update their equipment and/or manuals without prior notice.

Copyright

All information contained in this manual is the property of Tait Electronics Ltd. All rights are reserved. This manual may not, in whole or in part, be copied, photocopied, reproduced, translated, stored, or reduced to any electronic medium or machine-readable form, without prior written permission from Tait Electronics Limited. All trade names referenced are the service mark, trademark or registered trademark of the respective manufacturers.

Publication History

Issue	Publication Date	Product Code	Description
01	May 2001	M5000-00-100	First revision.
02	June 2001	M5000-00-101	New revision and cover.
03	September 2001	M5000-00-102	New revision (Section E).

Contacting Tait Electronics Ltd

To contact your nearest Tait Electronics regional office, refer to the Tait Website: <http://www.taitworld.com/>

Contents

Part A: Introduction

Servicing Tait Orca 5000 handportables	A-3
WWW technical support	A-3
What does this manual contain?	A-3
What is included in the calibration service kit?	A-3
Programming kit	A-4
Conventions	A-4
The Tait Orca 5000 series of handportables	A-5
The Tait Product Code Scheme	A-5
Operating instructions	A-6
Accessories	A-6
Important information	A-10
Basic servicing precautions	A-10
Programming	A-10
Calibrating	A-11
Test facilities	A-11
Basic maintenance	A-11

Part B: Radio specifications and circuit descriptions

Radio specifications	B-3
General specifications	B-3
Receiver performance	B-3
Transmitter performance	B-4
Tait Orca 5000 66-88MHz. Conventional and Trunked Radio Specifications	B-5
Tait Orca 5000 136-174MHz. Conventional and Trunked Radio Specifications	B-6
Tait Orca 5000 174-225MHz. Conventional and Trunked Radio Specifications	B-7
Tait Orca 5000 336-400MHz. Conventional and Trunked Radio Specifications	B-8
Tait Orca 5000 400-470MHz. Conventional and Trunked Radio Specifications	B-9
Tait Orca 5000 450-530MHz. Conventional and Trunked Radio Specifications	B-10
Tait Orca 5000 806-870MHz. Conventional and Trunked Radio Specifications	B-11
Tait Orca 5000 896-941MHz. Conventional and Trunked Radio Specifications	B-12

Circuit descriptionsB-13

- Transmitter B-13
- Transmit (Tx) audio B-13
- Receiver B-13
- Receive (Rx) audio B-13
- Synthesiser and VCO B-14
- Power supplies B-14
- Accessory connector interface B-15
- Universal band versus wideband IF filtering B-15

Part C: Diagnostics and fault finding

Test facilitiesC-3

- Error codes C-3
- Test commands..... C-5
- Calculating the parameters required for test command 101 C-7

Fault finding chartsC-8

- Fault finding – Radio cannot be switched on C-9
- Fault finding – Cannot change channel C-10
- Fault finding – No serial communication C-11
- Fault finding – Receive faults C-12
- Fault finding – Cannot transmit C-13
- Fault finding – No transmit audio C-14

Part D: Servicing the radio

Servicing the radio D-3

- Screw head types D-3

Disassembling the radio D-4

- Removing the front panel from the chassis D-4
- Removing the shield sub-assembly from the chassis D-5
- Removing the PCB from the chassis D-6
- Removing the rear panel D-7

Replacing key mechanical and ancillary devices D-8

- Replacing the lens (Orca 5020, Orca 5035 and Orca 5040) D-8
- Replacing the PTT keypad D-8
- Replacing the speaker D-9
- Replacing the LCD display (Orca 5020, Orca 5035 and Orca 5040) D-9

Replacing the shield, user interface PCB assembly and polyester dome (Orca 5020, Orca 5035 and Orca 5040)	D-12
Replacing the antenna connector, channel selector switch and volume control switch	D-12
Replacing the microphone	D-12
Replacing the battery and speaker contacts	D-12
Replacing the tact switch	D-12
Reassembling the radio	D-13
Rear panel reassembly and replacing the auxiliary flexible PCB	D-13
Fitting the PCB to the chassis and replacing the RF out assembly	D-14
Fitting the shield to the chassis	D-14
Fitting the front panel to the chassis	D-15
Spares kits	D-16
Orca 5010/5030 spares kit (TOPA-SP-401)	D-17
Orca 5035 spares kit (TOPA-SP-402).....	D-18
Orca 5020/5040 spares kit (TOPA-SP-403)	D-19
Orca 5010/5030 Re-skinning kit (TOPA-SP-404).....	D-20
Orca 5035 Re-skinning kit (TOPA-SP-405).....	D-20
Orca 5020/5040 Re-skinning kit (TOPA-SP-406).....	D-20
Orca 5020/5035/5040 User Interface PCB and Shield (TOPA-SP-407).....	D-20

Part E: Battery packs and chargers

Battery packs	E-3
Battery shift life	E-3
Disposing of used nickel-cadmium batteries	E-4
Battery chargers	E-5
Desktop fast charger	E-6
Fast charger operation	E-6
Using the fast charger	E-9
Repairing the fast charger	E-10
Desktop trickle charger	E-12
Trickle charger operation	E-12
Using the trickle charger	E-13
Repairing the trickle charger	E-13
Troubleshooting	E-14

Multi-charger E-15
 Multi-charger operation E-15
 Repairing the multi-charger E-15
 Fuse replacement E-16

Part F: Accessories

Tait Orca 5000 Accessory Connector F-3
 Connecting an Accessory F-3
 Connecting a Headset F-6
 Accessory Connector Signal Descriptions F-7

7.5 mm Accessory Adaptor F-9

Tait Orca Vehicle Kit F-11
 Product Codes F-11
 Installing a Vehicle Kit F-11
 Vehicle Kit Operation F-11
 Vehicle Kit Specifications F-13
 Servicing the Vehicle Kit F-14
 Spares Kits F-15
 Vehicle kit spares kit (TOPA-SP-301)..... F-16
 Vehicle kit reskinning kit (TOPA-SP-302)..... F-17
 Custom Modifications F-18
 Vehicle Kit Circuit Descriptions F-20

Part G: Additional information

Glossary G-3
Tait Electronics Limited Software Licence Agreement G-7

PART **A** Introduction

This part provides an introduction to servicing Tait Orca 5000 handportables. It includes an outline of the Tait Orca 5000 handportable range of products and precautions that should be taken before servicing Tait Orca 5000 handportables.

Detailed servicing instructions and information about spare parts are found in *Part D: Servicing the radio*.

Contents

Servicing Tait Orca 5000 handportables	A-3
WWW technical support	A-3
What does this manual contain?	A-3
What is included in the calibration service kit?	A-3
Programming kit	A-4
Conventions	A-4
The Tait Orca 5000 series of handportables	A-5
Product codes	A-5
The Tait Orca Product Naming Convention	A-5
Operating Instructions	A-6
Accessories	A-6
Important information	A-11
Basic servicing precautions	A-11
Programming	A-11
Calibrating	A-11
Test facilities	A-11
Basic maintenance	A-12